

AIRCRAFT TECHNICAL SUPPORT CAPLIST		
Part Number	Description	Manufacturer
130377	Solenoid	Samm
774217	Oil Cooler	Pratt
7584221	Oil Filter	PTI
7586890	Oil Filter	PTI
201374001	MLG	Messier
0008-1-000-9	Water Heater	Inventum
002000AA000NC9A	Air Filter	Sofrance
002002AA000NC9A	Air Filter	Sofrance
00-200-497	Thermocouple	Messier-Bugatti
003-001-001	Junction Probe	Parker Hannifin
003-001-002	Junction Probe	Parker Hannifin
003-001-003	Junction Probe	Parker Hannifin
003-001-004	Junction Probe	Parker Hannifin
003-001-005	Junction Probe	Parker Hannifin
003-001-006	Junction Probe	Parker Hannifin
003-001-007	Junction Probe	Parker Hannifin
00855-501	Ball Screw	Skytronics
0091520200-2	Valve	Essex Industries
0102AH2AG	Sensor	Rosemount Aerospace
0102JE2FG	Sensor	Rosemount Aerospace
0102KFP01	Fueling Control Panel	Smiths Industries
0102LA2AG	Sensor	Rosemount Aerospace
0103KFP01	Fueling Control Panel	Smiths Industries
0103KFP02	Fueling Control Panel	Smiths Industries
0103KFP03	Fueling Control Panel	Smiths Industries
010-57354-1	Hydraulic Servovalve	Moog
011260-500	Air Extraction Fan	EG & Rotron
01-149	Pressure Module	Kennco Magnaghi
011494-500	Recirculation Fan	EG & Rotron
011800AA0006C9A	Hydraulic Filter	Sofrance
011800AA000GC9A	Hydraulic Filter	Sofrance
011802AA000JC6A	Hydraulic Filter	Sofrance
011803AA000JC6A	LP Filter	Sofrance
011803AA000JC6B	LP Filter	Sofrance
01-200-102	Encoding Altimeter	Smiths Industries
01-200-103	Encoding Altimeter	Smiths Industries
01-200-104	Encoding Altimeter	Smiths Industries
01-200-105	Encoding Altimeter	Smiths Industries
01-200-106	Encoding Altimeter	Smiths Industries
0123FA2	Low Flow Detector	Rosemount
012N8330-25	Tee Gearbox assy	Boeing
012N8330-26	Tee Gearbox assy	Boeing
012N8330-27	Angle Gearbox assy	Boeing
012N8366-3	PDU Gearbox assy	Boeing
012N8366-4	PDU Gearbox assy	Boeing
012N8366-5	PDU Gearbox assy	Boeing
012N8366-6	PDU Gearbox assy	Boeing
012N8366-7	PDU Gearbox assy	Boeing
012N8706-10	Gearbox assy	Boeing
012N8706-11	Gearbox assy	Boeing
012N8706-12	Gearbox assy	Boeing
012N8706-13	Gearbox assy	Boeing
012N8706-14	Gearbox assy	Boeing
012N8706-15	Gearbox assy	Boeing

Repair_Capability_List_Excel

012N8706-7	Gearbox assy	Boeing
012N8706-8	Gearbox assy	Boeing
012N8706-9	Gearbox assy	Boeing
0154ED	Total Press & Temp Inlet Probe	Rosemount
0154ED2	Total Press & Temp Inlet Probe	Rosemount
0154EW2	CIT/P25 Probe	Rosemount
0154EW3	CIT/P25 Probe	Rosemount
0154EW4-1	CIT/P25 Probe	Rosemount
015T0070-4	Rud.Ctrl Feel & Trim Offset Torque Tube	Boeing
015T0070-5	Rud.Ctrl Feel & Trim Offset Torque Tube	Boeing
015T0070-6	Rud.Ctrl Feel & Trim Offset Torque Tube	Boeing
015T0094-15	Control Stand Thrust Lever	Boeing
015T0094-16	Control Stand Thrust Lever	Boeing
015T0156-2	Control Stand Thrust Lever	Boeing
015T0253-6	Aileron Control Force transducer Drum	Boeing
015T0253-7	Aileron Control Load Limiter Drum	Boeing
015T0253-8	Aileron Control Load Limiter Drum	Boeing
015T0253-9	Aileron Control Force transducer Drum	Boeing
015T0255-4	Lock ay	Goodrich
015T0255-5	Lock ay	Goodrich
015T0255-8	Lock ay	Goodrich
0171520100-3	NLG Priority Valve assy	Essex
019-012-001	Hyd. Qty Transmitter	Parker Aerospace
019-012-002	Hyd. Qty Transmitter	Parker Aerospace
019-012-003	Hyd. Qty Transmitter	Parker Aerospace
019-028-001	Transmitter	Parker Aerospace
0208KTU01	Fuel Quantity Tank Probe	Smiths Industries
0208KTU02	Fuel Quantity Tank Probe	Smiths Industries
0208KTU03	Fuel Quantity Tank Probe	Smiths Industries
0208KTU04	Fuel Quantity Tank Probe	Smiths Industries
0208KTU05	Fuel Quantity Tank Probe	Smiths Industries
0209KTU01	Fuel Tank Quantity Units	Smiths Industries
0209KTU02	Fuel Tank Quantity Units	Smiths Industries
0209KTU03	Fuel Tank Quantity Units	Smiths Industries
0209KTU04	Fuel Tank Quantity Units	Smiths Industries
0209KTU05	Fuel Tank Quantity Units	Smiths Industries
0209KTU06	Fuel Tank Quantity Units	Smiths Industries
0209KTU07	Fuel Tank Quantity Units	Smiths Industries
0209KTU09	Fuel Tank Quantity Units	Smiths Industries
0209KTU10	Fuel Tank Quantity Units	Smiths Industries
0210KTU01	Fuel Tank Quantity Units	Smiths Industries
021169	Fan Blower assy	Rotron
0212KTU01	Fuel Probe Quantity	Smiths Industries
0212KTU02	Fuel Probe Quantity	Smiths Industries
0212KTU03	Fuel Probe Quantity	Smiths Industries
0212KTU04	Fuel Probe Quantity	Smiths Industries
0212KTU05	Fuel Probe Quantity	Smiths Industries
0212KTU06	Fuel Probe Quantity	Smiths Industries
0212KTU07	Fuel Probe Quantity	Smiths Industries
0212KTU08	Fuel Probe Quantity	Smiths Industries
0212KTU09	Fuel Probe Quantity	Smiths Industries
0212KTU10	Fuel Probe Quantity	Smiths Industries
0212KTU11	Fuel Probe Quantity	Smiths Industries
0212KTU13	Fuel Probe Quantity	Smiths Industries
0212KTU14	Fuel Probe Quantity	Smiths Industries
0212KTU15	Fuel Probe Quantity	Smiths Industries
0212KTU16	Fuel Probe Quantity	Smiths Industries
0212KTU17	Fuel Probe Quantity	Smiths Industries

Repair_Capability_List_Excel

0212KTU20	Fuel Probe Quantity	Smiths Industries
0212KTU21	Fuel Probe Quantity	Smiths Industries
0218-0032-1	Drain Valve	Kaiser Electroprecision
0270KTU01	Fuel Tank Quantity Units	Smiths Industries
0270KTU02	Fuel Tank Quantity Units	Smiths Industries
02733015-1	Flood Light	Devore Aviation
02733015-2	Flood Light	Devore Aviation
02733015-3	Flood Light	Devore Aviation
02733015-4	Flood Light	Devore Aviation
02833008-21	Logo Light	Devore Aviation
02833008-22	Logo Light	Devore Aviation
02833008-521	Logo Light	Devore Aviation
02833008-522	Logo Light	Devore Aviation
02833020-1	Lamp Holder assy	Devore Aviation
02833020-2	Lamp Holder assy	Devore Aviation
02833020-3	Lamp Holder assy	Devore Aviation
02833020-4	Lamp Holder assy	Devore Aviation
0302KLM2	Fuel Quantity Probe Harness	Intertechnique
0314KLM03	Fuel Quantity Probe Harness	Intertechnique
0314KLM04	Fuel Quantity Probe Harness	Intertechnique
0335707270	Engine Breakout Harness	Hamilton Sundstrand
0335708100	Engine Breakout Harness	Hamilton Sundstrand
0335708140	Engine Breakout Harness	Hamilton Sundstrand
0335905020	Fuel Control Pump assy	Hamilton Sundstrand
0335905030	Fuel Control Pump assy	Hamilton Sundstrand
0335908010	Fuel Control Pump assy	Hamilton Sundstrand
0335908020	Fuel Control Pump assy	Hamilton Sundstrand
033638	Fan assy Blower	EG & G Rotron
034100AA000PC0A	Filter assy	Sofrance
035182	Blower assy	EG & G Rotron
035369500	Fan	Ametek
03P75-1	Switch Valve	Honeywell
03P75-2	Switch Valve	Honeywell
03P75-3	Switch Valve	Honeywell
0401KFP01-002	Fuel Control Panel	Smiths Industries
0402KFP01-001	Fuel Control Panel	Smiths Industries
0440KMA CP/2	MACH/EAS Switch	Smiths Industries
0440KMB CP/1	MACH/EAS Switch	Smiths Industries
0440KMB CP/2	MACH/EAS Switch	Smiths Industries
04P23-1	Pneumatic Solenoid Air Valve	Honeywell
04P23-10	Pneumatic Solenoid Air Valve	Honeywell
04P23-11	Pneumatic Solenoid Air Valve	Honeywell
04P23-12	Pneumatic Solenoid Air Valve	Honeywell
04P23-4	Pneumatic Solenoid Air Valve	Honeywell
04P23-5	Pneumatic Solenoid Air Valve	Honeywell
04P23-6	Pneumatic Solenoid Air Valve	Honeywell
04P23-7	Pneumatic Solenoid Air Valve	Honeywell
04P23-8	Pneumatic Solenoid Air Valve	Honeywell
04P23-9	Pneumatic Solenoid Air Valve	Honeywell
0501147-05	Cable Tension Regulator	Pacific Scientific
0501147-1	Cable Tension Regulator	Pacific Scientific
0501148-07	Elevator Tension Regulator	Pacific Scientific
0501148-1	Cable Tension Regulator	Pacific Scientific
0555-11	D.C. Motor	Menasco Aerospace
058-001-00	Rotary Switch	IEC Electronique
058-002-01	Rotary Switch	IEC Electronique
058-002-03	Rotary Switch	IEC Electronique
058-003-00	Rotary Switch	IEC Electronique

Repair_Capability_List_Excel

058-013-00	Rotary Switch	IEC Electronique
058-014-00	Rotary Switch	IEC Electronique
058-015-00	Rotary Switch	IEC Electronique
058-016-00	Rotary Switch	IEC Electronique
058-019-00	Rotary Switch	IEC Electronique
05939-10	Cabin Light Ballast	Bruce Industries
05939-103	Cabin Light Ballast	Bruce Industries
05939-104	Cabin Light Ballast	Bruce Industries
05939-105	Cabin Light Ballast	Bruce Industries
05939-107	Cabin Light Ballast	Bruce Industries
05939-108	Cabin Light Ballast	Bruce Industries
05939-109	Cabin Light Ballast	Bruce Industries
05939-110	Cabin Light Ballast	Bruce Industries
05939-113	Cabin Light Ballast	Bruce Industries
05939-114	Cabin Light Ballast	Bruce Industries
05939-115	Cabin Light Ballast	Bruce Industries
05939-116	Cabin Light Ballast	Bruce Industries
05939-13	Cabin Light Ballast	Bruce Industries
05939-14	Cabin Light Ballast	Bruce Industries
05939-15	Cabin Light Ballast	Bruce Industries
05939-16	Cabin Light Ballast	Bruce Industries
05939-3	Cabin Light Ballast	Bruce Industries
05939-4	Cabin Light Ballast	Bruce Industries
05939-5	Cabin Light Ballast	Bruce Industries
05939-7	Cabin Light Ballast	Bruce Industries
05939-8	Cabin Light Ballast	Bruce Industries
05939-9	Cabin Light Ballast	Bruce Industries
064-01016-0003	HF Control Unit	Thales Avionics
064-1047-00	VHF Comm Transceiver	Chelton
064-1047-01	VHF Comm Transceiver	Chelton
064-1047-02	VHF Comm Transceiver	Chelton
064-1047-32	VHF Comm Transceiver	Chelton
065-50001-0100	Command Sensor Unit	Honeywell
065-50001-0200	Command Sensor Unit	Honeywell
066-1056-01	ATC Transponder	Honeywell
066-1103-00	ATC Transponder	Chelton
066-1105-00	ADF Receiver	Chelton
066-1107-00	DME Transceiver	Chelton
066-50001-1101	Vertical Speed Indicator	Honeywell
071-01438-0202	Radar Control Panel	Thales Avionics
071-1341-16	VHF Comm Control Panel	Chelton
0711346-003	Thrust Reverser Valve	Arkwin Industries
071-1347-16	ADF Control Display	Chelton
071-1350-00	DME Control Panel	Chelton
071-1350-01	DME Control Panel	Chelton
071-1350-02	DME Control Panel	Chelton
071-1350-03	DME Control Panel	Chelton
071-1350-04	DME Control Panel	Chelton
071-1377-00	VHF Navigation Control Panel	Chelton
0725175	Refuel Coupling	FR Hitemp
0725185	Refuel Coupling	FR Hitemp
0727510	Refuel Cap Coupling	FR Hitemp
0727540	Refuel Cap Coupling	FR Hitemp
07311P000-01	Ballscrew assy	Umbrac Cuscinetti
07311P000-02	Ballscrew assy	Umbrac Cuscinetti
07312P000-01	Ballscrew assy	Umbrac Cuscinetti
07313P000-01	Ballscrew assy	Umbrac Cuscinetti
07314P000-01	Ballscrew assy	Umbrac Cuscinetti

Repair_Capability_List_Excel

07322P000-01	Ballscrew assy	Umbr Cuscinetti
07322P000-02	Ballscrew assy	Umbr Cuscinetti
07322P000-03	Ballscrew assy	Umbr Cuscinetti
07323P000-01	Ballscrew assy	Umbr Cuscinetti
07324P000-01	Ballscrew assy	Umbr Cuscinetti
07325P000-01	Ballscrew assy	Umbr Cuscinetti
07387P000-1	Ballscrew assy	Umbr Cuscinetti
07388P000-1	Actuator	Umbr Cuscinetti
07P95-1	Engine Pneumatic Relay Valve	Honeywell
07P95-2	Engine Pneumatic Relay Valve	Honeywell
07P95-3	Engine Pneumatic Relay Valve	Honeywell
07P95-4	Engine Pneumatic Relay Valve	Honeywell
07P95-7	Engine Pneumatic Relay Valve	Honeywell
07P95-8	Engine Pneumatic Relay Valve	Honeywell
0801801-1	First Observer Seat	Castle Ind.
0801801-10	First Observer Seat	Castle Ind.
0801801-11	First Observer Seat	Castle Ind.
0801801-12	First Observer Seat	Castle Ind.
0801801-2	First Observer Seat	Castle Ind.
0801801-3	First Observer Seat	Castle Ind.
0801801-4	First Observer Seat	Castle Ind.
0801801-5	First Observer Seat	Castle Ind.
0801801-6	First Observer Seat	Castle Ind.
0801801-7	First Observer Seat	Castle Ind.
0801801-8	First Observer Seat	Castle Ind.
0801801-9	First Observer Seat	Castle Ind.
080-20288-01	Transformer assy	Oeco
080-20325-01	Transformer Rectifier	Oeco Corporation
080-20705-01	Transformer assy	Oeco
081940-2	Ball Transfer Unit	Goodrich
081940-4	Ball Transfer Unit	Goodrich
0851JA	Probe Pitot	Rosemount Aerospace
085225-04645	Accumulator	Olaer Industries
0856AE18	Probe Pitot	Rosemount Aerospace
0856AE19	Probe Pitot	Rosemount Aerospace
0856LU1	Probe assy	Goodrich
0856LU2	Probe assy	Goodrich
0856LU3	Probe assy	Goodrich
0856LU4	Probe assy	Goodrich
0856LU5	Probe assy	Goodrich
0856LU6	Probe assy	Goodrich
0856PD1	Pitot Static Tube	Rosemount
0856PD3	Pitot Static Tube	Rosemount
0856PF1	Pitot Static Tube	Rosemount
0856PF2	Pitot Static Tube	Rosemount
0856PF3	Pitot Static Tube	Rosemount
0856PF4	Pitot Static Tube	Rosemount
0856PJ2	Pitot Static Tube	Rosemount
0856PJ4	Pitot Static Tube	Rosemount
085878-04645	Accumulator	Olaer Industries
0861CAG	AOA Transmitter	Rosemount Aerospace
0861CAS3	Sensor	Rosemount Aerospace
0861DD10	AOA Sensor	Rosemount
0861DD6	AOA Sensor	Rosemount
0861DL	AOA Sensor	Rosemount
0861DR	AOA Sensor	Rosemount
0861ED	AOA Sensor	Rosemount Aerospace
0861FL	AOA Sensor	Rosemount

Repair_Capability_List_Excel

0861FL1	AOA Sensor	Rosemount
086339-04645	Accumulator	Olaer Industries
0871BN3-10	Ice Detector	Rosemount Aerospace
0871BN3-2	Ice Detector	Rosemount Aerospace
0871BN3-3	Ice Detector	Rosemount Aerospace
0871BN3-4	Ice Detector	Rosemount Aerospace
0871BN3-5	Ice Detector	Rosemount Aerospace
0871BN3-6	Ice Detector	Rosemount Aerospace
0871BN3-8	Ice Detector	Rosemount Aerospace
0871DF1	Ice Detector	Rosemount
0871DF1-1	Ice Detector	Rosemount Aerospace
0871DL	Ice Detector	Rosemount Aerospace
0871DL1	Ice Detector	Rosemount Aerospace
0871DL4	Ice Detector	Rosemount Aerospace
0871DL5	Ice Detector	Rosemount Aerospace
0871DL6	Ice Detector	Rosemount Aerospace
0871DP3	Ice Detector	Rosemount Aerospace
0871DP4	Ice Detector	Rosemount Aerospace
088256-04644	Accumulator	Olaer Industries
088259-04644	Accumulator	Olaer Industries
08SM137D	Servomotor	Honeywell
09000-43220	Filler Cap w/ Relief Valve	Fokker Aircraft
09000-43240	Filler Cap w/ Relief Valve	Fokker Aircraft
09000-43280	Filler Cap w/ Relief Valve	Fokker Aircraft
09053YA01	MLG Swivel	Dowty Aerospace
09055YA01	MLG Swivel	Dowty Aerospace
09056YA01	MLG Swivel	Dowty Aerospace
09057YA01	MLG Drag Stay	Dowty Aerospace
09059YA01	Swivel	Dowty Aerospace
09060YA01	Swivel	Dowty Aerospace
09061YA01	Upper Swivel Coupling	Dowty Aerospace
09062YA01	Upper Swivel Coupling	Dowty Aerospace
09063YA01	Uplock Unit	Dowty Aerospace
093084-22488	Quantity Indicator	Simmonds Precision
093084-22825	Quantity Indicator	Simmonds Precision
094B0000-01	Actuator	Goodrich Control Systems
097-023-00	Rudder Trim Control Selector	IEC Electronique
097-023-01	Rudder Trim Control Selector	IEC Electronique
098C00160	Valve	Mitsubishi
098C00210	Uplock Sequence Valve assy	Mitsubishi
098C-00210	Uplock Sequence Valve assy	Mitsubishi
100000-60	Linear Actuator	Eaton
10-0027-1	Passenger Reading Light	Grimes Aerospace
10-0027-11	Passenger Reading Light	Grimes Aerospace
10-0027-13	Passenger Reading Light	Grimes Aerospace
10-0027-15	Passenger Reading Light	Grimes Aerospace
10-0027-17	Passenger Reading Light	Grimes Aerospace
10-0027-19	Passenger Reading Light	Grimes Aerospace
10-0027-21	Passenger Reading Light	Grimes Aerospace
10-0027-23	Passenger Reading Light	Grimes Aerospace
10-0027-3	Passenger Reading Light	Grimes Aerospace
10-0027-35	Passenger Reading Light	Grimes Aerospace
10-0027-39	Passenger Reading Light	Grimes Aerospace
10-0027-41	Passenger Reading Light	Grimes Aerospace
10-0027-43	Passenger Reading Light	Grimes Aerospace
10-0027-49	Passenger Reading Light	Grimes Aerospace
10-0027-5	Passenger Reading Light	Grimes Aerospace
10-0027-51	Passenger Reading Light	Grimes Aerospace

Repair_Capability_List_Excel

10-0027-55	Passenger Reading Light	Grimes Aerospace
10-0027-59	Passenger Reading Light	Grimes Aerospace
10-0027-7	Passenger Reading Light	Grimes Aerospace
10-0027-9	Passenger Reading Light	Grimes Aerospace
10-0031-15	Threshold Light	Grimes Aerospace
10-0035-1	Stairway Tread Light	Grimes Aerospace
10-0035-2	Stairway Tread Light	Grimes Aerospace
10-0055-1	Emergency Exit Light	Grimes Aerospace
10-0055-11	Emergency Exit Light	Grimes Aerospace
10-0055-13	Emergency Exit Light	Grimes Aerospace
10-0055-15	Emergency Exit Light	Grimes Aerospace
10-0055-17	Emergency Exit Light	Grimes Aerospace
10-0055-19	Emergency Exit Light	Grimes Aerospace
10-0055-21	Emergency Exit Light	Grimes Aerospace
10-0055-23	Emergency Exit Light	Grimes Aerospace
10-0055-25	Emergency Exit Light	Grimes Aerospace
10-0055-3	Emergency Exit Light	Grimes Aerospace
10-0055-5	Emergency Exit Light	Grimes Aerospace
10-0055-7	Emergency Exit Light	Grimes Aerospace
1000649	Anti-Ice Valve	Hamilton Sundstrand
10-0067-7	Emergency Exit Light	Grimes Aerospace
10-0067-9	Emergency Exit Light	Grimes Aerospace
1-001-0102-0026	Static Inverter	Avionic Instruments
1-001-0102-0027	Static Inverter	Avionic Instruments
1-001-0102-0028	Static Inverter	Avionic Instruments
1-001-0102-0029	Static Inverter	Avionic Instruments
1-001-0102-0033	Static Inverter	Avionic Instruments
1-001-0102-0038	Static Inverter	Avionic Instruments
1-001-0102-0039	Static Inverter	Avionic Instruments
1-001-0102-0041	Static Inverter	Avionic Instruments
1-001-0102-0042	Static Inverter	Avionic Instruments
1-001-0102-0046	Static Inverter	Avionic Instruments
1-001-0102-0047	Static Inverter	Avionic Instruments
1-001-0102-0048	Static Inverter	Avionic Instruments
1-001-0102-0049	Static Inverter	Avionic Instruments
1-001-0102-0051	Static Inverter	Avionic Instruments
1-001-0102-0052	Static Inverter	Avionic Instruments
1-001-0102-0057	Static Inverter	Avionic Instruments
1-001-0102-0081	Static Converter	Avionic Instruments
1-001-0102-0083	Static Inverter	Avionic Instruments
1-001-0102-0084	Static Inverter	Avionic Instruments
1-001-0102-0085	Static Inverter	Avionic Instruments
1-001-0102-0087	Static Converter	Avionic Instruments
1-001-0102-0088	Static Converter	Avionic Instruments
1-001-0102-0089	Static Converter	Avionic Instruments
1-001-0102-0090	Static Converter	Avionic Instruments
1-001-0102-0296	Static Inverter	Avionic Instruments
1-001-0102-1001	Static Inverter	Avionic Instruments
1-001-0102-1008	Static Inverter	Avionic Instruments
10-0101-1	Aft Airstairs Spotlight	Grimes Aerospace
10-0113-3	Passenger Reading Light	Grimes Aerospace
10-0119-1	Emergency Exit Light	Grimes Aerospace
10-0119-3	Emergency Exit Light	Grimes Aerospace
100-12062Y00	Pressure Module	Microtecnica
1001250	Low Limit By-Pass Valve	Hamilton Sundstrand
1001251-1	Ram Air Valve	Hamilton Sundstrand
1001252	Conditioned Air Check Valve	Hamilton Sundstrand
1001253	Torque Motor Control	Hamilton Sundstrand

Repair_Capability_List_Excel

1001254-1	Gasper Shut-Off Valve	Hamilton Sundstrand
1001479	Electrical Linear actuator	Hamilton Sundstrand
1001479-2	Electrical Linear actuator	Hamilton Sundstrand
1001497	Cargo Compartment Valve	Hamilton Sundstrand
1001541	Temperature Sensor	Hamilton Sundstrand
1001541-1	Temperature Sensor	Hamilton Sundstrand
1001657-1	Condenser/Reheater Heat Exchanger	Hamilton Sundstrand
1001658	Water Collector	Hamilton Sundstrand
1001778-2	Avionics Compartment Flow Sensor	Hamilton Sundstrand
1001778-3	Avionics Compartment Flow Sensor	Hamilton Sundstrand
1-002-0102-0265	Static Inverter	Avionic Instrument
1-002-0102-0317	Static Inverter	Avionic Instruments
1-002-0102-0461	Static Converter	Avionic Instruments
1-002-0102-0714	Static Converter	Avionic Instruments
1-002-0102-0752	Static Converter	Avionic Instruments
1-002-0102-0788	Light Dimmer	Avionic Instruments
1-002-0102-1000	Static Converter	Avionic Instruments
1-002-0102-1001	Static Inverter	Avionic Instruments
1-002-0102-1008	Static Inverter	Avionic Instruments
1-002-0102-2060	Static Converter	Avionic Instruments
1-002-0102-2061	Static Converter	Avionic Instruments
1-002-0102-2062	Static Converter	Avionic Instruments
1-002-0103TB20	Static Converter	Avionic Instruments
1002165	Precooler	Hamilton Sundstrand
1002166	Fan Air Valve	Hamilton Sundstrand
1002166-1	Fan Air Valve	Hamilton Sundstrand
1002167	Ram Air Inlet Check Valve	Hamilton Sundstrand
1002167-1	Ram Air Inlet Check Valve	Hamilton Sundstrand
1002302-1	Smoke Detector	Hamilton Sundstrand
1002391	Gage Pressure Sensor	Hamilton Sundstrand
1002391-1	Gage Pressure Sensor	Hamilton Sundstrand
10-0331-1	Passenger Warning Light	Grimes Aerospace
10-0331-101	Passenger Warning Light	Grimes Aerospace
10-0331-109	Passenger Warning Light	Grimes Aerospace
10-0331-117	Passenger Warning Light	Grimes Aerospace
10-0331-125	Passenger Warning Light	Grimes Aerospace
10-0331-133	Passenger Warning Light	Grimes Aerospace
10-0331-149	Passenger Warning Light	Grimes Aerospace
10-0331-157	Passenger Warning Light	Grimes Aerospace
10-0331-165	Passenger Warning Light	Grimes Aerospace
10-0331-173	Passenger Warning Light	Grimes Aerospace
10-0331-177	Passenger Warning Light	Grimes Aerospace
10-0331-181	Passenger Warning Light	Grimes Aerospace
10-0331-185	Passenger Warning Light	Grimes Aerospace
10-0331-189	Passenger Warning Light	Grimes Aerospace
10-0331-193	Passenger Warning Light	Grimes Aerospace
10-0331-197	Passenger Warning Light	Grimes Aerospace
10-0331-201	Passenger Warning Light	Grimes Aerospace
10-0331-205	Passenger Warning Light	Grimes Aerospace
10-0331-209	Passenger Warning Light	Grimes Aerospace
10-0331-213	Passenger Warning Light	Grimes Aerospace
10-0331-217	Passenger Warning Light	Grimes Aerospace
10-0331-221	Passenger Warning Light	Grimes Aerospace
10-0331-225	Passenger Warning Light	Grimes Aerospace
10-0331-229	Passenger Warning Light	Grimes Aerospace
10-0331-233	Passenger Warning Light	Grimes Aerospace
10-0331-237	Passenger Warning Light	Grimes Aerospace
10-0331-241	Passenger Warning Light	Grimes Aerospace

Repair_Capability_List_Excel

10-0331-245	Passenger Warning Light	Grimes Aerospace
10-0331-249	Passenger Warning Light	Grimes Aerospace
10-0331-253	Passenger Warning Light	Grimes Aerospace
10-0331-261	Passenger Warning Light	Grimes Aerospace
10-0331-265	Passenger Warning Light	Grimes Aerospace
10-0331-273	Passenger Warning Light	Grimes Aerospace
10-0331-281	Passenger Warning Light	Grimes Aerospace
10-0331-289	Passenger Warning Light	Grimes Aerospace
10-0331-293	Passenger Warning Light	Grimes Aerospace
10-0331-301	Passenger Warning Light	Grimes Aerospace
10-0331-305	Passenger Warning Light	Grimes Aerospace
10-0331-313	Passenger Warning Light	Grimes Aerospace
10-0331-317	Passenger Warning Light	Grimes Aerospace
10-0331-325	Passenger Warning Light	Grimes Aerospace
10-0331-329	Passenger Warning Light	Grimes Aerospace
10-0331-33	Passenger Warning Light	Grimes Aerospace
10-0331-333	Passenger Warning Light	Grimes Aerospace
10-0331-341	Passenger Warning Light	Grimes Aerospace
10-0331-345	Passenger Warning Light	Grimes Aerospace
10-0331-353	Passenger Warning Light	Grimes Aerospace
10-0331-357	Passenger Warning Light	Grimes Aerospace
10-0331-365	Passenger Warning Light	Grimes Aerospace
10-0331-369	Passenger Warning Light	Grimes Aerospace
10-0331-37	Passenger Warning Light	Grimes Aerospace
10-0331-377	Passenger Warning Light	Grimes Aerospace
10-0331-381	Passenger Warning Light	Grimes Aerospace
10-0331-387	Passenger Warning Light	Grimes Aerospace
10-0331-389	Passenger Warning Light	Grimes Aerospace
10-0331-393	Passenger Warning Light	Grimes Aerospace
10-0331-395	Passenger Warning Light	Grimes Aerospace
10-0331-399	Passenger Warning Light	Grimes Aerospace
10-0331-401	Passenger Warning Light	Grimes Aerospace
10-0331-405	Passenger Warning Light	Grimes Aerospace
10-0331-407	Passenger Warning Light	Grimes Aerospace
10-0331-41	Passenger Warning Light	Grimes Aerospace
10-0331-413	Passenger Warning Light	Grimes Aerospace
10-0331-417	Passenger Warning Light	Grimes Aerospace
10-0331-45	Passenger Warning Light	Grimes Aerospace
10-0331-49	Passenger Warning Light	Grimes Aerospace
10-0331-53	Passenger Warning Light	Grimes Aerospace
10-0331-57	Passenger Warning Light	Grimes Aerospace
10-0331-61	Passenger Warning Light	Grimes Aerospace
10-0331-69	Passenger Warning Light	Grimes Aerospace
10-0331-77	Passenger Warning Light	Grimes Aerospace
10-0331-85	Passenger Warning Light	Grimes Aerospace
10-0331-93	Passenger Warning Light	Grimes Aerospace
1003520	Water Collector	Hamilton Sundstrand
100-367-00	Rotary Switch	IEC Electronique
100-4125Y00	Hydraulic Reservoir	Microtecnica
10050-3	Limit Mech.	Hoover Industries
1005080-12-1	Pressure Reducing Valve	Moog
1005080-14	Valve	Bendix/King
10051-0000-01	Indicator	Goodrich Corporation
10-0512-3	Cross Aisle Dome Light	Grimes Aerospace
10-0512-5	Cross Aisle Dome Light	Grimes Aerospace
10-0512-7	Cross Aisle Dome Light	Grimes Aerospace
10-0513-3	Valance Sidewall Light	Grimes Aerospace
10-0519-11	Emergency Light	Hella

Repair_Capability_List_Excel

10-0519-5	Emergency Light	Hella
10-0519-7	Emergency Light	Hella
10-0519-9	Emergency Light	Hella
10-0590-1	Beverage Bar Light	Grimes Aerospace
10-0590-3	Beverage Bar Light	Grimes Aerospace
100-601177-000	Engine Rating Select Panel	Canadian Marconi
100-601177-001	Engine Rating Select Panel	Canadian Marconi
100-601177-002	Engine Rating Select Panel	Canadian Marconi
100-601177-003	Engine Rating Select Panel	Canadian Marconi
100-6094Y00	Accumulator	Microtecnica
10-0688-1	Floodlight	Grimes Aerospace
10-0688-11	Floodlight	Grimes Aerospace
10-0688-13	Floodlight	Grimes Aerospace
10-0688-15	Floodlight	Grimes Aerospace
10-0688-17	Floodlight	Grimes Aerospace
10-0688-19	Floodlight	Grimes Aerospace
10-0688-21	Floodlight	Grimes Aerospace
10-0688-23	Floodlight	Grimes Aerospace
10-0688-25	Floodlight	Grimes Aerospace
10-0688-27	Floodlight	Grimes Aerospace
10-0688-29	Floodlight	Grimes Aerospace
10-0688-3	Floodlight	Grimes Aerospace
10-0688-5	Floodlight	Grimes Aerospace
10-0688-7	Floodlight	Grimes Aerospace
10-0688-9	Floodlight	Grimes Aerospace
100-689-4	Pump	Delaval
10079-01	Fuel Qty Indic.Load Selector	Simmonds Precision
1007A0000-02	Brake Wing Tip	Goodrich Control Systems
1007A0000-03	Brake Wing Tip	Goodrich Control Systems
1007A0000-04	Brake Wing Tip	Liebherr Aerotechnik
1007A0000-05	Brake Wing Tip	Goodrich Control Systems
1007A0000-06	Brake Wing Tip	Goodrich Control Systems
1007B0000-01	Brake Wing Tip	Goodrich Control Systems
100800-1	Actuator	Eaton
100-833-1	Switch	Great
1008520-10	Pressure Relief Valve	Moog
1008520-7-2	Valve	Bendix/King
1008520-9	Pressure Relief Valve	Moog
10087-0101	Indicator	BF Goodrich
10087-0102	Indicator	BF Goodrich
10088-0101	Preselector	BF Goodrich
10088-0102	Preselector	BF Goodrich
1008A0100-01	Shaft assy APPU	Liebherr Aerotechnik
100CC01A	Single Pole Contactor	ECE
100CC01A02	Single Pole Contactor	ECE
101005-03	Solenoid	Puritan Bennett
10100N01Y00	Hydraulic Quantity Indicator	Ametek
10100N02Y00	Hydraulic Quantity Indicator	Ametek
10101000BC	Waste Drain Valve	Shaw Aero
10101000CK	Drain Valve	Shaw Aero Devices
101050A1	Fuel Deicing Valve	Colt Industries
101050A2	Fuel Deicing Valve	Colt Industries
101050A3	Fuel Deicing Valve	Colt Industries
101050A4	Fuel Deicing Valve	Colt Industries
101050A5	Fuel Deicing Valve	Colt Industries
10-1078-1	Int Illuminated Exit Sign	Grimes Aerospace
10-1110-1	Emergency Exit Sign	Grimes Aerospace
10-1110-11	Emergency Exit Sign	Grimes Aerospace

Repair_Capability_List_Excel

10-1110-13	Emergency Exit Sign	Grimes Aerospace
10-1110-15	Emergency Exit Sign	Grimes Aerospace
10-1110-17	Emergency Exit Sign	Grimes Aerospace
10-1110-19	Emergency Exit Sign	Grimes Aerospace
10-1110-21	Emergency Exit Sign	Grimes Aerospace
10-1110-23	Emergency Exit Sign	Grimes Aerospace
10-1110-25	Emergency Exit Sign	Grimes Aerospace
10-1110-27	Emergency Exit Sign	Grimes Aerospace
10-1110-29	Emergency Exit Sign	Grimes Aerospace
10-1110-3	Emergency Exit Sign	Grimes Aerospace
10-1110-31	Emergency Exit Sign	Grimes Aerospace
10-1110-33	Emergency Exit Sign	Grimes Aerospace
10-1110-35	Emergency Exit Sign	Grimes Aerospace
10-1110-37	Emergency Exit Sign	Grimes Aerospace
10-1110-39	Emergency Exit Sign	Grimes Aerospace
10-1110-41	Emergency Exit Sign	Grimes Aerospace
1011104-2	Accumulator	Bendix/King
10-1110-43	Emergency Exit Sign	Grimes Aerospace
10-1110-5	Emergency Exit Sign	Grimes Aerospace
10-1110-7	Emergency Exit Sign	Grimes Aerospace
10-1110-9	Emergency Exit Sign	Grimes Aerospace
10-111150-1	Ignition Unit	Bendix/King
10-111150-2	Ignition Unit	Bendix/King
10-111150-3	Ignition Unit	Bendix/King
10-111150-6	Ignition Unit	Bendix/King
10-111160-1	Ignition Unit	Bendix/King
10-111160-3	Ignition Unit	Bendix/King
10-111160-6	Ignition Unit	Bendix/King
10-1119-1	Dome Light	Grimes Aerospace
10-1119-11	Dome Light	Grimes Aerospace
10-1119-3	Dome Light	Grimes Aerospace
10-1119-5	Dome Light	Grimes Aerospace
10-1119-7	Dome Light	Grimes Aerospace
10-1119-9	Dome Light	Grimes Aerospace
1011362	Pressure Relief Valve	Moog
10-1178-1	Passenger Service Unit	Grimes Aerospace
10-1178-11	Passenger Service Unit	Grimes Aerospace
10-1178-11M	Passenger Service Unit	Grimes Aerospace
10-1178-12	Passenger Service Unit	Grimes Aerospace
10-1178-12M	Passenger Service Unit	Grimes Aerospace
10-1178-13	Passenger Service Unit	Grimes Aerospace
10-1178-13M	Passenger Service Unit	Grimes Aerospace
10-1178-14	Passenger Service Unit	Grimes Aerospace
10-1178-14M	Passenger Service Unit	Grimes Aerospace
10-1178-1M	Passenger Service Unit	Grimes Aerospace
10-1178-2	Passenger Service Unit	Grimes Aerospace
10-1178-23	Passenger Service Unit	Grimes Aerospace
10-1178-23M	Passenger Service Unit	Grimes Aerospace
10-1178-24	Passenger Service Unit	Grimes Aerospace
10-1178-24M	Passenger Service Unit	Grimes Aerospace
10-1178-25	Passenger Service Unit	Grimes Aerospace
10-1178-25M	Passenger Service Unit	Grimes Aerospace
10-1178-26	Passenger Service Unit	Grimes Aerospace
10-1178-26M	Passenger Service Unit	Grimes Aerospace
10-1178-2M	Passenger Service Unit	Grimes Aerospace
10-1178-3	Passenger Service Unit	Grimes Aerospace
10-1178-31	Passenger Service Unit	Grimes Aerospace
10-1178-32	Passenger Service Unit	Grimes Aerospace

Repair_Capability_List_Excel

10-1178-33	Passenger Service Unit	Grimes Aerospace
10-1178-34	Passenger Service Unit	Grimes Aerospace
10-1178-35	Passenger Service Unit	Grimes Aerospace
10-1178-36	Passenger Service Unit	Grimes Aerospace
10-1178-37	Passenger Service Unit	Grimes Aerospace
10-1178-38	Passenger Service Unit	Grimes Aerospace
10-1178-39	Passenger Service Unit	Grimes Aerospace
10-1178-3M	Passenger Service Unit	Grimes Aerospace
10-1178-4	Passenger Service Unit	Grimes Aerospace
10-1178-40	Passenger Service Unit	Grimes Aerospace
10-1178-41	Passenger Service Unit	Grimes Aerospace
10-1178-42	Passenger Service Unit	Grimes Aerospace
10-1178-43	Passenger Service Unit	Grimes Aerospace
10-1178-45	Passenger Service Unit	Grimes Aerospace
10-1178-47	Passenger Service Unit	Grimes Aerospace
10-1178-49	Passenger Service Unit	Grimes Aerospace
10-1178-4M	Passenger Service Unit	Grimes Aerospace
10-1178-51	Passenger Service Unit	Grimes Aerospace
10-1178-53	Passenger Service Unit	Grimes Aerospace
10-1178-55	Passenger Service Unit	Grimes Aerospace
10-1178-57	Passenger Service Unit	Grimes Aerospace
10-1178-59	Passenger Service Unit	Grimes Aerospace
10-1178-61	Passenger Service Unit	Grimes Aerospace
10-1178-63	Passenger Service Unit	Grimes Aerospace
10-1178-65	Passenger Service Unit	Grimes Aerospace
10117N01N00	Stabilizer Trim Indicator	Ametek
10-1180-1	Stairway Light	Grimes Aerospace
10-1180-3	Stairway Light	Grimes Aerospace
1011V0200	Solenoid Valve	Grimes Aerospace
1011V0200-2	Solenoid Valve	Grimes Aerospace
10121B01Y01	Hydraulic Qty Interface Module	Ametek
10121B02Y02	Hydraulic Qty Interface Module	Ametek
10-1221-1	Emergency Exit Light	Grimes Aerospace
10-1221-3	Emergency Exit Light	Grimes Aerospace
10-1221-5	Emergency Exit Light	Grimes Aerospace
10-1222-1	Emergency Light	Grimes Aerospace
10-1233-1	Illuminated Exit Sign	Grimes Aerospace
10-1266-1	Cabin Emergency Light	Airsigna GmbH
10-1267-1	Emergency Light	Airsigna GmbH
10-1267-5	Emergency Light	Airsigna GmbH
10-1275-1	Emergency Exit Light	Grimes Aerospace
10-1278-1	Info Sign Housing	Airsigna GmbH
10-1288-1	Emergency Light	Airsigna GmbH
10-1288-7	Emergency Light	Airsigna GmbH
10-1308-1	Emergency Light	Airsigna GmbH
10-1308-3	Emergency Light	Airsigna GmbH
10-1308-5	Emergency Light	Airsigna GmbH
10-1310-1	Emergency Exit Sign assy	Airsigna GmbH
10-1315-1	Lavatory Occupied Sign assy	Airsigna GmbH
10-1315-3	Lavatory Occupied Sign assy	Airsigna GmbH
10-1319-1	Area Call Panel	Airsigna GmbH
10-1319-5	Area Call Panel	Airsigna GmbH
10-1327-1	Light assy	Grimes Aerospace
10-1327-10	Light assy	Grimes Aerospace
10-1327-2	Light assy	Grimes Aerospace
10-1327-3	Light assy	Grimes Aerospace
10-1327-4	Light assy	Grimes Aerospace
10-1327-7	Light assy	Grimes Aerospace

Repair_Capability_List_Excel

10-1327-8	Light assy	Grimes Aerospace
10-1327-9	Light assy	Grimes Aerospace
10-1341-1	Speaker Panel	Grimes Aerospace
10-1341-11	Speaker Panel	Grimes Aerospace
10-1341-13	Speaker Panel	Grimes Aerospace
10-1341-15	Speaker Panel	Grimes Aerospace
10-1341-17	Speaker Panel	Grimes Aerospace
10-1341-21	Speaker Panel	Grimes Aerospace
10-1341-23	Speaker Panel	Grimes Aerospace
10-1341-25	Speaker Panel	Grimes Aerospace
10-1341-27	Speaker Panel	Grimes Aerospace
10-1341-3	Speaker Panel	Grimes Aerospace
10-1342-1	Speaker Panel	Grimes Aerospace
10-1342-11	Speaker Panel	Grimes Aerospace
10-1342-13	Speaker Panel	Grimes Aerospace
10-1342-21	Speaker Panel	Grimes Aerospace
10-1342-23	Speaker Panel	Grimes Aerospace
10-1342-25	Speaker Panel	Grimes Aerospace
10-1342-27	Speaker Panel	Grimes Aerospace
10-1342-3	Speaker Panel	Grimes Aerospace
10-1358-1	Call Light	Airsigna GmbH
10-1358-5	Light	Airsigna GmbH
101-388009-5	Accumulator	Airight
101-389006-11	Actuator	Electro-Mechanical
10138N01M01	Stand-By Engine Indicator	Ametek
101409	Damper assy	.
1014A	Power Unit	Meggitt Safety Systems
10151N01T00	Inner Turbine Temperature Indicator	Ametek
10-1530-1	Passenger Service Unit	Grimes Aerospace
10-1530-2	Passenger Service Unit	Grimes Aerospace
10-1571-1	Passenger Service Unit	Grimes Aerospace
10-1571-2	Passenger Service Unit	Grimes Aerospace
10-1571-3	Passenger Service Unit	Grimes Aerospace
10-1571-4	Passenger Service Unit	Grimes Aerospace
10-1571-5	Passenger Service Unit	Grimes Aerospace
10-1571-6	Passenger Service Unit	Grimes Aerospace
10-1571-7	Passenger Service Unit	Grimes Aerospace
10-1571-8	Passenger Service Unit	Grimes Aerospace
10-1607-1	Cabin Lighting System	Grimes Aerospace
10-1607-11	Cabin Lighting System	Grimes Aerospace
10-1607-1M	Cabin Lighting System	Grimes Aerospace
10-1607-3	Cabin Lighting System	Grimes Aerospace
10-1607-5	Cabin Lighting System	Grimes Aerospace
10-1607-5M	Cabin Lighting System	Grimes Aerospace
10-1607-7	Cabin Lighting System	Grimes Aerospace
10-1607-9	Cabin Lighting System	Grimes Aerospace
10-162650-1	Tachometer	Bendix/King
10-162650-2	Tachometer	Bendix/King
10-162650-3	Tachometer	Bendix/King
10-162650-4	Tachometer	Bendix/King
10-162810-2	Tachometer	Bendix/King
10-162810-3	Tachometer	Bendix/King
10-162950-1	Tachometer	Bendix/King
10-162950-3	Tachometer	Bendix/King
10-162950-6	Tachometer	Bendix/King
10-162950-7	Tachometer	Bendix/King
10166N01N00	Rudder Trim Indicator	Ametek
10167N01W00	Torque Indicator	Ametek

Repair_Capability_List_Excel

10167N02W00	Torque Indicator	Ametek
10168N01T00	ITT Indicator	Ametek
10169N01R00	Prop RPM Indicator	Ametek
10170N01R00	NH % RPM Indicator	Ametek
10171N01F01	Fuel Flow Indicator	Ametek
10-1733-1	Light assy	Grimes Aerospace
10-1733-2	Light assy	Grimes Aerospace
10-1733-3	Light assy	Grimes Aerospace
10-1733-4	Light assy	Grimes Aerospace
10174N01W01	Engine Torque Indicator	Ametek
10174N02W01	Engine Torque Indicator	Ametek
10174N03W02	Engine Torque Indicator	Ametek
10174N04W02	Engine Torque Indicator	Ametek
10174N05W03	Engine Torque Indicator	Ametek
10174N06W03	Engine Torque Indicator	Ametek
10174N07W04	Engine Torque Indicator	Ametek
10174N08W04	Engine Torque Indicator	Ametek
10174N09W05	Engine Torque Indicator	Ametek
10174N10W03	Engine Torque Indicator	Ametek
10175N01T00	ITT Indicator	Ametek
10176N01R00	NL % RPM Indicator	Ametek
10176N02R00	NL % RPM Indicator	Ametek
10177N01R00	NH % RPM Indicator	Ametek
10178N01T01	Static Air Temperature Indicator	Ametek
10178N02T01	Static Air Temperature Indicator	Ametek
101807-06	Low Pressure Gage	Puritan Bennett
101807-07	Indicator	Puritan Bennett
101807-08	Low Pressure Gage	Puritan Bennett
101809	Switch	Puritan Bennett
10181N01R00	Propeller % RPM Indicator	Ametek
10182N01M01	Stand-By Engine Indicator	Ametek
10182N02M01	Stand-By Engine Indicator	Ametek
10182N02M02	Standby Engine Indicator	Ametek
10183N01W01	Torque Indicator	Ametek
10183N02W01	Torque Indicator	Ametek
10183N03W02	Torque Indicator	Ametek
10183N04W02	Torque Indicator	Ametek
10183N05W03	Torque Indicator	Ametek
10192950-15	Tachometer	Bendix/King
10192950-16	Tachometer	Bendix/King
10192950-22	Tachometer	Bendix/King
101ACRBU1	Pressure Indicator	Smiths Industries
101ACRBU12	Pressure Indicator	Smiths Industries
101ACRBU4	Pressure Indicator	Smiths Industries
101ACRBU5	Pressure Indicator	Smiths Industries
101ACRBU6	Pressure Indicator	Smiths Industries
101ACRBU8	Pressure Indicator	Smiths Industries
101ACRCP1	Pressure Indicator	Smiths Industries
101ACRCP10	Pressure Indicator	Smiths Industries
101ACRCP11	Pressure Indicator	Smiths Industries
101ACRCP2	Pressure Indicator	Smiths Industries
101ACRCP7	Pressure Indicator	Smiths Industries
101ACRCP9	Pressure Indicator	Smiths Industries
101CC01A	Single Pole Contactor	ECE
101CC01A02	Single Pole Contactor	ECE
101CZ01Y01	Static Contactor	ECE
102114	Thermometer	Weston Aerospace
102116	Thermometer	Weston Aerospace

Repair_Capability_List_Excel

102130	Thermometer	Weston Aerospace
102134	Thermometer	Weston Aerospace
102138	Thermometer	Weston Aerospace
102182	Position Indicator	Weston Aerospace
102230	Thermometer	Weston Aerospace
10230-A	Air Pressure	Autolite Prod.Philco
102316	Thermocouple	Weston Aerospace
102319	Thermocouple	Weston Aerospace
10232-A	Pressure Gage	Autolite Prod.Philco
102-344-1	Valve	Adel Delaval
102-389012-5	Transmitter	Beechcraft
102526003	Pressure Relief Valve	Messier-Dowty
10260	Cylinder	Weston Aerospace
102650EG	Motor	ITT Aerospace Ctrls
102650EZ	Motor	ITT Aerospace Ctrls
102650J108	Motor	ITT Corporation
102650JE	Motor	ITT Corporation
1027-1	Probe	Avtech Corporation
1027T100-11	Actuator	Telair International
1027T100-13	Actuator	Telair International
1027T100-15	Stairway Actuator	Telair International
1027T100-17	Stairway Actuator	Telair International
1027T100-19	Stairway Actuator	Telair International
1027T100-9	Actuator	Telair International
102842DB	Actuator	ITT Aerospace Ctrls
102842ED	Actuator	ITT Aerospace Ctrls
102842HD	Actuator	ITT Corporation
102842MW	Actuator	ITT Aerospace Ctrls
10287N01T00	TAT Indicator	Ametek
10290N01Y00	Water Qty Indicator	Ametek
1029D100-1	Elect Lock Actuator Power Unit	Eaton
102AH2AF	Total Temperature Sensor	Rosemount Aerospace
102AH2AG	Total Temperature Sensor	Rosemount Aerospace
102AH2AJ	Total Temperature Sensor	Rosemount Aerospace
102CP2AG	Total Temperature Sensor	Rosemount Aerospace
102EH2BH	Total Temperature Sensor	Rosemount Aerospace
102EH2EB	Total Temperature Sensor	Rosemount Aerospace
102EU2BF	Air Temperature Probe	Rosemount Aerospace
102J033-1	Ball Screw assy	Skytronics
102J033-3	Ball Screw assy	Skytronics
102J033-5	Ball Screw assy	Skytronics
102J033-5016243	Ball Screw assy	Skytronics
102J033-5016250	Ball Screw assy	Skytronics
102J177-1	Ball Screw assy	Skytronics
102J177-3	Ball Screw assy	Skytronics
102JE2FG	Total Temperature Sensor	Rosemount Aerospace
102LA2AG	Total Temperature Sensor	Rosemount Aerospace
102LJ2AG	Total Temperature Sensor	Rosemount
10300	Hydraulic Shut-Off Valve	Sterer
103-00034	Temperature Probe	Thales Avionics
10300-10	Hydraulic Shut-Off Valve	Sterer
103106	Thermometer	Weston Aerospace
103107	Thermometer	Weston Aerospace
103-1190	VHF Standby Control Panel	Thales Avionics
103166-422	Cabin Pressure Relief Valve	Honeywell
10-319647-1	Igniter Plug Lead	Bendix/King
10-319648-1	Igniter Plug Lead	Bendix/King
10-319696-1	Igniter Plug Lead	Bendix/King

Repair_Capability_List_Excel

10-319697-1	Igniter Plug Lead	Bendix/King
1031T100-17	Actuator	Telair International
10-3208-1	Selector Valve	Sargent
10-3216-1	Shut-Off Valve assy	Boeing
10-3254	Transformer	Oeco Corporation
10-3269-10	Differential Pressure Switch	Boeing
103280-8	Valve assy	Honeywell
103298-1	Cabin Pressure Relief Valve	Honeywell
103298-2	Cabin Pressure Relief Valve	Honeywell
1033-5-3300	Valve	Pneudraulics Inc
103357	Position Indicator	Weston Aerospace
1034191-0-1	Actuator	Bendix/King
10-352680-1	Cable assy	Unison Industries
10-353875-1	Ignition Exciter	Unison
10-353875-14	IGNITION EXCITER	UNISON
10-353875-2	Ignition Exciter	Unison
10-353875-3	Ignition Exciter	Unison
10-353875-4	Ignition Exciter	Unison
10-357487-241A	Vibrator	Bendix/King
103583001	NLG Undercarriage Jack	Messier-Dowty
103583002	NLG Undercarriage Jack	Messier-Dowty
1035PG	Fuel Pressure Transmitter	Vibrometer
103612001	MLG Undercarriage Jack	Messier-Dowty
103612002	MLG Undercarriage Jack	Messier-Dowty
103636-1	Cabin Pressure Relief Valve	Honeywell
1036400-5	Actuator assy	Honeywell
1036403-3	Actuator assy	Honeywell
103641001	Steering Valve	Messier-Dowty
103641002	Steering Valve	Messier-Dowty
103641003	Steering Valve	Messier-Dowty
103641004	Steering Valve	Messier-Dowty
1036662-1	Actuator assy	Honeywell
1036662-2	Actuator assy	Honeywell
10-374091	Tachymeter Indicator	Bendix/King
10-374095-1	Tachymeter Indicator	Bendix/King
10-374115-1	Ignition Exciter	Bendix/King
103778001	Ejection Jack	Messier-Dowty
10-381160-2	Ignition Exciter	Unison
10-381175-1	Ignition Exciter	Unison
10-381175-10	Ignition Exciter	Unison
10-381175-2	Ignition Exciter	Unison
10-381175-3	Ignition Exciter	Unison
10-381175-4	Ignition Exciter	Unison
10-381175-5	Ignition Exciter	Unison
10-381175-6	Ignition Exciter	Unison
10-381175-7	Ignition Exciter	Unison
10-381175-8	Ignition Exciter	Unison
10-381175-9	Ignition Exciter	Unison
10-381550-4	Ignition Exciter	Bendix/King
10-381550-5	Ignition Exciter	Bendix/King
10-381750	Ignition Exciter	Unison
10-381750-1	Ignition Exciter	Unison
10-381750-10	Ignition Exciter	Unison
10-381750-11	Ignition Exciter	Unison
10-381750-12	Ignition Exciter	Unison
10-381750-13	Ignition Exciter	Unison
10-381750-14	Ignition Exciter	Unison
10-381750-14A	Ignition Exciter	Unison

Repair_Capability_List_Excel

10-381750-2	Ignition Exciter	Unison
10-381750-3	Ignition Exciter	Unison
10-381750-4	Ignition Exciter	Unison
10-381750-5	Ignition Exciter	Unison
10-381750-6	Ignition Exciter	Unison
10-381750-7	Ignition Exciter	Unison
10-381750-8	Ignition Exciter	Unison
10-381750-9	Ignition Exciter	Unison
10-381760-1	Ignition Exciter	Bendix/King
10-383900-12	Ignition Exciter	Bendix/King
10-383900-13	Ignition Exciter	Bendix/King
10-383900-14	Ignition Exciter	Bendix/King
10-383900-15	Ignition Exciter	Bendix/King
10-383900-15B	Ignition Exciter	Bendix/King
10-383900-16	Ignition Exciter	Bendix/King
10-383900-16B	Ignition Exciter	Bendix/King
10-387125-2	Ignition Exciter	Bendix/King
10390A12-1	Spherical Ball Valve	Intertechnique
10-395070-1	Cable assy	Bendix/King
10-395402-1	Ignitor Lead assy	Bendix/King
10-395402-1C	Ignitor Lead assy	Bendix/King
10-397650-1	Ignition Exciter	Bendix/King
1039B25-1	Low Pressure Valve	Intertechnique
104030	Fuel Pump assy	Hamilton Sundstrand
1040B25-1	Crossfeed Valve	Intertechnique
1040T100-5	Actuator	Telair International
104277001	Valve	Messier-Dowty
10434N01R00	NH % RPM Indicator	Ametek
10435N01R00	NL % RPM Indicator	Ametek
10437N01T00	Oil Temperature Indicator	Ametek
1043V0300	By-Pass Valve	Grimes Aerospace
104652001	Cowl Opening Actuator	Messier-Dowty
1046GT2102AY	Boomset	Holmberg
10470	Motor-Driven Hydraulic Pump	Hamilton Sundstrand
10470-1	Motor-Driven Hydraulic Pump	Hamilton Sundstrand
10470-2	Motor-Driven Hydraulic Pump	Hamilton Sundstrand
10470-6	Motor-Driven Hydraulic Pump	Hamilton Sundstrand
104749001	Damper	Messier-Dowty
104749002	Damper	Messier-Dowty
104754-1	Butterfly Valve	Honeywell
1047PG-CP	Oil Low Pressure Warning Switch	Vibrometer
1047PG-SB	Oil Low Pressure Warning Switch	Vibrometer
104822	Solenoid Valve	Honeywell
104908	Butterfly Valve	Honeywell
104908-1	Butterfly Valve	Honeywell
104908-2	Butterfly Valve	Honeywell
104922	Butterfly Valve	Honeywell
104924	Valve	Honeywell
104980	Valve	Honeywell
104992	Butterfly Valve	Honeywell
10499-A	Temperature Indicator	Autolite Prod.Philco
104AMAJA1	Mach Airspeed Indicator	Smiths Industries
104AMAJA2	Mach Airspeed Indicator	Smiths Industries
104AMAJA5	Mach Airspeed Indicator	Smiths Industries
104AMAJA6	Mach Airspeed Indicator	Smiths Industries
10500	Motor Pump	Hamilton Sundstrand
10500-1	Motor Pump	Hamilton Sundstrand
10500-6	Motor Pump	Hamilton Sundstrand

Repair_Capability_List_Excel

105058	Throttling Valve	Honeywell
105058-1	Throttling Valve	Honeywell
105112-300	Valve	Honeywell
10-516000-1	Ignition Exciter	Unison Industries
1051R160	Gearbox	Goodrich Control Systems
1051R195	Gearbox	Goodrich Control Systems
1051T100-23	Actuator	Telair International
1051T100-25	APU Door Actuator	Telair International
1051T100-9	APU Air Actuator	Telair International
105492-11	Valve	Honeywell
105492-300	Valve	Honeywell
105492-8-1.11	Valve	Honeywell
10549N01N00	Stabilizer Trim Indicator	Ametek
105726-1	Shut-Off Valve	Honeywell
105798	Pressure Regulator Valve	Honeywell
1058V0100-1	Valve	Grimes Aerospace
1058V0400-1	Valve	Grimes Aerospace
105976-1	Pneumatic Shut-Off Valve	Honeywell
105978-2	Shut-Off Valve	Honeywell
105978-3	Shut-Off Valve	Honeywell
105980-2	Valve	Honeywell
105982-2	Shut-Off Valve	Honeywell
105984-2	Shut-Off Valve	Honeywell
105986-1	Shut-Off Valve	Honeywell
10600-13	Valve	Honeywell
10-60450-1	Relay	Struthers-Dunn
10-60450-3	Relay	Struthers-Dunn
10-60470-10	VARIABLE HYP PUMP	PARKER
10-60470-11	VARIABLE HYP PUMP	PARKER
10-60470-12	VARIABLE HYP PUMP	PARKER
10-60470-13	VARIABLE HYP PUMP	PARKER
10-60470-3	VARIABLE HYP PUMP	PARKER
10-60470-8	VARIABLE HYP PUMP	PARKER
10-60479-31	Recepticle	TRW
10-60517-41	ENGINE ISOLATOR	BARRY CTLS
10-60517-42	ENGINE ISOLATOR	BARRY CTLS
10-60517-43	ENGINE ISOLATOR	BARRY CTLS
10-60517-44	ENGINE ISOLATOR	BARRY CTLS
10-60517-49	ENGINE ISOLATOR	BARRY CTLS
10-60517-50	ENGINE ISOLATOR	BARRY CTLS
10-60517-56	ENGINE ISOLATOR	BARRY CTLS
10-60518-12	DUAL CONTROL VALVE	CRANE
10-60551-3	Pressure Relief Valve	Pneudraulics Inc
10-60552-41	Pressure Switch	Boeing
10-60552-42	Pressure Switch	Boeing
10-60552-5	Pressure Switch	Boeing
10-60553-3	3-WAY VALVE	SMITHS
10-60757-122	Voltmeter	Wacli
10-60757-23	DC Voltmeter	Boeing
10-60757-26	Wattmeter	Rogerson Kratos
10-60757-27	AC Ammeter	Boeing
10-60757-41	Loadmeter	Boeing
10-60784-5	Fill Water Valve	Allen Aircraft
1060828	Transformer	Elect
10-60927-2	Pressure Switch	Boeing
10-60927-3	Pressure Switch	Boeing
106-1-1100	APU Actuator	Elektro Metall Exp.
106-1-1100-02	APU Actuator	Elektro Metall Exp.

Repair_Capability_List_Excel

10-61312-1	Ball Screw assy	Thomson Saginaw
10-61312-10	Wing Flap Screw	Boeing
10-61312-11	Wing Flap Screw	Boeing
10-61312-12	Ball Screw assy	Thomson Saginaw
10-61312-13	Ball Screw assy	Thomson Saginaw
10-61312-2	Ball Screw assy	Thomson Saginaw
10-61312-3	Ball Screw assy	Thomson Saginaw
10-61312-4	Ball Screw assy	Thomson Saginaw
10-61312-5	Ball Screw assy	Thomson Saginaw
10-61312-6	Ball Screw assy	Thomson Saginaw
10-61312-7	Wing Flap Screw	Boeing
10-61312-8	Wing Flap Screw	Boeing
10-61312-9	Wing Flap Screw	Boeing
10-61348-11	Cable assy	Aero Controlex
10-61348-13	Cable assy	Aero Controlex
10-61348-15	Cable assy	Aero Controlex
10-61348-6	Cable assy	Aero Controlex
10-61348-9	Cable assy	Aero Controlex
10-61458-13	Static Pitot	Rosemount Aerospace
10-617075-5	Ignition Exciter	Unison Industries
10-617075-6	Ignition Exciter	Unison Industries
10-617660-2	Ignition Lead	Unison
10-617660-3	Ignition Lead	Unison
10-617665-1	Ignition Lead	Unison
10-617665-2	Ignition Lead	Unison
10-617665-3	Ignition Lead	Unison
10-617675-1	Ignition Lead	Unison
10-617980-1	Ignition Exciter	Unison Industries
10-617980-1E	Ignition Exciter	Unison
10-61915-101	TEMP INDICATOR	SMITHS
10-61915-102	TEMP INDICATOR	SMITHS
10-62033-2	ROTARY ACTUATOR	GOODRICH
10-62033-3	ROTARY ACTUATOR	GOODRICH
10-62033-4	ROTARY ACTUATOR	GOODRICH
10620N01F01	Fuel Used Indicator	Ametek
10-621630-1	Ignition Exciter	Unison
10-631045-1	Ignition Exciter	Unison
10-631045-1E	Ignition Exciter	Unison
10-631045-2	Ignition Exciter	Unison
10-631045-2A	Ignition Exciter	Unison
10-631045-2B	Ignition Exciter	Unison
106324-2	Valve	Honeywell
106388-3	Shut-Off Valve	Honeywell
106497	Thermometer	Weston Aerospace
106498	Thermometer	Weston Aerospace
106499	Thermometer	Weston Aerospace
106785A-1	Motor	ITT Aerospace Ctrl's
106785A110	Motor	ITT Aerospace Ctrl's
106785A117	Motor	ITT Aerospace Ctrl's
106785B-1	Motor	ITT Aerospace Ctrl's
106785B106	Motor	ITT Aerospace Ctrl's
106785B114	Motor	ITT Aerospace Ctrl's
106785B121	Motor	ITT Aerospace Ctrl's
106788A103	Actuator assy	ITT Aerospace Ctrl's
106788A112	Actuator	ITT Aerospace Ctrl's
106788A128	Actuator assy	ITT Aerospace Ctrl's
106788A131	Actuator assy	ITT Aerospace Ctrl's
106788A140	Actuator assy	ITT Aerospace Ctrl's

Repair_Capability_List_Excel

106788A145	Actuator assy	ITT Aerospace Ctrl
106788A205	Actuator assy	ITT Aerospace Ctrl
106788A206	Actuator assy	ITT Aerospace Ctrl
106788A207	Actuator assy	ITT Aerospace Ctrl
106788A225	Actuator assy	ITT Aerospace Ctrl
106788A225A	Actuator assy	ITT Aerospace Ctrl
106788B153	Actuator assy	ITT Aerospace Ctrl
106788B200	Actuator assy	ITT Aerospace Ctrl
106788B508	Actuator assy	ITT Aerospace Ctrl
106788R127	Actuator assy	ITT Aerospace Ctrl
106788R137	Actuator assy	ITT Aerospace Ctrl
106788R151	Actuator assy	ITT Aerospace Ctrl
106801	Position Indicator	Weston Aerospace
106802	Position Indicator	Weston Aerospace
1068109-2	Actuator	ITT Corporation
1068-2	In Seat Power Supply	Astronics
106892-1-1	Tube Venturi	Honeywell
1068T100-4M	Linear Actuator	Telair International
1068T100-5M	Linear Actuator	Telair International
1068T100-6M	Airstair Handrail	Telair International
106932-1-1	Flow Sensing Valve	Honeywell
106RV	RPM Generator	Vibrometer
106RVSB	Electrical Speed Generator	Vibrometer
10-700335-1	Ignition Exciter	Unison
10-700336-1	Ignition Exciter	Unison
10701-10	Lockout Tab	Menasco Aerospace
10701-11	Lockout Tab	Menasco Aerospace
10701-12	Lockout Tab	Menasco Aerospace
10701-13	Lockout Tab	Menasco Aerospace
10701-14	Aileron Actuator assy	Menasco Aerospace
10701-15	Lockout Tab	Menasco Aerospace
10701-16	Lockout Tab	Menasco Aerospace
10701-17	Lockout Tab	Menasco Aerospace
10701-18	Lockout Tab	Menasco Aerospace
10701-19	Lockout Tab	Menasco Aerospace
10701-20	Lockout Tab	Menasco Aerospace
10701-21	Lockout Tab	Menasco Aerospace
10701-22	Lockout Tab	Menasco Aerospace
10701-23	Lockout Tab	Menasco Aerospace
10701-24	Lockout Tab	Menasco Aerospace
10701-9	Lockout Tab	Menasco Aerospace
107062	Check Valve	Honeywell
1070A0000-02	Flap Actuator	Goodrich Control Systems
1070B0000-01	Flap Actuator	Goodrich Control Systems
1070B0000-02	Flap Actuator	Goodrich Control Systems
1070B0000-03	Flap Actuator	Goodrich Control Systems
1070B0000-04	Flap Actuator	Goodrich Control Systems
1070C0000-01	Flap Actuator	Goodrich Control Systems
107124-1	Valve	.
1071A0000-02	Flap Actuator	Goodrich Control Systems
1071B0000-01	Flap Actuator	Goodrich Control Systems
1071B0000-02	Flap Actuator	Goodrich Control Systems
1071B0000-03	Flap Actuator	Goodrich Control Systems
1071B0000-04	Flap Actuator	Goodrich Control Systems
1071C0000-01	Flap Actuator	Goodrich Control Systems
1071D	Pressure Indicator	Hamilton Standard
107204	Check Valve	Honeywell
107232	Check Valve	Honeywell

Repair_Capability_List_Excel

107234	Check Valve	Honeywell
107234-1	Check Valve	Honeywell
1072A0000-01	Flap Actuator	Goodrich Control Systems
1072A0000-02	Flap Actuator	Goodrich Control Systems
1072A0000-03	Flap Actuator	Goodrich Control Systems
1072A0000-04	Flap Actuator	Goodrich Control Systems
1072C0000-01	Flap Actuator	Goodrich Control Systems
1072D0000-01	Flap Actuator	Goodrich Control Systems
107312	Pneumatic Relay	Honeywell
107312-1	Pneumatic Relay	Honeywell
107312-2	Pneumatic Relay	Honeywell
107312-4	Pneumatic Relay	Honeywell
107312-4-1	Pneumatic Relay	Honeywell
107312-5	Pneumatic Relay	Honeywell
107312-7	Pneumatic Relay	Honeywell
107312-8	Pneumatic Relay	Honeywell
107334-1	Pressure Controller	Honeywell
1073A0000-01	Flap Actuator	Goodrich Control Systems
1073A0000-02	Flap Actuator	Goodrich Control Systems
1073A0000-03	Flap Actuator	Goodrich Control Systems
1073A0000-04	Flap Actuator	Goodrich Control Systems
1073C0000-01	Flap Actuator	Goodrich Control Systems
107416-1	Rate of Change Control Valve	Honeywell
107416-2	Rate of Change Control Valve	Honeywell
107416-2-1	Rate Control Valve	Honeywell
107416-4	Rate of Change Control Valve	Honeywell
107442-3	Valve assy	Honeywell
107474-1	Pressure Regulator	Honeywell
107492-1	Bleed Air Reg	Honeywell
107492-2	Bleed Air Reg	Honeywell
107492-3	Bleed Air Reg	Honeywell
107492-5	Bleed Air Reg	Honeywell
107494-1	Check Valve	Honeywell
107494-2	Check Valve	Honeywell
107494-3	Check Valve	Honeywell
107494-4	Check Valve	Honeywell
1074A0000-01	Flap Actuator	Goodrich Control Systems
1074A0000-02	Flap Actuator	Goodrich Control Systems
1074A0000-03	Flap Actuator	Goodrich Control Systems
1074A0000-04	Flap Actuator	Goodrich Control Systems
1074C0000-01	Flap Actuator	Goodrich Control Systems
10750-10	Lockout Tab	Menasco Aerospace
10750-3	Lockout Tab	Menasco Aerospace
10750-4	Lockout Tab	Menasco Aerospace
10750-5	Lockout Tab	Menasco Aerospace
10750-6	Lockout Tab	Menasco Aerospace
10750-7	Lockout Tab	Menasco Aerospace
10750-8	Lockout Tab	Menasco Aerospace
10750-9	Lockout Tab	Menasco Aerospace
10751-17	Tab Lockout Actuator	Menasco Aerospace
1075-2-1	Standard Outlet assy	Primex
1075-2-2	Standard Outlet assy	Primex
1075-2-3	Standard Outlet assy	Primex
1075-2-4	Standard Outlet assy	Primex
1075-2-5	Standard Outlet assy	Primex
107728A100	Motor	ITT Aerospace Ctrl
107728A105	Motor	ITT Aerospace Ctrl
107729A100	Motor	ITT Aerospace Ctrl

Repair_Capability_List_Excel

107796A113	Actuator assy	ITT Aerospace Ctrl
107796A117	Actuator assy	ITT Aerospace Ctrl
107797A101	Actuator assy	ITT Aerospace Ctrl
107797A102	Actuator	ITT Aerospace Ctrl
107797A103	Actuator	ITT Aerospace Ctrl
107797A104	Actuator	ITT Aerospace Ctrl
107797A108	Actuator	ITT Aerospace Ctrl
1078-200	Pressure Drop Indicator	Messier-Bugatti
107890-15-1	Pneumatic Thermostat	Honeywell
107890-16	Thermostatic Switch	Honeywell
107890-16-1	Pneumatic Thermostat	Honeywell
107890-8	Thermostatic Switch	Honeywell
107890-8-1	Pneumatic Thermostat	Honeywell
1079	Switch	Carri
107954-1-1	Thermostat	Honeywell
107969	Valve	ITT Aerospace Ctrl
107971	Valve	ITT Aerospace Ctrl
107971-1	Valve	ITT Aerospace Ctrl
107996	Pneumatic Thermo Valve	Honeywell
107996-10-1	Pneumatic Thermo Valve	Honeywell
107996-1-1	Pneumatic Thermostat	Honeywell
107996-11-1	Pneumatic Thermo Valve	Honeywell
107996-12-1	Pneumatic Thermostat	Honeywell
107996-13-1	Pneumatic Thermostat	Honeywell
107996-16	Pneumatic Thermo Valve	Honeywell
107996-20-1	Pneumatic Thermostat	Honeywell
107996-22-1	Pneumatic Thermostat	Honeywell
107996-23-1	Pneumatic Thermostat	Honeywell
107996-24-1	Pneumatic Thermostat	Honeywell
107996-25-1	Pneumatic Thermostat	Honeywell
107996-27-1	Pneumatic Thermostat	Honeywell
107996-28-1	Pneumatic Thermostat	Honeywell
107996-30-1	Pneumatic Thermostat	Honeywell
107996-3-1	Pneumatic Thermo Valve	Honeywell
107996-31-1	Pneumatic Thermostat	Honeywell
107996-33-1	Pneumatic Thermostat	Honeywell
107996-34-1	Pneumatic Thermostat	Honeywell
107996-36-1	Pneumatic Thermostat	Honeywell
107996-39-1	Pneumatic Thermostat	Honeywell
107996-40-1	Pneumatic Thermostat	Honeywell
107996-4-1	Pneumatic Thermostat	Honeywell
107996-41-1	Pneumatic Thermostat	Honeywell
107996-42-1	Pneumatic Thermostat	Honeywell
107996-43-1	Pneumatic Thermostat	Honeywell
107996-44-1	Pneumatic Thermostat	Honeywell
107996-50-1	Pneumatic Thermostat	Honeywell
107996-5-1	Pneumatic Thermostat	Honeywell
107996-53-1	Pneumatic Thermostat	Honeywell
107996-56-1	Pneumatic Thermostat	Honeywell
107996-57-1	Pneumatic Thermostat	Honeywell
107996-58-1	Pneumatic Thermostat	Honeywell
107996-59-1	Pneumatic Thermo Valve	Honeywell
107996-61-1	Pneumatic Thermostat	Honeywell
107996-63-1	Pneumatic Thermostat	Honeywell
107996-65-1	Pneumatic Thermostat	Honeywell
107996-66-1	Pneumatic Thermo Valve	Honeywell
107996-67-1	Pneumatic Thermo Valve	Honeywell
107996-68-1	Pneumatic Thermostat	Honeywell

Repair_Capability_List_Excel

107996-72-1	Pneumatic Thermostat	Honeywell
107996-73-1	Pneumatic Thermostat	Honeywell
107996-74-1	Pneumatic Thermostat	Honeywell
107996-75-1	Pneumatic Thermostat	Honeywell
107996-76-1	Pneumatic Thermostat	Honeywell
107996-77-1	Pneumatic Thermostat	Honeywell
107996-78-1	Pneumatic Thermostat	Honeywell
107996-79-1	Pneumatic Thermostat	Honeywell
107996-80-1	Pneumatic Thermostat	Honeywell
107996-8-1	Pneumatic Thermo Valve	Honeywell
107996-81-1	Pneumatic Thermostat	Honeywell
108032-0-39	Press.Regulator Valve	Honeywell
108032-10	Press.Regulator Valve	Honeywell
108032-11	Press.Regulator Valve	Honeywell
108032-12	Press.Regulator Valve	Honeywell
108032-3	Press.Regulator Valve	Honeywell
108032-6	Press.Regulator Valve	Honeywell
108032-8	Press.Regulator Valve	Honeywell
108032-9	Press.Regulator Valve	Honeywell
108082-1	Valve	Honeywell
10810	Vaneaxial Fan assy	Hamilton Sundstrand
10810-1	Vaneaxial Fan assy	Hamilton Sundstrand
108136-1	Pressure Regulator	Honeywell
108136-11	Pressure Regulator	Honeywell
108136-21-3	Pressure Regulator	Honeywell
108136-22-1	Pressure Regulator	Honeywell
108136-25-1	Pressure Regulator	Honeywell
108136-26-1	Pressure Regulator	Honeywell
108260	Thermometer	Weston Aerospace
108261	Thermometer	Weston Aerospace
10835-15	Monitor	Dynamic Ctls Corporation
108420	Regulator	Honeywell
108525	Transmitter	Weston Aerospace
108528	Pressure Regulator	Honeywell
108605	Valve	Whittaker
108736-760-2	Pressure Regulator	Honeywell
108740-380-3	Pressure Regulator	Honeywell
108742-2	Regulator	Honeywell
108808-7-1	Pressure Regulator	Honeywell
108808-8-1	Pressure Regulator	Honeywell
108940-760	Pressure Regulator	Honeywell
10900-11	Lift Dumper Actuator	Menasco Aerospace
10900-19	Lift Dumper Actuator	Menasco Aerospace
10900-7	Actuator	Menasco Aerospace
10900-9	Lift Dumper Actuator	Menasco Aerospace
1091A0000-01	Water Injector	Liebherr Aerotechnik
109300-1	Turbine assy	Fairchild
109300-16	Drive Pneumatic Turbine	Fairchild
109300-18	Drive Pneumatic Turbine	Fairchild
109300-20	Drive Pneumatic Turbine	Fairchild
109365	Valve	Whittaker
109382-11-1	Butterfly Valve	Honeywell
109382-13-1	Butterfly Valve	Honeywell
109382-15-1	Butterfly Valve	Honeywell
109382-17-1	Butterfly Valve	Honeywell
109382-25-1	Butterfly Valve	Honeywell
109382-26-1	Butterfly Valve	Honeywell
109382-27-1	Butterfly Valve	Honeywell

Repair_Capability_List_Excel

109382-28-1	Butterfly Valve	Honeywell
109382-30-1	Butterfly Valve	Honeywell
109382-31-1	Butterfly Valve	Honeywell
109382-32-1	Butterfly Valve	Honeywell
109382-33-1	Butterfly Valve	Honeywell
109382-34-1	Butterfly Valve	Honeywell
109382-35-1	Butterfly Valve	Honeywell
109382-36-1	Butterfly Valve	Honeywell
109382-7-1	Butterfly Valve	Honeywell
109478-4-1	Shut-Off Valve	Honeywell
109478-6-1	Shut-Off Valve	Honeywell
109486-1-1	Pneumatic Shut-off Valve	Honeywell
109486-4-1	Pneumatic Shut-off Valve	Honeywell
109486-5-1	Pneumatic Shut-off Valve	Honeywell
109486-6-1	Pneumatic Shut-off Valve	Honeywell
109486-7	Pneumatic Shut-off Valve	Honeywell
109486-7-1	Pneumatic Shut-off Valve	Honeywell
109486-8	Pneumatic Shut-off Valve	Honeywell
10951-11	Lift Dumper Manifold assy	Menasco Aerospace
10951-13	Lift Dumper Manifold assy	Menasco Aerospace
10951-15	Lift Dumper Manifold assy	Menasco Aerospace
10951-17	Lift Dumper Manifold assy	Menasco Aerospace
10951-19	Lift Dumper Manifold assy	Menasco Aerospace
10951-23	Lift Dumper Manifold assy	Menasco Aerospace
10951-7	Lift Dumper Manifold assy	Menasco Aerospace
10951-9	Lift Dumper Manifold assy	Menasco Aerospace
109522-1-1	Linear Pneumatic Actuator	Honeywell
109522-2-1	Linear Pneumatic Actuator	Honeywell
109523-1	Linear Pneumatic Actuator	Honeywell
109523-2	Linear Pneumatic Actuator	Honeywell
1095732	Latching Contactor	Intertechnique
109580-5	Pneumatic Lock Ram Actuator	Honeywell
109580-6	Pneumatic Lock Ram Actuator	Honeywell
109612-3	Shut-Off Butterfly Valve ay	Honeywell
109644-1-1	Shut-Off Valve	Honeywell
109644-2-1	Shut-Off Valve	Honeywell
109644-3-1	Shut-Off Valve	Honeywell
109644-6-1	Shut-Off Valve	Honeywell
109646-10-1	Butterfly Valve	Honeywell
109646-1-1	Butterfly Valve	Honeywell
109646-2-1	Butterfly Valve	Honeywell
109646-3-1	Butterfly Valve	Honeywell
109646-4-1	Butterfly Valve	Honeywell
109646-5-1	Butterfly Valve	Honeywell
109646-6-1	Butterfly Valve	Honeywell
109646-7-1	Butterfly Valve	Honeywell
109646-9-1	Butterfly Valve	Honeywell
109654-3	Pneumatic Lock Ram Actuator	Honeywell
109700-3	Pressure Regulating Valve	Honeywell
109700-6	Pressure Regulating Valve	Honeywell
109700-7	Pressure Regulating Valve	Honeywell
109802-10-1	Butterfly Valve	Honeywell
109802-1-1	Butterfly Valve	Honeywell
109802-2-1	Butterfly Valve	Honeywell
109802-3-1	Butterfly Valve	Honeywell
109802-4-1	Butterfly Valve	Honeywell
109802-5-1	Butterfly Valve	Honeywell
109802-6-1	Butterfly Valve	Honeywell

Repair_Capability_List_Excel

109802-7-1	Butterfly Valve	Honeywell
109802-9-1	Butterfly Valve	Honeywell
109804-1-1	Butterfly Shut-Off Valve	Honeywell
109804-2-1	Butterfly Shut-Off Valve	Honeywell
109804-3-1	Butterfly Shut-Off Valve	Honeywell
109804-4-1	Butterfly Shut-Off Valve	Honeywell
109804-6-1	Butterfly Shut-Off Valve	Honeywell
109804-7-1	Butterfly Shut-Off Valve	Honeywell
1098-1	In-Seat Power Supply	Primex
109812-1	Butterfly Shut-Off Valve	Honeywell
109812-10	Butterfly Shut-Off Valve	Honeywell
109812-11	Butterfly Shut-Off Valve	Honeywell
109812-1-1	Butterfly Shut-Off Valve	Honeywell
109812-12	Butterfly Shut-Off Valve	Honeywell
109812-13	Butterfly Shut-Off Valve	Honeywell
109812-14	Butterfly Shut-Off Valve	Honeywell
109812-3	Butterfly Shut-Off Valve	Honeywell
109812-3-1	Butterfly Shut-Off Valve	Honeywell
109812-5	Butterfly Shut-Off Valve	Honeywell
109812-5-1	Butterfly Shut-Off Valve	Honeywell
109812-6	Butterfly Shut-Off Valve	Honeywell
109812-6-1	Butterfly Shut-Off Valve	Honeywell
109812-7	Butterfly Shut-Off Valve	Honeywell
109812-7-1	Butterfly Shut-Off Valve	Honeywell
109812-8	Butterfly Shut-Off Valve	Honeywell
109812-9	Butterfly Shut-Off Valve	Honeywell
109820-10-1	Pneumatic Valve	Honeywell
109820-1-1	Pneumatic Valve	Honeywell
109820-2-1	Pneumatic Valve	Honeywell
109820-3-1	Pneumatic Valve	Honeywell
109820-4-1	Pneumatic Valve	Honeywell
109820-5	Pneumatic Valve	Honeywell
109820-5-1	Pneumatic Valve	Honeywell
109820-6-1	Pneumatic Valve	Honeywell
109820-7-1	Pneumatic Valve	Honeywell
109820-9-1	Pneumatic Valve	Honeywell
1099-1	In-Seat Power Supply	Primex
10MZ4306000-10	Servo-Control Spoiler Actuator	Liebherr Aerospace
11002-11	Solenoid	Menasco Aerospace
11002-9	Solenoid	Menasco Aerospace
11010	Actuator	Menasco Aerospace
11010-19	Swing Gate Actuator	Menasco Aerospace
11010-21	Swing Gate Actuator	Menasco Aerospace
11010-23	Swing Gate Actuator	Menasco Aerospace
11010-25	Swing Gate Actuator	Menasco Aerospace
110111-14	Test Port assy	Puritan Bennett
1102-11	Solenoid	Menasco Aerospace
11-0283-2	Emergency Exit Light	Grimes Aerospace
11-0283-3	Emergency Exit Light	Grimes Aerospace
11-0283-5	Emergency Exit Light	Grimes Aerospace
11-0283-6	Emergency Exit Light	Grimes Aerospace
11-0283-7	Emergency Exit Light	Grimes Aerospace
1102V0500	Secondary Flow Control Valve	Honeywell
1102V0500-4	Secondary Flow Control Valve	Honeywell
1102V0500-5	Secondary Flow Control Valve	Honeywell
1102V0500-7	Secondary Flow Control Valve	Honeywell
1102V1000	Secondary Flow Control Valve	Honeywell
1102V1100	Secondary Flow Control Valve	Honeywell

Repair_Capability_List_Excel

1103080-100	Seat Electronic Box	Hughes-Avicom
1103P0702	Pressure Switch	ITT Corporation
1103P10	Anti-Icing Overpressure Switch	ITT Aerospace Ctrl's
110430	Thermocouple	Weston Aerospace
11045-11	Shut-Off Valve	Menasco Aerospace
11045-3	Shut-Off Manifold	Menasco Aerospace
11045-5	Shut-Off Manifold	Menasco Aerospace
11045-7	Shut-Off Manifold	Menasco Aerospace
11045-9	Shut-Off Valve	Menasco Aerospace
110507	Thermocouple	Weston Aerospace
1105123-1	Actuator	Smiths Industries
1105P117	Switch	ITT Corporation
1106A0000-01	Solenoid Valve	Liebherr Aerotechnik
11080-1	Spring Strut	Menasco Aerospace
1108V0100	Pneumatic Solenoid Valve	Grimes Aerospace
1108V0100-1	Pneumatic Solenoid Valve	Grimes Aerospace
1108V0100-2	Pneumatic Solenoid Valve	Grimes Aerospace
1109V0300	Pneumatic Solenoid Valve	Grimes Aerospace
1109V0300-1	Pneumatic Solenoid Valve	Grimes Aerospace
1109V0300-2	Pneumatic Solenoid Valve	Grimes Aerospace
110DB28	Pressure Relief Valve	FR Hitemp
110DD30	Non-Return Valve	FR Hitemp
110M2	Pressure Relief Valve	FR Hitemp
110M21	Valve assy	FR Hitemp
110M81	Non-Return Valve	FR Hitemp
110M8-1	Valve assy	FR Hitemp
110VU01-62004	Fan assy	Etri
11100-1039AA	Horizontal Stabilizer Control Unit	Menasco Aerospace
11100-1039AAA	Horizontal Stabilizer Control Unit	Menasco Aerospace
11100-1039AAA1	Horizontal Stabilizer Control Unit	Menasco Aerospace
11100-1039AAA3	Horizontal Stabilizer Control Unit	Menasco Aerospace
11100-1039AAA5	Horizontal Stabilizer Control Unit	Menasco Aerospace
11100-1040A	Horizontal Stabilizer Control Unit	Menasco Aerospace
11100-1041	Horizontal Stabilizer Control Unit	Menasco Aerospace
11100-1041A	Horizontal Stabilizer Control Unit	Menasco Aerospace
11100-1041A1	Horizontal Stabilizer Control Unit	Menasco Aerospace
11100-1041A3	Horizontal Stabilizer Control Unit	Menasco Aerospace
11100-1041A5	Horizontal Stabilizer Control Unit	Menasco Aerospace
11100-1042A	Horizontal Stabilizer Control Unit	Menasco Aerospace
11100-1043	Horizontal Stabilizer Control Unit	Menasco Aerospace
11100-1043A	Horizontal Stabilizer Control Unit	Menasco Aerospace
11100-1043A3	Horizontal Stabilizer Control Unit	Menasco Aerospace
11100-1043A5	Horizontal Stabilizer Control Unit	Menasco Aerospace
11100-1045	Horizontal Stabilizer Control Unit	Menasco Aerospace
11100-1045A	Horizontal Stabilizer Control Unit	Menasco Aerospace
11100-33	Horizontal Stabilizer Control Unit	Menasco Aerospace
11100-35	Horizontal Stabilizer Control Unit	Menasco Aerospace
11100-39	Horizontal Stabilizer Control Unit	Menasco Aerospace
11100-39AA	Horizontal Stabilizer Control Unit	Menasco Aerospace
11100-39AAA	Horizontal Stabilizer Control Unit	Menasco Aerospace
11100-39AAA1	Horizontal Stabilizer Control Unit	Menasco Aerospace
11100-39AAA3	Horizontal Stabilizer Control Unit	Menasco Aerospace
11100-39AAA5	Horizontal Stabilizer Control Unit	Menasco Aerospace
11100-40A	Horizontal Stabilizer Control Unit	Menasco Aerospace
11100-41	Horizontal Stabilizer Control Unit	Menasco Aerospace
11100-41A	Horizontal Stabilizer Control Unit	Menasco Aerospace
11100-41A1	Horizontal Stabilizer Control Unit	Menasco Aerospace
11100-41A3	Horizontal Stabilizer Control Unit	Menasco Aerospace

Repair_Capability_List_Excel

11100-41A5	Horizontal Stabilizer Control Unit	Menasco Aerospace
11100-42A	Horizontal Stabilizer Control Unit	Menasco Aerospace
11100-43	Horizontal Stabilizer Control Unit	Menasco Aerospace
11100-43A	Horizontal Stabilizer Control Unit	Menasco Aerospace
11100-43A1	Horizontal Stabilizer Control Unit	Menasco Aerospace
11100-43A3	Horizontal Stabilizer Control Unit	Menasco Aerospace
11100-43A-3	Horizontal Stabilizer Control Unit	Menasco Aerospace
11100-43A5	Horizontal Stabilizer Control Unit	Menasco Aerospace
11100-44A	Horizontal Stabilizer Control Unit	Menasco Aerospace
11100-45	Horizontal Stabilizer Control Unit	Menasco Aerospace
11100-45A	Horizontal Stabilizer Control Unit	Menasco Aerospace
11100-45A1	Horizontal Stabilizer Control Unit	Menasco Aerospace
11100-45A3	Horizontal Stabilizer Control Unit	Menasco Aerospace
11100-45A5	Horizontal Stabilizer Control Unit	Menasco Aerospace
1110V0500-1	Cooling Valve	Grimes Aerospace
1110V0500-2	Cooling Valve	Grimes Aerospace
1110V0500-3	Cooling Valve	Grimes Aerospace
1110V0500-4	Cooling Valve	Grimes Aerospace
1110V0500-5	Cooling Valve	Grimes Aerospace
1110V0500-6	Cooling Valve	Grimes Aerospace
111100-3	YZ Latch	Telair International
1-111-0102-0714	Static Inverter	Avionic Instruments
111-1-1100	Pressure Switch	Elektro Metall Exp.
1111-517710	Swing Check Valve	Parker Hannifin
1111-555219	Check Valve	Parker Aerospace
1111-565110	Fuel Check Valve	Parker Hannifin
1111-565528	Check Valve	Parker Hannifin
1111-568084	Check Valve	Parker Hannifin
1111-568267	Check Valve	Parker Hannifin
1111-577098M1	Check Valve	Parker Aerospace
1111-577401	Check Valve	Parker Hannifin
1111-588311	Check Valve	Parker Hannifin
1111A0000-01	Solenoid Valve	Liebherr Aerotechnik
1112-565277	Check Valve	Parker Hannifin
1112-565277M1	Check Valve	Parker Hannifin
11-1368-3	Valve assy	National Airmotive Corp
11-1460-8	Valve	Parker-Republic
1115V0300	Bleed Air Valve	Honeywell
1115V0300-1	Bleed Air Valve	Honeywell
1115V0300-5	Bleed Air Valve	Honeywell
1115V0300-6	Bleed Air Valve	Honeywell
1115V0700	Bleed Air Valve	Honeywell
1115V0700-10	Bleed Air Valve	Honeywell
1115V0700-4	Bleed Air Valve	Grimes Aerospace
1115V0700-5	Bleed Air Valve	Grimes Aerospace
1115V0700-6	Bleed Air Valve	Honeywell
1115V0700-7	Bleed Air Valve	Honeywell
1115V0700-8	Bleed Air Valve	Honeywell
1115V0700-9	Bleed Air Valve	Honeywell
111601	Position Indicator	Weston Aerospace
111602	Position Indicator	Weston Aerospace
111624-1	Stabilizer Trim Ball Screw assy	Skytronics
111624-501	Stabilizer Trim Ball Screw assy	Skytronics
111624-503	Stabilizer Trim Ball Screw assy	Skytronics
111624-509	Stabilizer Trim Ball Screw assy	Skytronics
111624-511	Stabilizer Trim Ball Screw assy	Skytronics
111624-513	Stabilizer Trim Ball Screw assy	Skytronics
111624-515	Stabilizer Trim Ball Screw assy	Skytronics

Repair_Capability_List_Excel

111624-517	Stabilizer Trim Ball Screw assy	Skytronics
111815	Valve	Whittaker
111CC01A02	Single Pole Contactor	ECE
111CZ01Y01	Static Contactor	ECE
111RAA3	Actuator assy	Smiths Industries
1121	Thermocouple	Weston Aerospace
11210-1	Speed Brake Actuator	Menasco
11210-11	Speed Brake Actuator	Menasco
11210-13	Speed Brake Actuator	Menasco
11210-3	Speed Brake Actuator	Menasco
11210-5	Speed Brake Actuator	Menasco
11210-7	Speed Brake Actuator	Menasco
11210-9	Speedbrake Actuator	Menasco Aerospace
112-1-1100	Pressure Switch	Elektro Metall Exp.
1122696	Temperature Transducer	Goodrich
112-303	Impeller & Motor assy	Hamilton Sundstrand
112-304	Impeller & Motor assy	Hamilton Sundstrand
112-507-02	Scroll Housing assy	Hamilton Sundstrand
112-507-03	Scroll Housing assy	Hamilton Sundstrand
112-509-02	Valve	Hamilton Sundstrand
11290-1	Valve	Hamilton Sundstrand
11290-2	Valve	Hamilton Sundstrand
11307-4	Relief Valve	Perkin Elmer
113149	Actuator	Whittaker
1134-014	Indicator	Rogerson Kratos
1-1359-000-001	Flashing Light	ABB CEAG
1135PG-CP	Inductor Pressure Transmitter	Vibrometer
11389-1	Pressure Sensor	Dynamic Ctls Corporation
11389-2	Pressure Sensor	Dynamic Ctls Corporation
1138PGCP1	Oil Pressure Warning Switch	Vibrometer
1139-6-4500	Valve	Pneudraulics Inc
1139-6-5650	Valve	Pneudraulics Inc
113A2610-1	Trailing Edge Flap Components	Boeing
113A2610-2	Trailing Edge Flap Components	Boeing
113A2612-1	Trailing Edge Flap Components	Boeing
113A2612-2	Trailing Edge Flap Components	Boeing
113A2620-1	Trailing Edge Flap Components	Boeing
113A2620-2	Trailing Edge Flap Components	Boeing
113A2630-1	Trailing Edge Flap Components	Boeing
113A2630-3	Trailing Edge Flap Components	Boeing
113A2800-1	Inboard Flap Inboard Carriage	Boeing
113A2800-2	Inboard Flap Inboard Carriage	Boeing
113N2100-1	Carriage assy	Boeing
113N2100-11	Carriage assy	Boeing
113N2100-13	Carriage assy	Boeing
113N2100-4	Carriage assy	Boeing
113N2100-6	Carriage assy	Boeing
113N2100-8	Carriage assy	Boeing
113N2150-1	Carriage assy	Boeing
113N2150-10	Carriage assy	Boeing
113N2150-17	Carriage assy	Boeing
113N2150-18	Carriage assy	Boeing
113N2150-2	Carriage assy	Boeing
113N2150-21	Carriage assy	Boeing
113N2150-22	Carriage assy	Boeing
113N2150-4	Carriage assy	Boeing
113N2150-5	Carriage assy	Boeing
113N2150-7	Carriage assy	Boeing

Repair_Capability_List_Excel

113N2150-8	Carriage assy	Boeing
113N2150-9	Carriage assy	Boeing
113N3100-1	Carriage assy	Boeing
113N3100-10	Carriage assy	Boeing
113N3100-11	Carriage assy	Boeing
113N3100-12	Carriage assy	Boeing
113N3100-13	Carriage assy	Boeing
113N3100-14	Carriage assy	Boeing
113N3100-2	Carriage assy	Boeing
113N3100-3	Carriage assy	Boeing
113N3100-4	Carriage assy	Boeing
113N3100-5	Carriage assy	Boeing
113N3100-6	Carriage assy	Boeing
113N3100-9	Carriage assy	Boeing
113N3150-1	Carriage assy	Boeing
113N3150-10	Carriage assy	Boeing
113N3150-11	Carriage assy	Boeing
113N3150-12	Carriage assy	Boeing
113N3150-15	Carriage assy	Boeing
113N3150-16	Carriage assy	Boeing
113N3150-2	Carriage assy	Boeing
113N3150-3	Carriage assy	Boeing
113N3150-4	Carriage assy	Boeing
113N3150-5	Carriage assy	Boeing
113N3150-6	Carriage assy	Boeing
113N3150-9	Carriage assy	Boeing
113T1750-1	Door Assy -INBD Te Flap Fairing	Boeing
113T1750-2	Door Assy -INBD Te Flap Fairing	Boeing
113T2000-100	Inboard Trailing Edge Flap Linkage	Boeing
113T2000-103	Inboard Trailing Edge Flap Track and Beam	Boeing
113T2000-131	Inboard Trailing Edge Flap Linkage	Boeing
113T2000-132	Inboard Trailing Edge Flap Linkage	Boeing
113T2000-133	Inboard Trailing Edge Flap Linkage	Boeing
113T2000-134	Inboard Trailing Edge Flap Linkage	Boeing
113T2000-137	Inboard Trailing Edge Flap Linkage	Boeing
113T2000-138	Inboard Trailing Edge Flap Linkage	Boeing
113T2000-151	Inboard Trailing Edge Flap Linkage	Boeing
113T2000-152	Inboard Trailing Edge Flap Linkage	Boeing
113T2000-153	Inboard Trailing Edge Flap Linkage	Boeing
113T2000-154	Inboard Trailing Edge Flap Linkage	Boeing
113T2000-155	Inboard Trailing Edge Flap Linkage	Boeing
113T2000-156	Inboard Trailing Edge Flap Linkage	Boeing
113T2000-3	Inboard Trailing Edge Flap Linkage	Boeing
113T2000-4	Inboard Trailing Edge Flap Linkage	Boeing
113T2000-61	Inboard Trailing Edge Flap Track and Beam	Boeing
113T2000-67	Inboard Trailing Edge Flap Linkage	Boeing
113T2000-68	Inboard Trailing Edge Flap Linkage	Boeing
113T2000-71	Inboard Trailing Edge Flap Track and Beam	Boeing
113T2000-73	Inboard Trailing Edge Flap Linkage	Boeing
113T2000-74	Inboard Trailing Edge Flap Linkage	Boeing
113T2000-75	Inboard Trailing Edge Flap Linkage	Boeing
113T2000-76	Inboard Trailing Edge Flap Linkage	Boeing
113T2000-85	Inboard Trailing Edge Flap Linkage	Boeing
113T2000-86	Inboard Trailing Edge Flap Linkage	Boeing
113T2000-89	Inboard Trailing Edge Flap Track and Beam	Boeing
113T2000-90	Inboard Trailing Edge Flap Track and Beam	Boeing
113T2000-99	Inboard Trailing Edge Flap Linkage	Boeing
113T2029-5	Door Install. Components Side of Body	Boeing

Repair_Capability_List_Excel

113T2029-6	Door Install. Components Side of Body	Boeing
113T2030-3	Door Install. Components Side of Body	Boeing
113T2030-4	Door Install. Components Side of Body	Boeing
113T2030-5	Door Install. Components Side of Body	Boeing
113T2030-6	Door Install. Components Side of Body	Boeing
113T3000-109	Outboard Trailing Edge Flap Linkage	Boeing
113T3000-110	Outboard Trailing Edge Flap Linkage	Boeing
113T3000-25	Outboard Trailing Edge Flap Linkage	Boeing
113T3000-26	Outboard Trailing Edge Flap Linkage	Boeing
113T3000-3	Outboard Trailing Edge Flap Linkage	Boeing
113T3000-33	Outboard Trailing Edge Flap Linkage	Boeing
113T3000-34	Outboard Trailing Edge Flap Linkage	Boeing
113T3000-35	Outboard Trailing Edge Flap Linkage	Boeing
113T3000-36	Outboard Trailing Edge Flap Linkage	Boeing
113T3000-37	Outboard Trailing Edge Flap Linkage	Boeing
113T3000-38	Outboard Trailing Edge Flap Linkage	Boeing
113T3000-4	Outboard Trailing Edge Flap Linkage	Boeing
113T3000-45	Outboard Trailing Edge Flap Linkage	Boeing
113T3000-46	Outboard Trailing Edge Flap Linkage	Boeing
113T3000-47	Outboard Trailing Edge Flap Linkage	Boeing
113T3000-48	Outboard Trailing Edge Flap Linkage	Boeing
113T3000-49	Outboard Trailing Edge Flap Linkage	Boeing
113T3000-50	Outboard Trailing Edge Flap Linkage	Boeing
113T3000-57	Outboard Trailing Edge Flap Linkage	Boeing
113T3000-58	Outboard Trailing Edge Flap Linkage	Boeing
113T3000-59	Outboard Trailing Edge Flap Linkage	Boeing
113T3000-60	Outboard Trailing Edge Flap Linkage	Boeing
113T3000-61	Outboard Trailing Edge Flap Linkage	Boeing
113T3000-62	Outboard Trailing Edge Flap Linkage	Boeing
113T3000-63	Outboard Trailing Edge Flap Linkage	Boeing
113T3000-64	Outboard Trailing Edge Flap Linkage	Boeing
113T3000-69	Outboard Trailing Edge Flap Linkage	Boeing
113T3000-70	Outboard Trailing Edge Flap Linkage	Boeing
113T3000-71	Outboard Trailing Edge Flap Linkage	Boeing
113T3000-72	Outboard Trailing Edge Flap Linkage	Boeing
113T3000-87	Outboard Trailing Edge Flap Linkage	Boeing
113T3000-88	Outboard Trailing Edge Flap Linkage	Boeing
113T3000-89	Outboard Trailing Edge Flap Linkage	Boeing
113T3000-90	Outboard Trailing Edge Flap Linkage	Boeing
113T8101-13	Drag Strut Door	Boeing
113T8101-14	Drag Strut Door	Boeing
113T8101-1SP	Drag Strut Door	Boeing
113T8101-2SP	Drag Strut Door	Boeing
113T8201-47SP	Shock Strut Door	Boeing
113T8201-48SP	Shock Strut Door	Boeing
113T8201-49SP	Shock Strut Door	Boeing
113T8201-50SP	Shock Strut Door	Boeing
113T8201-51SP	Shock Strut Door	Boeing
113T8201-52SP	Shock Strut Door	Boeing
113T8201-69SP	Shock Strut Door	Boeing
113T8201-70SP	Shock Strut Door	Boeing
113T8201-71SP	Shock Strut Door	Boeing
113T8201-72SP	Shock Strut Door	Boeing
113T8201-73SP	Shock Strut Door	Boeing
113T8201-74SP	Shock Strut Door	Boeing
113T8301-15SP	Trunion Door	Boeing
113T8301-16SP	Trunion Door	Boeing
113T8301-17	Trunion Door	Boeing

Repair_Capability_List_Excel

113T8301-18	Trunion Door	Boeing
113T8301-21SP	Trunion Door	Boeing
113T8301-22SP	Trunion Door	Boeing
113T8301-27SP	Trunion Door	Boeing
113T8301-28SP	Trunion Door	Boeing
113T8314-1	Fitting Assy-Trunion Door	Boeing
113T8314-10	Fitting Assy-Trunion Door	Boeing
113T8314-2	Fitting Assy-Trunion Door	Boeing
113T8314-5	Fitting Assy-Trunion Door	Boeing
113T8314-6	Fitting Assy-Trunion Door	Boeing
113T8314-9	Fitting Assy-Trunion Door	Boeing
11400	Hydraulic Pump	Hamilton Sundstrand
11400-1	Hydraulic Pump	Hamilton Sundstrand
1140-0110-10	Side Stick assy	Kaiser
1140-0110-11	Side Stick assy	Kaiser
1140-0110-12	Side Stick assy	Kaiser
1140-0110-13	Side Stick assy	Kaiser
1140-0110-14	Side Stick assy	Kaiser
1140-0110-15	Side Stick assy	Kaiser
1140-0110-16	Side Stick assy	Kaiser
1140-0110-17	Side Stick assy	Kaiser
1140-0110-18	Side Stick assy	Kaiser
1140-0110-19	Side Stick assy	Kaiser
1140-0110-2	Side Stick assy	Kaiser
1140-0110-20	Side Stick assy	Kaiser
1140-0110-21	Side Stick assy	Kaiser
1140-0110-211	Side Stick assy	Kaiser
1140-0110-212	Side Stick assy	Kaiser
1140-0110-213	Side Stick assy	Kaiser
1140-0110-214	Side Stick assy	Kaiser
1140-0110-215	Side Stick assy	Kaiser
1140-0110-216	Side Stick assy	Kaiser
1140-0110-217	Side Stick assy	Kaiser
1140-0110-218	Side Stick assy	Kaiser
1140-0110-22	Side Stick assy	Kaiser
1140-0110-221	Side Stick assy	Kaiser
1140-0110-222	Side Stick assy	Kaiser
1140-0110-223	Side Stick assy	Kaiser
1140-0110-224	Side Stick assy	Kaiser
1140-0110-225	Side Stick assy	Kaiser
1140-0110-226	Side Stick assy	Kaiser
1140-0110-227	Side Stick assy	Kaiser
1140-0110-228	Side Stick assy	Kaiser
1140-0110-23	Side Stick assy	Kaiser
1140-0110-231	Side Stick assy	Kaiser
1140-0110-232	Side Stick assy	Kaiser
1140-0110-233	Side Stick assy	Kaiser
1140-0110-234	Side Stick assy	Kaiser
1140-0110-235	Side Stick assy	Kaiser
1140-0110-236	Side Stick assy	Kaiser
1140-0110-237	Side Stick assy	Kaiser
1140-0110-24	Side Stick assy	Kaiser
1140-0110-241	Side Stick assy	Kaiser
1140-0110-242	Side Stick assy	Kaiser
1140-0110-243	Side Stick assy	Kaiser
1140-0110-244	Side Stick assy	Kaiser
1140-0110-245	Side Stick assy	Kaiser
1140-0110-246	Side Stick assy	Kaiser

Repair_Capability_List_Excel

1140-0110-247	Side Stick assy	Kaiser
1140-0110-248	Side Stick assy	Kaiser
1140-0110-25	Side Stick assy	Kaiser
1140-0110-26	Side Stick assy	Kaiser
1140-0110-27	Side Stick assy	Kaiser
1140-0110-28	Side Stick assy	Kaiser
1140-0110-29	Side Stick assy	Kaiser
1140-0110-3	Side Stick assy	Kaiser
1140-0110-31	Side Stick assy	Kaiser
1140-0110-311	Side Stick assy	Kaiser
1140-0110-312	Side Stick assy	Kaiser
1140-0110-313	Side Stick assy	Kaiser
1140-0110-314	Side Stick assy	Kaiser
1140-0110-315	Side Stick assy	Kaiser
1140-0110-32	Side Stick assy	Kaiser
1140-0110-321	Side Stick assy	Kaiser
1140-0110-322	Side Stick assy	Kaiser
1140-0110-323	Side Stick assy	Kaiser
1140-0110-324	Side Stick assy	Kaiser
1140-0110-325	Side Stick assy	Kaiser
1140-0110-33	Side Stick assy	Kaiser
1140-0110-331	Side Stick assy	Kaiser
1140-0110-332	Side Stick assy	Kaiser
1140-0110-333	Side Stick assy	Kaiser
1140-0110-334	Side Stick assy	Kaiser
1140-0110-335	Side Stick assy	Kaiser
1140-0110-34	Side Stick assy	Kaiser
1140-0110-35	Side Stick assy	Kaiser
1140-0110-36	Side Stick assy	Kaiser
1140-0110-37	Side Stick assy	Kaiser
1140-0110-38	Side Stick assy	Kaiser
1140-0110-4	Side Stick assy	Kaiser
1140-0110-5	Side Stick assy	Kaiser
1140-0110-6	Side Stick assy	Kaiser
1140-0110-7	Side Stick assy	Kaiser
1140-0110-8	Side Stick assy	Kaiser
1140-0110-9	Side Stick assy	Kaiser
1140-0111-1	Side Stick assy	Kaiser
1140-0111-10	Side Stick assy	Kaiser
1140-0111-11	Side Stick assy	Kaiser
1140-0111-12	Side Stick assy	Kaiser
1140-0111-13	Side Stick assy	Kaiser
1140-0111-14	Side Stick assy	Kaiser
1140-0111-15	Side Stick assy	Kaiser
1140-0111-16	Side Stick assy	Kaiser
1140-0111-17	Side Stick assy	Kaiser
1140-0111-18	Side Stick assy	Kaiser
1140-0111-19	Side Stick assy	Kaiser
1140-0111-2	Side Stick assy	Kaiser
1140-0111-20	Side Stick assy	Kaiser
1140-0111-21	Side Stick assy	Kaiser
1140-0111-22	Side Stick assy	Kaiser
1140-0111-23	Side Stick assy	Kaiser
1140-0111-24	Side Stick assy	Kaiser
1140-0111-25	Side Stick assy	Kaiser
1140-0111-26	Side Stick assy	Kaiser
1140-0111-27	Side Stick assy	Kaiser
1140-0111-28	Side Stick assy	Kaiser

Repair_Capability_List_Excel

1140-0111-29	Side Stick assy	Kaiser
1140-0111-3	Side Stick assy	Kaiser
1140-0111-30	Side Stick assy	Kaiser
1140-0111-31	Side Stick assy	Kaiser
1140-0111-32	Side Stick assy	Kaiser
1140-0111-33	Side Stick assy	Kaiser
1140-0111-4	Side Stick assy	Kaiser
1140-0111-42	Side Stick assy	Kaiser
1140-0111-43	Side Stick assy	Kaiser
1140-0111-44	Side Stick assy	Kaiser
1140-0111-45	Side Stick assy	Kaiser
1140-0111-46	Side Stick assy	Kaiser
1140-0111-47	Side Stick assy	Kaiser
1140-0111-48	Side Stick assy	Kaiser
1140-0111-49	Side Stick assy	Kaiser
1140-0111-5	Side Stick assy	Kaiser
1140-0111-50	Side Stick assy	Kaiser
1140-0111-51	Side Stick assy	Kaiser
1140-0111-52	Side Stick assy	Kaiser
1140-0111-53	Side Stick assy	Kaiser
1140-0111-54	Side Stick assy	Kaiser
1140-0111-55	Side Stick assy	Kaiser
1140-0111-56	Side Stick assy	Kaiser
1140-0111-57	Side Stick assy	Kaiser
1140-0111-58	Side Stick assy	Kaiser
1140-0111-59	Side Stick assy	Kaiser
1140-0111-61	Side Stick assy	Kaiser
1140-0111-62	Side Stick assy	Kaiser
1140-0111-63	Side Stick assy	Kaiser
1140-0111-64	Side Stick assy	Kaiser
1140-0111-65	Side Stick assy	Kaiser
1140-0111-66	Side Stick assy	Kaiser
1140-0111-67	Side Stick assy	Kaiser
1140-0111-68	Side Stick assy	Kaiser
1140-0111-69	Side Stick assy	Kaiser
1140-0111-7	Side Stick assy	Kaiser
1140-0111-70	Side Stick assy	Kaiser
1140-0111-72	Side Stick assy	Kaiser
1140-0111-73	Side Stick assy	Kaiser
1140-0111-74	Side Stick assy	Kaiser
1140-0111-75	Side Stick assy	Kaiser
1140-0111-76	Side Stick assy	Kaiser
1140-0111-77	Side Stick assy	Kaiser
1140-0111-78	Side Stick assy	Kaiser
1140-0111-79	Side Stick assy	Kaiser
1140-0111-8	Side Stick assy	Kaiser
1140-0160-100	Side Stick assy	Kaiser
1140-0160-101	Side Stick assy	Kaiser
1140-0160-102	Side Stick assy	Kaiser
1140-0160-103	Side Stick assy	Kaiser
1140-0160-104	Side Stick assy	Kaiser
1140-0160-105	Side Stick assy	Kaiser
1140-0160-106	Side Stick assy	Kaiser
1140-0160-107	Side Stick assy	Kaiser
1140-0160-108	Side Stick assy	Kaiser
1140-0160-109	Side Stick assy	Kaiser
1140-0160-110	Side Stick assy	Kaiser
1140-0160-111	Side Stick assy	Kaiser

Repair_Capability_List_Excel

1140-0160-112	Side Stick assy	Kaiser
1140-0160-113	Side Stick assy	Kaiser
1140-0160-114	Side Stick assy	Kaiser
1140-0160-115	Side Stick assy	Kaiser
1140-0160-116	Side Stick assy	Kaiser
1140-0160-117	Side Stick assy	Kaiser
1140-0160-118	Side Stick assy	Kaiser
1140-0160-119	Side Stick assy	Kaiser
1140-0160-120	Side Stick assy	Kaiser
1140-0160-121	Side Stick assy	Kaiser
1140-0160-122	Side Stick assy	Kaiser
1140-0160-123	Side Stick assy	Kaiser
1140-0160-124	Side Stick assy	Kaiser
1140-0174-1	Side Stick assy	Kaiser
1140-0174-10	Side Stick assy	Kaiser
1140-0174-11	Side Stick assy	Kaiser
1140-0174-12	Side Stick assy	Kaiser
1140-0174-2	Side Stick assy	Kaiser
1140-0174-3	Side Stick assy	Kaiser
1140-0174-4	Side Stick assy	Kaiser
1140-0174-5	Side Stick assy	Kaiser
1140-0174-6	Side Stick assy	Kaiser
1140-0174-7	Side Stick assy	Kaiser
1140-0174-8	Side Stick assy	Kaiser
1140-0174-9	Side Stick assy	Kaiser
1140-0183-1	Side Stick assy	Kaiser
1140-0183-2	Side Stick assy	Kaiser
1140-0183-3	Side Stick assy	Kaiser
1140-0183-4	Side Stick assy	Kaiser
1140-0183-5	Side Stick assy	Kaiser
1140-0183-6	Side Stick assy	Kaiser
1140-0183-7	Side Stick assy	Kaiser
1140-0183-8	Side Stick assy	Kaiser
114022	Indicator	Rogerson Kratos
114-022	Indicator	Rogerson Kratos
114029	Indicator	Rogerson Kratos
114-029	Indicator	Rogerson Kratos
114031001	NLG Door Actuator	Dowty Aerospace
114031002	NLG Door Actuator	Dowty Aerospace
114031003	NLG Door Actuator	Dowty Aerospace
114032001	NLG Door Uplock	Dowty Aerospace
114032002	NLG Door Uplock	Dowty Aerospace
114035	Indicator	Rogerson Kratos
114-035	Indicator	Rogerson Kratos
114035001	Centering Actuator	Dowty Aerospace
114037001	Retraction Actuator	Dowty Aerospace
114038001	Uplock Actuator	Dowty Aerospace
114044001	Selector Valve	Dowty Aerospace
114044002	Selector Valve	Dowty Aerospace
114044003	Selector Valve	Dowty Aerospace
114049	Indicator	Rogerson Kratos
114-049	Indicator	Rogerson Kratos
114054	Indicator	Negre
114-054	Indicator	Negre
114-056	Indicator	Negre
114-058	Indicator	Negre
114-059	Indicator	Negre
114059001	NLG Downlock Actuator	Dowty Aerospace

Repair_Capability_List_Excel

114-060	Indicator	Negre
114060001	Retraction Actuator	Dowty Aerospace
114-062	Indicator	Negre
114-063	Indicator	Negre
114-065	Indicator	Negre
114079001	Door Selector Valve	Messier-Dowty
114079002	Door Selector Valve	Messier-Dowty
114079005	Door Selector Valve	Messier-Dowty
114079006	Door Selector Valve	Messier-Dowty
114079009	Door Selector Valve	Messier-Dowty
114079010	Door Selector Valve	Messier-Dowty
114079012	Door Selector Valve	Messier-Dowty
114079013	Door Selector Valve	Messier-Dowty
114079014	Door Selector Valve	Messier-Dowty
114079015	Door Selector Valve	Messier-Dowty
114079016	Door Selector Valve	Messier-Dowty
114079017	Door Selector Valve	Messier-Dowty
114080001	Manifold assy	Messier-Dowty
114080003	Manifold assy	Messier-Dowty
114083003	Vent Valve	Messier-Dowty
114083004	Vent Valve	Messier-Dowty
114086001	Cut Out Valve	Messier-Dowty
114086002	Cut Out Valve	Messier-Dowty
114087001	Valve assy	Messier-Dowty
114087002	Valve assy	Messier-Dowty
114087003	Valve assy	Messier-Dowty
114087004	Valve assy	Messier-Dowty
114087005	Valve assy	Messier-Dowty
114094001	Actuator	Messier-Dowty
114094002	Actuator	Messier-Dowty
114094003	Actuator	Messier-Dowty
114094004	Actuator	Messier-Dowty
114094005	Actuator	Messier-Dowty
114094006	Actuator	Messier-Dowty
114094007	Actuator	Messier-Dowty
114095001	Actuator	Messier-Bugatti
114095002	Actuator	Messier-Bugatti
114095003	Actuator	Messier-Bugatti
114095004	Actuator	Messier-Bugatti
114-099-3	Indicator	Rogerson Kratos
114122002	MLG Door Actuator	Messier-Dowty
114122003	MLG Door Actuator	Messier-Dowty
114122004	MLG Door Actuator	Messier-Dowty
114122006	MLG Door Actuator	Messier-Dowty
114122007	MLG Door Actuator	Messier-Dowty
114122008	MLG Door Actuator	Messier-Dowty
114122009	MLG Door Actuator	Messier-Dowty
114122010	MLG Door Actuator	Messier-Dowty
114122011	MLG Door Actuator	Messier-Dowty
114-129-1	Indicator	Rogerson Kratos
114151001	Relief Valve	Messier-Dowty
114151002	Relief Valve	Messier-Dowty
114151003	Relief Valve	Messier-Dowty
114151004	Relief Valve	Messier-Dowty
114153001	Relief Valve	Messier-Dowty
114153002	Brake System Relief Valve	Dowty Aerospace
11416000	Ejection Jack	Dowty Aerospace
114160003	Ejection Jack	Messier-Dowty

Repair_Capability_List_Excel

114160004	Ejection Jack	Messier-Dowty
114160005	Ejection Jack	Messier-Dowty
114161001	Actuator Control Module	Hamilton Sundstrand
114161002	Actuator Control Module	Hamilton Sundstrand
114161003	Actuator Control Module	Hamilton Sundstrand
114167001	NLG Centring Actuator	Dowty Aerospace
114168001	Selector Valve	Dowty Aerospace
114170001	Selector Manifold Valve	Dowty Aerospace
114170002	Selector Manifold Valve	Dowty Aerospace
114170003	Selector Manifold Valve	Dowty Aerospace
114170004	Selector Manifold Valve	Dowty Aerospace
114170005	Selector Manifold Valve	Dowty Aerospace
114170006	Selector Manifold Valve	Dowty Aerospace
114170007	Selector Manifold Valve	Dowty Aerospace
114170008	Selector Manifold Valve	Dowty Aerospace
114193001	Retraction Actuator	Messier-Dowty
114193002	Retraction Actuator	Messier-Dowty
114193003	Retraction Actuator	Messier-Dowty
114193004	Retraction Actuator	Messier-Dowty
114193005	Retraction Actuator	Messier-Dowty
114193006	Retraction Actuator	Messier-Dowty
114193007	Retraction Actuator	Messier-Dowty
114193008	Retraction Actuator	Messier-Dowty
114194001	Uplock Actuator	Dowty Aerospace
114200001	Shimmy Restrictor	Dowty Aerospace
114201001	Steering Control Valve	Dowty Aerospace
114201002	Steering Control Valve	Dowty Aerospace
114202001	Steering Control Valve	Messier-Dowty
114202002	Steering Control Valve	Messier-Dowty
114202003	Steering Control Valve	Messier-Dowty
114205001	Relief Valve	Dowty Aerospace
114205002	Relief Valve	Dowty Aerospace
114205003	Relief Valve	Dowty Aerospace
114205004	Relief Valve	Dowty Aerospace
114220001	MLG Retraction Actuator	Dowty Aerospace
114220002	MLG Retraction Actuator	Dowty Aerospace
114256001	Retraction Actuator	Dowty Aerospace
114256002-020	MLG Retraction Actuator	Messier-Dowty
114256002-030	MLG Retraction Actuator	Messier-Dowty
114256002-035	MLG Retraction Actuator	Messier-Dowty
114256002-040	MLG Retraction Actuator	Messier-Dowty
114256002-045	MLG Retraction Actuator	Messier-Dowty
114257001	MLG Downlock Actuator	Messier-Dowty
114258004-030	MLG Pitch Trimmer	Messier-Dowty
114258004-040	MLG Pitch Trimmer	Messier-Dowty
114258004-050	MLG Pitch Trimmer	Messier-Dowty
114258004-060	MLG Pitch Trimmer	Messier-Dowty
114258004-065	MLG Pitch Trimmer	Messier-Dowty
1142600	Panel	Hughes-Avicom
114350001	NLG Undercarriage Jack	Messier-Dowty
114351001	Lock Stay Actuator	Messier-Bugatti
114354001	LOCK STAY ACTUATOR	MESSIER DOWTY
1145-0019	Switch	Royly
11480001	Manifold Block	Messier-Dowty
11480003	Manifold Block	Messier-Dowty
114D100	Rotary Actuator	Vickers
114DA30	Spherical Plug Valve	FR Hitemp
114M1	Motorised Valve	FR Hitemp

Repair_Capability_List_Excel

114M11	Motorised Valve	FR Hitemp
114RV	Engine Speed Indicator	Vibrometer
114T0101-1	Leading Edge Slat Track	Boeing
114T0111-1	Auxiliary Track Fitting	Boeing
114T0112-1	Auxiliary Track Fitting	Boeing
114T0112-2	Auxiliary Track Fitting	Boeing
114T0135-1	Rib Brace Strut	Boeing
114T0136-3	Rib Brace Strut	Boeing
114T0137-1	Rib Brace Strut	Boeing
114T0138-1	Rib Brace Strut	Boeing
114T0231-8	Slat Track Link	Boeing
114T0231-9	Slat Track Link	Boeing
114T0233-1	Leading Edge Slat Track	Boeing
114T3300-10	Slat Track Link	Boeing
114T3300-9	Slat Track Link	Boeing
114T3301-3	Slat Track Link	Boeing
114T3301-5	Slat Track Link	Boeing
114T3301-6	Slat Track Link	Boeing
114T3302-1	Leading Edge Slat Track	Boeing
114T6301-13SP	Fixed LE AT Nacelle Krueger Seal	Boeing
114T6301-14SP	Fixed LE AT Nacelle Krueger Seal	Boeing
114T6301-15	Fixed LE AT Nacelle Krueger Seal	Boeing
114T6301-16	Fixed LE AT Nacelle Krueger Seal	Boeing
114T6301-17	Fixed LE AT Nacelle Krueger Seal	Boeing
114T6301-18	Fixed LE AT Nacelle Krueger Seal	Boeing
114T6301-1SP	Fixed LE AT Nacelle Krueger Seal	Boeing
114T6301-2SP	Fixed LE AT Nacelle Krueger Seal	Boeing
114T6301-31	Fixed LE AT Nacelle Krueger Seal	Boeing
114T6301-32	Fixed LE AT Nacelle Krueger Seal	Boeing
114T6301-37A	Fixed LE AT Nacelle Krueger Seal	Boeing
114T6301-38A	Fixed LE AT Nacelle Krueger Seal	Boeing
114T6301-39	Fixed LE AT Nacelle Krueger Seal	Boeing
114T6301-40	Fixed LE AT Nacelle Krueger Seal	Boeing
114T6301-43	Fixed LE AT Nacelle Krueger Seal	Boeing
114T6301-44	Fixed LE AT Nacelle Krueger Seal	Boeing
114T6301-45A	Fixed LE AT Nacelle Krueger Seal	Boeing
114T6301-46A	Fixed LE AT Nacelle Krueger Seal	Boeing
114T6301-47	Fixed LE AT Nacelle Krueger Seal	Boeing
114T6301-48	Fixed LE AT Nacelle Krueger Seal	Boeing
114T6301-49	Fixed LE AT Nacelle Krueger Seal	Boeing
114T6301-50	Fixed LE AT Nacelle Krueger Seal	Boeing
114T6301-51	Fixed LE AT Nacelle Krueger Seal	Boeing
114T6301-52	Fixed LE AT Nacelle Krueger Seal	Boeing
114T6301-53	Fixed LE AT Nacelle Krueger Seal	Boeing
114T6301-54	Fixed LE AT Nacelle Krueger Seal	Boeing
114T6301-55	Fixed LE AT Nacelle Krueger Seal	Boeing
114T6301-56	Fixed LE AT Nacelle Krueger Seal	Boeing
114T6301-57	Fixed LE AT Nacelle Krueger Seal	Boeing
114T6301-58	Fixed LE AT Nacelle Krueger Seal	Boeing
114T6301-59	Fixed LE AT Nacelle Krueger Seal	Boeing
114T6301-60	Fixed LE AT Nacelle Krueger Seal	Boeing
114T6301-61	Fixed LE AT Nacelle Krueger Seal	Boeing
114T6301-62	Fixed LE AT Nacelle Krueger Seal	Boeing
114T6301-63	Fixed LE AT Nacelle Krueger Seal	Boeing
114T6301-64	Fixed LE AT Nacelle Krueger Seal	Boeing
114T6400-10	Fix.LE AT Nac.Krueger Seal Drive Mech.	Boeing
114T6400-5	Fix.LE AT Nac.Krueger Seal Drive Mech.	Boeing
114T6400-6	Fix.LE AT Nac.Krueger Seal Drive Mech.	Boeing

Repair_Capability_List_Excel

114T6400-9	Fix.LE AT Nac.Krueger Seal Drive Mech.	Boeing
114T6450-3	Fix.LE AT Nac.Krueger Seal Drive Mech.	Boeing
114T6450-4	Fix.LE AT Nac.Krueger Seal Drive Mech.	Boeing
1150010-1	Selector	Honeywell
115029	Indicator	Rogerson Kratos
1150322-1 S1	Manifold Temperature Sensor	Honeywell
1150980-1	Flow Sensor	Honeywell
115099	Indicator	Rogerson Kratos
115-099-5	Indicator	Rogerson Aircraft
115-099-6	Indicator	Rogerson Aircraft
115-099-7	Indicator	Rogerson Aircraft
115-099-8	Indicator	Rogerson Aircraft
115-099-9	Indicator	Rogerson Aircraft
115112	Fuel Pump assy	Hamilton Sundstrand
115-121-2	Indicator	Rogerson Kratos
115131	Indicator	Rogerson Kratos
1151324-1	VHF Emergency Loc Transmitter	Honeywell
115-159-1	Indicator	Rogerson Kratos
11516	Indicator	Rogerson Kratos
115163	Indicator	Rogerson Kratos
115164	Indicator	Rogerson Kratos
115-216	Indicator	Rogerson Aircraft
115-217	Indicator	Rogerson Aircraft
115-217-1	Water Qty Indicator	Rogerson Aircraft
1153-000	Fuel Pressure Switch	Intertechnique
1153-100	Pressure Switch	Intertechnique
1153-1B	Motor	Auxilec
1156-100	Differential Pressure Switch	Intertechnique
11562-103	DC Gear Motor	Menasco Aerospace
1157010	Valve assy	FR Hitemp
1157020	Canister Refuel/Defuel Valve	FR Hitemp
1157060	Refuel/Defuel Valve	FR Hitemp
1158000-15	Refuel Valve Canister & Check Valve	FR Hitemp
1158000-17	Refuel Valve Element	FR Hitemp
1158000-21	Refuel Valve Element	FR Hitemp
1158-200	Pressure Switch	Intertechnique
1159-072	Timer	Monogram Systems
1159P41100-21	Nose Cowl	Grumman Aerospace
1159P41100-23	Nose Cowl	Grumman Aerospace
1159P41100-47	Nose Cowl	Grumman Aerospace
1159P41100-65	Nose Cowl	Grumman Aerospace
1159P41100-67	Nose Cowl	Grumman Aerospace
1159P41100-73	Nose Cowl	Grumman Aerospace
1159P41100-75	Nose Cowl	Grumman Aerospace
1159P41150-11	Cowling	Grumman Aerospace
1159P41150-5	Cowling	Grumman Aerospace
1159P41150-7	Cowling	Grumman Aerospace
1159P41150-9	Cowling	Grumman Aerospace
1159P41230-5	Lower Cowl Door	Grumman Aerospace
1159P41230-7	Lower Cowl Door	Grumman Aerospace
1159P41440-3	Thrust Reverser	Grumman Aerospace
1159P41440-4	Thrust Reverser	Grumman Aerospace
1159P41440-41	Thrust Reverser	Grumman Aerospace
1159P41440-42	Thrust Reverser	Grumman Aerospace
1159P41440-7	Thrust Reverser	Grumman Aerospace
1159P41440-8	Thrust Reverser	Grumman Aerospace
1159PM41550-13	Bellcrank Drive	Grumman Aerospace
1159PM41550-15	Bellcrank Drive	Grumman Aerospace

Repair_Capability_List_Excel

1159PM41550-17	Bellcrank Drive	Grumman Aerospace
1159PM41550-19	Bellcrank Drive	Grumman Aerospace
1159PM41550-21	Bellcrank	Grumman Aerospace
1159PM41550-23	Bellcrank	Grumman Aerospace
1159PM41550-25	Bellcrank Drive	Grumman Aerospace
1159PM41550-51	Bellcrank Drive	Grumman Aerospace
1159PM41550-53	Bellcrank Drive	Grumman Aerospace
1159PM41550-55	Crank	Grumman Aerospace
1159SCP408-1	Secondary Lock Actuator	Fokker Aircraft
115D100	Rotary Actuator	Eaton Aerospace
115D100-1	Rotary Actuator	Eaton Aerospace
116900-2	Linear Door Actuator	Eaton
116900-3	Linear Door Actuator	Eaton
116900-3A	Linear Door Actuator	Eaton
116900-3B	Linear Door Actuator	Eaton
116900-3C	Linear Door Actuator	Eaton
116D100	Rotary Gearbox	Eaton Aerospace
1173T0639	Temperature Sensor	ITT Neo Dyn
1173T0640	Temperature Sensor	ITT Neo Dyn
1173T0691	Temperature Sensor	ITT Neo Dyn
1173T11-1	Sensor	Aerospace
1173T15-1	Temperature Sensor	ITT Neo Dyn
1173T211	Temperature Sensor	ITT Neo Dyn
117491-1	Pressure Switch	ITT Corporation
1175T100-9	Actuator	Telair International
1176000	Indicator	Airbus Industrie
1176T100-1	Power Drive Unit	Telair International
1176T100-3	Power Drive Unit	Telair International
11790-301	Power Drive Unit	Goodrich
117B2	Temperature Indicator	Honeywell
11-851154	Precooler Exchanger	Liebherr Aerospace
11-851154-5	Precooler Exchanger	Liebherr Aerospace
11-851154-5 Amdt A	Precooler Exchanger	Liebherr Aerospace
11-851154-6	Precooler Exchanger	Liebherr Aerospace
11-851433	Precooler Exchanger	Liebherr Aerospace
11-851433 Amdt A	Precooler Exchanger	Liebherr Aerospace
1186-000	Indicator	Messier-Bugatti
11-99517	Actuator	Curtiss-Wright
11-99517-04-0	Actuator	Curtiss-Wright
11-99517-12-0	Actuator	Curtiss-Wright
11-99517-14	Actuator	Curtiss-Wright
11-99517-14-0	Actuator	Curtiss-Wright
11-99517-22-0	Actuator	Curtiss-Wright
11CT4B	Flap Position Transmitter	Fokker Aircraft
11CT4C	Flap Position Transmitter	Fokker Aircraft
11CX4B	Flap Position Transmitter	Fokker Aircraft
1200006-008	Selcal Decoder	Avtech
1201-0028-3-02	Relay	ECE
1204	Motor	Auxilec
120485	Valve	Whittaker
1204A	Motor	Auxilec
120565-1	Valve	Whittaker
1209-100	Pressure Switch	Le Bozec
120965	Valve	Whittaker
120D2	Clogging Indicator	Le Bozec
121055	Thermostat	Whittaker
121100-1	Power Drive Unit	Telair International
121100-5	Power Drive unit	Telair International

Repair_Capability_List_Excel

121102TA01	Check Valve	Liebherr Aerospace
1211131-1	Feedback Cable Actuator	Arkwin Industries
1211131-2	Feedback Cable Actuator	Arkwin Industries
1211131-4	Feedback Cable Actuator	Arkwin Industries
1211131-6	Feedback Cable Actuator	Arkwin Industries
1211227-001	Feedback Cable Actuator	Arkwin Industries
1211233-2	RAm Air Turbine Actuator	Arkwin Industries
1211233-4	RAm Air Turbine Actuator	Arkwin Industries
1211233-5	RAm Air Turbine Actuator	Arkwin Industries
1211268-001	Feedback Cable Actuator	Arkwin Industries
1211318-002	VBV Actuator	Arkwin Industries
1211318-003	VBV Actuator	Arkwin Industries
1211318-004	VBV Actuator	Arkwin Industries
1211318-005	VBV Actuator	Arkwin Industries
1211342-003	VSV Actuator	Arkwin Industries
1211342-004	VSV Actuator	Arkwin Industries
1211342-005	VSV Actuator	Arkwin Industries
1211445-3	Actuator	Arkwin Industries
1211445-4	Actuator	Arkwin Industries
1211530-001	Actuator	Goodrich Control Systems
1211530-002	Actuator	Goodrich Control Systems
1211534-001	Actuator	Goodrich Control Systems
121174-1-1	Ball Screw Gearbox	Honeywell
121174-3-1	Ball Screw Gearbox	Honeywell
121190-4	Ballscrew assy	Honeywell
121196-3	Flexible Shaft assy	Honeywell
121200-7-1	Ballscrew & Interlock Gearbox	Honeywell
121227-001	Actuator	Honeywell
121245-010	Actuator	Honeywell
121245-10	Actuator	Honeywell
121276-2	Ball Screw Gearbox	Honeywell
121276-3	Ball Screw Gearbox	Honeywell
121276-4	Ball Screw Gearbox	Honeywell
121276-5	Ball Screw Gearbox	Honeywell
121278-2	Ball Screw Gearbox	Honeywell
121278-2B	Ball Screw Gearbox	Honeywell
121278-3	Ball Screw Gearbox	Honeywell
121278-4	Ball Screw Gearbox	Honeywell
121280-2	Pneumatic Switcher Valve	Honeywell
121332-1	Valve assy	Honeywell
121388-2	Flexible Shaft assy	Honeywell
121410-004	VBV Actuator	Arkwin Industries
121419-006	VBV Actuator	Arkwin Industries
121419-007	VBV Actuator	Arkwin Industries
121628-4	Valve assy	Honeywell
121664-10	Ballscrew Actuator	Honeywell
121664-11	Ballscrew Actuator	Honeywell
121664-12	Ballscrew Actuator	Honeywell
121664-3	Ballscrew Actuator	Honeywell
121664-4	Ballscrew Actuator	Honeywell
121664-5	Ballscrew Actuator	Honeywell
121664-6	Ballscrew Actuator	Honeywell
121664-7	Ballscrew Actuator	Honeywell
121664-8	Ballscrew Actuator	Honeywell
121666-11	Ballscrew Actuator	Honeywell
121666-13	Ballscrew Actuator	Honeywell
121666-14	Ballscrew Actuator	Honeywell
121666-15	Ballscrew Actuator	Honeywell

Repair_Capability_List_Excel

121666-16	Ballscrew Actuator	Honeywell
121666-17	Ballscrew Actuator	Honeywell
121666-18	Ballscrew Actuator	Honeywell
121666-19	Ballscrew Actuator	Honeywell
121666-21	Ballscrew Actuator	Honeywell
121666-3	Ballscrew Actuator	Honeywell
121666-4	Ballscrew Actuator	Honeywell
121666-5	Ballscrew Actuator	Honeywell
121666-6	Ballscrew Actuator	Honeywell
121666-7	Ballscrew Actuator	Honeywell
121666-8	Ballscrew Actuator	Honeywell
121666-9	Ballscrew Actuator	Honeywell
121668-1	Flex Shaft	Honeywell
121668-2	Flex Shaft	Honeywell
121728-1	Flexible Shaft assy	Honeywell
121734-2	Flex Shaft	Honeywell
121734-3	Flex Shaft	Honeywell
121734-4	Flex Shaft	Honeywell
121734-5	Flex Shaft	Honeywell
121734-6	Flex Shaft	Honeywell
121746-1	Flex Shaft	Honeywell
121746-2	Flex Shaft	Honeywell
121746-3	Flex Shaft	Honeywell
121746-5	Flex Shaft	Honeywell
121746-6	Flex Shaft	Honeywell
121762-1	Flex Shaft	Honeywell
121762-2	Flex Shaft	Honeywell
121762-3	Flex Shaft	Honeywell
121762-4	Flex Shaft	Honeywell
1218-100	Pressure Switch	Intertechnique
1218-2	Pressure Switch	Intertechnique
121CC01A	Single Pole Contactor	ECE
121CC01A02	Single Pole Contactor	ECE
12201-400	Toilet assy	Monogram
12201-401	Toilet assy	Monogram
12201-402	Toilet assy	Monogram
12201-403	Lavatory assy	Monogram
12201-405	Lavatory assy	Monogram
12201-406	Toilet assy	Monogram
12201-407	Toilet assy	Monogram
12201-411	Toilet assy	Monogram
12201-412	Toilet assy	Monogram
12201-413	Toilet assy	Monogram
12201-417	Toilet assy	Monogram
12201-418	Toilet assy	Monogram
12201-419	Toilet assy	Monogram
12201-423	Toilet assy	Monogram
12201-426	Lavatory assy	Monogram
122100	Shut-Off Valve	Honeywell
1221EB2	Electric Motor	Liebherr Aerospace
1221EB2-1	Electric Motor	Liebherr Aerospace
1221EBC	Electric Motor	Liebherr Aerospace
1221EH1	Electric Motor	Liebherr Aerospace
122250	Shut-Off Valve	Honeywell
122250-1-1	Shut-Off Valve	Honeywell
1222-5-2350	Valve	Pneudraulics Inc
1222-5-3600V	Valve	Pneudraulics Inc
122546-2-1	Relief Valve	Honeywell

Repair_Capability_List_Excel

122592-2-2	Shut-Off Valve	Honeywell
122594-1	Butterfly Valve	Honeywell
122594-3-1	Butterfly Valve	Honeywell
122594-6-1	Butterfly Valve	Honeywell
1225P11	Switch Pressure	ITT Aerospace Ctrl
1225P42	Switch Pressure	ITT Aerospace Ctrl
1225P42-2	Switch Pressure	ITT Aerospace Ctrl
1225P6-1	Switch Pressure	ITT Aerospace Ctrl
1225P6-2	Switch Pressure	ITT Aerospace Ctrl
122618-1-1	Valve assy	Honeywell
122620-1-2	Butterfly Valve	Honeywell
122666-1-1	Butterfly Valve	Honeywell
122666-2	Butterfly Valve	Honeywell
122723-200-01	Fuel Booster Pump	Pesco
122723-200-02	Fuel Booster Pump	Pesco
122900-1	Rotary Actuator	Eaton
122924-1-1	Shut-Off Valve	Honeywell
122926-1-1	Shut-Off Valve	Honeywell
122944-1	Pneumatic Shut-Off Valve	Honeywell
122944-1-1	Pneumatic Shut-Off Valve	Honeywell
122955	Valve	Whittaker
123100-1	Power Drive Unit	Telair International
123100-3	Power Drive Unit	Telair International
123100-3D	Power Drive Unit	Telair International
123100-5	Power Drive Unit	Telair International
123100-7	Power Drive Unit	Telair International
12311	Fixed Auto Transformer	Oeco
123188-1	Check Valve	Honeywell
123266-1-1	Check Valve	Honeywell
123266-2	Check Valve	Honeywell
123268-1-1	Check Valve	Honeywell
123504-1-1	Check Valve	Honeywell
123504-2	Check Valve	Honeywell
123504-5	Check Valve	Honeywell
123544-1	Check Valve	Honeywell
123544-2-1	Check Valve	Honeywell
123558-1-1	Check Valve	Honeywell
123558-1-3	Check Valve	Honeywell
123558-1-4	Check Valve	Honeywell
123605	Valve	Whittaker
123674-1-1	Check Valve	Honeywell
123710-4-1	Check Valve	Honeywell
123766-2	Valve assy	Honeywell
123776-1-1	Check Valve	Honeywell
123814-1	Compressor By-pass Valve	Honeywell
123848-1	Check Valve	Honeywell
123874-1-1	Check Valve	Honeywell
123894-2	LP Bleed Check Valve	Honeywell
1238C000	Valve	Honeywell
123934-1-1	Check Valve	Honeywell
123934-2-1	Check Valve	Honeywell
123940-1	LP Bleed Check Valve	Honeywell
123940-1ECPAC2	LP Bleed Check Valve	Honeywell
123940-2	LP Bleed Check Valve	Honeywell
123956-1-1	Check Valve	Honeywell
123992-1-1	Check Valve	Honeywell
123994-1	Check Valve	Honeywell
1239C0000	Valve	Honeywell

Repair_Capability_List_Excel

124.845-7	Oil Temp Indicator	Rogerson Kratos
124027	Indicator	Rogerson Kratos
124039	Indicator	Rogerson Kratos
12404	Indicator	Rogerson Kratos
124-040-1	Indicator	Rogerson Kratos
124-041	Indicator	Rogerson Kratos
124-041-1	Indicator	Rogerson Kratos
124-041-3	Indicator	Rogerson Kratos
124043	Indicator	Rogerson Kratos
124044	Indicator	Rogerson Kratos
124045	Indicator	Rogerson Kratos
124067	Indicator	Rogerson Kratos
124069	Indicator	Rogerson Kratos
12407	Indicator	Rogerson Kratos
124081	Indicator	Rogerson Kratos
124082	Indicator	Rogerson Kratos
124-1012-1	Indicator	Rogerson Kratos
124-1303	Flap Position Indicator	Rogerson Kratos
124132	Indicator	Rogerson Kratos
124146	Indicator	Rogerson Kratos
124155	Indicator	Rogerson Kratos
124168	Indicator	Rogerson Kratos
12428	Non Return Valve	Nord-Micro
124-318-1	Indicator	Rogerson Kratos
12432-1	Isolation Valve	Nord-Micro
12432-2	Isolation Valve	Nord-Micro
124-434-1	Indicator	Rogerson Kratos
124-444-20	Indicator	Rogerson Kratos
12448	Indicator	Rogerson Kratos
124486	Indicator	Rogerson Kratos
124-497-1	Indicator	Rogerson Kratos
1245-1	Ballast	Avtech Corporation
124-511-1	Indicator	Rogerson Kratos
124-551-8	Indicator	Rogerson Kratos
124-552-1	Indicator	Rogerson Kratos
124-560-1	Indicator	Rogerson Kratos
124611	Indicator	Rogerson Kratos
124-643-1	Indicator	Rogerson Kratos
124645	Valve	Whittaker
124-832	Voltmeter	Rogerson Aircraft
124-833	DC Voltmeter	Rogerson Aircraft
124-834	DC Ammeter	Rogerson Aircraft
124-835	Frequency Meter	Rogerson Aircraft
124-836	Wattmeter	Rogerson Aircraft
124-837	AC Ammeter	Rogerson Aircraft
124-838	Temperature Indicator	Rogerson Aircraft
124-845-1	AC Voltmeter	Rogerson Kratos
124-845-2	Frequency Meter	Rogerson Kratos
124-845-3	AC Load Gauge	Rogerson Kratos
124-845-4	DC Voltmeter	Rogerson Kratos
124-845-5	DC Ammeter	Rogerson Kratos
124-845-6	Oil Temperature Indicator	Rogerson Kratos
124-845-7	Oil Temp Indicator	Rogerson Kratos
124861	Indicator	Rogerson Kratos
124-934A	Indicator	Rogerson Kratos
124-935A	Indicator	Rogerson Kratos
124961	Indicator	Rogerson Kratos
124969	Indicator	Rogerson Kratos

Repair_Capability_List_Excel

12497	Indicator	Rogerson Kratos
124-971	Indicator	Rogerson Kratos
124-987	Temperature Indicator	Rogerson Kratos
124-987-1	Temperature Indicator	Rogerson Kratos
124-987-2	Temperature Indicator	Rogerson Kratos
124-987-3	Temperature Indicator	Rogerson Kratos
124-987-4	Dual Brake Temp Indicator	Rogerson Kratos
12500-1	NLG Door Actuator	Menasco Aerospace
12500-3	NLG Door Actuator	Menasco Aerospace
12500-5	NLG Door Actuator	Menasco Aerospace
12500-7	NLG Door Actuator	Menasco Aerospace
1250422-001	Observer Seat	Sicma Aero Seat
125120	Valve	ITT Aerospace Ctrl
125120-1	Valve	ITT Aerospace Ctrl
12525	Door Actuator	Menasco Aerospace
12525-1	Door Actuator	Menasco Aerospace
12525-11	Door Actuator	Menasco Aerospace
12525-13	Door Actuator	Menasco Aerospace
12525-15	MLG Door Actuator	Menasco Aerospace
12525-17	Door Actuator	Menasco Aerospace
12525-19	MLG Door Actuator	Menasco Aerospace
12525-21	MLG Door Actuator	Menasco Aerospace
12525-23	Door Actuator	Menasco Aerospace
12525-25	MLG Door Actuator	Menasco Aerospace
12525-3	Door Actuator	Menasco Aerospace
12525-5	Door Actuator	Menasco Aerospace
12525-7	Door Actuator	Menasco Aerospace
12525-9	Door Actuator	Menasco Aerospace
125272-121	Centrifugal Pump	Hamilton Sundstrand
125272-131	Centrifugal Pump	Hamilton Sundstrand
125329D	Actuator	ITT Aeroapace
125329D-1	Actuator	ITT Aeroapace
125334	Valve	ITT Aerospace Ctrl
125334-1	Valve	ITT Aerospace Ctrl
125334D	Valve	ITT Aerospace Ctrl
125334D-1	Valve	ITT Aerospace Ctrl
125334F	Valve	ITT Aerospace Ctrl
1254	Motor	Auxilec
125423	Valve	ITT Aerospace Ctrl
125423B	Valve	ITT Aerospace Ctrl
125442	Valve	ITT Aerospace Ctrl
125442B	Valve	ITT Aerospace Ctrl
12550-1	NLG Door Uplock Actuator	Menasco Aerospace
12550-5	NLG Door Uplock Actuator	Menasco Aerospace
125613A	Valve	ITT Aerospace Ctrl
12575-1	Actuator	Menasco Aerospace
12575-3	Actuator	Menasco Aerospace
12575-7	MLG Door Uplock Actuator	Menasco Aerospace
125770G	Body Valve	ITT Aerospace
125770G1	Body Valve	ITT Aerospace
125838AL	Body Valve	ITT Aerospace
125885-1	Valve	Meggitt Avionics
1259A	Motor	Abex
1262	Indicator	Rogerson Kratos
126236-3-3	Pneumatic Drive Actuator	Honeywell
126236-4-1	Pneumatic Drive Actuator	Honeywell
126236-4-2	Pneumatic Drive Actuator	Honeywell
126248	Flap Drive Actuator	Honeywell

Repair_Capability_List_Excel

126248-4-1	Pneumatic Drive Actuator	Honeywell
126344	Flap Drive Actuator	Honeywell
126344-100	Pneumatic Drive Actuator	Honeywell
126344-10-1	Pneumatic Drive Actuator	Honeywell
126344-1-1	Pneumatic Drive Actuator	Honeywell
126344-11-1	Pneumatic Drive Actuator	Honeywell
126344-12-1	Pneumatic Drive Actuator	Honeywell
126344-13-1	Pneumatic Drive Actuator	Honeywell
126344-14-1	Pneumatic Drive Actuator	Honeywell
126344-15-1	Pneumatic Drive Actuator	Honeywell
126344-16-1	Pneumatic Drive Actuator	Honeywell
126344-17-1	Pneumatic Drive Actuator	Honeywell
126344-18-1	Pneumatic Drive Actuator	Honeywell
126344-19-1	Pneumatic Drive Actuator	Honeywell
126344-20-1	Pneumatic Drive Actuator	Honeywell
126344-2-1	Pneumatic Drive Actuator	Honeywell
126344-21-1	Pneumatic Drive Actuator	Honeywell
126344-22-1	Pneumatic Drive Actuator	Honeywell
126344-23-1	Pneumatic Drive Actuator	Honeywell
126344-24-1	Pneumatic Drive Actuator	Honeywell
126344-25-1	Pneumatic Drive Actuator	Honeywell
126344-25-1A	Pneumatic Drive Actuator	Honeywell
126344-26-1	Pneumatic Drive Actuator	Honeywell
126344-27-1	Pneumatic Drive Actuator	Honeywell
126344-3-1	Pneumatic Drive Actuator	Honeywell
126344-4-1	Pneumatic Drive Actuator	Honeywell
126344-5-1	Pneumatic Drive Actuator	Honeywell
126344-6-1	Pneumatic Drive Actuator	Honeywell
126344-7-1	Pneumatic Drive Actuator	Honeywell
126344-8-1	Pneumatic Drive Actuator	Honeywell
126344-9-1	Pneumatic Drive Actuator	Honeywell
126348-12-1	Pneumatic Drive Actuator	Honeywell
126348-8-1	Pneumatic Drive Actuator	Honeywell
126366-19	Pneumatic Drive Motor assy	Honeywell
126366-21	Pneumatic Drive Motor assy	Honeywell
126366-22	Pneumatic Drive Motor assy	Honeywell
126550-1-1	Pneumatic Drive Actuator	Honeywell
1266-100	Pressure Switch	Intertechnique
1266-200	Pressure Switch	Intertechnique
12664	Check Valve	Nord-Micro
126664-1-1	Pneumatic Drive Actuator	Honeywell
126664-2-1	Pneumatic Drive Actuator	Honeywell
126664-3-1	Pneumatic Drive Actuator	Honeywell
126692-1	Actuator	Honeywell
126704-10	Pneumatic Drive Actuator	Honeywell
126704-11	Pneumatic Drive Actuator	Honeywell
126704-2	Pneumatic Drive Actuator	Honeywell
126704-4	Pneumatic Drive Actuator	Honeywell
126704-5	Pneumatic Drive Actuator	Honeywell
126704-6	Pneumatic Drive Actuator	Honeywell
126704-7	Pneumatic Drive Actuator	Honeywell
126704-8	Pneumatic Drive Actuator	Honeywell
126704-9	Pneumatic Drive Actuator	Honeywell
126712-1-1	Pneumatic Drive Actuator	Honeywell
126712-2-1	Pneumatic Drive Actuator	Honeywell
126748	Flap Drive Actuator	Honeywell
126748-1	Pneumatic Drive Actuator	Honeywell
126748-100	Pneumatic Drive Actuator	Honeywell

Repair_Capability_List_Excel

126748-2	Pneumatic Drive Actuator	Honeywell
126748-3	Pneumatic Drive Actuator	Honeywell
126748-4	Pneumatic Drive Actuator	Honeywell
126748-5	Pneumatic Drive Actuator	Honeywell
126748-6	Pneumatic Drive Actuator	Honeywell
126748-7	Pneumatic Drive Actuator	Honeywell
126748-8	Pneumatic Drive Actuator	Honeywell
126758-7	Pneumatic Drive Actuator	Honeywell
126758-8	Pneumatic Drive Actuator	Honeywell
126762	Flap Drive Actuator	Honeywell
126762-1	Flap Drive Actuator	Honeywell
126762-10	Flap Drive Actuator	Honeywell
126762-2	Flap Drive Actuator	Honeywell
126762-5	Flap Drive Actuator	Honeywell
126762-6	Flap Drive Actuator	Honeywell
126762-7	Flap Drive Actuator	Honeywell
126762-8	Flap Drive Actuator	Honeywell
126762-9	Flap Drive Actuator	Honeywell
126780-1	Pneumatic Slide Actuator	Honeywell
126780-2	Pneumatic Slide Actuator	Honeywell
126780-3	Pneumatic Slide Actuator	Honeywell
126784-10	Center Drive Unit Actuator	Honeywell
126784-2	Center Drive Unit Actuator	Honeywell
126784-3	Center Drive Unit Actuator	Honeywell
126784-4	Center Drive Unit Actuator	Honeywell
126784-5	Center Drive Unit Actuator	Honeywell
126784-6	Actuator	Honeywell
126784-7	Center Drive Unit Actuator	Honeywell
126784-8	Actuator	Honeywell
126784-9	Center Drive Unit Actuator	Honeywell
126812-1	Pneumatic Slide Actuator	Honeywell
126812-2	Pneumatic Slide Actuator	Honeywell
126812-7	Pneumatic Slide Actuator	Honeywell
126812-8	Pneumatic Slide Actuator	Honeywell
126848-2	Vane Actuator	Honeywell
126848-3	Vane Actuator	Honeywell
126865	Valve	Whittaker
127038-3-1	Pneumatic Drive Unit Actuator	Honeywell
127038-4-1	Pneumatic Drive Unit Actuator	Honeywell
127038-5-1	Pneumatic Drive Unit Actuator	Honeywell
127038-6-1	Pneumatic Drive Unit Actuator	Honeywell
127042-1-1	Pneumatic Drive Unit Actuator	Honeywell
127042-2-1	Pneumatic Drive Unit Actuator	Honeywell
127042-3-1	Pneumatic Drive Unit Actuator	Honeywell
127042-4-1	Pneumatic Drive Unit Actuator	Honeywell
127055	Valve	Whittaker
1271U-8-03	Pressure Indicator	Kollsman
127315-1	Valve	Meggitt Avionics
127495	Valve	Meggitt Avionics
12750	Booster assy	Menasco Aerospace
12750-11	Elevator Booster Actuator	Menasco Aerospace
12750-13	Elevator Booster Actuator	Menasco Aerospace
12750-15	Elevator Booster Actuator	Menasco Aerospace
12750-17	Elevator Booster Actuator	Menasco Aerospace
12750-9	Elevator Booster Actuator	Menasco Aerospace
128775	Valve	Whittaker
128814-1	By-Pass Check Valve	Fluid System Division
129110-2-1	Thermostat	Honeywell

Repair_Capability_List_Excel

129112-1-1	Pneumatic Anticipator	Honeywell
129115-1	Valve	Whittaker
129118-1-1	Pneumatic Thermostat	Honeywell
129118-2-1	Pneumatic Thermostat	Honeywell
129118-3-1	Pneumatic Thermostat	Honeywell
129118-4-1	Pneumatic Thermostat	Honeywell
129118-5	Pneumatic Thermostat	Honeywell
129150-2	Pneumatic Thermo Valve	Honeywell
129190-1	Pneumatic Thermo Valve	Honeywell
12920	Gearbox	Menasco Aerospace
12920-1	Gearbox Angle	Menasco Aerospace
12920-3	Gearbox Angle	Menasco Aerospace
129224-50	Pneumatic Thermo Valve	Honeywell
129224-53	Pneumatic Thermo Valve	Honeywell
129224-56	Pneumatic Thermo Valve	Honeywell
129224-57	Pneumatic Thermo Valve	Honeywell
129240-1	Thermostat	Honeywell
12925-01	Flap Actuator	Menasco Aerospace
12925-11A	Flap Actuator	Menasco Aerospace
12925-13A	Flap Actuator	Menasco Aerospace
12925-15A	Flap Actuator	Menasco Aerospace
12925-17	Flap Actuator	Menasco Aerospace
12925-17A	Flap Actuator	Menasco Aerospace
12925-21A	Flap Actuator	Menasco Aerospace
12925-23	Flap Actuator	Menasco Aerospace
12925-3A	Flap Actuator	Menasco Aerospace
12925-5A	Flap Actuator	Menasco Aerospace
12925-7A	Flap Actuator	Menasco Aerospace
12925-9A	Flap Actuator	Menasco Aerospace
12926-11A	Flap Actuator	Menasco Aerospace
12926-13A	Flap Actuator	Menasco Aerospace
12926-15A	Flap Actuator	Menasco Aerospace
12926-17	Flap Actuator	Menasco Aerospace
12926-17A	Flap Actuator	Menasco Aerospace
12926-21A	Flap Actuator	Menasco Aerospace
12926-23	Flap Actuator	Menasco Aerospace
12926-3A	Flap Actuator	Menasco Aerospace
12926-5A	Flap Actuator	Menasco Aerospace
12926-7A	Flap Actuator	Menasco Aerospace
12926-9A	Flap Actuator	Menasco Aerospace
12927-11A	Flap Actuator	Menasco Aerospace
12927-13A	Flap Actuator	Menasco Aerospace
12927-15A	Flap Actuator	Menasco Aerospace
12927-17A	Flap Actuator	Menasco Aerospace
12927-19	Flap Actuator	Menasco Aerospace
12927-19A	Flap Actuator	Menasco Aerospace
12927-23	Flap Actuator	Menasco Aerospace
12927-23A	Flap Actuator	Menasco Aerospace
12927-25	Flap Actuator	Menasco Aerospace
12927-3A	Flap Actuator	Menasco Aerospace
12927-5A	Flap Actuator	Menasco Aerospace
12927-7A	Flap Actuator	Menasco Aerospace
12927-9A	Flap Actuator	Menasco Aerospace
12928-11A	Flap Actuator	Menasco Aerospace
12928-13A	Flap Actuator	Menasco Aerospace
12928-15A	Flap Actuator	Menasco Aerospace
12928-17A	Flap Actuator	Menasco Aerospace
12928-19	Flap Actuator	Menasco Aerospace

Repair_Capability_List_Excel

12928-19A	Flap Actuator	Menasco Aerospace
12928-23	Flap Actuator	Menasco Aerospace
12928-23A	Flap Actuator	Menasco Aerospace
12928-25	Flap Actuator	Menasco Aerospace
12928-3A	Flap Actuator	Menasco Aerospace
12928-5A	Flap Actuator	Menasco Aerospace
12928-7A	Flap Actuator	Menasco Aerospace
12928-9A	Flap Actuator	Menasco Aerospace
12929-11A	Flap Actuator	Menasco Aerospace
12929-13A	Flap Actuator	Menasco Aerospace
12929-15A	Flap Actuator	Menasco Aerospace
12929-17	Flap Actuator	Menasco Aerospace
12929-17A	Flap Actuator	Menasco Aerospace
12929-19A	Flap Actuator	Menasco Aerospace
12929-21A	Flap Actuator	Menasco Aerospace
12929-23	Flap Actuator	Menasco Aerospace
12929-23A	Flap Actuator	Menasco Aerospace
12929-27	Flap Actuator	Menasco Aerospace
12929-29	Flap Actuator	Menasco Aerospace
12929-3A	Flap Actuator	Menasco Aerospace
12929-5A	Flap Actuator	Menasco Aerospace
129296-1	Pressure Anticipator	Honeywell
12929-7A	Flap Actuator	Menasco Aerospace
12929-9A	Flap Actuator	Menasco Aerospace
12930-11A	Flap Actuator	Menasco Aerospace
12930-13A	Flap Actuator	Menasco Aerospace
12930-15A	Flap Actuator	Menasco Aerospace
12930-17A	Flap Actuator	Menasco Aerospace
12930-19A	Flap Actuator	Menasco Aerospace
12930-21A	Flap Actuator	Menasco Aerospace
12930-23A	Flap Actuator	Menasco Aerospace
12930-27	Flap Actuator	Menasco Aerospace
12930-29	Flap Actuator	Menasco Aerospace
12930-3A	Flap Actuator	Menasco Aerospace
12930-5A	Flap Actuator	Menasco Aerospace
129307	Servo Control Actuator	Parker Hannifin
12930-7A	Flap Actuator	Menasco Aerospace
12930-9A	Flap Actuator	Menasco Aerospace
129440-1	Thermostat	Honeywell
129440-2	Thermostat	Honeywell
129448-1	Thermostat	Honeywell
129448-2	Thermostat	Honeywell
129475	Valve	Whittaker
129485	Valve assy	Meggitt Avionics
129525	Valve	Meggitt Avionics
129552-1-1	Pneumatic Thermostat	Honeywell
129580-6	Temperature Limiter	Honeywell
129612-1-1	Temperature Sensor	Honeywell
129645	Valve assy	Dynasciences
129666	Sensor	Honeywell
129666-1	Precooler Control Valve Sensor	Honeywell
129666-2	Precooler Control Valve Sensor	Honeywell
129694-1	Temperature Sensor	Honeywell
129694-2	Temperature Sensor	Honeywell
129700-02	Actuator	Lucas Aerospace
129700-03	Actuator	Lucas Aerospace
129700-06	Actuator	Lucas Aerospace
129700-08	Actuator	Lucas Aerospace

Repair_Capability_List_Excel

129738-1	Thermostat	Honeywell
12975-1	Flap System Feedback	Menasco Aerospace
12975-11	Flap Feedback assy	Menasco Aerospace
12975-3	Flap System Feedback	Menasco Aerospace
12975-5	Flap System Feedback	Menasco Aerospace
12975-7	Flap System Feedback	Menasco Aerospace
12975-9	Flap System Feedback	Menasco Aerospace
129878-1	Anticipator	Honeywell
12A073-4	Vane Actuator	Arkwin Industries
12A073-6	Vane Actuator	Arkwin Industries
12A073-7	Vane Actuator	Arkwin Industries
12A073-8	Vane Actuator	Arkwin Industries
12A092-3	By-pass Valve Actuator	Arkwin Industries
12A092-4	By-pass Valve Actuator	Arkwin Industries
12C1018	Valve	Allen Aircraft
12CBP61-05	Switch Guard	ECE
12CBP61-06	Switch Guard	ECE
12D1001	Valve	Allen Aircraft
12D1003	Valve	Allen Aircraft
12D1004	Valve	Allen Aircraft
12D1010	Valve	Allen Aircraft
12D1011	Valve	Allen Aircraft
12D1012	Valve	Allen Aircraft
12D1014-1	Valve	Allen Aircraft
12D1021-1	Valve	Allen Aircraft
12D117-13	Valve	Allen Aircraft
12D117-14	Valve	Allen Aircraft
12D117-4	Valve	Allen Aircraft
12D117-6	Valve	Allen Aircraft
12D117-9	Valve	Allen Aircraft
12D124-1	Valve	Allen Aircraft
12D124-10	Fill Water Valve	Allen Aircraft
12D124-5	Fill Water Valve	Allen Aircraft
12D124-6	Fill Water Valve	Allen Aircraft
12D149-3	Valve	Allen Aircraft
12XRP12A1	DC Reverse Current Circuit Breaker	General Electric
12XRP-12A1	Circuit Breaker	General Electric
130002N	Actuator assy	ITT Aeroapace
130003AB	Actuator assy	ITT Aeroapace
130003E	Actuator assy	ITT Aeroapace
130003E-1	Actuator assy	ITT Aeroapace
130003L	Actuator assy	ITT Aeroapace
130003L-1	Actuator assy	ITT Aeroapace
130003W	Actuator assy	ITT Aeroapace
130005P	Actuator	ITT Aerospace Ctrls
130009A	Actuator assy	ITT Aeroapace
130009B	Actuator assy	ITT Aeroapace
130009C	Actuator assy	ITT Aeroapace
130104-101	Cylinder	Goodrich Aerospace
130104-103	Cylinder	Goodrich Aerospace
130104-105	Cylinder	Goodrich Aerospace
130104-107	Cylinder	Goodrich Aerospace
130104-119	Cylinder	Goodrich Aerospace
130104-121	Cylinder	Goodrich Aerospace
130104-123	Cylinder	Goodrich Aerospace
130104-125	Cylinder	Goodrich Aerospace
130104-127	Cylinder	Goodrich Aerospace
130104-129	Cylinder	Goodrich Aerospace

Repair_Capability_List_Excel

130104-131	Cylinder	Goodrich Aerospace
130104-133	Cylinder	Goodrich Aerospace
130104-135	Cylinder	Goodrich Aerospace
130104-137	Cylinder	Goodrich Aerospace
130104-139	Cylinder	Goodrich Aerospace
130104-141	Cylinder	Goodrich Aerospace
130104-201	Cylinder	Goodrich Aerospace
130104-205	Cylinder	Goodrich Aerospace
130104-207	Cylinder	Goodrich Aerospace
130104-209	Cylinder	Goodrich Aerospace
130104-211	Cylinder	Goodrich Aerospace
130104-213	Cylinder	Goodrich Aerospace
130104-215	Cylinder	Goodrich Aerospace
130104-217	Cylinder	Goodrich Aerospace
130104-219	Cylinder	Goodrich Aerospace
130104-221	Cylinder	Goodrich Aerospace
130104-223	Cylinder	Goodrich Aerospace
130104-225	Cylinder	Goodrich Aerospace
130104-227	Cylinder	Goodrich Aerospace
130104-229	Cylinder	Goodrich Aerospace
130104-231	Cylinder	Goodrich Aerospace
130104-233	Cylinder	Goodrich Aerospace
130104-235	Cylinder	Goodrich Aerospace
130104-237	Cylinder	Goodrich Aerospace
1301-2	Motor	Auxilec
130158-1-1	Check Valve	Honeywell
130182-1	Pneumatic Relay	Honeywell
130182-1-1	Pneumatic Relay	Honeywell
13020	Parking Brake Valve	Weston Aerospace
130234-1	Time Relay	Honeywell
130337	Electro-Magnet	Goodrich Control Systems
130345	Center Wing Shut-Off Valve	Whittaker
130345-1	Center Wing Shut-Off Valve	Whittaker
1304-000	Pressure Switch	Intertechnique
130-4045	Control assy	Fokker
13050-1	Gearbox	Menasco Aerospace
13050-11	Flap Center Drive Gearbox	Menasco Aerospace
13050-3	Gearbox	Menasco Aerospace
13050-5	Gearbox	Menasco Aerospace
13050-7	Gearbox	Menasco Aerospace
13050-9	Flap Main Drive Gearbox	Menasco Aerospace
130522-1	Cabin Pressure Control Unit	Honeywell
130585	Valve	Meggitt Avionics
130595	Valve assy	Whittaker
130A01NA3	Light Cap	ECE
130A01NB3	Light Cap	ECE
130A01NV3	Light Cap	ECE
130E100-11	Rotary Actuator	Eaton Aerospace
130E100-13	Rotary Actuator	Eaton Aerospace
130E100-15	Rotary Actuator	Eaton Aerospace
130E100-2	Rotary Actuator	Eaton Aerospace
130E100-4	Rotary Actuator	Eaton Aerospace
130E100-9	Rotary Actuator	Eaton Aerospace
131004-2	Air Needle Valve	Honeywell
131004-7	Air Needle Valve	Honeywell
131150-1	Air Jet Pump	Honeywell
131150-1-1	Air Jet Pump	Honeywell
131160-1-1	Fan & Venturi Tube	Honeywell

Repair_Capability_List_Excel

131195	Valve	Whittaker
131200-1	Linear Actuator	Eaton
131252-1-1	Jet Ejector	Honeywell
1312A0000-01	By-Pass Valve	Liebherr Aerospace
1312B0000-01	By-Pass Valve	Liebherr Aerospace
131308-2	Pre-pressurization System	Honeywell
131310-1	Pre-pressurization System	Honeywell
131358-2	Control Valve	Honeywell
131410-1	Air Jet Pump	Honeywell
131485	Valve	Whittaker
1316200-3	Brake Metering Valve	Nabtesco
131CC01A02	Contactora	ECE
131FL01D3Y1	Switch	ECE
13200-5001	Valve	Parker Hannifin
1320600-1	Reservoir Fill Selector Valve	Nabtesco
132124-1	Pressure Regulator	Honeywell
132124-2	Pressure Regulator	Honeywell
1321-536250	Valve	Parker Hannifin
1321-566118	Valve	Parker Aerospace
1321-576662	Valve	Parker Aerospace
132172-1	Press Ratio Limit Valve	Honeywell
132282-3	Pressure Regulator	Honeywell
132322-1	Fan & Venturi	Honeywell
132322-2-1	Fan & Venturi	Honeywell
132322-3-1	Fan & Venturi	Honeywell
1323-566187	Pilot Float Valve	Parker Hannifin
1323-566187M1	Pilot Float Valve	Parker Hannifin
1324M10P01	FUEL FLOW TRANSMITTER	AMETEK
1324M10P02	FUEL FLOW TRANSMITTER	AMETEK
132706	Thermocouple	Weston Aerospace
1327-566098	Fuel Cap	Parker Hannifin
132845	Valve	Whittaker
1329-576530	Solenoid Pre-check Valve	Parker Hannifin
132VJ1RL13	Linear Actuator	Goodrich Control Systems
132VJ1RL13A	Linear Actuator	Goodrich Control Systems
132VJ2RL17	Linear Actuator	Goodrich
132VJ2RL17A	Linear Actuator	Goodrich
132VJ2RL17B	Linear Actuator	Goodrich
133016-2	Pressure Switch	Honeywell
1330622-070	3rd Occupant Seat	Sicma Aero Seat
1330622-070-1	3rd Occupant Seat	Sicma Aero Seat
1330622-070-2	3rd Occupant Seat	Sicma Aero Seat
1330622-100	3rd Occupant Seat	Sicma Aero Seat
1330622V	3rd Occupant Seat	Sicma Aero Seat
1330622V01	3rd Occupant Seat	Sicma Aero Seat
1330622V02	3rd Occupant Seat	Sicma Aero Seat
1330622V05	3rd Occupant Seat	Sicma Aero Seat
1330622V100-1	3rd Occupant Seat	Sicma Aero Seat
133258-1	Pressure Transducer	Honeywell
1333-542003	Valve	Whittaker
1333-542003M3	Valve	Whittaker
1333-593809	Valve	Parker Hannifin
1333-613233M1	Valve	Whittaker
1333-653527	Valve	Parker Hannifin
133-533-1011	Light	Korry Electronics
1338-1430	Rotating Mechanism	Labinal
1338-1450	Pressure Transducer	Labinal
134000-1	Linear Door Actuator	Eaton

Repair_Capability_List_Excel

134000-3	Linear Door Actuator	Eaton
134705	Valve	Whittaker
134RV	Engine Speed Indicator	Vibrometer
13503-104	Transmitter	Monogram Systems
1350722	Folding 3rd Occupant Seat	Sicma Aero Seat
1350722-1	Folding 3rd Occupant Seat	Sicma Aero Seat
1350722-2	Folding 3rd Occupant Seat	Sicma Aero Seat
1350722-3	Folding 3rd Occupant Seat	Sicma Aero Seat
135157-3	Air Filter assy	Honeywell
135157-4	Air Filter assy	Honeywell
135157-5	Air Filter assy	Honeywell
135157-6	Air Filter assy	Honeywell
135157-7	Air Filter assy	Honeywell
13550-1	Actuator	Menasco Aerospace
1355U-8-03	Pressure Indicator	Kollsman
135643	Thermocouple	Weston Aerospace
1356-603303	Accumulator	Parker-Hannifin
1356-603399	Accumulator	Parker-Hannifin
13581	Actuator	Manas
13581-1	Rudder Actuator	Menasco Aerospace
1359-579255	Steering Disconnect Valve	Parker Hannifin
13601	Transformer	Thales Avionics
13622-000	Air/Oil Heat Exchanger	Hughes Treitler
136608	Valve	Whittaker
136995	Shut-Off Valve	Whittaker
136A6-2	Water Drain	Intertechnique
137005	Shut-Off Valve	Whittaker
1370-100	Manocontact	Intertechnique
137035-1	Valve	Whittaker
1372-569466	Valve	Parker Hannifin
1372-579788	Valve assy	Parker Hannifin
1374M59P02	CIT PROBE	ROSEMOUNT
1374M59P03	CIT PROBE	ROSEMOUNT
137652	Thermocouple	Weston Aerospace
137661	Temperature Indicator	Weston Aerospace
138105	Valve	Meggitt Avionics
1386A0000-01 Amdt B	Servo-control Spoiler Actuator	Liebherr Aerotechnik
1386B0000-01	Servo-control Spoiler Actuator	Liebherr Aerotechnik
1387A0000-01 Amdt B	Servo-control Spoiler Actuator	Liebherr Aerotechnik
1387B0000-01	Servo-control Spoiler Actuator	Liebherr Aerotechnik
1387T100-11	Landing Gear Uplock Actuator	Telair International
1387T100-3	Landing Gear Uplock Actuator	Telair International
1387T100-5	Landing Gear Uplock Actuator	Telair International
1387T100-7	Landing Gear Uplock Actuator	Telair International
1387T100-9	Landing Gear Uplock Actuator	Telair International
1390A0100-01	PPU Adaptor assy	Liebherr Aerotechnik
1390A0200-01	APPU Shaft assy	Liebherr Aerotechnik
139595	Valve	Whittaker
139602-01-01	Indicator	Lear Siegler Inc
139725	Shut-Off Valve	Whittaker
139725-1	Shut-Off Valve	Whittaker
139735-1	Shut-Off Valve	Whittaker
139755	Shut-Off Valve	Whittaker
139755-1	Shut-Off Valve	Whittaker
139755-2	Shut-Off Valve	Whittaker
139775	Shut-Off Valve	Whittaker
139775-1	Shut-Off Valve	Whittaker
139905	Shut-Off Valve	Whittaker

Repair_Capability_List_Excel

139905-1	Shut-Off Valve	Whittaker
13CT0213A	Transmitter	CDA Astrointer
13TX0115-1	Transmitter	CDA Astrointer
13TX0115A	Transmitter	CDA Astrointer
13TX0615A	Transmitter	CDA Astrointer
13TX5315A	Transmitter	CDA Astrointer
140-0001-1	Control Unit	Rogerson Kratos
140-025-1	Transducer	Hydro-Aire
140-025-2	Transducer	Hydro-Aire
1400J12C1	Safety Toilet Coupling Plug	Kaiser Aerospace
1400J16C1	Safety Toilet Coupling Plug	Kaiser Aerospace
1402001-1	MLG Strut Spring	Sumitomo
1402020-1	MLG Strut Spring	Sumitomo
1402020-11	MLG Strut Spring	Sumitomo
1402-1TC1	Airspeed Indicator	Bendix
1402-4JC3	Airspeed Indicator	Bendix
1404KID-2	Five-Tank Indicator	Smiths Industries
1405A000	Valve	Norma
1405KID-2	Five-Tank Indicator	Smiths Industries
1406KID-02	Muti-Tank Indicator	Smiths Industries
1406KID-03	Muti-Tank Indicator	Smiths Industries
1407KID01-02	Fuel Quantity Indicator	Smiths Industries
1407KIDC1-01	Fuel Quantity Indicator	Smiths Industries
1408KID-01-002	Muti-Tank Indicator	Smiths Industries
140925	Valve	Meggitt Avionics
1409KID-02	Muti-Tank Indicator	Smiths Industries
140N2666-55	Handle Box assy	Boeing
140N2666-56	Handle Box assy	Boeing
140N2780-1	Gearbox assy	Boeing
140N2780-2	Gearbox assy	Boeing
140N2780-3	Gearbox assy	Boeing
140T2700-1	Forward and AFT Cargo Door	Boeing
140T2700-2	Forward and AFT Cargo Door	Boeing
140T2700-5	Forward and AFT Cargo Door	Boeing
140T2941-1	Forward/AFT Cargo Door Bungee	Boeing
140T2941-2	Forward/AFT Cargo Door Bungee	Boeing
141015	Valve	Whittaker
141082-025-01	Booster Pump	Pesco
1410KID-01	Muti-Tank Indicator	Smiths Industries
141100-1	Roller-Transport Type A	Telair International
141100-5	Roller-Transport Type A	Telair International
141100-7	Roller-Transport Type A	Telair International
1411KID-01	Muti-Tank Indicator	Smiths Industries
14127-1A	Vertical Gyro	Bendix
141385	Rotary Selector Valve	Whittaker
141385-1	Rotary Selector Valve	Whittaker
1417200-3	Thrust Reverser Isolation Valve	Nabtesco
1417200-5	Thrust Reverser Isolation Valve	Nabtesco
141A6105-1	Passenger Door Snubber	Boeing
141A6105-2	Passenger Door Snubber	Boeing
141A6105-3	Passenger Door Snubber	Boeing
141FL01D3	Switch	ECE
141T3016-10	Fwd Entry and Service Door	Boeing
141T3016-9	Fwd Entry and Service Door	Boeing
141T6102-10	Girt Bar Carrier Assy	Boeing
141T6102-11	Girt Bar Carrier Assy	Boeing
141T6102-6	Girt Bar Carrier Assy	Boeing
141T6102-7	Girt Bar Carrier Assy	Boeing

Repair_Capability_List_Excel

141T6105-3	Forward Entry and Service Door Track	Boeing
141T6105-4	Forward Entry and Service Door Track	Boeing
141T6105-45	Forward Entry and Service Door Track	Boeing
141T6105-49	Forward Entry and Service Door Track	Boeing
141T6105-50	Forward Entry and Service Door Track	Boeing
141T6105-51	Forward Entry and Service Door Track	Boeing
141T6105-65	Forward Entry and Service Door Track	Boeing
141T6121-1	Fwd Entry and Service Door	Boeing
141T6121-105	Fwd Entry and Service Door	Boeing
141T6121-107	Fwd Entry and Service Door	Boeing
141T6121-113	Fdw Entry and Service Door	Boeing
141T6121-115	Fwd Entry and Service Door	Boeing
141T6121-139	Fwd Entry and Service Door	Boeing
141T6121-141	Fwd Entry and Service Door	Boeing
141T6121-145	Fdw Entry and Service Door	Boeing
141T6121-146	Fwd Entry and Service Door	Boeing
141T6121-147	Fdw Entry and Service Door	Boeing
141T6121-148	Fwd Entry and Service Door	Boeing
141T6121-151	Fwd Entry and Service Door	Boeing
141T6121-3	Fwd Entry and Service Door	Boeing
141T6134-11	Entry/Service Doors Overcenter Mech.	Boeing
141T6134-12	Entry/Service Doors Overcenter Mech.	Boeing
141T6134-7	Entry/Service Doors Overcenter Mech.	Boeing
141T6134-8	Entry/Service Doors Overcenter Mech.	Boeing
141T6136-23	Fwd Entry/Service Door Handle Mech.	Boeing
141T6136-24	Fwd Entry/Service Door Handle Mech.	Boeing
141T6136-29	Fwd Entry/Service Door Handle Mech.	Boeing
141T6136-3	Fwd Entry/Service Door Handle Mech.	Boeing
141T6136-30	Fwd Entry/Service Door Handle Mech.	Boeing
141T6136-33	Fwd Entry/Service Door Handle Mech.	Boeing
141T6136-34	Fwd Entry/Service Door Handle Mech.	Boeing
141T6136-4	Fwd Entry/Service Door Handle Mech.	Boeing
141T6136-51	Fwd Entry/Service Door Handle Mech.	Boeing
141T6136-52	Fwd Entry/Service Door Handle Mech.	Boeing
141T6136-55	Fwd Entry/Service Door Handle Mech.	Boeing
141T6136-7	Fwd Entry/Service Door Handle Mech.	Boeing
141T6136-8	Fwd Entry/Service Door Handle Mech.	Boeing
141T6301-54	Elec/Elex Access Door	Boeing
141T6301-60	Elec/Elex Access Door	Boeing
141T6301-62	Elec/Elex Access Door	Boeing
141T6301-63	Elec/Elex Access Door	Boeing
141T6301-64	Elec/Elex Access Door	Boeing
141T6301-68	Elec/Elex Access Door	Boeing
141T6301-70	Elec/Elex Access Door	Boeing
141T6301-71	Elec/Elex Access Door	Boeing
141T6301-72	Elec/Elex Access Door	Boeing
141T6401-23	Forward Access Door	Boeing
141T6401-24	Forward Access Door	Boeing
141T6401-25	Forward Access Door	Boeing
141T6401-27	Forward Access Door	Boeing
141T6401-28	Forward Access Door	Boeing
141T6401-34	Forward Access Door	Boeing
141T6401-35	Forward Access Door	Boeing
141T6401-36	Forward Access Door	Boeing
141T6401-37	Forward Access Door	Boeing
141T6401-43	Forward Access Door	Boeing
141T6401-44	Forward Access Door	Boeing
141T6401-45	Forward Access Door	Boeing

Repair_Capability_List_Excel

141T6401-46	Forward Access Door	Boeing
141T6401-48	Forward Access Door	Boeing
141T6401-49	Forward Access Door	Boeing
141T6401-50	Forward Access Door	Boeing
141T6401-52	Forward Access Door	Boeing
141T6530-12	Entry and Service Doors Trolley/Link	Boeing
141T6530-15	Entry and Service Doors Trolley/Link	Boeing
141T6530-17	Entry and Service Doors Trolley/Link	Boeing
141T6530-18	Entry and Service Doors Trolley/Link	Boeing
141T6530-19	Entry and Service Doors Trolley/Link	Boeing
141T6530-20	Entry and Service Doors Trolley/Link	Boeing
141T6530-21	Entry and Service Doors Trolley/Link	Boeing
141T6530-22	Entry and Service Doors Trolley/Link	Boeing
141T6530-23	Entry and Service Doors Trolley/Link	Boeing
141T6530-24	Entry and Service Doors Trolley/Link	Boeing
141T6530-25	Entry and Service Doors Trolley/Link	Boeing
141T6530-26	Entry and Service Doors Trolley/Link	Boeing
141T6530-27	Entry and Service Doors Trolley/Link	Boeing
141T6530-28	Entry and Service Doors Trolley/Link	Boeing
141T6530-29	Entry and Service Doors Trolley/Link	Boeing
141T6561-3	Entry/Service Doors Handle Mech.Spring	Boeing
141T6561-4	Entry/Service Doors Handle Mech.Spring	Boeing
141T6583-25	Entry and Service Door Uplatch	Boeing
141T6583-28	Entry and Service Door Uplatch	Boeing
141T6583-29	Entry and Service Door Uplatch	Boeing
141T6583-30	Entry and Service Door Uplatch	Boeing
141T6910-19	Nose Landing Gear Forward Door	Boeing
141T6910-20	Nose Landing Gear Forward Door	Boeing
141T6910-21	Nose Landing Gear Forward Door	Boeing
141T6910-22	Nose Landing Gear Forward Door	Boeing
141T6910-27	Nose Landing Gear Forward Door	Boeing
141T6910-28	Nose Landing Gear Forward Door	Boeing
141T6910-29	Nose Landing Gear Forward Door	Boeing
141T6910-30	Nose Landing Gear Forward Door	Boeing
141T6910-31	Nose Landing Gear Forward Door	Boeing
141T6910-32	Nose Landing Gear Forward Door	Boeing
141T6910-33	Nose Landing Gear Forward Door	Boeing
141T6910-34	Nose Landing Gear Forward Door	Boeing
141T6910-35	Nose Landing Gear Forward Door	Boeing
141T6910-36	Nose Landing Gear Forward Door	Boeing
141T6910-39	Nose Landing Gear Forward Door	Boeing
141T6910-40	Nose Landing Gear Forward Door	Boeing
141T6920-37	Nose Landing Gear- AFT Door	Boeing
141T6920-38	Nose Landing Gear- AFT Door	Boeing
141T6920-39	Nose Landing Gear- AFT Door	Boeing
141T6920-40	Nose Landing Gear- AFT Door	Boeing
141T6920-41	Nose Landing Gear- AFT Door	Boeing
141T6920-42	Nose Landing Gear- AFT Door	Boeing
141T6920-45	Nose Landing Gear- AFT Door	Boeing
141T6920-46	Nose Landing Gear- AFT Door	Boeing
141T6920-50	Nose Landing Gear- AFT Door	Boeing
141T6920-52	Nose Landing Gear- AFT Door	Boeing
141T6920-53	Nose Landing Gear- AFT Door	Boeing
141T6920-54	Nose Landing Gear- AFT Door	Boeing
141T6963-4	Aft Nose Gear Door Strut	Boeing
141T6963-5	Aft Nose Gear Door Strut	Boeing
141T6963-6	Aft Nose Gear Door Strut	Boeing
141T6963-7	Aft Nose Gear Door Strut	Boeing

Repair_Capability_List_Excel

1421-000	Fuel Low Pressure Switch	Intertechnique
1421-100	Fuel Low Pressure Switch	Intertechnique
14-255A	Switch Trim	Kollmorgen Artus
1426-12DA1	Airspeed Indicator	Bendix
1426-12EA1	Airspeed Indicator	Bendix
1426-37AA6	Airspeed Indicator	Bendix
1426-47BB17	Airspeed Indicator	Bendix
1426A2A1	Airspeed Indicator	Bendix
14300-010	Motor Pump Filter assy	Monogram Systems
14300-011	Check Valve	Monogram Systems
14300-016	Motor	Monogram Systems
14300-065	Check Valve	Monogram Systems
14300-071	Valve assy	Monogram Systems
14300-084	Pump Filter assy	Monogram Systems
14300-092	Filter Unit-Motor Pump	Monogram Systems
14300-130	Motor	Monogram Systems
14300-136	Pump Filter assy	Monogram Systems
14300-137	Motor Pump Filter assy	Monogram Systems
14300-161	Check Valve	Monogram Systems
14300-330	LEVEL SENSOR	MONOGRAM
14300-335	LEVEL SENSOR	MONOGRAM
14302-201	Timer assy	Monogram Systems
14302-203	Timer assy	Monogram Systems
14302-205	Timer assy	Monogram Systems
14302-207	Timer assy	Monogram Systems
14302-209	Timer assy	Monogram Systems
14302-211	Timer assy	Monogram Systems
14310-101	Toilet assy	Monogram Systems
14310-102	Toilet assy	Monogram Systems
14310-103	Toilet assy	Monogram Systems
14310-107	Toilet assy	Monogram Systems
14310-108	Toilet assy	Monogram Systems
14310-201	Toilet assy	Monogram Systems
14310-202	Toilet assy	Monogram Systems
14310-203	Toilet assy	Monogram Systems
14310-205	Toilet assy	Monogram Systems
14310-206	Toilet assy	Monogram Systems
14310-301	Toilet assy	Monogram Systems
14310-302	Toilet assy	Monogram Systems
14310-303	Toilet assy	Monogram Systems
14310-304	Toilet assy	Monogram Systems
14310-305	Toilet assy	Monogram Systems
14310-307	Toilet assy	Monogram Systems
14310-401	Toilet assy	Monogram Systems
14310-402	Toilet assy	Monogram Systems
14310-403	Toilet assy	Monogram Systems
14312-020-1	Motor Pump	Monogram Systems
14312-020-2	Motor Pump	Monogram Systems
14312-026	Drain Valve Assy	Monogram Systems
14312-046	Drain Valve Assy	Monogram Systems
14312-076	Drain Valve Assy	Monogram Systems
14312-078	Drain Valve assy	Monogram Systems
14312-079	Drain Valve assy	Monogram Systems
14312-080	Drain Valve Assy	Monogram Systems
14320-001-1	Toilet assy	Monogram Systems
14320-001-2	Toilet assy	Monogram Systems
14320-001A1	Toilet assy	Monogram Systems
14320-001A2	Toilet assy	Monogram Systems

Repair_Capability_List_Excel

14320-001C1	Toilet assy	Monogram Systems
14320-001C2	Toilet assy	Monogram Systems
14320-002-1	Toilet assy	Monogram Systems
14320-002-2	Toilet assy	Monogram Systems
14320-002A1	Toilet assy	Monogram Systems
14320-002A2	Toilet assy	Monogram Systems
14320-002B1	Toilet assy	Monogram Systems
14320-002B2	Toilet assy	Monogram Systems
14320-002C1	Toilet assy	Monogram Systems
14320-002C2	Toilet assy	Monogram Systems
14320-020	Drain Valve Assy	Monogram Systems
14320-030	Drain Valve Assy	Monogram Systems
14320-230-1	Toilet assy	Monogram Systems
14320-230-2	Toilet assy	Monogram Systems
14330-004A1	Toilet assy	Monogram Systems
14330-004A2	Toilet assy	Monogram Systems
14330-004B1	Toilet assy	Monogram Systems
14330-004B2	Toilet assy	Monogram Systems
14330-008-1	Toilet assy	Monogram Systems
14330-008-2	Toilet assy	Monogram Systems
14330-050	Flush Valve	Monogram Systems
14330-144	Flush Control Unit	Monogram Systems
14330-350	Vacuum Generator	Monogram Systems
1433-613004	Actuator	Parker Hannifin
1433-613187	Actuator	Parker Hannifin
1433-613523	Actuator	Parker Aerospace
1433-623304	Actuator	Parker Hannifin
1433-663011	Actuator	Parker Hannifin
1433-663089	Actuator	Parker Aerospace
143415	Swivel	Deutsch Metal
143420	Swivel	Deutsch Metal
143425	Swivel	Deutsch Metal
143430	Swivel	Deutsch Metal
14350-006	Toilet assy	Monogram Systems
14352-002	Check Valve	Monogram Systems
14352-009	Filter Motor Pump assy	Monogram Systems
14352-010	Drain Valve	Monogram Systems
143705	Pump & Motor	Monogram Systems
143705-1	Pump & Motor	Monogram Systems
14378	Rod assy	Sarma
143D6354G2	Thrust Mode Select Panel ay	BAE Systems
143T6105-5	MID Entry Door Upper Track	Boeing
143T6105-6	MID Entry Door Upper Track	Boeing
143T6121-1	Door Assy MID Entry	Boeing
143T6121-2	Door Assy MID Entry	Boeing
143T6135-3	Entry/Service Doors Overcenter Mech.	Boeing
143T6135-4	Entry/Service Doors Overcenter Mech.	Boeing
143T6135-7	Entry/Service Doors Overcenter Mech.	Boeing
143T6135-8	Entry/Service Doors Overcenter Mech.	Boeing
143T6140-3	MID Entry/Service Door Handle Mech.	Boeing
143T6140-4	MID Entry/Service Door Handle Mech.	Boeing
143T6140-7	MID Entry/Service Door Handle Mech.	Boeing
143T6140-8	MID Entry/Service Door Handle Mech.	Boeing
143T6200-1	Main Deck Cargo Door	Boeing
143T6300-1	Large Cargo Door	Boeing
143T6300-2	Large Cargo Door	Boeing
143T6501-10	Cargo Door Latch Lock Ctrl Handle Mech	Boeing
143T6501-5	Cargo Door Latch Lock Ctrl Handle Mech	Boeing

Repair_Capability_List_Excel

143T6501-7	Cargo Door Latch Lock Ctrl Handle Mech	Boeing
143T6501-8	Cargo Door Latch Lock Ctrl Handle Mech	Boeing
143T6501-9	Cargo Door Latch Lock Ctrl Handle Mech	Boeing
14400-200-1	Toilet assy	Monogram Systems
14400-200-2	Toilet assy	Monogram Systems
14400-200A1	Toilet assy	Monogram Systems
14400-200A2	Toilet assy	Monogram Systems
14400-200B1	Toilet assy	Monogram Systems
14400-200B2	Toilet assy	Monogram Systems
14400-200C1	Toilet assy	Monogram Systems
14400-200C2	Toilet assy	Monogram Systems
14400-203A2	Valve assy	Monogram Systems
14400-230B1	Toilet assy	Monogram Systems
14400-230B2	Toilet assy	Monogram Systems
14400-230C1	Toilet assy	Monogram Systems
14400-230C2	Toilet assy	Monogram Systems
14401-002	Vacuum Generator	Monogram Systems
14401-003A	Vacuum Generator	Monogram Systems
14401-003B	Vacuum Generator	Monogram Systems
14401-003C	Vacuum Generator	Monogram Systems
14401-004	Check Valve	Monogram Systems
14401-005	Water Separator	Monogram Systems
14401-060	Water Separator	Monogram Systems
14402-001	Drain Valve Assy	Monogram Systems
14403-001	Waste Holding Tank assy	Monogram Systems
14403-003	Liquid Level Transmitter	Monogram Systems
14403-003A	Liquid Level Transmitter	Monogram Systems
14403-003B	Liquid Level Transmitter	Monogram Systems
14403-003C	Liquid Level Transmitter	Monogram Systems
14403-004	Liquid Level Sensor	Monogram Systems
14403-085	Liquid Level Sensor	Monogram Systems
14404-001-1	Vacuum System Controller	MAG Aerospace
14404-011	Vacuum System Controller	MAG Aerospace
14404-011-1	Vacuum System Controller	MAG Aerospace
14404-011A	Vacuum System Controller	MAG Aerospace
14404-011B	Vacuum System Controller	MAG Aerospace
144-151-000-101	Accelerometer	Vibrometer
144-171-000-031	Accelerometer	Vibrometer
1441G1K20	Headset	Holmberg
144213-010-01	Booster Pump	Hamilton Sundstrand
144213-020-01	Booster Pump	Hamilton Sundstrand
14-43040-1	Hydraulic Reservoir	North Safety Products
144305	Valve	Whittaker
144805	Water Pump	Weber Aircraft
14490	Shaft	Sarma
1453PGCP1	Fuel Low Pressure Warning Switch	Vibrometer
145765-1	Motor Pump	Monogram Systems
14602-1JA1	Gyroscopic Horizon Indicator	Bendix
14602-1JB1	Gyroscopic Horizon Indicator	Bendix
14602-1JC1	Gyroscopic Horizon Indicator	Bendix
14602-1JD1	Gyroscopic Horizon Indicator	Bendix
14602-1JE1	Gyroscopic Horizon Indicator	Bendix
14602-1JF1	Gyroscopic Horizon Indicator	Bendix
14608-1ANB1	Gyroscopic Horizon Indicator	Bendix
14608-1APB1	Gyroscopic Horizon Indicator	Bendix
146099	Fuel Indicator	Smiths Industries
1460T100	Roller	Telair International
1460T100-1	Roller	Telair International

Repair_Capability_List_Excel

1460T100-1A	Roller	Telair International
1460T100-3	Roller	Telair International
146280	Indicator	Whittaker
1463T100-1	Linear Actuator	Telair International
1463T100-2	Linear Actuator	Telair International
1463T100-3	Linear Actuator	Telair International
1463T100-4	Linear Actuator	Telair International
146435-1	Valve	Whittaker
146505-1	Valve	Whittaker
146905	Valve	Whittaker
146915	Valve	Whittaker
146T6121-1	Aft Entry and Service Door	Boeing
146T6121-5	Aft Entry and Service Door	Boeing
146T6121-69	Aft Entry and Service Door	Boeing
146T6121-7	Aft Entry and Service Door	Boeing
146T6121-70	Aft Entry and Service Door	Boeing
146T6121-77	Aft Entry and Service Door	Boeing
146T6121-78	Aft Entry and Service Door	Boeing
146T6121-79	Aft Entry and Service Door	Boeing
146T6121-80	Aft Entry and Service Door	Boeing
146T6121-81	Aft Entry and Service Door	Boeing
146T6121-82	Aft Entry and Service Door	Boeing
146T6125-15	Entry/Service Doors Overcenter Mech.	Boeing
146T6125-16	Entry/Service Doors Overcenter Mech.	Boeing
146T6125-19	Entry/Service Doors Overcenter Mech.	Boeing
146T6125-20	Entry/Service Doors Overcenter Mech.	Boeing
146T6125-23	Entry/Service Doors Overcenter Mech.	Boeing
146T6125-24	Entry/Service Doors Overcenter Mech.	Boeing
146T6125-27	Entry/Service Doors Overcenter Mech.	Boeing
146T6125-28	Entry/Service Doors Overcenter Mech.	Boeing
146T6140-11	Aft Entry/Service Door Handle Mech.	Boeing
146T6140-12	Aft Entry/Service Door Handle Mech.	Boeing
146T6140-17	Aft Entry/Service Door Handle Mech.	Boeing
146T6140-18	Aft Entry/Service Door Handle Mech.	Boeing
146T6140-37	Aft Entry/Service Door Handle Mech.	Boeing
146T6140-38	Aft Entry/Service Door Handle Mech.	Boeing
146T6140-41	Aft Entry/Service Door Handle Mech.	Boeing
146T6140-42	Aft Entry/Service Door Handle Mech.	Boeing
146T6140-45	Aft Entry/Service Door Handle Mech.	Boeing
146T6140-46	Aft Entry/Service Door Handle Mech.	Boeing
146T6140-49	Aft Entry/Service Door Handle Mech.	Boeing
146T6140-50	Aft Entry/Service Door Handle Mech.	Boeing
146T6140-7	Aft Entry/Service Door Handle Mech.	Boeing
146T6140-8	Aft Entry/Service Door Handle Mech.	Boeing
146T6301-1	Bulk Cargo Door	Boeing
146T6301-3	Bulk Cargo Door	Boeing
146T6387-5	Cargo Door Balance Syst.Spring Tube	Boeing
146T6387-6	Cargo Door Balance Syst.Spring Tube	Boeing
147265	Valve	Meggitt Avionics
147265-1	Valve	Meggitt Avionics
147425-1	Valve	Whittaker
147425-2	Valve	Whittaker
147425-3	Valve assy	Whittaker
147465	Valve	Whittaker
147825	Valve	Whittaker
147BDL21	Thermometer	Horizon Aerospace
148065	Valve	Whittaker
148085	Valve	Meggitt Avionics

Repair_Capability_List_Excel

148105	Valve	Meggitt Avionics
148275	Valve	Whittaker
148465	Valve	Meggitt Avionics
148725	Pump	Weber Aircraft
148885	Valve assy	Whittaker
148885-1	Valve assy	Whittaker
148975-1	Motor Operated Rotary Selector Valve	Whittaker
148975-2	Motor Operated Rotary Selector Valve	Whittaker
148995	Shut-Off Valve	Whittaker
148995-1	Shut-Off Valve	Whittaker
148T6550-1	Auxiliary Power Unit Access Door	Boeing
148T6550-2	Auxiliary Power Unit Access Door	Boeing
149150-01-01	Indicator	Smiths Industries
149150-01-02	Indicator	Smiths Industries
149155-01-02	Indicator	Smiths Industries
149270-01-01	TAT/EPR Indicator	Smiths Industries
149270-02-01	TAT/EPR Indicator	Smiths Industries
149270-03-01	TAT/EPR Indicator	Smiths Industries
149270-04-01	TAT/EPR Indicator	Smiths Industries
149270-05-01	TAT/EPR Indicator	Smiths Industries
149635-1	Valve	Whittaker
149645	Valve	Whittaker
14975	Valve	Whittaker
1497672-002	Pressure Transmitter	Honeywell
14-98324-02	Wiper	Marqu
149T6902-39	Main Landing Gear Door Hinge Bellcrank	Boeing
149T6902-40	Main Landing Gear Door Hinge Bellcrank	Boeing
149T6902-43	Main Landing Gear Door Hinge Bellcrank	Boeing
149T6902-44	Main Landing Gear Door Hinge Bellcrank	Boeing
149T6902-45	Main Landing Gear Door Hinge Bellcrank	Boeing
149T6902-46	Main Landing Gear Door Hinge Bellcrank	Boeing
149T6902-5	Main Landing Gear Door Hinge Bellcrank	Boeing
149T6902-6	Main Landing Gear Door Hinge Bellcrank	Boeing
149T6902-69	Main Landing Gear Door Hinge Bellcrank	Boeing
149T6902-70	Main Landing Gear Door Hinge Bellcrank	Boeing
149T6902-71	Main Landing Gear Door Hinge Bellcrank	Boeing
149T6902-72	Main Landing Gear Door Hinge Bellcrank	Boeing
149T6903-7	Main Landing Gear Door Uplock	Boeing
149T6903-8	Main Landing Gear Door Uplock	Boeing
149T6910-1	Main Landing Gear Door	Boeing
149T6910-2	Main Landing Gear Door	Boeing
149T6910-29	Main Landing Gear Door	Boeing
149T6910-30	Main Landing Gear Door	Boeing
149T7771-15	Ram Air Turbine Access Door	Boeing
15-0003-10	Flood Light	Grimes Aerospace
15-0003-11	Flood Light	Grimes Aerospace
15-0003-2	Flood Light	Grimes Aerospace
15-0003-3	Flood Light	Grimes Aerospace
15-0003-5	Flood Light	Grimes Aerospace
15-0003-6	Flood Light	Grimes Aerospace
15-0003-7	Flood Light	Grimes Aerospace
15-0003-8	Flood Light	Grimes Aerospace
15-0007-1	Cockpit Utility Light	Grimes Aerospace
15-0007-101	Cockpit Utility Light	Grimes Aerospace
15-0007-103	Cockpit Utility Light	Grimes Aerospace
15-0007-105	Cockpit Utility Light	Grimes Aerospace
15-0007-107	Cockpit Utility Light	Grimes Aerospace
15-0007-109	Cockpit Utility Light	Grimes Aerospace

Repair_Capability_List_Excel

15-0007-91	Cockpit Utility Light	Grimes Aerospace
15-0007-93	Cockpit Utility Light	Grimes Aerospace
15-0007-95	Cockpit Utility Light	Grimes Aerospace
15-0007-97	Cockpit Utility Light	Grimes Aerospace
15-0007-99	Cockpit Utility Light	Grimes Aerospace
15-0069-1	Light	Grimes Aerospace
15-0069-13	Light	Grimes Aerospace
15-0069-15	Light	Grimes Aerospace
15-0069-17	Light	Grimes Aerospace
15-0069-19	Light	Grimes Aerospace
15-0069-21	Light	Grimes Aerospace
15-0069-23	Light	Grimes Aerospace
15-0069-25	Light	Grimes Aerospace
15-0069-3	Light	Grimes Aerospace
15-0069-5	Light	Grimes Aerospace
1500P31	Anti-Icing Overpressure Indicator	ITT Aerospace Ctrls
15-0103-1	Dome Light assy	Grimes Aerospace
15-0103-3	Dome Light assy	Grimes Aerospace
15-0103-5	Dome Light assy	Grimes Aerospace
15-0105-1	Panel Light	Grimes Aerospace
15-0105-3	Panel Light	Grimes Aerospace
15-0188-1	Dome Light	Grimes Aeroapace
15-0188-11	Dome Light	Grimes Aeroapace
15-0188-13	Dome Light	Grimes Aeroapace
15-0188-15	Dome Light	Grimes Aeroapace
15-0188-19	Dome Light	Grimes Aeroapace
15-0188-21	Dome Light	Grimes Aeroapace
15-0188-5	Dome Light	Grimes Aeroapace
15-0188-7	Dome Light	Grimes Aeroapace
15-0188-9	Dome Light	Grimes Aeroapace
150201	Actuator	Whittaker
15-0247-9	Service Compartment Light	Grimes Aerospace
15-0248-107	Baggage Compartment Light	Grimes Aerospace
15-0258-5	Main Landing Gear Truck Light	Grimes Aerospace
15-0258-9	Main Landing Gear Truck Light	Grimes Aerospace
15-0277-1	Engine Compartment Dome Light	Grimes Aerospace
15-0277-5	Engine Compartment Dome Light	Grimes Aerospace
150485	Pump & Motor	Weber Aircraft
150485-1	Pump & Motor	Weber Aircraft
15-0714-1	Map Reading Light	Grimes Aeroapace
15-0714-3	Map Reading Light	Grimes Aerospace
15-0714-4	Map Reading Light	Grimes Aeroapace
15-0714-5	Map Reading Light	Grimes Aeroapace
150T36-1	Thermo Switch assy	Custom Control Sensors
150T36-2	Switch	Custom Control Sensors
150T44-2	Switch	Custom Control Sensors
1510F2200-000	Swivel Arm	System Technik Nord
1510H000	Solenoid Valve	Normalair-Garrett
1510S4000-002	Control Box	System Technik Nord
1510S4000-004	Control Box	System Technik Nord
1510S4000-006	Control Box	System Technik Nord
1510S4000-008	Control Box	System Technik Nord
1510S5000-000	Control Box	System Technik Nord
1510S5000-002	Control Box	System Technik Nord
15110-105	SHOCK STRUT	MESSIER DOWTY
151105001	Selector Valve	Dowty Aerospace
1511F1100-000	Cargo Control	System Technik Nord
1511F2000-000	Cargo Control	System Technik Nord

Repair_Capability_List_Excel

1511F3000	Cargo Control Panel	EMM
1511F3000-000	Cargo Control	System Technik Nord
1511N4000-000	Cargo Control	System Technik Nord
1511N5000-000	Cargo Control	System Technik Nord
1511S3000C000	Cargo Control Box	System Technik Nord
1511S3000C002	Cargo Control Box	System Technik Nord
1511S3000C004	Cargo Control Box	System Technik Nord
151245001	RAT Uplock assy	Messier-Dowty
151780-2	Oil Cooler	Honeywell
1518-14A	Rotary Inverter	Bendix
1518-14E	Rotary Inverter	Bendix
1518-16A	Rotary Inverter	Bendix
1518-8C	Rotary Inverter	Bendix
1518-8E	Rotary Inverter	Bendix
152	Transformer	Auxilec
152050-3-1	Tubular Oil Cooler	Honeywell
152050-4-1	Tubular Oil Cooler	Honeywell
152050-5-1	Tubular Oil Cooler	Honeywell
152050-6-1	Tubular Oil Cooler	Honeywell
1520F0000-000	Control Panel	System Technik Nord
1520N0101-000	Cable assy	STN Atlas Elektronik
1520S0000-000	Control Box	System Technik Nord
1520S0000-000A	Control Box	STN Atlas Elektronik
152305-1	Actuator	Whittaker
152305-2	Actuator	Whittaker
1523153-115	Landing Gear Position	Lockheed
1523153-119	Landing Gear Position	Lockheed
1523328-115	Actuator	Lockheed
1524E560	Actuator	Goodrich Control Systems
152530-01-01	MODE SEL PANEL	SMITHS
152550	Electrical Motor assy	Whittaker
1525551-109	Weight	Lockheed
152623	Thermocouple	Weston Aerospace
15263-101	GLG Harnesses	Messier-Bugatti
15263-103	GLG Harnesses	Messier-Bugatti
15264-101	GLG Harnesses	Messier-Bugatti
15264-103	GLG Harnesses	Messier-Bugatti
15265-101	GLG Harnesses	Messier-Bugatti
15265-103	GLG Harnesses	Messier-Bugatti
15266-101	GLG Harnesses	Messier-Bugatti
15266-103	GLG Harnesses	Messier-Bugatti
1527700-3	Aileron Power Control Unit	Nabtesco
1527700-5	Aileron Power Control Unit	Nabtesco
1529200-1	Yaw Damper Servo	Nabtesco
152B2	Indicator	Honeywell
152B4	Indicator	Honeywell
152B8	Indicator	Honeywell
152CA01C1-02Y1	Three Pole Contactor	ECE
153	Transformer	Auxilec
1531463-30	Stator	Honeywell
1532-2A	De-Icer Distributor Valve	Goodrich
1532-3A	De-Icing Distribution Valve	Goodrich
1532-3B	De-Icing Distribution Valve	Goodrich
1532-3C	De-Icing Distribution Valve	Goodrich
1532-6A	De-Icer Distributor Valve	Goodrich
1532-6C	De-Icer Distributor Valve	Goodrich
1533A	Junction & Amplifier	TEAM
1533B	Junction & Amplifier	TEAM

Repair_Capability_List_Excel

1533C	Junction & Amplifier	TEAM
1536400-11	Inboard Elevator Actuator	Nabtesco
1536400-31	Inboard Elevator Actuator	Nabtesco
1536400-503	Inboard Elevator Actuator	Nabtesco
1536400-51	Inboard Elevator Actuator	Nabtesco
1536400-703	Inboard Elevator Actuator	Nabtesco
1536400-71	Inboard Elevator Actuator	Nabtesco
1536500-11	Outboard Elevator Actuator	Nabtesco
1536500-31	Outboard Elevator Actuator	Nabtesco
1536500-51	Outboard Elevator Actuator	Nabtesco
1536500-71	Outboard Elevator Actuator	Nabtesco
1536600-1	Yaw Damper Servo	Nabtesco
1536600-3	Yaw Damper Servo	Nabtesco
1536600-5	Yaw Damper Servo	Nabtesco
1536600-7	Yaw Damper Servo	Nabtesco
15370-101	CLG Harnesses	Dowty Canada
15370-103	CLG Harnesses	Dowty Canada
15371-101	CLG Harnesses	Dowty Canada
15371-103	CLG Harnesses	Dowty Canada
1538200-1	Leading Edge Slat Actuator	Nabtesco
154	Transformer	Auxilec
1540500-1	Yaw Damper Servo	Nabtesco
1540500-11	Yaw Damper Servo	Nabtesco
1540500-3	Yaw Damper Servo	Nabtesco
1540500-5	Yaw Damper Servo	Nabtesco
1540500-7	Yaw Damper Servo	Nabtesco
1540500-9	Yaw Damper Servo	Nabtesco
1540600-1	Aileron Power Control Unit	Nabtesco
1540600-3	Aileron Power Control Unit	Nabtesco
1542500-1	Inboard Spoiler Power Control	Nabtesco
1542500-11	Inboard Spoiler Power Control	Nabtesco
1542500-13	Inboard Spoiler Power Control	Nabtesco
1542500-15	Inboard Spoiler Power Control	Nabtesco
1542500-3	Inboard Spoiler Power Control	Nabtesco
1542500-5	Inboard Spoiler Power Control	Nabtesco
1542500-7	Inboard Spoiler Power Control	Nabtesco
1542500-9	Inboard Spoiler Power Control	Nabtesco
1542600-1	Outboard Spoiler Power Control	Nabtesco
1542600-11	Outboard Spoiler Power Control	Nabtesco
1542600-13	Outboard Spoiler Power Control	Nabtesco
1542600-15	Outboard Spoiler Power Control	Nabtesco
1542600-17	Outboard Spoiler Power Control	Nabtesco
1542600-19	Outboard Spoiler Power Control	Nabtesco
1542600-3	Outboard Spoiler Power Control	Nabtesco
1542600-5	Outboard Spoiler Power Control	Nabtesco
1542600-7	Outboard Spoiler Power Control	Nabtesco
1542600-9	Outboard Spoiler Power Control	Nabtesco
1544100-3	Flaperon Power Control Unit	Nabtesco
1544100-5	Flaperon Power Control Unit	Nabtesco
1544100-7	Flaperon Power Control Unit	Nabtesco
1544200-1	Aileron Power Control Unit	Nabtesco
1544200-3	Aileron Power Control Unit	Nabtesco
1544300-3	Elevator Power Control Unit	Nabtesco
1544400-3	Rudder Power Control Unit	Nabtesco
1546-01-5	CTL UNIT	SIMMONDS
1546-1-1	Dimmer	Avtech
1546-1-2	Dimmer	Avtech
1546-1-3	Dimmer	Avtech

Repair_Capability_List_Excel

1546-1-4	Dimmer	Avtech
1546-1-5	Dimmer	Avtech
1546-1-6	Dimmer	Avtech
1547-1	Light	Avtech
1547-1-1	Light	Avtech
1547143-1	Exciter Stator	Honeywell
1547154-1	PMG Stator	Honeywell
1547750-1	Stator assy	Honeywell
1547T100-1	Latch Pallet	Telair International
1547T100-1A	Latch Pallet	Telair International
1547T100-3	Latch Pallet	Telair International
1548-1-2	Lamp	Avtech
1548200-1	Rudder Power Control Unit	Nabtesco
1548671-2	End Bell assy	Honeywell
1548T100-3	Latch Pallet	Telair International
1548T100-3A	Latch Pallet	Telair International
1549-1-1	Light	Avtech
1549-1-2	Light	Avtech
1549581-1	Stator assy	Honeywell
1549583-1	End Bell assy	Honeywell
154BY	Temperature Sensor	Goodrich
15500-1011	CLG Retraction Actuator	Messier-Bugatti
15500-103	CLG Retraction Actuator	Messier-Bugatti
15500-1031	CLG Retraction Actuator	Messier-Bugatti
1553A9900-01	HP Manifold	Liebherr Aerospace
1554A9900-01	HP Manifold	Liebherr Aerospace
1555A9900-01	PTU Manifold	Liebherr Aerospace
1556000-1	Spoiler Actuator assy	Nabtesco
1556A9900-01	PTU Manifold	Liebherr Aerospace
155750	Actuator assy	Whittaker
155750-1	Actuator assy	Whittaker
155770-4	Actuator assy	Meggitt Avionics
1558-041040	Oil Pressure Indicator	Kollsman
155850-1	Actuator assy	Meggitt Avionics
1558B-041040	Oil Pressure Indicator	Kollsman
1558C-041040	Oil Pressure Indicator	Kollsman
1559A9900-01	HP Manifold	Liebherr Aerospace
156	Transformer	Thales Avionics
15600-101	CLG Downlock Release Actuator	Messier-Bugatti
15600-103	CLG Downlock Release Actuator	Messier-Bugatti
1560690-109	Light	Tristar
1560690-111	Light	Tristar
1560690-113	Light	Tristar
1561200-1	Rudder Power Control Unit	Nabtesco
1561300-1	Rudder Power Control Unit	Nabtesco
156210-1	Fuel Heater	Honeywell
15622-000	Air/Oil Heat Exchanger	Hughes Treitler
15625	Encoder	Fairchild
1566-1-1	Monitor assy	Avtech
1566-1-2	Monitor assy	Avtech
1567700-3	Flaperon Power Control Unit	Nabtesco
1567A0000-01	Selector Valve	Liebherr Aerotechnik
1571B	Amplifier	SFIM
1572T100-11	Butterfly Valve	Telair International
1572T100-13	Butterfly Valve	Telair International
1572T100-15	Butterfly Valve	Telair International
1572T100-17	Butterfly Valve	Telair International
1572T100-19	Butterfly Valve	Telair International

Repair_Capability_List_Excel

1572T100-3	Butterfly Valve	Telair International
1572T100-5	Butterfly Valve	Telair International
1572T100-7	Butterfly Valve	Telair International
1572T100-9	Butterfly Valve	Telair International
157405-01-01	TAT/N1 Indicator	Smiths Industries
157405-02-01	TAT/N1 Indicator	Smiths Industries
157405-03-01	TAT/N1 Indicator	Smiths Industries
157409-02-01	MODE SEL PANEL	SMITHS
1576A0000-01	CLG Door Actuator	Liebherr Aerotechnik
157710-4	Actuator	Meggitt Avionics
157720-1	Rotary Actuator	Meggitt Avionics
157720-2	Rotary Actuator	Meggitt Avionics
15772-3	Drive assy	Hamilton Sundstrand
158000-104	Autopilot Actuator	Moog
158000-105	Autopilot Actuator	Moog
158000-15	Fuel Canister	FR Hitemp
158000-21	Fuel Element	FR Hitemp
15800-348	Rinse Valve assy	Monogram
15800-348A	Rinse Valve assy	Monogram
1580147-1	Rotor Armature	Honeywell
158210-11	Fuel/Oil Heat Exchanger	Honeywell
158210-14	Fuel/Oil Heat Exchanger	Honeywell
158210-16	Fuel/Oil Heat Exchanger	Honeywell
158210-18	Fuel/Oil Heat Exchanger	Honeywell
158210-5	Fuel/Oil Heat Exchanger	Honeywell
158210-6	Fuel/Oil Heat Exchanger	Honeywell
158210-7	Fuel/Oil Heat Exchanger	Honeywell
158210-8	Fuel/Oil Heat Exchanger	Honeywell
158300-100	Autopilot Actuator	Moog
158300-101	Autopilot Actuator	Moog
158300-102	Autopilot Actuator	Moog
1583130-1	Housing & Stator assy	Honeywell
1583829-1	Housing & Stator assy	Honeywell
158440-3	Oil Cooler	Goodrich Control Systems
158570	Oil Heater	Honeywell
15866-1A	Vertical Gyro	Bendix/King
15866-1B	Vertical Gyro	Bendix/King
15866-1C	Vertical Gyro	Bendix/King
15866-1D	Vertical Gyro	Bendix/King
15866-2C	Vertical Gyro	Bendix/King
15866-2D	Vertical Gyro	Bendix/King
15866-3C	Vertical Gyro	Bendix/King
15870	Vaneaxial Fan assy	Hamilton Sundstrand
15870-1	Vaneaxial Fan assy	Hamilton Sundstrand
158935-1	Oil Temperature Control Valve	Honeywell
158935-2	Oil Temperature Control Valve	Honeywell
15897-1A	Vertical Gyro	Honeywell
15897-1C	Vertical Gyro	Bendix/King
15897-1D	Vertical Gyro	Honeywell
15897-2D	Vertical Gyro	Honeywell
159120-01-01	MODE SEL PANEL	SMITHS
159120-02-01	MODE SEL PANEL	SMITHS
16005-001	Valve	Monogram Systems
16006-001	Motor Pump	Monogram Systems
160065-3	Valve	Koehl
1600D000	Cooling Unit	Honeywell
160122-1	Oil Cooler	Honeywell
160126-2	Regulator	Honeywell

Repair_Capability_List_Excel

160142-1	Fuel/Oil Heat Exchanger	Honeywell
160142-2	Fuel/Oil Heat Exchanger	Honeywell
160142-4	Fuel/Oil Heat Exchanger	Honeywell
160142-5	Fuel/Oil Heat Exchanger	Honeywell
160186-1	Oil Temperature Regulator	Honeywell
160186-1 SER A	Oil Temperature Regulator	Honeywell
160186-1 SER B	Oil Temperature Regulator	Honeywell
160282-1	Air/Oil Cooler assy	Honeywell
160282-2	Air/Oil Cooler assy	Honeywell
160282-3	Air/Oil Cooler assy	Honeywell
160282-4	Air/Oil Cooler assy	Honeywell
160282-5	Air/Oil Cooler assy	Honeywell
160282-6	Air/Oil Cooler assy	Honeywell
160424-2	Oil Temperature Regulator	Honeywell
160466-1	Oil Temp Regulator	Honeywell
1605000-1	Thrust Reverser Actuator	Parker Hannifin
160500-100	Stabilizer Control Brake ay	Moog
160500-101	Stabilizer Control Brake ay	Moog
16052-0001	Power Dividor	Thales Avionics
160544-1	Ignitor	Hamilton Sundstrand
160550-1	Temp Control Valve	Honeywell
160564-1	Oil Cooler	Honeywell
1606100-001	Cable assy	Transdigm
1606140-001	Cable assy	Transdigm
160668-1	Air/Oil Cooler assy	Honeywell
1608450	Overflow Valve	FR Hitemp
1608550	Overflow Valve	FR Hitemp
1608555	Valve assy	FR Hitemp
1608565	Valve assy	FR Hitemp
160ZA01-02	Cell-Photoresistor	ECE
161A1500-1	MLG Installation Components	Boeing
161A1500-2	MLG Installation Components	Boeing
161A2100-1	Main Landing Gear Side Strut	Boeing
161A2100-2	Main Landing Gear Side Strut	Boeing
161A6300-1	MLG Installation Components	Boeing
161A6301-1	MLG Installation Components	Boeing
161A6302-1	MLG Installation Components	Boeing
161A6303-1	MLG Installation Components	Boeing
161A6303-2	MLG Installation Components	Boeing
161A7000-3	MLG Walking Beam Components	Boeing
161A7000-4	MLG Walking Beam Components	Boeing
161A7100-1	MLG Walking Beam Components	Boeing
161A7100-2	MLG Walking Beam Components	Boeing
161A7119-1	MLG Walking Beam Components	Boeing
161A7301-1	MLG Walking Beam Components	Boeing
161A7303-1	MLG Walking Beam Components	Boeing
161A7304-1	MLG Walking Beam Components	Boeing
161A7304-2	MLG Walking Beam Components	Boeing
161A7304-3	MLG Walking Beam Components	Boeing
161B101	Thermometer	Horizon Aerospace
161BCL2	Electrical Resistance Thermometer	Horizon Aerospace
161BL302	Thermometer	Horizon Aerospace
161BL501	Thermometer	Horizon Aerospace
161N0001-113	Actuator	Boeing
161N0001-115	Actuator	Boeing
161N0001-116	Actuator	Boeing
161N0001-136	Actuator	Boeing
161N0001-147	Actuator	Boeing

Repair_Capability_List_Excel

161N0001-148	Actuator	Boeing
161N0001-22	Actuator	Boeing
161N0001-50	Actuator	Boeing
161N0001-54	Actuator	Boeing
161N0001-55	Actuator	Boeing
161N0001-81	Actuator	Boeing
161N5001-113	Uplock Actuator	Boeing
161N5001-22	Uplock Actuator	Boeing
161N5001-5	Uplock Actuator	Boeing
161N5001-50	Uplock Actuator	Boeing
161N5001-7	Uplock Actuator	Boeing
161N5002-4	MLG Uplock	Boeing
161N5002-5	MLG Uplock	Boeing
161N5002-6	MLG Uplock	Boeing
161N5002-7	MLG Uplock	Boeing
161T2033-1	Main Landing Gear Spring Cartridge	Boeing
161T2033-2	Main Landing Gear Spring Cartridge	Boeing
16204	Filter	Monogram Systems
16204-001	Motor	Monogram Systems
16204-002	Motor	Monogram Systems
16204-003	Motor	Monogram Systems
16205-001	Valve	Monogram Systems
16205-002	Drain Valve	Monogram Systems
16205-012	Valve	Monogram Systems
16205-100	Valve	Monogram Systems
16205-101	Valve	Monogram Systems
16205-102	Valve	Monogram Systems
1620T100-3	Actuator	Telair International
1621C450	Indicator	.
162A0301-1	NLG Installation Components	Boeing
162A0302-1	NLG Installation Components	Boeing
162A2100-1	Nose Landing Gear Drag Strut	Boeing
162A2301-1	NLG Installation Components	Boeing
162A2302-1	NLG Installation Components	Boeing
162A2302-2	NLG Installation Components	Boeing
162A3100-1	Door Mechanism	Boeing
162BCL81	Indicator	Horizon Aerospace
162BCL82W	Indicator	Horizon Aerospace
162BL402	Indicator	Horizon Aerospace
162BL402A	Indicator	Horizon Aerospace
162BL403	Indicator	Horizon Aerospace
162BL403A	Indicator	Horizon Aerospace
162BL403B	Indicator	Horizon Aerospace
162BL403C	Indicator	Horizon Aerospace
162BL602	Indicator	Horizon Aerospace
162C38	Indicator	Honeywell
162C38A	Indicator	Honeywell
162T4001-10	NLG Door Operator Fwd Door Mech.	Boeing
162T4001-9	NLG Door Operator Fwd Door Mech.	Boeing
162T4002-1	NLG Door Operator Fwd Door Mech.	Boeing
162T4002-3	NLG Door Operator Fwd Door Mech.	Boeing
162T4004-3	NLG Door Operator Fwd Door Mech.	Boeing
162T4010-1	NLG Door Operator Fwd Door Mech.	Boeing
162T4012-1	NLG Door Operator Fwd Door Mech.	Boeing
162T4012-2	NLG Door Operator Fwd Door Mech.	Boeing
162T4012-7	NLG Door Operator Fwd Door Mech.	Boeing
162T4012-8	NLG Door Operator Fwd Door Mech.	Boeing
163000-103	Autopilot Lat.Ctrl Servo Actuator	Moog

Repair_Capability_List_Excel

163000-104	Autopilot Lat.Ctrl Servo Actuator	Moog
163000-105	Autopilot Lat.Ctrl Servo Actuator	Moog
163000-106	Autopilot Lat.Ctrl Servo Actuator	Moog
163000-107	Autopilot Lat.Ctrl Servo Actuator	Moog
163000-108	Autopilot Lat.Ctrl Servo Actuator	Moog
163100-101	Autopilot Pitch Ctrl Servo Actuator	Moog
163100-102	Autopilot Pitch Ctrl Servo Actuator	Moog
163100-103	Autopilot Pitch Ctrl Servo Actuator	Moog
163100-104	Autopilot Pitch Ctrl Servo Actuator	Moog
163100-105	Autopilot Pitch Ctrl Servo Actuator	Moog
163100-106	Autopilot Pitch Ctrl Servo Actuator	Moog
163100-107	Autopilot Pitch Ctrl Servo Actuator	Moog
163200-100	Autopilot Rollout Ctrl Servo Actuator	Moog
163200-101	Autopilot Rollout Ctrl Servo Actuator	Moog
163200-102	Autopilot Rollout Ctrl Servo Actuator	Moog
163200-103	Autopilot Rollout Ctrl Servo Actuator	Moog
163200-104	Autopilot Rollout Ctrl Servo Actuator	Moog
163200-105	Autopilot Rollout Ctrl Servo Actuator	Moog
16330-3	Windshield Water Pump	Hamilton Sundstrand
1634-1AL-C1-1	Rate of Climb Indicator	Bendix/King
1634-1AT-C1-1	Rate of Climb Indicator	Bendix/King
1634-2AC-C1-1	Rate of Climb Indicator	Bendix/King
163T0000-020	Tail Skid Complete Shock Strut	Boeing
163T0000-021	Tail Skid Complete Shock Strut	Boeing
163T1000-1	Tail Skid Installation Components	Boeing
16430-1	Pump	Hamilton Sundstrand
16432	Variable Transformer	Oeco Corporation
164PG	Pressure Transmitter	Vibrometer
164PG-M	Pressure Transmitter	Vibrometer
164PG-SB	Pressure Transmitter	Vibrometer
164PG-SB-M	Pressure Transmitter	Vibrometer
16500-1	Vaneaxial Fan assy	Hamilton Sundstrand
16500-2	Vaneaxial Fan assy	Hamilton Sundstrand
16500-3	Vaneaxial Fan assy	Hamilton Sundstrand
16500-5	Actuator	Menasco Aerospace
1650E412	Ballscrew	Goodrich Control Systems
1650R139	Gearbox	Goodrich Control Systems
1651	Pressure Relief Valve	Pneudraulics Inc
16510	Vaneaxial Fan assy	Hamilton Sundstrand
1652	Pressure Relief Valve	Pneudraulics Inc
16520	Vaneaxial Fan assy	Hamilton Sundstrand
16520-1	Fan assy	Hamilton Sundstrand
16520-2	Fan assy	Hamilton Sundstrand
16520-3	Fan assy	Hamilton Sundstrand
16550-1	Manifold	Hamilton Sundstrand
16580-1	Valve	Hamilton Sundstrand
16590-1	Valve	Hamilton Sundstrand
165RC01	Solid State Flasher	ECE
165RC01W	Solid State Flasher	ECE
165W01003	Pump	Dynapower
165W01004-5	Pump	Dynapower
165W01007	Pump	Dynapower
165W01010-3	Pump	Dynapower
165W01020	Aux Motor Driven Pump	Dynapower
165W01022	Hydraulic Motor Pump	Vickers
16600-1	Valve	Hamilton Sundstrand
16600-2	Valve	Hamilton Sundstrand
16602-1	Valve	Hamilton Sundstrand

Repair_Capability_List_Excel

1666MK5	Master LPC Bleed Actuator	Goodrich
1667	Valve assy	Pneudraulics Inc
1667MK3	Slave LPC Bleed Actuator	Goodrich
166D100	Sill Actuator	Eaton
166D100-1	Sill Actuator	Eaton
16730-1	Fan	Hamilton Sundstrand
16730-2	Fan	Hamilton Sundstrand
167457	Engine Control Harness assy	Hamilton Sundstrand
1674DA1	Flap Actuator	Sangamoweston
1674DA2	Flap Actuator	Sangamoweston
1674DA3	Flap Actuator	Sangamoweston
1674DA4	Flap Actuator	Sangamoweston
1674DA5	Flap Actuator	Sangamoweston
16780-2	Fan assy	Hamilton Sundstrand
16783-1	Motor Pump	Hamilton Sundstrand
16783-2	Motor Pump	Hamilton Sundstrand
16792-1A	Actuator	Bendix/King
168661-3	Oil Cooler	Hamilton Sundstrand
1692RA-10	Valve	Sargent
1692RA-11	Valve	Sargent
1692RA-12	Valve	Sargent
1692RA-4	Valve	Sargent
1692RA-5	Valve	Sargent
1692RA-7	Valve	Sargent
1692RA-8	Valve	Sargent
1692RA-9	Valve	Sargent
1697EA	Hydraulic Control Valve	Sangamoweston
1699073501	AOA SENSOR	SEXTANT
169967	Fuel Pump	Hamilton Sundstrand
16C193	Check Valve	Allen Aircraft
16C194	Check Valve	Allen Aircraft
170-001-125	Circuit Breaker	Mechanical Products
170-001-140	Circuit Breaker	Mechanical Products
170-001-160	Circuit Breaker	Mechanical Products Inc
170-001-200	Circuit Breaker	Mechanical Products
1700064	Slat & Flap Actuation Control	Hamilton Sundstrand
1700064A	Slat & Flap Actuation Control	Hamilton Sundstrand
1700064B	Slat & Flap Actuation Control	Hamilton Sundstrand
1700089	Rotor Balance assy	Hamilton Sundstrand
1700591	Power Drive Unit	Hamilton Sundstrand
1700593	Inboard & Outboard Slat Actuator	Hamilton Sundstrand
1700595	Sealed Bearing Support	Hamilton Sundstrand
1700597	Inboard & Outboard Slat Actuator	Hamilton Sundstrand
1700599	Angle Gearbox	Hamilton Sundstrand
1700637	Angle Gearbox	Hamilton Sundstrand
1700639	Angle Gearbox	Hamilton Sundstrand
1700641	Bearing Support	Hamilton Sundstrand
1700891	AC Generator	Hamilton Sundstrand
1701320	Generator assy	Hamilton Sundstrand
1701422	Rotor Balance assy	Hamilton Sundstrand
1701422A	Rotor Balance assy	Hamilton Sundstrand
170155	Fuel Control Pump assy	Hamilton Sundstrand
1701736	Input Housing assy	Hamilton Sundstrand
1702286	RH & LH Slat Disconnect Sensor	Hamilton Sundstrand
1702288	RH & LH Slat Disconnect Sensor	Hamilton Sundstrand
1702885B	Type B & D Slat Actuator	Hamilton Sundstrand
1702885C	Type B & D Slat Actuator	Hamilton Sundstrand
1702961	Bearing Support	Hamilton Sundstrand

Repair_Capability_List_Excel

1703781	Ram Air Turbine	Hamilton Sundstrand
1703785	Deployment Actuator assy	Hamilton Sundstrand
1703787	Uplock assy	Hamilton Sundstrand
1703815	Generator assy	Hamilton Sundstrand
1703883	Torque Tube assy	Hamilton Sundstrand
1703909	Type B & D Slat Actuator	Hamilton Sundstrand
1703911	Inboard & Outboard Slat Actuator	Hamilton Sundstrand
1703913	Torque Tube assy	Hamilton Sundstrand
1703917	Torque Tube assy	Hamilton Sundstrand
1703939	Center Housing assy	Hamilton Sundstrand
1704203	Torque Tube assy	Hamilton Sundstrand
1704208	Angle Gearbox	Hamilton Sundstrand
1704600-1	Pressure Reducer By-Pass Valve	Nabtesco
1704600-3	Pressure Reducer By-Pass Valve	Nabtesco
1704600-5	Pressure Reducer By-Pass Valve	Nabtesco
1705800-1	Elevator Feel Shift Module	Nabtesco
1705900-1	Bulk Cargo Door Snubler assy	Nabtesco
1706-1	Valve	Pneudraulics Inc
170ZS01Y01	Aural Warning Trim	ECE
170ZS01Y02	Aural Warning Trim	ECE
17201-1A	Transmitter	Bendix/King
17210-1A	Transmitter	Bendix/King
17216-1A	Transmitter	Bendix/King
17216-2A	Transmitter	Bendix/King
1721F3	Drain Line Level Sensor	Goodrich
1721F4	Drain Line Level Sensor	Goodrich
17240-1A	Transmitter	Bendix/King
17240-2A	Transmitter	Bendix/King
172625-5	Pneumatic Valve assy	Whittaker
172625-6	Pneumatic Valve assy	Whittaker
172625-7	Pneumatic Valve assy	Whittaker
17290-3-4	Windshield Wiper Motor	Hamilton Sundstrand
172EP01T02	Unlocking Solenoid	ECE
173-1010-1	Thrust Reverser Assy	Rohr
173-1010-2	Thrust Reverser Assy	Rohr
173-1010-501	Thrust Reverser Assy	Rohr
173-1010-503	Thrust Reverser Assy	Rohr
173-1010-507	Thrust Reverser Assy	Rohr
173-1010-508	Thrust Reverser Assy	Rohr
173-1010-509	Thrust Reverser Assy	Rohr
173-1010-511	Thrust Reverser Assy	Rohr
173-1010-513	Thrust Reverser Assy	Rohr
173-1010-515	Thrust Reverser Assy	Rohr
173-1010-516	Thrust Reverser Assy	Rohr
173-1010-517	Thrust Reverser Assy	Rohr
173-1010-519	Thrust Reverser Assy	Rohr
173-1010-521	Thrust Reverser Assy	Rohr
173-1010-523	Thrust Reverser Assy	Rohr
173-1010-525	Thrust Reverser Assy	Rohr
173-1010-526	Thrust Reverser Assy	Rohr
173-1010-527	Thrust Reverser Assy	Rohr
173-1010-528	Thrust Reverser Assy	Rohr
173-1201	Panel	Rohr
173-1204	Panel	Rohr
1732510	Filter assy	Facet Enterprises
1732510-02	Filter assy	Facet Enterprises
173251003	Filter assy	Facet Enterprises
1747-11	Air Outlet	Puritan Bennett

Repair_Capability_List_Excel

1747-17	Air Outlet	Puritan Bennett
1747-2	Individual Air Outlet	BE Aerospace
174EP01T	Unlocking Solenoid	ECE
174RV-CP-1	Engine Speed Indicator	Vibrometer
1753M52P02	Differential Pressure Switch	Westport International
1763H1	Microfilter	Fairey Hydraulics
1763-H1	Filter	Fairey Hydraulics
176900-200	Flap Actuator	Curtiss-Wright
176900-201	Flap Actuator	Curtiss-Wright
177-131	Transformer	ITT Aerospace Ctrl
1775EA	Valve	Sargent Controls
1776365-201	Horizon Flight Director Indicator	Honeywell
1776365-202	Horizon Flight Director Indicator	Honeywell
1776365-203	Horizon Flight Director Indicator	Honeywell
1776365-204	Horizon Flight Director Indicator	Honeywell
1776365-205	Horizon Flight Director Indicator	Honeywell
1776365-207	Horizon Flight Director Indicator	Honeywell
1776365-208	Horizon Flight Director Indicator	Honeywell
1776365-209	Horizon Flight Director Indicator	Honeywell
1776365-324	Horizon Flight Director Indicator	Honeywell
1776365-325	Horizon Flight Director Indicator	Honeywell
1776365-354	Horizon Flight Director Indicator	Honeywell
1776365-355	Horizon Flight Director Indicator	Honeywell
1776365-358	Horizon Flight Director Indicator	Honeywell
1776365-359	Horizon Flight Director Indicator	Honeywell
1776365-424	Horizon Flight Director Indicator	Honeywell
1776365-425	Horizon Flight Director Indicator	Honeywell
1776365-454	Horizon Flight Director Indicator	Honeywell
1776365-455	Horizon Flight Director Indicator	Honeywell
1776365-458	Horizon Flight Director Indicator	Honeywell
1776365-459	Horizon Flight Director Indicator	Honeywell
1776365-600	Horizon Flight Director Indicator	Honeywell
1776365-601	Horizon Flight Director Indicator	Honeywell
1776365-602	Horizon Flight Director Indicator	Honeywell
1776365-603	Horizon Flight Director Indicator	Honeywell
1776365-604	Horizon Flight Director Indicator	Honeywell
1776365-605	Horizon Flight Director Indicator	Honeywell
1776365-606	Horizon Flight Director Indicator	Honeywell
1776365-607	Horizon Flight Director Indicator	Honeywell
1776365-620	Horizon Flight Director Indicator	Honeywell
1776365-621	Horizon Flight Director Indicator	Honeywell
1776365-622	Horizon Flight Director Indicator	Honeywell
1776365-623	Horizon Flight Director Indicator	Honeywell
1776365-624	Horizon Flight Director Indicator	Honeywell
1776365-625	Horizon Flight Director Indicator	Honeywell
1776365-626	Horizon Flight Director Indicator	Honeywell
1776365-627	Horizon Flight Director Indicator	Honeywell
1776365-700	Horizon Flight Director Indicator	Honeywell
1776365-701	Horizon Flight Director Indicator	Honeywell
1776365-702	Horizon Flight Director Indicator	Honeywell
1776365-703	Horizon Flight Director Indicator	Honeywell
1776365-704	Horizon Flight Director Indicator	Honeywell
1776365-705	Horizon Flight Director Indicator	Honeywell
1776365-706	Horizon Flight Director Indicator	Honeywell
1776365-707	Horizon Flight Director Indicator	Honeywell
1776365-720	Horizon Flight Director Indicator	Honeywell
1776365-721	Horizon Flight Director Indicator	Honeywell
1776365-722	Horizon Flight Director Indicator	Honeywell

Repair_Capability_List_Excel

1776365-723	Horizon Flight Director Indicator	Honeywell
1776365-724	Horizon Flight Director Indicator	Honeywell
1776365-725	Horizon Flight Director Indicator	Honeywell
1776365-726	Horizon Flight Director Indicator	Honeywell
1776365-727	Horizon Flight Director Indicator	Honeywell
1776365-824	Horizon Flight Director Indicator	Honeywell
1776365-825	Horizon Flight Director Indicator	Honeywell
1776365-854	Horizon Flight Director Indicator	Honeywell
1776365-855	Horizon Flight Director Indicator	Honeywell
1776365-858	Horizon Flight Director Indicator	Honeywell
1776365-859	Horizon Flight Director Indicator	Honeywell
1776365-924	Horizon Flight Director Indicator	Honeywell
1776365-925	Horizon Flight Director Indicator	Honeywell
1776365-954	Horizon Flight Director Indicator	Honeywell
1776365-955	Horizon Flight Director Indicator	Honeywell
1776365-958	Horizon Flight Director Indicator	Honeywell
1776365-959	Horizon Flight Director Indicator	Honeywell
1776885	Control Indicator	Sperry Flight
1777211-601	Course Indicator	Honeywell
1777211-701	Course Indicator	Honeywell
1777213	Gyrosyn Compass Indicator	Honeywell
1777213-603	Gyrosyn Compass Indicator	Honeywell
1777214-603	Gyrosyn Compass Indicator	Honeywell
1777215-625	Gyrosyn Compass Indicator	Honeywell
1778MK1	Slave LPC Bleed Actuator	Goodrich
1779DA	Actuator	Sargent Controls
1779MK2	Bearing N4 Scavange Valve	Goodrich
177BCL3	Thermometer	Horizon Aerospace
178050-2-1	Water Separator	Honeywell
178050-3-1	Water Separator	Honeywell
1783867-1	Servo Amplifier	Honeywell
1783867-11	Servo Amplifier	Honeywell
1783867-2	Servo Amplifier	Honeywell
1783867-3	Servo Amplifier	Honeywell
1783867-4	Servo Amplifier	Honeywell
1784023-3	Sensor	Honeywell
1784389-623	Gyrosyn Compass Indicator	Honeywell
1784389-653	Gyrosyn Compass Indicator	Honeywell
1784460-355	Indicator Compass	Honeywell
1784460-525	Indicator Compass	Honeywell
1784460-555	Indicator Compass	Honeywell
1784460-655	Indicator Compass	Honeywell
1784460-656	Indicator Compass	Honeywell
1784460-657	Indicator Compass	Honeywell
178800-101	Flap Actuator	Curtiss-Wright
178800-102	Flap Actuator	Curtiss-Wright
178800-103	Flap Actuator	Curtiss-Wright
178800-104	Flap Actuator	Curtiss-Wright
178800-105	Flap Actuator	Curtiss-Wright
178800-106	Flap Actuator	Curtiss-Wright
178800-107	Flap Actuator	Curtiss-Wright
178800-108	Flap Actuator	Curtiss-Wright
178800-109	Flap Actuator	Curtiss-Wright
178800-201	Flap Actuator	Curtiss-Wright
178800-202	Flap Actuator	Curtiss-Wright
178800-203	Flap Actuator	Curtiss-Wright
178800-204	Flap Actuator	Curtiss-Wright
178800-205	Flap Actuator	Curtiss-Wright

Repair_Capability_List_Excel

178800-206	Flap Actuator	Curtiss-Wright
178800-207	Flap Actuator	Curtiss-Wright
178800-208	Flap Actuator	Curtiss-Wright
178800-209	Flap Actuator	Curtiss-Wright
178900-2	Flap Actuator	Curtiss-Wright
178900-3	Flap Actuator	Curtiss-Wright
178900-4	Flap Actuator	Curtiss-Wright
178900-5	Flap Actuator	Curtiss-Wright
178900-6	Flap Actuator	Curtiss-Wright
179060-2	Brake assy	Curtiss-Wright
179060-4	Brake assy	Curtiss-Wright
179120-2	Starter Motor	Hamilton Sundstrand
179120-3	Starter Motor	Hamilton Sundstrand
179127-2	Ball Screw assy	Curtiss-Wright
179190-14	Switch Box	Curtiss-Wright
179190-14ATA	Can Switch	Curtiss-Wright
179190-15	Switch Box	Curtiss-Wright
179190-15ATA	Can Switch	Curtiss-Wright
179190-9	Switch Box	Curtiss-Wright
179370-1	Solenoid Valve	Curtiss-Wright
179406-2	Ball Screw assy	Curtiss-Wright
179420-2	Ignition Exciter	Hamilton Sundstrand
179438	Anti-Surge Valve	Hamilton Sundstrand
179452-2	Ball Screw assy	Curtiss-Wright
179455	Fuel Pump	Hamilton Sundstrand
179455-2	Fuel Pump	Hamilton Sundstrand
179460-3-3	Water Separator	Honeywell
179460-8-1	Water Separator	Honeywell
179460-9	Water Separator	Honeywell
179461-7	Coupling	Curtiss-Wright
179468-2	Ball Screw assy	Curtiss-Wright
179505	Ignition Lead assy	Hamilton Sundstrand
179525-3	Comparator	Curtiss-Wright
179528-3	Servo Valve	Hamilton Sundstrand
1795H1	Microfilter	Fairey Hydraulics
1795-H1	Filter	Fairey Hydraulics
179601-4	Flap Actuator Gearbox	Curtiss-Wright
179601-5	Flap Actuator Gearbox	Curtiss-Wright
179601-6	Flap Actuator Gearbox	Curtiss-Wright
179602-4	Flap Actuator Gearbox	Curtiss-Wright
179602-5	Flap Actuator Gearbox	Curtiss-Wright
179602-6	Flap Actuator Gearbox	Curtiss-Wright
179603-4	Flap Actuator Gearbox	Curtiss-Wright
179603-5	Flap Actuator Gearbox	Curtiss-Wright
179603-6	Flap Actuator Gearbox	Curtiss-Wright
179604-4	Flap Actuator Gearbox	Curtiss-Wright
179604-5	Flap Actuator Gearbox	Curtiss-Wright
179604-6	Flap Actuator Gearbox	Curtiss-Wright
179606	Rear Ball Screw Mount assy	Curtiss-Wright
179606-1	Rear Ball Screw Mount assy	Curtiss-Wright
179606-2	Rear Ball Screw Mount assy	Curtiss-Wright
179610-10	Gearbox assy	Curtiss-Wright
179610-11	Gearbox assy	Curtiss-Wright
179610-8	Gearbox assy	Curtiss-Wright
179610-9	Gearbox assy	Curtiss-Wright
179611-9	Ball Screw assy	Curtiss-Wright
179612-9	Ball Screw assy	Curtiss-Wright
179614-9	Ball Screw assy	Curtiss-Wright

Repair_Capability_List_Excel

179615-9	Ball Screw assy	Curtiss-Wright
179616-2	LH Fwd Gearbox	Curtiss-Wright
179616-3	LH Fwd Gearbox	Curtiss-Wright
179617-2	RH Fwd Gearbox	Curtiss-Wright
179617-3	RH Fwd Gearbox	Curtiss-Wright
179618-1	Aft Angle Brake Gearbox	Curtiss-Wright
179618-2	Aft Angle Brake Gearbox	Curtiss-Wright
179620-14	Power Drive Unit	Curtiss-Wright
179620-19	Power Drive Unit	Curtiss-Wright
179620-20	Power Drive Unit	Curtiss-Wright
179620-21	Power Drive Unit	Curtiss-Wright
179620-22	Power Drive Unit	Curtiss-Wright
179620-23	Power Drive Unit	Curtiss-Wright
179620-24	Power Drive Unit	Curtiss-Wright
179621-3	Shaft Assembly	Curtiss-Wright
179621-4	Shaft Assembly	Curtiss-Wright
179622-1	Shaft Assembly	Curtiss-Wright
179622-10	Shaft Assembly	Curtiss-Wright
179622-11	Shaft Assembly	Curtiss-Wright
179622-12	Shaft Assembly	Curtiss-Wright
179622-13	Shaft Assembly	Curtiss-Wright
179622-14	Shaft Assembly	Curtiss-Wright
179622-15	Shaft Assembly	Curtiss-Wright
179622-16	Shaft Assembly	Curtiss-Wright
179622-2	Shaft Assembly	Curtiss-Wright
179622-3	Shaft Assembly	Curtiss-Wright
179622-5	Shaft Assembly	Curtiss-Wright
179622-6	Shaft Assembly	Curtiss-Wright
179622-8	Shaft Assembly	Curtiss-Wright
179622-9	Shaft Assembly	Curtiss-Wright
179623-5	Shaft Assembly	Curtiss-Wright
179623-6	Shaft Assembly	Curtiss-Wright
179623-7	Shaft Assembly	Curtiss-Wright
179623-8	Shaft Assembly	Curtiss-Wright
179625-10	Shaft Assembly	Curtiss-Wright
179625-11	Shaft Assembly	Curtiss-Wright
179625-12	Shaft Assembly	Curtiss-Wright
179626-6	Shaft Assembly	Curtiss-Wright
179626-8	Shaft Assembly	Curtiss-Wright
179626-9	Shaft Assembly	Curtiss-Wright
179627-5	Shaft Assembly	Curtiss-Wright
179627-6	Shaft Assembly	Curtiss-Wright
179630-3	Yoke assy	Curtiss-Wright
179631-3	Yoke assy	Curtiss-Wright
179631-4	Yoke assy	Curtiss-Wright
179675-2	Torque Brake assy	Curtiss-Wright
179757	Oil Cooler assy	Hamilton Sundstrand
1797MK2	Master LPC Bleed Actuator	Goodrich
179832-1-1	Heat Exchanger	Honeywell
179835-8	Hydraulic Control Valve	Curtiss-Wright
179877-2	T.E. Flap Transmitter	Curtiss-Wright
17989-2	Actuator	Conrac Corporation
17989-3	Actuator	Conrac Corporation
17989-4	Actuator	Conrac Corporation
1798MK1	Slave LPC Bleed Actuator	Goodrich
17B25	Temperature Indicator	Honeywell
17B31	Temperature Indicator	Honeywell
17B531	Temperature Indicator	Honeywell

Repair_Capability_List_Excel

1800	Valve	Pneudraulics Inc
180231-1	Hydraulic Motor	Curtiss-Wright
180231-2	Hydraulic Motor	Curtiss-Wright
180231-3	Hydraulic Motor	Curtiss-Wright
180231-4	Hydraulic Motor	Curtiss-Wright
1807H1	Sampling Valve	Fairey Hydraulics
1808420	Starter	Honeywell
18-1000-1	Engine Gauge Unit	A.I.D.
18-1258-1	Indicator	Bendix/King
18-1299	Flap Position Indicator	Honeywell
18-1299-6	Flap Position Indicator	Honeywell
18-1299-6-2	Flap Position Indicator	Honeywell
18-1510-5	Indicator	Honeywell
18-1510-8	Indicator	Honeywell
18-1540	Indicator	Honeywell
18-1541	Indicator	Honeywell
18-1545	Indicator	Honeywell
18-1557	Indicator	Honeywell
18-1570-13	Flap Position Transmitter	Honeywell
18-1585-10	Flap Position Transmitter	Honeywell
18-1585-11	Flap Position Transmitter	Honeywell
18-1585-14	Flap Position Transmitter	Honeywell
18-1585-15	Flap Position Transmitter	Honeywell
18-1586-12	Flap Position Transmitter	Honeywell
18-1586-16	Flap Position Transmitter	Honeywell
18-1597	Dual Duct Pressure Indicator	Honeywell
18-1704	Transmitter	Bendix/King
18-1738-1	Transmitter	Bendix/King
18-1738-10	Flap Position Transmitter	Honeywell
18-1738-3	Flap Position Transmitter	Honeywell
18-1738-5	Flap Position Transmitter	Honeywell
18-1738-52	Flap Position Transmitter	Honeywell
18-1738-6	Flap Position Transmitter	Honeywell
18-1738-7	Flap Position Transmitter	Honeywell
18-1738-8	Flap Position Transmitter	Honeywell
18-1738-9	Flap Position Transmitter	Honeywell
18-1739-2	Flap Position Transmitter	Honeywell
18-1739-4	Flap Position Transmitter	Honeywell
18-1958-10	Flap Position Transmitter	Honeywell
18-1958-11	Flap Position Transmitter	Honeywell
18-1958-12	Flap Position Transmitter	Honeywell
18-1958-13	Flap Position Transmitter	Honeywell
18-1958-14	Flap Position Transmitter	Honeywell
18-1958-15	Flap Position Transmitter	Honeywell
18-1958-16	Flap Position Transmitter	Honeywell
18-1958-17	Flap Position Transmitter	Honeywell
18-1958-19	Flap Position Transmitter	Honeywell
18-1958-20	Flap Position Transmitter	Honeywell
18-1958-21	Flap Position Transmitter	Honeywell
18-1958-7	Flap Position Transmitter	Honeywell
18-1958-8	Flap Position Transmitter	Honeywell
18-1968-3	Wheel Position Transmitter	Honeywell
18-1968-31	Wheel Position Transmitter	Honeywell
18-1969-12	Flap/Slat Transmitter	Honeywell
18-1969-13	Flap/Slat Transmitter	Honeywell
18-1969-14	Flap/Slat Transmitter	Honeywell
18-1969-15	Flap/Slat Transmitter	Honeywell
18-1969-16	Flap/Slat Transmitter	Honeywell

Repair_Capability_List_Excel

18-1969-17	Flap/Slat Transmitter	Honeywell
18-1969-18	Flap/Slat Transmitter	Honeywell
181D100	Lock Actuator	Eaton
181PG	Differential Pressure Transmitter	Vibrometer
181PG-CP	Differential Pressure Transmitter	Vibrometer
181PG-SB	Differential Pressure Transmitter	Vibrometer
181R42	AC Motor	Goodrich Control Systems
181R42R181	Power Drive Unit	Goodrich Control Systems
181R42R181-1	Power Drive Unit	Goodrich Control Systems
181RA22R158	Actuator	Goodrich Control Systems
181RA74ARP260	Actuator	Goodrich Aero Systems
181RA74BRP260	Actuator	Goodrich Aero Systems
181RA74CRP260	Actuator	Goodrich Aero Systems
18-2141	Hydraulic Pressure Transmitter	Bendix/King
18-2141-1	Hydraulic Pressure Transmitter	Bendix/King
18-2141-2	Hydraulic Pressure Transmitter	Honeywell
18-2141-3	Hydraulic Pressure Transmitter	Honeywell
18220-3	Valve	Consolidated Controls
18220-5	Valve	Consolidated Controls
1822-222LW	Nacelle Temperature Indicator	Weston Instruments
182350-1-1	Water Separator	Honeywell
182350-1-2	Water Separator	Honeywell
182350-1-3	Water Separator	Honeywell
182350-1-4	Water Separator	Honeywell
182350-1-5	Water Separator	Honeywell
18235701	Pressure Indicator	HTL Industries
1823T100-1	Power Drive Unit	Telair International
1823T100-3	Power Drive Unit	Telair International
182400-1-1	Precooler Heat Exchanger	Honeywell
1824T100-1	Motor	Telair International
1824T100-3	Motor	Telair International
182570	Cargo Door Actuator	Curtiss-Wright
182570-1	Cargo Door Actuator	Curtiss-Wright
182592-1	Torque Brake assy	Curtiss-Wright
1825T100-3	Motor	Telair International
1825T100-5	Motor	Telair International
18263-101	CLG Harnesses	Dowty Canada
18264-101	CLG Harnesses	Dowty Canada
18265-101	CLG Harnesses	Dowty Canada
18266-101	CLG Harnesses	Dowty Canada
18270-101	CLG Harnesses	Dowty Canada
182708	Control Indicator	Spery Flight
1827DA	Actuator	Sargent Controls
1827T100-1	Linear Actuator	Telair International
1827T100-3	Actuator	Telair International
1827T100-5	Actuator	Telair International
1827T100-7	Actuator	Telair
182820-1-1	Heat Exchanger	Honeywell
182820-2	Heat Exchanger	Honeywell
182820-3	Heat Exchanger	Honeywell
182936	O2 Pressure Indicator	Weston Instruments
182972	O2 System Pressure Indicator	Ametek
18300	CLG DRAG STAY	MESSIER DOWTY
18-3001-2	3 Axis Accelerometer	Honeywell
18-3001-3	3 Axis Accelerometer	Honeywell
183010-1	Water Separator	Honeywell
183010-3	Water Separator	Honeywell
183010-4	Water Separator	Honeywell

Repair_Capability_List_Excel

1830T100-3	Actuator Linear	Telair International
1830T100-5	Actuator Linear	Telair International
1831-11H	Volt/Amperemeter	Weston
1831-6H	Volt/Amperemeter	Weston
1833-13H	Volt/Amperemeter	Weston
1833-13Y1	Voltmeter	Weston
1833-20H	Volt/Amperemeter	Weston
1833-20Y1	AC Ammeter	Weston
18370-101	CLG Harnesses	Dowty Canada
18371-101	CLG Harnesses	Dowty Canada
18380	Vaneaxial Fan	Hamilton Sundstrand
18-380011-1	Fuel Quantity Indicator	Weston Aerospace
184060-1-1	Secondary Heat Exchanger	Honeywell
184060-2-1	Secondary Heat Exchanger	Honeywell
184060-3-1	Secondary Heat Exchanger	Honeywell
184060-3-2	Secondary Heat Exchanger	Honeywell
184-331011100000	Gearbox	BGT
18-4400-1	Defuel Valve	Sweeney
18-4400-2	Defuel Valve	Sweeney
1846T100-3	Elevator Authority Stop Actuator	Telair International
1850	Hydraulic Relief Valve	Pneudraulics
18500-100-01	MLG Door Actuating Cylinder	Messier-Bugatti
18500-100-02	MLG Door Actuating Cylinder	Messier-Bugatti
18500-100-03	MLG Door Actuating Cylinder	Messier-Bugatti
18500-104-03	MLG Door Actuating Cylinder	Messier-Bugatti
185003-4	Water Separator Support ay	Honeywell
1851M60P02	CIT PROBE	ROSEMOUNT
185450-2	Actuator	Curtiss-Wright
18-5600-1	Water Shut-Off Valve	Sweeney
18-5600-2	Water Shut-Off Valve	Sweeney
18575	Hand Pump	Messier-Bugatti
18576	Hand Pump	Messier-Bugatti
1865T100-1	Motor assy	Telair International
1865T100-5	Motor assy	Telair International
18-6800-1	Drain Valve	Sweeney
18700-10	Heat Exchanger	Honeywell
18700-6	Heat Exchanger	Honeywell
18700-7	Heat Exchanger	Honeywell
18700-8	Heat Exchanger	Honeywell
18700-9	Heat Exchanger	Honeywell
18701850	Control Unit	Jarry
18766-1	Blower	Hamilton Sundstrand
18766-3	Blower	Hamilton Sundstrand
18766-6	Blower	Hamilton Sundstrand
187730	Screw Jack	Morse Controls
187730-001	Screw Jack	Morse Controls
187790-1	Water Separator	Honeywell
187790-3	Water Separator	Honeywell
187790-4	Water Separator	Honeywell
187900-10	Heat Exchanger	Honeywell
187900-6	Heat Exchanger	Honeywell
187900-7	Heat Exchanger	Honeywell
187900-8	Heat Exchanger	Honeywell
187900-9	Heat Exchanger	Honeywell
1880T100-1	Actuator	Telair International
18841-1A	Coupler	Honeywell
188792	Cable Tension Regulator	Morse Controls
188911	Hydraulic Motor	Vickers

Repair_Capability_List_Excel

189-3003	Actuator	Tuthill Corp.
189-3004	Actuator	Tuthill Corp.
189-3012	Actuator	Tuthill Corp.
189-3015	Actuator	Tuthill Corp.
1893T100-1	Gearbox	Telair
1894T100-1	Right Angle Gearbox	Telair International
189739	Jack Screw	Morse Controls
189770-001	Engine Control assy	Morse Controls
189770-002	Engine Control assy	Morse Controls
189770-003	Cable assy	Morse Controls
189770-004	Engine Control assy	Morse Controls
189770-005	Cable assy	Morse Controls
189770-006	Engine Control assy	Morse Controls
18C452-L	Engine Gauge Unit	A.I.D.
1903896-1	Autothrottle Servo	Honeywell
190585	Valve	Bendix/King
1905A0000-01	Safety Valve	Liebherr Aerotechnik
190772	Valve	Bendix/King
190QA01	Transformer	ECE
190QA01A	Transformer	ECE
1912-1-1	Ballast	Avtech
1913-1-1	Ballast	Avtech
1918-01	Lighting Arrest	Joslyn
191AC1A	AC Motor	Goodrich
191AC1AR193A	Actuator ay	Goodrich
191AC1B	AC Motor	Goodrich
191AC1BR193A	Actuator ay	Goodrich
191AC1BR193B	Actuator ay	Goodrich
191AC1C	AC Motor	Goodrich
191AC1CR193B	Actuator ay	Goodrich
191AC3	AC Motor	Goodrich
191AC3R193C	Actuator ay	Goodrich
1925756-1	Indicator	Bendix/King
1925756-2	Indicator	Bendix/King
194110-1	Primary Heat Exchanger	Honeywell
194270-1	Primary Heat Exchanger	Honeywell
194270-2	Primary Heat Exchanger	Honeywell
194270-3	Primary Heat Exchanger	Honeywell
194270-31	Primary Heat Exchanger	Honeywell
194270-4	Primary Heat Exchanger	Honeywell
194272-1	Secondary Heat Exchanger	Honeywell
194272-2	Secondary Heat Exchanger	Honeywell
194272-3	Secondary Heat Exchanger	Honeywell
194272-31	Secondary Heat Exchanger	Honeywell
194274-1	Heat Exchanger Reheater	Honeywell
194274-2	Heat Exchanger Reheater	Honeywell
194274-3	Heat Exchanger Reheater	Honeywell
194274-4	Heat Exchanger Reheater	Honeywell
194276-1	Condenser Heat Exchanger	Honeywell
194276-2	Condenser Heat Exchanger	Honeywell
194276-3	Condenser Heat Exchanger	Honeywell
194276-4	Condenser Heat Exchanger	Honeywell
194276-5	Condenser Heat Exchanger	Honeywell
194278-1	Water Extractor	Honeywell
194278-2	Water Extractor	Honeywell
194278-4	Water Extractor	Honeywell
194540-2	Condenser	Honeywell
194542-2	Water Extractor	Honeywell

Repair_Capability_List_Excel

194546-3	Primary/Secondary Air Heat Exchanger	Honeywell
194546-4	Primary/Secondary Air Heat Exchanger	Honeywell
194550-1	Water Separator	Honeywell
194550-2	Water Separator	Honeywell
194768-1	Bleed Air Precooler	Honeywell
194768-2	Bleed Air Precooler	Honeywell
194768-3	Bleed Air Precooler	Honeywell
194768-4	Bleed Air Precooler	Honeywell
194780-1	Water Extractor	Honeywell
194792-1	Bleed Air Precooler	Honeywell
194792-2	Bleed Air Precooler	Honeywell
194792-3	Bleed Air Precooler	Honeywell
194792-4	Bleed Air Precooler	Honeywell
195-1SN112	Engine Gauge Unit	Edison
195-1TN112	Engine Gauge Unit	Edison
195-7SN112	Engine Gauge Unit	Edison
195-7SN122	Engine Gauge Unit	Edison
195PN01	Rudder Trim Indicator	ECE
195PN01Y01	Rudder Trim Indicator	ECE
1964145-1	Servo Control Amplifier	Honeywell
1964145-2	Servo Control Amplifier	Honeywell
1964146-1	Servo Control Amplifier	Honeywell
1964147-1	Servo Control Amplifier	Honeywell
196-5001-3	Hydraulic Filter	Rohr
19689	AOA Transducer	Teledyne Controls
19689-1	AOA Transducer	Teledyne Controls
19689-10	AOA Transducer	Teledyne Controls
19689-30	AOA Transducer	Teledyne Controls
19689-40	AOA Transducer	Teledyne Controls
1976910-1	Attitude Indicator	Honeywell
1976910-2	Attitude Indicator	Honeywell
1976910-3	Attitude Indicator	Honeywell
1978128-1	Attitude Indicator	Honeywell
1978191-1	Attitude Indicator	Honeywell
1990088-1	Attitude Indicator	Honeywell
1990097-4	Annunciator	Bendix/King
1990513-1	Attitude Indicator	Honeywell
1990529-1	Attitude Indicator	Honeywell
19915909-3	Pressure Gauge	HTL
19B428-1	Fuel Quantity Indicator	Weston Aerospace
1A094-0000-05	Actuator	Goodrich Control Systems
1A094-0000-06	Actuator	Goodrich Control Systems
1A094-0000-07	Actuator	Goodrich Control Systems
1A125-	Inverter assy	Avionic Instruments
1A125-1A	Static Inverter	Avionic Instruments
1A125-1B1	Static Inverter	Avionic Instruments
1A125-1C1	Static Inverter	Avionic Instruments
1A50-1A	Inverter assy	Avionic Instruments
1A50-1B1	Static Inverter	Avionic Instruments
1A50-1B-1	Inverter assy	Avionic Instruments
1A50-1C1	Static Inverter	Avionic Instruments
1A50-1C-1	Inverter assy	Avionic Instruments
1A700-1A	Static Inverter	Avionic Instruments
1A700-1B	Static Inverter	Avionic Instruments
1A700-1C	Static Inverter	Avionic Instruments
1B1000-1G	Static Inverter	Avionic Instruments
1B1000-1GRR901	Static Inverter	Avionic Instruments
1B1000-1GS	Static Inverter	Avionic Instruments

Repair_Capability_List_Excel

1B250-1A	Static Inverter	Avionic Instruments
1B250-1B1	Static Inverter	Avionic Instruments
1B250-1B-I/B1642	Inverter assy	Avionic Instruments
1B250-1C	Static Inverter	Avionic Instruments
1B250-1D1	Static Inverter	Avionic Instruments
1B250-1E1	Static Inverter	Avionic Instruments
1B250-1F1	Static Inverter	Avionic Instruments
1B350-1A	Inverter assy	Avionic Instruments
1B350-1B1	Static Inverter	Avionic Instruments
1B350-1B-1	Inverter assy	Avionic Instruments
1B350-1B-2	Inverter assy	Avionic Instruments
1B350-1BFK1008	Static Inverter	Avionic Instruments
1B350-1B-FK-1008	Inverter assy	Avionic Instruments
1B350-1C1	Static Inverter	Avionic Instruments
1B350-1C-1	Inverter assy	Avionic Instruments
1B350-1D	Inverter assy	Avionic Instruments
1B350-1F-A+	Inverter assy	Avionic Instruments
1B6820	Air/Oil Separator	Eaton
1B800-1G	Static Inverter	Avionic Instruments
1B800-1GLN1001	Static Inverter	Avionic Instruments
1C27-5	Booster Pump Cartridge	Parker Hannifin
1C42-1	Booster Pump	Parker Hannifin
1C6-10	Pump	Airborne
1F2870-3	Air/Oil Separator	Eaton
1FA01134-1	Landing Gear Selector Bypass Valve	Frisby Aerospace
1FA01134-2	Landing Gear Selector Bypass Valve	Frisby Aerospace
1FA10019-5	Thrust Reverser Cowl Opening Actuator	Frisby Aerospace
1FA10019-7	Thrust Reverser Cowl Opening Actuator	Frisby Aerospace
1FA1301750	DC Electric Motor	Frisby Aerospace
1FA1301750-1	DC Electric Motor	Frisby Aerospace
1FA1301750-2	DC Electric Motor	Frisby Aerospace
1FA14012-6	Thrust Reverser Cowl Opening Actuator	Frisby Aerospace
1FA14012-7	Thrust Reverser Cowl Opening Actuator	Frisby Aerospace
1FA14012-8	Thrust Reverser Cowl Opening Actuator	Frisby Aerospace
1FA14013-4	Thrust Reverser Cowl Opening Actuator	Frisby Aerospace
1FA14013-5	Thrust Reverser Cowl Opening Actuator	Frisby Aerospace
1FA14013-6	Thrust Reverser Cowl Opening Actuator	Frisby Aerospace
1FA14013-7	Thrust Reverser Cowl Opening Actuator	Frisby Aerospace
1FA14013-8	Thrust Reverser Cowl Opening Actuator	Frisby Aerospace
1FA14013-9	Thrust Reverser Cowl Opening Actuator	Frisby Aerospace
1G113	Switch	Custom Control Sensors
1G174-1A	Switch	Custom Control Sensors
1G196	Switch	Custom Control Sensors
1G196-1	Switch	Custom Control Sensors
1G196-2	Switch	Custom Control Sensors
1G196-3	Switch	Custom Control Sensors
1G222	Switch	Custom Control Sensors
1G256	Switch	Custom Control Sensors
1G257	Switch	Custom Control Sensors
1G259-1	Switch	Custom Control Sensors
1G259-2	Switch	Custom Control Sensors
1G309	Switch	Custom Control Sensors
1G357-2	Switch	Custom Control Sensors
1G386	Switch	Custom Control Sensors
1G98-2	Switch	Custom Control Sensors
1G98-5	Switch	Custom Control Sensors
1U028	Fuel Flow Indicator	EDO-Aire
1U1061	Valve	Smiths Industries

Repair_Capability_List_Excel

1U1065	Compensator	Smiths Industries
1U1065-2	Compensator	Smiths Industries
1U1065-2A	Compensator	Smiths Industries
1U1065A	Compensator	Smiths Industries
1U1077	Compensator	Smiths Industries
1U1084	Valve	Dowty
1U1085	Valve	Smiths Industries
1U1085-1	Valve	Smiths Industries
1U1087	Power Unit	Dowty
1U1087-1	Valve	Smiths Industries
1U1087-2	Power Unit	Dowty
1U1089	Valve	Messier-Dowty
1U1095	Actuator	Dowty
1U1095-5	Actuator	Dowty
1U1095-9-2	Actuator	Dowty
1U1103	Actuator	Dowty
1U1103-2	Actuator	Dowty
1U1103-2-2	Actuator	Dowty
1U1110	Actuator	Smiths Industries
1U1136	Valve	Smiths Industries
1U1147	Valve	Smiths Industries
1U1150	Actuator	Smiths Industries
1U1150-1	Auxiliary Rudder Power Ctrl Unit	Smiths Industries
1U1150-2	Auxiliary Rudder Power Ctrl Unit	Smiths Industries
1U1150-3	Auxiliary Rudder Power Ctrl Unit	Smiths Industries
1U1150-4	Auxiliary Rudder Power Ctrl Unit	Smiths Industries
1U1154	Valve	Smiths Industries
1U1168	Actuator	Smiths Industries
1U1169	Actuator	Smiths Industries
1U1171-2	Steering Actuator	Smiths Industries
1U1171-3	Steering Actuator	Smiths Industries
1U1171-4	Steering Actuator	Smiths Industries
1U1171-5	Steering Actuator	Smiths Industries
1U1192-5	Actuator	Smiths Industries
1U1192-6	Actuator	Smiths Industries
1U1192-8	Actuator	Smiths Industries
1U1193-4	Actuator	Smiths Industries
1U1193-5	Actuator	Smiths Industries
1U1193-7	Actuator	Smiths Industries
1U1198-3	Actuator	Smiths Industries
1U1198-4	Actuator	Smiths Industries
1U1198-5	Actuator	Smiths Industries
1U1198-6	Actuator	Smiths Industries
1U1204-3	Lock Actuator	Smiths Industries
1U1204-4	Lock Actuator	Smiths Industries
1U1220-2	Actuator	Smiths Industries
1U1222	Actuator	Smiths Industries
1U1225	Water Separator	Smiths Industries
1U1234	Shut-Off Valve	Smiths Industries
1U1243-1	Actuator	Smiths Industries
1U1243-2	Actuator	Smiths Industries
1U1261-3	Valve assy	Smiths Industries
1U1261-4	Valve assy	Smiths Industries
1U1261-5	Valve assy	Smiths Industries
1U1261-6	Valve assy	Smiths Industries
1U1301-1	Modular assy	Messier-Dowty
1U1302	Selector Valve	Smiths Industries
1U1302-1	Selector Valve	Smiths Industries

Repair_Capability_List_Excel

1U1501-2	Isolation Valve	Smiths Industries
1U1501-3	Isolation Valve	Smiths Industries
1U1503-2	Directional Control Valve ay	Smiths Industries
1U1509-4	Sync-Lock/Manual Drive ay	Smiths Industries
1U1509-4A	Sync-Lock/Manual Drive ay	Smiths Industries
1U1509-5	Sync-Lock/Manual Drive ay	Smiths Industries
1U1524-4	Non-Locking Actuator assy	Smiths Industries
1U1524-5	Non-Locking Actuator assy	Smiths Industries
1U1524-6	Non-Locking Actuator assy	Smiths Industries
1U1525-5	Locking Actuator assy	Smiths Industries
1U1525-6	Locking Actuator assy	Smiths Industries
1U1525-7	Locking Actuator assy	Smiths Industries
1U1544-4	Non-Locking Actuator assy	Smiths Industries
1U1544-5	Non-Locking Actuator assy	Smiths Industries
1U1545-5	Locking Actuator assy	Smiths Industries
1U1545-6	Locking Actuator assy	Smiths Industries
1U1554	Non-Locking Actuator assy	Smiths Industries
1U1555	Locking Actuator assy	Smiths Industries
1X2001517-09	Light	Hella
1X2001517-11	Light	Hella
1X2002749-00	Light	Hella
1X2002749-00M13	Light	Hella
1X2005012-00	Loading Area Light	Hella
1X2005097-00	Logo Light	Hella
200-002-001	Indicator	Parker Hannifin
200-002-002	Indicator	Parker Hannifin
200-007-005	Master Indicator	Parker Hannifin
200-007-006	Master Indicator	Parker Hannifin
200-007-007	Master Indicator	Parker Hannifin
200-007-008	Master Indicator	Parker Hannifin
200-007-009	Master Indicator	Parker Hannifin
200-007-010	Master Indicator	Parker Hannifin
200-0606-001	Indicator	Parker Hannifin
200061004	NLG Strut	Dowty Aerospace
200061006	NLG Strut	Dowty Aerospace
200061008	NLG Strut	Dowty Aerospace
200061010	NLG Strut	Dowty Aerospace
200061012	NLG Strut	Dowty Aerospace
200061014	NLG Strut	Dowty Aerospace
200061016	NLG Strut	Dowty Aerospace
200061018	NLG Strut	Dowty Aerospace
200061020	NLG Strut	Dowty Aerospace
200062007	NLG Shock Absorber	Dowty Aerospace
200062008	NLG Shock Absorber	Dowty Aerospace
200062010	NLG Shock Absorber	Dowty Aerospace
200062011	NLG Shock Absorber	Dowty Aerospace
200062012	NLG Shock Absorber	Dowty Aerospace
200062013	NLG Shock Absorber	Dowty Aerospace
200062014	NLG Shock Absorber	Dowty Aerospace
200062015	NLG Shock Absorber	Dowty Aerospace
200063001	MLG Strut	Dowty Aerospace
200063002	MLG Strut	Dowty Aerospace
200063003	MLG Strut	Dowty Aerospace
200063004	MLG Strut	Dowty Aerospace
200063005	MLG Strut	Dowty Aerospace
200063006	MLG Strut	Dowty Aerospace
200063107	Leg Main Undercarriage	Dowty Aerospace
2000866-2	Starter Motor	Honeywell

Repair_Capability_List_Excel

2000866-3	Starter Motor	Honeywell
200100	Servo assy	Parker Hannifin
200100-5031	Servo assy	Parker Hannifin
200100-5033	Servo assy	Parker Hannifin
200100658A	RAT Leg & Pump	Sundstrand
200140	Servo assy	Parker Hannifin
200175001	NLG Downlock Block	Dowty Aerospace
200175002	NLG Downlock Block	Dowty Aerospace
200223001	MLG Strut	Dowty Aerospace
200223203	Swivel	Dowty Aerospace
200223204	Swivel	Dowty Aerospace
200223206	Swivel	Dowty Aerospace
200223208	Swivel	Dowty Aerospace
200224001	MLG Drag Stay	Dowty Aerospace
200228001	Lock	Dowty Aerospace
200228002	Lock	Dowty Aerospace
200251001	MLG Upper Member	Dowty Aerospace
200260001	MLG Lock Strut	Dowty Aerospace
200261001	MLG Drag Stay	Dowty Aerospace
200-26500-01	Transformer	Oeco Corporation
20-035008-043	Air Leak Detection Controller	Fenwal
2004022-105	Valve assy	Conair
200427003	MLG Strut	Dowty Aerospace
200427004	MLG Strut	Dowty Aerospace
200427005	MLG Strut	Dowty Aerospace
200427006	MLG Strut	Dowty Aerospace
200427007	MLG Strut	Dowty Aerospace
200427008	MLG Strut	Dowty Aerospace
200427009	MLG Strut	Dowty Aerospace
200427010	MLG Strut	Dowty Aerospace
200427013	MLG Strut	Dowty Aerospace
200427014	MLG Strut	Dowty Aerospace
200427015	MLG Strut	Dowty Aerospace
200427016	MLG Strut	Dowty Aerospace
200427017	MLG Strut	Dowty Aerospace
200427018	MLG Strut	Dowty Aerospace
200427019	MLG Strut	Dowty Aerospace
200427020	MLG Strut	Dowty Aerospace
200427264	Electrical Harness	Messier-Dowty
200429002	NLG Strut	Dowty Aerospace
200429003	NLG Strut	Dowty Aerospace
200429004	NLG Strut	Dowty Aerospace
200429005	NLG Strut	Dowty Aerospace
200444001	MLG Damper	Dowty Aerospace
200444002	MLG Damper	Dowty Aerospace
200444003	MLG Damper	Dowty Aerospace
200444004	MLG Damper	Dowty Aerospace
200444-004	Damper assy	Messier-Dowty
200472001	NLG Strut	Dowty Aerospace
200473002	NLG Shock Absorber	Dowty Aerospace
200473003	NLG Shock Absorber	Dowty Aerospace
200473004	NLG Shock Absorber	Dowty Aerospace
200473006	NLG Shock Absorber	Dowty Aerospace
200473007	NLG Shock Absorber	Dowty Aerospace
200473008	NLG Shock Absorber	Dowty Aerospace
200474001	Swivel	Dowty Aerospace
200485001	MLG Drag Stay Unit	Dowty Aerospace
200487001	Single Swivel Pipe	Dowty Aerospace

Repair_Capability_List_Excel

200490001	NLG Strut	Dowty Aerospace
200497004	MLG Downlock Actuator	Dowty Aerospace
200497-004	Jack assy	Dowty Aerospace
200497005	Actuator	Dowty Aerospace
200498004	MLG Downlock Actuator	Dowty Aerospace
200498-004	Jack assy	Dowty Aerospace
200498005	Jack assy	Dowty Aerospace
200499001	MLG Side Strut	Dowty Aerospace
200556254	MLG Electrical Harness	Dowty Aerospace
200556255	MLG Electrical Harness	Dowty Aerospace
200556277	MLG Electrical Harness	Dowty Aerospace
200556278	MLG Electrical Harness	Dowty Aerospace
200556289	MLG Electrical Harness	Dowty Aerospace
200556290	MLG Electrical Harness	Dowty Aerospace
200566001	MLG Shock Absorber	Dowty Aerospace
200566002	MLG Shock Absorber	Dowty Aerospace
200633001	MLG Strut	Dowty Aerospace
200633002	MLG Strut	Dowty Aerospace
200633005	MLG Strut	Dowty Aerospace
200633006	MLG Strut	Dowty Aerospace
200634001	MLG Side Strut	Dowty Aerospace
200642001	MLG Strut	Dowty Aerospace
200642002	MLG Strut	Dowty Aerospace
200642005	MLG Strut	Dowty Aerospace
200642006	MLG Strut	Dowty Aerospace
200642007	MLG Strut	Dowty Aerospace
200642008	MLG Strut	Dowty Aerospace
200642009	MLG Strut	Dowty Aerospace
200642010	MLG Strut	Dowty Aerospace
200643001	NLG Strut	Dowty Aerospace
200643002	NLG Strut	Dowty Aerospace
200678001	NLG Strut	Dowty Aerospace
200679001	MLG Strut	Dowty Aerospace
200679002	MLG Strut	Dowty Aerospace
200679003	MLG Strut	Dowty Aerospace
200679004	MLG Strut	Dowty Aerospace
200680001	Upper Member	Dowty Aerospace
200680002	Upper Member	Dowty Aerospace
200682001	Uplock Actuator	Dowty Aerospace
200682002	Uplock Actuator	Dowty Aerospace
200683001	MLG Lock Strut	Dowty Aerospace
200684001	MLG Drag Stay	Dowty Aerospace
200684004	MLG Drag Stay	Dowty Aerospace
200685001	NLG Uplock	Dowty Aerospace
200725001	NLG Strut	Dowty Aerospace
200736001	NLG Strut	Dowty Aerospace
200739001	MLG Strut	Dowty Aerospace
200739002	MLG Strut	Dowty Aerospace
200739003	MLG Strut	Dowty Aerospace
200739005	Strut	Dowty Aerospace
200739006	MLG Strut	Dowty Aerospace
200739205	MLG Electrical Harness	Dowty Aerospace
200739211	MLG Electrical Harness	Dowty Aerospace
200739215	MLG Electrical Harness	Dowty Aerospace
200739216	MLG Electrical Harness	Dowty Aerospace
200739228	Harness assy	Dowty Aerospace
200752001	MLG Strut	Dowty Aerospace
200752002	MLG Strut	Dowty Aerospace

Repair_Capability_List_Excel

200752003	MLG Strut	Dowty Aerospace
200752004	MLG Strut	Dowty Aerospace
200752005	MLG Strut	Dowty Aerospace
200752006	MLG Strut	Dowty Aerospace
200798001	MLG Strut	Dowty Aerospace
200844002	MLG Upstop Damper	Dowty Aerospace
200900-5007	Aileron Power Control Unit	Parker Hannifin
200900-5009	Aileron Power Control Unit	Parker Hannifin
200900-5011	Aileron Power Control Unit	Parker Hannifin
200900-5013	Aileron Power Control Unit	Parker Hannifin
201013001	MLG Strut	Dowty Aerospace
201014001	MLG Drag Brace	Dowty Aerospace
20101420-001	Autobrake Valve Module	HR Textron
20101420-002	Autobrake Valve Module	HR Textron
20101420-003	Autobrake Valve Module	HR Textron
20101420-004	Autobrake Valve Module	HR Textron
20101420-005	Autobrake Valve Module	HR Textron
20101420-006	Autobrake Valve Module	HR Textron
20101420-007	Autobrake Valve Module	HR Textron
201018001	MLG Lock Link	Dowty Aerospace
201019001	MLG Downlock Springbox	Dowty Aerospace
201020367	MLG Sliding Member	Dowty Aerospace
201021001	MLG Upper Member	Dowty Aerospace
201022002	MLG Uplock Unit	Dowty Aerospace
201023001	MLG Lower Swivel Unit	Dowty Aerospace
201023002	MLG Lower Swivel Unit	Dowty Aerospace
201024001	MLG Upper Swivel Unit	Dowty Aerospace
201024002	MLG Upper Swivel Unit	Dowty Aerospace
201024003	MLG Upper Swivel Unit	Dowty Aerospace
201024004	MLG Upper Swivel Unit	Dowty Aerospace
201025001	MLG Centre Swivel Unit	Dowty Aerospace
201025002	MLG Centre Swivel Unit	Dowty Aerospace
20102575	Main Strut Harness	Ultra Electronics
20102576	Main Strut Harness	Ultra Electronics
20102577	Main Strut Harness	Ultra Electronics
20102578	Main Strut Harness	Ultra Electronics
201042462	Bogie Harness assy	Dowty Aerospace
201042463	Bogie Harness assy	Dowty Aerospace
201042538	Delay Valve	Messier-Dowty
201042559	Delay Valve	Messier-Dowty
201042561	Delay Valve	Messier-Dowty
201042569	Electrical Harness	Messier-Dowty
201042570	Electrical Harness	Messier-Dowty
201042575	Electrical Harness	Messier-Dowty
201042576	Electrical Harness	Messier-Dowty
201042577	Electrical Harness	Messier-Dowty
201042578	Electrical Harness	Messier-Dowty
201042579	Bogie Electrical Harness	Messier-Dowty
201042580	Bogie Electrical Harness	Messier-Dowty
201042587	Bogie Electrical Harness	Messier-Dowty
201042588	Bogie Electrical Harness	Messier-Dowty
201042589	Electrical Harness	Messier-Dowty
201042590	Electrical Harness	Messier-Dowty
201042632	Electrical Harness	Messier-Dowty
201042633	Electrical Harness	Messier-Dowty
201042634	Main Strut Harness	Ultra Electronics
201042635	Main Strut Harness	Ultra Electronics
201042636	Bogie Electrical Harness	Messier-Dowty

Repair_Capability_List_Excel

201042637	Bogie Electrical Harness	Messier-Dowty
201042640	Electrical Harness	Messier-Dowty
201042641	Electrical Harness	Messier-Dowty
201042642	Electrical Harness	Messier-Dowty
201042643	Electrical Harness	Messier-Dowty
201042644	Bogie Electrical Harness	Messier-Dowty
201042645	Bogie Electrical Harness	Messier-Dowty
201042646	Electrical Harness	Messier-Dowty
201042647	Electrical Harness	Messier-Dowty
201042655	Electrical Harness	Messier-Dowty
201042656	Electrical Harness	Messier-Dowty
201042659	Bogie Electrical Harness	Messier-Dowty
201042660	Bogie Electrical Harness	Messier-Dowty
201042661	Bogie Beam Harness	Ultra Electronics
201042662	Bogie Beam Harness	Ultra Electronics
201042670	Electrical Harness	Messier-Dowty
201042671	Electrical Harness	Messier-Dowty
201042672	Electrical Harness	Messier-Dowty
201042673	Electrical Harness	Messier-Dowty
201042681	Electrical Harness	Messier-Dowty
201042682	Electrical Harness	Messier-Dowty
201042683	Electrical Harness	Messier-Dowty
201042684	Electrical Harness	Messier-Dowty
201042694	Bogie Beam Harness	Ultra Electronics
201042695	Bogie Beam Harness	Ultra Electronics
201042725	Bogie Beam Harness	Ultra Electronics
201042726	Bogie Electrical Harness	Messier-Dowty
201042727	Bogie Beam Harness	Ultra Electronics
201042728	Bogie Electrical Harness	Messier-Dowty
201042731	Bogie Electrical Harness	Messier-Dowty
201042760	Main Strut Harness	Ultra Electronics
201042761	Main Strut Harness	Ultra Electronics
201042762	Main Strut Harness	Ultra Electronics
201042763	Main Strut Harness	Ultra Electronics
201042778	Main Strut Harness	Ultra Electronics
201042779	Main Strut Harness	Ultra Electronics
201042780	Main Strut Harness	Ultra Electronics
201042781	Main Strut Harness	Ultra Electronics
201042782	Main Strut Harness	Ultra Electronics
201042783	Main Strut Harness	Ultra Electronics
201042784	Main Strut Harness	Ultra Electronics
201042785	Main Strut Harness	Ultra Electronics
201042786	Electrical Harness	Messier-Dowty
201042787	Main Strut Harness	Ultra Electronics
201042788	Electrical Harness	Messier-Dowty
201042789	Main Strut Harness	Ultra Electronics
201042790	Electrical Harness	Messier-Dowty
201042791	Main Strut Harness	Ultra Electronics
201042792	Electrical Harness	Messier-Dowty
201042793	Main Strut Harness	Ultra Electronics
201042794	Bogie Electrical Harness	Messier-Dowty
201042795	Bogie Beam Harness	Ultra Electronics
201042796	Bogie Electrical Harness	Messier-Dowty
201042797	Bogie Beam Harness	Ultra Electronics
201042798	Bogie Electrical Harness	Messier-Dowty
201057001	Basic Side Stay	Messier-Dowty
201057002	Basic Side Stay	Messier-Dowty
201057003	Basic Side Stay	Messier-Dowty

Repair_Capability_List_Excel

201057004	Basic Side Stay	Messier-Dowty
201058001	Lock Stay	Messier-Dowty
201058002	Lock Stay	Messier-Dowty
201059001	Spring Lock	Messier-Dowty
201061001	Side Stay assy	Messier-Dowty
201061002	Side Stay assy	Messier-Dowty
201061003	Side Stay assy	Messier-Dowty
201061004	Side Stay assy	Messier-Dowty
201061005	Side Stay assy	Messier-Dowty
201061006	Side Stay assy	Messier-Dowty
201061007	Side Stay assy	Messier-Dowty
201061008	Side Stay assy	Messier-Dowty
201061009	Side Stay assy	Messier-Dowty
201061010	Side Stay assy	Messier-Dowty
201061011	Side Stay assy	Messier-Dowty
201061012	Side Stay assy	Messier-Dowty
201069001	NLG Swivel Coupling	Dowty Aerospace
201071001	NLG Strut	Dowty Aerospace
201071002	NLG Strut	Dowty Aerospace
201071004	NLG Strut	Dowty Aerospace
201072011	MLG Strut	Dowty Aerospace
201072012	MLG Strut	Dowty Aerospace
201072013	MLG Strut	Dowty Aerospace
201072014	MLG Strut	Dowty Aerospace
201072015	MLG Strut	Dowty Aerospace
201072016	MLG Strut	Dowty Aerospace
201072201	Member	Dowty Aerospace
201072218	Sliding Member	Dowty Aerospace
201072294	MLG Electrical Harness	Dowty Aerospace
201072301	Sliding Member	Dowty Aerospace
201073001	Side Stay	Dowty Aerospace
201073002	Side Stay	Dowty Aerospace
201073003	Side Stay	Dowty Aerospace
201100-1	ZY Single Latch	Telair International
201117005	MLG Uplock assy	Dowty Aerospace
201117006	MLG Uplock assy	Dowty Aerospace
201117007	MLG Uplock assy	Dowty Aerospace
201117008	MLG Uplock assy	Dowty Aerospace
201117009	MLG Uplock assy	Dowty Aerospace
201117010	MLG Uplock assy	Dowty Aerospace
201117011	MLG Uplock assy	Dowty Aerospace
201117012	MLG Uplock assy	Dowty Aerospace
201117013	MLG Uplock assy	Dowty Aerospace
201117014	MLG Uplock assy	Dowty Aerospace
201117015	MLG Uplock assy	Dowty Aerospace
201117016	MLG Uplock assy	Dowty Aerospace
201117017	MLG Uplock assy	Dowty Aerospace
201117018	MLG Uplock assy	Dowty Aerospace
201117019	MLG Uplock assy	Dowty Aerospace
201117020	MLG Uplock assy	Dowty Aerospace
201117021	MLG Uplock assy	Dowty Aerospace
201117022	MLG Uplock assy	Dowty Aerospace
201122001	MLG Door Uplock	Dowty Aerospace
201122002	MLG Door Uplock	Dowty Aerospace
201122003	MLG Door Uplock	Dowty Aerospace
201122004	MLG Door Uplock	Dowty Aerospace
201122005	MLG Door Uplock	Dowty Aerospace
201122006	MLG Door Uplock	Dowty Aerospace

Repair_Capability_List_Excel

201122007	MLG Door Uplock	Dowty Aerospace
201122008	MLG Door Uplock	Dowty Aerospace
201127000	Dressings	Messier-Dowty
201127001	Dressings	Messier-Dowty
201127002	Dressings	Messier-Dowty
201127003	Dressings	Messier-Dowty
201127004	Dressings	Messier-Dowty
201127005	Dressings	Messier-Dowty
201127006	Dressings	Messier-Dowty
201127007	Dressings	Messier-Dowty
201127008	Dressings	Messier-Dowty
201127009	Dressings	Messier-Dowty
201127010	Dressings	Messier-Dowty
201127011	Dressings	Messier-Dowty
201127012	Dressings	Messier-Dowty
201127013	Dressings	Messier-Dowty
201127014	Dressings	Messier-Dowty
201127015	Dressings	Messier-Dowty
201127016	Dressings	Messier-Dowty
201134015	Electrical Harness	Messier-Dowty
201134016	Electrical Harness	Messier-Dowty
201158007	Electrical Harness	Messier-Dowty
201158008	Electrical Harness	Messier-Dowty
201159007	Electrical Harness	Messier-Dowty
201159008	Electrical Harness	Messier-Dowty
201161001	Dressings	Messier-Dowty
201161002	Dressings	Messier-Dowty
201161003	Dressings	Messier-Dowty
201161004	Dressings	Messier-Dowty
201161015-030	MLG Dressing	Messier-Dowty
201161015-040	MLG Dressing	Messier-Dowty
201161016-030	MLG Dressing	Messier-Dowty
201161016-040	MLG Dressing	Messier-Dowty
201163001	Side Stay	Messier-Dowty
201163002	Side Stay	Messier-Dowty
201163003	Side Stay	Messier-Dowty
201163004	Side Stay	Messier-Dowty
201166001	Side Stay assy	Messier-Dowty
201166002	Side Stay assy	Messier-Dowty
201166003	Side Stay assy	Messier-Dowty
201166004	Side Stay assy	Messier-Dowty
201166007	Side Stay assy	Messier-Dowty
201166008	Side Stay assy	Messier-Dowty
201166009	Side Stay assy	Messier-Dowty
201166010	Side Stay assy	Messier-Dowty
201166011	Side Stay assy	Messier-Dowty
201166012	Side Stay assy	Messier-Dowty
201166013	Side Stay assy	Messier-Dowty
201166014	Side Stay assy	Messier-Dowty
201168007	Electrical Harness	Messier-Dowty
201168021	Electrical Harness	Messier-Dowty
201168022	Electrical Harness	Messier-Dowty
201170001	Bogie Dressings	Messier-Dowty
201170002	Bogie Dressings	Messier-Dowty
201170006	Bogie Dressings	Messier-Dowty
201171001	Bogie Beam Assy	Messier-Dowty
201171002	Bogie Beam Assy	Messier-Dowty
201179001	MLG Uplock Actuator assy	Messier-Dowty

Repair_Capability_List_Excel

201180001	MLG Uplock Actuator assy	Messier-Dowty
201218001	MLG Downlock Actuator	Dowty Aerospace
201218002	MLG Downlock Actuator	Dowty Aerospace
201218003	MLG Downlock Actuator	Dowty Aerospace
201218004	MLG Downlock Actuator	Dowty Aerospace
201218005	MLG Downlock Actuator	Dowty Aerospace
201218006	MLG Downlock Actuator	Dowty Aerospace
201218007	MLG Downlock Actuator	Dowty Aerospace
201218008	MLG Downlock Actuator	Dowty Aerospace
201238001	Lock Link	Dowty Aerospace
201251202	MLG Electrical Harness	Dowty Aerospace
201251203	MLG Electrical Harness	Dowty Aerospace
201251235	Downlock Harness	Dowty Aerospace
201251236	MLG Electrical Harness	Dowty Aerospace
201251240	MLG Electrical Harness	Dowty Aerospace
201251241	MLG Electrical Harness	Dowty Aerospace
201251243	MLG Electrical Harness	Dowty Aerospace
201251244	MLG Electrical Harness	Dowty Aerospace
201251254	MLG Electrical Harness	Dowty Aerospace
201251255	MLG Electrical Harness	Dowty Aerospace
201251256	MLG Electrical Harness	Dowty Aerospace
201251257	MLG Electrical Harness	Dowty Aerospace
201251260	MLG Electrical Harness	Dowty Aerospace
201251261	MLG Electrical Harness	Dowty Aerospace
201251275	Sensor assy	Dowty Aerospace
201252001	LANDING GEAR	MESSIER-DOWTY
201253002	SIDE STAY	DOWTY AEROSPACE
201254001	STRUT AND DRESSING	MESSIER-DOWTY
201254001	STRUT AND DRESSING	MESSIER-DOWTY
201267001	SIDE STAY	DOWTY AEROSPACE
201268001	LOCK LINK	MESSIER-DOWTY
201272004	BAGIE ASSY	MESSIER-SOWTY
201274001	BAGIE AND DRESSING	MESSIER-DOWTY
201274002	BAGIE AND DRESSING	MESSIER-DOWTY
20128-0101	Tank Unit	Goodrich
20128-0103	Tank Unit	Goodrich
20128-0104	Tank Unit	Goodrich
20128-0105	Tank Unit	Goodrich
20128-0107	Tank Unit	Goodrich
20128-0108	Tank Unit	Goodrich
20128-0109	Tank Unit	Goodrich
20128-0110	Tank Unit	Goodrich
20128-0112	Tank Unit	Goodrich
20128-0113	Tank Unit	Goodrich
20128-0115	Tank Unit	Goodrich
20128-0116	Tank Unit	Goodrich
20128-0117	Tank Unit	Goodrich
20128-0118	Tank Unit	Goodrich
20128-0119	Tank Unit	Goodrich
20128-0120	Tank Unit	Goodrich
20128-0121	Tank Unit	Goodrich
20128-0122	Tank Unit	Goodrich
20128-0123	Tank Unit	Goodrich
20128-0124	Tank Unit	Goodrich
20128-0125	Tank Unit	Goodrich
20128-0127	Tank Unit	Goodrich
20128-0128	Tank Unit	Goodrich
20128-0129	Tank Unit	Goodrich

Repair_Capability_List_Excel

20128-0130	Tank Unit	Goodrich
20128-0131	Tank Unit	Goodrich
20128-0132	Tank Unit	Goodrich
20128-0133	Tank Unit	Goodrich
201281004	MLG Downlock Actuator	Dowty Aerospace
2012A000	Valve	Norma
2013-1A	Power Supply	Intertechnique
201389001	Side Stay	Messier-Dowty
201403001	Lock Stay	Messier-Dowty
201419001	Torque Link Damper	Messier-Dowty
201419001-010	MLG Torque Link Damper	Messier-Dowty
201428001	MAIN STRUT	MESSIER-DOWTY
20142800X	MAIN STRUT	DOWTY AEROSPACE
201428010	MAIN STRUT	MESSIER-DOWTY
201442001	LOCK LINK	MESSIER-DOWTY
20145-0101	Fuel Probe Quantity	BF Goodrich
201456001	NLG Strut	Dowty Aerospace
201457001	SIDE STAY	MESSIER-DOWTY
201458001	SIDE STAY	MESSIER-DOWTY
20146-0101	Fuel Probe Quantity	BF Goodrich
20146-0102	Fuel Probe Quantity	BF Goodrich
20146-0103	Fuel Probe Quantity	BF Goodrich
20146-0104	Fuel Probe Quantity	BF Goodrich
20146-0105	Fuel Probe Quantity	BF Goodrich
20146-0106	Fuel Probe Quantity	BF Goodrich
20146-0107	Fuel Probe Quantity	BF Goodrich
20146-0108	Fuel Probe Quantity	BF Goodrich
20146-0109	Fuel Probe Quantity	BF Goodrich
20146-0110	Fuel Probe Quantity	BF Goodrich
201461001	NLG Strut	Dowty Aerospace
20147-0101	Fuel Probe Quantity	BF Goodrich
20147-0102	Fuel Probe Quantity	BF Goodrich
20147-0103	Fuel Probe Quantity	BF Goodrich
201480002	MLG Pitch Trimmer	Messier-Dowty
201480002-10	MLG Pitch Trimmer	Messier-Dowty
201480002-15	MLG Pitch Trimmer	Messier-Dowty
201480002-20	MLG Pitch Trimmer	Messier-Dowty
201481001	Unlock Actuator	Messier-Bugatti
201481001-005	Unlock Actuator	Messier-Bugatti
201482001	LOCK LINK	MESSIER DOWTY
201483001	SIDE STAY	MESSIER-DOWTY
201484001	SIDE STAY	MESSIER-DOWTY
201485001	BAGIE ASSY	MESSIER-DOWTY
201486001	BAGIE AND DRESSING	MESSIER-DOWTY
201487001-010	SHOCK STRUT	MESSIER-DOWTY
201489002-040	STRUT AND DRESSING	MESSIER-DOWTY
201489003	STRUT AND DRESSING	MESSIER-DOWTY
201490001	LANDING GEAR	MESSIER-DOWTY
20149-0101	Dualcomp	Simmonds Precision
20150-0101	Ultracomp	BF Goodrich
20151-0101	Fuel Quantity Probe	Simmonds Precision
20151-0102	Fuel Quantity Probe	Simmonds Precision
20151-0103	Fuel Quantity Probe	Simmonds Precision
20151-0104	Fuel Quantity Probe	Simmonds Precision
20151-0105	Fuel Quantity Probe	Simmonds Precision
20151-0106	Fuel Quantity Probe	Simmonds Precision
20151-0107	Fuel Quantity Probe	Simmonds Precision
20151-0108	Fuel Quantity Probe	Simmonds Precision

Repair_Capability_List_Excel

20151-0109	Fuel Quantity Probe	Simmonds Precision
20151-0111	Fuel Quantity Probe	Simmonds Precision
20151-0113	Fuel Quantity Probe	Simmonds Precision
20151-0114	Fuel Quantity Probe	Simmonds Precision
20151-0115	Fuel Quantity Probe	Simmonds Precision
20151-0116	Fuel Quantity Probe	Simmonds Precision
20151-0117	Fuel Quantity Probe	Simmonds Precision
20151-0118	Fuel Quantity Probe	Simmonds Precision
20151-0119	Fuel Quantity Probe	Simmonds Precision
20151-0120	Fuel Quantity Probe	Simmonds Precision
20151-0121	Fuel Quantity Probe	Simmonds Precision
20151-0122	Fuel Quantity Probe	Simmonds Precision
20151-0123	Fuel Quantity Probe	Simmonds Precision
20151-0124	Fuel Quantity Probe	Simmonds Precision
20151-0125	Fuel Quantity Probe	Simmonds Precision
20151-0204	Fuel Quantity Probe	Simmonds Precision
20151-0205	Fuel Quantity Probe	Simmonds Precision
20151-0210	Fuel Quantity Probe	Simmonds Precision
201520001	Electrical Harness	Messier-Dowty
201520002	Electrical Harness	Messier-Dowty
201520003	Electrical Harness	Messier-Dowty
201520004	Electrical Harness	Messier-Dowty
201520005	Electrical Harness	Messier-Dowty
201520006	Electrical Harness	Messier-Dowty
201520007	Electrical Harness	Messier-Dowty
201520008	Electrical Harness	Messier-Dowty
201590001	Manifold Block	Messier-Dowty
201590002	Manifold Block	Messier-Dowty
20-181-109	Step Motor	Liebherr Aerospace
201LAAFA1	Linear Actuator	Smiths Industries
201LAAFA2	Linear Actuator	Smiths Industries
202000-5005	Outboard Aileron Actuator	Parker Hannifin
202000-5007	Outboard Aileron Actuator	Parker Hannifin
202000-5009	Outboard Aileron Actuator	Parker Hannifin
202000-5011	Outboard Aileron Actuator	Parker Hannifin
202100-1	Y-Single Latch	Telair International
202100-11	Y-Single Latch	Telair International
202100-3	Y-Single Latch	Telair International
202100-5	Y-Single Latch	Telair International
202100-7	Y-Single Latch	Telair International
202100-9	Y-Single Latch	Telair International
20211118-1	Actuator	Honeywell
2021118-1	Actuator	Honeywell
2021134-1	Electromechanical Actuator	Honeywell
2021134-2	Electromechanical Actuator	Honeywell
2021134-4	Electromechanical Actuator	Honeywell
2021136-1	Rotary Actuator	Honeywell
2021136-2	Rotary Actuator	Honeywell
2021136-4	Rotary Actuator	Honeywell
2021158-2	Linear Mechanical Actuator	Moog
2021158-4	Linear Mechanical Actuator	Moog
2021272-1	Actuator	Honeywell
2021814-1	Rotary Actuator	Telair International
2021858-2	Rotary Actuator	Moog
2021858-3	Rotary Actuator	Moog
2021858-4	Rotary Actuator	Moog
2021858-5	Rotary Actuator	Moog
2021860-2	Mechanical Rotary Actuator	Honeywell

Repair_Capability_List_Excel

2021860-3	Mechanical Rotary Actuator	Honeywell
2021860-4	Mechanical Rotary Actuator	Honeywell
2021860-5	Mechanical Rotary Actuator	Honeywell
2021860-6	Mechanical Rotary Actuator	Honeywell
2021860-7	Mechanical Rotary Actuator	Honeywell
2021972-1-1	Rotary Actuator	Honeywell
2021974-1	Valve Actuator	Honeywell
2021974-2	Valve Actuator	Honeywell
2022014-1	Motor	Honeywell
2022014-2	Motor	Honeywell
2022014-3	Motor	Honeywell
2022432-1	Ram Air Door Actuator	Honeywell
2022432-3	Ram Air Door Actuator	Honeywell
2022432-4	Ram Air Door Actuator	Honeywell
2022478-1	Alternative Current Motor	Honeywell
2022478-2	Alternative Current Motor	Honeywell
2022478-3	Alternative Current Motor	Honeywell
2022478-4	Alternative Current Motor	Honeywell
2022478-5	Alternative Current Motor	Honeywell
2022494-1	Electromechanical Rotary Actuator	Honeywell
2022494-2	Electromechanical Rotary Actuator	Honeywell
2022494-3	Electromechanical Rotary Actuator	Honeywell
2022494-4	Electromechanical Rotary Actuator	Honeywell
2022494-5	Electromechanical Rotary Actuator	Honeywell
2022494-6	Electromechanical Rotary Actuator	Honeywell
2022506-1	Direct Current Motor	Honeywell
2022506-2	Direct Current Motor	Honeywell
2022506-3	Direct Current Motor	Honeywell
2022506-4	Direct Current Motor	Honeywell
2022506-5	Direct Current Motor	Honeywell
2022506-6	Direct Current Motor	Honeywell
2022506-7	Direct Current Motor	Honeywell
2022506-8	Direct Current Motor	Honeywell
2022522-1	Electromechanical Rotary Actuator	Honeywell
2022522-2	Electromechanical Rotary Actuator	Honeywell
2022522-3	Electromechanical Rotary Actuator	Honeywell
2022522-4	Electromechanical Rotary Actuator	Honeywell
2022522-5	Electromechanical Rotary Actuator	Honeywell
2022536-2	Rotary Actuator	Honeywell
2022536-5	Rotary Actuator	Honeywell
2022536-6	Rotary Actuator	Honeywell
2022536-7	Rotary Actuator	Honeywell
2022538-2	Lower Deck Cargo PDU	Honeywell
2022538-3	Lower Deck Cargo PDU	Honeywell
2022538-4	Power Drive Unit	Honeywell
2022538-5	Power Drive Unit	Honeywell
2022538-6	Power Drive Unit	Honeywell
2022538-7	Power Drive Unit	Honeywell
2022538-8	Power Drive Unit	Honeywell
2022622-1	Shock Absorber	Moog
2022622-2	Shock Absorber	Moog
2022622-3	Shock Absorber	Moog
2022622-4	Shock Absorber	Moog
2022622-5	Shock Absorber	Moog
2022670-1	Mechanical Rotary Actuator	Honeywell
202500-5009	Rudder Actuator	Parker Hannifin
202500-5011	Rudder Actuator	Parker Hannifin
202600-5007	Rudder Actuator	Parker Hannifin

Repair_Capability_List_Excel

202600-5009	Rudder Actuator	Parker Hannifin
2029686	Actuator	Messier-Dowty
20300-38A-43-A1	Indicator	Pioneer
2031512	Valve	Messier-Dowty
2032242	Actuator	Messier-Dowty
20362	Stator & Housing	Parker Hannifin
2041220-0401	Weather Radar Control Panel	Honeywell
2041220-0402	Weather Radar Control Panel	Honeywell
2041220-0404	Weather Radar Control Panel	Honeywell
2041220-0405	Weather Radar Control Panel	Honeywell
2041220-0406	Weather Radar Control Panel	Honeywell
2041220-0407	Weather Radar Control Panel	Honeywell
2041220-0409	Weather Radar Control Panel	Honeywell
2041220-0410	Weather Radar Control Panel	Honeywell
2041220-0411	Weather Radar Control Panel	Honeywell
2041220-0412	Weather Radar Control Panel	Honeywell
2041220-0413	Weather Radar Control Panel	Honeywell
2041220-0414	Weather Radar Control Panel	Honeywell
2041220-0415	Weather Radar Control Panel	Honeywell
2041220-0416	Weather Radar Control Panel	Honeywell
2041220-0417	Weather Radar Control Panel	Honeywell
2041220-0418	Weather Radar Control Panel	Honeywell
2041220-0419	Weather Radar Control Panel	Honeywell
2041220-0424	Weather Radar Control Panel	Honeywell
2041220-0425	Weather Radar Control Panel	Honeywell
2041220-0426	Weather Radar Control Panel	Honeywell
2041220-0427	Weather Radar Control Panel	Honeywell
2041220-0429	Weather Radar Control Panel	Honeywell
2041220-0430	Weather Radar Control Panel	Honeywell
2041220-1405	Weather Radar Control Panel	Honeywell
2041220-1406	Weather Radar Control Panel	Honeywell
2041220-1407	Weather Radar Control Panel	Honeywell
2041220-1409	Weather Radar Control Panel	Honeywell
2041230-3503	ILS Receiver	Honeywell
2041230-3504	ILS Receiver	Honeywell
2041230-3514	ILS Receiver	Honeywell
2041230-3515	ILS Receiver	Honeywell
2041230-3516	ILS Receiver	Honeywell
2041230-3517	ILS Receiver	Honeywell
2041230-3518	ILS Receiver	Honeywell
2041230-3519	ILS Receiver	Honeywell
2041230-3520	ILS Receiver	Honeywell
2041230-3521	ILS Receiver	Honeywell
2041230-3522	ILS Receiver	Honeywell
2041230-3523	ILS Receiver	Honeywell
2041230-3525	ILS Receiver	Honeywell
2041230-3526	ILS Receiver	Honeywell
2041230-3527	ILS Receiver	Honeywell
2041230-3528	ILS Receiver	Honeywell
2041230-3529	ILS Receiver	Honeywell
2041230-3530	ILS Receiver	Honeywell
2041230-3531	ILS Receiver	Honeywell
2041230-3532	ILS Receiver	Honeywell
2041230-3533	ILS Receiver	Honeywell
2041231-3601	VOR/Marker Receiver	Honeywell
2041231-3604	VOR/Marker Receiver	Honeywell
2041231-3606	VOR/Marker Receiver	Honeywell
2041231-3607	VOR/Marker Receiver	Honeywell

Repair_Capability_List_Excel

2041231-3608	VOR/Marker Receiver	Honeywell
2041231-3609	VOR/Marker Receiver	Honeywell
2041231-3610	VOR/Marker Receiver	Honeywell
2041231-3611	VOR/Marker Receiver	Honeywell
2041231-3613	VOR/Marker Receiver	Honeywell
2041231-3614	VOR/Marker Receiver	Honeywell
2041231-3615	VOR/Marker Receiver	Honeywell
2041231-3616	VOR/Marker Receiver	Honeywell
2041231-3617	VOR/Marker Receiver	Honeywell
2041231-3618	VOR/Marker Receiver	Honeywell
2041231-3622	VOR/Marker Receiver	Honeywell
2041231-3623	VOR/Marker Receiver	Honeywell
2041237-4401	VHF Comm Transceiver	Honeywell
2041237-4407	VHF Comm Transceiver	Honeywell
2041237-4411	VHF Comm Transceiver	Honeywell
2041237-4413	VHF Comm Transceiver	Honeywell
2041237-4418	VHF Comm Transceiver	Honeywell
2041237-4422	VHF Comm Transceiver	Honeywell
2041237-4424	VHF Comm Transceiver	Honeywell
2041237-4425	VHF Comm Transceiver	Honeywell
2041237-4426	VHF Comm Transceiver	Honeywell
2041237-4428	VHF Comm Transceiver	Honeywell
2041237-4429	VHF Comm Transceiver	Honeywell
2041237-4430	VHF Comm Transceiver	Honeywell
2041237-4431	VHF Comm Transceiver	Honeywell
2041237-4433	VHF Comm Transceiver	Honeywell
2041309-5	Roller Drive Unit	Telair International
2041444-0401	Radar Antenna	Honeywell
2041444-0402	Radar Antenna	Honeywell
2041444-0403	Radar Antenna	Honeywell
2041444-0404	Radar Antenna	Honeywell
2041444-0405	Radar Antenna	Honeywell
2041444-0406	Radar Antenna	Honeywell
2041444-0407	Radar Antenna	Honeywell
2041444-0408	Radar Antenna	Honeywell
2041444-0409	Radar Antenna	Honeywell
2041444-0410	Radar Antenna	Honeywell
2041444-0411	Radar Antenna	Honeywell
2041444-0412	Radar Antenna	Honeywell
2041445-0401	Planar Array	Honeywell
2041445-0402	Planar Array	Honeywell
2041445-0403	Planar Array	Honeywell
2041446-0401	Planar Array	Honeywell
2041446-0402	Planar Array	Honeywell
204185-2	Compressor	Honeywell
204185-3	Compressor	Honeywell
20-455	Trim Push Button Switch	SAMM
2048150-1	Mechanical Rotary Actuator	Moog
204943-2	Diffuser assy	Honeywell
205100-1	XZ-Double Latch	Telair International
2052C08	Booster Pump	Intertechnique
2052C08B	Booster Pump	Intertechnique
2052C09	Booster Pump	Intertechnique
2052C11	Canister Booster Pump	Intertechnique
2052C12	Canister Booster Pump	Intertechnique
2052C20	Booster Pump	Intertechnique
2052C21	Booster Pump	Intertechnique
2052C22	Booster Pump	Intertechnique

Repair_Capability_List_Excel

2052C23	Booster Pump	Intertechnique
2054-03-1	Altimeter	Smiths Industries
2056A0000-01	Air Plenum Chamber	Liebherr Aerotechnik
2057A0101	Control Box	Liebherr Aerospace
2057A0101 Index A	Control Box	Liebherr Aerospace
2057A0101 Index B	Control Box	Liebherr Aerospace
2057A0101 Index C	Control Box	Liebherr Aerospace
205PN01	DC Voltmeter	ECE
205PN01Y01	DC Voltmeter	ECE
205RGU/FA/1	Rate Sensor	Smiths Industries
205RGUFA1	Rate Sensor	Smiths Industries
206200-5001	Check Valve	Parker Hannifin
206200-5003	Check Valve	Parker Hannifin
206200-5005	Check Valve	Parker Hannifin
206200-5007	Check Valve	Parker Hannifin
206200-5009	Check Valve	Parker Hannifin
206200-5011	Check Valve	Parker Hannifin
206200-5013	Check Valve	Parker Hannifin
206200-5015	Check Valve	Parker Hannifin
20645-000-01	NLG Door Actuating Cylinder	Messier-Bugatti
2068600-0701	Wave Guide Switch	Bendix/King
206PN01	DC Voltmeter	ECE
20700-000	Fuel Isolation Valve	Westland-Sitec
20700-300	Fuel Valve assy	Westland-Sitec
2070-06-1	Vertical Speed Indicator	Harowe
207100-1	XZ-Single Latch	Telair International
207100-2	XZ-Single Latch	Telair International
207562-1	Fan	Honeywell
20792-01AA	Outflow Valve	Nord-Micro
20792-02AC	Outflow Valve	Nord-Micro
20800	Control assy	Aero Controlex
20800-1	Control assy	Aero Controlex
20800-1M	Control assy	Aero Controlex
20800-3	Control assy	Aero Controlex
20800-3M	Control assy	Aero Controlex
20800-4	Control assy	Aero Controlex
20800-5	Control assy	Aero Controlex
20800M	Control assy	Aero Controlex
208100-1	YZ-Single Latch	Telair International
208100-2	YZ-Single Latch	Telair International
208100-5	YZ-Single Latch	Telair International
208100-7	YZ-Single Latch	Telair International
20825-3	Cable assy	Aero Controlex
20825-3M	Cable assy	Aero Controlex
20825-4	Cable assy	Aero Controlex
20825-5	Cable assy	Aero Controlex
20841-01	Actuator assy	Hamilton Sundstrand
2086-01-1	Airspeed Indicator	Smiths Industries
209089	Booster Pump	Intertechnique
2090JFA	Fuel Booster Pump	Intertechnique
2090J-FA	Fuel Booster Pump	Intertechnique
209100-1	YZ-Single Latch	Telair International
209100-11	YZ-Single Latch	Telair International
209100-3	YZ-Single Latch	Telair International
209100-5	YZ-Single Latch	Telair International
209100-7	YZ-Single Latch	Telair International
209100-9	YZ-Single Latch	Telair International
2092D	Pump assy	Intertechnique

Repair_Capability_List_Excel

2092E030	APU Fuel Pump Canister	Intertechnique
2092E031	APU Fuel Pump Canister	Intertechnique
20994-01	Safety Valve	Nord-Micro
20995-01AB	Actuator assy	Hamilton Sundstrand
20995-02AC	Actuator assy	Hamilton Sundstrand
20B82-6	Regulator	Bendix/King
20B95-4-A	Regulator	Bendix/King
20C144-3	Check Valve	Allen Aircraft
20C144-4	Check Valve	Allen Aircraft
20C144-7	Check Valve	Allen Aircraft
2100906-011	Turbine Electronics Control	Honeywell
2100906-021	Turbine Electronics Control	Honeywell
210100-1	YZ-Single Latch	Telair International
210100-3	YZ-Single Latch	Telair International
210100-9	YZ-Single Latch	Telair International
21029-01	Gearbox assy	Nord-Micro
21030-000-00	MLG Door Actuating Cylinder	Messier-Bugatti
21036-01	Check Valve	Nord-Micro
210RA01	Probe	ECE
210TS07Y	Control Lever	ECE
210TS07Y01	Control Lever	ECE
211100-1	YZ-Double Latch	Telair International
2111135	Fuse	Messier-Dowty
2111501	Fuse	Messier-Dowty
21179-001	Actuator	Lear Siegler Inc
21182-003	Rotary Actuator	Lear Siegler Inc
21182-004	Rotary Actuator	Lear Siegler Inc
21182-005	Rotary Actuator	Lear Siegler Inc
21182-006	Rotary Actuator	Lear Siegler Inc
21182-007	Rotary Actuator	Lear Siegler Inc
21182-008	Rotary Actuator	Lear Siegler Inc
21182-1	Actuator	Lear Siegler Inc
21183-002	Linear Actuator	Lear Siegler Inc
21183-003	Linear Actuator	Lear Siegler Inc
21183-004	Linear Actuator	Lear Siegler Inc
21183-005	Linear Actuator	Lear Siegler Inc
21185-000	Spoiler/Slat Actuator	Lear Siegler Inc
21191-002	Actuator	Lear Siegler Inc
2119170	Fuse	Messier-Dowty
211C117-185	Pressure Switch	Eaton Aerospace
211C117-222	Pressure Switch	Eaton Aerospace
211C117-223	Pressure Switch	Eaton Aerospace
211C117-245	Pressure Switch	Eaton Aerospace
211C223	Pressure Switch	Consolidated Controls
211C223-175	Pressure Switch	Eaton Aerospace
211C223-176	Pressure Switch	Eaton Aerospace
211C223-177	Pressure Switch	Consolidated Controls
211C223-178	Pressure Switch	Eaton Aerospace
211C223-199	Pressure Switch	Eaton Aerospace
211C223-200	Pressure Switch	Eaton Aerospace
211C223-203	Pressure Switch	Eaton Aerospace
211C223-208	Pressure Switch	Eaton Aerospace
211C223-209	Pressure Switch	Eaton Aerospace
211C223-211	Pressure Switch	Eaton Aerospace
211C223-212	Pressure Switch	Eaton Aerospace
211C223-214	Pressure Switch	Eaton Aerospace
211C223-216	Pressure Switch	Eaton Aerospace
211C223-243	Pressure Switch	Eaton Aerospace

Repair_Capability_List_Excel

211C223-252	Pressure Switch	Eaton Aerospace
211C223-253	Pressure Switch	Eaton Aerospace
211C223-275	Pressure Switch	Eaton Aerospace
211C223-278	Pressure Switch	Eaton Aerospace
211C223-296	Pressure Switch	Eaton Aerospace
211C223-297	Pressure Switch	Eaton Aerospace
211C223-301	Pressure Switch	Eaton Aerospace
211C223-312	Pressure Switch	Eaton Aerospace
211C223-319	Pressure Switch	Consolidated Controls
211C223-320	Pressure Switch	Eaton Aerospace
211C223-321	Pressure Switch	Eaton Aerospace
211C223-322	Pressure Switch	Eaton Aerospace
211C223-323	Pressure Switch	Eaton Aerospace
211C223-324	Pressure Switch	Eaton Aerospace
211C223-326	Pressure Switch	Consolidated Controls
211C223-327	Pressure Switch	Consolidated Controls
211C223-333	Pressure Switch	Eaton
211C223-334	Pressure Switch	Eaton
211C223-474A	Pressure Switch	Consolidated Controls
211C223-516	Pressure Switch	Eaton Aerospace
211C223-517	Pressure Switch	Eaton Aerospace
211C223-518	Pressure Switch	Eaton Aerospace
211C223-519	Pressure Switch	Eaton Aerospace
211C223-520	Pressure Switch	Eaton Aerospace
211C223-521	Pressure Switch	Eaton Aerospace
211C223-522	Pressure Switch	Eaton Aerospace
211C223-523	Pressure Switch	Eaton Aerospace
211C223-524	Pressure Switch	Eaton Aerospace
211C223-525	Pressure Switch	Eaton Aerospace
211C223-526	Pressure Switch	Eaton Aerospace
211C223-527	Pressure Switch	Eaton Aerospace
211C223-528	Pressure Switch	Eaton Aerospace
211C223-529	Pressure Switch	Eaton Aerospace
211C223-534	Pressure Switch	Eaton Aerospace
211C223-535	Pressure Switch	Eaton Aerospace
2120	Individual Air Outlet assy	Puritan Bennett
2120-03	Individual Air Outlet assy	Puritan Bennett
212100-1	YZ-Double Latch	Telair International
212200	Valve	HR Textron
2123M100	Toilet Timer	Amerace
2126-125-00-00	DC Voltmeter	Thales Avionics
2126-215-00-00	AC Voltmeter	Thales Avionics
2126-321-00-00	Ammeter	Thales Avionics
21295-01	Shut-Off Valve	Nord-Micro
2130858	Fuse	Messier-Dowty
2130T100-1	Linear Actuator	Telair International
2131223	Fuse	Messier-Dowty
2131588	Fuse	Messier-Dowty
2133T100-1	Latch	Telair International
2135T100-1	Latch Pallet	Telair International
2135T100-3	Latch Pallet	Telair International
2135T100-5	Latch Pallet	Telair International
2136-113-8	DC Voltmeter	Sextant Avionique
2136-213-8	AC Voltmeter	Sextant Avionique
2136-313-8	DC Ammeter	Sextant Avionique
2136-315-80-11	Ammeter	Thales Avionics
2136-423-8	AC Charge Indicator	Sextant Avionique
2136-713-8	Frequency Meter	Sextant Avionique

Repair_Capability_List_Excel

2136T100-1	Combi Latch	Telair International
2136T100-3	Combi Latch	Telair International
2137	Valve	Lamar
213700	Valve	Textron
2137T100-1	Latch Pallet	Telair International
2137T100-3	Latch Pallet	Telair International
2138T100-1	Latch Pallet	Telair International
2138T100-3	Latch Pallet	Telair International
2139T100-1	Container Latch	Telair International
2139T100-3	Container Latch	Telair International
2139T100-5	Container Latch	Telair International
2139T100-7	Latch-Container	Telair International
214-001-960-101	Servomotor Elevator	Textron
2143T100-1	Latch Pallet	Telair International
2143T100-3	Latch Pallet	Telair International
21450-11	Spoiler Actuator	Parker-Hannifin
21450-13	Spoiler Actuator	Parker-Hannifin
21450-14	Spoiler Actuator	Parker-Hannifin
21450-15	Spoiler Actuator	Parker-Hannifin
2147T100-1	Latch Pallet	Telair International
2147T100-3	Latch Pallet	Telair International
2147T100-5	Latch Pallet	Telair International
214C40-1-113	Switch	Eaton
214C40-1-115	Switch	Eaton
214C40-1-122	Switch	Eaton
214C40-1-59	Pressure Switch	Eaton
214C40-1-71	Switch	Eaton
214C40-1-75	Switch	Eaton
214C40-1-77	Switch	Eaton
214C40-1-8	Pressure Switch	Eaton
214C50-2	Altitude Pressure Switch	Consolidated Controls
214C50-52	Altitude Pressure Switch	Eaton
214C50-71	Transducer	Consolidated Controls
214C50-75	Altitude Pressure Switch	Eaton
215-016-001	Flap Position Indicator	Parker Hannifin
215100-1	Endstop	Telair International
21520	Mixed Flow Fan	Hamilton Sundstrand
21520-1	Mixed Flow Fan	Hamilton Sundstrand
21546-3-11-6	Thermo Switch assy	Klixon
21546-3-12-6	Thermo Switch assy	Klixon
21546-3-86-6	Thermo Switch assy	Klixon
21546-3-95-1	Thermo Switch assy	Klixon
21546-3-96-1	Thermo Switch assy	Klixon
2156-10A	Smoke Detector	Autronics
2156-10B	Smoke Detector	Autronics
2156-10C	Smoke Detector	Autronics
2156-2	Smoke Detector	Autronics
2156-204A	Smoke Detector	Autronics
2156-206A	Smoke Detector	Autronics
2156-2A	Smoke Detector	Autronics
2156-2B	Smoke Detector	Autronics
2156-2C	Smoke Detector	Autronics
2156-4	Smoke Detector	Autronics
2156-4A	Smoke Detector	Autronics
2156-4B	Smoke Detector	Autronics
2156-556HA	Smoke Detector	Autronics
2156-556HS	Smoke Detector	Autronics
2156-604	Smoke Detector	Autronics

Repair_Capability_List_Excel

2156-604A	Smoke Detector	Autronics
2156-606	Smoke Detector	Autronics
2156-606A	Smoke Detector	Autronics
2156-646	Smoke Detector	Autronics
2156-646A	Smoke Detector	Autronics
2156-656	Smoke Detector	Autronics
2156-656A	Smoke Detector	Autronics
2156-756	Smoke Detector	Autronics
2156-756A	Smoke Detector	Autronics
2156-80	Smoke Detector	Autronics
2157520	Fuse	Messier-Dowty
2157T100-1	Latch-Container	Telair International
2158T100-1	Variable YZ Latch	Telair International
215900-5001	Actuator	Parker Hannifin
215900-5003	Actuator	Parker Hannifin
215900-5005	Actuator	Parker Hannifin
215900-5007	Actuator	Parker Hannifin
215900-5009	Actuator	Parker Hannifin
215900-5011	Actuator	Parker Hannifin
215900-5013	Actuator	Parker Hannifin
215900-5015	Actuator	Parker Hannifin
215900-5017	Actuator	Parker Hannifin
216000-5001	Actuator	Berteau
216000-5003	Actuator	Berteau
216000-5005	Actuator	Berteau
216000-5007	Actuator	Berteau
216000-5009	Actuator	Berteau
216000-5011	Actuator	Berteau
216000-5013	Actuator	Berteau
216100-1	YZ Triple Latch	Telair International
216100-11	YZ Latch	Telair International
216100-13	YZ Latch	Telair International
216100-3	YZ Triple Latch	Telair International
216100-5	YZ Latch	Telair International
216100-6	Latch-YZ	Telair International
216100-7	YZ Latch	Telair International
216100-9	YZ Latch	Telair International
2165-4	Sensor	Autronics
2165-4A	Module	Autro
21700-1001	Valve	Parker Hannifin
21700-5001	Valve	Parker Hannifin
217100-1	Latch-YZ	Telair International
217200-4	Check Valve	Textron
217200-5	Check Valve	Textron
217200-6	Check Valve	Textron
217300-5005	Aileron Actuator assy	Parker Hannifin
217300-5007	Aileron Actuator assy	Parker Hannifin
217300-SER	Actuator	Parker Hannifin
2177000	Actuator	NWL Control Systems
2178000	Actuator	NWL Control Systems
2179ACF	Horizon	Bendix/King
218100-1	Latch-YZ	Telair International
218363	Windshield Washer Pump	Intertechnique
218386-2	Scavenge Fuel Pump	Intertechnique
218386-3	Scavenge Fuel Pump	Intertechnique
218386-6	Scavenge Fuel Pump	Intertechnique
218387	APU Fuel Pump	Intertechnique
218391	Scavenge Pump Canister	Intertechnique

Repair_Capability_List_Excel

218391-1	Scavenge Pump Canister	Intertechnique
218391-6	Canister assy	Intertechnique
218813	APU Pump Housing	Intertechnique
218813-1	APU Pump Housing	Intertechnique
2189000-15	Reverser Actuator	Parker Hannifin
2189000-18	Reverser Actuator	Parker Hannifin
2189000-3	Reverser Actuator	Parker Hannifin
2189000-4	Reverser Actuator	Parker Hannifin
2190000-13	Thrust Reverse Actuator	Parker Hannifin
2190000-13M	Thrust Reverse Actuator	Parker Hannifin
2190000-15	Thrust Reverse Actuator	Parker Hannifin
2190000-18	Thrust Reverse Actuator	Parker Hannifin
2190000-18M	Thrust Reverse Actuator	Parker Hannifin
2190000-20	Thrust Reverse Actuator	Parker Hannifin
2190000-21	Thrust Reverse Actuator	Parker Hannifin
2190000-22	Thrust Reverse Actuator	Parker Hannifin
2190000-23	Thrust Reverse Actuator	Parker Hannifin
2190000-24	Thrust Reverse Actuator	Parker Hannifin
2190000-26	Thrust Reverse Actuator	Parker Hannifin
2190000-28	Thrust Reverser Actuator	Parker Hannifin
2190000-30	Thrust Reverser Actuator	Parker Hannifin
2190000-32	Thrust Reverse Actuator	Parker Hannifin
2190000-32M	Thrust Reverse Actuator	Parker Hannifin
2190000-34	Thrust Reverser Actuator	Parker Hannifin
2190000-34M	Thrust Reverser Actuator	Parker Hannifin
2190000-36	Thrust Reverser Actuator	Parker Hannifin
2190000-40	Thrust Reverse Actuator	Parker Hannifin
2190000-42	Locking Actuator	Parker Hannifin
2190000-42M	Locking Actuator	Parker Hannifin
2190000-44	Locking Actuator	Parker Hannifin
2190000-44M	Locking Actuator	Parker Hannifin
2190000-46	Locking Actuator	Parker Hannifin
2190000-48	Thrust Reverse Actuator	Parker Hannifin
2190000-50	Thrust Reverse Actuator	Parker Hannifin
219-003-001	Repeater Indicator	Parker Hannifin
219-003-002	Repeater Indicator	Parker Hannifin
219-003-003	Repeater Indicator	Parker Hannifin
219100-1	Latch YZ Single	Telair International
219100-2	Latch YZ Single	Telair International
2192000-3	Thrust Reverser Actuator	Parker Hannifin
2192000-4	Thrust Reverser Actuator	Parker Hannifin
2192000-5	Thrust Reverser Actuator	Parker Hannifin
2192000-6	Thrust Reverser Actuator	Parker Hannifin
2192000-7	Thrust Reverser Actuator	Parker Hannifin
21B107-6-A	Generator Control Unit	Hamilton Sundstrand
21SN04-104A	Pressure Switch	Eaton
21SN04-104B	Pressure Switch	Eaton
21SN04-104D	Pressure Switch	Eaton
21SN04-121	Pressure Switch	Consolidated Controls
21SN04-123	Pressure Switch	Eaton
21SN04-124	Pressure Switch	Eaton
21SN04-148	Pressure Switch	Eaton
21SN04-149	Pressure Switch	Eaton
21SN04-158A	Pressure Switch	Eaton
21SN04-158B	Pressure Switch	Eaton
21SN04-159	Pressure Switch	Eaton
21SN04-159A	Pressure Switch	Eaton
21SN04-159B	Pressure Switch	Eaton

Repair_Capability_List_Excel

21SN04-180	Pressure Switch	Eaton
21SN04-180A	Pressure Switch	Eaton
21SN04-183	Pressure Switch	Eaton
21SN04-183A	Pressure Switch	Eaton
21SN04-19A	Pressure Switch	Eaton
21SN04-19B	Pressure Switch	Eaton
21SN04-209	Pressure Switch	Eaton
21SN04-209A	Pressure Switch	Eaton
21SN04-20A	Pressure Switch	Eaton
21SN04-211	Pressure Switch	Eaton
21SN04-211A	Pressure Switch	Eaton
21SN04-223	Fuel Pressure Switch	Eaton
21SN04-224	Differential Pressure Switch	Eaton
21SN04-225	Differential Pressure Switch	Eaton
21SN04-226	Pressure Switch	Eaton
21SN04-226A	Pressure Switch	Eaton
21SN04-228	Pressure Switch	Eaton
21SN04-23F	Pressure Switch	Eaton
21SN04-23G	Pressure Switch	Eaton
21SN04-23H	Pressure Switch	Eaton
21SN04-23J	Pressure Switch	Eaton
21SN04-24F	Pressure Switch	Eaton
21SN04-24G	Pressure Switch	Eaton
21SN04-24H	Pressure Switch	Eaton
21SN04-25C	Pressure Switch	Consolidated Controls
21SN04-25F	Pressure Switch	Eaton
21SN04-25G	Pressure Switch	Eaton
21SN04-25H	Pressure Switch	Eaton
21SN04-268	Pressure Switch	Eaton
21SN04-269	Pressure Switch	Eaton
21SN04-26E	Pressure Switch	Eaton
21SN04-26F	Pressure Switch	Eaton
21SN04-26G	Pressure Switch	Eaton
21SN04-30	Pressure Switch	Consolidated Controls
21SN04-306A	Pressure Switch	Eaton
21SN04-323A	Fuel Pressure Switch	Eaton
21SN04-324	Differential Pressure Switch	Eaton
21SN04-325	Differential Pressure Switch	Eaton
21SN04-33	Pressure Switch	Consolidated Controls
21SN04-333	Fuel Pressure Switch	Eaton
21SN04-334	Differential Pressure Switch	Eaton
21SN04-335	Differential Pressure Switch	Eaton
21SN04-33A	Pressure Switch	Consolidated Controls
21SN04-34	Pressure Switch	Consolidated Controls
21SN04-389A	Pressure Switch	Eaton
21SN04-389B	Pressure Switch	Eaton
21SN04-402	Pressure Switch	Eaton
21SN04-403	Pressure Switch	Eaton
21SN04-414	Pressure Switch	Eaton
21SN04-415	Pressure Switch	Eaton
21SN04-460	Pressure Switch	Eaton
21SN04-461	Pressure Switch	Eaton
21SN04-466	Fuel Pressure Switch	Eaton
21SN04-467	Differential Pressure Switch	Eaton
21SN04-468	Differential Pressure Switch	Eaton
21SN04-58	Pressure Switch	Eaton
21SN04-59	Pressure Switch	Eaton
21SN04-70A	Moicroswitch assy	Consolidated Controls

Repair_Capability_List_Excel

21SN04-71	Pressure Switch	Consolidated Controls
21SN04-89	Pressure Switch	Eaton
21SN04-98	Pressure Switch	Eaton Aerospace
21SN41	Pressure Switch	Consolidated Controls
21SN41-129A	Pressure Switch	Goodrich
21SN41-13	Pressure Switch	Eaton
21SN41-1A	Pressure Switch	Eaton
21SN41-1B	Pressure Switch	Eaton
21SN41-30	Pressure Switch	Eaton
21SN41-4	Pressure Switch	Eaton
21SN41-42	Pressure Switch	Eaton
21SN41-43	Pressure Switch	Consolidated Controls
21SN41-49	Pressure Switch	Consolidated Controls
21SN41-49A	Pressure Switch	Eaton
21SN41-4A	Pressure Switch	Eaton
21SN41-5	Pressure Switch	Eaton
21SN41-52	Pressure Switch	Eaton
21SN41-5A	Pressure Switch	Eaton
21SN41-82	Pressure Switch	Eaton
21SN41-82A	Pressure Switch	Eaton
21SN41-84	Pressure Switch	Eaton
21SN41-86A	Pressure Switch	Eaton
21SY3008B1	Core Speed Sensor	General Electric
2200218-1	Relief Valve	Honeywell
2201968-1	Cooling Air Plenum ay	Honeywell
2201968-2	Cooling Air Plenum ay	Honeywell
2212845-2	Temperature Control Valve	Honeywell
2214079-1	Water Extractor Duct	Honeywell
2214805-2	Turbine Inlet Control Valve	Honeywell
2214805-4	Turbine Inlet Control Valve	Honeywell
2215240-1	LH Primary Heat Exch Unit	Honeywell
2215240-2	LH Primary Heat Exch Unit	Honeywell
2215250-1	LH Secondary Heat Exch Unit	Honeywell
2215280-1	RH Primary Heat Exch Unit	Honeywell
2215280-2	RH Primary Heat Exch Unit	Honeywell
2215290-1	RH Secondary Heat Exch Unit	Honeywell
2215490-1	LH Secondary Heat Exch Unit	Honeywell
2215510-1	RH Secondary Heat Exch Unit	Honeywell
22185-000	Actuator	Lear Siegler Inc
221TS02Y02	Landing Gear Control Handle Module	ECE
22200-8-A5	Pressure Transmitter	Pioneer
22201-14-A5	Pressure Transmitter	Pioneer
22201-14-B5-1	Pressure Transmitter	Pioneer
222075	Valve	Whittaker
222085	Valve	Meggitt Avionics
22229	Hydraulic Pump	Hamilton Sundstrand
22229-1	Hydraulic Pump	Hamilton Sundstrand
22253340	Servo Valve	Hydraulic Research
22253350	Servo Valve	Hydraulic Research
22-262	Fuel Flow Indicator	EDO-Aire
22270-3	Valve	Goodrich Control Systems
22280710	Servo Valve	HR Textron
22280730	Servo Valve	HR Textron
22290010-104	Servo Valve	HR Textron
223-0057-000	Three Axis Accelerometer	Sagem
22310	Vaneaxial Fan assy	Hamilton Sundstrand
223100-1	XZ Single Latch	Telair International
22310-1	Fan assy	Hamilton Sundstrand

Repair_Capability_List_Excel

22322SET12	Clock	Newal
223585	Valve assy	Meggitt Avionics
224245-1	Valve	Meggitt Avionics
224245-2	Valve	Meggitt Avionics
224245-3	Valve	Meggitt Avionics
224245-4	Valve	Meggitt Avionics
224545	Valve	Meggitt Avionics
224575	Valve	Whittaker
224575-1	Valve assy	Whittaker
22-468	Fuel Flow Indicator	EDO-Aire
224685	Valve	Meggitt Avionics
224TS05Y	Landing Gear Control Module Handle	ECE
225485	Valve	Meggitt Avionics
225885	Valve	Whittaker
226114-1	Fuel Booster Pump	Intertechnique
226114-3	Fuel Booster Pump	Intertechnique
226115-1	Canister	Intertechnique
226115-2	Canister	Intertechnique
2262-02-1	Total Air Temperature Indicator	Smiths Industries
226215	Valve	Whittaker
2263-01-01	Compartment Temperature Indicator	Smiths Industries
2263-01-1	Compartment Temperature Indicator	Smiths Industries
22715-000-00	Door Actuating Cylinder	Messier-Bugatti
22715-000-02	Door Actuating Cylinder	Messier-Bugatti
2275020	Indicator	Honeywell
2275021	Indicator	Honeywell
227545	Valve	Whittaker
227565	Valve	Whittaker
2279-001-1	Valve	Carleton Technologies
2279-002-1	Valve	Carleton Technologies
2279-003-1	Valve	Carleton Technologies
2279-003-11	Valve	Carleton Technologies
2279-003-13	Valve	Carleton Technologies
2279-003-15	Valve	Carleton Technologies
2279-003-17	Valve	Carleton Technologies
2279-004-1	Valve	Carleton Technologies
2279-005-1	Valve	Carleton Technologies
2279-006-1	Valve	Carleton Technologies
228077-3	APU Booster Pump	Intertechnique
228078	Canister	Intertechnique
228100-1	YZ-Double Latch	Telair International
228105	Valve	Whittaker
228106	Valve	Whittaker
228143	APU Booster Pump	Intertechnique
2283-07	Reverser Opening Power Pack	Fluid Regulators
2-2856-3	Valve	Teledyne Controls
22890-2	Valve assy	Sterer
229-0316-040	Rate Gyro	Rockwell-Collins
2290A02	Check Valve	Liebherr Aerospace
2290A02 Amdt A	Check Valve	Liebherr Aerospace
2290A030000	Check Valve	Liebherr Aerospace
2290A030000 Amdt A	Check Valve	Liebherr Aerospace
2290A040000	Check Valve	Liebherr Aerospace
2290A050000	Check Valve	Liebherr Aerospace
2290B010000	Check Valve	Liebherr Aerospace
229165	Valve assy	Whittaker
2291A010000	Check Valve	Liebherr Aerospace
2291A020000	Check Valve	Liebherr Aerospace

Repair_Capability_List_Excel

2291A030000	Check Valve	Liebherr Aerospace
2292A010000	Check Valve	Liebherr Aerospace
2293A010000	Check Valve	Liebherr Aerospace
2293B010000	Check Valve	Liebherr Aerospace
229432	Fuel Booster Pump	Intertechnique
229506	Inlet Valve assy	Intertechnique
229507	Inlet Valve assy	Intertechnique
229508	Inlet Valve assy	Intertechnique
229509	Inlet Valve assy	Intertechnique
2-299	Transformer 'Rectifier	Eldec Corp.
229-9006-010	Sensor	Rockwell-Collins
2-299-1	Transformer 'Rectifier	Eldec Corp.
229945	Fuel Booster Pump	Intertechnique
22A667	Generator	Globe Industries Inc
2300-01-1	Fuel Indicator	Smiths Industries
23000-3	Aileron Actuator assy	Menasco Aerospace
23000-3A	Aileron Actuator assy	Menasco Aerospace
23000-4	Aileron Actuator	Menasco Aerospace
23000-4A	Aileron Actuator assy	Menasco Aerospace
23000-5	Aileron Actuator assy	Menasco Aerospace
23000-6	Aileron Actuator assy	Menasco Aerospace
23000-7	Aileron Actuator assy	Menasco Aerospace
23000-8	Aileron Actuator assy	Menasco Aerospace
2300-1	Motor Fan	Smiths Industries
2300-10	Motor Fan	Smiths Industries
2300-11	Motor Fan	Smiths Industries
2300-12	Motor Fan	Smiths Industries
2300-13	Motor Fan	Smiths Industries
2300-14	Motor Fan	Smiths Industries
2300-2	Motor Fan	Smiths Industries
2300-3	Motor Fan	Smiths Industries
2300-4	Motor Fan	Smiths Industries
2300-5	Motor Fan	Smiths Industries
2300-6	Motor Fan	Smiths Industries
2300-7	Motor Fan	Smiths Industries
2300-8	Motor Fan	Smiths Industries
2300-9	Motor Fan	Smiths Industries
2-301	Battery Charger	Eldec Corp.
2-301-3	Battery Charger	Eldec Corp.
2301KID01	Tank Contents Display	Smiths Industries
2302KID01	Tank Contents Display	Smiths Industries
2303KID01	Tank Contents Display	Smiths Industries
2304KID01	Tank Contents Display	Smiths Industries
2306-101-00-10	DC Voltmeter	Thales Avionics
2306-201-00-10	AC Voltmeter	Thales Avionics
2306-301-00-11	DC Ammeter	Thales Avionics
23064-001	DC Generator	Lear Siegler Inc
2306-401-00-10	AC Ammeter	Thales Avionics
2306-701-00-10	Frequency Meter	Thales Avionics
2307-06-2	FUEL QTY INDICATOR	SMITHS
2307-07-2	FUEL QTY INDICATOR	SMITHS
2307-08-2	FUEL QTY INDICATOR	SMITHS
2307-09-2	FUEL QTY INDICATOR	SMITHS
2307-10-2	FUEL QTY INDICATOR	SMITHS
23078-019	Generator	Lear Siegler Inc
230905	Shut-Off Valve	Whittaker
230905-1	Shut-Off Valve	Whittaker
230QA01	Unbalance Detector	ECE

Repair_Capability_List_Excel

23100-11	Horizontal Stabilizer Control Unit	Menasco Aerospace
23100-5	Horizontal Stabilizer Control Unit	Menasco Aerospace
23100-5A	Horizontal Stabilizer Control Unit	Menasco Aerospace
23100-5AA	Horizontal Stabilizer Control Unit	Menasco Aerospace
23100-7	Horizontal Stabilizer Control Unit	Menasco Aerospace
23100-9	Horizontal Stabilizer Control Unit	Menasco Aerospace
2311M132	Wiper	Rosemount Aerospace
2311M208	Wiper Motor	Rosemount Aerospace
2311M49-1	Windshield Wiper Motor	Rosemount Aerospace
2311M49-2	Windshield Wiper Motor	Rosemount Aerospace
2311M49-3	Windshield Wiper Motor	Rosemount Aerospace
2311M50-1	Windshield Wiper Motor	Rosemount Aerospace
2311M50-2	Windshield Wiper Motor	Rosemount Aerospace
2311M51-1	Windshield Wiper Motor	Rosemount Aerospace
2311M51-2	Windshield Wiper Motor	Rosemount Aerospace
2311M69-1	Windshield Wiper Motor	Rosemount Aerospace
2311M69-2	Windshield Wiper Motor	Rosemount Aerospace
2311M69-3	Windshield Wiper Motor	Rosemount Aerospace
2311M69-4	Windshield Wiper Motor	Rosemount Aerospace
2311M69-5	Windshield Wiper Motor	Rosemount Aerospace
2311M69-6	Windshield Wiper Motor	Rosemount Aerospace
2311M84-1	Windshield Wiper Motor	Rosemount Aerospace
231-2	Temperature Control	Primex-Pac.Elect.Dyn.
231-2A	Temperature Control	Primex-Pac.Elect.Dyn.
231-2B	Temperature Control	Primex-Pac.Elect.Dyn.
231-2C	Temperature Control	Primex-Pac.Elect.Dyn.
2312M30-1	Convactor assy	Rosemount
2312M30-31	Windshield Wiper Converter	Rosemount Aerospace
2312M35-2	Windshield Wiper Converter	Rosemount Aerospace
2312M41	Wiper Converter	Rosemount Aerospace
2312M55-1	Convactor assy	Rosemount
2312M67-1	Windshield Wiper Converter	Rosemount Aerospace
231-3	Temperature Control	Primex-Pac.Elect.Dyn.
2313M153	Motor Converter	Rosemount Aerospace
2313M186-3	Windshield Wiper Motor Converter	Rosemount
2313M186-4	Windshield Wiper Motor Converter	Rosemount
2313M194	Motor Converter	Rosemount Aerospace
2313M194-3	Motor Converter	Rosemount Aerospace
2313M194-4	Motor Converter	Rosemount Aerospace
2313M21	Motor Converter	Rosemount Aerospace
2313M227	Wiper Converter	Rosemount Aerospace
2313M334-1	Windshield Wiper Motor-Converter	Rosemount Aerospace
2313M335-1	Windshield Wiper Motor-Converter	Rosemount Aerospace
2313M37-1	Windshield Wiper Motor-Converter	Rosemount Aerospace
2313M37-2	Windshield Wiper Motor-Converter	Rosemount Aerospace
2313M37-3	Windshield Wiper Motor-Converter	Rosemount Aerospace
23156-1	Harness assy	Fokker Aircraft
23156-3	Harness assy	Fokker Aircraft
23156-5	Harness assy	Fokker Aircraft
23164-1	Harness assy	Fokker Aircraft
231CZ01	Latching Contactactor	Intertechnique
231QA01	Unbalance Detector	ECE
23203	Flap Position Transmitter	Bendix
2321961	Fan	Precvo
2326776	Fan	Precvo
232QA01	Unbalance Detector	ECE
23300-5	Speedbrake Actuator	Menasco Aerospace
23300-7	Speedbrake Actuator	Menasco Aerospace

Repair_Capability_List_Excel

23300-9	Speedbrake Actuator	Menasco Aerospace
233145	Valve assy	Whittaker
23318	Cable assy	ECE
23318-1	Cable assy	ECE
233N3201-11	Windshield Clearance Panel	Boeing
233N3201-13	Windshield Clearance Panel	Boeing
233N3201-16	Windshield Clearance Panel	Boeing
233N3201-18	Windshield Clearance Panel	Boeing
233N3201-300	Windshield Clearance Panel	Boeing
233N3201-302	Windshield Clearance Panel	Boeing
233N3201-303	Windshield Clearance Panel	Boeing
233N3201-304	Windshield Clearance Panel	Boeing
233N3201-9	Windshield Clearance Panel	Boeing
233N3209-12	Panel assy	Boeing
233N3209-14	Panel assy	Boeing
233N3209-16	Panel assy	Boeing
233N3209-18	Panel assy	Boeing
233N3209-19	Panel assy	Boeing
233N3209-20	Panel assy	Boeing
233N3209-22	Panel assy	Boeing
233N3209-23	Panel assy	Boeing
233N3209-24	Panel assy	Boeing
233N3209-25	Panel assy	Boeing
233N3209-26	Panel assy	Boeing
233N3209-27	Panel assy	Boeing
233N3209-28	Panel assy	Boeing
233N3209-29	Panel assy	Boeing
233N3209-300	Panel assy	Boeing
233N3209-301	Panel assy	Boeing
233N3209-302	Panel assy	Boeing
233N3209-303	Panel assy	Boeing
233N3209-304	Panel assy	Boeing
233N3209-305	Panel assy	Boeing
233N3209-306	Panel assy	Boeing
233N3209-307	Panel assy	Boeing
233N3209-308	Panel assy	Boeing
233N3209-309	Panel assy	Boeing
233N3209-34	Panel assy	Boeing
233N3209-6	Panel assy	Boeing
233N3211-11	Battery Stand-by Panel	Boeing
233N3211-15	Battery Stand-by Panel	Boeing
233N3211-19	Battery Stand-by Panel	Boeing
233N3211-24	Battery Stand-by Panel	Boeing
233N3211-25	Battery Stand-by Panel	Boeing
233N3211-26	Battery Stand-by Panel	Boeing
233N3211-27	Battery Stand-by Panel	Boeing
233N3211-29	Battery Stand-by Panel	Boeing
233N3211-30	Battery Stand-by Panel	Boeing
233N3211-31	Battery Stand-by Panel	Boeing
233N3211-32	Battery Stand-by Panel	Boeing
233N3211-33	Battery Stand-by Panel	Boeing
233N3211-34	Battery Stand-by Panel	Boeing
233N3211-35	Battery Stand-by Panel	Boeing
233N3211-36	Battery Stand-by Panel	Boeing
233N3211-37	Battery Stand-by Panel	Boeing
233N3211-38	Battery Stand-by Panel	Boeing
233N3211-39	Battery Stand-by Panel	Boeing
233N3211-40	Battery Stand-by Panel	Boeing

Repair_Capability_List_Excel

233N3211-41	Battery Stand-by Panel	Boeing
233N3211-42	Battery Stand-by Panel	Boeing
233N3211-46	Panel assy	Boeing
233N3211-8	Battery Stand-by Panel	Boeing
233N3212-10	Window Heat Panel	Boeing
233N3212-11	Window Heat Panel	Boeing
233N3212-12	Window Heat Panel	Boeing
233N3212-13	Window Heat Panel	Boeing
233N3212-14	Window Heat Panel	Boeing
233N3212-300	Window Heat Panel	Boeing
233N3212-301	Window Heat Panel	Boeing
233N3212-302	Window Heat Panel	Boeing
233N3212-8	Window Heat Panel	Boeing
233N3214-22	Lighting Control Panel	Boeing
233N3214-24	Lighting Control Panel	Boeing
233N3214-26	Lighting Control Panel	Boeing
233N3214-27	Lighting Control Panel	Boeing
233N3214-28	Lighting Control Panel	Boeing
233N3214-29	Lighting Control Panel	Boeing
233N3214-300	Lighting Control Panel	Boeing
233N3214-301	Lighting Control Panel	Boeing
233N3214-302	Lighting Control Panel	Boeing
233N3214-303	Lighting Control Panel	Boeing
233N3214-304	Lighting Control Panel	Boeing
233N3214-305	Lighting Control Panel	Boeing
233N3214-31	Lighting Control Panel	Boeing
233N3214-32	Lighting Control Panel	Boeing
233N3214-33	Lighting Control Panel	Boeing
233N3214-34	Lighting Control Panel	Boeing
233N3214-38	Lighting Control Panel	Boeing
233N3214-41	Lighting Control Panel	Boeing
233N3216-14	Panel assy	Boeing
233N3216-15	Panel assy	Boeing
233N3216-18	Panel assy	Boeing
233N3216-19	Panel assy	Boeing
233N3216-20	Panel assy	Boeing
233N3216-21	Panel assy	Boeing
233N3216-22	Panel assy	Boeing
233N3216-23	Panel assy	Boeing
233N3216-24	Panel assy	Boeing
233N3216-25	Panel assy	Boeing
233N3216-26	Panel assy	Boeing
233N3216-27	Panel assy	Boeing
233N3216-30	Panel assy	Boeing
233N3216-300	Panel assy	Boeing
233N3216-301	Panel assy	Boeing
233N3216-302	Panel assy	Boeing
233N3216-303	Panel assy	Boeing
233N3217-15	Control Panel	Boeing
233N3221-300	Right Lighting Control Panel	Boeing
233N3221-301	Right Lighting Control Panel	Boeing
233N3221-302	Right Lighting Control Panel	Boeing
233N3221-303	Right Lighting Control Panel	Boeing
233N3221-304	Right Lighting Control Panel	Boeing
233N3221-305	Right Lighting Control Panel	Boeing
233N3221-306	Right Lighting Control Panel	Boeing
233N3221-307	Right Lighting Control Panel	Boeing
233N3221-308	Right Lighting Control Panel	Boeing

Repair_Capability_List_Excel

233N3221-309	Right Lighting Control Panel	Boeing
233N3221-31	Right Lighting Control Panel	Boeing
233N3221-310	Right Lighting Control Panel	Boeing
233N3221-311	Right Lighting Control Panel	Boeing
233N3221-312	Right Lighting Control Panel	Boeing
233N3221-313	Right Lighting Control Panel	Boeing
233N3221-314	Right Lighting Control Panel	Boeing
233N3221-315	Right Lighting Control Panel	Boeing
233N3221-316	Right Lighting Control Panel	Boeing
233N3221-317	Right Lighting Control Panel	Boeing
233N3221-318	Right Lighting Control Panel	Boeing
233N3221-319	Right Lighting Control Panel	Boeing
233N3221-32	Right Lighting Control Panel	Boeing
233N3221-320	Right Lighting Control Panel	Boeing
233N3221-321	Right Lighting Control Panel	Boeing
233N3221-322	Right Lighting Control Panel	Boeing
233N3221-323	Right Lighting Control Panel	Boeing
233N3221-324	Right Lighting Control Panel	Boeing
233N3221-325	Right Lighting Control Panel	Boeing
233N3221-326	Right Lighting Control Panel	Boeing
233N3221-34	Right Lighting Control Panel	Boeing
233N3221-40	Right Lighting Control Panel	Boeing
233N3221-43	Right Lighting Control Panel	Boeing
233N3221-44	Right Lighting Control Panel	Boeing
233N3221-45	Right Lighting Control Panel	Boeing
233N3221-46	Right Lighting Control Panel	Boeing
233N3221-47	Right Lighting Control Panel	Boeing
233N3221-50	Right Lighting Control Panel	Boeing
233N3221-51	Right Lighting Control Panel	Boeing
233N3221-57	Right Lighting Control Panel	Boeing
233N3221-58	Right Lighting Control Panel	Boeing
233N3221-59	Right Lighting Control Panel	Boeing
233N3221-60	Right Lighting Control Panel	Boeing
233N3221-61	Right Lighting Control Panel	Boeing
233N3221-63	Right Lighting Control Panel	Boeing
233N3221-64	Right Lighting Control Panel	Boeing
233N3221-66	Right Lighting Control Panel	Boeing
233N3221-69	Right Lighting Control Panel	Boeing
233N3221-72	Right Lighting Control Panel	Boeing
233N3221-73	Right Lighting Control Panel	Boeing
233N3221-75	Right Lighting Control Panel	Boeing
233N3221-80	Right Lighting Control Panel	Boeing
233N3221-82	Right Lighting Control Panel	Boeing
233N3221-83	Right Lighting Control Panel	Boeing
233N3221-84	Right Lighting Control Panel	Boeing
233N3221-85	Right Lighting Control Panel	Boeing
233N3221-86	Right Lighting Control Panel	Boeing
233N3221-87	Right Lighting Control Panel	Boeing
233N3221-88	Right Lighting Control Panel	Boeing
233N3221-89	Right Lighting Control Panel	Boeing
233N3221-90	Right Lighting Control Panel	Boeing
233N3221-94	Right Lighting Control Panel	Boeing
233N3232-1	Panel assy	Boeing
233N3232-300	Panel assy	Boeing
233N6203-103	APU & Fire Control Panel	Boeing
233N6203-104	APU & Fire Control Panel	Boeing
233N6203-105	APU & Fire Control Panel	Boeing
233N6203-109	APU & Fire Control Panel	Boeing

Repair_Capability_List_Excel

233N6203-110	APU & Fire Control Panel	Boeing
233N6203-111	APU & Fire Control Panel	Boeing
233N6203-112	APU & Fire Control Panel	Boeing
233N6203-114	APU & Fire Control Panel	Boeing
233N6203-117	APU & Fire Control Panel	Boeing
233N6203-12	APU & Fire Control Panel	Boeing
233N6203-120	APU & Fire Control Panel	Boeing
233N6203-123	APU & Cargo Fire Control Pane	Boeing
233N6203-126	APU & Cargo Fire Control Pane	Boeing
233N6203-129	APU & Fire Control Panel	Boeing
233N6203-13	APU & Fire Control Panel	Boeing
233N6203-132	APU & Cargo Fire Control Pane	Boeing
233N6203-135	APU & Cargo Fire Control Pane	Boeing
233N6203-138	APU & Fire Control Panel	Boeing
233N6203-143	APU & Fire Control Panel	Boeing
233N6203-144	APU & Fire Control Panel	Boeing
233N6203-146	APU & Fire Control Panel	Boeing
233N6203-157	APU & Fire Control Panel	Boeing
233N6203-159	APU & Fire Control Panel	Boeing
233N6203-160	APU & Cargo Fire Control Pane	Boeing
233N6203-161	APU & Fire Control Panel	Boeing
233N6203-162	APU & Fire Control Panel	Boeing
233N6203-163	APU & Fire Control Panel	Boeing
233N6203-164	APU & Fire Control Panel	Boeing
233N6203-165	APU & Fire Control Panel	Boeing
233N6203-166	APU & Fire Control Panel	Boeing
233N6203-169	APU & Fire Control Panel	Boeing
233N6203-170	APU & Fire Control Panel	Boeing
233N6203-171	APU & Fire Control Panel	Boeing
233N6203-172	APU & Fire Control Panel	Boeing
233N6203-173	APU & Fire Control Panel	Boeing
233N6203-174	APU & Fire Control Panel	Boeing
233N6203-175	APU & Fire Control Panel	Boeing
233N6203-177	APU & Fire Control Panel	Boeing
233N6203-178	APU & Fire Control Panel	Boeing
233N6203-179	APU & Fire Control Panel	Boeing
233N6203-180	APU & Fire Control Panel	Boeing
233N6203-181	APU & Fire Control Panel	Boeing
233N6203-182	APU & Cargo Fire Control Pane	Boeing
233N6203-183	APU & Cargo Fire Control Pane	Boeing
233N6203-184	APU & Cargo Fire Control Pane	Boeing
233N6203-185	APU & Cargo Fire Control Pane	Boeing
233N6203-186	APU & Fire Control Panel	Boeing
233N6203-187	APU & Fire Control Panel	Boeing
233N6203-188	APU & Fire Control Panel	Boeing
233N6203-189	APU & Fire Control Panel	Boeing
233N6203-190	APU & Fire Control Panel	Boeing
233N6203-191	APU & Fire Control Panel	Boeing
233N6203-192	APU & Fire Control Panel	Boeing
233N6203-193	APU & Fire Control Panel	Boeing
233N6203-194	APU & Fire Control Panel	Boeing
233N6203-195	APU & Fire Control Panel	Boeing
233N6203-196	APU & Fire Control Panel	Boeing
233N6203-197	APU & Fire Control Panel	Boeing
233N6203-198	APU & Fire Control Panel	Boeing
233N6203-199	APU & Cargo Fire Control Pane	Boeing
233N6203-200	APU & Fire Control Panel	Boeing
233N6203-201	APU & Cargo Fire Control Pane	Boeing

Repair_Capability_List_Excel

233N6203-202	APU & Fire Control Panel	Boeing
233N6203-203	APU & Fire Control Panel	Boeing
233N6203-204	APU & Fire Control Panel	Boeing
233N6203-205	APU & Fire Control Panel	Boeing
233N6203-206	APU & Fire Control Panel	Boeing
233N6203-207	APU & Fire Control Panel	Boeing
233N6203-208	APU & Fire Control Panel	Boeing
233N6203-209	APU & Fire Control Panel	Boeing
233N6203-21	APU & Fire Control Panel	Boeing
233N6203-210	APU & Fire Control Panel	Boeing
233N6203-211	APU & Fire Control Panel	Boeing
233N6203-212	APU & Fire Control Panel	Boeing
233N6203-213	APU & Fire Control Panel	Boeing
233N6203-214	APU & Fire Control Panel	Boeing
233N6203-215	APU & Fire Control Panel	Boeing
233N6203-216	APU & Fire Control Panel	Boeing
233N6203-217	APU & Fire Control Panel	Boeing
233N6203-218	APU & Fire Control Panel	Boeing
233N6203-219	APU & Fire Control Panel	Boeing
233N6203-220	APU & Fire Control Panel	Boeing
233N6203-221	APU & Fire Control Panel	Boeing
233N6203-222	APU & Cargo Fire Control Pane	Boeing
233N6203-23	APU & Fire Control Panel	Boeing
233N6203-24	APU & Fire Control Panel	Boeing
233N6203-32	APU & Fire Control Panel	Boeing
233N6203-339	APU & Cargo Fire Control Pane	Boeing
233N6203-340	APU & Cargo Fire Control Pane	Boeing
233N6203-341	APU & Cargo Fire Control Pane	Boeing
233N6203-342	APU & Cargo Fire Control Pane	Boeing
233N6203-343	APU & Cargo Fire Control Pane	Boeing
233N6203-344	APU & Cargo Fire Control Pane	Boeing
233N6203-345	APU & Cargo Fire Control Pane	Boeing
233N6203-346	APU & Cargo Fire Control Pane	Boeing
233N6203-35	APU & Fire Control Panel	Boeing
233N6203-36	APU & Fire Control Panel	Boeing
233N6203-45	APU & Fire Control Panel	Boeing
233N6203-46	APU & Fire Control Panel	Boeing
233N6203-47	APU & Fire Control Panel	Boeing
233N6203-48	APU & Fire Control Panel	Boeing
233N6203-53	APU & Fire Control Panel	Boeing
233N6203-56	APU & Fire Control Panel	Boeing
233N6203-67	APU & Fire Control Panel	Boeing
233N6203-7	APU & Fire Control Panel	Boeing
233N6203-70	APU & Fire Control Panel	Boeing
233N6203-73	APU & Fire Control Panel	Boeing
233N6203-75	APU & Fire Control Panel	Boeing
233N6203-77	APU & Fire Control Panel	Boeing
233N6203-78	APU & Cargo Fire Control Pane	Boeing
233N6203-79	APU & Fire Control Panel	Boeing
233N6203-80	APU & Cargo Fire Control Pane	Boeing
233N6203-81	APU & Cargo Fire Control Pane	Boeing
233N6203-82	APU & Fire Control Panel	Boeing
233N6203-83	APU & Cargo Fire Control Pane	Boeing
233N6203-84	APU & Cargo Fire Control Pane	Boeing
233N6203-85	APU & Fire Control Panel	Boeing
233N6203-86	APU & Fire Control Panel	Boeing
233N6203-88	APU & Fire Control Panel	Boeing
233N6203-89	APU & Fire Control Panel	Boeing

Repair_Capability_List_Excel

233N6203-9	APU & Fire Control Panel	Boeing
233N6203-90	APU & Fire Control Panel	Boeing
233N6203-91	APU & Fire Control Panel	Boeing
233N6203-92	APU & Fire Control Panel	Boeing
233N6203-93	APU & Fire Control Panel	Boeing
233N6203-94	APU & Fire Control Panel	Boeing
233N6203-95	APU & Fire Control Panel	Boeing
233N6203-96	APU & Fire Control Panel	Boeing
233N6203-97	APU & Fire Control Panel	Boeing
233N6203-98	APU & Fire Control Panel	Boeing
233N6203-99	APU & Fire Control Panel	Boeing
233N6205-1	Engine Fire Control Panel	Boeing
233N6205-12	Engine Fire Control Panel	Boeing
233N6205-18	Engine Fire Control Panel	Boeing
233N6205-6	Engine Fire Control Panel	Boeing
233N6205-8	Engine Fire Control Panel	Boeing
233N6205-9	Engine Fire Control Panel	Boeing
233N6206-1	Panel assy	Boeing
233N6206-301	Panel assy	Boeing
233N6206-302	Panel assy	Boeing
233N6206-6	Panel assy	Boeing
233N7508-11	Recorder/Service Interphone Panel	Boeing
233N7508-13	Recorder/Service Interphone Panel	Boeing
233N7508-14	Recorder/Service Interphone Panel	Boeing
233N7508-20	Recorder/Service Interphone Panel	Boeing
233N7508-23	Recorder/Service Interphone Panel	Boeing
233N7508-7	Recorder/Service Interphone Panel	Boeing
233N7508-9	Recorder/Service Interphone Panel	Boeing
233T2222-31	Two Crew Control Panel	Boeing
233T2222-67	Two Crew Control Panel	Boeing
233T2222-73	Two Crew Control Panel	Boeing
233T2222-74	Two Crew Control Panel	Boeing
233T3210-1022	Emergency Lights Panel	Boeing
233T3210-1024	Emergency Lights Panel	Boeing
233T3210-1025	Emergency Lights Panel	Boeing
233T3210-1027	Emergency Lights Panel	Boeing
233T3210-1028	Emergency Lights Panel	Boeing
233T3210-1029	Emergency Lights Panel	Boeing
233T3210-1030	Emergency Lights Panel	Boeing
233T3210-1031	Emergency Lights Panel	Boeing
233T3210-1033	Emergency Lights Panel	Boeing
233T3210-1037	Emergency Lights Panel	Boeing
233T3210-1038	Emergency Lights Panel	Boeing
233T3210-1300	Emergency Lights Panel	Boeing
233T3210-1301	Emergency Lights Panel	Boeing
233T3210-1302	Emergency Lights Panel	Boeing
233T3210-1303	Emergency Lights Panel	Boeing
233T3210-1304	Emergency Lights Panel	Boeing
233T3210-1305	Emergency Lights Panel	Boeing
233T3210-1306	Emergency Lights Panel	Boeing
233T3210-1307	Emergency Lights Panel	Boeing
233T3210-1308	Emergency Lights Panel	Boeing
233T3210-1309	Emergency Lights Panel	Boeing
233T3210-1310	Emergency Lights Panel	Boeing
233T3210-22	Emergency Lights Panel	Boeing
233T3210-24	Emergency Lights Panel	Boeing
233T3210-25	Emergency Lights Panel	Boeing
233T3210-27	Emergency Lights Panel	Boeing

Repair_Capability_List_Excel

233T3210-28	Emergency Lights Panel	Boeing
233T3210-29	Emergency Lights Panel	Boeing
233T3210-30	Emergency Lights Panel	Boeing
233T3210-300	Emergency Lights Panel	Boeing
233T3210-301	Emergency Lights Panel	Boeing
233T3210-302	Emergency Lights Panel	Boeing
233T3210-303	Emergency Lights Panel	Boeing
233T3210-304	Emergency Lights Panel	Boeing
233T3210-305	Emergency Lights Panel	Boeing
233T3210-306	Emergency Lights Panel	Boeing
233T3210-307	Emergency Lights Panel	Boeing
233T3210-31	Emergency Lights Panel	Boeing
233T3210-33	Emergency Lights Panel	Boeing
233T3210-35	Emergency Lights Panel	Boeing
233T3210-37	Emergency Lights Panel	Boeing
233T3210-38	Emergency Lights Panel	Boeing
233T3216-1	Passenger Sign Control Panel	Boeing
233T3216-10	Passenger Sign Control Panel	Boeing
233T3217-300	Lighting Anti-Collision and Landing Panel	Boeing
233T3217-301	Lighting Anti-Collision and Landing Panel	Boeing
233T3217-302	Lighting Anti-Collision and Landing Panel	Boeing
233T3217-304	Lighting Anti-Collision and Landing Panel	Boeing
233T3217-36	Lighting Anti-Collision and Landing Panel	Boeing
233T3217-38	Lighting Anti-Collision and Landing Panel	Boeing
233T3217-40	Lighting Anti-Collision and Landing Panel	Boeing
233T3217-41	Lighting Anti-Collision and Landing Panel	Boeing
233T3217-42	Lighting Anti-Collision and Landing Panel	Boeing
233T3217-44	Lighting Anti-Collision and Landing Panel	Boeing
233T3217-46	Lighting Anti-Collision and Landing Panel	Boeing
233T3217-48	Lighting Anti-Collision and Landing Panel	Boeing
233T3230-1	Panel assy	Boeing
233T3230-14	Panel assy	Boeing
233T3230-15	Panel assy	Boeing
233T3230-18	Panel assy	Boeing
233T3230-20	Panel assy	Boeing
233T3230-22	Panel assy	Boeing
233T3230-23	Panel assy	Boeing
233T3230-24	Panel assy	Boeing
233T3230-300	Panel assy	Boeing
233T3230-301	Panel assy	Boeing
233T3230-302	Panel assy	Boeing
233T3230-303	Panel assy	Boeing
233T3230-304	Panel assy	Boeing
233T3230-305	Panel assy	Boeing
233T3230-32	Panel assy	Boeing
233T3230-36	Panel assy	Boeing
233T3230-39	Panel assy	Boeing
233T3230-40	Panel assy	Boeing
233T3230-46	Panel assy	Boeing
233T3230-48	Panel assy	Boeing
233T3230-51	Panel assy	Boeing
233T3230-53	Panel assy	Boeing
233T3230-8	Panel assy	Boeing
233T3231-1	Fuel Heat Panel	Boeing
233T3231-5	Fuel Heat Panel	Boeing
233T3231-6	Fuel Heat Panel	Boeing
233T3232-1	APU Control Panel	Boeing
233T3232-11	APU Control Panel	Boeing

Repair_Capability_List_Excel

233T3232-12	APU Control Panel	Boeing
233T3232-13	APU Control Panel	Boeing
233T3232-300	APU Control Panel	Boeing
233T3232-301	APU Control Panel	Boeing
233T3232-5	APU Control Panel	Boeing
233T3232-6	APU Control Panel	Boeing
233T3232-9	APU Control Panel	Boeing
233T3233-10	Miscellaneous Annunciator Panel	Boeing
233T3233-11	Miscellaneous Annunciator Panel	Boeing
233T3233-12	Miscellaneous Annunciator Panel	Boeing
233T3233-14	Miscellaneous Annunciator Panel	Boeing
233T3233-16	Miscellaneous Annunciator Panel	Boeing
233T3233-18	Miscellaneous Annunciator Panel	Boeing
233T3233-19	Miscellaneous Annunciator Panel	Boeing
233T3233-20	Miscellaneous Annunciator Panel	Boeing
233T3233-21	Miscellaneous Annunciator Panel	Boeing
233T3233-22	Miscellaneous Annunciator Panel	Boeing
233T3233-23	Miscellaneous Annunciator Panel	Boeing
233T3233-24	Miscellaneous Annunciator Panel	Boeing
233T3233-26	Miscellaneous Annunciator Panel	Boeing
233T3233-29	Miscellaneous Annunciator Panel	Boeing
233T3233-30	Miscellaneous Annunciator Panel	Boeing
233T3233-31	Miscellaneous Annunciator Panel	Boeing
233T3233-33	Miscellaneous Annunciator Panel	Boeing
233T3233-34	Miscellaneous Annunciator Panel	Boeing
233T3233-35	Miscellaneous Annunciator Panel	Boeing
233T3233-38	Miscellaneous Annunciator Panel	Boeing
233T3233-40	Miscellaneous Annunciator Panel	Boeing
233T3233-42	Miscellaneous Annunciator Panel	Boeing
233T3233-43	Miscellaneous Annunciator Panel	Boeing
233T3233-45	Miscellaneous Annunciator Panel	Boeing
233T3233-48	Miscellaneous Annunciator Panel	Boeing
233T3233-51	Miscellaneous Annunciator Panel	Boeing
233T3233-54	Miscellaneous Annunciator Panel	Boeing
233T3234-1	Hydraulic System Control Panel	Boeing
233T3234-10	Hydraulic System Control Panel	Boeing
233T3234-12	Hydraulic System Control Panel	Boeing
233T3234-14	Hydraulic System Control Panel	Boeing
233T3234-15	Hydraulic System Control Panel	Boeing
233T3234-16	Hydraulic System Control Panel	Boeing
233T3234-17	Hydraulic System Control Panel	Boeing
233T3234-19	Hydraulic System Control Panel	Boeing
233T3234-22	Hydraulic System Control Panel	Boeing
233T3234-25	Hydraulic System Control Panel	Boeing
233T3234-26	Hydraulic System Control Panel	Boeing
233T3234-29	Hydraulic System Control Panel	Boeing
233T3234-30	Hydraulic System Control Panel	Boeing
233T3234-300	Hydraulic System Control Panel	Boeing
233T3234-301	Hydraulic System Control Panel	Boeing
233T3234-302	Hydraulic System Control Panel	Boeing
233T3234-303	Hydraulic System Control Panel	Boeing
233T3234-304	Hydraulic System Control Panel	Boeing
233T3234-305	Hydraulic System Control Panel	Boeing
233T3234-31	Hydraulic System Control Panel	Boeing
233T3234-33	Hydraulic System Control Panel	Boeing
233T3234-35	Hydraulic System Control Panel	Boeing
233T3234-36	Hydraulic System Control Panel	Boeing
233T3234-38	Hydraulic System Control Panel	Boeing

Repair_Capability_List_Excel

233T3234-39	Hydraulic System Control Panel	Boeing
233T3234-42	Hydraulic System Control Panel	Boeing
233T3234-43	Hydraulic System Control Panel	Boeing
233T3234-44	Hydraulic System Control Panel	Boeing
233T3234-5	Hydraulic System Control Panel	Boeing
233T3234-7	Hydraulic System Control Panel	Boeing
233T3234-8	Hydraulic System Control Panel	Boeing
233T3235-10	Fuel Management Panel	Boeing
233T3235-1005	Fuel Management Panel	Boeing
233T3235-1007	Fuel Management Panel	Boeing
233T3235-1010	Fuel Management Panel	Boeing
233T3235-1011	Fuel Management Panel	Boeing
233T3235-1012	Fuel Management Panel	Boeing
233T3235-1013	Fuel Management Panel	Boeing
233T3235-1015	Fuel Management Panel	Boeing
233T3235-11	Fuel Management Panel	Boeing
233T3235-12	Fuel Management Panel	Boeing
233T3235-13	Fuel Management Panel	Boeing
233T3235-1300	Fuel Management Panel	Boeing
233T3235-1301	Fuel Management Panel	Boeing
233T3235-1302	Fuel Management Panel	Boeing
233T3235-1303	Fuel Management Panel	Boeing
233T3235-1304	Fuel Management Panel	Boeing
233T3235-1305	Fuel Management Panel	Boeing
233T3235-1306	Fuel Management Panel	Boeing
233T3235-1307	Fuel Management Panel	Boeing
233T3235-15	Fuel Management Panel	Boeing
233T3235-17	Fuel Management Panel	Boeing
233T3235-20	Fuel Management Panel	Boeing
233T3235-21	Fuel Management Panel	Boeing
233T3235-23	Fuel Management Panel	Boeing
233T3235-300	Fuel Management Panel	Boeing
233T3235-301	Fuel Management Panel	Boeing
233T3235-5	Fuel Management Panel	Boeing
233T3235-7	Fuel Management Panel	Boeing
233T3236-10	Temperature Control Panel	Boeing
233T3236-1001	Temperature Control Panel	Boeing
233T3236-1005	Temperature Control Panel	Boeing
233T3236-1010	Temperature Control Panel	Boeing
233T3236-1016	Temperature Control Panel	Boeing
233T3236-1020	Temperature Control Panel	Boeing
233T3236-1022	Temperature Control Panel	Boeing
233T3236-1024	Temperature Control Panel	Boeing
233T3236-1026	Temperature Control Panel	Boeing
233T3236-1028	Temperature Control Panel	Boeing
233T3236-1029	Temperature Control Panel	Boeing
233T3236-1031	Temperature Control Panel	Boeing
233T3236-1032	Temperature Control Panel	Boeing
233T3236-1033	Temperature Control Panel	Boeing
233T3236-1035	Temperature Control Panel	Boeing
233T3236-1037	Temperature Control Panel	Boeing
233T3236-1038	Temperature Control Panel	Boeing
233T3236-1039	Temperature Control Panel	Boeing
233T3236-1040	Temperature Control Panel	Boeing
233T3236-1042	Temperature Control Panel	Boeing
233T3236-1044	Temperature Control Panel	Boeing
233T3236-1047	Temperature Control Panel	Boeing
233T3236-1050	Temperature Control Panel	Boeing

Repair_Capability_List_Excel

233T3236-66	Temperature Control Panel	Boeing
233T3236-69	Temperature Control Panel	Boeing
233T3236-70	Temperature Control Panel	Boeing
233T3236-71	Temperature Control Panel	Boeing
233T3236-73	Temperature Control Panel	Boeing
233T3236-77	Temperature Control Panel	Boeing
233T3236-79	Temperature Control Panel	Boeing
233T3236-84	Temperature Control Panel	Boeing
233T3236-85	Temperature Control Panel	Boeing
233T3236-87	Temperature Control Panel	Boeing
233T3236-91	Temperature Control Panel	Boeing
233T3236-93	Temperature Control Panel	Boeing
233T3236-94	Temperature Control Panel	Boeing
233T3236-95	Temperature Control Panel	Boeing
233T3236-96	Temperature Control Panel	Boeing
233T3236-97	Temperature Control Panel	Boeing
233T3237-10	Bleed Air Control Panel	Boeing
233T3237-13	Bleed Air Control Panel	Boeing
233T3237-14	Bleed Air Control Panel	Boeing
233T3237-15	Bleed Air Control Panel	Boeing
233T3237-16	Bleed Air Control Panel	Boeing
233T3237-17	Bleed Air Control Panel	Boeing
233T3237-18	Bleed Air Control Panel	Boeing
233T3237-19	Bleed Air Control Panel	Boeing
233T3237-21	Bleed Air Control Panel	Boeing
233T3237-24	Bleed Air Control Panel	Boeing
233T3237-25	Bleed Air Control Panel	Boeing
233T3237-27	Bleed Air Control Panel	Boeing
233T3237-30	Bleed Air Control Panel	Boeing
233T3237-5	Bleed Air Control Panel	Boeing
233T3237-7	Bleed Air Control Panel	Boeing
233T3240-1	Alt.Thrust Reserfer Hydraulics Panel	Boeing
233T3240-14	Alt.Thrust Reserfer Hydraulics Panel	Boeing
233T3241-1	Wing and Engine Anti-Ice Control Panel	Boeing
233T3241-10	Wing and Engine Anti-Ice Control Panel	Boeing
233T3241-11	Wing and Engine Anti-Ice Control Panel	Boeing
233T3241-12	Wing and Engine Anti-Ice Control Panel	Boeing
233T3241-13	Wing and Engine Anti-Ice Control Panel	Boeing
233T3241-14	Wing and Engine Anti-Ice Control Panel	Boeing
233T3241-15	Wing and Engine Anti-Ice Control Panel	Boeing
233T3241-17	Wing and Engine Anti-Ice Control Panel	Boeing
233T3241-20	Wing and Engine Anti-Ice Control Panel	Boeing
233T3241-22	Wing and Engine Anti-Ice Control Panel	Boeing
233T3241-25	Wing and Engine Anti-Ice Control Panel	Boeing
233T3241-28	Wing and Engine Anti-Ice Control Panel	Boeing
233T3241-300	Wing and Engine Anti-Ice Control Panel	Boeing
233T3241-301	Wing and Engine Anti-Ice Control Panel	Boeing
233T3241-302	Wing and Engine Anti-Ice Control Panel	Boeing
233T3241-303	Wing and Engine Anti-Ice Control Panel	Boeing
233T3241-304	Wing and Engine Anti-Ice Control Panel	Boeing
233T3241-305	Wing and Engine Anti-Ice Control Panel	Boeing
233T3241-39	Wing and Engine Anti-Ice Control Panel	Boeing
233T3241-41	Wing and Engine Anti-Ice Control Panel	Boeing
233T3241-42	Wing and Engine Anti-Ice Control Panel	Boeing
233T3241-43	Wing and Engine Anti-Ice Control Panel	Boeing
233T3241-44	Wing and Engine Anti-Ice Control Panel	Boeing
233T3241-45	Wing and Engine Anti-Ice Control Panel	Boeing
233T3241-46	Wing and Engine Anti-Ice Control Panel	Boeing

Repair_Capability_List_Excel

233T3241-47	Wing and Engine Anti-Ice Control Panel	Boeing
233T3241-48	Wing and Engine Anti-Ice Control Panel	Boeing
233T3241-49	Wing and Engine Anti-Ice Control Panel	Boeing
233T3241-5	Wing and Engine Anti-Ice Control Panel	Boeing
233T3241-50	Wing and Engine Anti-Ice Control Panel	Boeing
233T3241-53	Wing and Engine Anti-Ice Control Panel	Boeing
233T3241-54	Wing and Engine Anti-Ice Control Panel	Boeing
233T3241-56	Wing and Engine Anti-Ice Control Panel	Boeing
233T3241-58	Wing and Engine Anti-Ice Control Panel	Boeing
233T3241-60	Wing and Engine Anti-Ice Control Panel	Boeing
233T3241-62	Wing and Engine Anti-Ice Control Panel	Boeing
233T3241-63	Wing and Engine Anti-Ice Control Panel	Boeing
233T3241-64	Wing and Engine Anti-Ice Control Panel	Boeing
233T3241-67	Wing and Engine Anti-Ice Control Panel	Boeing
233T3241-68	Wing and Engine Anti-Ice Control Panel	Boeing
233T3241-69	Wing and Engine Anti-Ice Control Panel	Boeing
233T3241-70	Wing and Engine Anti-Ice Control Panel	Boeing
233T3241-8	Wing and Engine Anti-Ice Control Panel	Boeing
233T3242-1	EEC Control Panel	Boeing
233T3242-10	EEC Control Panel	Boeing
233T3242-11	EEC Control Panel	Boeing
233T3242-13	EEC Control Panel	Boeing
233T3242-15	EEC Control Panel	Boeing
233T3242-4	EEC Control Panel	Boeing
233T3242-6	EEC Control Panel	Boeing
233T3242-7	EEC Control Panel	Boeing
233T3242-8	EEC Control Panel	Boeing
233T3243-11	Fuel Jettison Panel	Boeing
233T3243-12	Fuel Jettison Panel	Boeing
233T3243-14	Fuel Jettison Panel	Boeing
233T3243-15	Fuel Jettison Panel	Boeing
233T3243-300	Fuel Jettison Panel	Boeing
233T3243-301	Fuel Jettison Panel	Boeing
233T3243-6	Fuel Jettison Panel	Boeing
233T3243-8	Fuel Jettison Panel	Boeing
233T3243-9	Fuel Jettison Panel	Boeing
233T3244-1	Engine Ignition and Start Control Panel	Boeing
233T3244-10	Engine Ignition and Start Control Panel	Boeing
233T3244-11	Engine Ignition and Start Control Panel	Boeing
233T3244-13	Engine Ignition and Start Control Panel	Boeing
233T3244-17	Engine Ignition and Start Control Panel	Boeing
233T3244-18	Engine Ignition and Start Control Panel	Boeing
233T3244-19	Engine Ignition and Start Control Panel	Boeing
233T3244-21	Engine Ignition and Start Control Panel	Boeing
233T3244-23	Engine Ignition and Start Control Panel	Boeing
233T3244-25	Engine Ignition and Start Control Panel	Boeing
233T3244-300	Engine Ignition and Start Control Panel	Boeing
233T3244-301	Engine Ignition and Start Control Panel	Boeing
233T3244-302	Engine Ignition and Start Control Panel	Boeing
233T3244-303	Engine Ignition and Start Control Panel	Boeing
233T3244-304	Engine Ignition and Start Control Panel	Boeing
233T3244-5	Engine Ignition and Start Control Panel	Boeing
233T3244-6	Engine Ignition and Start Control Panel	Boeing
233T3244-7	Engine Ignition and Start Control Panel	Boeing
233T3244-8	Engine Ignition and Start Control Panel	Boeing
233T3244-9	Engine Ignition and Start Control Panel	Boeing
233T4238-1	Engine Vibration Panel	Boeing
233T4239-10	Miscellaneous Test Panel	Boeing

Repair_Capability_List_Excel

233T4239-12	Miscellaneous Test Panel	Boeing
233T4239-13	Miscellaneous Test Panel	Boeing
233T4239-16	Miscellaneous Test Panel	Boeing
233T4239-18	Miscellaneous Test Panel	Boeing
233T4239-19	Miscellaneous Test Panel	Boeing
233T4239-24	Miscellaneous Test Panel	Boeing
233T4239-25	Miscellaneous Test Panel	Boeing
233T4239-26	Miscellaneous Test Panel	Boeing
233T4239-28	Miscellaneous Test Panel	Boeing
233T4240-1	Miscellaneous Systems Control Panel	Boeing
233T4240-10	Miscellaneous Systems Control Panel	Boeing
233T4240-12	Miscellaneous Systems Control Panel	Boeing
233T4240-13	Miscellaneous Systems Control Panel	Boeing
233T4240-15	Miscellaneous Systems Control Panel	Boeing
233T4240-6	Miscellaneous Systems Control Panel	Boeing
233T4240-7	Miscellaneous Systems Control Panel	Boeing
233T4244-1	Supernumerary Lighting Control Panel	Boeing
233T4244-10	Supernumerary Lighting Control Panel	Boeing
233T4244-12	Supernumerary Lighting Control Panel	Boeing
233T4244-300	Supernumerary Lighting Control Panel	Boeing
233T4244-301	Supernumerary Lighting Control Panel	Boeing
233T4244-302	Supernumerary Lighting Control Panel	Boeing
233T4244-303	Supernumerary Lighting Control Panel	Boeing
233T4244-5	Supernumerary Lighting Control Panel	Boeing
233T4244-8	Supernumerary Lighting Control Panel	Boeing
233T4246-1	Squib Test Panel	Boeing
233T4246-11	Squib Test Panel	Boeing
233T4246-18	Squib Test Panel	Boeing
233T4246-4	Squib Test Panel	Boeing
233T4246-7	Squib Test Panel	Boeing
233T4246-8	Squib Test Panel	Boeing
233T4248-10	Reserve Brakes and Steering Panel	Boeing
233T4248-12	Reserve Brakes and Steering Panel	Boeing
233T4248-13	Reserve Brakes and Steering Panel	Boeing
233T4248-14	Reserve Brakes and Steering Panel	Boeing
233T4248-15	Reserve Brakes and Steering Panel	Boeing
233T4248-5	Reserve Brakes and Steering Panel	Boeing
233T4248-7	Reserve Brakes and Steering Panel	Boeing
233T4248-9	Reserve Brakes and Steering Panel	Boeing
233T4249-1	Alt.Thrust Reverser Hyd. Test Panel	Boeing
233T4259-1	Thrust Reserver Test Panel	Boeing
233T6201-14	Aileron Rudder Trim Panel	Boeing
233T6201-19	Aileron Rudder Trim Panel	Boeing
233T6201-21	Aileron Rudder Trim Panel	Boeing
233T6201-22	Aileron Rudder Trim Panel	Boeing
233T6201-25	Aileron Rudder Trim Panel	Boeing
233T6201-301	Aileron Rudder Trim Panel	Boeing
233T6201-323	Aileron Rudder Trim Panel	Boeing
233T6201-324	Aileron Rudder Trim Panel	Boeing
233T6209-1	Panel assy	Boeing
233T6209-302	Panel assy	Boeing
233T7212-1	Panel assy	Boeing
233T7212-300	Panel assy	Boeing
233T7212-6	Panel assy	Boeing
233T7212-7	Panel assy	Boeing
23400-3	Elevator Booster Control Unit	Menasco Aerospace
23400-3B	Elevator Booster Control Unit	Menasco Aerospace
23400-5	Elevator Booster Control Unit	Menasco Aerospace

Repair_Capability_List_Excel

23400-7	Elevator Booster Control Unit	Menasco Aerospace
2340356-3	Dual Heat Exchanger	Honeywell
2340358-1	Condenser and Mixer	Honeywell
2340400-1	Hight Pressure Water Separator	Honeywell
2340402-1	Heat Exchanger Reheater	Honeywell
2340404-1	Condonser Heat Exchanger	Honeywell
2340406-1	Water Extractor	Honeywell
2341178-1	Bleed Air Precooler	Honeywell
2341178-2	Bleed Air Precooler	Honeywell
23438-1	Harness assy	Menasco Aerospace
23438-3	Harness assy	Menasco Aerospace
23438-5	Harness assy	Menasco Aerospace
23438-7	Harness assy	Menasco Aerospace
23442-1	Harness assy	Menasco Aerospace
23-455	Roll Trim Control Switch	SAMM
2346-011-8	Pneumatic Supply Pressure Indicator	Thales Avionics
234625	Valve	Meggitt Avionics
234A0101	Air Filter	Liebherr Aerospace
234TS05Y01	Eng 1 Fire Shut-Off Control Panel	ECE
2350-0030-4	Actuator	Circle Seal Control
2350-0030-5	Actuator	Circle Seal Control
2350-0073	Actuator	Circle Seal Control
2350-0074	Actuator	Circle Seal Control
2350-0075	Actuator	Circle Seal Control
2350-0082	Actuator	Circle Seal Control
23510-1	Flap Actuator	Menasco Aerospace
23510-3	Flap Actuator	Menasco Aerospace
23510-5	Mechanical Actuator	Menasco Aerospace
23511-3	Flap Actuator	Menasco Aerospace
23511-5	Mechanical Actuator	Menasco Aerospace
23520-1	Flap Actuator	Menasco Aerospace
23520-3	Flap Actuator	Menasco Aerospace
23520-5	Mechanical Actuator	Menasco Aerospace
23521-3	Flap Actuator	Menasco Aerospace
23521-5	Mechanical Actuator	Menasco Aerospace
23530-3	Flap Actuator	Menasco Aerospace
23530-5	Mechanical Actuator	Menasco Aerospace
2353-1	Ni-Cad Battery	Saft
23531-3	Flap Actuator	Menasco Aerospace
23531-5	Mechanical Actuator	Menasco Aerospace
235TS05Y03	Eng 1 Fire Shut-Off Control Panel	ECE
236TS05Y01	Eng 2 Fire Shut-Off Control Panel	ECE
23700-1	MLG Damper	Menasco Aerospace
23700-3	MLG Damper	Menasco Aerospace
23700-5	MLG Damper	Menasco Aerospace
23700-7	MLG Damper	Menasco Aerospace
2376-2	Ni-Cad Battery	Saft
237BC101-1	Battery Charger	Acme Electric
237BC101-2	Battery Charger	Acme Electric
237TS05Y03	Eng 2 Fire Shut-Off Control Panel	ECE
238D1015-507	Pressure Transducer	Eaton
238D1024-501	Differential Pressure Switch	Rohr
238D1024-509	Differential Pressure Switch	Rohr
238D1025-507	Differential Pressure Switch	Rohr
238TS05Y01	APU Fire Shut-Off Control Panel	ECE
239TS05Y02	APU Fire Shut-Off Control Panel	ECE
239TS05Y03	APU Fire Shut-Off Control Panel	ECE
23E59-2	Shut-Off Valve assy	Grimes Aerospace

Repair_Capability_List_Excel

23E59-3	Shut-Off Valve assy	Grimes Aerospace
23E59-4	Shut-Off Valve assy	Grimes Aerospace
23E59-5	Shut-Off Valve assy	Grimes Aerospace
23E59-6	Shut-Off Valve assy	Grimes Aerospace
23E59-7	Shut-Off Valve assy	Grimes Aerospace
240085	Motor Actuated Valve	Whittaker
240545	Parking Brake Modular	Whittaker
240695-1	Motor Actuated Valve	Whittaker
240695-2	Motor Actuated Valve	Whittaker
240705-1	Motor Operated Rotary Selector Valve	Whittaker
240705-2	Motor Operated Rotary Selector Valve	Whittaker
240863	Hydraulic Motor	Vickers
240RA01	Current Detector	ECE
24127	Static Probe	Thales Avionics
2-414	Power Supply	Crane Eldec
24200-14B-43-A1	Indicator	Pioneer
24200-78A-43-A1	Indicator	Pioneer
24200-78A-44-A1	Indicator	Pioneer
242082-3	Solenoid Valve assy	Intertechnique
242082-4	Solenoid Valve assy	Intertechnique
242113-1	Shut-Off Valve	Intertechnique
242113-2	Shut-Off Valve	Intertechnique
242114-1	Shut-Off Valve	Intertechnique
242114-2	Shut-Off Valve	Intertechnique
242114-3	Shut-Off Valve	Intertechnique
242452	Valve	Tavco Inc
24250-400-2	Valve	Aeroquip
244-02534	Fire Detection Cable assy	Edison
244-046-34	Fire Detection Cable assy	Edison
244EAP	Engage & Trim Indicator	Smiths Industries
2450-1	Actuator	General Design Inc
2-463-03	Switch	Crane Eldec
2-463-04	Switch	Crane Eldec
2-463-05	Switch	Crane Eldec
2-463-2	Switch	Crane Eldec
2465T100-1	Flap Actuator	Telair International
246700-1001	Rudder Actuator	Parker Hannifin
246700-1003	Rudder Actuator	Parker Hannifin
2473T100-1	Trailing Edge Flap Actuator	Telair International
2474T100-1	Slat Drive Unit	Telair International
2475T100-1	Slat Drive Unit	Telair International
248387	Control Indicator	Sperry Flight
248541	Indicator	Weston Aerospace
248794	Indicator	Weston Aerospace
24E17-3	Shut-Off Valve	Grimes Aerospace
24E507009G01	Water Heater	BF Goodrich
24E507009G02	Water Heater	BF Goodrich
24E507009G03	Water Heater	BF Goodrich
24E507040G	Heater	Goodrich
24E507040G01	Heater	Goodrich
24E507040G02	Heater	Goodrich
24E507040G03	Heater	Goodrich
24E507040G04	Heater	Goodrich
24E507040G05	Heater	Goodrich
2503851	Control Indicator	Sperry Flight
2504560-1	Motor	Honeywell
2504687	Control Indicator	Sperry Flight
25-0918-21C	Light assy	Grimes Aerospace

Repair_Capability_List_Excel

250EAP	Engage & Trim Indicator	Smiths Industries
250N2004-1002	Control Rod	Boeing
250N2004-1003	Control Rod	Boeing
250N2004-101	Control Rod	Boeing
250N2004-103	Control Rod	Boeing
250N2004-104	Control Rod	Boeing
250N2004-105	Control Rod	Boeing
250N2004-107	Control Rod	Boeing
250N2004-108	Control Rod	Boeing
250N2004-109	Control Rod	Boeing
250N2004-110	Control Rod	Boeing
250N2004-1101	Control Rod	Boeing
250N2004-1103	Control Rod	Boeing
250N2004-1104	Control Rod	Boeing
250N2004-1106	Control Rod	Boeing
250N2004-1107	Control Rod	Boeing
250N2004-1108	Control Rod	Boeing
250N2004-1110	Control Rod	Boeing
250N2004-1112	Control Rod	Boeing
250N2004-1113	Control Rod	Boeing
250N2004-1115	Control Rod	Boeing
250N2004-1116	Control Rod	Boeing
250N2004-1117	Control Rod	Boeing
250N2004-1118	Control Rod	Boeing
250N2004-1119	Control Rod	Boeing
250N2004-112	Control Rod	Boeing
250N2004-1120	Control Rod	Boeing
250N2004-1121	Control Rod	Boeing
250N2004-1122	Control Rod	Boeing
250N2004-1123	Control Rod	Boeing
250N2004-113	Control Rod	Boeing
250N2004-114	Control Rod	Boeing
250N2004-1201	Control Rod	Boeing
250N2004-1202	Control Rod	Boeing
250N2004-1205	Control Rod	Boeing
250N2004-1206	Control Rod	Boeing
250N2004-1207	Control Rod	Boeing
250N2004-1208	Control Rod	Boeing
250N2004-1209	Control Rod	Boeing
250N2004-1801	Control Rod	Boeing
250N2004-1802	Control Rod	Boeing
250N2004-201	Control Rod	Boeing
250N2004-202	Control Rod	Boeing
250N2004-205	Control Rod	Boeing
250N2004-206	Control Rod	Boeing
250N2004-207	Control Rod	Boeing
250N2004-208	Control Rod	Boeing
250N2004-209	Control Rod	Boeing
250N2004-210	Control Rod	Boeing
250N2004-211	Control Rod	Boeing
250N2004-214	Control Rod	Boeing
250N2004-215	Control Rod	Boeing
250N2004-217	Control Rod	Boeing
250N2004-218	Control Rod	Boeing
250N2004-219	Control Rod	Boeing
250N2004-220	Control Rod	Boeing
250N2004-221	Control Rod	Boeing
250N2004-222	Control Rod	Boeing

Repair_Capability_List_Excel

250N2004-301	Control Rod	Boeing
250N2004-302	Control Rod	Boeing
250N2004-303	Control Rod	Boeing
250N2004-304	Control Rod	Boeing
250N2004-305	Control Rod	Boeing
250N2004-311	Control Rod	Boeing
250N2004-312	Control Rod	Boeing
250N2004-313	Control Rod	Boeing
250N2004-314	Control Rod	Boeing
250N2004-315	Control Rod	Boeing
250N2004-318	Control Rod	Boeing
250N2004-320	Control Rod	Boeing
250N2004-321	Control Rod	Boeing
250N2004-323	Control Rod	Boeing
250N2004-324	Control Rod	Boeing
250N2004-325	Control Rod	Boeing
250N2004-326	Control Rod	Boeing
250N2004-327	Control Rod	Boeing
250N2004-328	Control Rod	Boeing
250N2004-329	Control Rod	Boeing
250N2004-330	Control Rod	Boeing
250N2004-331	Control Rod	Boeing
250N2004-332	Control Rod	Boeing
250N2004-333	Control Rod	Boeing
250N2004-334	Control Rod	Boeing
250N2004-335	Control Rod	Boeing
250N2004-336	Control Rod	Boeing
250N2004-602	Control Rod	Boeing
250N2004-606	Control Rod	Boeing
250N2004-607	Control Rod	Boeing
250N2004-608	Control Rod	Boeing
250N2004-702	Control Rod	Boeing
250N2004-703	Control Rod	Boeing
250N2004-704	Control Rod	Boeing
250N2004-705	Control Rod	Boeing
250N2004-802	Control Rod	Boeing
250T1003-2	Landing Gear Brake Met.Valve Module	Boeing
250T1003-3	Landing Gear Brake Met.Valve Module	Boeing
250T1003-4	Landing Gear Brake Met.Valve Module	Boeing
250T1003-5	Landing Gear Brake Met.Valve Module	Boeing
2510112-05-01	Electrically Operated Pilot Seat	EADS Sogerma
2510112-05-03	Electrically Operated Pilot Seat	EADS Sogerma
2510112-05-04	Electrically Operated Pilot Seat	EADS Sogerma
2510112-24-01	Electrically Operated Pilot Seat	EADS Sogerma
2510112-25-04	Electrically Operated Pilot Seat	EADS Sogerma
2510113-04-11	Electrically Operated Copilot Seat	EADS Sogerma
2510113-05-01	Electrically Operated Copilot Seat	EADS Sogerma
2510113-05-03	Electrically Operated Copilot Seat	EADS Sogerma
2510113-05-04	Electrically Operated Copilot Seat	EADS Sogerma
2510114-01-01	Third Occupant Seat	EADS Sogerma
2510114-01-05	Third Occupant Seat	EADS Sogerma
2510114-01-06	Third Occupant Seat	EADS Sogerma
2510144-04-01	Electrical Pilot Seat	EADS Sogerma
2510144-04-02	Electrical Pilot Seat	EADS Sogerma
2510144-04-03	Electrical Pilot Seat	EADS Sogerma
2510144-04-04	Electrical Pilot Seat	EADS Sogerma
2510144-23-01	Mechanical Pilot Seat	EADS Sogerma
2510144-23-02	Mechanical Pilot Seat	EADS Sogerma

Repair_Capability_List_Excel

2510144-34-01	Electrical Pilot Seat	EADS Sogerma
2510144-43-01	Mechanical Pilot Seat	EADS Sogerma
2510144-43-02	Mechanical Pilot Seat	EADS Sogerma
2510144-44-01	Electrical Pilot Seat	EADS Sogerma
2510144-44-02	Electrical Pilot Seat	EADS Sogerma
2510144-44-03	Electrical Pilot Seat	EADS Sogerma
2510144-54-01	Electrical Pilot Seat	EADS Sogerma
2510144-54-02	Electrical Pilot Seat	EADS Sogerma
2510144-54-03	Electrical Pilot Seat	EADS Sogerma
2510145-04-01	Electrical Copilot Seat	EADS Sogerma
2510145-04-02	Electrical Copilot Seat	EADS Sogerma
2510145-04-03	Electrical Copilot Seat	EADS Sogerma
2510145-04-04	Electrical Copilot Seat	EADS Sogerma
2510145-23-01	Mechanical Copilot Seat	EADS Sogerma
2510145-23-02	Mechanical Copilot Seat	EADS Sogerma
2510145-43-01	Mechanical Copilot Seat	EADS Sogerma
2510145-43-02	Mechanical Copilot Seat	EADS Sogerma
2510145-44-01	Electrical Copilot Seat	EADS Sogerma
2510145-44-02	Electrical Copilot Seat	EADS Sogerma
2510145-44-03	Electrical Copilot Seat	EADS Sogerma
2510154-00-00	4th Occupant Seat	EADS Sogerma
2510154-01-00	4th Occupant Seat	EADS Sogerma
25130	Fan	Hamilton Sundstrand
25130-1	Vaneaxial Fan	Hamilton Sundstrand
2514-1D	Transmitter	Hamilton Standard
25-1430-11	Lens assy	Airsigna GmbH
25-1430-9	Lens assy	Airsigna GmbH
25-1456-13	Lens assy	Airsigna GmbH
25147A-3B	Transducer	Conrac Corporation
25-1560690-111	Light	Lockheed
2518000-4	Door Actuator	Parker Hannifin
251A1120-1	Aileron Tab Control Rod	Boeing
251A2160-2	Aileron Power Control Unit	Boeing
251A3440-1	Rudder Control Torque Tube	Boeing
251N2040-2	Valve assy	Boeing
251N2051-10	Stabilizer Trim Actuator	Boeing
251N2051-2	Stabilizer Trim Actuator	Boeing
251N2051-3	Stabilizer Trim Actuator	Boeing
251N2051-4	Stabilizer Trim Actuator	Boeing
251N2051-7	Stabilizer Trim Actuator	Boeing
251N2051-8	Stabilizer Trim Actuator	Boeing
251N2051-9	Stabilizer Trim Actuator	Boeing
251N2080-1	Rod assy	Boeing
251N2080-2	Rod assy	Boeing
251N2080-3	Rod assy	Boeing
251N2082-1	Rod assy	Boeing
251N2082-2	Rod assy	Boeing
251N2656-1	Rod assy	Boeing
251N2656-2	Rod assy	Boeing
251N2660-1	Rod assy	Boeing
251N2662-1	Rod assy	Boeing
251N2662-2	Rod assy	Boeing
251N2662-8	Rod assy	Boeing
251N2777-1	Rod assy	Boeing
251N2777-2	Rod assy	Boeing
251N2777-8	Rod assy	Boeing
251N3018-2	Valve assy	Boeing
251N3018-3	Valve assy	Boeing

Repair_Capability_List_Excel

251N3018-4	Valve assy	Boeing
251N4008-15	Gimbal Transmission assy	Boeing
251N4008-16	Gimbal Transmission assy	Boeing
251N4008-17	Gimbal Transmission assy	Boeing
251N4008-18	Gimbal Transmission assy	Boeing
251N4008-25	Gimbal Transmission assy	Boeing
251N4008-26	Gimbal Transmission assy	Boeing
251N4009-15	Gimbal Transmission assy	Boeing
251N4009-16	Gimbal Transmission assy	Boeing
251N4009-17	Gimbal Transmission assy	Boeing
251N4009-18	Gimbal Transmission assy	Boeing
251N4009-23	Gimbal Transmission assy	Boeing
251N4009-24	Gimbal Transmission assy	Boeing
251N4010-10	Gimbal Transmission assy	Boeing
251N4010-15	Gimbal Transmission assy	Boeing
251N4010-16	Gimbal Transmission assy	Boeing
251N4010-7	Gimbal Transmission assy	Boeing
251N4010-8	Gimbal Transmission assy	Boeing
251N4010-9	Gimbal Transmission assy	Boeing
251N4011-15	Gimbal Transmission assy	Boeing
251N4011-16	Gimbal Transmission assy	Boeing
251N4011-17	Gimbal Transmission assy	Boeing
251N4011-18	Gimbal Transmission assy	Boeing
251N4011-23	Gimbal Transmission assy	Boeing
251N4011-24	Gimbal Transmission assy	Boeing
251N4011-31	Gimbal Transmission assy	Boeing
251N4022-24	Transmission assy	Curtiss-Wright
251N4022-25	Transmission assy	Curtiss-Wright
251N4022-26	Transmission assy	Curtiss-Wright
251N4022-27	Transmission assy	Curtiss-Wright
251N4022-28	Transmission assy	Curtiss-Wright
251N4022-29	Transmission assy	Curtiss-Wright
251N4022-30	Transmission assy	Curtiss-Wright
251N4022-31	Transmission assy	Curtiss-Wright
251N4022-32	Transmission assy	Curtiss-Wright
251N4022-33	Transmission assy	Curtiss-Wright
251N4022-34	Transmission assy	Curtiss-Wright
251N4022-35	Transmission assy	Curtiss-Wright
251N4050-13	Transmission assy	Curtiss-Wright
251N4050-14	Transmission assy	Curtiss-Wright
251N4050-15	Transmission assy	Curtiss-Wright
251N4050-16	Transmission assy	Curtiss-Wright
251N4050-17	Transmission assy	Curtiss-Wright
251N4050-18	Transmission assy	Curtiss-Wright
251N4050-19	Transmission assy	Curtiss-Wright
251N4050-20	Transmission assy	Curtiss-Wright
251N4050-21	Transmission assy	Curtiss-Wright
251N4050-22	Transmission assy	Curtiss-Wright
251N4050-23	Transmission assy	Curtiss-Wright
251N4050-24	Transmission assy	Curtiss-Wright
251N4050-25	Transmission assy	Curtiss-Wright
251N4050-26	Transmission assy	Curtiss-Wright
251N4050-27	Transmission assy	Curtiss-Wright
251N4050-28	Transmission assy	Curtiss-Wright
251N4050-29	Transmission assy	Curtiss-Wright
251N4050-30	Transmission assy	Curtiss-Wright
251N4050-31	Transmission assy	Curtiss-Wright
251N4050-32	Transmission assy	Curtiss-Wright

Repair_Capability_List_Excel

251N4050-33	Transmission assy	Curtiss-Wright
251N4050-34	Transmission assy	Curtiss-Wright
251N4050-35	Transmission assy	Curtiss-Wright
251N4050-36	Transmission assy	Curtiss-Wright
251N4050-37	Transmission assy	Curtiss-Wright
251N4050-38	Transmission assy	Curtiss-Wright
251N4050-39	Transmission assy	Curtiss-Wright
251N4050-40	Transmission assy	Curtiss-Wright
251N4050-41	Transmission assy	Curtiss-Wright
251N4050-42	Transmission assy	Curtiss-Wright
251N4050-43	Transmission assy	Curtiss-Wright
251N4050-44	Transmission assy	Curtiss-Wright
251N4050-45	Transmission assy	Curtiss-Wright
251N4050-46	Transmission assy	Curtiss-Wright
251N4050-47	Transmission assy	Curtiss-Wright
251N4050-48	Transmission assy	Curtiss-Wright
251N4052-10	PDU Gearbox assy	Boeing
251N4052-11	PDU Gearbox assy	Boeing
251N4052-13	PDU Gearbox assy	Boeing
251N4052-14	PDU Gearbox assy	Boeing
251N4052-15	PDU Gearbox assy	Boeing
251N4052-21	PDU Gearbox assy	Boeing
251N4052-5	PDU Gearbox assy	Boeing
251N4052-6	PDU Gearbox assy	Boeing
251N4052-9	PDU Gearbox assy	Boeing
251N4053-1	U-Joint assy	Curtiss-Wright
251N4053-2	U-Joint assy	Curtiss-Wright
251N4053-3	U-Joint assy	Curtiss-Wright
251N4053-4	U-Joint assy	Curtiss-Wright
251N4080-1	Angle Gearbox assy	Boeing
251N4080-2	Angle Gearbox assy	Boeing
251N4080-3	Angle Gearbox assy	Boeing
251N4092-13	Tee Gearbox assy	Boeing
251N4092-14	Tee Gearbox assy	Boeing
251N4092-17	Tee Gearbox assy	Boeing
251N4092-18	Tee Gearbox assy	Boeing
251N4092-19	Tee Gearbox assy	Boeing
251N4092-20	Tee Gearbox assy	Boeing
251N4092-21	Tee Gearbox assy	Boeing
251N4092-22	Tee Gearbox assy	Boeing
251N4092-23	Tee Gearbox assy	Boeing
251N4092-24	Tee Gearbox assy	Boeing
251N4092-25	Tee Gearbox assy	Boeing
251N4092-26	Tee Gearbox assy	Boeing
251N4101-41	Transmission assy	Boeing
251N4101-42	Transmission assy	Boeing
251N4101-43	Transmission assy	Boeing
251N4101-44	Transmission assy	Boeing
251N4101-45	Transmission assy	Boeing
251N4101-46	Transmission assy	Boeing
251N4101-47	Transmission assy	Boeing
251N4101-48	Transmission assy	Boeing
251N4101-49	Transmission assy	Boeing
251N4101-50	Transmission assy	Boeing
251N4101-51	Transmission assy	Boeing
251N4101-52	Transmission assy	Boeing
251N4101-53	Transmission assy	Boeing
251N4101-54	Transmission assy	Boeing

Repair_Capability_List_Excel

251N4101-55	Transmission assy	Boeing
251N4101-56	Transmission assy	Boeing
251N4101-57	Transmission assy	Boeing
251N4101-58	Transmission assy	Boeing
251N4101-59	Transmission assy	Boeing
251N4101-60	Transmission assy	Boeing
251N4101-61	Transmission assy	Boeing
251N4101-62	Transmission assy	Boeing
251N4101-63	Transmission assy	Boeing
251N4101-64	Transmission assy	Boeing
251N4101-65	Transmission assy	Boeing
251N4101-66	Transmission assy	Boeing
251N4101-67	Transmission assy	Boeing
251N4101-68	Transmission assy	Boeing
251N4101-69	Transmission assy	Boeing
251N4101-70	Transmission assy	Boeing
251N4101-71	Transmission assy	Boeing
251N4101-72	Transmission assy	Boeing
251N4101-73	Transmission assy	Boeing
251N4101-74	Transmission assy	Boeing
251N4101-75	Transmission assy	Boeing
251N4101-76	Transmission assy	Boeing
251N4101-77	Transmission assy	Boeing
251N4101-78	Transmission assy	Boeing
251N4101-79	Transmission assy	Boeing
251N4101-80	Transmission assy	Boeing
251N4101-81	Transmission assy	Boeing
251N4101-82	Transmission assy	Boeing
251N4101-83	Transmission assy	Boeing
251N4101-84	Transmission assy	Boeing
251N4101-85	Transmission assy	Boeing
251N4101-86	Transmission assy	Boeing
251N4101-87	Transmission assy	Boeing
251N4101-88	Transmission assy	Boeing
251N4101-89	Transmission assy	Boeing
251N4101-90	Transmission assy	Boeing
251N4101-91	Transmission assy	Boeing
251N4101-92	Transmission assy	Boeing
251N4101-93	Transmission assy	Boeing
251N4101-94	Transmission assy	Boeing
251N4101-95	Transmission assy	Boeing
251N4101-96	Transmission assy	Boeing
251N4204-1	Tee Gearbox assy	Boeing
251N4204-2	Tee Gearbox assy	Boeing
251N4204-3	Tee Gearbox assy	Boeing
251N4204-4	Tee Gearbox assy	Boeing
251N4204-5	Tee Gearbox assy	Boeing
251N4204-6	Tee Gearbox assy	Boeing
251N4218-1	Tee Gearbox assy	Boeing
251N4218-2	Tee Gearbox assy	Boeing
251N4218-3	Tee Gearbox assy	Boeing
251N4218-4	Tee Gearbox assy	Boeing
251N4218-5	Tee Gearbox assy	Boeing
251N4222-2	Angle Gearbox assy	Boeing
251N4222-3	Angle Gearbox assy	Boeing
251N4222-4	Angle Gearbox assy	Boeing
251N4222-5	Angle Gearbox assy	Boeing
251N4222-6	Angle Gearbox assy	Boeing

Repair_Capability_List_Excel

251N4241-11	Angle Gearbox assy	Boeing
251N4241-12	Angle Gearbox assy	Boeing
251N4241-13	Angle Gearbox assy	Boeing
251N4241-14	Angle Gearbox assy	Boeing
251N4241-15	Angle Gearbox assy	Boeing
251N4241-16	Angle Gearbox assy	Boeing
251N4241-17	Angle Gearbox assy	Boeing
251N4241-18	Angle Gearbox assy	Boeing
251N4241-19	Angle Gearbox assy	Boeing
251N4241-20	Angle Gearbox assy	Boeing
251N4241-21	Angle Gearbox assy	Boeing
251N4241-22	Angle Gearbox assy	Boeing
251N4241-23	Angle Gearbox assy	Boeing
251N4241-24	Angle Gearbox assy	Boeing
251N4241-25	Angle Gearbox assy	Boeing
251N4241-26	Angle Gearbox assy	Boeing
251N5082-5	Angle Gearbox assy	Boeing
251N5082-6	Angle Gearbox assy	Boeing
251N5091-12	Power Drive Unit	Boeing
251N5091-13	Power Drive Unit	Boeing
251N5091-14	Power Drive Unit	Boeing
251T0100-101	Control Rod	Boeing
251T0100-102	Control Rod	Boeing
251T0100-103	Control Rod	Boeing
251T0100-104	Control Rod	Boeing
251T0100-105	Control Rod	Boeing
251T0100-108	Control Rod	Boeing
251T0100-110	Control Rod	Boeing
251T0100-112	Control Rod	Boeing
251T0100-113	Control Rod	Boeing
251T0100-114	Control Rod	Boeing
251T0100-115	Control Rod	Boeing
251T0100-117	Control Rod	Boeing
251T0100-118	Control Rod	Boeing
251T0100-120	Control Rod	Boeing
251T0100-122	Control Rod	Boeing
251T0100-123	Control Rod	Boeing
251T0100-124	Control Rod	Boeing
251T0100-127	Control Rod	Boeing
251T0100-128	Control Rod	Boeing
251T0100-129	Control Rod	Boeing
251T0100-130	Control Rod	Boeing
251T0100-131	Control Rod	Boeing
251T0100-132	Control Rod	Boeing
251T0100-133	Control Rod	Boeing
251T0100-134	Control Rod	Boeing
251T0100-137	Control Rod	Boeing
251T0100-139	Control Rod	Boeing
251T0100-140	Control Rod	Boeing
251T0100-1401	Control Rod	Boeing
251T0100-1402	Control Rod	Boeing
251T0100-1403	Control Rod	Boeing
251T0100-1404	Control Rod	Boeing
251T0100-1405	Control Rod	Boeing
251T0100-1406	Control Rod	Boeing
251T0100-1407	Control Rod	Boeing
251T0100-141	Control Rod	Boeing
251T0100-1417	Control Rod	Boeing

Repair_Capability_List_Excel

251T0100-142	Control Rod	Boeing
251T0100-145	Control Rod	Boeing
251T0100-146	Control Rod	Boeing
251T0100-147	Control Rod	Boeing
251T0100-148	Control Rod	Boeing
251T0100-149	Control Rod	Boeing
251T0100-150	Control Rod	Boeing
251T0100-162	Control Rod	Boeing
251T0100-201	Control Rod	Boeing
251T0100-202	Control Rod	Boeing
251T0100-203	Control Rod	Boeing
251T0100-205	Control Rod	Boeing
251T0100-213	Control Rod	Boeing
251T0100-215	Control Rod	Boeing
251T0100-216	Control Rod	Boeing
251T0100-218	Control Rod	Boeing
251T0100-220	Control Rod	Boeing
251T0100-223	Control Rod	Boeing
251T0100-226	Control Rod	Boeing
251T0100-228	Control Rod	Boeing
251T0100-230	Control Rod	Boeing
251T0100-231	Control Rod	Boeing
251T0100-234	Control Rod	Boeing
251T0100-235	Control Rod	Boeing
251T0100-236	Control Rod	Boeing
251T0100-237	Control Rod	Boeing
251T0100-238	Control Rod	Boeing
251T0100-239	Control Rod	Boeing
251T0100-302	Control Rod	Boeing
251T0100-304	Control Rod	Boeing
251T0100-305	Control Rod	Boeing
251T0100-306	Control Rod	Boeing
251T0100-307	Control Rod	Boeing
251T0100-308	Control Rod	Boeing
251T0100-309	Control Rod	Boeing
251T0100-311	Control Rod	Boeing
251T0100-314	Control Rod	Boeing
251T0100-318	Control Rod	Boeing
251T0100-319	Control Rod	Boeing
251T0100-320	Control Rod	Boeing
251T0100-321	Control Rod	Boeing
251T0100-323	Control Rod	Boeing
251T0100-328	Control Rod	Boeing
251T0100-329	Control Rod	Boeing
251T0100-332	Control Rod	Boeing
251T0100-333	Control Rod	Boeing
251T0100-335	Control Rod	Boeing
251T0100-336	Control Rod	Boeing
251T0100-337	Control Rod	Boeing
251T0100-338	Control Rod	Boeing
251T0100-339	Control Rod	Boeing
251T0100-340	Control Rod	Boeing
251T0100-341	Control Rod	Boeing
251T0100-342	Control Rod	Boeing
251T0100-344	Control Rod	Boeing
251T0100-351	Control Rod	Boeing
251T0100-353	Control Rod	Boeing
251T0100-354	Control Rod	Boeing

Repair_Capability_List_Excel

251T0100-356	Control Rod	Boeing
251T0100-357	Control Rod	Boeing
251T0100-358	Control Rod	Boeing
251T0100-359	Control Rod	Boeing
251T0100-361	Control Rod	Boeing
251T0100-363	Control Rod	Boeing
251T0100-364	Control Rod	Boeing
251T0100-365	Control Rod	Boeing
251T0100-366	Control Rod	Boeing
251T0100-367	Control Rod	Boeing
251T0100-368	Control Rod	Boeing
251T0100-369	Control Rod	Boeing
251T0100-370	Control Rod	Boeing
251T0100-371	Control Rod	Boeing
251T0100-372	Control Rod	Boeing
251T0100-373	Control Rod	Boeing
251T0100-374	Control Rod	Boeing
251T0100-375	Control Rod	Boeing
251T0100-376	Control Rod	Boeing
251T0100-377	Control Rod	Boeing
251T0100-378	Control Rod	Boeing
251T0100-380	Control Rod	Boeing
251T0100-381	Control Rod	Boeing
251T0100-383	Control Rod	Boeing
251T0100-384	Control Rod	Boeing
251T0100-385	Control Rod	Boeing
251T0100-386	Control Rod	Boeing
251T0100-387	Control Rod	Boeing
251T0100-390	Control Rod	Boeing
251T0100-392	Control Rod	Boeing
251T0100-393	Control Rod	Boeing
251T0100-394	Control Rod	Boeing
251T0100-395	Control Rod	Boeing
251T0100-398	Control Rod	Boeing
251T0100-399	Control Rod	Boeing
251T0100-401	Control Rod	Boeing
251T0100-402	Control Rod	Boeing
251T0100-403	Control Rod	Boeing
251T0100-405	Control Rod	Boeing
251T0100-406	Control Rod	Boeing
251T0100-407	Control Rod	Boeing
251T0100-408	Control Rod	Boeing
251T0100-409	Control Rod	Boeing
251T0100-410	Control Rod	Boeing
251T0100-411	Control Rod	Boeing
251T0100-412	Control Rod	Boeing
251T0100-414	Control Rod	Boeing
251T0100-415	Control Rod	Boeing
251T0100-416	Control Rod	Boeing
251T0100-501	Control Rod	Boeing
251T0100-502	Control Rod	Boeing
251T0100-503	Control Rod	Boeing
251T0100-504	Control Rod	Boeing
251T0100-505	Control Rod	Boeing
251T0100-604	Control Rod	Boeing
251T0100-605	Control Rod	Boeing
251T0100-606	Control Rod	Boeing
251T0100-801	Control Rod	Boeing

Repair_Capability_List_Excel

251T0100-802	Control Rod	Boeing
251T1010-10	Inb./Out.Aileron Surface Position Xmtr	Boeing
251T1010-11	Inb./Out.Aileron Surface Position Xmtr	Boeing
251T1010-12	Inb./Out.Aileron Surface Position Xmtr	Boeing
251T1010-13	Inb./Out.Aileron Surface Position Xmtr	Boeing
251T1010-14	Inb./Out.Aileron Surface Position Xmtr	Boeing
251T1010-17	Inb./Out.Aileron Surface Position Xmtr	Boeing
251T1010-18	Inb./Out.Aileron Surface Position Xmtr	Boeing
251T1010-5	Inb./Out.Aileron Surface Position Xmtr	Boeing
251T1010-6	Inb./Out.Aileron Surface Position Xmtr	Boeing
251T1010-7	Inb./Out.Aileron Surface Position Xmtr	Boeing
251T1010-8	Inb./Out.Aileron Surface Position Xmtr	Boeing
251T1010-9	Inb./Out.Aileron Surface Position Xmtr	Boeing
251T1011-11	Inb./Out.Aileron Surface Position Xmtr	Boeing
251T1011-12	Inb./Out.Aileron Surface Position Xmtr	Boeing
251T1011-13	Inb./Out.Aileron Surface Position Xmtr	Boeing
251T1011-14	Inb./Out.Aileron Surface Position Xmtr	Boeing
251T1011-15	Inb./Out.Aileron Surface Position Xmtr	Boeing
251T1011-16	Inb./Out.Aileron Surface Position Xmtr	Boeing
251T1011-5	Inb./Out.Aileron Surface Position Xmtr	Boeing
251T1011-6	Inb./Out.Aileron Surface Position Xmtr	Boeing
251T1011-7	Inb./Out.Aileron Surface Position Xmtr	Boeing
251T1011-8	Inb./Out.Aileron Surface Position Xmtr	Boeing
251T1205-13	Aileron Control Feel Mechanism	Boeing
251T1205-16	Aileron Control Feel Mechanism	Boeing
251T1205-18	Aileron Control Feel Mechanism	Boeing
251T1205-20	Aileron Control Feel Mechanism	Boeing
251T1205-22	Aileron Control Feel Mechanism	Boeing
251T1205-25	Aileron Control Feel Mechanism	Boeing
251T1205-27	Aileron Control Feel Mechanism	Boeing
251T1289-1	Right Aileron Control Output Quadrant	Boeing
251T1300-4	Aileron Control RH Wheel well Quadrant	Boeing
251T1300-5	Aileron Control RH Wheel well Quadrant	Boeing
251T1300-6	Aileron Control RH Wheel well Quadrant	Boeing
251T1300-7	Aileron Control RH Wheel well Quadrant	Boeing
251T1305-10	LH Hand Lateral Central Control Actuator	Boeing
251T1305-11	LH Hand Lateral Central Control Actuator	Boeing
251T1305-12	LH Hand Lateral Central Control Actuator	Boeing
251T1305-13	LH Hand Lateral Central Control Actuator	Boeing
251T1305-14	LH Hand Lateral Central Control Actuator	Boeing
251T1305-15	LH Hand Lateral Central Control Actuator	Boeing
251T1305-9	LH Hand Lateral Central Control Actuator	Boeing
251T1413-11	Left Side Output Quadrant and Support	Boeing
251T1413-12	Left Side Output Quadrant and Support	Boeing
251T1413-13	Left Side Output Quadrant and Support	Boeing
251T1505-2	Aileron Control Quadrant Override	Boeing
251T1505-3	Aileron Control Quadrant Override	Boeing
251T1505-4	Aileron Control Quadrant Override	Boeing
251T1505-5	Aileron Control Quadrant Override	Boeing
251T1505-6	Aileron Control Quadrant Override	Boeing
251T1505-7	Aileron Control Quadrant Override	Boeing
251T1506-10	Lateral Central Ctrl Act.Output Quadrant	Boeing
251T1506-11	Lateral Central Ctrl Act.Output Quadrant	Boeing
251T1506-9	Lateral Central Ctrl Act.Output Quadrant	Boeing
251T1509-1	Aileron Control Components	Boeing
251T1510-5	Right Aileron Control Output Quadrant	Boeing
251T1510-6	Right Aileron Control Output Quadrant	Boeing
251T1510-7	Right Aileron Control Output Quadrant	Boeing

Repair_Capability_List_Excel

251T1512-5	Aileron Control Components	Boeing
251T1597-1	Aileron Control Right Side Torque Shaft	Boeing
251T1597-2	Aileron Control Right Side Torque Shaft	Boeing
251T1597-3	Aileron Control Right Side Torque Shaft	Boeing
251T1602-10	Inb.Aileron Ctrl & Droop Mech. Quadrant	Boeing
251T1602-5	Inb.Aileron Ctrl & Droop Mech. Quadrant	Boeing
251T1602-6	Inb.Aileron Ctrl & Droop Mech. Quadrant	Boeing
251T1602-7	Inb.Aileron Ctrl & Droop Mech. Quadrant	Boeing
251T1602-8	Inb.Aileron Ctrl & Droop Mech. Quadrant	Boeing
251T1602-9	Inb.Aileron Ctrl & Droop Mech. Quadrant	Boeing
251T1603-10	Inb.Aileron Ctrl & Droop Mech. Quadrant	Boeing
251T1603-7	Inb.Aileron Ctrl & Droop Mech. Quadrant	Boeing
251T1603-8	Inb.Aileron Ctrl & Droop Mech. Quadrant	Boeing
251T1603-9	Inb.Aileron Ctrl & Droop Mech. Quadrant	Boeing
251T1644-1	Aileron Control Quadrant Rod	Boeing
251T1644-2	Aileron Control Quadrant Rod	Boeing
251T1646-1	Aileron Control Quadrant Rod	Boeing
251T1646-2	Aileron Control Quadrant Rod	Boeing
251T1710-10	Outboard Aileron Lockout Mechanism	Boeing
251T1710-11	Outboard Aileron Lockout Mechanism	Boeing
251T1710-12	Outboard Aileron Lockout Mechanism	Boeing
251T1710-5	Outboard Aileron Lockout Mechanism	Boeing
251T1710-6	Outboard Aileron Lockout Mechanism	Boeing
251T1710-7	Outboard Aileron Lockout Mechanism	Boeing
251T1710-8	Outboard Aileron Lockout Mechanism	Boeing
251T1710-9	Outboard Aileron Lockout Mechanism	Boeing
251T2010-10	Elevator Controls Position Transmitter	Boeing
251T2010-11	Elevator Controls Position Transmitter	Boeing
251T2010-12	Elevator Controls Position Transmitter	Boeing
251T2010-13	Elevator Controls Position Transmitter	Boeing
251T2010-14	Elevator Controls Position Transmitter	Boeing
251T2010-3	Elevator Controls Position Transmitter	Boeing
251T2010-4	Elevator Controls Position Transmitter	Boeing
251T2010-5	Elevator Controls Position Transmitter	Boeing
251T2010-6	Elevator Controls Position Transmitter	Boeing
251T2010-7	Elevator Controls Position Transmitter	Boeing
251T2010-8	Elevator Controls Position Transmitter	Boeing
251T2010-9	Elevator Controls Position Transmitter	Boeing
251T2210-10	Elevator Control Feel & Centering Unit	Boeing
251T2210-11	Elevator Control Feel & Centering Unit	Boeing
251T2210-12	Elevator Control Feel & Centering Unit	Boeing
251T2210-13	Elevator Control Feel & Centering Unit	Boeing
251T2210-14	Elevator Control Feel & Centering Unit	Boeing
251T2210-15	Elevator Control Feel & Centering Unit	Boeing
251T2210-7	Elevator Control Feel & Centering Unit	Boeing
251T2210-8	Elevator Control Feel & Centering Unit	Boeing
251T2220-1	Elevator Neutral Shift and Override	Boeing
251T2220-3	Elevator Neutral Shift and Override	Boeing
251T2220-4	Elevator Neutral Shift and Override	Boeing
251T2220-5	Elevator Neutral Shift and Override	Boeing
251T2220-7	Elevator Neutral Shift and Override	Boeing
251T2220-8	Elevator Neutral Shift and Override	Boeing
251T2310-10	Elevator Controls LH & RH Aft Quadrant	Boeing
251T2310-11	Elevator Controls LH & RH Aft Quadrant	Boeing
251T2310-12	Elevator Controls LH & RH Aft Quadrant	Boeing
251T2310-9	Elevator Controls LH & RH Aft Quadrant	Boeing
251T2400-5	Elevator Slave Linkage Lost Motion	Boeing
251T2400-6	Elevator Slave Linkage Lost Motion	Boeing

Repair_Capability_List_Excel

251T2400-7	Elevator Slave Linkage Lost Motion	Boeing
251T2400-8	Elevator Slave Linkage Lost Motion	Boeing
251T2430-1	Elevator Control Components	Boeing
251T2430-4	Elevator Control Components	Boeing
251T2431-1	Elevator Control Components	Boeing
251T2431-4	Elevator Control Components	Boeing
251T2600-10	Horiz.Stabilizer Center Elev.Ctrl Linkage	Boeing
251T2600-9	Horiz.Stabilizer Center Elev.Ctrl Linkage	Boeing
251T2651-1	Elevator Control Components	Boeing
251T2651-4	Elevator Control Components	Boeing
251T2652-1	Elevator Control Components	Boeing
251T2652-2	Elevator Control Components	Boeing
251T2652-7	Elevator Control Components	Boeing
251T2652-8	Elevator Control Components	Boeing
251T2663-1	Elevator Control Components	Boeing
251T3010-2	Rudder Control Position Transmitter	Boeing
251T3010-4	Rudder Control Position Transmitter	Boeing
251T3010-6	Rudder Control Position Transmitter	Boeing
251T3010-7	Rudder Control Position Transmitter	Boeing
251T3010-8	Rudder Control Position Transmitter	Boeing
251T3010-9	Rudder Control Position Transmitter	Boeing
251T3200-2	Rudder Control Feel Centering	Boeing
251T3200-3	Rudder Control Feel Centering	Boeing
251T3200-4	Rudder Control Feel Centering	Boeing
251T3200-5	Rudder Control Feel Centering	Boeing
251T3200-6	Rudder Control Feel Centering	Boeing
251T3200-7	Rudder Control Feel Centering	Boeing
251T3200-8	Rudder Control Feel Centering	Boeing
251T3200-9	Rudder Control Feel Centering	Boeing
251T3210-11	Rud.Ctrl Feel & Trim Offset Torque Tube	Boeing
251T3210-12	Rud.Ctrl Feel & Trim Offset Torque Tube	Boeing
251T3210-13	Rud.Ctrl Feel & Trim Offset Torque Tube	Boeing
251T3210-14	Rud.Ctrl Feel & Trim Offset Torque Tube	Boeing
251T3210-15	Rud.Ctrl Feel & Trim Offset Torque Tube	Boeing
251T3210-17	Rud.Ctrl Feel & Trim Offset Torque Tube	Boeing
251T3210-3	Rud.Ctrl Feel & Trim Offset Torque Tube	Boeing
251T3210-4	Rud.Ctrl Feel & Trim Offset Torque Tube	Boeing
251T3210-5	Rud.Ctrl Feel & Trim Offset Torque Tube	Boeing
251T3210-7	Rud.Ctrl Feel & Trim Offset Torque Tube	Boeing
251T3210-8	Rud.Ctrl Feel & Trim Offset Torque Tube	Boeing
251T3210-9	Rud.Ctrl Feel & Trim Offset Torque Tube	Boeing
251T3216-10	Rud. Ctrl Feel Cent.& Trim Instal.Comp.	Boeing
251T3216-3	Rud. Ctrl Feel Cent.& Trim Instal.Comp.	Boeing
251T3216-5	Rud. Ctrl Feel Cent.& Trim Instal.Comp.	Boeing
251T3216-7	Rud. Ctrl Feel Cent.& Trim Instal.Comp.	Boeing
251T3216-8	Rud. Ctrl Feel Cent.& Trim Instal.Comp.	Boeing
251T3216-9	Rud. Ctrl Feel Cent.& Trim Instal.Comp.	Boeing
251T3220-7	Rud. Ctrl Feel Cent.& Trim Instal.Comp.	Boeing
251T3220-8	Rud. Ctrl Feel Cent.& Trim Instal.Comp.	Boeing
251T3238-1	Rud. Ctrl Feel Cent.& Trim Instal.Comp.	Boeing
251T3238-2	Rud. Ctrl Feel Cent.& Trim Instal.Comp.	Boeing
251T3238-3	Rud. Ctrl Feel Cent.& Trim Instal.Comp.	Boeing
251T3238-5	Rud. Ctrl Feel Cent.& Trim Instal.Comp.	Boeing
251T3600-11	Rudder Control Ratio Changer	Boeing
251T3600-5	Rudder Control Ratio Changer	Boeing
251T3624-6	Rudder Control Ratio Changer Load Limiter	Boeing
251T3700-11	Rudder Control Yaw Damper & Servo	Boeing
251T3700-2	Rudder Control Yaw Damper & Servo	Boeing

Repair_Capability_List_Excel

251T3700-4	Rudder Control Yaw Damper & Servo	Boeing
251T3745-1	Rudder Control Yaw Damper Bias Pogo	Boeing
251T4201-3	Stabilizer Trim Quadrant and Crank	Boeing
251T4201-4	Stabilizer Trim Quadrant and Crank	Boeing
251T4310-1	Stabilizer Trim Ballscrew Actuator	Boeing
251T4310-2	Stabilizer Trim Ballscrew Actuator	Boeing
251T4310-3	Stabilizer Trim Ballscrew Actuator	Boeing
251T4310-4	Stabilizer Trim Ballscrew Actuator	Boeing
251T4431-1	Stab. Trim Switch & Xmtr Module Driver	Boeing
251T4431-3	Stab. Trim Switch & Xmtr Module Driver	Boeing
252794	Fluid Swing Check	Crissair Inc.
252794-1	Fluid Swing Check	Crissair Inc.
252CA01C1-02Y1	Three-Pole Contactor	ECE
252T1100-6	Inboard Aileron Installation Components	Boeing
252T1100-7	Inboard Aileron Installation Components	Boeing
252T1154-1	Inboard Aileron Installation Components	Boeing
252T1154-3	Inboard Aileron Installation Components	Boeing
252T1154-6	Inboard Aileron Installation Components	Boeing
252T1200-5	Outboard Aileron Install. Components	Boeing
252T1200-6	Outboard Aileron Install. Components	Boeing
252T1200-7	Outboard Aileron Install. Components	Boeing
252T1200-8	Outboard Aileron Install. Components	Boeing
252T1200-9	Outboard Aileron Installation Components	Boeing
252T1211-1	Outboard Aileron Install. Components	Boeing
252T1301-1	Inboard Spoiler Power Control Actuator	Boeing
252T1301-2	Inboard Spoiler Power Control Actuator	Boeing
252T1301-3	Inboard Spoiler Power Control Actuator	Boeing
252T1401-1	Outboard Spoiler Power Control Actuator	Boeing
252T1401-2	Outboard Spoiler Power Control Actuator	Boeing
252T1401-3	Outboard Spoiler Power Control Actuator	Boeing
252T2100-3	Elevator Actuator Link	Boeing
252T2110-1	Elevator Actuator Input Rod	Boeing
252T2110-3	Elevator Actuator Input Rod	Boeing
252T2110-4	Elevator Actuator Input Rod	Boeing
252T2118-1	Elevator Actuator Bellcrank	Boeing
252T2118-2	Elevator Actuator Bellcrank	Boeing
252T3100-3	Rudder Actuator Link	Boeing
252T3114-1	Rudder Actuator Input Crank	Boeing
252T3114-2	Rudder Actuator Input Crank	Boeing
252T3116-1	Rudder Actuator Center Bellcrank	Boeing
252T3116-5	Rudder Actuator Center Bellcrank	Boeing
252T3116-6	Rudder Actuator Center Bellcrank	Boeing
252UF9R160A	Drive Unit	Goodrich Control Systems
252UF9R160B	Drive Unit	Goodrich Control Systems
2535	Actuator	Grimes Aerospace
2535-3	Actuator	General Design Inc
2535-4	Actuator	General Design Inc
253682	Indicator	Weston Aerospace
253683	Indicator	Weston Aerospace
2537	Valve	Sabre Industries
253732	Control Indicator	Sperry Flight
253884	Surface Position Indicator	Weston Instruments
253CA01C1-02Y1	Three-Pole Contactor	ECE
253CA01F1-02Y1	Three-Pole Contactor	ECE
253T1141-1	Aileron Control Force transducer Drum	Boeing
253T1141-3	Aileron Control Force transducer Drum	Boeing
253T1141-4	Aileron Control Force transducer Drum	Boeing
253T1141-6	Aileron Control Force transducer Drum	Boeing

Repair_Capability_List_Excel

253T1141-7	Aileron Control Force transducer Drum	Boeing
253T1141-8	Aileron Control Force transducer Drum	Boeing
253T1142-2	Aileron Control Load Limiter Drum	Boeing
253T1142-3	Aileron Control Load Limiter Drum	Boeing
253T1142-4	Aileron Control Load Limiter Drum	Boeing
253T1142-5	Aileron Control Load Limiter Drum	Boeing
253T1142-6	Aileron Control Load Limiter Drum	Boeing
253T1200-3	Control Stand Speed Brake Mechanism	Boeing
253T1200-5	Control Stand Speed Brake Mechanism	Boeing
253T2111-19	Aileron & Elevator Ctrl/Wheel & Colum	Boeing
253T2111-20	Aileron & Elevator Ctrl/Wheel & Colum	Boeing
253T2111-21	Aileron & Elevator Ctrl/Wheel & Colum	Boeing
253T2111-22	Aileron & Elevator Ctrl/Wheel & Colum	Boeing
253T2111-23	Aileron & Elevator Ctrl/Wheel & Colum	Boeing
253T2111-24	Aileron & Elevator Ctrl/Wheel & Colum	Boeing
253T2111-25	Aileron & Elevator Ctrl/Wheel & Colum	Boeing
253T2111-26	Aileron & Elevator Ctrl/Wheel & Colum	Boeing
253T2111-27	Aileron & Elevator Ctrl/Wheel & Colum	Boeing
253T2111-28	Aileron & Elevator Ctrl/Wheel & Colum	Boeing
253T2111-29	Aileron & Elevator Ctrl/Wheel & Colum	Boeing
253T2111-30	Aileron & Elevator Ctrl/Wheel & Colum	Boeing
253T2111-31	Aileron & Elevator Ctrl/Wheel & Colum	Boeing
253T2111-32	Aileron & Elevator Ctrl/Wheel & Colum	Boeing
253T2111-33	Aileron & Elevator Ctrl/Wheel & Colum	Boeing
253T2111-34	Aileron & Elevator Ctrl/Wheel & Colum	Boeing
253T2111-35	Aileron & Elevator Ctrl/Wheel & Colum	Boeing
253T2111-36	Aileron & Elevator Ctrl/Wheel & Colum	Boeing
253T2111-37	Aileron & Elevator Ctrl/Wheel & Colum	Boeing
253T2111-38	Aileron & Elevator Ctrl/Wheel & Colum	Boeing
253T2111-39	Aileron & Elevator Ctrl/Wheel & Colum	Boeing
253T2111-40	Aileron & Elevator Ctrl/Wheel & Colum	Boeing
253T2111-41	Aileron & Elevator Ctrl/Wheel & Colum	Boeing
253T2111-42	Aileron & Elevator Ctrl/Wheel & Colum	Boeing
253T2111-51	Aileron & Elevator Ctrl/Wheel & Colum	Boeing
253T2111-52	Aileron & Elevator Ctrl/Wheel & Colum	Boeing
253T2111-53	Aileron & Elevator Ctrl/Wheel & Colum	Boeing
253T2111-54	Aileron & Elevator Ctrl/Wheel & Colum	Boeing
253T2127-10	Elevator Control Torque Tube	Boeing
253T2127-11	Elevator Control Torque Tube	Boeing
253T2127-12	Elevator Control Torque Tube	Boeing
253T2127-13	Elevator Control Torque Tube	Boeing
253T2127-14	Elevator Control Torque Tube	Boeing
253T2127-15	Elevator Control Torque Tube	Boeing
253T2127-16	Elevator Control Torque Tube	Boeing
253T2127-17	Elevator Control Torque Tube	Boeing
253T2127-18	Elevator Control Torque Tube	Boeing
253T2127-19	Elevator Control Torque Tube	Boeing
253T2127-5	Elevator Control Torque Tube	Boeing
253T2127-6	Elevator Control Torque Tube	Boeing
253T2127-7	Elevator Control Torque Tube	Boeing
253T2127-8	Elevator Control Torque Tube	Boeing
253T2127-9	Elevator Control Torque Tube	Boeing
253T2144-11	Stabilizer Cutoff Switch	Boeing
253T2144-12	Stabilizer Cutoff Switch	Boeing
253T2144-15	Stabilizer Cutoff Switch	Boeing
253T2144-16	Stabilizer Cutoff Switch	Boeing
253T2144-24	Stabilizer Cutoff Switch	Boeing
253T2144-25	Stabilizer Cutoff Switch	Boeing

Repair_Capability_List_Excel

253T2144-26	Stabilizer Cutoff Switch	Boeing
253T2144-27	Stabilizer Cutoff Switch	Boeing
253T2144-7	Stabilizer Cutoff Switch	Boeing
253T2144-8	Stabilizer Cutoff Switch	Boeing
253T2211-4	Elevator Control Components	Boeing
253T2211-5	Elevator Control Components	Boeing
253T2211-6	Elevator Control Components	Boeing
253T2211-7	Elevator Control Components	Boeing
253T2214-3	Elevator Control Components	Boeing
253T2214-4	Elevator Control Components	Boeing
253T3100-11	Rudder Control Pedal /Crank	Boeing
253T3100-7	Rudder Control Pedal /Crank	Boeing
253T3100-8	Rudder Control Pedal /Crank	Boeing
253T3119-1	Rudder Control Components	Boeing
253T3119-2	Rudder Control Components	Boeing
253T3119-5	Rudder Control Components	Boeing
253T3211-1	Rudder Control Jackshaft	Boeing
253T3211-2	Rudder Control Jackshaft	Boeing
253T3211-3	Rudder Control Jackshaft	Boeing
253T3211-4	Rudder Control Jackshaft	Boeing
253T3524-3	Main Landing Gear Brake Quadrant	Boeing
253T3524-4	Main Landing Gear Brake Quadrant	Boeing
253T3524-5	Main Landing Gear Brake Quadrant	Boeing
253T3524-6	Main Landing Gear Brake Quadrant	Boeing
253T3526-1	Main Landing Gear Brake Quadrant	Boeing
253T3526-2	Main Landing Gear Brake Quadrant	Boeing
253T3616-2	Rudder Control Components	Boeing
253T3616-3	Rudder Control Components	Boeing
253T5425-1	Control Stand Stabilizer Trim Lever	Boeing
253T5611-5	Speed Brake Lever Install.Components	Boeing
253T5616-1	Speed Brake Lever Install.Components	Boeing
253T5623-1	Speed Brake Lever	Boeing
253T5623-2	Speed Brake Lever	Boeing
253T5710-1	Control Stand Flap Control Lever	Boeing
253T5723-2	Control Stand Flap Pos.Sensor Gearbox	Boeing
253T5800-13	Control Stand Thrust Lever	Boeing
253T5800-15	Control Stand Thrust Lever	Boeing
253T5800-17	Control Stand Thrust Lever	Boeing
253T5800-19	Control Stand Thrust Lever	Boeing
253T5800-21	Control Stand Thrust Lever	Boeing
253T5800-23	Control Stand Thrust Lever	Boeing
253T5800-25	Control Stand Thrust Lever	Boeing
253T5800-27	Control Stand Thrust Lever	Boeing
253T5800-29	Control Stand Thrust Lever	Boeing
253T5800-31	Control Stand Thrust Lever	Boeing
253T5800-33	Control Stand Thrust Lever	Boeing
253T5800-35	Control Stand Thrust Lever	Boeing
253T5800-37	Control Stand Thrust Lever	Boeing
253T5800-39	Control Stand Thrust Lever	Boeing
253T5800-9	Control Stand Thrust Lever	Boeing
253T7114-1	Autothrottle Gearbox assy	Boeing
253T7114-3	Autothrottle Gearbox assy	Boeing
2-541501-1	Hydraulic Snubber	Dowty Aerospace
2-541501-1A	Hydraulic Snubber	Dowty Aerospace
2-541501-2	Hydraulic Snubber	Dowty Aerospace
2-541501-2A	Hydraulic Snubber	Dowty Aerospace
2-541501-3	Hydraulic Snubber	Dowty Aerospace
254A1141-1	Autothrottle Brake	Boeing

Repair_Capability_List_Excel

254A1141-2	Autothrottle Brake	Boeing
254A1147-1	Control Stand Autothrottle Gearbox	Boeing
254A1150-1	Autothrottle Switchpack	Boeing
254A1150-2	Autothrottle Switchpack	Boeing
254A1240-1	Control Stand Thrust Lever	Boeing
254A1240-2	Control Stand Thrust Lever	Boeing
254N1185-14	Autothrottle Microswitch Pack ay	Boeing
254N1185-19	Autothrottle Microswitch Pack ay	Boeing
254N1185-3	Autothrottle Microswitch Pack ay	Boeing
254N1185-5	Autothrottle Microswitch Pack ay	Boeing
254N1185-7	Autothrottle Microswitch Pack ay	Boeing
254N1185-9	Autothrottle Microswitch Pack ay	Boeing
2550A010100	Valve assy	Liebherr Aerospace
25530562-01	Thermostat Relay	Hamilton Sundstrand
25530562-02	Temperature Control Box	Hamilton Sundstrand
255SP162	Headset	Elno
25600-5001	Valve	Sterer
25604	Control Cable	Aero Controlex
25615C32D26A3	Dual Autosyn Indicator	Bendix
2566A-21	AOA Sensor	Ametek
2566A-23	AOA Sensor	Ametek
2566A25	AOA Transducer	Conrac
2566A-25	AOA Sensor	Ametek
2566A27	AOA Transducer	Conrac
2566A-27	AOA Sensor	Ametek
2566A-30	AOA Sensor	Ametek
2566A-40S	AOA Sensor	Ametek
2568A13	Transmitter	Conrac Corporation
2568F	MODE SEL PANEL	SMITHS
2568K1	MODE SEL PANEL	SMITHS
2568N	MODE SEL PANEL	SMITHS
2568P	MODE SEL PANEL	SMITHS
2568P1	MODE SEL PANEL	SMITHS
2568U	MODE SEL PANEL	SMITHS
256A3110-1	Trailing Edge Flap Transmission	Boeing
256A3110-2	Trailing Edge Flap Transmission	Boeing
256A3110-3	Transmission Gearbox assy	Curtiss-Wright
256A3110-4	Transmission Gearbox assy	Curtiss-Wright
256A3110-5	Transmission Gearbox assy	Curtiss-Wright
256A3110-6	Transmission Gearbox assy	Curtiss-Wright
256A3110-7	Transmission Gearbox assy	Curtiss-Wright
256A3110-8	Transmission Gearbox assy	Curtiss-Wright
256A3151-3	Torque Brake assy	Curtiss-Wright
256A3151-4	Torque Brake assy	Curtiss-Wright
256A3151-5	Torque Brake assy	Curtiss-Wright
256A3151-6	Torque Brake assy	Curtiss-Wright
256A3151-7	Torque Brake assy	Curtiss-Wright
256A3151-8	Torque Brake assy	Curtiss-Wright
256A3210-1	Trailing Edge Flap Transmission	Boeing
256A3210-2	Trailing Edge Flap Transmission	Boeing
256A3210-3	Transmission Gearbox assy	Curtiss-Wright
256A3210-4	Transmission Gearbox assy	Curtiss-Wright
256A3210-5	Transmission Gearbox assy	Curtiss-Wright
256A3210-6	Transmission Gearbox assy	Curtiss-Wright
256A3210-7	Transmission Gearbox assy	Curtiss-Wright
256A3210-8	Transmission Gearbox assy	Curtiss-Wright
256A3310-1	Trailing Edge Flap Transmission	Boeing
256A3310-2	Trailing Edge Flap Transmission	Boeing

Repair_Capability_List_Excel

256A3310-3	Transmission Gearbox assy	Curtiss-Wright
256A3310-4	Transmission Gearbox assy	Curtiss-Wright
256A3310-5	Transmission Gearbox assy	Curtiss-Wright
256A3310-6	Transmission Gearbox assy	Curtiss-Wright
256A3310-7	Transmission Gearbox assy	Curtiss-Wright
256A3310-8	Transmission Gearbox assy	Curtiss-Wright
256A3410-1	Trailing Edge Flap Transmission	Boeing
256A3410-2	Trailing Edge Flap Transmission	Boeing
256A3410-3	Transmission Gearbox assy	Curtiss-Wright
256A3410-4	Transmission Gearbox assy	Curtiss-Wright
256A3410-5	Transmission Gearbox assy	Curtiss-Wright
256A3410-6	Transmission Gearbox assy	Curtiss-Wright
256A3410-7	Transmission Gearbox assy	Curtiss-Wright
256A3410-8	Transmission Gearbox assy	Curtiss-Wright
256A3515-1	Flap Actuation Gearbox assy	Boeing
256A3515-2	Flap Actuation Gearbox assy	Boeing
256A3515-3	Flap Actuation Gearbox assy	Boeing
256A3640-1	Flap Actuation MLG Beam Angle Gearbox	Boeing
256A3640-2	Flap Actuation MLG Beam Angle Gearbox	Boeing
256T1111-8	Leading Edge High Lift Ctrl Install.Comp.	Boeing
256T1111-9	Leading Edge High Lift Ctrl Install.Comp.	Boeing
256T1116-1	Leading Edge High Lift Ctrl Install.Comp.	Boeing
256T1116-10	Leading Edge High Lift Ctrl Install.Comp.	Boeing
256T1116-14	Leading Edge High Lift Ctrl Install.Comp.	Boeing
256T1116-15	Leading Edge High Lift Ctrl Install.Comp.	Boeing
256T1116-16	Leading Edge High Lift Ctrl Install.Comp.	Boeing
256T1116-2	Leading Edge High Lift Ctrl Install.Comp.	Boeing
256T1128-1	Leading Edge High Lift Ctrl Install.Comp.	Boeing
256T1128-2	Leading Edge High Lift Ctrl Install.Comp.	Boeing
256T2110-2	Inb.Leadng Edge Slat Drive Rotary Act.	Boeing
256T2110-3	Inb.Leadng Edge Slat Drive Rotary Act.	Boeing
256T2110-4	Rotary Actuator	Boeing
256T2120-10	Rotary Actuator	Boeing
256T2120-11	Rotary Actuator	Boeing
256T2120-12	Rotary Actuator	Boeing
256T2120-3	Outboard Leading Edge Rotary Actuator	Boeing
256T2120-4	Outboard Leading Edge Rotary Actuator	Boeing
256T2120-5	Outboard Leading Edge Rotary Actuator	Boeing
256T2120-6	Outboard Leading Edge Rotary Actuator	Boeing
256T2120-9	Rotary Actuator	Boeing
256T2210-10	Slat Drive Offset Gearbox	Boeing
256T2210-11	Slat Drive Offset Gearbox	Boeing
256T2210-12	Slat Drive Offset Gearbox	Boeing
256T2210-3	Slat Drive Offset Gearbox	Boeing
256T2210-4	Slat Drive Offset Gearbox	Boeing
256T2210-5	Slat Drive Offset Gearbox	Boeing
256T2210-6	Slat Drive Offset Gearbox	Boeing
256T2210-7	Slat Drive Offset Gearbox	Boeing
256T2210-8	Slat Drive Offset Gearbox	Boeing
256T2220-10	Slat Drive Offset Gearbox	Boeing
256T2220-11	Slat Drive Offset Gearbox	Boeing
256T2220-12	Slat Drive Offset Gearbox	Boeing
256T2220-3	Slat Drive Offset Gearbox	Boeing
256T2220-4	Slat Drive Offset Gearbox	Boeing
256T2220-5	Slat Drive Offset Gearbox	Boeing
256T2220-6	Slat Drive Offset Gearbox	Boeing
256T2220-7	Slat Drive Offset Gearbox	Boeing
256T2220-8	Slat Drive Offset Gearbox	Boeing

Repair_Capability_List_Excel

256T2310-1	Slat Drive Angle Gearbox	Boeing
256T2320-1	Slat Drive Angle Gearbox	Boeing
256T2330-1	Slat Drive Angle Gearbox	Boeing
256T2601-5	Leading Edge High Lift Ctrl Install.Comp.	Boeing
256T2601-7	Leading Edge High Lift Ctrl Install.Comp.	Boeing
256T2610-10	Slat Drive Power Drive Unit	Boeing
256T2610-11	Slat Drive Power Drive Unit	Boeing
256T2610-12	Slat Drive Power Drive Unit	Boeing
256T2610-5	Slat Drive Power Drive Unit	Boeing
256T2610-7	Slat Drive Power Drive Unit	Boeing
256T2610-8	Slat Drive Power Drive Unit	Boeing
256T2610-9	Slat Drive Power Drive Unit	Boeing
256T2611-1	Slat Drive Power Drive Unit Gearbox	Boeing
256T2630-1	Gearbox assy	Boeing
256T2660-3	Inboard Leading Edge Slat Drive Control Unit	Boeing
256T2660-4	Inboard Leading Edge Slat Drive Control Unit	Boeing
256T2660-5	Inboard Leading Edge Slat Drive Control Unit	Boeing
256T2710-10	Slat Drive Power Drive Unit	Boeing
256T2710-11	Slat Drive Power Drive Unit	Boeing
256T2710-5	Slat Drive Power Drive Unit	Boeing
256T2710-6	Slat Drive Power Drive Unit	Boeing
256T2710-7	Slat Drive Power Drive Unit	Boeing
256T2710-8	Slat Drive Power Drive Unit	Boeing
256T2710-9	Slat Drive Power Drive Unit	Boeing
256T2711-1	Slat Drive Power Drive Unit Gearbox	Boeing
256T2760-4	Slat Drive Control Unit	Boeing
256T2760-5	Slat Drive Control Unit	Boeing
256T2760-6	Slat Drive Control Unit	Boeing
256T2800-1	Leading Edge Slat Drive Driveshaft	Boeing
256T2800-10	Leading Edge Slat Drive Driveshaft	Boeing
256T2800-101	Leading Edge Slat Drive Driveshaft	Boeing
256T2800-102	Leading Edge Slat Drive Driveshaft	Boeing
256T2800-104	Leading Edge Slat Drive Driveshaft	Boeing
256T2800-105	Leading Edge Slat Drive Driveshaft	Boeing
256T2800-106	Leading Edge Slat Drive Driveshaft	Boeing
256T2800-107	Leading Edge Slat Drive Driveshaft	Boeing
256T2800-11	Leading Edge Slat Drive Driveshaft	Boeing
256T2800-112	Leading Edge Slat Drive Driveshaft	Boeing
256T2800-113	Leading Edge Slat Drive Driveshaft	Boeing
256T2800-114	Leading Edge Slat Drive Driveshaft	Boeing
256T2800-115	Leading Edge Slat Drive Driveshaft	Boeing
256T2800-117	Leading Edge Slat Drive Driveshaft	Boeing
256T2800-118	Leading Edge Slat Drive Driveshaft	Boeing
256T2800-119	Leading Edge Slat Drive Driveshaft	Boeing
256T2800-12	Leading Edge Slat Drive Driveshaft	Boeing
256T2800-120	Leading Edge Slat Drive Driveshaft	Boeing
256T2800-121	Leading Edge Slat Drive Driveshaft	Boeing
256T2800-122	Leading Edge Slat Drive Driveshaft	Boeing
256T2800-123	Leading Edge Slat Drive Driveshaft	Boeing
256T2800-13	Leading Edge Slat Drive Driveshaft	Boeing
256T2800-14	Leading Edge Slat Drive Driveshaft	Boeing
256T2800-2	Leading Edge Slat Drive Driveshaft	Boeing
256T2800-20	Leading Edge Slat Drive Driveshaft	Boeing
256T2800-21	Leading Edge Slat Drive Driveshaft	Boeing
256T2800-22	Leading Edge Slat Drive Driveshaft	Boeing
256T2800-25	Leading Edge Slat Drive Driveshaft	Boeing
256T2800-29	Leading Edge Slat Drive Driveshaft	Boeing
256T2800-3	Leading Edge Slat Drive Driveshaft	Boeing

Repair_Capability_List_Excel

256T2800-34	Leading Edge Slat Drive Driveshaft	Boeing
256T2800-35	Leading Edge Slat Drive Driveshaft	Boeing
256T2800-36	Leading Edge Slat Drive Driveshaft	Boeing
256T2800-37	Leading Edge Slat Drive Driveshaft	Boeing
256T2800-38	Leading Edge Slat Drive Driveshaft	Boeing
256T2800-39	Leading Edge Slat Drive Driveshaft	Boeing
256T2800-4	Leading Edge Slat Drive Driveshaft	Boeing
256T2800-5	Leading Edge Slat Drive Driveshaft	Boeing
256T2800-6	Leading Edge Slat Drive Driveshaft	Boeing
256T2800-7	Leading Edge Slat Drive Driveshaft	Boeing
256T2800-8	Leading Edge Slat Drive Driveshaft	Boeing
256T2800-9	Leading Edge Slat Drive Driveshaft	Boeing
256T2857-1	Leading Edge High Lift Ctrl Install.Comp.	Boeing
256T3110-10	Flap Drive Power Drive Unit	Boeing
256T3110-11	Flap Drive Power Drive Unit	Boeing
256T3110-12	Flap Drive Power Drive Unit	Boeing
256T3110-13	Flap Drive Power Drive Unit	Boeing
256T3110-16	Flap Drive Power Drive Unit	Boeing
256T3110-17	Flap Drive Power Drive Unit	Boeing
256T3110-2	Flap Drive Power Drive Unit	Boeing
256T3110-3	Flap Drive Power Drive Unit	Boeing
256T3110-4	Flap Drive Power Drive Unit	Boeing
256T3110-5	Flap Drive Power Drive Unit	Boeing
256T3110-6	Flap Drive Power Drive Unit	Boeing
256T3110-7	Flap Drive Power Drive Unit	Boeing
256T3110-8	Flap Drive Power Drive Unit	Boeing
256T3110-9	Flap Drive Power Drive Unit	Boeing
256T3130-4	Flap Drive Power Drive Unit Gearbox	Boeing
256T3130-5	Flap Drive Power Drive Unit Gearbox	Boeing
256T3160-2	Flap Drive Power Control Unit	Boeing
256T3160-4	Flap Drive Power Control Unit	Boeing
256T3160-5	Flap Drive Power Control Unit	Boeing
256T3210-2	Flap Drive Rotary Actuator	Boeing
256T3210-4	Flap Drive Rotary Actuator	Boeing
256T3250-2	Flap Drive Rotary Actuator	Boeing
256T3250-4	Flap Drive Rotary Actuator	Boeing
256T3310-2	Trailing Edge Flap Drive Tee Gearbox	Boeing
256T3340-2	Trailing Edge Flap Drive Angle Gearbox	Boeing
256T3410-2	Trailing Edge Flap Drive Angle Gearbox	Boeing
256T3410-4	Trailing Edge Flap Drive Angle Gearbox	Boeing
256T3430-3	Flap Drive Angle Gearbox & Aileron Mech.	Boeing
256T3430-4	Flap Drive Angle Gearbox & Aileron Mech.	Boeing
256T3510-3	Flap Drive Actuator Input Angle Gearbox	Boeing
256T3510-4	Flap Drive Actuator Input Angle Gearbox	Boeing
256T3540-3	Trailing Edge Flap Drive Tee Gearbox	Boeing
256T3540-4	Trailing Edge Flap Drive Tee Gearbox	Boeing
256T3570-3	Trailing Edge Flap Drive Tee Gearbox	Boeing
256T3570-5	Trailing Edge Flap Drive Tee Gearbox	Boeing
256T3600-5	Trailing Edge Flap Drive Bearing Support	Boeing
256T3600-6	Trailing Edge Flap Drive Bearing Support	Boeing
256T3600-7	Trailing Edge Flap Drive Bearing Support	Boeing
256T3600-8	Trailing Edge Flap Drive Bearing Support	Boeing
256T3700-10	Flap Drive Shaft Assy	Boeing
256T3700-11	Flap Drive Shaft Assy	Boeing
256T3700-12	Flap Drive Shaft Assy	Boeing
256T3700-13	Flap Drive Shaft Assy	Boeing
256T3700-27	Flap Drive Shaft Assy	Boeing
256T3700-3	Flap Drive Shaft Assy	Boeing

Repair_Capability_List_Excel

256T3700-30	Flap Drive Shaft Assy	Boeing
256T3700-31	Flap Drive Shaft Assy	Boeing
256T3700-34	Flap Drive Shaft Assy	Boeing
256T3700-4	Flap Drive Shaft Assy	Boeing
256T3700-5	Flap Drive Shaft Assy	Boeing
256T3700-6	Flap Drive Shaft Assy	Boeing
256T3700-7	Flap Drive Shaft Assy	Boeing
256T3700-8	Flap Drive Shaft Assy	Boeing
256T3700-9	Flap Drive Shaft Assy	Boeing
256T3760-3	Flap Drive Position Xmtr Gearbox & Housing	Boeing
256T3760-4	Flap Drive Position Xmtr Gearbox & Housing	Boeing
256T3760-5	Transmitter Gearbox assy	Boeing
256T3760-6	Transmitter Gearbox assy	Boeing
256T3760-7	Transmitter Gearbox assy	Boeing
256T3760-8	Transmitter Gearbox assy	Boeing
256T3767-1	Flap Drive Position Xmtr Gearbox & Housing	Boeing
256T6110-2	Rotary Actuator	Boeing
256T6110-3	Rotary Actuator	Boeing
256T6310-2	Rotary Actuator	Boeing
256T6310-3	Rotary Actuator	Boeing
256U3120-1	Control assy	Boeing
256U3120-10	Control assy	Boeing
256U3120-2	Control assy	Boeing
256U3120-3	Control assy	Boeing
256U3120-4	Control assy	Boeing
256U3120-5	Control assy	Boeing
256U3120-6	Control assy	Boeing
256U3120-9	Control assy	Boeing
256U3210-1	Trailing Edge Flap Drive	Boeing
256U3210-2	Trailing Edge Flap Drive	Boeing
256U3210-3	Trailing Edge Flap Drive	Boeing
256U3210-4	Trailing Edge Flap Drive	Boeing
256U3210-5	Trailing Edge Flap Drive	Boeing
256U3210-6	Trailing Edge Flap Drive	Boeing
256U3210-7	Trailing Edge Flap Drive	Boeing
256U3210-8	Trailing Edge Flap Drive	Boeing
256U3250-1	Trailing Edge Flap Drive	Boeing
256U3250-10	Trailing Edge Flap Drive	Boeing
256U3250-4	Trailing Edge Flap Drive	Boeing
256U3250-5	Trailing Edge Flap Drive	Boeing
256U3250-6	Trailing Edge Flap Drive	Boeing
256U3250-7	Trailing Edge Flap Drive	Boeing
256U3250-8	Trailing Edge Flap Drive	Boeing
256U3250-9	Trailing Edge Flap Drive	Boeing
25730032-02	Solenoid	Hamilton Sundstrand
2577B	Control Unit	Smiths Industries
257T1102-5	Landing Gear Control Lever Quadrant	Boeing
257T1200-10	Main Landing Gear Door Latch Actuator	Boeing
257T1200-12	Main Landing Gear Door Latch Actuator	Boeing
257T1200-16	Main Landing Gear Door Latch Actuator	Boeing
257T1200-18	Main Landing Gear Door Latch Actuator	Boeing
257T1200-5	Main Landing Gear Door Latch Actuator	Boeing
257T1200-6	Main Landing Gear Door Latch Actuator	Boeing
257T1200-7	Main Landing Gear Door Latch Actuator	Boeing
257T3011-1	MLG Alt.Extend Load Limiter	Boeing
257T3101-1	Landing Gear Extend Lever	Boeing
257T3101-2	Landing Gear Extend Lever	Boeing
257T3102-1	MLG Alternate Extended Quadrant	Boeing

Repair_Capability_List_Excel

257T3103-1	MLG Alternate Extend Control Rod	Boeing
257T3103-2	MLG Alternate Extend Control Rod	Boeing
257T3200-2	NLG Alt. Extend Install.Components	Boeing
257T3212-1	NLG Alt. Extend Install.Components	Boeing
257T3212-4	NLG Alt. Extend Install.Components	Boeing
257T3213-1	NLG Alt. Extend Install.Components	Boeing
257T3214-1	NLG Alt. Extend Install.Components	Boeing
257T3214-4	NLG Alt. Extend Install.Components	Boeing
257T3216-5	NLG Alt. Extend Install.Components	Boeing
257T3216-7	NLG Alt. Extend Install.Components	Boeing
257T3220-1	NLG Alt. Extend Install.Components	Boeing
257T3220-3	NLG Alt. Extend Install.Components	Boeing
257T3220-4	NLG Alt. Extend Install.Components	Boeing
257T3225-1	NLG Alt. Extend Install.Components	Boeing
257T3225-5	NLG Alt. Extend Install.Components	Boeing
257T3225-6	NLG Alt. Extend Install.Components	Boeing
257T3225-8	NLG Alt. Extend Install.Components	Boeing
257T3300-5	Main Gear Door Ground Release	Boeing
257T3300-6	Main Gear Door Ground Release	Boeing
257T3401-1	MLG Alt.Ext.Uplock Rel. Crank Shaft	Boeing
257T3401-2	MLG Alt.Ext.Uplock Rel. Crank Shaft	Boeing
257T3403-3	MLG Alt.Ext.Uplock Rel. Crank Shaft	Boeing
257T3403-4	MLG Alt.Ext.Uplock Rel. Crank Shaft	Boeing
257T3404-3	MLG Alt.Ext.Uplock Rel. Crank Shaft	Boeing
257T3404-4	MLG Alt.Ext.Uplock Rel. Crank Shaft	Boeing
257T3404-5	MLG Alt.Ext.Uplock Rel. Crank Shaft	Boeing
257T3404-6	MLG Alt.Ext.Uplock Rel. Crank Shaft	Boeing
257T3406-3	Main Gear Alt.Ext.Uplock Rel.Lockout	Boeing
257T3406-4	Main Gear Alt.Ext.Uplock Rel.Lockout	Boeing
257T3406-7	Main Gear Alt.Ext.Uplock Rel.Lockout	Boeing
257T3406-8	Main Gear Alt.Ext.Uplock Rel.Lockout	Boeing
257T3407-1	MLG Alt.Ext.Uplock Rel. Safety Vlve	Boeing
257T3407-2	MLG Alt.Ext.Uplock Rel. Safety Vlve	Boeing
257T3409-1	MLG Alt.Ext.Uplock Rel. Crank Shaft	Boeing
257T3413-4	MLG Alt.Ext.Uplock Rel. Crank Shaft	Boeing
257T3414-2	MLG Alt.Ext.Uplock Rel. Crank Shaft	Boeing
257T3415-1	MLG Alt.Ext.Uplock Rel. Crank Shaft	Boeing
257T3415-2	MLG Alt.Ext.Uplock Rel. Crank Shaft	Boeing
257T3416-1	MLG Alt.Ext.Uplock Rel. Crank Shaft	Boeing
257T3416-2	MLG Alt.Ext.Uplock Rel. Crank Shaft	Boeing
257T3416-3	MLG Alt.Ext.Uplock Rel. Crank Shaft	Boeing
257T3417-2	MLG Alt.Ext.Uplock Rel. Crank Shaft	Boeing
257T3418-2	MLG Alt.Ext.Uplock Rel. Crank Shaft	Boeing
257T3419-7	MLG Alt.Ext.Uplock Rel. Crank Shaft	Boeing
257T3429-13	MLG Alt.Ext.Uplock Rel. Crank Shaft	Boeing
257T3429-14	MLG Alt.Ext.Uplock Rel. Crank Shaft	Boeing
257T3431-1	MLG Alt.Ext.Uplock Rel. Crank Shaft	Boeing
257T3431-2	MLG Alt.Ext.Uplock Rel. Crank Shaft	Boeing
257T3440-1	MLG Alt.Ext.Uplock Rel. Crank Shaft	Boeing
257T3501-1	Torque Shaft	Boeing
257T3501-2	Torque Shaft	Boeing
257T3502-2	Nose Gear Alt. Extend Load Limiter	Boeing
257T3502-3	Nose Gear Alt. Extend Load Limiter	Boeing
257T3502-4	Nose Gear Alt. Extend Load Limiter	Boeing
257T3502-5	Nose Gear Alt. Extend Load Limiter	Boeing
257T4100-7	NW Steering Load Lim.& Fwd Quadrant	Boeing
257T4117-1	Nose Wheel Steering Install.Components	Boeing
257T4117-2	Nose Wheel Steering Install.Components	Boeing

Repair_Capability_List_Excel

257T4119-4	Nose Wheel Steering Install.Components	Boeing
257T4120-1	Nose Wheel Steering Gearbox	Boeing
257T4120-2	Nose Wheel Steering Gearbox	Boeing
257T4155-1	Nose Wheel Steering Install.Components	Boeing
257T4158-1	Nose Wheel Steering Install.Components	Boeing
257T4159-1	Nose Wheel Steering Install.Components	Boeing
257T4162-1	Nose Wheel Steering Install.Components	Boeing
257T4162-2	Nose Wheel Steering Install.Components	Boeing
257T4164-1	Nose Wheel Steering Install.Components	Boeing
257T4165-1	Nose Wheel Steering Install.Components	Boeing
257T4169-1	Nose Wheel Steering Install.Components	Boeing
257T4200-10	Nose Wheel Steering Centering Spring	Boeing
257T4200-11	Nose Wheel Steering Centering Spring	Boeing
257T4200-5	Nose Wheel Steering Centering Spring	Boeing
257T4200-7	Nose Wheel Steering Centering Spring	Boeing
257T4311-1	Nose Wheel Steering Spring Cartridge	Boeing
257T4316-2	Nose Wheel Steering Cable Compensat.	Boeing
257T4316-3	Nose Wheel Steering Cable Compensat.	Boeing
257T4318-10	Nose wheel Steering Drum and Lockout	Boeing
257T4318-4	Nose wheel Steering Drum and Lockout	Boeing
257T4318-5	Nose wheel Steering Drum and Lockout	Boeing
257T4318-6	Nose wheel Steering Drum and Lockout	Boeing
257T4318-7	Nose wheel Steering Drum and Lockout	Boeing
257T4318-8	Nose wheel Steering Drum and Lockout	Boeing
257T4318-9	Nose wheel Steering Drum and Lockout	Boeing
258000-1	Fuel Booster Pump	Argo Tech
258000-2	Fuel Booster Pump	Argo Tech
258000-3	Fuel Booster Pump	Argo Tech
258000-5	Fuel Booster Pump	Argo Tech
2580-1	Temperature Controller	Hamilton Standard
2580-1D	Temperature Controller	Hamilton Standard
25811B0SHUNT	Three Pole Contactor	ECE
25811B0SHUNTKL	Three Pole Contactor	ECE
2585703	Slaving Amplifier	Sperry
2585703-2	Slaving Amplifier	Sperry
2586488-1	Compass Amplifier	Honeywell
2586689-1	Autopilot Controller	Honeywell
2586689-10	Autopilot Controller	Honeywell
2586689-101	Autopilot Controller	Honeywell
2586689-11	Autopilot Controller	Honeywell
2586689-111	Autopilot Controller	Honeywell
2586689-201	Autopilot Controller	Honeywell
2586689-211	Autopilot Controller	Honeywell
2586689-3	Autopilot Controller	Honeywell
2586689-31	Autopilot Controller	Honeywell
2587317-355	Compass Indicator	Honeywell
2587317-653	Compass Indicator	Honeywell
2587317-655	Compass Indicator	Honeywell
2587317-656	Compass Indicator	Honeywell
2587317-657	Compass Indicator	Honeywell
2587317-658	Compass Indicator	Honeywell
2587335-11	Vertical Gyro	Honeywell
2587335-111	Vertical Gyro	Honeywell
2587335-112	Vertical Gyro	Honeywell
2587335-113	Vertical Gyro	Honeywell
2587335-12	Vertical Gyro	Honeywell
2587335-121	Vertical Gyro	Honeywell
2587335-122	Vertical Gyro	Honeywell

Repair_Capability_List_Excel

2587335-13	Vertical Gyro	Honeywell
2587335-21	Vertical Gyro	Honeywell
2587335-211	Vertical Gyro	Honeywell
2587335-22	Vertical Gyro	Honeywell
2587335-8	Vertical Gyro	Honeywell
2587335-9	Vertical Gyro	Honeywell
2587781-901	Throttle Rotary Actuator	Honeywell
2587781-903	Throttle Rotary Actuator	Honeywell
2588282-653	Compass Indicator	Honeywell
2588282-655	Compass Indicator	Honeywell
2588282-656	Compass Indicator	Honeywell
2588282-657	Compass Indicator	Honeywell
2588302-2	Directional Gyro	Honeywell
2588302-3	Directional Gyro	Honeywell
2588302-7	Directional Gyro	Honeywell
2588302-8	Directional Gyro	Honeywell
2588369-905	Flight Director Indicator	Honeywell
2588381-903	Gyroscopic Compass	Honeywell
2588696-901	Accelerometer	Honeywell
2588696-902	Accelerometer	Honeywell
2588696-903	Accelerometer	Honeywell
2588696-904	Accelerometer	Honeywell
2588696-905	Accelerometer	Honeywell
2588810-901	Pitch Control Channel	Honeywell
2589201-902	Amplifier	Sperry
2589513	Transducer	Honeywell
258T1100-10	Overhead Pax Door Counterbalance	Boeing
258T1100-11	Overhead Pax Door Counterbalance	Boeing
258T1100-12	Overhead Pax Door Counterbalance	Boeing
258T1100-5	Overhead Pax Door Counterbalance	Boeing
258T1100-6	Overhead Pax Door Counterbalance	Boeing
258T1100-7	Overhead Pax Door Counterbalance	Boeing
258T1100-8	Overhead Pax Door Counterbalance	Boeing
258T1100-9	Overhead Pax Door Counterbalance	Boeing
258T1110-1	Overhead Passenger Door Gearbox	Boeing
258T1110-3	Overhead Passenger Door Gearbox	Boeing
258T1110-4	Overhead Passenger Door Gearbox	Boeing
258T1110-5	Overhead Passenger Door Gearbox	Boeing
258T1110-6	Overhead Passenger Door Gearbox	Boeing
258T1190-3	Entry and Service Door Counterbalance	Boeing
258T1190-4	Entry and Service Door Counterbalance	Boeing
258T1190-5	Entry and Service Door Counterbalance	Boeing
258T1190-6	Entry and Service Door Counterbalance	Boeing
258T1190-7	Entry and Service Door Counterbalance	Boeing
258T1190-8	Entry and Service Door Counterbalance	Boeing
258T3230-1	Entry and Service Door Components	Boeing
258T3230-2	Entry and Service Door Components	Boeing
258T3230-3	Entry and Service Door Components	Boeing
258T3230-4	Entry and Service Door Components	Boeing
258T3401-1	Entry and Service Door Components	Boeing
258T4240-2	Entry and Service Door Components	Boeing
258T4240-3	Entry and Service Door Components	Boeing
258T4240-4	Entry and Service Door Components	Boeing
258T4240-5	Entry and Service Door Components	Boeing
258T5001-1	Large Cargo Door Manual Drive Gearbox	Boeing
258T5004-3	Forward Cargo Door Components	Boeing
258T5005-3	Forward Cargo Door Components	Boeing
258T5005-5	Forward Cargo Door Components	Boeing

Repair_Capability_List_Excel

258T5021-1	Forward Cargo Door Components	Boeing
258U1301-1	Gearbox assy	Boeing
258U1301-2	Gearbox assy	Boeing
258U1301-3	Gearbox assy	Boeing
258U1302-1	Rotary Actuator	Boeing
258U1303-2	Brake assy	Boeing
2590650-901	Mach Trim Coupler	Honeywell
2590653-901	Mach Trim Actuator	Honeywell
2591200-901	Magnetic Compensator	Honeywell
2591201-911	Compass Coupler	Honeywell
2591201-921	Compass Coupler	Honeywell
2591201-922	Compass Coupler	Honeywell
2591202-901	Compass Controller	Honeywell
2591202-902	Compass Controller	Honeywell
2593379-2	Remote Magnetic Compensator	Honeywell
2594366-904	Actuator	Honeywell
2594517-909	Temperature Indicator	Honeywell
2594617-901	SAT Meter	Honeywell
2594617-909	SAT Meter	Honeywell
2594618-901	Indicator	Honeywell
2594620-904	Altitude Indicator	Honeywell
2594620-905	Altitude Indicator	Honeywell
2594620-909	Altitude Indicator	Honeywell
2594620-909AF	Altitude Indicator	Honeywell
2594620-910	Altitude Indicator	Honeywell
2594620-912	Altitude Indicator	Honeywell
2594620-914	Altitude Indicator	Honeywell
2594620-915	Altitude Indicator	Honeywell
2594621-909	Airspeed-Mach Indicator	Honeywell
2594621-916	Airspeed-Mach Indicator	Honeywell
2594621-917	Airspeed-Mach Indicator	Honeywell
2594621-918	Airspeed-Mach Indicator	Honeywell
2594621-919	Airspeed-Mach Indicator	Honeywell
2594621-921	Airspeed-Mach Indicator	Honeywell
2594621-922	Airspeed-Mach Indicator	Honeywell
2594624-902	Horizontal Situation Indicator	Honeywell
2594624-905	Horizontal Situation Indicator	Honeywell
2594624-906	Horizontal Situation Indicator	Honeywell
2594624-908	Horizontal Situation Indicator	Honeywell
2594624-909	Horizontal Situation Indicator	Honeywell
2594624-910	Horizontal Situation Indicator	Honeywell
2594624-911	Horizontal Situation Indicator	Honeywell
2594624-912	Horizontal Situation Indicator	Honeywell
2594625-901	RMI	Honeywell
2594625-902	RMI	Honeywell
2594625-903	RMI	Honeywell
2598D	Lighting Transformer	BIP
25TP19-1	AC Motor	Telair International
2600-03-1	Clock	Smiths Industries
2600-04-1	Clock	Smiths Industries
2600-06-1	Clock	Smiths Industries
2600-08-1	Digital Electrical Clock	Smiths Industries
2600-09-1	Clock	Smiths Industries
260455	Ammeter AC Power Indicator	Ametek
260461	O2 Pressure Indicator	Ametek
260462	Comp & Duct Temp Indicator	Ametek
2604942	Drain Valve	Trans-Cal Industries
2604945	Drain Valve	Trans-Cal Industries

Repair_Capability_List_Excel

2604971	Drain Valve	Trans-Cal Industries
2604972	Drain Valve	Trans-Cal Industries
2605002	Drain Valve	Trans-Cal Industries
2605003	Drain Valve	Trans-Cal Industries
2605004	Drain Valve	Trans-Cal Industries
260638	Indicator	Weston Aerospace
2607219	Brake Fan	Technofan
2607219-1	Brake Fan	Technofan
2607219-11	Brake Fan	Technofan
2607219-2	Brake Fan	Technofan
2607219-21	Brake Fan	Technofan
2607399-1	Brake Cooling Fan	Technofan
2607399-11	Brake Cooling Fan	Technofan
2607399-2	Brake Cooling Fan	Technofan
2607399-21	Brake Cooling Fan	Technofan
2607399-3	Brake Cooling Fan	Technofan
2607734	Sensor	Messier-Bugatti
2611125	Body Fan Axle Kit	Technofan
26130010	Valve	Hamilton Sundstrand
26130011	Valve	Hamilton Sundstrand
26130105	Valve	Hamilton Sundstrand
2621956C00	Manifold	TBV
26230074-01	Valve	Hamilton Sundstrand
2630074	Valve	Hamilton Sundstrand
2630356	Pressure Adapter	Parker Hannifin
2630356-101	Pressure Adapter	Parker Hannifin
2630356-102	Pressure Adapter	Parker Hannifin
2630427	Lever Control Pilot	Parker Hannifin
2630427M1	Level Control Pilot Valve	Parker Hannifin
2630486M1	Fuel Shut-Off Valve	Parker Hannifin
2630486M2	Fuel Shut-Off Valve	Parker Hannifin
2630486M3	Fuel Shut-Off Valve	Parker Hannifin
2630486M4	Fuel Shut-Off Valve	Parker Hannifin
26340061-04	Battery Charger	Hamilton Sundstrand
26340061-06	Battery Charger	Hamilton Sundstrand
26405	Rheostat	Oeco Corporation
2641809	Actuator	Parker Hannifin
26440005-01	Static Inverter	Hamilton Sundstrand
2650-05-1	Electronic Clock	Smiths Industries
2650102	Check Valve	Parker Hannifin
2650102-102	APU Fuel Check Valve	Parker Hannifin
2650102-103	APU Fuel Check Valve	Parker Hannifin
2650169M1	Shut-Off Valve	Parker Hannifin
2650169M2	Shut-Off Valve	Parker Hannifin
2650266	Cap	Parker Hannifin
2650324	Valve	Parker Aerospace
2651-258-1	Drain Valve	Kaiser Aerospace
2651-2581-1	Drain Valve	Kaiser Aerospace
2651-269	Drain Valve	Kaiser Aerospace
2651-269-2	Lavatory Drain Cap assy	Kaiser Aerospace
2651-278-12	Waste System Valve ay	Kaiser
2651-278-13	Waste System Valve ay	Kaiser
2651-278-14	Waste System Valve ay	Kaiser
2651-278-15	Waste System Valve ay	Kaiser
2651-278-16	Waste System Valve ay	Kaiser
2651-278-17	Waste System Valve ay	Kaiser
2651-278-18	Waste System Valve ay	Kaiser
2651-278-19	Waste System Valve ay	Kaiser

Repair_Capability_List_Excel

2651-278-21	Waste System Valve ay	Kaiser
2651-278-22	Waste System Valve ay	Kaiser
2651-278-23	Waste System Valve ay	Kaiser
2651-278-24	Waste System Valve ay	Kaiser
2651-278-7	Waste System Valve ay	Kaiser
2651-278-8	Waste System Valve ay	Kaiser
2651-311-1	Valve Lavatory Drain	Kaiser Aerospace
2651-311-10	Valve Lavatory Drain	Kaiser Aerospace
2651-311-2	Valve Lavatory Drain	Kaiser Aerospace
2651-311-3	Valve Lavatory Drain	Kaiser Aerospace
2651-311-4	Valve Lavatory Drain	Kaiser Aerospace
2651-311-5	Valve Lavatory Drain	Kaiser Aerospace
2651-311-6	Valve Lavatory Drain	Kaiser Aerospace
2651-311-7	Valve Lavatory Drain	Kaiser Aerospace
2651-311-8	Valve Lavatory Drain	Kaiser Aerospace
2651-311-9	Valve Lavatory Drain	Kaiser Aerospace
2651-321	Valve assy	Kaiser Aerospace
265156	Hydraulic Pump	Vickers
26519-1	Igniter Plug	Hamilton Sundstrand
26520407	PCB Switch & Sensor assy	Hamilton Sundstrand
265567	Hydraulic Motor Pump	Vickers
2660461-2	Valve	Parker Hannifin
2660472-1	Accumulator	Parker Hannifin
2660472-2	Accumulator	Parker Hannifin
2660472-3	Accumulator	Parker Hannifin
2660472-4	Accumulator	Parker Hannifin
2660472-5	Accumulator	Parker Hannifin
2660472-6	Accumulator	Parker Hannifin
2660472-7	Accumulator	Parker Hannifin
2660472M1	Accumulator	Parker Hannifin
2660472M2	Accumulator	Parker Hannifin
2660472M3	Accumulator	Parker Hannifin
2660472M4	Accumulator	Parker Hannifin
2660472M5	Accumulator	Parker Hannifin
2660472M6	Accumulator	Parker Hannifin
2660472M7	Accumulator	Parker Hannifin
2660591-1	Valve	Parker Hannifin
2660591-4	Valve	Parker Hannifin
26659-5312	Oil Cooler Flap Actuator	Serk Aviation
26659-6313	Press/Temp Valve	Serk Aviation
2-670001-1	Brake Modular assy	Smiths Aerospace
2670005M2	Valve assy	Parker Hannifin
2670005M21	Valve assy	Parker Hannifin
2670005M4	Valve assy	Parker Hannifin
2670005M5	Valve assy	Parker Hannifin
2670005M6	Valve assy	Parker Hannifin
2670005M7	Valve assy	Parker Hannifin
2670150-5	Manifold	Parker Hannifin
2670282M2	Drain Valve assy	Parker Hannifin
2670288-4	Valve assy	Parker Hannifin
2670288-5	Valve assy	Parker Hannifin
2670288-6	Valve assy	Parker Hannifin
2670288-7	Valve assy	Parker Hannifin
2670288-8	Valve assy	Parker Hannifin
2670288-9	Valve assy	Parker Hannifin
2670296	Nose Gear Sequence Valve	Parker Hannifin
2670296M1	Nose Gear Sequence Valve	Parker Hannifin
2670324	Drain Check Valve	Parker Hannifin

Repair_Capability_List_Excel

2670324-101	Drain Check Valve	Parker Hannifin
2670T100-x	Trailing Edge Flap Actuator	Telair International
2671T100-x	Trailing Edge Flap Actuator	Telair International
2680212	Valve	Parker Aerospace
2680215M3	Spoiler Actuator	Parker Hannifin
2680215M3A	Spoiler Actuator	Parker Hannifin
2680215M4	Spoiler Actuator	Parker Hannifin
2680215M5	Spoiler Actuator	Parker Hannifin
2680215M5B	Spoiler Actuator	Parker Hannifin
2680215M5C	Spoiler Actuator	Parker Hannifin
2682358	Electromech.Actuator	Hamilton Sundstrand
268737	Hydraulic Motorpump	Vickers
2-690029-1	Actuator	Smiths Aerospace
2-690029-10	Actuator	Dowty
2-690029-10L	Actuator	Dowty
2-690029-10M	Actuator	Dowty
2-690029-10MT	Actuator	Dowty
2-690029-11	Actuator	Dowty
2-690029-11M	Actuator	Dowty
2-690029-12M	Actuator	Dowty
2-690029-13	Actuator	Dowty
2-690029-13L	Actuator	Dowty
2-690029-15	Actuator	Dowty
2-690029-16	Actuator	Dowty
2-690029-16M	Actuator	Dowty
2-690029-17	Actuator	Dowty
2-690029-18	Actuator	Smiths Aerospace
2-690029-18LN	Actuator	Dowty
2-690029-1M	Actuator	Dowty
2-690029-2	Actuator	Dowty
2-690029-4	Actuator	Dowty
2-690029-4FGH	Actuator	Dowty
2-690029-4HFJKM	Actuator	Dowty
2-690029-4HJLT	Actuator	Dowty
2-690029-4M	Actuator	Dowty
2-690029-5	Actuator	Dowty
2-690029-5D	Actuator	Dowty
2-690029-5DM	Actuator	Dowty
2-690029-5FHJKL	Actuator	Dowty
2-690029-5FKLR	Actuator	Dowty
2-690029-6	Actuator	Dowty
2-690029-6M	Actuator	Dowty
2-690029-7	Actuator	Dowty
2-690029-7KM	Actuator	Dowty
2-690029-7L	Actuator	Dowty
2-690029-7M	Actuator	Dowty
2-690029-8	Actuator	Dowty
2-690029-8KM	Actuator	Dowty
2-690029-9	Actuator	Dowty
2-690029-9L	Actuator	Dowty
2-690029-9LT	Actuator	Dowty
2-690029-9M	Actuator	Dowty
2690194	Hydraulic Accumulator	Parker Hannifin
2690194M1	Hydraulic Accumulator	Parker Hannifin
2690212	Hydraulic Accumulator	Parker Hannifin
2690212M1	Hydraulic Accumulator	Parker Hannifin
26C1-3C	Electric Motor	Liebherr Aerospace
26V10TT4B01	Position Transmitter	Precilec

Repair_Capability_List_Excel

26V10TTD4B01	Position Transmitter	Precilec
27000-3	Power Control Unit Spoiler	Menasco
27000-5	Power Control Unit Spoiler	Menasco
27000-7	Power Control Unit Spoiler	Menasco
2700187M1	Hydraulic Actuator assy	Parker Hannifin
2700187M1A	Hydraulic Actuator assy	Parker Hannifin
2700187M2	Hydraulic Actuator assy	Parker Hannifin
270-0867-010	Switch	Rockwell Collins
2704202-1	Alternative Current Geared Motor	Honeywell
2704202-2	Alternative Current Geared Motor	Honeywell
2704202-3	Alternative Current Geared Motor	Honeywell
2704202-4	Alternative Current Geared Motor	Honeywell
2704202-5	Alternative Current Geared Motor	Honeywell
2704204-1	Alternative Current Geared Motor	Honeywell
2704204-2	Alternative Current Geared Motor	Honeywell
2704204-3	Alternative Current Geared Motor	Honeywell
2704280-2	Motor Driven Fan	Honeywell
2704286-1	Motor	Honeywell
2704376-1	Direct Current Motor	Honeywell
2704376-2	Direct Current Motor	Honeywell
2704376-3	Direct Current Motor	Honeywell
2704376-5	Direct Current Motor	Honeywell
2704442-3	Direct Current Motor	Honeywell
2704442-4	Direct Current Motor	Honeywell
2704480-1	Starter Motor	Honeywell
2704488-2	Direct Current Motor	Honeywell
2704506-1	Starter Motor	Honeywell
2704506-2	Starter Motor	Honeywell
270VC01Y1	Light Body	ECE
2710540-1	Starter Motor	Honeywell
271100-1	YZ-Double Latch	Telair International
271EAP	Engage & Trim Indicator	Smiths Industries
271N1012-2	Module	Boeing
271N2020-1	Filter Module	Boeing
271N2040-2	Filter assy	Boeing
271N6113-3	MLG Retract Actuator	Boeing
271N6113-4	MLG Retract Actuator	Boeing
271T0001-1	Return Filter Module	Boeing
271T0001-2	Return Filter Module	Boeing
271T0001-3	Return Filter Module	Boeing
271T0042-1	AC Motor Pump Press.& Drain Filter	Boeing
271T0042-2	AC Motor Pump Press.& Drain Filter	Boeing
271T0042-3	AC Motor Pump Press.& Drain Filter	Boeing
271T0042-4	AC Motor Pump Press.& Drain Filter	Boeing
271T0068-1	Eng.Driv. Pump & Air Driv. Pump Press.	Boeing
271T0068-10	Eng.Driv. Pump & Air Driv. Pump Press.	Boeing
271T0068-11	Eng.Driv. Pump & Air Driv. Pump Press.	Boeing
271T0068-12	Eng.Driv. Pump & Air Driv. Pump Press.	Boeing
271T0068-4	Eng.Driv. Pump & Air Driv. Pump Press.	Boeing
271T0068-5	Eng.Driv. Pump & Air Driv. Pump Press.	Boeing
271T0068-6	Eng.Driv. Pump & Air Driv. Pump Press.	Boeing
271T0068-7	Eng.Driv. Pump & Air Driv. Pump Press.	Boeing
271T0068-8	Eng.Driv. Pump & Air Driv. Pump Press.	Boeing
271T0068-9	Eng.Driv. Pump & Air Driv. Pump Press.	Boeing
271T0115-12	Center System Hydraulic Reservoir	Boeing
271T0115-13	Center System Hydraulic Reservoir	Boeing
271T4904-2	Central Ground Service Reservoir Press.	Boeing
271T4904-4	Central Ground Service Reservoir Press.	Boeing

Repair_Capability_List_Excel

271T5212-21	LH & RH System Hydraulic Reservoir	Boeing
271T5212-22	LH & RH System Hydraulic Reservoir	Boeing
271T5212-23	LH & RH System Hydraulic Reservoir	Boeing
271T5212-24	LH & RH System Hydraulic Reservoir	Boeing
271T5212-25	LH & RH System Hydraulic Reservoir	Boeing
271T5212-26	LH & RH System Hydraulic Reservoir	Boeing
271T5212-31	LH & RH System Hydraulic Reservoir	Boeing
271T5212-33	LH & RH System Hydraulic Reservoir	Boeing
271T5212-35	LH & RH System Hydraulic Reservoir	Boeing
271T5212-41	LH & RH System Hydraulic Reservoir	Boeing
271T5212-42	LH & RH System Hydraulic Reservoir	Boeing
271T5212-43	LH & RH System Hydraulic Reservoir	Boeing
271T5212-44	LH & RH System Hydraulic Reservoir	Boeing
271T5212-45	LH & RH System Hydraulic Reservoir	Boeing
271T5212-46	LH & RH System Hydraulic Reservoir	Boeing
271T5212-47	LH & RH System Hydraulic Reservoir	Boeing
271T5212-48	LH & RH System Hydraulic Reservoir	Boeing
271T5212-49	LH & RH System Hydraulic Reservoir	Boeing
271T5212-50	LH & RH System Hydraulic Reservoir	Boeing
27200-5	Power Control Unit Aileron	Menasco
27200-7	Power Control Unit Aileron	Menasco
27261298-01	Windshield Temperature Controller	Hamilton Sundstrand
27261298-02	Windshield Temperature Controller	Hamilton Sundstrand
27261298-03	Windshield Temperature Controller	Hamilton Sundstrand
2730426	Valve assy	Parker Hannifin
2730498M1	Actuator assy	Parker Aerospace
2730498M3	Actuator assy	Parker Aerospace
273-7SN112	Engine Gauge Unit	Edison
2739	Fire Detection Control Unit	Whittaker
2739-01	Fire Detection Control Unit	Whittaker
2739-02	Fire Detection Control Unit	Whittaker
273A1101-1	Nose Landing Gear Retract Actuator	Boeing
273A1201-1	Nose Landing Gear Lock Actuator	Boeing
273A2101-2	MLG Retract Actuator	Boeing
273A2201-1	Main Landing Gear Downlock Actuator	Boeing
273A2501-1	Main Landing Gear Uplock Actuator	Boeing
273N1004-2	NLG Retract Actuator	Boeing
273N1004-3	NLG Retract Actuator	Boeing
273N2004-1	Truck Position Actuator	Boeing
273N2004-2	Truck Position Actuator	Boeing
273N2004-3	Truck Position Actuator	Boeing
273N2004-6	Truck Position Actuator	Boeing
273N2006-1	MLG Retract Actuator	Boeing
273N2006-2	MLG Retract Actuator	Boeing
273N2006-3	MLG Retract Actuator	Boeing
273N2006-4	MLG Retract Actuator	Boeing
273N2006-5	MLG Retract Actuator	Boeing
273N2007-1	Uplock Actuator	Boeing
273N2008-2	MLG Downlock Actuator	Boeing
273N2008-3	MLG Downlock Actuator	Boeing
273N4003-3	Actuator	Boeing
273N4004-2	Actuator	Boeing
273N4005-2	Actuator	Boeing
273N4006-2	Actuator	Boeing
273N4006-3	Actuator	Boeing
273N4034-3	Actuator	Boeing
273N4041-10	Actuator	Boeing
273N4041-17	Actuator	Boeing

Repair_Capability_List_Excel

273N4041-22	Actuator	Boeing
273N4041-6	Actuator	Boeing
273N4171-1	Actuator	Boeing
273N4171-3	Actuator	Boeing
273N4171-4	Actuator	Boeing
273T0073-1	Main Landing Gear Door Actuator	Boeing
273T1100	Actuator	Boeing
273T1100-5	Main Landing Gear Retract Actuator	Boeing
273T1100-6	Main Landing Gear Retract Actuator	Boeing
273T1102	Actuator	Boeing
273T1102-7	Main Landing Gear Retract Actuator	Boeing
273T1102-8	Main Landing Gear Retract Actuator	Boeing
273T1400-3	MLG Oper.Sequence Valve & Cam Box	Boeing
273T1400-4	MLG Oper.Sequence Valve & Cam Box	Boeing
273T1400-7	MLG Oper.Sequence Valve & Cam Box	Boeing
273T1400-8	MLG Oper.Sequence Valve & Cam Box	Boeing
273T1401-1	MLG Oper.Sequence Valve & Cam Box	Boeing
273T1401-2	MLG Oper.Sequence Valve & Cam Box	Boeing
273T1401-3	MLG Oper.Sequence Valve & Cam Box	Boeing
273T1401-4	MLG Oper.Sequence Valve & Cam Box	Boeing
273T4110-4	Nose Landing Gear Retract Actuator	Boeing
273T4110-6	Nose Landing Gear Retract Actuator	Boeing
273T4110-8	MLG Retract Actuator	Boeing
273T4112-3	Nose Landing Gear Retract Actuator	Boeing
273T4112-4	Nose Landing Gear Retract Actuator	Boeing
273T4112-5	MLG Retract Actuator	Boeing
273T4120-2	Nose Gear Lock Actuator	Boeing
273T4121-1	Nose Gear Lock Actuator	Boeing
273T4520-3	Main Landing Gear Door Actuator	Boeing
273T4520-4	Main Landing Gear Door Actuator	Boeing
273T4520-9	Main Landing Gear Door Actuator	Boeing
273T4521-2	Main Landing Gear Door Actuator	Boeing
273T4521-3	Main Landing Gear Door Actuator	Boeing
273T4531-1	Main Gear Door Oper.Sequence Valve	Boeing
273T4551-1	MLG Door Actuator	Boeing
273T4551-2	MLG Door Actuator	Boeing
273T4561-2	Main Landing Gear Door Latch Actuator	Boeing
273T4561-3	Main Landing Gear Door Latch Actuator	Boeing
273T4561-4	Main Landing Gear Door Latch Actuator	Boeing
273T4561-5	Main Landing Gear Door Latch Actuator	Boeing
273T4561-6	Main Landing Gear Door Latch Actuator	Boeing
273T4561-7	Main Landing Gear Door Latch Actuator	Boeing
273T4561-8	Main Landing Gear Door Latch Actuator	Boeing
273T4561-9	Main Landing Gear Door Latch Actuator	Boeing
273T4572-1	MLG Door Arming Lockout Actuator	Boeing
273T6100-10	Main Landing Gear Truck Positioner	Boeing
273T6100-4	Main Landing Gear Truck Positioner	Boeing
273T6100-6	Main Landing Gear Truck Positioner	Boeing
273T6100-8	Main Landing Gear Truck Positioner	Boeing
273T6101-3	Main Landing Gear Truck Positioner	Boeing
273T6101-4	Main Landing Gear Truck Positioner	Boeing
273T6101-5	Main Landing Gear Truck Positioner	Boeing
273T6101-6	Main Landing Gear Truck Positioner	Boeing
273T6101-7	Main Landing Gear Truck Positioner	Boeing
273T6101-8	Main Landing Gear Truck Positioner	Boeing
273T6101-9	Main Landing Gear Truck Positioner	Boeing
273T6200-2	MLG Side Brace Lock Actuator	Boeing
273T6200-4	MLG Side Brace Lock Actuator	Boeing

Repair_Capability_List_Excel

273T6200-6	MLG Side Brace Lock Actuator	Boeing
273T6200-9	Brace Lock Actuator	Boeing
273T6201-1	MLG Side Brace Lock Actuator	Boeing
273T6201-2	MLG Side Brace Lock Actuator	Boeing
273T6201-3	MLG Side Brace Lock Actuator	Boeing
273T6201-4	Brace Lock Actuator	Boeing
273T6300-11	Brace Lock Actuator	Boeing
273T6300-2	MLG Drag Brace Lock Actuator	Boeing
273T6300-3	MLG Drag Brace Lock Actuator	Boeing
273T6300-4	MLG Drag Brace Lock Actuator	Boeing
273T6300-6	MLG Drag Brace Lock Actuator	Boeing
273T6300-7	Brace Lock Actuator	Boeing
273T6300-8	MLG Drag Brace Lock Actuator	Boeing
273T6301-1	MLG Drag Brace Lock Actuator	Boeing
273T6301-2	MLG Drag Brace Lock Actuator	Boeing
273T6301-3	MLG Drag Brace Lock Actuator	Boeing
273T6301-4	MLG Drag Brace Lock Actuator	Boeing
273T6301-5	MLG Drag Brace Lock Actuator	Boeing
273T6301-6	MLG Drag Brace Lock Actuator	Boeing
273T7114-1	Gearbox assy	Boeing
27400-1	Power Control Unit Rudder	Menasco
2740028-1	Rotary Actuator	Honeywell
2740028-2	Rotary Actuator	Honeywell
27400-5	Power Control Unit Rudder	Menasco
2740062-1	Ram Door Actuator	Honeywell
2740062-2	Ram Door Actuator	Honeywell
2740156-1	Rotary Actuator	Honeywell
2740650-1	Actuator assy	Honeywell
2740650-2	Actuator assy	Honeywell
2740650-3	Actuator assy	Honeywell
2740650-4	Actuator assy	Honeywell
2741124-3	Rotary Actuator	Honeywell
2741620-1	Rotary Actuator	Honeywell
27-457	Control Switch	SAMM
2-7457-10	MLG Door Actuator	Smiths Aerospace
2-7457-11	MLG Door Actuator	Smiths Aerospace
2-7457-12	MLG Door Actuator	Smiths Aerospace
2-7457-13	MLG Door Actuator	Smiths Aerospace
2-7457-14	MLG Door Actuator	Smiths Aerospace
2-7457-2	MLG Door Actuator	Smiths Aerospace
2-7457-3	MLG Door Actuator	Smiths Aerospace
2-7457-4	MLG Door Actuator	Smiths Aerospace
2-7457-5	MLG Door Actuator	Smiths Aerospace
2-7457-6	MLG Door Actuator	Smiths Aerospace
2-7457-7	MLG Door Actuator	Smiths Aerospace
2-7457-8	MLG Door Actuator	Smiths Aerospace
2-7457-9	MLG Door Actuator	Smiths Aerospace
2-7460-2	Anti-Skid Shuttle Valve Module	Smiths Aerospace
2-7460-3	Anti-Skid Shuttle Valve Module	Smiths Aerospace
2-7460-4	Anti-Skid Shuttle Valve Module	Smiths Aerospace
2-7460-5	Anti-Skid Shuttle Valve Module	Smiths Aerospace
2-7461-1	Anti-Skid Shuttle Valve Module	Smiths Aerospace
2-7461-3	Anti-Skid Shuttle Valve Module	Smiths Aerospace
2-7462-1	Valve Modual	Smiths Aerospace
2-7462-2	Valve Modual	Smiths Aerospace
2-7462-3	Valve Modual	Smiths Aerospace
2-7462-4	Valve Modual	Smiths Aerospace
2-7462-5	Valve Modual	Smiths Aerospace

Repair_Capability_List_Excel

2-7462-6	Valve Modual	Smiths Aerospace
2-7464-3	NLG Door Actuator assy	Smiths Aerospace
2-7464-4	NLG Door Actuator assy	Smiths Aerospace
2-7464-5	NLG Door Actuator assy	Smiths Aerospace
2-7464-5A	NLG Door Actuator assy	Smiths Aerospace
2-7464-6	NLG Door Actuator assy	Smiths Aerospace
2-7464-6B	NLG Door Actuator assy	Smiths Aerospace
2-7464-6C	NLG Door Actuator assy	Smiths Aerospace
2-7464-7	NLG Door Actuator assy	Smiths Aerospace
2-7464-7A	NLG Door Actuator assy	Smiths Aerospace
274N1003	Brake Valve	Boeing
274N1003-10	Isol. Valve & Alt.Brake Select.Valve	Boeing
274N1003-13	Isol. Valve & Alt.Brake Select.Valve	Boeing
274N1003-4	Isol. Valve & Alt.Brake Select.Valve	Boeing
274N1003-5	Isol. Valve & Alt.Brake Select.Valve	Boeing
274N1003-6	Isol. Valve & Alt.Brake Select.Valve	Boeing
274N1003-7	Isol. Valve & Alt.Brake Select.Valve	Boeing
274N1003-8	Isol. Valve & Alt.Brake Select.Valve	Boeing
274N1028-4	Isol. Valve & Alt.Brake Select.Valve	Boeing
274N1028-5	Isol. Valve & Alt.Brake Select.Valve	Boeing
274N1028-6	Isol. Valve & Alt.Brake Select.Valve	Boeing
274N1051-1	Isol. Valve & Alt.Brake Select.Valve	Boeing
274N1051-2	Isol. Valve & Alt.Brake Select.Valve	Boeing
274N1051-3	Isol. Valve & Alt.Brake Select.Valve	Boeing
274T0005-3	Brake Accumulator Isolation Valve	Boeing
274T0005-5	Brake Accumulator Isolation Valve	Boeing
274T0005-7	Brake Accumulator Isolation Valve	Boeing
274T4570-2	Wheel Brake Actuator	Boeing
274T4620-3	Brake Accumulator Isolation Valve	Boeing
274T4620-5	Brake Accumulator Isolation Valve	Boeing
274T4620-7	Brake Accumulator Isolation Valve	Boeing
274T4621-2	Brake Accumulator Isolation Valve	Boeing
274T4621-3	Brake Accumulator Isolation Valve	Boeing
274T4621-4	Brake Accumulator Isolation Valve	Boeing
274U0003-2	Brake Accumulator Isolation Valve	Boeing
274U0003-4	Isol. Valve & Alt.Brake Select.Valve	Boeing
274U0009-1	Valve assy	Boeing
27550-1	Oxygen Shut-off Valve	Intertechnique
27550-3	Oxygen Shut-off Valve	Intertechnique
27550-5	Oxygen Shut-off Valve	Intertechnique
275A1101-1	Nose Landing Gear Steering Actuator	Boeing
275A1101-2	Nose Landing Gear Steering Actuator	Boeing
275D929	Electrical Unit	Telephonics Corporation
275GV3	Valve	Custom Control Sensors
275N1211-2	Actuator	Boeing
275N1230-1	Steering Actuator	Boeing
275T4112-2	Nose Gear Steering Check Valve Mod.	Boeing
275T4112-3	Nose Gear Steering Check Valve Mod.	Boeing
275T6221-1	Nose Gear Steering Actuator	Boeing
275T6221-2	Nose Gear Steering Actuator	Boeing
275T6221-3	Nose Gear Steering Actuator	Boeing
2760000-101	Motor Operated Shut-Off Valve	Parker Hannifin
2762052-101	Actuator assy	Parker Aerospace
2762052-102	Actuator assy	Parker Aerospace
2762052-103	Actuator assy	Parker Aerospace
2762052-104	Actuator assy	Parker Aerospace
2763543-101	AC Actuator & Motor	Parker Aerospace
2763543-102	AC Valve Motor	Parker Aerospace

Repair_Capability_List_Excel

2763543-103	AC Motor	Parker Aerospace
2763543-104	AC Motor	Parker Aerospace
2-7679-2	Flow Rate Fuse assy	Dowty Aerospace
2-7680-2	Flow Rate Fuse assy	Dowty Aerospace
2769-2	Temperature Sensor	Hamilton Standard
2770002-101	Sniffle Valve	Parker Hannifin
2770002-103	Sniffle Valve	Parker Hannifin
2770561-101	4-3 Way Valve	Parker Hannifin
27755	AC Motor	Honeywell
2780536-101	Cargo Heating Valve	Parker Aerospace
2780536-102	Cargo Heating Valve	Parker Aerospace
2780537-102	Anti-Ice Valve	Parker Hannifin
2780537-103	Anti-Ice Valve	Parker Hannifin
2780537-104	Anti-Ice Valve	Parker Hannifin
2780539-101	Bleed Air Manifold Isolation Valve	Parker Aerospace
2780539-102	Bleed Air Manifold Isolation Valve	Parker Hannifin
2780539-103	Bleed Air Manifold Isolation Valve	Parker Hannifin
2780539-104	Bleed Air Manifold Isolation Valve	Parker Hannifin
2780539-105	Bleed Air Manifold Isolation Valve	Parker Hannifin
2780539-106	Bleed Air Manifold Isolation Valve	Parker Hannifin
2780540-101	APU Shut-Off Valve	Parker Aerospace
2780540-102	APU Shut-Off Valve	Parker Aerospace
2-7892-1	Hydraulic Snubber	Dowty Aerospace
2-7892-2	Hydraulic Snubber	Dowty Aerospace
2790409-101	Pressure Fueling Adapter	Parker Hannifin
2790409-102	Pressure Fueling Adapter	Parker Hannifin
2790475-101	Surge Tank Press. Relief Valve	Parker Hannifin
2790475-102	Surge Tank Press. Relief Valve	Parker Hannifin
2790475-103	Surge Tank Press. Relief Valve	Parker Hannifin
2790481-102	Float Act Vent Channel Valve	Parker Hannifin
2790482-101	Float Actuated Vent Valve	Parker Hannifin
2790521-101	Cartridge Check Valve	Parker Hannifin
2790521-102	Cartridge Check Valve	Parker Hannifin
2790523-101	Cartridge Check Valve	Parker Hannifin
2790523-102	Cartridge Check Valve	Parker Hannifin
2790523-103	Cartridge Check Valve	Parker Hannifin
2790583-104	Anti-Ice Valve	Parker Hannifin
2790583-105	Anti-Ice Valve	Parker Hannifin
2790583-106	Anti-Ice Valve	Parker Hannifin
2790583-107	Anti-Ice Valve	Parker Hannifin
2790583-108	Anti-Ice Valve	Parker Hannifin
2790592-101	Shut-Off Valve	Parker Hannifin
2790592-102	Shut-Off Valve	Parker Hannifin
2790592-103	Shut-Off Valve	Parker Hannifin
2790598-101	Shut-Off Valve	Parker Hannifin
2790598-102	Shut-Off Valve	Parker Hannifin
2790598-103	Shut-Off Valve	Parker Hannifin
2790605-101	Nacelle Vent Valve	Parker Hannifin
2790605-102	Nacelle Vent Valve	Parker Hannifin
2790605-103	Nacelle Vent Valve	Parker Hannifin
2794-901-00-11	Power Generation Display Panel	Thales Avionics
279952	Hydraulic Motorpump	Vickers
2801T100-1	Power Drive Unit	Telair International
2807219-2	Fan Brake	Technofan
280VC01Y1	Light Body	ECE
2810039-101	Swing Ckeck Cartridge Valve	Parker Hannifin
2810050-101	Fuel Level Control Pilot Valve	Parker Hannifin
2812125-101	Actuator assy	Parker Aerospace

Repair_Capability_List_Excel

2812125-102	Actuator assy	Parker Aerospace
2812125-103	Actuator assy	Parker Aerospace
2812125-104	Actuator assy	Parker Aerospace
2812125-105	Actuator assy	Parker Aerospace
2812125-106	Actuator assy	Parker Aerospace
2812125-107	Actuator assy	Parker Aerospace
281GC01	Battery Charge Controller	ECE
281GC01Y01	Battery Charge Controller	ECE
281GC01Y01K	Battery Charge Controller	ECE
281TS02Y06	Servo Motor Selector	Grimes Aerospace
281TS02Y07	Servo Motor Selector	Grimes Aerospace
281TS02Y08	Servo Motor Selector	Grimes Aerospace
281TS02Y09	Servo Motor Selector	Grimes Aerospace
282-03-000	Flight Compartment Cabin Door Lock	Buhl
282-05-000	Flight Compartment Cabin Door Lock	Buhl
282050-1	Cargo Control Unit	Goodrich
282-07-000	Lavatory Cabin Door Lock	Buhl
282-09-000	Lavatory Cabin Door Lock	Buhl
282-25-000	Wardrobe Door Lock	Buhl
282-26-000	Wardrobe Door Lock	Buhl
282673	Generator	Messier-Bugatti
282700-1001	Elevator Actuator	Parker Aerospace
282700-1003	Elevator Actuator	Parker Aerospace
282700-1005	Elevator Actuator	Parker Aerospace
282700-1007	Elevator Actuator	Parker Aerospace
282700-1009	Elevator Actuator	Parker Aerospace
282700-1011	Elevator Actuator	Parker Aerospace
282726	Hydraulic Pump	Vickers
282800-1001	Inboard Aileron PCA	Parker Aerospace
282800-1003	Inboard Aileron PCA	Parker Aerospace
282800-1005	Inboard Aileron PCA	Parker Aerospace
282800-1007	Inboard Aileron PCA	Parker Aerospace
282800-1009	Inboard Aileron PCA	Parker Aerospace
282800-1011	Inboard Aileron PCA	Parker Aerospace
282900-1001	Rudder PCA	Parker Aerospace
282900-1003	Rudder PCA	Parker Aerospace
282900-1005	Rudder PCA	Parker Aerospace
282900-1007	Rudder PCA	Parker Aerospace
282900-1009	Rudder PCA	Parker Aerospace
282900-1011	Rudder PCA	Parker Aerospace
282900-1013	Rudder PCA	Parker Aerospace
282EP01TY01	Solenoid Valve	Grimes Aerospace
282EP01TY02	Solenoid Valve	Grimes Aerospace
283126	Stator	Vickers
283200-1001	Outboard Aileron PCA	Parker Aerospace
283200-1003	Outboard Aileron PCA	Parker Aerospace
283200-1005	Outboard Aileron PCA	Parker Aerospace
283200-1007	Outboard Aileron PCA	Parker Aerospace
283400-1001	Rudder Power Control Actuator	Parker Hannifin
283400-1003	Rudder Power Control Actuator	Parker Hannifin
283553	Electric Motor	Vickers
283554	Hydraulic Motorpump	Vickers
2842T100-1	Latch XZ Single	Telair International
2842T100-3	Latch XZ Single	Telair International
28433	Temperature Bulb	Hamilton Sundstrand
284-331011100000	Gearbox	BGT
2843T100-1	Roller-Transport Type A	Telair International
28450	Fuel Shut-Off Valve	Sterer

Repair_Capability_List_Excel

2846T100-1	Sill Actuator	Telair International
28470-1	Power Brake Valve	Moog
28470-2	Power Brake Valve	Moog
28470-3	Power Brake Valve	Moog
2847T100-1	Roller	Telair International
285N0412-1	Handset assy	Boeing
285N0412-10	Handset assy	Boeing
285N0412-2	Handset assy	Boeing
285N0412-28	Handset assy	Boeing
285N0412-29	Handset assy	Boeing
285N0412-3	Handset assy	Boeing
285N0412-30	Handset assy	Boeing
285N0412-4	Handset assy	Boeing
285N0412-8	Handset assy	Boeing
285N0412-9	Handset assy	Boeing
285T0001-201	Audio Accessory Unit	Boeing
285T0001-202	Audio Accessory Unit	Boeing
285T0001-203	Audio Accessory Unit	Boeing
285T0001-204	Audio Accessory Unit	Boeing
285T0001-205	Audio Accessory Unit	Boeing
285T0001-206	Audio Accessory Unit	Boeing
285T0001-207	Audio Accessory Unit	Boeing
285T0001-208	Audio Accessory Unit	Boeing
285T0001-209	Audio Accessory Unit	Boeing
285T0001-21	Audio Accessory Unit	Boeing
285T0001-210	Audio Accessory Unit	Boeing
285T0001-211	Audio Accessory Unit	Boeing
285T0001-22	Audio Accessory Unit	Boeing
285T0001-23	Audio Accessory Unit	Boeing
285T0001-301	Audio Accessory Unit	Boeing
285T0001-302	Audio Accessory Unit	Boeing
285T0001-303	Audio Accessory Unit	Boeing
285T0001-304	Audio Accessory Unit	Boeing
285T0001-32	Audio Accessory Unit	Boeing
285T0001-33	Audio Accessory Unit	Boeing
285T0001-35	Audio Accessory Unit	Boeing
285T0001-36	Audio Accessory Unit	Boeing
285T0001-37	Audio Accessory Unit	Boeing
285T0001-40	Audio Accessory Unit	Boeing
285T0001-41	Audio Accessory Unit	Boeing
285T0001-42	Audio Accessory Unit	Boeing
285T0001-43	Audio Accessory Unit	Boeing
285T0001-46	Audio Accessory Unit	Boeing
285T0001-47	Audio Accessory Unit	Boeing
285T0001-48	Audio Accessory Unit	Boeing
285T0001-49	Audio Accessory Unit	Boeing
285T0001-50	Audio Accessory Unit	Boeing
285T0001-51	Audio Accessory Unit	Boeing
285T0001-52	Audio Accessory Unit	Boeing
285T0001-53	Audio Accessory Unit	Boeing
285T0001-54	Audio Accessory Unit	Boeing
285T0001-55	Audio Accessory Unit	Boeing
285T0001-56	Audio Accessory Unit	Boeing
285T0001-57	Audio Accessory Unit	Boeing
285T0001-58	Audio Accessory Unit	Boeing
285T0001-69	Audio Accessory Unit	Boeing
285T0001-70	Audio Accessory Unit	Boeing
285T0001-73	Audio Accessory Unit	Boeing

Repair_Capability_List_Excel

285T0001-75	Audio Accessory Unit	Boeing
285T0001-76	Audio Accessory Unit	Boeing
285T0001-77	Audio Accessory Unit	Boeing
285T0020-10	ILS Control Panel	Boeing
285T0020-8	ILS Control Panel	Boeing
285T0020-9	ILS Control Panel	Boeing
285T0021-16	VOR Control Panel	Boeing
285T0021-17	VOR Control Panel	Boeing
285T0021-19	VOR Control Panel	Boeing
285T0021-20	VOR Control Panel	Boeing
285T0022-19	Audio Panel	Boeing
285T0022-20	Audio Panel	Boeing
285T0022-21	Audio Panel	Boeing
285T0022-22	Panel assy	Boeing
285T0022-25	Audio Panel	Boeing
285T0022-26	Audio Panel	Boeing
285T0022-27	Audio Panel	Boeing
285T0022-28	Audio Panel	Boeing
285T0022-29	Audio Panel	Boeing
285T0022-30	Audio Panel	Boeing
285T0022-31	Panel assy	Boeing
285T0022-35	Panel assy	Boeing
285T0022-36	Panel assy	Boeing
285T0022-37	Panel assy	Boeing
285T0022-38	Panel assy	Boeing
285T0022-39	Panel assy	Boeing
285T0022-40	Panel assy	Boeing
285T0022-41	Panel assy	Boeing
285T0022-42	Panel assy	Boeing
285T0022-43	Panel assy	Boeing
285T0022-44	Panel assy	Boeing
285T0022-45	Panel assy	Boeing
285T0022-46	Panel assy	Boeing
285T0026-10	ATC Control Panel	Boeing
285T0026-11	ATC Control Panel	Boeing
285T0026-13	ATC Control Panel	Boeing
285T0026-14	ATC Control Panel	Boeing
285T0027-14	ADF Control Panel	Boeing
285T0027-15	ADF Control Panel	Boeing
285T0035-201	Power Supply	Boeing
285T0035-202	Power Supply	Boeing
285T0387-5	Power Supply	Boeing
285T0387-6	Power Supply	Boeing
285T0387-8	Power Supply	Boeing
285T0433-11	Control Panel Power Supply	Boeing
285T0433-13	Control Panel Power Supply	Boeing
285T0524-1	ILS Control Panel	Boeing
285T0524-6	ILS Control Panel	Boeing
285T0524-7	ILS Control Panel	Boeing
285T0524-8	ILS Control Panel	Boeing
285T0537-1	Dual ADF with BFO Control Panel	Boeing
285T0553-1	ILS Control Panel	Boeing
285T0553-2	ILS Control Panel	Boeing
285T0553-3	ILS Control Panel	Boeing
285T0553-4	ILS Control Panel	Boeing
285T0554-3	VOR Control Panel	Boeing
285T0554-4	VOR Control Panel	Boeing
285T0554-5	VOR Control Panel	Boeing

Repair_Capability_List_Excel

285T0554-6	VOR Control Panel	Boeing
285T0555-1	ATC Control Panel	Boeing
285T0555-2	ATC Control Panel	Boeing
285T0555-3	ATC Control Panel	Boeing
285T0555-4	ATC Control Panel	Boeing
285T0556-1	ADF Control Panel	Boeing
285T0557-1	Dual ADF Control Panel	Boeing
285T0557-2	Dual ADF Control Panel	Boeing
285U0037-101	Radio Communication Panel	Boeing
285U0037-104	Radio Communication Panel	Boeing
285U0037-105	Radio Communication Panel	Boeing
285U0037-201	Radio Communication Panel	Boeing
285U0037-202	Radio Communication Panel	Boeing
285U0037-203	Radio Communication Panel	Boeing
285U0037-301	Radio Communication Panel	Boeing
285U0037-301 MOD A	Radio Communication Panel	Boeing
285U0037-301 MOD B	Radio Communication Panel	Boeing
285U0037-302	Radio Communication Panel	Boeing
285U0037-302 MOD A	Radio Communication Panel	Boeing
285U0037-302 MOD B	Radio Communication Panel	Boeing
285U0037-303	Radio Communication Panel	Boeing
285U0037-303 MOD A	Radio Communication Panel	Boeing
285U0037-303 MOD B	Radio Communication Panel	Boeing
285U0037-304	Radio Communication Panel	Boeing
285U0037-304 MOD A	Radio Communication Panel	Boeing
285U0037-304 MOD B	Radio Communication Panel	Boeing
285U0037-305	Radio Communication Panel	Boeing
285U0037-305 MOD A	Radio Communication Panel	Boeing
285U0037-305 MOD B	Radio Communication Panel	Boeing
285U0037-306	Radio Communication Panel	Boeing
285U0037-306 MOD A	Radio Communication Panel	Boeing
285U0037-306 MOD B	Radio Communication Panel	Boeing
285U0037-307	Radio Communication Panel	Boeing
285U0037-307 MOD A	Radio Communication Panel	Boeing
285U0037-307 MOD B	Radio Communication Panel	Boeing
286.467	Servo Valve	Messier-Bugatti
286.467.100	Servo Valve	Messier-Bugatti
286.467.100.1	Servo Valve	Messier-Bugatti
286466	Brake Pedal Transmitter	Messier-Bugatti
286466E	Brake Pedal Transmitter	Messier-Bugatti
286467	Servo Valve	Messier-Bugatti
286-467	Servo Valve	Messier-Bugatti
286467100	Servo Valve	Messier-Bugatti
286-467-100	Servo Valve	Messier-Bugatti
286467100-1	Servo Valve	Messier-Bugatti
286-467-100-1	Servo Valve	Messier-Bugatti
286467A	Servo Valve	Messier-Bugatti
286467B	Servo Valve	Messier-Bugatti
286467C	Servo Valve	Messier-Bugatti
286467D	Servo Valve	Messier-Bugatti
286467E	Servo Valve	Messier-Bugatti
287092	Brake System Control Box	Messier-Bugatti
287092-0-1	Brake System Control Box	Messier-Bugatti
287092015	Brake System Control Box	Messier-Bugatti
287092016	Brake System Control Box	Messier-Bugatti
287092017	Brake System Control Box	Messier-Bugatti
287092018	Brake System Control Box	Messier-Bugatti
287092020	Brake System Control Box	Messier-Bugatti

Repair_Capability_List_Excel

287092021	Brake System Control Box	Messier-Bugatti
287092-1	Brake System Control Box	Messier-Bugatti
287105	Brake System Control Box	Messier-Bugatti
287219-1	Thermocouple	Messier-Bugatti
287494	D.C. Generator	Messier-Bugatti
287T6104-23	Main Landing Gear Wire Harness	Boeing
287T6104-24	Main Landing Gear Wire Harness	Boeing
287T6104-25	Main Landing Gear Wire Harness	Boeing
287T6104-26	Main Landing Gear Wire Harness	Boeing
287T6104-29	Main Landing Gear Wire Harness	Boeing
287T6104-30	Main Landing Gear Wire Harness	Boeing
287T6104-31	Main Landing Gear Wire Harness	Boeing
287T6104-32	Main Landing Gear Wire Harness	Boeing
287T6104-33	Main Landing Gear Wire Harness	Boeing
287T6104-34	Main Landing Gear Wire Harness	Boeing
287T6104-35	Main Landing Gear Wire Harness	Boeing
287T6104-36	Main Landing Gear Wire Harness	Boeing
287T6104-37	Main Landing Gear Wire Harness	Boeing
287T6104-38	Main Landing Gear Wire Harness	Boeing
287T6104-39	Main Landing Gear Wire Harness	Boeing
287T6104-40	Main Landing Gear Wire Harness	Boeing
287T6104-45	Main Landing Gear Wire Harness	Boeing
287T6104-46	Main Landing Gear Wire Harness	Boeing
287T6104-47	Main Landing Gear Wire Harness	Boeing
287T6104-48	Main Landing Gear Wire Harness	Boeing
287T6104-49	Main Landing Gear Wire Harness	Boeing
287T6104-50	Main Landing Gear Wire Harness	Boeing
287T6104-55	Main Landing Gear Wire Harness	Boeing
287T6104-56	Main Landing Gear Wire Harness	Boeing
287T6104-57	Main Landing Gear Wire Harness	Boeing
287T6104-58	Main Landing Gear Wire Harness	Boeing
287T6104-59	Main Landing Gear Wire Harness	Boeing
287T6104-60	Main Landing Gear Wire Harness	Boeing
287T6104-73	Main Landing Gear Wire Harness	Boeing
287T6104-74	Main Landing Gear Wire Harness	Boeing
287T6104-75	Main Landing Gear Wire Harness	Boeing
287T6104-76	Main Landing Gear Wire Harness	Boeing
287T6104-77	Main Landing Gear Wire Harness	Boeing
287T6104-78	Main Landing Gear Wire Harness	Boeing
288PG	Pressure Transmitter	Vibrometer
288PG-CP	Pressure Transmitter	Vibrometer
288PG-CP-M	Pressure Transmitter	Vibrometer
288PG-M	Pressure Transmitter	Vibrometer
288PG-SB	Pressure Transmitter	Vibrometer
288PG-SB-M	Pressure Transmitter	Vibrometer
2897T100-1	Latch XZ	Telair International
28C1-121	Electric Motor	Liebherr Aerospace
28E99-3	Oil Cooler/Heat Exchanger	Honeywell
28E99-4	Oil Cooler/Heat Exchanger	Honeywell
28E99-6	Oil Cooler/Heat Exchanger	Honeywell
28E99-7	Oil Cooler/Heat Exchanger	Honeywell
28VS200Y4B	Transformer Rectifier Unit	Federal Mogul
28VS200Y4B1	Transformer Rectifier Unit	Federal Mogul
28VS200Y4B2	Transformer Rectifier Unit	Federal Mogul
29000-3	Fuel Vent Float Valve	Fokker Aircraft
290210L	Rudder Controller	Parker Hannifin
290AS3	Airspeed Indicator	Smiths Industries
290D8042-503	Over Pressure Indicator	Rohr

Repair_Capability_List_Excel

291-10	Rear Navigation Light	Air Precision
291-21	RH Navigation Light	Air Precision
291-31	LH Navigation Light	Air Precision
2915T100-1	Latch XZ	Telair International
2916T100-1	YZ Single Latch	Telair International
2917T100-1	Latch YZ	Telair International
291F01000-005	Hydraulic Reservoir	Omaspa
291F01000-005A	Hydraulic Reservoir	Omaspa
291F02000-003	Accumulator	Omaspa
291SP017	Hand Microphone	Elno
292-12	Strobe Light	Air Precision
292-13	Strobe Light	Air Precision
2921T100-1	Latch YZ	Telair International
292204A	Actuator assy	MPC Products
292204B	Actuator assy	MPC Products
292204C	Actuator assy	MPC Products
292204D	Actuator assy	MPC Products
292-22D	Strobe Light Power Supply Unit	Air Precision
292-23	Strobe Light Power Supply Unit	Air Precision
292-23B	Strobe Light Power Supply Unit	Air Precision
292-24	Strobe Light Power Supply Unit	Air Precision
292-25	Strobe Light Power Supply Unit	Air Precision
29261-7EA1	Oxygen Regulator	Bendix/King
29261-7E-A1	Oxygen Regulator	Bendix/King
2930005-101	Thermal Relief Fuel Check Valve	Parker Hannifin
2930005-102	Thermal Relief Fuel Check Valve	Parker Hannifin
29340-3	Ground Spoiler Actuator	Moog
29340-4	Ground Spoiler Actuator	Moog
2936	Low Pressure Valve Actuator	Intertechnique
293GC01	Current Sensor	ECE
293GC01Y02	Current Sensor	ECE
2940	Crossfeed Valve Actuator	Intertechnique
2944T100-1	Power Drive Unit	Telair International
2955T100-3	Power Drive Unit	Telair International
29600-2	Pressure Regulator Valve	Sterer
29600-3	Pressure Regulator Valve	Sterer
2962	Lock door	Adams Rite
2966	Individual Air Outlet assy	Puritan Bennett
29680	Pressure Reducer	Sterer
29680-1	MLG Pressure Reducer	Sterer
29680-2	MLG Pressure Reducer	Sterer
2969T100-1	Braking Roller	Telair International
29700-480	Hydraulic Flow Regulator	Sterer
29700-550	Hydraulic Flow Regulator	Sterer
2980032100000	Mixing Faucet assy	Aqua Butzke-Werk.
2980042100000	Faucet assy	Aqua Butzke-Werk.
2980052100000	Faucet Water assy	Aqua Butzke-Werke
2980132100000	Water Faucet	Aqua Butzke-Werk.
2980142100000	Water Faucet	Aqua Butzke-Werk.
2980152100000	Faucet Water assy	Aqua Butzke-Werke
2980192100000	Water Faucet	Aqua Butzke-Werk.
2980292100000	Water Faucet	Aqua Butzke-Werk.
298113	Hydraulic Motor Pump	Vickers
2982T100-1	Single Latch Y	Telair International
2982T100-3	Single Latch Y	Telair International
2983T100-1	Double Latch XZ	Telair International
2984T100-1	Single Latch XZ	Telair International
2985T100-1	Single Latch XZ	Telair International

Repair_Capability_List_Excel

2986T100-1	YZ Single Latch	Telair International
2987T100-1	XZ Single Latch	Telair International
2987T100-101	XZ Single Latch	Telair International
2987T100-3	XZ Single Latch	Telair International
2988T100-1	Latch XZ	Telair International
2988T100-3	Latch XZ	Telair International
2989T100-1	Triple Latch XZ	Telair International
2995-100-00-11	Shunt	Thales Avionics
2995-250	Ammeter Shunt	Sextant Avionique
29992	AC Motor	Skurka Aerospace
29B33-23-A	AC/DC Generator	Bendix/King
2A0528	Temperature Sensor	Rosemount Aerospace
2A125-1A	Inverter assy	Avionic Instruments
2A250-1A	Inverter assy	Avionic Instruments
2A350-1AS1830	Inverter assy	Avionic Instruments
2A350-1B-1	Inverter assy	Avionic Instruments
2A50-1A	Inverter assy	Avionic Instruments
2A50-1B-1	Inverter assy	Avionic Instruments
2A7200A	Actuator assy	MPC Products
2A7205A	Actuator assy	MPC Products
2A7206B	Actuator assy	MPC Products
2B7-201B	Actuator assy	MPC Products
2B7-201C	Actuator assy	MPC Products
2B7-201D	Actuator assy	MPC Products
2B7-201E	Actuator assy	MPC Products
2B74-1A	Current Transformer	Honeywell
2B75-1A	Current Transformer	Honeywell
2B79-1A	Current Transformer	Honeywell
2C6380	Valve	Crissair Inc.
2C7-4	Fuel Booster Pump	Parker Hannifin
2C9168	Check Valve assy	Crissair
2C9180	Valve	Crissair Inc.
2CM15AAB1	Generator	General Electric
2CM16RAA1	Alternator	Pacific Scientific
2CM16SAB2	Alternator	Pacific Scientific
2CM16SAB3	Alternator	Pacific Scientific
2CM18RAA1	Alternator	Pacific Scientific
2CM18SAA2	Alternator	Pacific Scientific
2CM353C1-D	Generator	General Electric
2CM353C1-F	Generator	General Electric
2CM353C1-H	Generator	General Electric
2CM353C1-J	Generator	General Electric
2CM5BAL20	Tachymeter	General Electric
2CM5BAL21	Tachymeter	General Electric
2LA002606-01	Service Area Light	Hella
2LA002607-00	Light	Hella
2LA002607-02	Light	Hella
2LA002607-10	Light	Hella
2LA002607-15	Light	Hella
2LA002607-30	Light	Hella
2LA002607-35	Light	Hella
2LA002692-02	Emergency Light	Hella
2LA002699-00	Warning Light	Hella
2LA002760-70	Strobe Light	Hella
2LA003544-30	Emergency Light	Hella
2LA003622-00	Area Light Panel	Hella
2LA003622-01	Area Light Panel	Hella
2LA003717-01	Reading Light	Hella

Repair_Capability_List_Excel

2LA003717-05	Reading Light	Hella
2LA003926-00	Tail Position Light	Hella
2LA003954-00	Wing Strobe Light	Hella
2LA003965-00	Unit Light	Hella
2LA003968-00	Anticollision Light	Hella
2LA004116-00	Wing Strobe Light	Hella
2LA004351-00	Reading Light	Hella
2LA004626-00	Reading Light	Hella
2LA004794-00	Tail Position Light	Hella
2LA004891-00	Reading Light	Hella
2LA004892-00	Reading Light	Hella
2LA005127-01	Overwing Emergency Light	Hella
2LA005128-01	Overwing Emergency Light	Hella
2LA005163-00	Reading Light	Hella
2LA005303-01	Strobe Light Unit	Hella
2LA005303-05	Strobe Light Unit	Hella
2LA005308-01	Strobe Light Unit	Hella
2LA005308-05	Strobe Light Unit	Hella
2LA005351-00	Cargo Compartment Light	Hella
2LA005356-00	Flood Light	Hella
2LA005356-01	Flood Light	Hella
2LA005356-02	Flood Light	Hella
2LA005356-03	Flood Light	Hella
2LA005356-04	Flood Light	Hella
2LA005391-00	Reading Light	Hella
2LA005391-05	Reading Light	Hella
2LA005392-00	Reading Light	Hella
2LA005392-05	Reading Light	Hella
2LA005413-01	Overwing Emergency Light	Hella
2LA005414-01	Overwing Emergency Light	Hella
2LA005467-00	Warning Light Panel	Hella
2LA005469-00	Warning Light Panel	Hella
2LA005482-00	Floodlight	Hella
2LA005482-15	Bay Light	Hella
2LA005496-00	Warning Light Panel	Hella
2LA005541-00	Captain Flood Light Unit	Hella
2LA005541-10	Captain Flood Light Unit	Hella
2LA005542-20	Main Instrument Panel Light	Hella
2LA005543-00	Flood Light Unit	Hella
2LA005543-10	Flood Light Unit	Hella
2LA005573-00	Dome Light	Hella
2LA005573-01	Dome Light	Hella
2LA005715-00	Sign Unit Utility Light	Hella
2LA005742-00	Reading Light	Hella
2LA005776-00	Reading Light	Hella
2LA006482-05	Reading Light	Hella
2LA006483-05	Reading Light	Hella
2LA007307-00	Warning Panel Light	Hella
2LA007417-00	Reading Light Module	Hella
2LA007417-20	Reading Light Module	Hella
2LA2607-16	Ceiling Light	Hella
2LA403700-01	Rear Single Navigation Light	Hella
2LA403702-01	Rear Dual Navigation Light	Hella
2LA408353-00	Chart Holder Light	Hella
2S2110	Check Valve	Crissair Inc.
2S2124	Check Valve	Crissair Inc.
2S2794	Check Valve	Crissair Inc.
2S2794-1	Check Valve	Crissair Inc.

Repair_Capability_List_Excel

2VA39-25G1	Yaw Damper Actuator	Goodrich Control Systems
2Z6468	Air/Oil Separator	Eaton
30001300-003	Control Parking	HR Textron
30001300-007	Control Parking	HR Textron
30001300-007A	Control Parking	HR Textron
30001300-009	Package Control	HR Textron
30001300-009A	Control Parking	HR Textron
30001300-009B	Package Control	HR Textron
30001300-011	Control Parking	HR Textron
30001300-011A	Package Control	HR Textron
30001300-013	Control Parking	HR Textron
30001300-013A	Package Control	HR Textron
30001300-015	Package Control	HR Textron
30001300-017	Package Control	HR Textron
30001300-019	Control Parking	HR Textron
30001300-021	Package Control	HR Textron
30001300-023	Control Parking	HR Textron
300040000	Anti-Ice Air Valve	Tac Tair
300040001	Anti-Ice Air Valve	Tac Tair
300040002	Anti-Ice Air Valve	Tac Tair
3000-46-24	Thermal Switch	Honeywell
3001-01-111	Accelerometer	Honeywell
30-0127-1	Navigational Tail Position Light	Grimes Aerospace
30-0127-11	Navigational Tail Position Light	Grimes Aerospace
30-0127-13	Navigational Tail Position Light	Grimes Aerospace
30-0127-3	Navigational Tail Position Light	Grimes Aerospace
30-0127-5	Navigational Tail Position Light	Grimes Aerospace
30-0127-7	Navigational Tail Position Light	Grimes Aerospace
30-0127-9	Navigational Tail Position Light	Grimes Aerospace
30-0180-1	Wing Inspection Light	Grimes Aerospace
30-0180-2	Wing Inspection Light	Grimes Aerospace
30-0180-3	Wing Inspection Light	Grimes Aerospace
30-0180-4	Wing Inspection Light	Grimes Aerospace
30-0180-5	Wing Inspection Light	Grimes Aerospace
30-0180-6	Wing Inspection Light	Grimes Aerospace
30-0180-7	Wing Inspection Light	Grimes Aerospace
30-0180-8	Wing Inspection Light	Grimes Aerospace
30-0191-1	Wing Position Navigation Light	Grimes Aerospace
30-0191-10	Wing Position Navigation Light	Grimes Aerospace
30-0191-11	Wing Position Navigation Light	Grimes Aerospace
30-0191-2	Wing Position Navigation Light	Grimes Aerospace
30-0191-3	Wing Position Navigation Light	Grimes Aerospace
30-0191-5	Wing Position Navigation Light	Grimes Aerospace
30-0191-6	Wing Position Navigation Light	Grimes Aerospace
30-0191-7	Wing Position Navigation Light	Grimes Aerospace
30-0191-8	Wing Position Navigation Light	Grimes Aerospace
30-0191-9	Wing Position Navigation Light	Grimes Aerospace
30-0332-1	Wing Tip Light	Grimes Aerospace
30-0332-10	Wing Tip Light	Grimes Aerospace
30-0332-2	Wing Tip Light	Grimes Aerospace
30-0332-3	Wing Tip Light	Grimes Aerospace
30-0332-4	Wing Tip Light	Grimes Aerospace
30-0332-5	Wing Tip Light	Grimes Aerospace
30-0332-6	Wing Tip Light	Grimes Aerospace
30-0332-7	Wing Tip Light	Grimes Aerospace
30-0332-8	Wing Tip Light	Grimes Aerospace
30-0332-9	Wing Tip Light	Grimes Aerospace
30-0333-7	Tail Position Light	Grimes Aerospace

Repair_Capability_List_Excel

30-0333-9	Tail Position Light	Grimes Aerospace
30-0360-3	High Instensity Strobe Light	Grimes Aerospace
30-0360-5	High Instensity Strobe Light	Grimes Aerospace
30-0360-7	High Instensity Strobe Light	Grimes Aerospace
30-0404-1	Wing Position Navigation Light	Grimes Aerospace
30-0404-2	Wing Position Navigation Light	Grimes Aerospace
30-0418-1A	Light	Grimes Aerospace
30042-000-0202	Level Sensing Control Unit	Simmonds Precision
30042-000-0301	Level Sensing Control Unit	Simmonds Precision
30042-000-0302	Level Sensing Control Unit	Simmonds Precision
30042-000-0303	Level Sensing Control Unit	Simmonds Precision
30042-000-0401	Level Sensing Control Unit	Simmonds Precision
30042-000-0402	Level Sensing Control Unit	Simmonds Precision
30042-000-0601	Level Sensing Control Unit	Simmonds Precision
300425-01	Actuator	Grimes Aerospace
300425-02	Actuator	Grimes Aerospace
30-0443-5	Logo Tail Flood Light	Grimes Aerospace
30-0443-6	Logo Tail Flood Light	Grimes Aerospace
30-0443-7	Logo Tail Flood Light	Grimes Aerospace
30-0443-8	Logo Tail Flood Light	Grimes Aerospace
30-0491-5	Wing Position Light	Grimes Aerospace
30-0491-6	Wing Position Light	Grimes Aerospace
30-0536-13	Light	Grimes Aerospace
30-0536-14	Light	Grimes Aerospace
30-0544-1	Emergency Exit Slide Light	Grimes Aerospace
30-0621-11	Flashing Light	Grimes Aerospace
30-0621-3	Flashing Light	Grimes Aerospace
30-0621-5	Flashing Light	Grimes Aerospace
30-0621-7	Flashing Light	Grimes Aerospace
30-0621-9	Flashing Light	Grimes Aerospace
30-0626-11	Tail Position Light	Grimes Aerospace
30-0626-3	Tail Position Light	Grimes Aerospace
30-0626-5	Tail Position Light	Grimes Aerospace
30-0626-7	Tail Position Light	Grimes Aerospace
30-0626-9	Tail Position Light	Grimes Aerospace
30-0627-1	Wing Position Light	Grimes Aerospace
30-0627-2	Wing Position Light	Grimes Aerospace
30-0627-3	Wing Position Light	Grimes Aerospace
30-0627-3M	Wing Position Light	Grimes Aerospace
30-0627-4	Wing Position Light	Grimes Aerospace
30-0627-4M	Wing Position Light	Grimes Aerospace
30-0627-5	Wing Position Light	Grimes Aerospace
30-0627-6	Wing Position Light	Grimes Aerospace
30-0627-9	Wing Position Light	Grimes Aerospace
30-0639-1	Wing Position Flashtube Light	Grimes Aerospace
30-0651-1	Wing Position Flashtube Light	Grimes Aerospace
30-0778-1	Wheel Well Light	Grimes Aerospace
30-0778-11	Wheel Well Light	Grimes Aerospace
30-0778-3	Wheel Well Light	Grimes Aerospace
30-0778-5	Wheel Well Light	Grimes Aerospace
30-0778-7	Wheel Well Light	Grimes Aerospace
30-0778-9	Wheel Well Light	Grimes Aerospace
30-0837-1	Anti-Collision Strobe Light	Grimes Aerospace
30-0837-11	Anti-Collision Strobe Light	Grimes Aerospace
30-0837-13	Anti-Collision Strobe Light	Grimes Aerospace
30-0837-15	Anti-Collision Strobe Light	Grimes Aerospace
30-0837-17	Anti-Collision Strobe Light	Grimes Aerospace
30-0837-19	Anti-Collision Strobe Light	Grimes Aerospace

Repair_Capability_List_Excel

30-0837-21	Anti-Collision Strobe Light	Grimes Aerospace
30-0837-23	Anti-Collision Strobe Light	Grimes Aerospace
30-0837-25	Anti-Collision Strobe Light	Grimes Aerospace
30-0837-27	Anti-Collision Strobe Light	Grimes Aerospace
30-0837-29	Anti-Collision Strobe Light	Grimes Aerospace
30-0837-3	Anti-Collision Strobe Light	Grimes Aerospace
30-0837-31	Anti-Collision Strobe Light	Grimes Aerospace
30-0837-33	Anti-Collision Strobe Light	Grimes Aerospace
30-0837-35	Anti-Collision Strobe Light	Grimes Aerospace
30-0837-37	Anti-Collision Strobe Light	Grimes Aerospace
30-0837-39	Anti-Collision Strobe Light	Grimes Aerospace
30-0837-41	Anti-Collision Strobe Light	Grimes Aerospace
30-0837-43	Anti-Collision Strobe Light	Grimes Aerospace
30-0837-45	Anti-Collision Strobe Light	Grimes Aerospace
30-0837-47	Anti-Collision Strobe Light	Grimes Aerospace
30-0837-5	Anti-Collision Strobe Light	Grimes Aerospace
30-0837-7	Anti-Collision Strobe Light	Grimes Aerospace
30-0837-9	Anti-Collision Strobe Light	Grimes Aerospace
30-0881-1	Anticollision Light	Grimes Aerospace
30-0881-11	Anticollision Light	Grimes Aerospace
30-0881-3	Anticollision Light	Grimes Aerospace
30-0881-5	Anticollision Light	Grimes Aerospace
30-0881-7	Anticollision Light	Grimes Aerospace
30-0881-9	Anticollision Light	Grimes Aerospace
30-0896-1	Navigational Anti-Collision Strobe Light	Grimes Aerospace
300-90116-0506	Spare Proximity Board	Honeywell
30-0906-1	Light	Grimes Aerospace
30-0906-10	Light	Grimes Aerospace
30-0906-101	Light	Grimes Aerospace
30-0906-103	Light	Grimes Aerospace
30-0906-104	Light	Grimes Aerospace
30-0906-105	Light	Grimes Aerospace
30-0906-106	Light	Grimes Aerospace
30-0906-107	Light	Grimes Aerospace
30-0906-109	Light	Grimes Aerospace
30-0906-11	Light	Grimes Aerospace
30-0906-110	Light	Grimes Aerospace
30-0906-111	Light	Grimes Aerospace
30-0906-113	Light	Grimes Aerospace
30-0906-115	Light	Grimes Aerospace
30-0906-116	Light	Grimes Aerospace
30-0906-117	Light	Grimes Aerospace
30-0906-118	Light	Grimes Aerospace
30-0906-119	Light	Grimes Aerospace
30-0906-121	Light	Grimes Aerospace
30-0906-122	Light	Grimes Aerospace
30-0906-123	Light	Grimes Aerospace
30-0906-124	Light	Grimes Aerospace
30-0906-125	Light	Grimes Aerospace
30-0906-126	Light	Grimes Aerospace
30-0906-128	Light	Grimes Aerospace
30-0906-129	Light	Grimes Aerospace
30-0906-13	Light	Grimes Aerospace
30-0906-15	Light	Grimes Aerospace
30-0906-16	Light	Grimes Aerospace
30-0906-17	Light	Grimes Aerospace
30-0906-18	Light	Grimes Aerospace
30-0906-19	Light	Grimes Aerospace

Repair_Capability_List_Excel

30-0906-21	Light	Grimes Aerospace
30-0906-22	Light	Grimes Aerospace
30-0906-23	Light	Grimes Aerospace
30-0906-24	Light	Grimes Aerospace
30-0906-25	Light	Grimes Aerospace
30-0906-26	Light	Grimes Aerospace
30-0906-3	Light	Grimes Aerospace
30-0906-4	Light	Grimes Aerospace
30-0906-5	Light	Grimes Aerospace
30-0906-6	Light	Grimes Aerospace
30-0906-7	Light	Grimes Aerospace
30-0906-9	Light	Grimes Aerospace
30-0908-1	Tail Position Flashtube Light	Grimes Aerospace
30-0908-3	Tail Position Flashtube Light	Grimes Aerospace
30-0908-5	Tail Position Flashtube Light	Grimes Aerospace
30-0909-1	Light	Grimes Aerospace
30-0909-101	Light	Grimes Aerospace
30-0909-103	Light	Grimes Aerospace
30-0909-107	Light	Grimes Aerospace
30-0909-201	Light	Grimes Aerospace
30-0909-203	Light	Grimes Aerospace
30-0909-207	Light	Grimes Aerospace
30-0910-1	Navigational Strobe Light	Grimes Aerospace
30-0910-3	Navigational Strobe Light	Grimes Aerospace
30-0911-3	Navigational Strobe Light	Grimes Aerospace
30-0911-7	Navigational Strobe Light	Grimes Aerospace
30-0983-1	Lens assy	Grimes Aerospace
30-0983-2	Lens assy	Grimes Aerospace
3010	Static Inverter	Euroatlas
30-1033-1	Anti-Collision Light	Grimes Aerospace
30-1033-11	Anti-Collision Light	Grimes Aerospace
30-1033-13	Anti-Collision Light	Grimes Aerospace
30-1033-15	Anti-Collision Light	Grimes Aerospace
30-1033-17	Anti-Collision Light	Grimes Aerospace
30-1033-19	Anti-Collision Light	Grimes Aerospace
30-1033-21	Anti-Collision Light	Grimes Aerospace
30-1033-23	Anti-Collision Light	Grimes Aerospace
30-1033-25	Anti-Collision Light	Grimes Aerospace
30-1033-27	Anti-Collision Light	Grimes Aerospace
30-1033-29	Anti-Collision Light	Grimes Aerospace
30-1033-3	Anti-Collision Light	Grimes Aerospace
30-1033-31	Anti-Collision Light	Grimes Aerospace
30-1033-33	Anti-Collision Light	Grimes Aerospace
30-1033-35	Anti-Collision Light	Grimes Aerospace
30-1033-37	Anti-Collision Light	Grimes Aerospace
30-1033-39	Anti-Collision Light	Grimes Aerospace
30-1033-41	Anti-Collision Light	Grimes Aerospace
30-1033-43	Anti-Collision Light	Grimes Aerospace
30-1033-45	Anti-Collision Light	Grimes Aerospace
30-1033-49	Anti-Collision Light	Grimes Aerospace
30-1033-5	Anti-Collision Light	Grimes Aerospace
30-1033-51	Anti-Collision Light	Grimes Aerospace
30-1033-53	Anti-Collision Light	Grimes Aerospace
30-1033-55	Anti-Collision Light	Grimes Aerospace
30-1033-57	Anti-Collision Light	Grimes Aerospace
30-1033-59	Anti-Collision Light	Grimes Aerospace
30-1033-61	Anti-Collision Light	Grimes Aerospace
30-1033-63	Anti-Collision Light	Grimes Aerospace

Repair_Capability_List_Excel

30-1033-65	Anti-Collision Light	Grimes Aerospace
30-1033-67	Anti-Collision Light	Grimes Aerospace
30-1033-7	Anti-Collision Light	Grimes Aerospace
30-1099-1	Light	Grimes Aerospace
30-1099-1M	Light	Grimes Aerospace
30-1099-3	Light	Grimes Aerospace
30-1099-5	Light	Grimes Aerospace
3010P	Static Inverter	Euroatlas
3010R	Static Inverter	Euroatlas
30-1108-1	Light assy	Grimes Aerospace
30-1108-11	Anti-Collision Light	Grimes Aerospace
30-1108-13	Anti-Collision Light	Grimes Aerospace
30-1108-2	Light assy	Grimes Aerospace
30-1108-3	Light assy	Grimes Aerospace
30-1108-4	Light assy	Grimes Aerospace
30-1108-5	Light assy	Grimes Aerospace
30-1108-6	Light assy	Grimes Aerospace
30-1108-7	Light assy	Grimes Aerospace
30-1108-8	Light assy	Grimes Aerospace
30-1108-9	Light assy	Grimes Aerospace
30-1122-1	Wing Tip Navigation Light	Grimes Aerospace
30-1133-1	Navigational Wing Position Light	Grimes Aerospace
30-1133-2	Navigational Wing Position Light	Grimes Aerospace
30-1136-1	Navigational Strobe Light	Grimes Aerospace
30-1136-11	Navigational Strobe Light	Grimes Aerospace
30-1136-13	Navigational Strobe Light	Grimes Aerospace
30-1136-15	Navigational Strobe Light	Grimes Aerospace
30-1136-3	Navigational Strobe Light	Grimes Aerospace
30-1136-5	Navigational Strobe Light	Grimes Aerospace
30-1136-7	Navigational Strobe Light	Grimes Aerospace
30-1136-9	Navigational Strobe Light	Grimes Aerospace
301-2300	Emergency Light Box assy	NEC
301-2323	Exit Lens	NEC
301-2400	Emergency Light Box assy	NEC
301-2500	Exit Emergency Sign	NEC
301-2551	Emergency Light Box assy	NEC
301-2560	Emergency Light Frame assy	NEC
301-2570	Emergency Light Adapter	NEC
301-2600	Attendant Panel	NEC
301-2640	Attendant Panel	NEC
301-2700	Emergency Flood Light	NEC
301-2701	Emergency Flood Light	NEC
301-3000	Emergency Lighting Power Supply Unit	NEC
301-3100	Emergency Lighting Power Supply Unit	NEC
30136-0102	Water Quantity Transmitter	Goodrich
30136-0104	Water Quantity Transmitter	Goodrich
30136-0105	Water Quantity Transmitter	Goodrich
30136-0106	Water Quantity Transmitter	Goodrich
30136-0107	Water Quantity Transmitter	Goodrich
30136-0108	Water Quantity Transmitter	Goodrich
301400-3	Valve	Grimes Aerospace
30-1401-1	Light	Grimes Aerospace
30-1401-11	Anti-Collision Strobe Light	Grimes Aerospace
30-1401-13	Anti-Collision Strobe Light	Grimes Aerospace
30-1401-15	Anti-Collision Strobe Light	Grimes Aerospace
30-1401-3	Light	Grimes Aerospace
30-1401-5	Light	Grimes Aerospace
30-1401-7	Light	Grimes Aerospace

Repair_Capability_List_Excel

30-1401-9	Anti-Collision Strobe Light	Grimes Aerospace
30-1404-1	Emergency Exit Light	Grimes Aerospace
30-1404-2	Emergency Exit Light	Grimes Aerospace
3014985	Igniter Plug	Hamilton Sundstrand
3014986	Igniter Plug	Hamilton Sundstrand
30-1521-1	Rear Position Navigation Light	Grimes
30-1521-2	Rear Position Navigation Light	Grimes
30-1521-3	Rear Position Navigation Light	Grimes
30-1521-4	Rear Position Navigation Light	Grimes
30-1521-5	Rear Position Navigation Light	Grimes
30-1521-6	Rear Position Navigation Light	Grimes
30-1526-11	Anti-Collision Strobe Light	Grimes Aerospace
30-1526-3	Anti-Collision Strobe Light	Grimes Aerospace
30-1526-5	Anti-Collision Strobe Light	Grimes Aerospace
30-1526-7	Anti-Collision Strobe Light	Grimes Aerospace
30-1526-9	Anti-Collision Strobe Light	Grimes Aerospace
30-1554-1	Overwing Emergency Light	Grimes Aeroapace
30-1554-3	Overwing Emergency Light	Grimes Aeroapace
30-1554-5	Overwing Emergency Light	Grimes Aeroapace
30-1554-7	Overwing Emergency Light	Grimes Aeroapace
30-1562-1	Forward Slide Floodlight	Grimes Aerospace
30-1562-2	Forward Slide Floodlight	Grimes Aerospace
30-1564-1	Wing Slide Floodlight	Grimes
30-1564-2	Wing Slide Floodlight	Grimes
30-1564-3	Wing Slide Floodlight	Grimes
30-1564-4	Wing Slide Floodlight	Grimes
30-1564-5	Wing Slide Floodlight	Grimes
30-1564-6	Wing Slide Floodlight	Grimes
30-1564-7	Wing Slide Floodlight	Grimes
30-1564-8	Wing Slide Floodlight	Grimes
30-1579-1	Anti-Collision Flashtube Light	Grimes Aerospace
30-1588-1	Wing Position Light	Grimes Aerospace
30-1588-2	Wing Position Light	Grimes Aerospace
30-1588-5	Wing Position Light	Grimes Aerospace
30-1588-6	Wing Position Light	Grimes Aerospace
30-1627-1	Bulk Cargo Door Floodlight	Grimes Aerospace
30-1627-5	Bulk Cargo Door Floodlight	Grimes Aerospace
30-1660-5	Rear Position Light assy	Grimes Aerospace
30-1667-1	Wing Position Light	Grimes Aerospace
30-1667-2	Wing Position Light	Grimes Aerospace
30-1685-1	Wing Tip Strobe Light	Grimes Aerospace
30-1685-2	Wing Tip Strobe Light	Grimes Aerospace
30-1691-1	Wing Anti-Collision Light	Grimes Aerospace
30-1691-2	Wing Anti-Collision Light	Grimes Aerospace
30-1712-1	Anti-Collision Strobe Flash Tube	Grimes Aerospace
30-1712-2	Anti-Collision Strobe Flash Tube	Grimes Aerospace
30-1712-4	Anti-Collision Strobe Flash Tube	Grimes Aerospace
30-1712-5	Anti-Collision Strobe Flash Tube	Grimes Aerospace
30-1739-1	Wing Inspection Floodlight	Grimes Aerospace
30-1739-2	Wing Inspection Floodlight	Grimes Aerospace
30-1742-5	Emergency Egress Light	Grimes Aerospace
30-1742-6	Emergency Egress Light	Grimes Aerospace
3017449	Wiring Harness	Hamilton Sundstrand
30-1768-1	Light	Grimes Aerospace
30-1768-2	Light	Grimes Aerospace
30-1768-3	Light	Grimes Aerospace
30-1768-4	Light	Grimes Aerospace
30-1768-5	Light	Grimes Aerospace

Repair_Capability_List_Excel

30-1768-6	Light	Grimes Aerospace
30-1768-7	Light	Grimes Aerospace
30-1768-8	Light	Grimes Aerospace
30-1777-5	Emergency Light	Grimes Aerospace
30-1777-7	Emergency Light	Grimes Aerospace
30-1809-1	Anti-Collision Flashtube Light	Grimes Aerospace
30180B21	Flood Refuelling	Grimes Aerospace
30180B211683	Flood Refuelling	Grimes Aerospace
30180B231683	Flood Refuelling	Grimes Aerospace
30180B23D	Flood Refuelling	Grimes Aerospace
30180B25	Flood Refuelling	Grimes Aerospace
30180B25-2233	Flood Refuelling	Grimes Aerospace
3018828	Oil/Fuel Heater	Hamilton Sundstrand
30-1883-3	Wing & Nacelle Inspection Floodlight	Grimes Aerospace
30-1883-4	Wing & Nacelle Inspection Floodlight	Grimes Aerospace
30-1883-5	Wing & Nacelle Inspection Floodlight	Grimes Aerospace
30-1883-6	Wing & Nacelle Inspection Floodlight	Grimes Aerospace
30-1948-1	Anti-Collision Light	Grimes Aerospace
30-1948-2	Anti-Collision Light	Grimes Aerospace
30195-100	Hand Pump	Goodrich Control Systems
30-1951-1	Anti-Collision Light	Grimes Aerospace
30-1951-3	Anti-Collision Light	Grimes Aerospace
30-1953-3	Anti-Collision Light	Grimes Aerospace
30-1953-5	Anti-Collision Light	Grimes Aerospace
30-1953-7	Anti-Collision Light	Grimes Aerospace
30-1953-9	Navigation Light	Grimes Aerospace
301RAA/1	ROTARY ACTUATOR	SMITHS
301RAA/2	Rotary Actuator	Smiths Industries
301RAA2	Rotary Actuator	Smiths Industries
301RGS1	Miniature Rate Gyro	Smiths Industries
301RGS2	Miniature Rate Gyro	Smiths Industries
301RGS3	Miniature Rate Gyro	Smiths Industries
301RGS4	Miniature Rate Gyro	Smiths Industries
301RGS5	Miniature Rate Gyro	Smiths Industries
301RGS6	Miniature Rate Gyro	Smiths Industries
30-2022-1	Wing Position Navigation Light	Grimes Aerospace
30-2022-2	Wing Position Navigation Light	Grimes Aerospace
30-2042-1	Light	Grimes Aerospace
30-2042-2	Light	Grimes Aerospace
30-2044-1	Light	Grimes Aerospace
30-2044-2	Light	Grimes Aerospace
30-2044-3	Light	Grimes Aerospace
30-2044-4	Light	Grimes Aerospace
30-2044-5	Light	Grimes Aerospace
30-2044-6	Light	Grimes Aerospace
30-2109-1	Anti-Collision Strobe Light	Grimes Aerospace
30-2109-3	Anti-Collision Strobe Light	Grimes Aerospace
30-2110-1	Anti-Collision Strobe Light	Grimes Aerospace
30-2110-3	Anti-Collision Strobe Light	Grimes Aerospace
3022016-000	Brake System Relief Valve	Vickers
3022017-001	Hydraulic Motor assy	Vickers
30-231-15	Smoke Detector	Pyrotector
30-231-26	Smoke Detector	Walter Kidde
30-231-3	Smoke Detector	Pyrotector
30-231-30	Smoke Detector	Grimes Aerospace
30-231-33	Smoke Detector	Pyrotector
30-231-4	Smoke Detector	Pyrotector
30-231-8	Smoke Detector	Pyrotector

Repair_Capability_List_Excel

30-231A-7	Smoke Detector	Pyrotector
30-231R-1	Smoke Detector	Kidde Technologies
30-231R-26	Smoke Detector	Kidde Technologies
30-231R-30	Smoke Detector	Kidde Technologies
30-231R-30-1	Smoke Detector	Kidde Technologies
30-231R7	Smoke Detector	Kidde Aerospace
30-2320-1	Navigation Light	Grimes Aerospace
30-2320-2	Navigation Light	Grimes Aerospace
30-2438-1	Tail Position Light	Grimes Aerospace
30-2438-3	Tail Position Light	Grimes Aerospace
3025	Static Converter	Euroatlas
30-2510-1	Emergency Egress Light	Grimes Aerospace
30-2510-3	Emergency Egress Light	Grimes Aerospace
30-2647-1	Anti-Collision Navigation Light	Grimes Aerospace
30-2673-1	Anti-Collision Light	Grimes Aerospace
30-2675-1	Anti-Collision Light	Grimes Aerospace
30-2676-1	Anti-Collision Light	Grimes Aerospace
3027609	Wiring Harness	Hamilton Sundstrand
30-284R9	Smoke Detector	Kidde Aerospace
30-284R9B	Smoke Detector	Kidde Aerospace
302RGS1	Miniature Rate Gyro	Smiths Industries
302RGS10	Miniature Rate Gyro	Smiths Industries
302RGS11	Miniature Rate Gyro	Smiths Industries
302RGS2	Miniature Rate Gyro	Smiths Industries
302RGS3	Miniature Rate Gyro	Smiths Industries
302RGS4	Miniature Rate Gyro	Smiths Industries
302RGS5	Miniature Rate Gyro	Smiths Industries
302RGS6	Miniature Rate Gyro	Smiths Industries
302RGS7	Miniature Rate Gyro	Smiths Industries
302RGS8	Miniature Rate Gyro	Smiths Industries
302RGS9	Miniature Rate Gyro	Smiths Industries
303-0250-3	Door Position Indicating	NEC
303-0250-4	Door Position Indicating	NEC
3031690	Wiring Harness	Hamilton Sundstrand
3033509	Pulse Pick-Up Probe	Pratt & Whitney
3035681	Filter Element	Oxford Aviation
303638-01	Rotary Actuator	Lear Siegler Inc
303638-02	Rotary Actuator	Lear Siegler Inc
303638-03	Actuator	Lucas Aerospace
3038240	Propeller Brake	Pratt & Whitney
3041181	Selector Rotary Switch	ECE
3041468	Fuel Drain & Ejector Pump	Pratt & Whitney
3042000-1	Power Control Actuator	Parker
3042000-2	Power Control Actuator	Parker
3042000-3	Power Control Actuator	Parker
304313-1	Temperature Controller	Honeywell
304313-2	Temperature Controller	Honeywell
304369-020	Load Limit Controller	Simmonds Precision
304685-1	Aux Power Unit Control	Honeywell
3049261	Actuator	Consolidated Controls
30501-508	Servo Control	Goodrich Control Systems
30501-510	Servo Control	Goodrich Control Systems
30501-550	Servo Control	Goodrich Control Systems
30501-630	Servo Control	Goodrich Control Systems
30501-650	Servo Control	Goodrich Control Systems
30502-510	Servo Control	Goodrich Control Systems
30502-630	Servo Control	Goodrich Control Systems
30503-310	Servo Control	Goodrich Control Systems

Repair_Capability_List_Excel

30503-350	Servo Control	Goodrich Control Systems
30503-630	Servo Control	Goodrich Control Systems
30503-650	Servo Control	Goodrich Control Systems
30504-310	Servo Control	Goodrich Control Systems
30504-350	Servo Control	Goodrich Control Systems
30504-630	Servo Control	Goodrich Control Systems
30504-650	Servo Control	Goodrich Control Systems
30505-411	Servo Control	Goodrich Control Systems
30505-411-03	Servo Control	Goodrich Control Systems
30505-411-05	Servo Control	Goodrich Control Systems
30505-450	Servo Control	Goodrich Control Systems
30513-124	Autopilot Servomotor	Goodrich Control Systems
30513-124-3	Autopilot Servomotor	Goodrich Control Systems
30513-124-4	Autopilot Servomotor	Goodrich Control Systems
30513-125	Autopilot Servomotor	Goodrich Control Systems
30513-136	Autopilot Servomotor	Goodrich Control Systems
30514	Cargo Door Jack	Goodrich Control Systems
30514-100	Cargo Door Jack	Goodrich Control Systems
30514-101	Cargo Door Jack	Goodrich Control Systems
30514-110	Cargo Door Jack	Goodrich Control Systems
30514-111	Cargo Door Jack	Goodrich Control Systems
3052172	Selector Rotary Switch	ECE
30527-320	Servomotor Unit Lever	Goodrich Control Systems
30528-310	Servomotor Unit Lever	Goodrich Control Systems
30529-110	Servomotor Unit Lever	Goodrich Control Systems
30529-210	Servomotor Unit Lever	Goodrich Control Systems
3053230	Valve	Bendix/King
305454-11-1	Speed Switch assy	Honeywell
305454-12-1	Speed Switch assy	Honeywell
305454-13-1	Speed Switch assy	Honeywell
305454-14-1	Speed Switch assy	Honeywell
305454-15-1	Speed Switch assy	Honeywell
305562-3	DC Motor	Honeywell
305562-5	DC Motor	Honeywell
3055635-1	Fuel Drain & Ejector Pump	Pratt & Whitney
305593-2	Speed Switch	Honeywell
305593-3	Speed Switch	Honeywell
305593-4	Speed Switch	Honeywell
305593-5	Speed Switch	Honeywell
305593-6	Speed Switch	Honeywell
305593-7	Speed Switch	Honeywell
305593-8	Speed Switch	Honeywell
305608-1	Time Delay Relay	Honeywell
3056B-1	Rotary Actuator	Lucas Aerospace
3056B-2	Rotary Actuator	Lucas Aerospace
3056B-3	Rotary Actuator	Lucas Aerospace
3056B-5	Rotary Actuator	Lucas Aerospace
3059103	Accumulator	Moog Gmbh
3059103-1	Accumulator	Moog Gmbh
3059103-2	Accumulator	Moog Gmbh
3059103-7	Spherical Accumulator	Moog
305RAA1	Autothrottle Servo Motor	Smiths Industries
305TA01	Isolating Valve Block	Goodrich Control Systems
305TA02	Isolating Valve Block	Goodrich Control Systems
305TA03	Isolating Valve Block	Goodrich Control Systems
305TB01	Isolating Valve Block	Goodrich Control Systems
305TB02	Isolating Valve Block	Goodrich Control Systems
305TB03	Isolating Valve Block	Goodrich Control Systems

Repair_Capability_List_Excel

305TB04	Isolating Valve Block	Goodrich Control Systems
305TB05	Isolating Valve Block	Goodrich Control Systems
305TC01	Isolating Valve Block	Goodrich Control Systems
305TC02	Isolating Valve Block	Goodrich Control Systems
305TC0201	Isolating Valve Block	Goodrich Control Systems
305TC03	Isolating Valve Block	Goodrich Control Systems
305TD01	Isolating Valve Block	Goodrich Control Systems
305TE01	Isolating Valve Block	Goodrich Control Systems
305TF01	Isolating Valve Block	Goodrich Control Systems
3062910-1	Cylinder assy	Bendix/King
3062910-2	Cylinder assy	Bendix/King
3070378-1	Ignition Exciter	Unison Industries
3070378-2	Ignition Exciter	Unison Industries
3081-11	Ballast	Diehl
3081-21	Ballast	Diehl
3081-25	Ballast	Diehl
3081-31	Ballast	Diehl
3081-35	Ballast	Diehl
3081-41	Ballast	Diehl
3081-51	Ballast	Diehl
3081-61	Ballast	Diehl
3081-65	Ballast	Diehl
30829-100	Block assy	Goodrich Control Systems
30832-100	Inner Group Valve	Goodrich Control Systems
30832-110	Inner Group Valve	Goodrich Control Systems
30834	Valve assy	Goodrich Control Systems
30873-312	Valve assy	Air Equipement
3092	Autotransformer	Diehl
3092B	Autotransformer	Diehl
309RGS1	Miniature Rate Gyro	Smiths Industries
309RGS2	Miniature Rate Gyro	Smiths Industries
309RGS3	Miniature Rate Gyro	Smiths Industries
309RGS4	Miniature Rate Gyro	Smiths Industries
309RGS5	Miniature Rate Gyro	Smiths Industries
30B02-21G	DC Generator	Bendix/King
30B02-27A	DC Generator	Bendix/King
30B37-23	Generator	Bendix/King
30B37-23-B	Generator	Bendix/King
30B37-49	Generator	Bendix/King
30B37-49-B	Generator	Bendix/King
30B37-7	Generator	Bendix/King
30B37-7-B	Generator	Bendix/King
30E02-21G	DC Generator	Bendix
30E02-27A	DC Generator	Bendix
3100013	Temperature Transducer	Goodrich
3100051	Brake Temperature Monitor Unit	Goodrich
3100072	Temperature Transducer	Goodrich
3100130	Temperature Transducer	Goodrich
310-13569-02	Auto Transformer	OECO
31042-030	Servo Control	Goodrich Control Systems
31042-130	Servo Control	Goodrich Control Systems
31043-030	Servo Control	Goodrich Control Systems
31043-130	Servo Control	Goodrich Control Systems
31055-030	Servo Control	Goodrich Control Systems
31055-130	Servo Control	Goodrich Control Systems
31-0562	Light	Grimes Aerospace
31058-111	Actuator	Goodrich Control Systems
31058-211	Actuator	Goodrich Control Systems

Repair_Capability_List_Excel

31076-110	Outboard Spoiler Actuator	Goodrich Control Systems
31077-050	Inboard Spoiler Actuator	Goodrich Control Systems
31077-060	Inboard Spoiler Actuator	Goodrich Control Systems
31077-100	Inboard Spoiler Actuator	Goodrich Control Systems
31077-110	Inboard Spoiler Actuator	Goodrich Control Systems
31077-111	Inboard Spoiler Actuator	Goodrich Control Systems
310T1020-3	Aft Engine Mount	Boeing
310T3020-10	Forward and AFT Engine Mount	Boeing
310T3020-2	Forward and AFT Engine Mount	Boeing
310T3020-3	Forward and AFT Engine Mount	Boeing
310T3020-4	Forward and AFT Engine Mount	Boeing
310T3020-6	Forward and AFT Engine Mount	Boeing
310T3020-7	Forward and AFT Engine Mount	Boeing
310T3020-8	Forward and AFT Engine Mount	Boeing
310T4020-10	Forward and AFT Engine Mount	Boeing
310T4020-11	Forward and AFT Engine Mount	Boeing
310T4020-13	Forward and AFT Engine Mount	Boeing
310T4020-14	Forward and AFT Engine Mount	Boeing
310T4020-16	Forward and AFT Engine Mount	Boeing
310T4020-17	Forward and AFT Engine Mount	Boeing
310T4020-3	Forward and AFT Engine Mount	Boeing
310T4020-5	Forward and AFT Engine Mount	Boeing
310T4020-7	Forward and AFT Engine Mount	Boeing
310T4020-8	Forward and AFT Engine Mount	Boeing
310T4020-9	Forward and AFT Engine Mount	Boeing
310U2020-10	Aft Engine Mount	Boeing
310U2020-13	Aft Engine Mount	Boeing
310U2020-18	Aft Engine Mount	Boeing
310U2020-2	Aft Engine Mount	Boeing
310U2020-3	Aft Engine Mount	Boeing
310U2020-4	Aft Engine Mount	Boeing
310U2020-6	Aft Engine Mount	Boeing
310U2020-7	Aft Engine Mount	Boeing
310U2020-8	Aft Engine Mount	Boeing
310U4020-2	Forward and AFT Engine Mount	Boeing
310U4020-3	Forward and AFT Engine Mount	Boeing
310U4020-5	Forward and AFT Engine Mount	Boeing
310U4020-6	Forward and AFT Engine Mount	Boeing
310ZN01Y01	Unbalance Detector	ECE
31110-055	Rudder Servocontrol	Goodrich Control Systems
31110-060	Rudder Servocontrol	Goodrich Control Systems
31110-100	Rudder Servocontrol	Goodrich Control Systems
31110-120	Rudder Servocontrol	Goodrich Control Systems
31115-060	Rudder Servocontrol	Goodrich Control Systems
3-111794	Valve	Parker Hannifin
3112895-01	Filter Element	Oxford Aviation
3-114055	Valve	Parker Hannifin
311473-4	DC Electrical Solenoid Assy	Honeywell
31164-003	Generator	Lear Siegler Inc
31164-003A	Generator	Lear Siegler Inc
31164-003B	Generator	Lear Siegler Inc
31164-004	Generator	Lear Siegler Inc
31164-004B	Generator	Lear Siegler Inc
31164-005	Generator	Lear Siegler Inc
3-116515-1	Valve	Parker Hannifin
3-116515-2	Valve	Parker Hannifin
3-118605	Valve	Parker Hannifin
3120891-01	Propeller Brake	Pratt & Whitney

Repair_Capability_List_Excel

3121	Supply Unit	Diehl
3121-01	Supply Unit	Diehl
312T1310-1	Precooler Exhaust Duct Kiss Seal	Boeing
312T1310-9	Precooler Exhaust Duct Kiss Seal	Boeing
312T3216-26	Precooler Installation Components	Boeing
312T3216-28	Precooler Installation Components	Boeing
312T3216-30	Precooler Installation Components	Boeing
312T3216-32	Precooler Installation Components	Boeing
312T3216-34	Precooler Installation Components	Boeing
312T3216-36	Precooler Installation Components	Boeing
31330-3	Heat Exchanger Cooling Fan	Able Corp
31330-3G	Heat Exchanger Cooling Fan	Able Corp
313T3350-1	Strut AFT Fairing Hold Open Rod	Boeing
313T3350-10	Strut AFT Fairing Hold Open Rod	Boeing
313T3350-11	Strut AFT Fairing Hold Open Rod	Boeing
313T3350-12	Strut AFT Fairing Hold Open Rod	Boeing
313T3350-14	Strut AFT Fairing Hold Open Rod	Boeing
313T3350-19	Strut AFT Fairing Hold Open Rod	Boeing
313T3350-21	Strut AFT Fairing Hold Open Rod	Boeing
313T3350-22	Strut AFT Fairing Hold Open Rod	Boeing
313T3350-23	Strut AFT Fairing Hold Open Rod	Boeing
313T3350-3	Strut AFT Fairing Hold Open Rod	Boeing
313T3350-5	Strut AFT Fairing Hold Open Rod	Boeing
313T3350-7	Strut AFT Fairing Hold Open Rod	Boeing
313T3350-9	Strut AFT Fairing Hold Open Rod	Boeing
314195	Hydraulic Pump	Vickers
314450	Variable Displacement Hyd. Pump	Vickers
31450	Hydraulic Pump	Honeywell
315A1016-1	Strut Drum Control Box	Boeing
315A1016-2	Strut Drum Control Box	Boeing
315A1016-3	Strut Drum Control Box	Boeing
315A1016-4	Strut Drum Control Box	Boeing
315A1040-10	Engine Throttle Fuel Control Box	Boeing
315A1040-11	Engine Throttle Fuel Control Box	Boeing
315A1040-3	Engine Throttle Fuel Control Box	Boeing
315A1040-4	Engine Throttle Fuel Control Box	Boeing
315A1040-5	Engine Throttle Fuel Control Box	Boeing
315A1040-6	Engine Throttle Fuel Control Box	Boeing
315A1040-7	Engine Throttle Fuel Control Box	Boeing
315A1040-8	Engine Throttle Fuel Control Box	Boeing
315A1040-9	Engine Throttle Fuel Control Box	Boeing
315A1060-10	Fuel Shutoff	Boeing
315A1060-4	Fuel Shutoff	Boeing
315A1060-6	Fuel Shutoff	Boeing
315A1060-7	Fuel Shutoff	Boeing
315A1060-8	Fuel Shutoff	Boeing
315A1060-9	Fuel Shutoff	Boeing
315A1800-4	Thrust Reverser Non- Locking Actuator	Boeing
315A1800-5	Thrust Reverser Non- Locking Actuator	Boeing
315A1800-6	Thrust Reverser Non- Locking Actuator	Boeing
315A1800-7	Thrust Reverser Non- Locking Actuator	Boeing
315A1801-13	Thrust Reverser Locking Actuator	Boeing
315A1801-14	Thrust Reverser Locking Actuator	Boeing
315A1801-15	Thrust Reverser Locking Actuator	Boeing
315A1801-16	Thrust Reverser Actuator	Boeing
315A1801-17	Thrust Reverser Locking Actuator	Boeing
315A1801-18	Thrust Reverser Locking Actuator	Boeing
315A1801-19	Thrust Reverser Locking Actuator	Boeing

Repair_Capability_List_Excel

315A1801-20	Thrust Reverser Actuator	Boeing
315A1801-21	Thrust Reverser Locking Actuator	Boeing
315A1801-22	Thrust Reverser Locking Actuator	Boeing
315A1801-23	Thrust Reverser Locking Actuator	Boeing
315A1801-24	Thrust Reverser Actuator	Boeing
315A1801-25	Thrust Reverser Locking Actuator	Boeing
315A1801-26	Thrust Reverser Locking Actuator	Boeing
315A1801-27	Thrust Reverser Locking Actuator	Boeing
315A1801-28	Thrust Reverser Actuator	Boeing
315A1802-1	Flow Control Tee	Boeing
315A1802-2	Flow Control Tee	Boeing
315A1802-4	Flow Control Tee	Boeing
315A1803-2	Thrust Reverser Manual Drive	Boeing
315A2800-1	Thrust Reverser Non- Locking Actuator	Boeing
315A2801-1	Thrust Reverser Locking Actuator	Boeing
315N3800-1	Thrust Reverser Actuator	Boeing
315T1016-10	Thrust Reserver Strut Control Box	Boeing
315T1016-2	Thrust Reserver Strut Control Box	Boeing
315T1016-3	Thrust Reserver Strut Control Box	Boeing
315T1016-4	Thrust Reserver Strut Control Box	Boeing
315T1016-7	Thrust Reserver Strut Control Box	Boeing
315T1016-8	Thrust Reserver Strut Control Box	Boeing
315T1016-9	Thrust Reserver Strut Control Box	Boeing
315T1040-10	Engine Throttle Fuel Control Box	Boeing
315T1040-12	Engine Throttle Fuel Control Box	Boeing
315T1040-16	Engine Throttle Fuel Control Box	Boeing
315T1040-17	Engine Throttle Fuel Control Box	Boeing
315T1040-19	Engine Throttle Fuel Control Box	Boeing
315T2011-3	Thrust Reserver Strut Control Box	Boeing
315T2011-4	Thrust Reserver Strut Control Box	Boeing
315T3016-10	Strut Thrust Reserver Control Box	Boeing
315T3016-11	Strut Thrust Reserver Control Box	Boeing
315T3016-12	Strut Thrust Reserver Control Box	Boeing
315T3016-13	Strut Thrust Reserver Control Box	Boeing
315T3016-14	Strut Thrust Reserver Control Box	Boeing
315T3016-2	Strut Thrust Reserver Control Box	Boeing
315T3016-3	Strut Thrust Reserver Control Box	Boeing
315T3016-4	Strut Thrust Reserver Control Box	Boeing
315T3016-5	Strut Thrust Reserver Control Box	Boeing
315T3016-6	Strut Thrust Reserver Control Box	Boeing
315T3016-9	Strut Thrust Reserver Control Box	Boeing
315T3040-10	Fuel Control Box	Boeing
315T3040-11	Fuel Control Box	Boeing
315T3040-12	Fuel Control Box	Boeing
315T3040-13	Fuel Control Box	Boeing
315T3040-14	Fuel Control Box	Boeing
315T3040-4	Fuel Control Box	Boeing
315T3040-6	Fuel Control Box	Boeing
315T3040-7	Fuel Control Box	Boeing
315T3040-8	Fuel Control Box	Boeing
315T3040-9	Fuel Control Box	Boeing
315T3056-1	Directional Flow Valve	Boeing
315T3056-2	Directional Flow Valve	Boeing
315T3800-3	Actuator	Boeing
315T3800-4	Actuator	Boeing
315U2027-1	Cowl Opening Syst. Auxiliary Reservoir	Boeing
3160785-15	Electromagnetic Control Valve	Honeywell
3160785-30	Electromagnetic Control Valve	Honeywell

Repair_Capability_List_Excel

3160785-43	Electromagnetic Control Valve	Honeywell
3160785-52	Electromagnetic Control Valve	Honeywell
316525	Pump	Hydro-Aire
31-6551-1	Lens assy	Grimes Aerospace
31-6551-2	Lens assy	Grimes Aerospace
316841	Variable Displacement	Vickers
3170120-1	Aileron Power Control Unit	Moog
3170120-1A	Aileron Power Control Unit	Moog
3170120-2	Aileron Power Control Unit	Moog
3170120-3	Aileron Power Control Unit	Moog
3170120-4	Aileron Power Control Unit	Moog
3170120-5	Aileron Power Control Unit	Moog
3170120-6	Aileron Power Control Unit	Moog
3170120-7	Aileron Power Control Unit	Moog
3170120-8	Aileron Power Control Unit	Moog
3170130-1	Aileron Power Control Unit	Moog
3170130-2	Aileron Power Control Unit	Moog
3170130-3	Aileron Power Control Unit	Moog
3170130-4	Aileron Power Control Unit	Moog
3170130-5	Aileron Power Control Unit	Moog
3170130-6	Aileron Power Control Unit	Moog
3170130-7	Aileron Power Control Unit	Moog
3170130-8	Aileron Power Control Unit	Moog
3175887-1	Inboard Flap Actuator	Moog
3175887-1L	Inboard Flap Actuator	Moog
3180131-1	Spherical Accumulator	Moog
3180131-2	Spherical Accumulator	Moog
3180203-1	Leading Edge Slat Actuator	Moog
3181-196-901	Vacuum & Pressure Relief Valve	Fokker Aircraft
3181-233-901	Vacuum & Pressure Relief Valve	Fokker Aircraft
3185800-2	Slat Actuator	Moog
3185800-4	Slat Actuator	Moog
3185800-5	Slat Actuator	Moog
3185800-6	Slat Actuator	Moog
3185800-7	Slat Actuator	Moog
3185800-8	Slat Actuator	Moog
3187007	Outboard Flap Actuator	Moog
3187007-1	Outboard Flap Actuator	Moog
3189690-3	Actuator	Moog
319405-16	DC Solenoid Valve	Honeywell
319405-20	DC Solenoid Valve	Honeywell
3194-1	Stick Shaker	Thales Avionics
319465-6	Solenoid Valve Assy	Honeywell
319465-8	Solenoid Valve Assy	Honeywell
319525-10	Solenoid Valve	Honeywell
319525-11	Solenoid Valve	Honeywell
319525-13	Solenoid Valve	Honeywell
319525-14	Solenoid Valve	Honeywell
319525-15	Solenoid Valve	Honeywell
319525-16	Solenoid Valve	Honeywell
319525-21	Solenoid Valve	Honeywell
319525-22	Solenoid Valve	Honeywell
319525-24	Solenoid Valve	Honeywell
319525-25	Solenoid Valve	Honeywell
319525-3	Solenoid Valve	Honeywell
319525-4	Solenoid Valve	Honeywell
319525-6	Solenoid Valve	Honeywell
319525-7	Solenoid Valve	Honeywell

Repair_Capability_List_Excel

319545-8	Solenoid Valve	Goodrich Control Systems
319545-80	Solenoid Valve	Goodrich Control Systems
319545-81	Solenoid Valve	Goodrich Control Systems
319545-82	Solenoid Valve	Goodrich Control Systems
319545-83	Solenoid Valve	Goodrich Control Systems
319545-84	Solenoid Valve	Goodrich Control Systems
319545-85	Solenoid Valve	Goodrich Control Systems
319545-86	Solenoid Valve	Goodrich Control Systems
319545-87	Solenoid Valve	Goodrich Control Systems
319545-88	Solenoid Valve	Goodrich Control Systems
319545-89	Solenoid Valve	Goodrich Control Systems
319545-90	Solenoid Valve	Goodrich Control Systems
319545-91	Solenoid Valve	Goodrich Control Systems
319545-92	Solenoid Valve	Goodrich Control Systems
319545-93	Solenoid Valve	Goodrich Control Systems
319545-94	Solenoid Valve	Goodrich Control Systems
319545-95	Solenoid Valve	Goodrich Control Systems
319545-96	Solenoid Valve	Goodrich Control Systems
31960	Pressure Gage	Ranco
319625-1	Solenoid Valve	Honeywell
319625-5	Solenoid Valve	Honeywell
319675-12	DC Solenoid Valve	Honeywell
319675-17	DC Solenoid Valve	Honeywell
319675-56	DC Solenoid Valve	Honeywell
319675-9	DC Solenoid Valve	Honeywell
3197850-1	Leading Edge Slat Actuator	Moog
3197850-3	Leading Edge Slat Actuator	Moog
3199634A	Sensor	Goodrich
3199680	Brake Temperature Monitor Unit	Goodrich
3199949	Brake Temperature Monitor Unit	Goodrich
319995-1	Solenoid Valve Assy	Honeywell
3199958	Temperature Transducer	Goodrich
320115	Valve assy	Meggitt Avionics
320115-1	Solenoid Valve Assy	Honeywell
320115-10	Solenoid Valve Assy	Honeywell
320115-11	Solenoid Valve	Honeywell
320115-12	Solenoid Valve	Honeywell
320115-13	Solenoid Valve Assy	Honeywell
320115-14	Solenoid Valve	Honeywell
320115-15	Solenoid Valve Assy	Honeywell
320115-16	Solenoid Valve Assy	Honeywell
320115-17	Solenoid Valve Assy	Honeywell
320115-2	Solenoid Valve Assy	Honeywell
320115-3	Solenoid Valve Assy	Honeywell
320115-4	Solenoid Valve Assy	Honeywell
320115-5	Solenoid Valve Assy	Honeywell
320115-6	Solenoid Valve Assy	Honeywell
320115-7	Solenoid Valve Assy	Honeywell
320115-8	Solenoid Valve Assy	Honeywell
320115-9	Solenoid Valve Assy	Honeywell
32017-12	Torque Press Gage	Ranco
3202096-2	Check Valve	Honeywell
3202122-1	Check Valve	Honeywell
3202130-1	Check Valve	Honeywell
3202130-2	Check Valve	Honeywell
3202130-3	Check Valve	Honeywell
3202142-1	Check Valve	Honeywell
3202142-2	Check Valve	Honeywell

Repair_Capability_List_Excel

3202154-1	Check Valve	Honeywell
3202164-1	Check Valve	Honeywell
3202164-2	Check Valve	Honeywell
3202164-3	Check Valve	Honeywell
3202164-4	Check Valve	Honeywell
3202176-1	Check Valve	Honeywell
3202176-2	Check Valve	Honeywell
3202176-3	Check Valve	Honeywell
3202200-1	LP Bleed Check Valve	Honeywell
3202222-1	Check Valve	Honeywell
3202250-1	Check Valve	Honeywell
3202250-2	Check Valve	Honeywell
3202250-3	Check Valve	Honeywell
3202250-4	Check Valve	Honeywell
3202258-2	Check Valve	Honeywell
3202442-2	Trim Air Check Valve	Honeywell
3202444-1	Trim Air Check Valve	Honeywell
3202446-1	Cont Air Check Valve	Honeywell
3202468-1	Check Valve	Honeywell
3202544-2	Check Valve	Honeywell
3202544-3	Check Valve	Honeywell
3202544-4	Check Valve	Honeywell
3202544-5	Check Valve	Honeywell
3202598-1	Low Press Check Valve	Honeywell
32-0260-4	AC Actuator	Honeywell
32-0260-5	AC Actuator	Honeywell
3202726-1	Check Zone Trim Valve	Honeywell
3202804-1	Pressure Check Valve	Honeywell
320281-1	Solenoid Valve Assy	Honeywell
320281-2	Solenoid Valve Assy	Honeywell
320281-3	Solenoid Valve Assy	Honeywell
320281-4	Solenoid Valve Assy	Honeywell
320362-2-1	Solenoid Shut-Off Valve	Honeywell
320362-3-1	Solenoid Shut-Off Valve	Honeywell
320362-4-1	Solenoid Shut-Off Valve	Honeywell
320490-1	Water Separator Control Valve	Honeywell
3204908-5	Override Valve	Honeywell
3204958-1	Shut-Off Valve	Honeywell
320499-3	Solenoid Valve	Honeywell
320499-4	Solenoid Valve	Honeywell
3204994-1	Isolation Valve	Honeywell
3204994-2	Isolation Valve	Honeywell
320499-5	Solenoid Valve	Honeywell
320499-6	Solenoid Valve	Honeywell
320499-7	Solenoid Valve	Honeywell
320501-2	Solenoid Valve	Honeywell
320501-3	Solenoid Valve	Honeywell
320501-4	Solenoid Valve	Honeywell
320501-5	Solenoid Valve	Honeywell
320501-7	Solenoid Valve	Honeywell
320501-9	Solenoid Valve	Honeywell
320522-11	Solenoid Valve	Honeywell
320522-13	Solenoid Valve	Honeywell
320522-14	Solenoid Valve	Honeywell
320522-15	Solenoid Valve	Honeywell
320522-5	Solenoid Valve	Honeywell
320522-6	Solenoid Valve	Honeywell
320522-7	Solenoid Valve	Honeywell

Repair_Capability_List_Excel

320548-1	Solenoid Valve	Honeywell
320548-2	Solenoid Valve	Honeywell
320995-1	Air Shut-Off Valve	Meggitt
320995-2	Air Shut-Off Valve	Meggitt
320995-3	Air Shut-Off Valve	Meggitt
320995-4	Air Shut-Off Valve	Meggitt
321000M02	Side Stick Transducer Unit	Sarma
321000M03	Side Stick Transducer Unit	Sarma
321000M03 Amdt A	Side Stick Transducer Unit	Sarma
321000M03 Amdt C	Side Stick Transducer Unit	Sarma
321000M03 Amdt D	Side Stick Transducer Unit	Sarma
321000M03 Amdt E	Side Stick Transducer Unit	Sarma
321200M02	Transducer Unit	Sarma
321300M02	Transducer Unit	Sarma
3213754-1	Pressure Regulator	Honeywell
3213754-2	Pressure Regulator	Honeywell
3213868-3	Shut-Off Valve	Honeywell
3213868-4	Shut-Off Valve	Honeywell
3213944-1-1	Modulating Valve	Honeywell
321400M01	Throttle Control Unit	Sarma
321404-1-1	Shut-Off Valve	Honeywell
3214102-4	Pressure Regulator	Honeywell
3214-20	Emergency Power Supply Unit	Diehl
3214230-2	Regulator Shut-Off Valve	Honeywell
3214230-3	Regulator Shut-Off Valve	Honeywell
3214230-4	Regulator Shut-Off Valve	Honeywell
3214-30	Emergency Power Supply Unit	Diehl
3214304-1	Modulating Valve	Honeywell
3214304-2	Modulating Valve	Honeywell
3214304-4	Modulating Valve	Honeywell
3214306-1	Pressure Regulator Valve	Honeywell
3214306-4	Pressure Regulator Valve	Honeywell
3214306-5	Pressure Regulator Valve	Honeywell
3214306-6	Pressure Regulator Valve	Honeywell
3214306-7	Pressure Regulator Valve	Honeywell
3214306-8	Pressure Regulator Valve	Honeywell
3214306-9	Pressure Regulator Valve	Honeywell
3214330-2	Regulator Shut-Off Valve	Honeywell
3214330-3	Regulator Shut-Off Valve	Honeywell
3214330-4	Regulator Shut-Off Valve	Honeywell
3214330-5	Regulator Shut-Off Valve	Honeywell
3214330-6	Regulator Shut-Off Valve	Honeywell
3214334-1	Shut-Off Valve	Honeywell
3214334-2	Shut-Off Valve	Honeywell
3214334-3	Shut-Off Valve	Honeywell
3214336-1	Modulating Valve	Honeywell
3214336-2	Modulating Valve	Honeywell
3214336-3	Modulating Valve	Honeywell
3214-40	Emergency Power Supply Unit	Diehl
3214414-3	Pressure Reg. & Shut-Off Valve	Honeywell
3214414-4	Pressure Reg. & Shut-Off Valve	Honeywell
3214446-1	Valve assy	Honeywell
3214446-2	Valve assy	Honeywell
3214446-3	Valve assy	Honeywell
3214446-4	Valve assy	Honeywell
3214-52	Emergency Power Supply Unit	Diehl
3214-54	Emergency Power Supply Unit	Diehl
3214-54-10	Emergency Power Supply Unit	Diehl

Repair_Capability_List_Excel

3214552-1	Shut-Off Valve	Honeywell
3214552-2	Shut-Off Valve	Honeywell
3214552-3	Shut-Off Valve	Honeywell
3214552-4	Shut-Off Valve	Honeywell
3214552-5	Shut-Off Valve	Honeywell
321460-1-1	Mixing Valve	Honeywell
3214608-1	Trim Air Valve	Honeywell
3214612-1	Shut-Off Valve	Honeywell
3214612-3	Shut-Off Valve	Honeywell
3214-62	Emergency Power Supply Unit	Diehl
321464-2-1	Shut-Off Valve	Honeywell
321464-5-1	Shut-Off Valve	Honeywell
3214684-1	Reg. & Shut-Off Valve	Honeywell
3214684-2	Reg. & Shut-Off Valve	Honeywell
3214862-1	Pressure Regulator Valve	Honeywell
3214888-1	Pressure Regulator	Honeywell
3214888-2	Pressure Regulator	Honeywell
3214-90	Autonomous Stand-by Supply	Diehl
3214-91	Autonomous Stand-by Supply	Diehl
3214958-2	HP Air Bleed Valve	Honeywell
3214960-2	Pack Flow Control Valve	Honeywell
3214960-3	Pack Flow Control Valve	Honeywell
3214962-1	Trim Air Press Reg Valve	Honeywell
3214972-1	Regulator Shut-Off Valve	Honeywell
3215268-2	Regulating & Shut-Off Valve	Honeywell
3215268-3	Regulating & Shut-Off Valve	Honeywell
3215358-1	Starter Shut-Off Valve	Honeywell
3215358-2	Starter Shut-Off Valve	Honeywell
3215618-2	Nose Cowl Anti- Ice Valve	Honeywell
3215618-3	Nose Cowl Anti- Ice Valve	Honeywell
3215618-4	Nose Cowl Anti- Ice Valve	Honeywell
3215886-1	Air Control Valve	Honeywell
321674-3-1	Electric Shut-Off Valve	Honeywell
321674-4-1	Electric Shut-Off Valve	Honeywell
3217-100	Solenoid Valve	Intertechnique
3217-200	Solenoid Valve	Intertechnique
321812-2-1	Shut-Off Valve	Honeywell
321846-1-1	Shut-Off Valve	Honeywell
321858-3-1	Temp. Control Valve	Honeywell
321862-1-1	Shut-Off Valve	Honeywell
321892-1	Modulating & Shut-Off Valve	Honeywell
321892-1-1	Modulating & Shut-Off Valve	Honeywell
321916-1-1	Shut-Off Butterfly Valve	Honeywell
321942-1	Shut-Off Butterfly Valve	Honeywell
321942-1-1	Shut-Off Butterfly Valve	Honeywell
322000M01	Transducer Unit	Sarma
322000M02	Transducer Unit	Sarma
322300	Transducer Unit	Sarma
3224-11	Foot Warmer	Diehl
3224-50	Foot Warmer	Diehl
3225006-1	Precooler Control Valve	Honeywell
32-2684-003	Shut-Off Valve	Grimes Aerospace
32-2684-004	Shut-Off Valve	Grimes Aerospace
32-2684-007	Shut-Off Valve	Grimes Aerospace
32-2861-001	Valve assy	Grimes Aerospace
32-2963-010	Anti-Ice Valve	Grimes Aerospace
3229980-5	Ball Bearing Screw & Nut	Honeywell
3229980-6	Ball Bearing Screw & Nut	Honeywell

Repair_Capability_List_Excel

3229980-7	Ball Bearing Screw & Nut	Honeywell
3229980-8	Ball Bearing Screw & Nut	Honeywell
32-3110-001	Shut-Off Valve	Grimes Aerospace
32-3110-002	Shut-Off Valve	Grimes Aerospace
32-3110-003	Shut-Off Valve	Grimes Aerospace
32-3110-004	Shut-Off Valve	Grimes Aerospace
32-3110-005	Shut-Off Valve	Grimes Aerospace
32-3110-006	Shut-Off Valve	Grimes Aerospace
323636	Hydraulic Motor Pump	Vickers
324-02806	Fire Control Unit	Liebherr Aerospace
324-02808	Fire Control Unit	Liebherr Aerospace
324-02810	Fire Control Unit	Liebherr Aerospace
324195-1	Anti-ice Valve	Rohr
3250-20	Ballast Unit	Diehl
3250-30	Ballast Unit	Diehl
3250-60	Ballast Unit	Diehl
3250-70	Ballast Unit	Diehl
3250-80	Ballast Unit	Diehl
325365-4	Valve Actuator	Whittaker
325365-5	Valve Actuator	Whittaker
325ZN01ZUW	Detector	ECE
3269086-11	Feedback Actuator	Honeywell
3269086-12	Feedback Actuator	Honeywell
3269086-13	Feedback Actuator	Honeywell
3269086-14	Feedback Actuator	Honeywell
3269086-21	Feedback Actuator	Honeywell
3269086-22	Feedback Actuator	Honeywell
3269086-23	Feedback Actuator	Honeywell
3269086-24	Feedback Actuator	Honeywell
3269086-25	Feedback Actuator	Honeywell
3269086-26	Feedback Actuator	Honeywell
3269086-27	Feedback Actuator	Honeywell
3269086-28	Feedback Actuator	Honeywell
3269086-29	Feedback Actuator	Honeywell
3269086-30	Feedback Actuator	Honeywell
3269086-31	Feedback Actuator	Honeywell
3269086-32	Feedback Actuator	Honeywell
3269086-33	Feedback Actuator	Honeywell
3269086-34	Feedback Actuator	Honeywell
3269086-5	Feedback Actuator	Honeywell
3269086-6	Feedback Actuator	Honeywell
3269086-7	Feedback Actuator	Honeywell
3269086-8	Feedback Actuator	Honeywell
3269264-1	Feedback Actuator	Honeywell
3269264-10	Feedback Actuator	Honeywell
3269264-19	Feedback Actuator	Honeywell
3269264-2	Feedback Actuator	Honeywell
3269264-20	Feedback Actuator	Honeywell
3269264-21	Feedback Actuator	Honeywell
3269264-22	Feedback Actuator	Honeywell
3269264-23	Feedback Actuator	Honeywell
3269264-24	Feedback Actuator	Honeywell
3269264-25	Feedback Actuator	Honeywell
3269264-26	Feedback Actuator	Honeywell
3269264-27	Feedback Actuator	Honeywell
3269264-28	Feedback Actuator	Honeywell
3269264-29	Feedback Actuator	Honeywell
3269264-3	Feedback Actuator	Honeywell

Repair_Capability_List_Excel

3269264-30	Feedback Actuator	Honeywell
3269264-4	Feedback Actuator	Honeywell
3269264-7	Feedback Actuator	Honeywell
3269264-8	Feedback Actuator	Honeywell
3269264-9	Feedback Actuator	Honeywell
3270-000	Rain Repellent Solenoid Valve	Intertechnique
3270514-1	Pneumatic Drive Unit	Honeywell
3270514-2	Pneumatic Drive Unit	Honeywell
3270514-3	Pneumatic Drive Unit	Honeywell
327155-1	Anti-ice Valve	Rohr
327155-2	Anti-ice Valve	Rohr
327155-3	Anti-ice Valve	Rohr
3272546-3	Locking Gearbox	Honeywell
3272546-5	Locking Gearbox	Honeywell
3272546-6	Locking Gearbox	Honeywell
3272546-7	Locking Gearbox	Honeywell
3272546-8	Locking Gearbox	Honeywell
3272546-9	Locking Gearbox	Honeywell
3272558-2	Slave Ballscrew Actuator	Honeywell
3272560-2	Ball Screw Actuator	Honeywell
3272560-3	Ball Screw Actuator	Honeywell
3272560-4	Ball Screw Actuator	Honeywell
3272560-5	Ball Screw Actuator	Honeywell
3272626-1	Locking Gearbox	Honeywell
3272626-2	Locking Gearbox	Honeywell
327400-1001	Inboard Elevator Actuator	Parker Aerospace
327400-1003	Inboard Elevator Actuator	Parker Aerospace
327400-1005	Inboard Elevator Actuator	Parker Aerospace
327400-1007	Inboard Elevator Actuator	Parker Aerospace
327400-1009	Inboard Elevator Actuator	Parker Aerospace
327400-9001	Inboard Elevator Actuator	Parker Aerospace
327400-9003	Inboard Elevator Actuator	Parker Aerospace
327400-9005	Inboard Elevator Actuator	Parker Aerospace
327400-9007	Inboard Elevator Actuator	Parker Aerospace
3282556-1	Bleed Valve Stop Mechanism	Honeywell
3282556-2	Bleed Valve Stop Mechanism	Honeywell
3282948-3	Feedback Mechanism	Honeywell
3282948-4	Feedback Mechanism	Honeywell
3282948-5	Feedback Mechanism	Honeywell
3282948-6	Feedback Mechanism	Honeywell
3282970-2	Bleed Valve Stop Mechanism	Honeywell
3282970-3	Bleed Valve Stop Mechanism	Honeywell
3282970-4	Bleed Valve Stop Mechanism	Honeywell
3282982-1	Linear Hydraulic Actuator	Honeywell
3282982-2	Linear Hydraulic Actuator	Honeywell
3282982-3	Linear Hydraulic Actuator	Honeywell
3283086-1	Fan Reverser Lock Brake	Honeywell
3283086-3	Fan Reverser Lock Brake	Honeywell
3283086-30	Fan Reverser Lock Brake	Honeywell
3283086-32	Fan Reverser Lock Brake	Honeywell
3283096-2	Starter Control Valve	Honeywell
3284-11	Aut.Fire Extinghisher Control Unit	Diehl
3284-12	Aut.Fire Extinghisher Control Unit	Diehl
3284-13	Aut.Fire Extinghisher Control Unit	Diehl
3284-14	Aut.Fire Extinghisher Control Unit	Diehl
328759	Hydraulic Motorpump	Vickers
328833	Electric Motor	Vickers
3289526-1	Valve assy	Honeywell

Repair_Capability_List_Excel

3289562-1	Precooler Control Valve	Honeywell
3289562-2	Precooler Control Valve	Honeywell
3289562-3	Precooler Control Valve	Honeywell
3289562-4	Precooler Control Valve	Honeywell
3289562-5	Precooler Control Valve	Honeywell
3289614-1	Shut-Off Valve	Honeywell
3289614-2	Shut-Off Valve	Honeywell
3289614-3	Shut-Off Valve	Honeywell
3289630-1	Starter Valve	Honeywell
3289630-2	Starter Valve	Honeywell
3289630-3	Starter Valve	Honeywell
3289696-1	Low Limit Control Valve	Honeywell
3289704-1	Shut-Off Valve assy	Honeywell
3289834-1	Anti-Ice Shut-Off Valvey	Honeywell
3289834-4	Anti-Ice Shut-Off Valvey	Honeywell
3289898-1	Temperature Control Valve	Honeywell
3289898-3	Temperature Control Valve	Honeywell
3289902-1	Overpressure Shut-Off Valve	Honeywell
3289902-2	Overpressure Shut-Off Valve	Honeywell
3289902-3	Overpressure Shut-Off Valve	Honeywell
3290050-1	Surge Control Valve	Honeywell
3290050-2	Surge Control Valve	Honeywell
3290050-3	Surge Control Valve	Honeywell
3290050-4	Surge Control Valve	Honeywell
3290052-1	Shut-Off Valve	Honeywell
3290052-2	Load Control Valve	Honeywell
3290052-3	Load Control Valve	Honeywell
3290054-1	Butterfly Valve	Honeywell
3290064-10	Valve assy	Honeywell
3290064-13	Valve assy	Honeywell
3290064-17	Starter Valve	Honeywell
3290064-18	Starter Valve	Honeywell
3290064-19	Starter Valve	Honeywell
3290064-2	Valve assy	Honeywell
3290064-3	Valve assy	Honeywell
3290104-1	Hot By-Pass Valve	Honeywell
3290276-2	Anti-Ice Valve	Honeywell
3290280-3	Pressure Regulator Valve	Honeywell
3290402-1-1	Valve assy	Honeywell
3290406-2	Surge Control Valve	Honeywell
3290476-3	Surge Control Valve	Honeywell
3290476-4	Surge Control Valve	Honeywell
3290476-5	Surge Control Valve	Honeywell
3290662-1	Nose Cowl Therma Anti- Ice Valve	Honeywell
3290694-2	Pneumatic Butterfly Valve	Honeywell
3290694-3	Pneumatic Butterfly Valve	Honeywell
329096-1	Xfeed Air Bleed Valve	Honeywell
329096-2	Xfeed Air Bleed Valve	Honeywell
3290976-2	Starter Valve	Honeywell
3291172-1	Pneumatic Butterfly Shut-Off Valve	Honeywell
3291172-2	Pneumatic Butterfly Shut-Off Valve	Honeywell
3291172-3	Pneumatic Butterfly Shut-Off Valve	Honeywell
3291214-2	APU Bleed Valve	Honeywell
3291238-1	Surge Control Valve	Honeywell
3291238-2	Surge Control Valve	Honeywell
3291466-1	Surge Control Valve	Honeywell
3291466-2	Surge Control Valve	Honeywell
3291556-1	Starter Control Valve	Honeywell

Repair_Capability_List_Excel

3291676-2	Starter Air Valve	Honeywell
3294-10-1	Cargo Compartment Light	Diehl
3294-10-2	Cargo Compartment Light	Diehl
3294-20-1	Cargo Compartment Light	Diehl
329445-210	Solenoid Valve	Goodrich Control Systems
329445-210C	Solenoid Valve	Goodrich Control Systems
32-96-5	External Mechanical Call Light	Labinal
3299	Toilet Timer	Monogram
3299-1	Toilet Timer	Monogram
3299-11	Toilet Timer	Monogram
3299-1-1	Toilet Timer	Monogram
3299-23	Toilet Timer	Monogram
3299-3	Toilet Timer	Monogram
32D37-1	Pressure Switch	Custom Control Sensors
32E14-1	Oil Cooler/Heat Exchanger	Honeywell
32E14-2	Oil Cooler/Heat Exchanger	Honeywell
32EN14-4	Switch	Honeywell
32M2	Transmitter	Precilec
33-019	Landing Manifold	Hydro-Aire
33-019-1	Landing Manifold	Hydro-Aire
33-019G	Landing Manifold	Hydro-Aire
33-021	Take-Off Manifold	Hydro-Aire
33-021E	Take-Off Manifold	Hydro-Aire
330400M00	Throttle Control Unit	Sarma
330400M01	Throttle Control Unit	Sarma
33-065-1	Anti-Skid Valve	Hydro-Aire
33-065-2	Anti-Skid Valve	Hydro-Aire
33-067-1	Anti-Skid Valve	Hydro-Aire
33-067-2	Anti-Skid Valve	Hydro-Aire
330RU01B01E02	Three Pole Contactor	ECE
330TS08Y	Eng/APU Fire Panel	ECE
330VZ01Y01	Push Button Switch	ECE
330VZ01Y02	Push Button Switch	ECE
3311586	Accumulator	Bendix
3311586-1	Accumulator	Bendix
3311586A	Accumulator	Bendix
3311586C	Accumulator	Bendix
33135	Manometer	Badin-Crouzet
33135-01	Manometer	Thales Avionics
33135-02	Manometer	Thales Avionics
33135-3	Manometer	Thales Avionics
33140-02	Rate of Climb Indicator	Thales Avionics
33140-3	Rate of Climb Indicator	Thales Avionics
331P-1/IV	Direction Gyro Indicator	Rockwell-Collins
33200	Thermometer	Edison
33201	Thermometer	Edison
33202	Thermometer	Edison
33203	Thermometer	Edison
33204	Thermometer	Edison
33205	Thermometer	Edison
3320500	Spoiler Package Control	Moog
3320500-1	Spoiler Package Control	Moog
3320500-2	Spoiler Package Control	Moog
3320500-3	Spoiler Package Control	Moog
33206	Thermometer	Edison
3320600	Spoiler Actuator	Moog
3320600-1	Spoiler Actuator	Moog
3320600-2	Spoiler Actuator	Moog

Repair_Capability_List_Excel

3320650-1	Inboard SP Flight Spoiler Actuator	Honeywell
3320650-2	Inboard SP Flight Spoiler Actuator	Honeywell
3320650-3	Inboard SP Flight Spoiler Actuator	Honeywell
3320690	Ground Spoiler Actuator	Moog
3320690-1	Ground Spoiler Actuator	Moog
33207	Thermometer	Edison
3320720-3	Spoiler Power Control Pack	Moog
3320720-4	Spoiler Power Control Pack	Moog
3320720-5	Spoiler Power Control Pack	Moog
3320720-6	Spoiler Power Control Pack	Moog
3320731-3	Ground Spoiler Actuator	Moog
3320731-4	Ground Spoiler Actuator	Moog
3320740-10	Spoiler Power Control Pack	Moog
3320740-11	Spoiler Power Control Pack	Moog
3320740-12	Spoiler Power Control Pack	Moog
3320740-6	Spoiler Power Control Pack	Moog
3320740-60	Spoiler Power Control Pack	Moog
3320740-7	Spoiler Power Control Pack	Moog
3320740-8	Spoiler Power Control Pack	Moog
3320740-8A	Spoiler Power Control Pack	Moog
3320740-8B	Spoiler Power Control Pack	Moog
3320740-9	Spoiler Power Control Pack	Moog
3320770-2	Ground Spoiler Actuator	Moog
3320770-3	Ground Spoiler Actuator	Moog
3320770-4	Ground Spoiler Actuator	Moog
3320770-5	Ground Spoiler Actuator	Moog
33208	Thermometer	Edison
3321480-10	Spoiler Power Control Unit	Moog
3321480-10A	Spoiler Power Control Unit	Moog
3321480-11	Spoiler Power Control Unit	Moog
3321480-11A	Spoiler Power Control Unit	Moog
3321480-12	Spoiler Power Control Unit	Moog
3321480-12A	Spoiler Power Control Unit	Moog
3321480-13	Spoiler Power Control Unit	Moog
3321480-14	Spoiler Power Control Unit	Moog
3321480-15	Spoiler Power Control Unit	Moog
3321480-16	Spoiler Power Control Unit	Moog
3321480-4	Spoiler Power Control Unit	Moog
3321480-4A	Spoiler Power Control Unit	Moog
3321480-5	Spoiler Power Control Unit	Moog
3321480-5A	Spoiler Power Control Unit	Moog
3321480-6	Spoiler Power Control Unit	Moog
3321480-6A	Spoiler Power Control Unit	Moog
3321480-7	Spoiler Power Control Unit	Moog
3321480-7A	Spoiler Power Control Unit	Moog
3321480-8	Spoiler Power Control Unit	Moog
3321480-8A	Spoiler Power Control Unit	Moog
3321480-9	Spoiler Power Control Unit	Moog
3321480-9A	Spoiler Power Control Unit	Moog
3321500-10	Spoiler Power Control Unit	Moog
3321500-10A	Spoiler Power Control Unit	Moog
3321500-11	Spoiler Power Control Unit	Moog
3321500-11A	Spoiler Power Control Unit	Moog
3321500-12	Spoiler Power Control Unit	Moog
3321500-13	Spoiler Power Control Unit	Moog
3321500-14	Spoiler Power Control Unit	Moog
3321500-15	Spoiler Power Control Unit	Moog
3321500-16	Spoiler Power Control Unit	Moog

Repair_Capability_List_Excel

3321500-3	Spoiler Power Control Unit	Moog
3321500-3A	Spoiler Power Control Unit	Moog
3321500-4	Spoiler Power Control Unit	Moog
3321500-4A	Spoiler Power Control Unit	Moog
3321500-5	Spoiler Power Control Unit	Moog
3321500-5A	Spoiler Power Control Unit	Moog
3321500-6	Spoiler Power Control Unit	Moog
3321500-6A	Spoiler Power Control Unit	Moog
3321500-7	Spoiler Power Control Unit	Moog
3321500-7A	Spoiler Power Control Unit	Moog
3321500-8	Spoiler Power Control Unit	Moog
3321500-8A	Spoiler Power Control Unit	Moog
3321500-9	Spoiler Power Control Unit	Moog
3321500-9A	Spoiler Power Control Unit	Moog
3321520-4	Rudder Power Control Unit	Moog
3321520-5	Rudder Power Control Unit	Moog
3321520-6	Rudder Power Control Unit	Moog
3321520-7	Rudder Power Control Unit	Moog
3321520-8	Rudder Power Control Unit	Moog
3321520-9	Rudder Power Control Unit	Moog
3321530-10	Elevator Power Control Unit	Moog
3321530-11	Elevator Power Control Unit	Moog
3321530-12	Elevator Power Control Unit	Moog
3321530-7	Elevator Power Control Unit	Moog
3321530-8	Elevator Power Control Unit	Moog
3321530-9	Elevator Power Control Unit	Moog
33223	Thermometer	Edison
332797	Pump	Vickers
332A2341-1	Precooler Installation Components	Boeing
33349	Thermometer	Edison
33350	Thermometer	Edison
3337457-15	Inboard Aileron Servo Control	Moog Inc
3337457-18	Inboard Aileron Servocontrol	Moog Inc
3337457-19	Inboard Aileron Servocontrol	Moog Inc
3337457-22	Inboard Aileron Servocontrol	Moog Inc
3337457-23	Inboard Aileron Servocontrol	Moog Inc
3337457-27	Inboard Aileron Servocontrol	Moog Inc
3337457-30	Inboard Aileron Servocontrol	Moog Inc
3337457-31	Inboard Aileron Servocontrol	Moog Inc
3337457-35	Inboard Aileron Servocontrol	Moog Inc
3337457-36	Inboard Aileron Servocontrol	Moog Inc
3337457-37	Inboard Aileron Servocontrol	Moog Inc
3337457-38	Inboard Aileron Servocontrol	Moog Inc
3337457-39	Inboard Aileron Servocontrol	Moog Inc
3337457-59	Inboard Aileron Servocontrol	Moog Inc
3337457-60	Inboard Aileron Servocontrol	Moog Inc
3337458-18	Outboard Aileron Servocontrol	Moog Inc
3337458-19	Outboard Aileron Servocontrol	Moog Inc
3337458-22	Outboard Aileron Servocontrol	Moog Inc
3337458-23	Outboard Aileron Servocontrol	Moog Inc
3337458-27	Outboard Aileron Servocontrol	Moog Inc
3337458-30	Outboard Aileron Servocontrol	Moog Inc
3337458-31	Outboard Aileron Servocontrol	Moog Inc
3337458-35	Outboard Aileron Servocontrol	Moog Inc
3337458-36	Outboard Aileron Servocontrol	Moog Inc
3337458-37	Outboard Aileron Servocontrol	Moog Inc
3337458-38	Outboard Aileron Servocontrol	Moog Inc
3337458-59	Outboard Aileron Servocontrol	Moog Inc

Repair_Capability_List_Excel

3337458-60	Outboard Aileron Servocontrol	Moog Inc
3338660-3	Pressure Relief % Override Valve	Moog
3338660-4	Pressure Relief % Override Valve	Moog
33400	Thermometer	Edison
33724	Thermometer	Edison
338100-5001	Outboard Aileron Actuator	Parker Hannifin
338100-5003	Outboard Aileron Actuator	Parker Hannifin
338100-5005	Outboard Aileron Actuator	Parker Hannifin
338100-5007	Outboard Aileron Actuator	Parker Hannifin
338100-5009	Outboard Aileron Actuator	Parker Hannifin
338100-5011	Outboard Aileron Actuator	Parker Hannifin
3-39274	Valve	Parker Hannifin
3399046-1	Valve assy	Honeywell
3399046-2	Valve assy	Honeywell
34000	Engine Gauge Unit	Edison
340-001	Autobrake Selector Switch	Madelec Aero
340545	Valve assy	Whittaker
340RT01ZUV150MA	Time Delay Relay	ECE
341400M01	Rud Travel Limiter Unit	Sarma
341400M02	Rud Travel Limiter Unit	Sarma
341525	Rotary Shut-Off Valve	Whittaker
341B010000	Solenoid Thermostat	Liebherr Aerospace
341B020000	Solenoid Thermostat	Liebherr Aerospace
341B020000 Amdt A	Solenoid Thermostat	Liebherr Aerospace
341D010000	Solenoid Thermostat	Liebherr Aerospace
341E010000	Solenoid Thermostat	Liebherr Aerospace
341E020000	Solenoid Thermostat	Liebherr Aerospace
341E030000	Solenoid Thermostat	Liebherr Aerospace
34200	Engine Gauge Unit	Edison
342300M00	Transducer Unit	Sarma
342300M00 Amdt A	Transducer Unit	Sarma
342300M01	Transducer Unit	Sarma
342381	Hydraulic Motor	Eaton Aerospace
342B010000	Control Thermostat	Liebherr Aerospace
342B020000	Control Thermostat	Liebherr Aerospace
342B030000	Control Thermostat	Liebherr Aerospace
342D010000	Control Thermostat	Liebherr Aerospace
342D020000	Control Thermostat	Liebherr Aerospace
342D030000	Control Thermostat	Liebherr Aerospace
34343500M00	Limiter	Sarma
34343500M00 Amdt A	Limiter	Sarma
343500M00	Rud Travel Limiter Unit	Sarma
343500M00 Amdt A	Rud Travel Limiter Unit	Sarma
34400	Engine Gauge Unit	Edison
3-459-301	Valve	Parker Hannifin
34620-2	Actuator	Weston Aerospace
34620-3	Actuator	Weston Aerospace
34620-4	Actuator	Weston Aerospace
34620-5	Actuator	Weston Aerospace
34722	Fan	.
34800A200-2	Filter Air Recirculation	Le Bozec
34800A200-3 Amdt B	Filter Air Recirculation	Le Bozec
34800A200-4	Filter Air Recirculation	Le Bozec
34800B200-1	Filter Air Recirculation	Le Bozec
348AC12	Sensor Halder	Weshand Aerospace
34964	Cooling Fan	EG&G Rotron
34970	Thermometer	Edison
34A1-111	Fan	Airscrew Howden

Repair_Capability_List_Excel

35.840.1001	Static Inverter	Thales Avionics
35008-2	Control Unit	Fenwal
3505010-11-1	Engine Starter	Honeywell
3505010-13-1	Engine Starter	Honeywell
3505010-5-1	Engine Starter	Honeywell
3505010-8-1	Engine Starter	Honeywell
3505010-9-1	Engine Starter	Honeywell
3505228-1-1	Engine Starter	Honeywell
3505230-1-1	Engine Starter	Honeywell
3505436-2-1	Engine Starter	Honeywell
3505436-4-1	Engine Starter	Honeywell
3505436-6-1	Engine Starter	Honeywell
3505436-7	Engine Starter	Honeywell
3505448-3-1	Engine Starter	Honeywell
3505448-5-1	Engine Starter	Honeywell
3505466-4	Hydraulic Pump	Honeywell
3505466-5	Hydraulic Pump	Honeywell
3505466-6	Hydraulic Pump	Honeywell
3505466-7	Hydraulic Pump	Honeywell
3505468-4	Engine Starter	Honeywell
3505526-1-1	Engine Starter	Honeywell
3505526-3-1	Engine Starter	Honeywell
3505526-4-1	Engine Starter	Honeywell
3505526-5-1	Engine Starter	Honeywell
3505526-6-1	Engine Starter	Honeywell
3505526-7-1	Engine Starter	Honeywell
3505526-8-1	Engine Starter	Honeywell
3505526-9-1	Engine Starter	Honeywell
3505582-1	Engine Starter	Honeywell
3505582-12	Engine Starter	Honeywell
3505582-14	Engine Starter	Honeywell
3505582-15	Engine Starter	Honeywell
3505582-2	Engine Starter	Honeywell
3505582-22	Engine Starter	Honeywell
3505582-23	Engine Starter	Honeywell
3505582-24	Engine Starter	Honeywell
3505582-25	Engine Starter	Honeywell
3505582-26	Engine Starter	Honeywell
3505582-27	Engine Starter	Honeywell
3505582-3	Engine Starter	Honeywell
3505582-4	Engine Starter	Honeywell
3505582-40	Engine Starter	Honeywell
3505582-41	Engine Starter	Honeywell
3505582-42	Engine Starter	Honeywell
3505582-43	Engine Starter	Honeywell
3505582-44	Engine Starter	Honeywell
3505582-45	Engine Starter	Honeywell
3505582-60	Engine Starter	Honeywell
3505582-61	Engine Starter	Honeywell
3505582-62	Engine Starter	Honeywell
3505582-63	Engine Starter	Honeywell
3505582-64	Engine Starter	Honeywell
3505582-65	Engine Starter	Honeywell
3505716-3	Engine Starter	Honeywell
3505716-4	Engine Starter	Honeywell
3505716-5	Engine Starter	Honeywell
3505716-6	Engine Starter	Honeywell
35077-2	Pressure Switch	Industria

Repair_Capability_List_Excel

35077-3	Pressure Switch	Industria
3508000	Magnetic Fluid Level Indicator	FR Hitemp
3508000-106	Fluid Level Indicator	FR Hitemp
3508000-145	Fluid Level Indicator	FR Hitemp
3508000-177	Fluid Level Indicator	FR Hitemp
3508000-178	Fluid Level Indicator	FR Hitemp
3508000-179	Magnetic Fluid Level Indicator	FR Hitemp
3508000-197	Fluid Level Indicator	FR Hitemp
3508000-198	Fluid Level Indicator	FR Hitemp
3508000-199	Magnetic Fluid Level Indicator	FR Hitemp
3508000-220	Fluid Level Indicator	FR Hitemp
3508000-221	Fluid Level Indicator	FR Hitemp
3508000-222	Magnetic Fluid Level Indicator	FR Hitemp
3508000-223	Fluid Level Indicator	FR Hitemp
3508000-227	Fluid Level Indicator	FR Hitemp
3508000-228	Fluid Level Indicator	FR Hitemp
3508000-60	Fluid Level Indicator	FR Hitemp
3508000-61	Fluid Level Indicator	FR Hitemp
3508000-62	Fluid Level Indicator	FR Hitemp
3508000-63	Fluid Level Indicator	FR Hitemp
3508000-64	Fluid Level Indicator	FR Hitemp
3508000-65	Fluid Level Indicator	FR Hitemp
3508000-92	Fluid Level Indicator	FR Hitemp
3508000-93	Fluid Level Indicator	FR Hitemp
3508000-94	Fluid Level Indicator	FR Hitemp
3508000-95	Fluid Level Indicator	FR Hitemp
3508000-96	Fluid Level Indicator	FR Hitemp
3508000-97	Fluid Level Indicator	FR Hitemp
3508400-60	Magnetic Fluid Level Indicator	FR Hitemp
3508400-61	Magnetic Fluid Level Indicator	FR Hitemp
3508400-62	Magnetic Fluid Level Indicator	FR Hitemp
350880	Hydraulic Pump	Vickers
350880-1	Hydraulic Pump	Vickers
350880-2	Hydraulic Pump	Vickers
3508802-24	Magnetic Level Housing Indicator	FR Hitemp
3508802-25	Magnetic Level Housing Indicator	FR Hitemp
3508802-26	Magnetic Level Housing Indicator	FR Hitemp
3508802-27	Magnetic Level Housing Indicator	FR Hitemp
3508802-29	Magnetic Level Housing Indicator	FR Hitemp
3508802-35	Magnetic Level Housing Indicator	FR Hitemp
3508802-36	Magnetic Level Housing Indicator	FR Hitemp
3508802-37	Magnetic Level Housing Indicator	FR Hitemp
3508802-38	Magnetic Level Housing Indicator	FR Hitemp
3508802-39	Magnetic Level Housing Indicator	FR Hitemp
3508802-40	Magnetic Level Housing Indicator	FR Hitemp
3508802-72	Magnetic Fluid Level Indicator	FR Hitemp
3508802-73	Magnetic Fluid Level Indicator	FR Hitemp
350880-3	Hydraulic Pump	Vickers
3508803-501	Magnetic Level Indicator	FR Hitemp
3508803-507	Magnetic Level Indicator	FR Hitemp
3508803-513	Magnetic Level Indicator	FR Hitemp
3508803-519	Magnetic Level Indicator	FR Hitemp
3508803-525	Magnetic Level Indicator	FR Hitemp
3508803-531	Magnetic Level Indicator	FR Hitemp
350880-5	Hydraulic Pump	Vickers
350880-6	Variable Disp.Hydraulic Pump	Vickers
350880-7	Variable Disp.Hydraulic Pump	Vickers
35-0D5-1002	Cockpit Loudspeaker Ampli	Airbus Industrie

Repair_Capability_List_Excel

35-0D5-1003	Cockpit Loudspeaker Ampli	Airbus Industrie
35-0F5-1000	Annuciator Light Test Board	Airbus Industrie
35-0F5-5000	Blanking Panel	Airbus Industrie
35-0F6-1000	Warning Light Control Box	Airbus Industrie
350KU01-6AA	Switch Guard	ECE
35-11	Utility Light assy	Labinal
3515000	Switch	FR Hitemp
3515000-127	Switch	FR Hitemp
3515000-135	Float Switch	FR Hitemp
3515000-273	Float Switch	FR Hitemp
3515000-72	Maximum Level Float Switch	FR Hitemp
35170-4	Rotary Actuator	Honeywell
35198-14	Rotary Actuator	Honeywell
35198-15	Rotary Actuator	Honeywell
35198-8	Rotary Actuator	Honeywell
35-1H5-1001	Brake Temp.Monitor Unit	Thales Avionics
35-1H5-1002	Brake Temp.Monitor Unit	Thales Avionics
351T0300-13	Auxiliary Power Unit	Boeing
351T0300-14	Auxiliary Power Unit	Boeing
351T0300-15	Auxiliary Power Unit	Boeing
351T0300-16	Auxiliary Power Unit	Boeing
351T0300-17	Auxiliary Power Unit	Boeing
351T0300-18	Auxiliary Power Unit	Boeing
351T0300-19	Auxiliary Power Unit	Boeing
351T0300-20	Auxiliary Power Unit	Boeing
351T0300-21	Auxiliary Power Unit	Boeing
351T0300-22	Auxiliary Power Unit	Boeing
351T0300-23	Auxiliary Power Unit	Boeing
351T0300-24	Auxiliary Power Unit	Boeing
351T0300-25	Auxiliary Power Unit	Boeing
351T0300-26	Auxiliary Power Unit	Boeing
351T0300-27	Auxiliary Power Unit	Boeing
351T0300-28	Auxiliary Power Unit	Boeing
351T0300-29	Auxiliary Power Unit	Boeing
351T0300-31	Auxiliary Power Unit	Boeing
351T0300-32	Auxiliary Power Unit	Boeing
351T0300-33	Auxiliary Power Unit	Boeing
351T0300-34	Auxiliary Power Unit	Boeing
351T0300-35	Auxiliary Power Unit	Boeing
351T0300-36	Auxiliary Power Unit	Boeing
351T0300-38	Auxiliary Power Unit	Boeing
351T0300-39	Auxiliary Power Unit	Boeing
351T0300-41	Auxiliary Power Unit	Boeing
351T0300-45	Auxiliary Power Unit	Boeing
351T0300-46	Auxiliary Power Unit	Boeing
351T0300-47	Auxiliary Power Unit	Boeing
351T0300-48	Auxiliary Power Unit	Boeing
351T0300-50	Auxiliary Power Unit	Boeing
351T0300-51	Auxiliary Power Unit	Boeing
351T0300-52	Auxiliary Power Unit	Boeing
351T0300-53	Auxiliary Power Unit	Boeing
351T0300-54	Auxiliary Power Unit	Boeing
351T0300-55	Auxiliary Power Unit	Boeing
351T0300-56	Auxiliary Power Unit	Boeing
351T0300-57	Auxiliary Power Unit	Boeing
351T0300-58	Auxiliary Power Unit	Boeing
35-242-100	Compensator	Airbus Industrie
35-292-100	Strobe Light Flasher	Thales

Repair_Capability_List_Excel

35-292-1001	Strobe Light Flasher	Airbus Industrie
352T0102-1	Auxiliary Power System Support	Boeing
352T0102-5	Auxiliary Power System Support	Boeing
352T0102-6	Auxiliary Power System Support	Boeing
352T0102-7	Auxiliary Power System Support	Boeing
352T0102-8	Auxiliary Power System Support	Boeing
352T0102-9	Auxiliary Power System Support	Boeing
352T0103-1	Auxiliary Power System Support	Boeing
352T0104-1	Auxiliary Power System Support	Boeing
352T0105-1	Auxiliary Power System Support	Boeing
352T0105-10	Auxiliary Power System Support	Boeing
352T0105-11	Auxiliary Power System Support	Boeing
352T0105-5	Auxiliary Power System Support	Boeing
352T0105-6	Auxiliary Power System Support	Boeing
352T0105-7	Auxiliary Power System Support	Boeing
352T0105-8	Auxiliary Power System Support	Boeing
352T0105-9	Auxiliary Power System Support	Boeing
3530000-1	High/Low Level Sensor	FR Hitemp
3530000-3	FQI Level Sensor	FR Hitemp
3530000-4	FQI Temperature Sensor	FR Hitemp
35-309-1001	Master Warning Panel	Airbus Industrie
35-309-1002	Master Warning Panel	Airbus Industrie
35-309-1003	Master Warning Panel	Airbus Industrie
35-309-1004	Master Warning Panel	Airbus Industrie
35-309-1005	Master Warning Panel	Airbus Industrie
35-309-1006	Master Warning Panel	Airbus Industrie
35-309-1007	Master Warning Panel	Airbus Industrie
35-309-1008	Master Warning Panel	Airbus Industrie
35-309-1009	Master Warning Panel	Airbus Industrie
35-309-100A	Master Warning Panel	Airbus Industrie
35-309-1010	Master Warning Panel	Airbus Industrie
35-309-1013	Master Warning Panel	Aerospatiale
35-309-1014	Master Warning Panel	Aerospatiale
35-309-1015	Master Warning Panel	Aerospatiale
35-309-1016	Master Warning Panel	Airbus Industrie
35-309-1017	Master Warning Panel	Aerospatiale
35-309-1019	Master Warning Panel	Aerospatiale
35-309-1020	Master Warning Panel	Airbus Industrie
35-309-1021	Master Warning Panel	Aerospatiale
35-309-1022	Master Warning Panel	Aerospatiale
35-309-1023	Master Warning Panel	Aerospatiale
35-315-100	Jamming Detect. Control Box	Airbus Industrie
35-315-1001	Jamming Detect. Control Box	Airbus Industrie
35-315-1002	Jamming Detect. Control Box	Airbus Industrie
35-315-1003	Jamming Detect. Control Box	Airbus Industrie
35-315-1004	Jamming Detect. Control Box	Airbus Industrie
35-315-1005	Jamming Detect. Control Box	Airbus Industrie
35-315-1006	Jamming Detect. Control Box	Airbus Industrie
35-315-1007	Jamming Detect. Control Box	Airbus Industrie
35-315-2002	Jamming Detection Control Unit	Airbus Industrie
35-315-2003	Jamming Detection Control Unit	Airbus Industrie
35-320-100	Pulse Indicator	Airbus Industrie
35-325-100	Indicating Unit	Airbus Industrie
35-325-1001	Indicating Unit	Airbus Industrie
35-349-100	Braking System Test Unit	Airbus Industrie
35-349-1001	Braking System Test Unit	Airbus Industrie
35-349-1002	Braking System Test Unit	Airbus Industrie
35-349-1003	Braking System Test Unit	Airbus Industrie

Repair_Capability_List_Excel

35-349-1004	Braking System Test Unit	Airbus Industrie
35-349-1005	Braking System Test Unit	Airbus Industrie
35350	Thermometer	Edison
353T0100-3	Auxiliary Power Syst.Intake Port & Door	Boeing
353T0100-4	Auxiliary Power Syst.Intake Port & Door	Boeing
353T0100-6	Auxiliary Power Syst.Intake Port & Door	Boeing
3540000-1	Temperature Sensor	FR Hitemp
3540000-3	Temperature Sensor	FR Hitemp
3540000-4	Temperature Sensor	FR Hitemp
35-430-100	Ground Spoilers Control Box	Airbus Industrie
35-430-1001	Ground Spoilers Control Box	Airbus Industrie
35-430-1002	Ground Spoilers Control Box	Airbus Industrie
35-430-1003	Ground Spoilers Control Box	Airbus Industrie
35-441-1002	Flaps Indicating Unit	Airbus Industrie
35-454-100	Static Inverter	Airbus Industrie
35-454-1001	Static Inverter	Airbus Industrie
35-454-1004	Static Inverter	Airbus Industrie
35-454-1005	Static Inverter	Airbus Industrie
35-461-1000	Auto Land Indicator	Airbus Industrie
35-465-1000	VOR Signal Condition	Airbus Industrie
35-467-100	Brake Temperature Panel	Airbus Industrie
35-467-1001	Brake Temperature Panel	Airbus Industrie
35-467-1002	Brake Temperature Panel	Airbus Industrie
35-467-1003	Brake Temperature Panel	Airbus Industrie
35-467-1004	Brake Temperature Panel	Airbus Industrie
35-467-1005	Brake Temperature Panel	Airbus Industrie
35-467-1006	Brake Temperature Panel	Airbus Industrie
35-467-1007	Brake Temperature Panel	Airbus Industrie
35-467-1008	Brake Temperature Panel	Airbus Industrie
35-467-1009	Brake Temperature Panel	Airbus Industrie
35-467-1010	Brake Temperature Panel	Airbus Industrie
35-467-1012	Brake Temperature Panel	Airbus Industrie
35-467-1013	Brake Temperature Panel	Airbus Industrie
35-467-1014	Brake Temperature Panel	Airbus Industrie
35-467-1018	Brake Temperature Panel	Airbus Industrie
35-467-1020	Brake Temperature Panel	Airbus Industrie
35-467-2001	Brake Temperature Detection Unit	Airbus Industrie
35-493-100	Indicator Light Dimmer	Airbus Industrie
35-493-1001	Indicator Light Dimmer	Airbus Industrie
35-493-1002	Indicator Light Dimmer	Airbus Industrie
35-493-1002A	Indicator Light Dimmer	Airbus Industrie
35-493-1003	Indicator Light Dimmer	Airbus Industrie
35-493-1004	Indicator Light Dimmer	Airbus Industrie
35-493-1005	Indicator Light Dimmer	Airbus Industrie
35-493-1006	Indicator Light Dimmer	SNIAS
35-493-2001	Light Dimmer Indicator	Airbus Industrie
35-493-2002	Light Dimmer Indicator	Airbus Industrie
35-497-1003	Regulation Sequence Box	Airbus Industrie
35-497-1004	Regulation Sequence Box	Airbus Industrie
35-497-1005	Regulation Sequence Box	Airbus Industrie
35-497-1006	Regulation Sequence Box	Airbus Industrie
35-497-1007	Regulation Sequence Box	Airbus Industrie
35-497-1008	Regulation Sequence Box	Airbus Industrie
35500	Engine Gauge Unit	Edison
35-514-401	Indicator Light	Airbus Industrie
35518-3-255	Air Leak Detection Element Sensing	Fenwal
35518-3-310	Air Leak Detection Element Sensing	Fenwal
35-53	Dome Light	Labinal

Repair_Capability_List_Excel

35530-2-255	Air Leak Detection Element Sensing	Fenwal
35530-2-310	Air Leak Detection Element Sensing	Fenwal
35540-2-255	Air Leak Detection Element Sensing	Fenwal
35540-2-310	Air Leak Detection Element Sensing	Fenwal
35544-3-255	Air Leak Detection Element Sensing	Fenwal
35544-3-310	Air Leak Detection Element Sensing	Fenwal
35-551-1000	Autobrake Control Unit	Airbus Industrie
35-551-1003	Autobrake Control Unit	Airbus Industrie
35-551-1004	Autobrake Control Unit	Airbus Industrie
35-551-1005	Autobrake Control Unit	Airbus Industrie
35-551-1007	Autobrake Control Unit	Airbus Industrie
35-551-1010	Autobrake Control Unit	Airbus Industrie
35-551-1011	Autobrake Control Unit	Airbus Industrie
35-551-1012	Autobrake Control Unit	Airbus Industrie
35-552-1000	Autobrake Selector Module	Airbus Industrie
35560-4-310	Element Sensing	Fenwal
35-561-1000	Fluorescent Tube Socket	Airbus Industrie
35567-2-255	Air Leak Detection Element Sensing	Fenwal
35567-2-310	Air Leak Detection Element Sensing	Fenwal
35-57-1	Dome Light	Labinal
35592-3-255	Air Leak Detection Element Sensing	Fenwal
35592-3-310	Air Leak Detection Element Sensing	Fenwal
35596-2-255	Element Sensing	Fenwal
35622-4-255	Air Leak Detection Element Sensing	Fenwal
35622-4-310	Air Leak Detection Element Sensing	Fenwal
35624-2-255	Element Sensing	Fenwal
35625-2-255	Element Sensing	Fenwal
35625-4-255	Element Sensing	Fenwal
35626-4-255	Element Sensing	Fenwal
35629-2-255	Element Sensing	Fenwal
35640-2-255	Element Sensing	Fenwal
35640-3-255	Element Sensing	Fenwal
35641-2-255	Element Sensing	Fenwal
35641-2-400	Element Sensing	Fenwal
35646-2-255	Element Sensing	Fenwal
35652-2-255	Element Sensing	Fenwal
35652-3-255	Element Sensing	Fenwal
35657-4-255	Element Sensing	Fenwal
35658-2-255	Element Sensing	Fenwal
35658-4-255	Element Sensing	Fenwal
35660-2-255	Element Sensing	Fenwal
35661-2-255	Element Sensing	Fenwal
3567313-0001	Stabilizer Position Transmitter	Bendix
3567318-0001	Flap Position Transmitter	Bendix
3567402-0201	TRANSMITTER	ALLIED SIGNAL
3567403-3001	TRANSMITTER	ALLIED SIGNAL
3567404-7001	TRANSMITTER	ALLIED SIGNAL
3567407-0101	TRANSMITTER	ALLIED SIGNAL
3567645-3701	Pressure Transmitter	Bendix/King
3567709-5501	Blower Pressure Transmitter	Bendix
3567709-7202	Fuel Pressure Transmitter	Bendix
3571212-3001	Horizontal Stabilizer Trim Position Indicator	Bendix
3571212-3002	Speedbrake Position Indicator	Bendix
3571212-3003	Flap Position Indicator	Bendix
3571212-3004	Hydraulic Pressure Indicator	Bendix
3571212-3005	Hydraulic Indicator	Smiths Industries
3571212-3006	Trim Position Indicator	Bendix
3571212-3009	Flap Position Indicator	Bendix

Repair_Capability_List_Excel

3571212-3011	Trim Position Indicator	Bendix
3571220-5001	Dual Autosyn Synchro Indicator	Honeywell
3571220-5002	Dual Autosyn Synchro Indicator	Honeywell
3571220-5003	Dual Autosyn Synchro Indicator	Honeywell
3571220-5004	Dual Autosyn Synchro Indicator	Honeywell
3571220-5005	Dual Autosyn Synchro Indicator	Honeywell
3571220-5007	Dual Autosyn Synchro Indicator	Honeywell
3571220-5008	Dual Autosyn Synchro Indicator	Honeywell
35-763	Light	Labinal
35-763-1	Light	Labinal
357EAP/1	Servo Motor	Smiths Industries
357EAP/2	Servo Motor	Smiths Industries
35-820-1004	Cockpit Loudspeaker	Airbus Industrie
35-830-1005-005	Display Warning Lighted Panel	Airbus Industrie
35-840-1001	Static Inverter	Thales Avionics
35-850-1001	Reversing Module	Airbus Industrie
35-890-1001	Control ECAM Panel	Airbus Industrie
358EAP/1	Servo Motor	Smiths Industries
358EAP/2	Servo Motor	Smiths Industries
35-910-1000	Window Heat Protection Unit	Airbus Industrie
35-930-1001	Rudder Trim Indicator	Airbus Industrie
35-940-1003-051	Annunciator Light Test Unit	Airbus Industrie
35950	Brake Control Valve ay	Douglas
35950-501	Brake Control Valve ay	Douglas
35950-503	Brake Control Valve ay	Douglas
35950-505	Brake Control Valve ay	Douglas
359EAP/1	Servo Motor	Smiths Industries
359EAP/2	Servo Motor	Smiths Industries
35E38-5	IDG Air/Oil Cooler	Grimes
3600-1-1	Drain Valve	Monogram Systems
3600232-1	Hydraulic Actuator assy	Honeywell
3600232-2	Hydraulic Actuator assy	Honeywell
3600727-1	Oil Tank assy	Honeywell
3600925-3	Electrical Starter	Honeywell
3601030-1	Multi Switch	Honeywell
3601030-10	Multi-Switch assy	Honeywell
3601030-10-1	Multi-Switch assy	Honeywell
3601030-11	Multi Switch	Honeywell
3601030-1-1	Multi-Switch assy	Honeywell
3601030-11-1	Multi-Switch assy	Honeywell
3601030-13	Multi-Switch assy	Honeywell
3601030-13-1	Multi-Switch assy	Honeywell
3601030-2-1	Multi-Switch assy	Honeywell
3601030-3-1	Switch assy	Honeywell
3601030-5	Multi-Switch assy	Honeywell
3601030-5-1	Multi-Switch assy	Honeywell
3601030-6-1	Multi-Switch assy	Honeywell
3601030-9-1	Multi-Switch assy	Honeywell
3601-91	Under Pylon Fire Detector	L'Hotellier
3601-92	Under Pylon Fire Detector	L'Hotellier
3602773-1	Valve assy	Honeywell
3603281-1	Ignition Unit	Honeywell
3603281-2	Ignition Exciter	Honeywell
3603281-3	Ignition Exciter	Honeywell
3603281-4	Ignition Exciter	Honeywell
3603281-6	Ignition Exciter	Honeywell
3603281-7	Ignition Exciter	Honeywell
3603281-8	IGNITION EXCITER	UNISON

Repair_Capability_List_Excel

360362-2-1	Solenoid Shut-Off Valve	Honeywell
360362-3-1	Solenoid Shut-Off Valve	Honeywell
360362-4-1	Solenoid Shut-Off Valve	Honeywell
3603756-2	Speed Sensor Assy	Honeywell
3603756-4	Speed Sensor Assy	Honeywell
360450-1001	Ground Spoiler Valve Module ay	Parker Hannifin
3604524-47	APU Combuster Unit	Honeywell
360550-1001	Speedbrake Valve Module assy	Parker Hannifin
360550-1003	Speedbrake Valve Module assy	Parker Hannifin
3605812-1	Electrical Engine Starter	Honeywell
3605812-10-1	Electrical Engine Starter	Honeywell
3605812-11	Electrical Engine Starter	Honeywell
3605812-1-1	Electrical Engine Starter	Honeywell
3605812-11-1	Electrical Engine Starter	Honeywell
3605812-12	Electrical Engine Starter	Honeywell
3605812-12-1	Electrical Engine Starter	Honeywell
3605812-13-1	Electrical Engine Starter	Honeywell
3605812-14	Electrical Engine Starter	Honeywell
3605812-14-1	Electrical Engine Starter	Honeywell
3605812-16	Electrical Engine Starter	Honeywell
3605812-16-1	Electrical Engine Starter	Honeywell
3605812-17	Electrical Engine Starter	Honeywell
3605812-17-1	Electrical Engine Starter	Honeywell
3605812-18	Electrical Engine Starter	Honeywell
3605812-19	Electrical Engine Starter	Honeywell
3605812-19-1	Electrical Engine Starter	Honeywell
3605812-21	Electrical Engine Starter	Honeywell
3605812-2-1	Electrical Engine Starter	Honeywell
3605812-22	Electrical Engine Starter	Honeywell
3605812-22-1	Electrical Engine Starter	Honeywell
3605812-3	Electrical Engine Starter	Honeywell
3605812-3-1	Electrical Engine Starter	Honeywell
3605812-4	Electrical Engine Starter	Honeywell
3605812-4-1	Electrical Engine Starter	Honeywell
3605812-6	Electrical Engine Starter	Honeywell
3605812-9	Electrical Engine Starter	Honeywell
3605812-9-1	Electrical Engine Starter	Honeywell
3607680-5	Acceleration Control Unit	Honeywell
3607680-6	Acceleration Control Unit	Honeywell
3607680-7	Acceleration Control Unit	Honeywell
3607680-8	Acceleration Control Unit	Honeywell
3607680-9	Acceleration Control Unit	Honeywell
3609200	Valve assy	FR Hitemp
3609290	Valve assy	FR Hitemp
3609295	Valve assy	FR Hitemp
3609480-1	Switch assy	Honeywell
3609480-10	Switch assy	Honeywell
3609480-11	Switch assy	Honeywell
3609480-1-1	Switch assy	Honeywell
3609480-13	Switch assy	Honeywell
3609480-13-1	Switch assy	Honeywell
3609480-2	Switch assy	Honeywell
3609480-3	Switch assy	Honeywell
3609480-5	Switch assy	Honeywell
3609480-5-1	Switch assy	Honeywell
3609480-6	Switch assy	Honeywell
3609480-9	Switch assy	Honeywell
3614001-4001	VHF Comm Transceiver	Chelton

Repair_Capability_List_Excel

3614004-4101	VHF Navigation Receiver	Chelton
3614009-4201	ATC Transponder	Chelton
3614013-4301	ADF Receiver	Chelton
3614019-4401	DME Transceiver	Chelton
3614163-1	Cooling Fan	Honeywell
3614163-2	Cooling Fan	Honeywell
3614163-4	Cooling Fan	Honeywell
3614163-5	Cooling Fan	Honeywell
3614295-2	Cooling Valve	Honeywell
3614416-1	Fan assy	Honeywell
3614416-2	Fan assy	Honeywell
3614961-2	Flow Sensor Transducer	Honeywell
3614961-3	Flow Sensor Transducer	Honeywell
3614961-4	Flow Sensor Transducer	Honeywell
3614961-5	Flow Sensor Transducer	Honeywell
3615133-1	Fan Assy	Honeywell
3615133-2	Fan Assy	Honeywell
3615133-3	Fan Assy	Honeywell
3615133-4	Fan Assy	Honeywell
3615133-5	Fan Assy	Honeywell
3615133-6	Fan Assy	Honeywell
3615143-2	Current Limiting Control	Marsh Aviation
3615700-10	Mul Cent Switch	Honeywell
3615700-13	Mul Cent Switch	Honeywell
3615700-5	Mul Cent Switch	Honeywell
3616140-4	Fan assy	Honeywell
3616140-6	Fan assy	Honeywell
3616140-7	Fan assy	Honeywell
3616960-1	Cooling Fan	Honeywell
3616960-2	Cooling Fan	Honeywell
3617750-1	Turb Type Cont. Unit	Honeywell
3617750-2	Turb Type Cont. Unit	Honeywell
3617750-3	Turb Type Cont. Unit	Honeywell
3617750-4	Turb Type Cont. Unit	Honeywell
362-112-45-200	Control Head	Gables Engineering
36260-2	Tail Navigation Light	Grimes Aerospace
3638-036	Fitting	Airesearch
363EAP-1	Trim Servo Motor	Smiths Industries
364EAP-1	Trim Servo Motor	Smiths Industries
364EAP3	Trim Servo Mounting	Smiths Industries
36500A63-1	Overwing Refuelling Cap	Intertechnique
36500A63-11	Overwing Refuelling Cap	Intertechnique
365A01	Thermal Expansion Valve	Liebherr Aerospace
365A02	Thermal Expansion Valve	Liebherr Aerospace
36610-3	Valve assy	Sterer
36700	DC Motor	Honeywell
36702	D.C. Motor	Honeywell
36702-2	D.C. Motor	Honeywell
36702-3	D.C. Motor	Honeywell
367-027-002	Hydraulic Qty Monitor Unit	Parker Hannifin
367-027-003	Hydraulic Qty Monitor Unit	Parker Hannifin
367-027-004	Hydraulic Qty Monitor Unit	Parker Hannifin
367-027-005	Monitor Unit	Parker Hannifin
367-027-006	Monitor Unit	Parker Hannifin
367-027-019	Hydraulic Qty Monitor Unit	Parker Hannifin
367-027-020	Hydraulic Qty Monitor Unit	Parker Hannifin
36787-2	D.C. Motor	Honeywell
369256	Ignition Exciter	Honeywell

Repair_Capability_List_Excel

369256-1	IGNITION EXCITER	UNISON
369257-1	Ignition Unit	Honeywell
369259-13	Igniter Plug Lead	Honeywell
369259-15	Igniter Plug Lead	Honeywell
369259-20	Igniter Plug Lead	Honeywell
369259-23	Igniter Plug Lead	Honeywell
369259-24	Igniter Plug Lead	Honeywell
369259-26	Igniter Plug Lead	Honeywell
369259-28	Igniter Plug Lead	Honeywell
369259-29	Igniter Plug Lead	Honeywell
369259-32	Igniter Plug Lead	Honeywell
369259-35	Igniter Plug Lead	Honeywell
369259-40	Igniter Plug Lead	Honeywell
369259-41	Igniter Plug Lead	Honeywell
369259-42	Igniter Plug Lead	Honeywell
369259-45	Igniter Plug Lead	Honeywell
369259-46	Igniter Plug Lead	Honeywell
369259-47	Igniter Plug Lead	Honeywell
369259-48	Igniter Plug Lead	Honeywell
369259-52	Igniter Plug Lead	Honeywell
369259-55	Igniter Plug Lead	Honeywell
369259-59	Igniter Plug Lead	Honeywell
369259-60	Igniter Plug Lead	Honeywell
369259-61	Igniter Plug Lead	Honeywell
369259-62	Igniter Plug Lead	Honeywell
369259-7	Igniter Plug Lead	Honeywell
369724	Hydraulic Pump	Vickers
36-9F	Clock	Auricoste
36E14-1	Engine Air Shut-Off Valve	Honeywell
36E14-2	Engine Air Shut-Off Valve	Honeywell
36E14-3	Engine Air Shut-Off Valve	Honeywell
36E14-4	Engine Air Shut-Off Valve	Honeywell
36E14-5	Engine Air Shut-Off Valve	Honeywell
36E14-6	Engine Air Shut-Off Valve	Honeywell
37000	Cabin Altimeter	Thales Avionics
37000-10	Cabin Altimeter	Thales Avionics
3700-01-01	Fire Detection Unit	L'Hotellier
37000-2	Cabin Altimeter	Thales Avionics
3700-02-02	Fire Detection Unit	L'Hotellier
37000-3	Cabin Altimeter	Thales Avionics
370EAP/1/13	Torque Limiter	Smiths Industries
370EAP/1/14	Torque Limiter	Smiths Industries
370EAP/1/15	Torque Limiter	Smiths Industries
370EAP/1/16	Torque Limiter	Smiths Industries
370EAP/1/17	Torque Limiter	Smiths Industries
370EAP/1/18	Torque Limiter	Smiths Industries
370EAP/1/19	Torque Limiter	Smiths Industries
370EAP/1/20	Torque Limiter	Smiths Industries
370EAP/1/21	Torque Limiter	Smiths Industries
370EAP/1/22	Torque Limiter	Smiths Industries
370EAP/1/23	Torque Limiter	Smiths Industries
370EAP/1/24	Torque Limiter	Smiths Industries
370EAP/1/25	Torque Limiter	Smiths Industries
370EAP/2/13	Torque Limiter	Smiths Industries
370EAP/2/14	Torque Limiter	Smiths Industries
370EAP/2/15	Torque Limiter	Smiths Industries
370EAP/2/16	Torque Limiter	Smiths Industries
370EAP/2/17	Torque Limiter	Smiths Industries

Repair_Capability_List_Excel

370EAP/2/18	Torque Limiter	Smiths Industries
370EAP/2/19	Torque Limiter	Smiths Industries
370EAP/2/20	Torque Limiter	Smiths Industries
370EAP/2/21	Torque Limiter	Smiths Industries
370EAP/2/22	Torque Limiter	Smiths Industries
370EAP/2/23	Torque Limiter	Smiths Industries
370EAP/2/24	Torque Limiter	Smiths Industries
370EAP/2/25	Torque Limiter	Smiths Industries
370EAP/3/13	Torque Limiter	Smiths Industries
370EAP/3/14	Torque Limiter	Smiths Industries
370EAP/3/15	Torque Limiter	Smiths Industries
370EAP/3/16	Torque Limiter	Smiths Industries
370EAP/3/17	Torque Limiter	Smiths Industries
370EAP/3/18	Torque Limiter	Smiths Industries
370EAP/3/19	Torque Limiter	Smiths Industries
370EAP/3/20	Torque Limiter	Smiths Industries
370EAP/3/21	Torque Limiter	Smiths Industries
370EAP/3/22	Torque Limiter	Smiths Industries
370EAP/3/23	Torque Limiter	Smiths Industries
370EAP/3/24	Torque Limiter	Smiths Industries
370EAP/3/25	Torque Limiter	Smiths Industries
3710-00-00	Fire Detection Unit	L'Hotellier
37100-1001	Shock Strut assy	Dowty Canada
37101-1001	Shock Strut assy	Dowty Canada
371380	Variable Disp. Hydraulic Pump	Vickers
37-16	Ballast	NEC
37-17-2	Ballast	NEC
371976-14	Oil Pump	Honeywell
371976-18	Oil Pump	Honeywell
372000	Shuttle Valve	Fairchild
37-231	Anti-Skid Servo Valve	Crane
37265-101	CLG Electrical Harness	Icore International
37266-101	CLG Electrical Harness	Icore International
372697-10	Electrical Engine Starter	Honeywell
372697-13	Electrical Engine Starter	Honeywell
372697-13-1	Electrical Engine Starter	Honeywell
372697-15	Electrical Engine Starter	Honeywell
372697-16	Electrical Engine Starter	Honeywell
372697-18-1	Electrical Engine Starter	Honeywell
372697-21	Electrical Engine Starter	Honeywell
372697-21-1	Electrical Engine Starter	Honeywell
372697-22	Electrical Engine Starter	Honeywell
372697-22-1	Electrical Engine Starter	Honeywell
372697-24	Electrical Engine Starter	Honeywell
372697-24-1	Electrical Engine Starter	Honeywell
372697-9	Electrical Engine Starter	Honeywell
373048-1	Pressure Relief Valve	Honeywell
373048-3	Pressure Relief Valve	Honeywell
37-309	Servo Valve	Crane
373364	Hydraulic Motor	Vickers
373FL01	Proximity Switch	ECE
37-40	Dome Light	Sela
374290-4	Gauge Transmitter	Bronzavia-Air Equipement
374290-7	Gauge Transmitter	Bronzavia-Air Equipement
374291-8	Transmitter	Lucas Air Equipement
374294-1	Pressure Gauge	Bronzavia-Air Equipement
374294-2	Pressure Gauge	Bronzavia-Air Equipement
3743010-4	Flight Mode Annunciator	Honeywell

Repair_Capability_List_Excel

3743016-4	Flight Mode Annunciator	Honeywell
374669	Temperature Sensor	Bronzavia-Air Equipement
374FL01	Proximity Switch	ECE
3750	Self Sealing Coupling	Aeroquip
37-51	Control Pedestal Floodlight	Abadie
375135	Transmitter	Lucas Air Equipement
375248-12	Self Sealing Half Coupling	Aeroquip
375322-X	Electrical Engine Starter	Honeywell
375324-2	Oil Pump	Honeywell
375324-3	Oil Pump	Honeywell
3755-2	AC Actuator	Grimes Aerospace
375530-12	Self Sealing Half Coupling	Aeroquip
37-605A	Console Spotlight	Abadie
3772374-5503	Valve assy	Douglas
377869	Ignition Unit	Honeywell
377EAP/1	Servo Motor	Smiths Industries
377EAP/2	Servo Motor	Smiths Industries
378000	Electric Motor	Vickers
378001	Hydraulic Motorpump	Vickers
3780078-101	Accumulator	Parker Hannifin
3780078-102	Accumulator	Parker Hannifin
3780078-103	Accumulator	Parker Hannifin
3780078-104	Accumulator	Parker Hannifin
3780078-105	Accumulator	Parker Hannifin
378640	Ignition Exciter	Honeywell
378EAP/1	Servo Motor	Smiths Industries
378EAP/2	Servo Motor	Smiths Industries
3790005	Module	Parker Hannifin
3790006	Module	Parker Hannifin
3790011-101	Rudder Ratio Changer	Parker Hannifin
3790011-102	Rudder Ratio Changer	Parker Hannifin
3790011-103	Rudder Ratio Changer	Parker Hannifin
3790011-104	Rudder Ratio Changer	Parker Hannifin
3790011-105	Rudder Ratio Changer	Parker Hannifin
3790011-106	Rudder Ratio Changer	Parker Hannifin
3790011-107	Rudder Ratio Changer	Parker Hannifin
3790011-L108	Servo Actuator	Parker Hannifin
3790033-101	Door Safety Valve	Parker Hannifin
3790033-102	Door Safety Valve	Parker Hannifin
3790033-104	Door Safety Valve	Parker Hannifin
3790034-101	Main Gear Door Sequence Valve	Parker Hannifin
3790034-102	Main Gear Door Sequence Valve	Parker Hannifin
3790034-103	Main Gear Door Sequence Valve	Parker Hannifin
3790034-105	Main Gear Door Sequence Valve	Parker Hannifin
3790034-106	Main Gear Door Sequence Valve	Parker Hannifin
3790034-107	Main Gear Door Sequence Valve	Parker Hannifin
3790037-101	Nose Wheel Steering Valve	Parker Hannifin
3790037-102	Nose Wheel Steering Valve	Parker Hannifin
3790037-103	Nose Wheel Steering Valve	Parker Hannifin
3790037-104	Nose Wheel Steering Valve	Parker Hannifin
3790037-105	Nose Wheel Steering Valve	Parker Hannifin
3790037-106	Nose Wheel Steering Valve	Parker Hannifin
3790037-107	Nose Wheel Steering Valve	Parker Hannifin
3790037-108	Nose Wheel Steering Valve	Parker Hannifin
3790055-101	Transfer Cylinder	Parker Hannifin
3790055-102	Transfer Cylinder	Parker Hannifin
3790073-101	Actuator	Parker Hannifin
3790074-101	Actuator	Parker Hannifin

Repair_Capability_List_Excel

3790076-101	IGV Actuator	Honeywell
3790076-102	IGV Actuator	Honeywell
3790076-103	IGV Actuator	Honeywell
3790076-104	IGV Actuator	Honeywell
3790076-105	IGV Actuator	Honeywell
379018-1-1	Check Valve	Honeywell
379580-150	Oil Pump	Honeywell
379580-200	Oil Pump	Honeywell
379580-250	Oil Pump	Honeywell
379580-300	Oil Pump	Honeywell
379580-350	Oil Pump	Honeywell
379580-400	Oil Pump	Honeywell
379580-450	Oil Pump	Honeywell
379580-500	Oil Pump	Honeywell
379580-550	Oil Pump	Honeywell
379580-600	Oil Pump	Honeywell
379580-650	Oil Pump	Honeywell
379580-700	Oil Pump	Honeywell
379700	Oil Tank assy	Honeywell
379EAP/1	Servo Motor	Smiths Industries
379EAP/2	Servo Motor	Smiths Industries
3800022-101	Rudder Ratio Changer	Parker Hannifin
3800022-102	Rudder Ratio Changer	Parker Hannifin
3800022-103	Rudder Ratio Changer	Parker Hannifin
3800022-104	Rudder Ratio Changer	Parker Hannifin
3800022-105	Rudder Ratio Changer	Parker Hannifin
3800022-106	Rudder Ratio Changer	Parker Hannifin
3800022-107	Rudder Ratio Changer	Parker Hannifin
3800022L105	Rudder Ratio Changer	Parker Hannifin
3800035-105	Actuator	Parker Hannifin
3800035-106	Actuator	Parker Hannifin
3800035-108	Actuator	Parker Hannifin
3800035-109	Actuator	Parker Hannifin
3800035-110	Actuator	Parker Hannifin
3800035-111	Actuator	Parker Hannifin
3800035-113	Actuator	Parker Hannifin
3800035-114	Actuator	Parker Hannifin
3800035-116	Actuator	Parker Hannifin
3800035-117	Actuator	Parker Hannifin
3800035-118	Actuator	Parker Hannifin
3800035-119	Actuator	Parker Hannifin
3800035-120	Actuator	Parker Hannifin
3800504-2	IGV Actuator assy	Honeywell
3800608-1	Engine Wiring Harness	Honeywell
3800610-1	Engine Wiring Harness	Honeywell
3803-001-401	Flap Emergency Drive Gearbox	Fokker Aircraft
3803-001-703	Flap Emergency Drive Gearbox	Fokker Aircraft
3803-001-911	Flap Emergency Drive Gearbox	Fokker Aircraft
3803-003-401	Fuselage Spindle Gearbox	Fokker Aircraft
3803-003-901	Fuselage Spindle Gearbox	Fokker Aircraft
3803-004-401	Fuselage Spindle Gearbox	Fokker Aircraft
3803-004-901	Fuselage Spindle Gearbox	Fokker Aircraft
3803-005-401	Nacelle Spindle Gearbox	Fokker Aircraft
3803-005-901	Nacelle Spindle Gearbox	Fokker Aircraft
3803-006-401	Nacelle Spindle Gearbox	Fokker Aircraft
3803-006-911	Nacelle Spindle Gearbox	Fokker Aircraft
3803-007-401	Nacelle Spindle Gearbox	Fokker Aircraft
3803-007-901	Nacelle Spindle Gearbox	Fokker Aircraft

Repair_Capability_List_Excel

3803-008-401	Nacelle Spindle Gearbox	Fokker Aircraft
3803-008-901	Nacelle Spindle Gearbox	Fokker Aircraft
3803-009-407	Position Transmitter Gearbox	Fokker Aircraft
3803-009-409	Position Transmitter Gearbox	Fokker Aircraft
3803-009-411	Position Transmitter Gearbox	Fokker Aircraft
3803-011-401	Flap Main Drive Gearbox	Fokker Aircraft
3803-011-403	Flap Main Drive Gearbox	Fokker Aircraft
3803-011-703	Flap Main Drive Gearbox	Fokker Aircraft
3803-011-901	Flap Main Drive Gearbox	Fokker Aircraft
3803-012-401	Intermediate Gearbox	Fokker Aircraft
3803-012-403	Intermediate Gearbox	Fokker Aircraft
3803-012-901	Intermediate Gearbox	Fokker Aircraft
380428-10	Pneum & Shaft Power GTE	Honeywell
380428-11	Pneum & Shaft Power GTE	Honeywell
380428-12	Pneum & Shaft Power GTE	Honeywell
380428-4	Pneum & Shaft Power GTE	Honeywell
380428-4-1	Pneum & Shaft Power GTE	Honeywell
380428-4-2	Pneum & Shaft Power GTE	Honeywell
380428-6	Pneum & Shaft Power GTE	Honeywell
380428-6-1	Pneum & Shaft Power GTE	Honeywell
380428-6-2	Pneum & Shaft Power GTE	Honeywell
380428-7	Pneum & Shaft Power GTE	Honeywell
380428-7-1	Pneum & Shaft Power GTE	Honeywell
380428-7-2	Pneum & Shaft Power GTE	Honeywell
380428-8	Pneum & Shaft Power GTE	Honeywell
380428-8-1	Pneum & Shaft Power GTE	Honeywell
380428-8-2	Pneum & Shaft Power GTE	Honeywell
3805-001-401	Outboard Spindle Gearbox	Fokker Aircraft
3805-001-901	Outboard Spindle Gearbox	Fokker Aircraft
3805-003-401	Flap Synchro Unit	Fokker Aircraft
3805-003-403	Flap Synchro Unit	Fokker Aircraft
3805-003-405	Flap Synchro Unit	Fokker Aircraft
3805-003-407	Flap Synchro Unit	Fokker Aircraft
3805-003-409	Flap Synchro Unit	Fokker Aircraft
3805-003-411	Flap Synchro Unit	Fokker Aircraft
3805-003-413	Flap Synchro Unit	Fokker Aircraft
3805-003-415	Flap Synchro Unit	Fokker Aircraft
3805-003-702	Flap Synchro Unit	Fokker Aircraft
3805-003-703	Flap Synchro Unit	Fokker Aircraft
3805-003-704	Flap Synchro Unit	Fokker Aircraft
3805-003-705	Flap Synchro Unit	Fokker Aircraft
3805-003-706	Flap Synchro Unit	Fokker Aircraft
3805-003-707	Flap Synchro Unit	Fokker Aircraft
3805-003-901	Flap Synchro Unit	Fokker Aircraft
3805-003-911	Flap Synchro Unit	Fokker Aircraft
3805-010-801	Flap Asymmetry Synchro ay	Fokker Aircraft
3805-010-803	Flap Asymmetry Synchro ay	Fokker Aircraft
3806-001-401	Outboard Spindle Gearbox	Fokker Aircraft
3806-001-901	Outboard Spindle Gearbox	Fokker Aircraft
3806-003-401	Flap Synchro Unit	Fokker Aircraft
3806-003-403	Flap Synchro Unit	Fokker Aircraft
3806-003-405	Flap Synchro Unit	Fokker Aircraft
3806-003-407	Flap Synchro Unit	Fokker Aircraft
3806-003-409	Flap Synchro Unit	Fokker Aircraft
3806-003-411	Flap Synchro Unit	Fokker Aircraft
3806-003-413	Flap Synchro Unit	Fokker Aircraft
3806-003-415	Flap Synchro Unit	Fokker Aircraft
3806-003-702	Flap Synchro Unit	Fokker Aircraft

Repair_Capability_List_Excel

3806-003-703	Flap Synchro Unit	Fokker Aircraft
3806-003-704	Flap Synchro Unit	Fokker Aircraft
3806-003-705	Flap Synchro Unit	Fokker Aircraft
3806-003-706	Flap Synchro Unit	Fokker Aircraft
3806-003-707	Flap Synchro Unit	Fokker Aircraft
3806-003-708	Flap Synchro Unit	Fokker Aircraft
3806-003-901	Flap Synchro Unit	Fokker Aircraft
3806-003-911	Flap Synchro Unit	Fokker Aircraft
3806-003-921	Flap Synchro Unit	Fokker Aircraft
3806-010-801	Flap Asymmetry Synchro ay	Fokker Aircraft
3806-010-803	Flap Asymmetry Synchro ay	Fokker Aircraft
380678-4	Speed Switch	Honeywell
380-85	Hup Cap Kit	BF Goodrich
380-86	Hup Cap Kit	BF Goodrich
380-87	Hup Cap Kit	BF Goodrich
380-88	Hup Cap Kit	BF Goodrich
380-96	Brake Fan Motor assy	BF Goodrich
380968-1	Speed Switch	Honeywell
380-97-1	Fan Axle Carrier	BF Goodrich
380-98-1	Brake Fan Wheel assy	BF Goodrich
381027NP70-2	Sensor	TBV
381800-1001	Slat Actuator	Parker Hannifin
381800-1003	Slat Actuator	Parker Hannifin
381800-1005	Slat Actuator	Parker Hannifin
381923	Hydraulic Motor	Vickers
382000-1001	Flap Actuator	Parker Hannifin
382-03-000	Flight Compartment Door Lock	Buhl
382-05-000	Flight Compartment Door Lock	Buhl
382-07-000	Lavatory Door Lock	Buhl
382-09-000	Lavatory Door Lock	Buhl
382-15-000	Lavatory Door Lock	Buhl
38215-262	Solenoid Valve	Goodrich Control Systems
382-25-000	Wardrobe Door Lock	Buhl
3822556-1	Stop Mechanism	Honeywell
382-26-000	Wardrobe Door Lock	Buhl
382300-1	Booster Pump	Argo Tech
382300-2	Booster Pump	Argo Tech
382300-3	Booster Pump	Argo Tech
382401-26	Fuel Booster Pump	Argo Tech
382401-27	Fuel Booster Pump	Argo Tech
382401-28	Fuel Booster Pump	Argo Tech
382401-29	Fuel Booster Pump	Argo Tech
382401-30	Fuel Booster Pump	Argo Tech
382401-32	Fuel Booster Pump	Argo Tech
382401-34	Fuel Booster Pump	Argo Tech
382401-36	Fuel Booster Pump	Argo Tech
382927	Hydraulic Power Transfer Package	Vickers
3830041-101	Actuator	Parker Hannifin
3830041-101K	Actuator	Parker Hannifin
3830041-103	Actuator	Parker Hannifin
3830041-103K	Actuator	Parker Hannifin
3830041-104	Actuator	Parker Hannifin
3830041-104K	Actuator	Parker Hannifin
3830041-105	Actuator	Parker Hannifin
3830041-106	Actuator	Parker Hannifin
3830041-107	Actuator	Parker Hannifin
3830041-108	Actuator	Parker Hannifin
3830041-109	Actuator	Parker Hannifin

Repair_Capability_List_Excel

3830061-103	Accumulator	Parker Hannifin
3830061-104	Accumulator	Parker Hannifin
383152-1-2	Engine Starter	Honeywell
383152-16-1	Engine Starter	Honeywell
383152-19-1	Engine Starter	Honeywell
383152-5-1	Engine Starter	Honeywell
383152-6-1	Engine Starter	Honeywell
383152-7-1	Engine Starter	Honeywell
383152-8-1	Engine Starter	Honeywell
383496-1-1	Engine Starter	Honeywell
383496-2-1	Engine Starter	Honeywell
384022-1-2	Engine Starter	Honeywell
384022-1-3	Engine Starter	Honeywell
384022-2-1	Engine Starter	Honeywell
384022-3-1	Engine Starter	Honeywell
384022-4-1	Engine Starter	Honeywell
384022-4-2	Engine Starter	Honeywell
384022-5-1	Engine Starter	Honeywell
384178-072	Switch	Simmonds Precision
384300	Fuel Pump	Argo Tech
384301-009	Thermo Controller	Simmonds Precision
384301-10	FUEL GEAR PUMP	ARGOTECH
384301-2	Fuel Pump	Argo Tech
384301-3	Fuel Pump	Argo Tech
384301-4	Fuel Pump	Argo Tech
384301-5	Fuel Pump	Argo Tech
384301-6	Fuel Pump	Argo Tech
384301-7	Fuel Pump	Argo Tech
384301-8	FUEL GEAR PUMP	ARGOTECH
384301-9	FUEL GEAR PUMP	ARGOTECH
384369-01488	Load Limit Controller	Simmonds Precision
384369-01825	Load Limit Controller	Simmonds Precision
384369-020	Load Limit Controller	Simmonds Precision
384369-023	Load Limit Controller	Simmonds Precision
384486	Tachymeter Transmitter	Simmonds Precision
3850125-101	Landing Gear Valve	Parker Hannifin
3850125-102	Landing Gear Valve	Parker Hannifin
3850125-103	Landing Gear Valve	Parker Hannifin
385840	Hydraulic Motor	Vickers
3860060-101	Lower Rudder Actuator	Parker Hannifin
3860060-102	Lower Rudder Actuator	Parker Hannifin
3860061-101	Upper Rudder Actuator	Parker Hannifin
3860061-102	Upper Rudder Actuator	Parker Hannifin
3862160-3	Cooling Fan	Honeywell
3862160-4	Cooling Fan	Honeywell
3862160-5	Cooling Fan	Honeywell
3862160-9	Cooling Fan	Honeywell
3862775-1	Fan	Honeywell
3862775-2	Fan	Honeywell
3862775-3	Fan	Honeywell
386TA01	Restrictor	Bronzavia-Air Equipment
3870127-102	Compensator assy	Parker Hannifin
38702-4	Pressure Gauge	Bourdon
38702-7	Pressure Gauge	Bourdon
3876023-2	Oil Temperature Switch	Honeywell
3876072-2	Inlet Temperature Sensor	Honeywell
3876166-1	De-Oil Sol Valve	Honeywell
3876259-1	Three Speed Switch	Honeywell

Repair_Capability_List_Excel

3876259-2	Three Speed Switch	Honeywell
3876356-1	De-Oiling Solenoid Valve	Honeywell
387B010000	Solenoid Thermostat	Liebherr Aerospace
387B030000	Solenoid Thermostat	Liebherr Aerospace
387B030000 Amdt A	Solenoid Thermostat	Liebherr Aerospace
387B040000	Solenoid Thermostat	Liebherr Aerospace
3880050-101	Actuator	Parker Hannifin
3880130-5	Lube Pump	Honeywell
3880130-6	Lube Pump	Honeywell
3880799-1	Oil Cooler	Honeywell
3881000-2	Oil Pump assy	Honeywell
3881000-4	Oil Pump assy	Honeywell
3881000-5	Oil Pump assy	Honeywell
3881000-6	Oil Pump assy	Honeywell
388134-1	NC Solenoid Valve	Honeywell
388134-3	NC Solenoid Valve	Honeywell
388134-4	NC Solenoid Valve	Honeywell
388134-5	NC Solenoid Valve	Honeywell
388222	Hydraulic Pump	Vickers
3882639-1	Fuel Check Valve	Honeywell
3882639-2	Fuel Check Valve	Honeywell
3882639-3	Fuel Check Valve	Honeywell
3883220-1	IGV Actuator assy	Honeywell
3883220-2	IGV Actuator assy	Honeywell
3883220-3	IGV Actuator assy	Honeywell
3884538-1	Shut-Off Valve	Honeywell
3884538-2	Shut-Off Valve	Honeywell
3884538-3	Shut-Off Valve	Honeywell
3884569-1	Shut-Off Valve	Honeywell
3884569-2	Shut-Off Valve	Honeywell
3884569-3	Shut-Off Valve	Honeywell
3884713-3	Duct	Honeywell
3886070-1	IGV Actuator	Honeywell
3886070-2	IGV Actuator	Honeywell
3886070-3	IGV Actuator	Honeywell
3886070-4	IGV Actuator	Honeywell
3886167-2	IGV Actuator assy	Honeywell
3886167-3	IGV Actuator assy	Honeywell
3886168-1	Inlet Guide Vane	Honeywell
3886169-1	IGV Actuator assy	Honeywell
3886182-1	IGV Actuator assy	Honeywell
3886188-2	IGV Actuator assy	Honeywell
3888058-3	Ignition Exciter	Honeywell
3888058-5	Ignition Exciter	Honeywell
3888076-1	Igniter Plug Lead	Honeywell
3888076-2	Igniter Plug Lead	Honeywell
3888076-3	Igniter Plug Lead	Honeywell
3888134-1	NC Solenoid Valve	Honeywell
3888448	Wiring Harness	Honeywell
3888449	Wiring Harness	Honeywell
3888458-3	Engine Wiring Harness	Honeywell
388B010000	Thermostat	Liebherr Aerospace
388C010000	Thermostat	Liebherr Aerospace
388C030000	Thermostat	Liebherr Aerospace
388D010000	Thermostat	Liebherr Aerospace
389GC01Y01	Battery Charge Controller	ECE
389GC01Y02	Battery Charge Controller	ECE
389GC01Y03	Battery Charge Controller	ECE

Repair_Capability_List_Excel

38E01-1A	Air Safety Valve	Bendix
38E01-2A	Air Safety Valve	Bendix
38E01-3A	Air Safety Valve	Bendix
38E01-4A	Air Safety Valve	Bendix
38E01-5A	Air Safety Valve	Bendix
38E01-6A	Air Safety Valve	Bendix
38E01-7A	Air Safety Valve	Bendix
38E63-12A	Distributor Valve	Bendix
38E63-12B	Distributor Valve	Bendix
38E63-12C	Distributor Valve	Bendix
38E63-1B	Distributor Valve	Bendix
38E85-2B	Pressure Regulator & Relief Valve	Bendix
38E93-5	Anti-Ice Valve	Grimes Aerospace
390017	Hydraulic Motor	Vickers
390060	Hydraulic Pump	Vickers
3901035	Jet Pump	FR Hitemp
3901055	Jet Pump	FR Hitemp
3901100	Jet Pump	FR Hitemp
3901395	Scavenge Jet Pump	FR Hitemp
3901515	Jet Pump	FR Hitemp
39-043A	Control Valve	Hydro-Aire
39-047	Control Valve	Hydro-Aire
3906	Turn & Slip Indicator	Bendix
3907	Turn & Slip Indicator	Bendix
3907130402	Full Color Display Unit	Thales
3907-1KA1-1	Turn & Slip Indicator	Bendix
3907-1MA1-1	Turn & Bank Indicator	Bendix
3909295	Valve assy	FR Hitemp
390984	Hydraulic Motor	Vickers
39-101	Control Valve	Hydro-Aire
39-101-1	Control Valve	Hydro-Aire
391057-06094	Fuel Transmitter	Simmonds Precision
391057-06097	Tank Unit	Simmonds Precision
391057-06245	Tank Unit	Simmonds Precision
39-107	Anti-Skid Valve	Crane
3913275-5001	Ground Spoiler	McDonnell Douglas
391357	Hydraulic Motor	Vickers
3914016-5001	MLG Cylinder	Douglas
3914016-5501	MLG Cylinder	Douglas
3914016-5503	MLG Cylinder	Douglas
3914016-5505	MLG Cylinder	Douglas
3915180-5001	Hydraulic Swivel Gland assy	Douglas
3915180-5501	Hydraulic Swivel Gland assy	Douglas
3915180-5503	Hydraulic Swivel Gland assy	Douglas
3915878-5001	Manifold	Douglas
3915878-5501	Manifold	Douglas
3915878-5503	Manifold	Douglas
3916301-5001	Flight Spoiler	McDonnell Douglas
3917382-5001	Cylinder	Douglas
3918668-5001	Gear Pump	McDonnell Douglas
3919-1A	Indicator	Bendix/King
39-20V4	Rate Gyro	Thales Avionics
392166-2-1	Valve	Honeywell
392220-1-1	Flow Control Butterfly Valve	Honeywell
392220-3-1	Flow Control Butterfly Valve	Honeywell
392234-10-1	Pressure Regulator	Honeywell
392234-1-1	Pressure Regulator	Honeywell
392234-3-1	Pressure Regulator	Honeywell

Repair_Capability_List_Excel

392234-4-1	Pressure Regulator	Honeywell
392234-5-1	Pressure Regulator	Honeywell
39-233-1	Skid Control Modular	Hydro-Aire
39-233-1A	Skid Control Modular	Hydro-Aire
39-233-1B	Skid Control Modular	Hydro-Aire
39-233-1C	Skid Control Modular	Hydro-Aire
39-233-2	Skid Control Modular	Hydro-Aire
39-233-2A	Skid Control Modular	Hydro-Aire
39-233-3	Skid Control Modular	Hydro-Aire
39-233-3A	Skid Control Modular	Hydro-Aire
39-233-3B	Skid Control Modular	Hydro-Aire
39-233-3C	Skid Control Modular	Hydro-Aire
39-233-3D	Skid Control Modular	Hydro-Aire
39-233-4	Skid Control Modular	Hydro-Aire
392452-1	Shut-Off Valve	Honeywell
392452-1-1	Shut-Off Valve	Honeywell
392454-1-1	Regulator	Honeywell
392454-3-1	Regulator	Honeywell
39-249	Control Valve	Hydro-Aire
39-249-1	Control Valve	Hydro-Aire
39-249-2	Valve assy	Crane
392530-1	Press.Regulator Shut-Off Valve	Honeywell
392530-10	Press.Regulator Shut-Off Valve	Honeywell
392530-1-1	Press.Regulator Shut-Off Valve	Honeywell
392530-2	Press.Regulator Shut-Off Valve	Honeywell
392530-2-1	Press.Regulator Shut-Off Valve	Honeywell
392530-3	Press.Regulator Shut-Off Valve	Honeywell
392530-3-1	Press.Regulator Shut-Off Valve	Honeywell
392530-8	Press.Regulator Shut-Off Valve	Honeywell
392530-9	Press.Regulator Shut-Off Valve	Honeywell
392614-1-1	Pressure Regulator	Honeywell
392614-2	Pressure Regulator	Honeywell
392614-2-1	Pressure Regulator	Honeywell
392664-1-1	Shutoff Airflow Regulator	Honeywell
392664-2-1	Shutoff Airflow Regulator	Honeywell
392678-1-1	Valve assy	Honeywell
392678-3-1	Valve assy	Honeywell
392686-3	Diff. Pressure Regulator	Honeywell
392686-3-1	Diff. Pressure Regulator	Honeywell
392688-10-1	Regulator Shut-Off Valve	Honeywell
392688-1-1	Regulator Shut-Off Valve	Honeywell
392688-11-1	Regulator Shut-Off Valve	Honeywell
392688-12-1	Regulator Shut-Off Valve	Honeywell
392688-16-1	Regulator Shut-Off Valve	Honeywell
392688-17-1	Regulator Shut-Off Valve	Honeywell
392688-18-1	Regulator Shut-Off Valve	Honeywell
392688-19-1	Regulator Shut-Off Valve	Honeywell
392688-21-1	Regulator Shut-Off Valve	Honeywell
392688-22-1	Regulator Shut-Off Valve	Honeywell
392688-5-1	Regulator Shut-Off Valve	Honeywell
392688-6-1	Regulator Shut-Off Valve	Honeywell
392688-7-1	Regulator Shut-Off Valve	Honeywell
392688-8-1	Regulator Shut-Off Valve	Honeywell
392688-9-1	Regulator Shut-Off Valve	Honeywell
392708-1-1	Thermostatic Airflow Regulator	Honeywell
392708-2-1	Regulator	Honeywell
392708-3-1	Regulator	Honeywell
392710-1-1	Pneumatic Shut-Off Valve	Honeywell

Repair_Capability_List_Excel

392710-1-2	Pneumatic Shut-Off Valve	Honeywell
392710-2	Pneumatic Shut-Off Valve	Honeywell
392714-1-1	Shut-Off Valve	Honeywell
392716-1-1	Pneumatic Shut-Off Valve	Honeywell
392716-3-1	Pneumatic Shut-Off Valve	Honeywell
3927920-3	Valve assy	Honeywell
392796-2-1	Shut-Off Valve	Honeywell
392796-2-2	Shut-Off Valve	Honeywell
392796-3-1	Shut-Off Valve	Honeywell
392796-5	Shut-Off Valve	Honeywell
392796-6	Shut-Off Valve	Honeywell
3928137-5001	Retracting Cylinder	Douglas
392827	Power Transfer Unit	Vickers
392914-1-1	Pressure Regulator	Honeywell
392964-1	Valve	Honeywell
392964-1-1	Valve	Honeywell
392964-2	Valve	Honeywell
392964-2-1	Valve	Honeywell
392974-1	Shut-Off Valve	Honeywell
392974-1-1	Shut-Off Valve	Honeywell
392974-5-1	Shut-Off Valve	Honeywell
392974-6	Shut-Off Valve	Honeywell
393004-01409	Quantity Indicator	Simmonds Precision
393020-01789	Indicator	Simmonds Precision
393026-001	Fuel Indicator	Simmonds Precision
393026-002	Fuel Indicator	Simmonds Precision
393026-003	Fuel Indicator	Simmonds Precision
393026-01837	Fuel Indicator	Simmonds Precision
393026-01838	Fuel Indicator	Simmonds Precision
393026-01840	Fuel Indicator	Simmonds Precision
393026-01841	Fuel Indicator	Simmonds Precision
393026-01880	Fuel Indicator	Simmonds Precision
393026-03235	Fuel Indicator	Simmonds Precision
393026-03236	Fuel Indicator	Simmonds Precision
393026-03508	Fuel Indicator	Simmonds Precision
393026-03569	Fuel Indicator	Simmonds Precision
393026-036	Fuel Indicator	Simmonds Precision
393026-037	Fuel Indicator	Simmonds Precision
393026-040	Fuel Indicator	Simmonds Precision
393026-042	Fuel Indicator	Simmonds Precision
393026-044	Fuel Indicator	Simmonds Precision
393026-047	Fuel Indicator	Simmonds Precision
393026-048	Fuel Indicator	Simmonds Precision
393026-052	Fuel Indicator	Simmonds Precision
393084-031	Transmitter	Simmonds Precision
393084-036	Transmitter	Simmonds Precision
393084-054	Transmitter	Simmonds Precision
393084-22488	Fuel Quantity Indicator	Simmonds Precision
393084-22825	Fuel Quantity Indicator	Simmonds Precision
3934-1AG-B1-1	Turn and Slip Indicator	Bendix/King
3934-1AG-C1-1	Turn and Slip Indicator	Bendix/King
3934689-5001	Cylinder	Douglas
3934689-5501	Cylinder	Douglas
39-353	Control Valve	Hydro Aire
3937033-5501	Cylinder	Douglas
3937033-5503	Cylinder	Douglas
393TS02Y02	Probe Heating Control Unit	ECE
393TS02Y03	Probe Heating Control Unit	ECE

Repair_Capability_List_Excel

393TS02Y05	Probe Heating Control Unit	ECE
39-483	Control Valve	Hydro-Aire
39-491-1	Skid Control Modular	Hydro-Aire
39-491-3	Skid Control Modular	Hydro-Aire
39-525-1	Skid Control Modular	Hydro-Aire
39-525-3	Skid Control Modular	Hydro-Aire
395400-1011	Spoiler Actuator	Parker Hannifin
395400-1013	Spoiler Actuator	Parker Hannifin
39-557	Valve assy	Hydro-Aire
395812	Hydraulic Power Transfer Package	Vickers
396-00740	Oil Pressure Indicator	Edison
396-01740	Oil Pressure Indicator	Edison
396028-1-1	Valve assy	Honeywell
396028-4-1	Valve assy	Honeywell
396028-6-1	Valve assy	Honeywell
396064-1-1	Flow Control Valve	Honeywell
396088-3-1	Control Valve	Honeywell
396088-4-1	Control Valve	Honeywell
396-100S1	Oil Pressure Indicator	Edison
396-100S1-D1	Oil Pressure Indicator	Edison
396130-1-1	Flow Control Valve	Honeywell
396132-1-1	Flow Control Valve	Honeywell
39-617	Valve assy	Crane
396196-10	Flow Control Valve	Honeywell
396196-10AT1	Flow Control Valve	Honeywell
396196-13	Flow Control Valve	Honeywell
396196-7	Flow Control Valve	Honeywell
396196-8	Flow Control Valve	Honeywell
396196-9	Flow Control Valve	Honeywell
396276-1	Air Flow Sensor	Honeywell
396300-1007	Actuator	Goodrich
396362	Electric Motor	Vickers
396372-2	Flow Control Valve	Honeywell
396416-1	Flow Control Valve	Honeywell
396416-2	Flow Control Valve	Honeywell
396416-3	Flow Control Valve	Honeywell
396430-2	Valve assy	Honeywell
396430-4	Valve assy	Honeywell
396432-1	Flow Control Valve	Honeywell
396432-2	Flow Control Valve	Honeywell
396432-3	Flow Control Valve	Honeywell
396436-2	Valve assy	Honeywell
396442-1	Flow Control Valve	Honeywell
396462-1	Flow Control Valve	Honeywell
396462-2	Flow Control Valve	Honeywell
396496-1	Shut-Off Valve	Honeywell
396498-1	Flow Control Valve	Honeywell
396498-2	Flow Control Valve	Honeywell
396516-1	Flow Control Valve	Honeywell
396516-2	Flow Control Valve	Honeywell
396516-3	Flow Control Valve	Honeywell
396582-2	Flow Control Valve	Honeywell
396608-1	Flow Control Valve	Honeywell
39-685-2	Antiskid Module	Hydro-Aire
397018-1	Shut-Off Valve	Honeywell
397018-1-1	Shut-Off Valve	Honeywell
397066-1	Water Separator Temp.Cont.Valve	Honeywell
397066-4	Water Separator Temp.Cont.Valve	Honeywell

Repair_Capability_List_Excel

39-729	Valve assy	Crane
397364-3-1	Valve assy	Honeywell
397531003	Shaft Assembly	Goodrich Control Systems
397728-1-1	Shut-Off Valve	Honeywell
397728-3-1	Shut-Off Valve	Honeywell
397728-4-1	Shut-Off Valve	Honeywell
397728-4-2	Shut-Off Valve	Honeywell
397728-6-1	Shut-Off Valve	Honeywell
397728-7-1	Shut-Off Valve	Honeywell
397728-8	Shut-Off Valve	Honeywell
39-777-1	Valve assy	Crane
397802-4	Valve assy	Honeywell
397802-5	Valve assy	Honeywell
397802-6	Valve assy	Honeywell
397802-7	Valve assy	Honeywell
397802-8	Valve assy	Honeywell
397860-1	Valve assy	Honeywell
397860-2	Valve assy	Honeywell
397860-3	Valve assy	Honeywell
397860-5	Valve assy	Honeywell
397868-1-1	Pneumatic Shutoff Valve	Honeywell
397892-1	Starter Valve assy	Honeywell
397B01000	Thermostat	Liebherr Aerospace
397B02000	Thermostat	Liebherr Aerospace
397B020000	Solenoid Thermostat	Liebherr Aerospace
397B03000	Thermostat	Liebherr Aerospace
398000-1	Pump & Lock Ring	Goodrich Control Systems
39-807	Brake Control Valve	Crane
398116-1-1	Valve assy	Honeywell
398148-2-1	Butterfly Valve	Honeywell
398310-2-1	Shut-Off Valve	Honeywell
398310-3-1	Shut-Off Valve	Honeywell
398310-4-1	Shut-Off Valve	Honeywell
398310-5-1	Shut-Off Valve	Honeywell
398396-2	Valve assy	Honeywell
398396-3	Valve assy	Honeywell
398396-4	Valve assy	Honeywell
398396-5	Valve assy	Honeywell
398398-2	Valve assy	Honeywell
398398-3	Valve assy	Honeywell
398444-1-1	Valve	Honeywell
398444-2-1	Valve	Honeywell
398504-2	Pneumatic System Isolation Valve	Honeywell
398528-1	Valve Pack Shut-Off	Honeywell
39854	Rotary Actuator	Allied Signal
398540-2-1	Valve	Honeywell
398542-1-1	Shut-Off Valve	Honeywell
398542-2-1	Shut-Off Valve	Honeywell
398554-2	Valve assy	Honeywell
398554-3	Valve assy	Honeywell
398554-4	Valve assy	Honeywell
39858	Actuator	Allied Signal
398626-1	Shut-Off Valve	Honeywell
398626-1-1	Shut-Off Valve	Honeywell
398750-2	Control Valve	Honeywell
398750-3	Control Valve	Honeywell
398750-4	Control Valve	Honeywell
398750-5	Control Valve	Honeywell

Repair_Capability_List_Excel

398774-2	Shut-Off Valve	Honeywell
398774-3	Shut-Off Valve	Honeywell
398774-4	Shut-Off Valve	Honeywell
398774-5	Shut-Off Valve	Honeywell
398774-6	Shut-Off Valve	Honeywell
398774-7	Shut-Off Valve	Honeywell
398774-8	Shut-Off Valve	Honeywell
398774-9	Shut-Off Valve	Honeywell
398786-2	Modulating Valve	Honeywell
398786-3	Modulating Valve	Honeywell
398786-4	Modulating Valve	Honeywell
398786-5	Modulating Valve	Honeywell
398908-2	Temperature Control Valve	Honeywell
398908-3	Temperature Control Valve	Honeywell
398946-1	Turbine By-Pass Valve	Honeywell
398946-2	Turbine By-Pass Valve	Honeywell
398B010000	Thermostat	Liebherr Aerospace
398B020000	Thermostat	Liebherr Aerospace
398B030000	Thermostat	Liebherr Aerospace
398D-X-01	Direction Indicator	Kollsman
398F-X-01	Direction Indicator	Kollsman
39B168-1-A	Static Inverter	Honeywell
39B168-1-B	Static Inverter	Honeywell
39B168-1-C	Static Inverter	Honeywell
3A125-1B	Inverter assy	Avionic Instruments
3A155-3400	End Fitting assy	Goodrich Control Systems
3A155-3500	Universal Joint assy	Goodrich Control Systems
3A155-3500-01	Universal Joint assy	Goodrich Control Systems
3A155-3500L	Universal Joint assy	Goodrich Control Systems
3A2-203B	Transducer Rotary	MPC Products
3A250-1A	Inverter assy	Avionic Instruments
3A350-1A	Inverter assy	Avionic Instruments
3A50-1B-1	Inverter assy	Avionic Instruments
3B39-1B	Electrical Load Control Unit	Honeywell
3B39-1C	Electrical Load Control Unit	Honeywell
3B39-2A	Electrical Load Control Unit	Honeywell
3B41-1A	Electrical Load Control Unit	Honeywell
3B41-1B	Electrical Load Control Unit	Honeywell
3B41-3A	Electrical Load Control Unit	Honeywell
3B41-3B	Electrical Load Control Unit	Honeywell
3D307-1	Fuel Flow Indicator	Elliott
3D377	Fuel Flow Transmitter	Elliott
3D658-1	Fuel Flow Indicator	Elliott
3F2202A	Flight Spoiler Control Lever	Thales Avionics
3M3	Motor assy	FR Hitemp
3M3-1	Lightweight Motor Unit	FR Hitemp
3M3-203C	Transducer	MPC Products
3M3-205A	Transducer	MPC Products
3M4	Lightweight Motor Unit	FR Hitemp
3M4-1	Lightweight Motor Unit	FR Hitemp
3S2060DM169A1	Battery Charger	BF Goodrich
3S2060DM169A3	Battery Charger	BF Goodrich
3S2060DV108B1	Static Inverter	BF Goodrich
3U3141-2	Flow Regulator	Smiths Industries
3U3175	Selector Valve	Dowty Aerospace
3U3196	Engine Pump Valve	Dowty Aerospace
3U3211	Compensator	Dowty Aerospace
3U3211-1	Compensator	Dowty Aerospace

Repair_Capability_List_Excel

3U3322-14	Elevator Actuator	Frisby Aerospace
4000-11B	Emergency Locator Xmtr	Thales Avionics
40-0061-1	Light	Grimes Aerospace
40-0061-5	Light	Grimes Aerospace
40-0074-11	Light	Grimes Aerospace
40-0074-13	Light	Grimes Aerospace
40-0074-15	Light	Grimes Aerospace
40-0074-17	Light	Grimes Aerospace
40-0074-19	Light	Grimes Aerospace
40-0103-31	Navigation Warning Light	Grimes Aerospace
400117	Check Valve	FR Hitemp
40-0135-10	Wing Position Nav Light assy	Grimes Aerospace
40-0135-3	Wing Position Nav Light assy	Grimes Aerospace
40-0135-4	Wing Position Nav Light assy	Grimes Aerospace
40-0135-5	Wing Position Nav Light assy	Grimes Aerospace
40-0135-6	Wing Position Nav Light assy	Grimes Aerospace
40-0135-7	Wing Position Nav Light assy	Grimes Aerospace
40-0135-8	Wing Position Nav Light assy	Grimes Aerospace
40-0135-9	Wing Position Nav Light assy	Grimes Aerospace
40-0196-11	Light	Grimes Aerospace
40-0196-13	Light	Grimes Aerospace
400300-1	Shut-Off Valve	Sabre
400300-2	Shut-Off Valve	Sabre
4004TC00101	Selector	Lucas Aerospace
4004TC01	Selector	Lucas Aerospace
4004TC02	Selector	Lucas Aerospace
4004TC03	Selector	Lucas Aerospace
4004TD0101	Selector	Lucas Aerospace
4006092	Switch	Simmonds Precision
40068	Hydraulic Pump	Abex
40070	Hydraulic Motor	Abex
40070-01	Hydraulic Motor	Abex
40073	Hydraulic Pump	Abex
400970-503	Engine Kit	Pratt & Whitney
40099-01	Hydraulic Motor	Abex
40099-04	Hydraulic Motor	Abex
40109	Hydraulic Pump	Abex
401-09410-01	Brake assy	Moog
401-09410-02	Brake assy	Moog
401-09410-03	Brake assy	Moog
401-09410-10	Brake assy	Moog
40109B	Hydraulic Pump	Abex
401-15149	Hand Pitch Feel Trim ay	Moog
4013013-905	Indicator	Honeywell
4013013-913	Vertical Speed Indicator	Honeywell
40147	Hydraulic Pump	Abex
401494	Hydraulic Motorpump assy	Vickers
40157	Hydraulic Pump	Abex
401-66000	Hand Feel Trim ay	Moog
401-66001	Electrical Trim Actuator ay	Moog
401-66002	Mechanical Trim Actuator ay	Moog
401-66003	Electrical Feel Program.Actuator ay	Moog
401-66004	Mech. Feel Program.Actuator ay	Moog
401-66077	Linear Differential Transformer	Moog
401-66084-01	Motor Generator	Moog
401-66221-01	Motor Tachometer	Moog
401-66221-03	Motor Tachometer	Moog
401-67300	Inboard Spoiler Servo Control	Moog

Repair_Capability_List_Excel

401-67310	Mid-Spoiler Spoiler Servo Control	Moog
401-67320	Outboard Spoiler Servo Control	Moog
401-67400	Direct Lift Servo Control	Moog
401-67814	Hand Feel Unit ay	Moog
401-67815	Hand Feel Unit ay	Moog
40176	Hydraulic Motor	Parker Hannifin
40180	Hydraulic Pump	Abex
4018001	Hydraulic Pump	Abex
4019501	AC Electric Pump	Parker Hannifin
4019501D	AC Electric Pump	Parker Hannifin
40198954	Drive Flexible Shaft	ECE
4020226	Fuel Tank Cable	ECE
40205-3-4559	Landing Light	Grimes Aerospace
40205-3Q4559	Landing Light	Grimes Aerospace
40205-3Q4559X	Landing Light	Grimes Aerospace
4020761	Motor assy	ECE
4020E60-2	Screen Filter assy	Le Bozec
4020W35-1	Rain Repellent Gage	Le Bozec
4020W35-2	Rain Repellent Gage	Le Bozec
4020W35-3	Rain Repellent Gage	Le Bozec
40-249	Anti-Skid Controller	Hydro-Aire
40-249A	Anti-Skid Controller	Hydro-Aire
40-249B	Anti-Skid Controller	Hydro-Aire
4027170-901	Horizon Situation Indicator	Sperry
4027170-902	Horizon Situation Indicator	Sperry
4027170-904	Horizon Situation Indicator	Sperry
4027170-905	Horizon Situation Indicator	Sperry
4029529-901	Horizon Situation Indicator	Sperry
4029529-902	Horizon Situation Indicator	Sperry
4029529-903	Horizon Situation Indicator	Sperry
4029529-904	Horizon Situation Indicator	Sperry
402EED1-1	Standby Engine Indicator	Smiths Industries
402EED1-3	Standby Engine Indicator	Smiths Industries
402EED2-1	Standby Engine Indicator	Smiths Industries
402EED3-2	Standby Engine Indicator	Smiths Industries
402Q12-2	Protective Device	Le Bozec
402TS02Y	Control assy	ECE
402TS02Y01	Control assy	ECE
4031474-903	Autopilot Status Panel	Grimes Aerospace
4032466	Flexible Control	ECE
40340-10008	Selector Valve	Kayaba Industry
40340-10009	Selector Valve	Kayaba Industry
40340-10010	Selector Valve	Kayaba Industry
40340-10011	Selector Valve	Kayaba Industry
40340-10013	Selector Valve	Kayaba Industry
4034559-901	Distance Bearing Indicator	Honeywell
4034559-902	Distance Bearing Indicator	Honeywell
4034559-903	Indicator	Honeywell
4034559-904	Indicator	Honeywell
4034559-908	Distance Bearing Indicator	Honeywell
4034559-909	Distance Bearing Indicator	Honeywell
4034559-910	Distance Bearing Indicator	Honeywell
4037102	Light	ECE
4037132	Light	ECE
403756	Hydraulic Motorpump assy	Vickers
4039891-903	Mach Airspeed Indicator	Honeywell
4039891-904	Mach Airspeed Indicator	Honeywell
4039891-905	Mach Airspeed Indicator	Honeywell

Repair_Capability_List_Excel

4039891-906	Mach Airspeed Indicator	Honeywell
4039891-907	Mach Airspeed Indicator	Honeywell
4039892-904	Barometric Altimeter	Honeywell
4039892-905	Barometric Altimeter	Honeywell
4039892-906	Barometric Altimeter	Honeywell
4039892-907	Barometric Altimeter	Honeywell
4039892-908	Barometric Altimeter	Honeywell
4039892-909	Barometric Altimeter	Honeywell
4039892-910	Barometric Altimeter	Honeywell
4039893-902	Vertical Speed Indicator	Honeywell
4039893-903	Vertical Speed Indicator	Honeywell
403TS02Y	Control Unit	ECE
403TS02Y01	Control Unit	ECE
40400-000	Drain Valve	Westland-Sitec
404250	Power Transfer Unit	Vickers
404A0100	Jet Pump	Liebherr Aerospace
40-533	Anti-Skid Detector Transducer	Crane
4056511-903	DIM Control Panel	Honeywell
4056511-904	DIM Control Panel	Honeywell
40574	Actuator	Argo-Tech
40574-2	Actuator	Argo-Tech
40574-4	Actuator	Argo-Tech
405893	Hydraulic Pump	Vickers
405894	Variable Displacement Hydraulic Pump	Vickers
40-618-11	Stabilizer Trim Indicator	Meggitt
40-618-12	Stabilizer Trim Indicator	Meggitt
40-618-2	Stabilizer Trim Indicator	Meggitt
40-618-4	Stabilizer Trim Indicator	Meggitt
40-618-5	Stabilizer Trim Indicator	Meggitt
40-618-6	Stabilizer Trim Indicator	Meggitt
40-618-7	Stabilizer Trim Indicator	Meggitt
40-618-8	Stabilizer Trim Indicator	Meggitt
40-625	Transducer	Hydro-Aire
40-625-2	Transducer	Hydro-Aire
40-625-4	Transducer	Hydro-Aire
40-625-4A	Transducer	Hydro-Aire
40-625-5	Transducer	Hydro-Aire
40-625-6	Transducer	Hydro-Aire
40-62575	Transducer	Hydro-Aire
4063-16082-2	Isolation Valve	Nord-Micro
4063-16082-3	Isolation Valve	Nord-Micro
4063-16083	Isolation Valve	Nord-Micro
4063-16085-3	Isolation Valve	Nord-Micro
4063-18139	Check Valve	Nord-Micro
4063-18140	Check Valve	Nord-Micro
4063-18140-01	Check Valve	Nord-Micro
4063-18167-1	Recirculation Valve	Nord-Micro
4063-18167-1 Amdt A	Recirculation Valve	Nord-Micro
4063-18167-1 Amdt A/B	Recirculation Valve	Nord-Micro
4063-18167-1 Amdt B	Recirculation Valve	Nord-Micro
4063-18202-1	APU Check Valve	Nord-Micro
4063-18202-2	APU Check Valve	Nord-Micro
4063-18203	Cross Bleed Isolation Valve	Nord-Micro
4063-18204-1	Cold Air Valve	Nord-Micro
4063-18221	Isolation Valve	Nord-Micro
4063-18221 Amdt A	Isolation Valve	Nord-Micro
4063-18221 Amdt AB	Isolation Valve	Nord-Micro
4063-18221 Amdt ABC	Isolation Valve	Nord-Micro

Repair_Capability_List_Excel

4063-18221 Amdt AC	Isolation Valve	Nord-Micro
4063-18221 Amdt B	Isolation Valve	Nord-Micro
4063-18221 Amdt BC	Isolation Valve	Nord-Micro
4063-18221 Amdt C	Isolation Valve	Nord-Micro
4063-19972-01AA	Cabin Pressure Outflow Valve	Nord Micro
4063-19972-01AB	Cabin Pressure Outflow Valve	Nord Micro
4064198	Cable assy	ECE
4064198C	Cable assy	ECE
4065713	Wing Icing Inspection Light	ECE
4065729	Wing Icing Inspection Light	ECE
4065736	Inspection Light	ECE
4065743	Inspection Light	ECE
4065914	Fire Control Panel	ECE
4065914A	Fire Control Panel	ECE
4065914B	Fire Control Panel	ECE
4069-11	Latch assy	Adams Rite
4070-11	Latch assy	Adams Rite
40710-106	Artificial Feel Hydro Mech.Unit	Goodrich Control Systems
40710-107	Artificial Feel Hydro Mech.Unit	Goodrich Control Systems
40710-108	Artificial Feel Hydro Mech.Unit	Goodrich Control Systems
40710-230	Artificial Feel Hydro Mech.Unit	Goodrich Control Systems
4071-1	Ni-Cad Battery	Saft
4071778B	Windshield Wiper System	ECE
4072	Sensor	Labem
40720-104	Variable Lever Arm	Goodrich Control Systems
40720-105	Variable Lever Arm	Goodrich Control Systems
40720-106	Variable Lever Arm	Goodrich Control Systems
40720-107	Variable Lever Arm	Goodrich Control Systems
4075077	Depressurization Control Valve	ECE
4076124	Ram Air Control	ECE
4076131	Ram Air Control	ECE
4076965	Parking Brake Lever	ECE
4076965B	Parking Brake Lever	ECE
4077521	Taxi & Take-Off Floodlight	ECE
407A0103	Jet Pump	Liebherr Aerospace
40-817	Transducer	Hydro-Aire
40-835	Transducer	Hydro-Aire
40850	Pressure Differential Indicator	Hamilton Sundstrand
4087T100-3	Flap Power Drive Unit	Telair
4087T100-x	Trailing Edge Flap Actuator	Telair International
40884-23	Pressure Fueling Valve	Argo-Tech
40884-4	Pressure Fueling Valve	Argo-Tech
40884-44	Pressure Fueling Valve	Argo-Tech
40884-6	Pressure Fueling Valve	Argo-Tech
40884-7	Pressure Fueling Valve	Argo-Tech
40884-8	Pressure Fueling Valve	Argo-Tech
4089665	Overflow Valve Cable	ECE
4098954	Shaft Assembly	ECE
4099414	Wiper assy	ECE
4099579	Wiper Arm	ECE
4099579B	Wiper Arm	ECE
4099586	Wiper Arm	ECE
4099586B	Wiper Arm	ECE
4099593	Windshield Wiper Blade	ECE
4099593B	Windshield Wiper Blade	ECE
40997001	Ozone Converter	Engelhard
40997002	Ozone Converter	Engelhard
40997003	Ozone Converter	Engelhard

Repair_Capability_List_Excel

40C151-1	Cooling Valve	Honeywell
40E18-2	Anti-Ice Press Reg & Shut-Off Valve	Honeywell
40E18-3	Anti-Ice Press Reg & Shut-Off Valve	Honeywell
4100149	Lavatory/Galley Vent. Fan	Hamilton Sundstrand
4100149A	Lavatory/Galley Vent. Fan	Hamilton Sundstrand
4100149B	Lavatory/Galley Vent. Fan	Hamilton Sundstrand
4100149C	Lavatory/Galley Vent. Fan	Hamilton Sundstrand
4100256	Motor Hydraulic	Garrett
4100256-4	Hydraulic Motor	Honeywell
4100256-5	Hydraulic Motor	Honeywell
4100310-4	Hydraulic Pump	Honeywell
4100310-5	Hydraulic Pump	Honeywell
4100310-6	Hydraulic Pump	Honeywell
4100362-1	Flap Drive Hydraulic Motor	Frisby Aerospace
4100406-1	Slat Drive Hydraulic Motor	Frisby Aerospace
4100406-2	Hydraulic Motor	Honeywell
4100439	Parking Brake Control Lever assy	ECE
4100439B	Parking Brake Control Lever assy	ECE
4100446	Parking Brake Control Lever assy	ECE
4100446B	Parking Brake Control Lever assy	ECE
4100681	Crew Rest Fan assy	Hamilton Sundstrand
4100713B	Inlet Guide Actuator ay	APIC
4100713C	Inlet Guide Actuator ay	APIC
4100714C	Inlet Guide Actuator ay	APIC
4100714D	Inlet Guide Actuator ay	APIC
4100714E	Inlet Guide Actuator ay	APIC
41007210-102	Lateral Control Package	HR Textron
41007210-103	Lateral Control Package	HR Textron
41007230-102	Lateral Autopilot Servo	HR Textron
41007230-103	Lateral Autopilot Servo	HR Textron
41007330-101	Hydraulic Actuator	HR Textron
41007330-102	Hydraulic Actuator	HR Textron
4100762-2	Power Transfer Unit	Honeywell
4101002-11	Power Transfer Unit	Frisby Aerospace
4101002-2	Power Transfer Unit	Frisby Aerospace
4101002-20	Power Transfer Unit	Frisby Aerospace
4101002-4	Power Transfer Unit	Frisby Aerospace
4101002-5	Power Transfer Unit	Frisby Aerospace
4101002-6	Power Transfer Unit	Frisby Aerospace
4101002-7	Power Transfer Unit	Frisby Aerospace
4101002-8	Power Transfer Unit	Frisby Aerospace
4101002-9	Power Transfer Unit	Frisby Aerospace
4101002-91	Power Transfer Unit	Frisby Aerospace
4101054	Lavatory/Galley Vent. Fan	Hamilton Sundstrand
4101378	Mixed Flow Fan	Hamilton Sundstrand
4101415	Cooling Fan	Hamilton Sundstrand
4101632	Vaneaxial Fan assy	Hamilton Sundstrand
4101634	Vaneaxial Fan assy	Hamilton Sundstrand
4101636	Vaneaxial Fan assy	Hamilton Sundstrand
4101722	Mixed Flow Fan	Hamilton Sundstrand
4101724	Vaneaxial Fan assy	Hamilton Sundstrand
4101734	Axial Flow Fan assy	Hamilton Sundstrand
4101910	Recirculation Fan	Hamilton Sundstrand
4102638	Vaneaxial Fan assy	Hamilton Sundstrand
410302-5	Air Driven Pump	Honeywell
410302-6	Air Driven Pump	Honeywell
41050-10	Shock Strut Dressed	Menasco Aerospace
41050-11	Shock Strut Dressed	Menasco Aerospace

Repair_Capability_List_Excel

41050-12	Shock Strut Dressed	Menasco Aerospace
41050-13	Shock Strut Dressed	Menasco Aerospace
41050-14	Shock Strut Dressed	Menasco Aerospace
41050-15	Shock Strut Dressed	Menasco Aerospace
41050-16	Shock Strut Dressed	Menasco Aerospace
41050-5	Shock Strut Dressed	Menasco Aerospace
41050-6	Shock Strut Dressed	Menasco Aerospace
41050-7	Shock Strut Dressed	Menasco Aerospace
41050-8	Shock Strut Dressed	Menasco Aerospace
41050-9	Shock Strut Dressed	Menasco Aerospace
4105890022	Pressure Detection Unit	Labinal
4105890023	Pressure Detection Unit	Labinal
4105DA	Valve assy	Sargent
41060-1	Strut	Menasco Aerospace
41060-2	Strut	Menasco Aerospace
41060-3	Strut	Menasco Aerospace
41060-4	Strut	Menasco Aerospace
41060-5	Strut	Menasco Aerospace
41060-6	Strut	Menasco Aerospace
41063E01	Check Valve	Liebherr Aerospace
41076A01	Valve assy	Liebherr Aerospace
41115A01	Check Valve	Liebherr Aerospace
411200	SOLENOID VALVE	VICKERS
41125A01	Check Valve	Liebherr Aerospace
41140-3	Piston assy	Sterer
41140-5	Piston assy	Sterer
41152-1	Torque Link	Menasco Aerospace
41152-3	Torque Link	Menasco Aerospace
41152C010000	Check Valve	ABG Semca
41152C020000	Check Valve	Liebherr Aerospace
41157-3	Torque Link	Menasco Aerospace
411N1144-4BCCA	Shade assy	Boeing
411T3017-10	Aft Entry and Service Door	Boeing
411T3017-9	Aft Entry and Service Door	Boeing
41-2-1100	Actuator	Elektro Metall Exp.
41-2-1100-01	Actuator	Elektro Metall Exp.
41-2-1100-02	Actuator	Elektro Metall Exp.
412177	Fire Detector assy	Kidde Aerospace
412178	Fire Detector assy	Kidde Aerospace
412179	Fire Detector assy	Kidde Aerospace
412180	Fire Detector assy	Kidde Aerospace
4127360	Vent & Drain Valve	FR Hitemp
41275-5	Retract Actuator Brake	Menasco Aerospace
4129RA	Nose Steering Valve	Sargent Controls
4129RA1	Nose Steering Valve	Sargent Controls
4129RA10	Nose Steering Valve	Sargent Controls
4129RA2	Nose Steering Valve	Sargent Controls
4129RA3	Nose Steering Valve	Sargent Controls
4129RA4	Nose Steering Valve	Sargent Controls
4129RA5	Nose Steering Valve	Sargent Controls
4129RA6	Nose Steering Valve	Sargent Controls
4129RA7	Nose Steering Valve	Sargent Controls
4129RA8	Nose Steering Valve	Sargent Controls
4129RA9	Nose Steering Valve	Sargent Controls
412UZ01A	Switch	ECE
412UZ01B	Switch	ECE
413-0001	Water Heater	FL Aerospace
413-0001-1	Water Heater	FL Aerospace

Repair_Capability_List_Excel

41300-1	Lower Side Brace	Menasco Aerospace
41300-3	Lower Side Brace	Menasco Aerospace
41300-5	Lower Side Brace	Menasco Aerospace
4131020-1	Lube Module	Honeywell
4131020-2	Lube Module	Honeywell
4131020-3	Lube Module	Honeywell
4131020-4	Lube Module	Honeywell
4133801010	Rotating mechanism	Labinal
4133801030	Pressure Transducer	Labinal
4133801060	Holder Transducer	Labinal
4134T100-x	Slat Actuator	Telair International
41350-1	Upper Side Brace	Menasco Aerospace
41350-5	Upper Side Brace	Menasco Aerospace
4135T100-3	Slat Power Drive Unit	Telair
4135T100-x	Slat Actuator	Telair International
4136T100-1	Power Drive Unit	Telair
4136T100-x	Trailing Edge Flap Actuator	Telair International
4137T100-1	Power Drive Unit	Telair
4137T100-x	Trailing Edge Flap Actuator	Telair International
41390-10	Shuttle Valve	Sterer
41400-1	Lock Link	Menasco Aerospace
41400-400	Spoiler Differential Mechanism	Lear Siegler
41400-500	Spoiler Differential Mechanism	Lear Siegler
41400-600	Spoiler Differential Mechanism	Lear Siegler
41400-610	Spoiler Differential Mechanism	Lear Siegler
414470	Hydraulic Pump	Vickers
414496	Electrical Motor assy	Vickers
414800-1005	Spoiler Actuator assy	Nabtesco
41500-1	MLG Lock Actuator	Menasco Aerospace
41500-3	MLG Retract Actuator	Menasco Aerospace
41500-5	MLG Retract Actuator	Menasco Aerospace
4150-3 B3	Pressure Transmitter	Bendix
4150-3-B3	Pressure Transmitter	Bendix
4155959	Mechanical Converter	ECE
4156091	Mechanical Converter	ECE
4156783	Windshield Wiper System	ECE
41581-1	Pressure Gage	Bourdon
41581-3	Pressure Gage	Bourdon
41600-1	MLG Lock Actuator	Menasco Aerospace
41600-2	MLG Lock Actuator	Menasco Aerospace
41600-3	MLG Lock Actuator	Menasco Aerospace
41600-4	MLG Lock Actuator	Menasco Aerospace
41600-5	MLG Lock Actuator	Menasco Aerospace
41600-6	MLG Lock Actuator	Menasco Aerospace
41600-7	MLG Lock Actuator	Menasco Aerospace
41600-8	MLG Lock Actuator	Menasco Aerospace
416T2042-10	Forward Door Bustle	Boeing
416T2042-11	Forward Door Bustle	Boeing
416T2042-12	Forward Door Bustle	Boeing
416T2042-4	Forward Door Bustle	Boeing
416T2042-5	Forward Door Bustle	Boeing
416T2042-9	Forward Door Bustle	Boeing
416T2047-3	Aft Door Bustle	Boeing
416T2047-5	Aft Door Bustle	Boeing
416T2047-6	Aft Door Bustle	Boeing
416T2047-7	Aft Door Bustle	Boeing
41700-10	Electrical Harness	Menasco Aerospace
41700-5	Electrical Harness	Menasco Aerospace

Repair_Capability_List_Excel

41700-6	Electrical Harness	Menasco Aerospace
41700-7	Electrical Harness	Menasco Aerospace
41700-8	Electrical Harness	Menasco Aerospace
41700-9	Electrical Harness	Menasco Aerospace
41700S2100-7	Electrical Harness	Menasco Aerospace
41700S2100-8	Electrical Harness	Menasco Aerospace
4173763	Extensible Landing Light	ECE
417N2117-1	Waste Water Drain Mast	Boeing
417N2117-2	Waste Water Drain Mast	Boeing
417N2117-4	Waste Water Drain Mast	Boeing
417N2117-5	Waste Water Drain Mast	Boeing
417N2117-6	Waste Water Drain Mast	Boeing
417N2117-7	Waste Water Drain Mast	Boeing
417N2117-8	Waste Water Drain Mast	Boeing
417N3011-1 SP	Passenger Service Unit	Boeing
417N3011-101 SP	Passenger Service Unit	Boeing
417N3011-102 SP	Passenger Service Unit	Boeing
417N3011-103 SP	Passenger Service Unit	Boeing
417N3011-104 SP	Passenger Service Unit	Boeing
417N3011-105 SP	Passenger Service Unit	Boeing
417N3011-106 SP	Passenger Service Unit	Boeing
417N3011-107 SP	Passenger Service Unit	Boeing
417N3011-108 SP	Passenger Service Unit	Boeing
417N3011-109 SP	Passenger Service Unit	Boeing
417N3011-11 SP	Passenger Service Unit	Boeing
417N3011-110 SP	Passenger Service Unit	Boeing
417N3011-111 SP	Passenger Service Unit	Boeing
417N3011-112 SP	Passenger Service Unit	Boeing
417N3011-113 SP	Passenger Service Unit	Boeing
417N3011-114 SP	Passenger Service Unit	Boeing
417N3011-115 SP	Passenger Service Unit	Boeing
417N3011-116 SP	Passenger Service Unit	Boeing
417N3011-117 SP	Passenger Service Unit	Boeing
417N3011-118 SP	Passenger Service Unit	Boeing
417N3011-119 SP	Passenger Service Unit	Boeing
417N3011-12 SP	Passenger Service Unit	Boeing
417N3011-120 SP	Passenger Service Unit	Boeing
417N3011-121 SP	Passenger Service Unit	Boeing
417N3011-122 SP	Passenger Service Unit	Boeing
417N3011-123 SP	Passenger Service Unit	Boeing
417N3011-124 SP	Passenger Service Unit	Boeing
417N3011-125 SP	Passenger Service Unit	Boeing
417N3011-126 SP	Passenger Service Unit	Boeing
417N3011-127 SP	Passenger Service Unit	Boeing
417N3011-128 SP	Passenger Service Unit	Boeing
417N3011-129 SP	Passenger Service Unit	Boeing
417N3011-13 SP	Passenger Service Unit	Boeing
417N3011-136 SP	Passenger Service Unit	Boeing
417N3011-137 SP	Passenger Service Unit	Boeing
417N3011-138 SP	Passenger Service Unit	Boeing
417N3011-139 SP	Passenger Service Unit	Boeing
417N3011-14 SP	Passenger Service Unit	Boeing
417N3011-140 SP	Passenger Service Unit	Boeing
417N3011-142 SP	Passenger Service Unit	Boeing
417N3011-143 SP	Passenger Service Unit	Boeing
417N3011-144 SP	Passenger Service Unit	Boeing
417N3011-145 SP	Passenger Service Unit	Boeing
417N3011-147 SP	Passenger Service Unit	Boeing

Repair_Capability_List_Excel

417N3011-54 SP	Passenger Service Unit	Boeing
417N3011-55 SP	Passenger Service Unit	Boeing
417N3011-56 SP	Passenger Service Unit	Boeing
417N3011-57 SP	Passenger Service Unit	Boeing
417N3011-58 SP	Passenger Service Unit	Boeing
417N3011-59 SP	Passenger Service Unit	Boeing
417N3011-6 SP	Passenger Service Unit	Boeing
417N3011-60 SP	Passenger Service Unit	Boeing
417N3011-61 SP	Passenger Service Unit	Boeing
417N3011-62 SP	Passenger Service Unit	Boeing
417N3011-63 SP	Passenger Service Unit	Boeing
417N3011-64 SP	Passenger Service Unit	Boeing
417N3011-7 SP	Passenger Service Unit	Boeing
417N3011-8 SP	Passenger Service Unit	Boeing
417N3100-1 SP	Underbin Passenger Service Unit	Boeing
417N3100-11 SP	Underbin Passenger Service Unit	Boeing
417N3100-111 SP	Underbin Passenger Service Unit	Boeing
417N3100-113 SP	Underbin Passenger Service Unit	Boeing
417N3100-115 SP	Underbin Passenger Service Unit	Boeing
417N3100-117 SP	Underbin Passenger Service Unit	Boeing
417N3100-119 SP	Underbin Passenger Service Unit	Boeing
417N3100-12 SP	Underbin Passenger Service Unit	Boeing
417N3100-121 SP	Underbin Passenger Service Unit	Boeing
417N3100-122 SP	Underbin Passenger Service Unit	Boeing
417N3100-123 SP	Underbin Passenger Service Unit	Boeing
417N3100-124 SP	Underbin Passenger Service Unit	Boeing
417N3100-125 SP	Underbin Passenger Service Unit	Boeing
417N3100-126 SP	Underbin Passenger Service Unit	Boeing
417N3100-128 SP	Underbin Passenger Service Unit	Boeing
417N3100-129 SP	Partial Und. Passenger Service Unit	Boeing
417N3100-13 SP	Underbin Passenger Service Unit	Boeing
417N3100-130 SP	Partial Und. Passenger Service Unit	Boeing
417N3100-131 SP	Partial Und. Passenger Service Unit	Boeing
417N3100-132 SP	Partial Und. Passenger Service Unit	Boeing
417N3100-133 SP	Partial Und. Passenger Service Unit	Boeing
417N3100-134 SP	Partial Und. Passenger Service Unit	Boeing
417N3100-135 SP	Aft Partial Underbin Pax Service Unit	Boeing
417N3100-136 SP	Aft Partial Underbin Pax Service Unit	Boeing
417N3100-137 SP	Underbin Passenger Service Unit	Boeing
417N3100-138 SP	Underbin Passenger Service Unit	Boeing
417N3100-139 SP	Underbin Passenger Service Unit	Boeing
417N3100-14 SP	Underbin Passenger Service Unit	Boeing
417N3100-140 SP	Underbin Passenger Service Unit	Boeing
417N3100-141 SP	Partial Und. Passenger Service Unit	Boeing
417N3100-142 SP	Partial Und. Passenger Service Unit	Boeing
417N3100-143 SP	Partial Und. Passenger Service Unit	Boeing
417N3100-144 SP	Underbin Passenger Service Unit	Boeing
417N3100-145 SP	Underbin Passenger Service Unit	Boeing
417N3100-146 SP	Underbin Passenger Service Unit	Boeing
417N3100-147 SP	Underbin Passenger Service Unit	Boeing
417N3100-148 SP	Partial Und. Passenger Service Unit	Boeing
417N3100-153 SP	Underbin Passenger Service Unit	Boeing
417N3100-154 SP	Underbin Passenger Service Unit	Boeing
417N3100-156 SP	Partial Und. Passenger Service Unit	Boeing
417N3100-157 SP	Underbin Passenger Service Unit	Boeing
417N3100-158 SP	Underbin Passenger Service Unit	Boeing
417N3100-159 SP	Underbin Passenger Service Unit	Boeing
417N3100-160 SP	Underbin Passenger Service Unit	Boeing

Repair_Capability_List_Excel

417N3100-641 SP	Underbin Passenger Service Unit	Boeing
417N3100-643 SP	Underbin Passenger Service Unit	Boeing
417N3100-645 SP	Underbin Passenger Service Unit	Boeing
417N3100-647 SP	Underbin Passenger Service Unit	Boeing
417N3100-649 SP	Underbin Passenger Service Unit	Boeing
417N3100-650 SP	Underbin Passenger Service Unit	Boeing
417N3100-653 SP	Underbin Passenger Service Unit	Boeing
417N3100-655 SP	Underbin Passenger Service Unit	Boeing
417N3100-657 SP	Underbin Passenger Service Unit	Boeing
417N3100-658 SP	Underbin Passenger Service Unit	Boeing
417N3100-659 SP	Underbin Passenger Service Unit	Boeing
417N3100-660 SP	Underbin Passenger Service Unit	Boeing
417N3100-661 SP	Partial Und. Passenger Service Unit	Boeing
417N3100-662 SP	Underbin Passenger Service Unit	Boeing
417N3100-663 SP	Partial Und. Passenger Service Unit	Boeing
417N3100-664 SP	Partial Und. Passenger Service Unit	Boeing
417N3100-665 SP	Partial Und. Passenger Service Unit	Boeing
417N3100-666 SP	Partial Und. Passenger Service Unit	Boeing
417N3100-667 SP	Underbin Passenger Service Unit	Boeing
417N3100-668 SP	Underbin Passenger Service Unit	Boeing
417N3100-669 SP	Underbin Passenger Service Unit	Boeing
417N3100-670 SP	Underbin Passenger Service Unit	Boeing
417N3100-671 SP	Underbin Passenger Service Unit	Boeing
417N3100-672 SP	Underbin Passenger Service Unit	Boeing
417N3100-673 SP	Partial Und. Passenger Service Unit	Boeing
417N3100-674 SP	Partial Und. Passenger Service Unit	Boeing
417N3100-676 SP	Underbin Passenger Service Unit	Boeing
417N3100-678 SP	Underbin Passenger Service Unit	Boeing
417N3100-679 SP	Underbin Passenger Service Unit	Boeing
417N3100-680 SP	Underbin Passenger Service Unit	Boeing
417N3100-681 SP	Underbin Passenger Service Unit	Boeing
417N3100-682 SP	Underbin Passenger Service Unit	Boeing
417N3100-683 SP	Underbin Passenger Service Unit	Boeing
417N3100-684 SP	Underbin Passenger Service Unit	Boeing
417N3100-685 SP	Partial Und. Passenger Service Unit	Boeing
417N3100-686 SP	Partial Und. Passenger Service Unit	Boeing
417N3100-687 SP	Underbin Passenger Service Unit	Boeing
417N3100-688 SP	Underbin Passenger Service Unit	Boeing
417N3100-689 SP	Underbin Passenger Service Unit	Boeing
417N3100-68SP	Underbin Passenger Service Unit	Boeing
417N3100-690 SP	Underbin Passenger Service Unit	Boeing
417N3100-691 SP	Underbin Passenger Service Unit	Boeing
417N3100-692 SP	Underbin Passenger Service Unit	Boeing
417N3100-91 SP	Underbin Passenger Service Unit	Boeing
417N3100-93 SP	Underbin Passenger Service Unit	Boeing
417N3100-97 SP	Underbin Passenger Service Unit	Boeing
417N3100-98 SP	Underbin Passenger Service Unit	Boeing
417N3130-1 SP	Oxygen Box	Boeing
417N3130-10 SP	Oxygen Box	Boeing
417N3130-101 SP	Oxygen Box	Boeing
417N3130-102 SP	Oxygen Box	Boeing
417N3130-103 SP	Oxygen Box	Boeing
417N3130-104 SP	Oxygen Box	Boeing
417N3130-105 SP	Oxygen Box	Boeing
417N3130-107 SP	Oxygen Box	Boeing
417N3130-108 SP	Oxygen Box	Boeing
417N3130-111 SP	Oxygen Box	Boeing
417N3130-112 SP	Oxygen Box	Boeing

Repair_Capability_List_Excel

417N3130-113 SP	Oxygen Box	Boeing
417N3130-114 SP	Oxygen Box	Boeing
417N3130-115 SP	Oxygen Box	Boeing
417N3130-116 SP	Oxygen Box	Boeing
417N3130-117 SP	Oxygen Box	Boeing
417N3130-118 SP	Oxygen Box	Boeing
417N3130-119 SP	Oxygen Box	Boeing
417N3130-120 SP	Oxygen Box	Boeing
417N3130-122 SP	Oxygen Box	Boeing
417N3130-123 SP	Oxygen Box	Boeing
417N3130-124 SP	Oxygen Box	Boeing
417N3130-127 SP	Oxygen Box	Boeing
417N3130-128 SP	Oxygen Box	Boeing
417N3130-129 SP	Oxygen Box	Boeing
417N3130-130 SP	Oxygen Box	Boeing
417N3130-131 SP	Oxygen Box	Boeing
417N3130-132 SP	Oxygen Box	Boeing
417N3130-133 SP	Oxygen Box	Boeing
417N3130-134 SP	Oxygen Box	Boeing
417N3130-135 SP	Oxygen Box	Boeing
417N3130-137 SP	Oxygen Box	Boeing
417N3130-15 SP	Oxygen Box	Boeing
417N3130-16 SP	Oxygen Box	Boeing
417N3130-18 SP	Oxygen Box	Boeing
417N3130-2 SP	Oxygen Box	Boeing
417N3130-21 SP	Oxygen Box	Boeing
417N3130-22 SP	Oxygen Box	Boeing
417N3130-23 SP	Oxygen Box	Boeing
417N3130-24 SP	Oxygen Box	Boeing
417N3130-25 SP	Oxygen Box	Boeing
417N3130-26 SP	Oxygen Box	Boeing
417N3130-27 SP	Oxygen Box	Boeing
417N3130-28 SP	Oxygen Box	Boeing
417N3130-29 SP	Oxygen Box	Boeing
417N3130-30 SP	Oxygen Box	Boeing
417N3130-31 SP	Oxygen Box	Boeing
417N3130-32 SP	Oxygen Box	Boeing
417N3130-33 SP	Oxygen Box	Boeing
417N3130-34 SP	Oxygen Box	Boeing
417N3130-35 SP	Oxygen Box	Boeing
417N3130-36 SP	Oxygen Box	Boeing
417N3130-39 SP	Oxygen Box	Boeing
417N3130-4 SP	Oxygen Box	Boeing
417N3130-40 SP	Oxygen Box	Boeing
417N3130-41 SP	Oxygen Box	Boeing
417N3130-42 SP	Oxygen Box	Boeing
417N3130-43 SP	Oxygen Box	Boeing
417N3130-44 SP	Oxygen Box	Boeing
417N3130-45 SP	Oxygen Box	Boeing
417N3130-46 SP	Oxygen Box	Boeing
417N3130-47 SP	Oxygen Box	Boeing
417N3130-48 SP	Oxygen Box	Boeing
417N3130-49 SP	Oxygen Box	Boeing
417N3130-5 SP	Oxygen Box	Boeing
417N3130-50 SP	Oxygen Box	Boeing
417N3130-51 SP	Oxygen Box	Boeing
417N3130-52 SP	Oxygen Box	Boeing
417N3130-53 SP	Oxygen Box	Boeing

Repair_Capability_List_Excel

417N3130-54 SP	Oxygen Box	Boeing
417N3130-56 SP	Oxygen Box	Boeing
417N3130-57 SP	Oxygen Box	Boeing
417N3130-58 SP	Oxygen Box	Boeing
417N3130-6 SP	Oxygen Box	Boeing
417N3130-60 SP	Oxygen Box	Boeing
417N3130-61 SP	Oxygen Box	Boeing
417N3130-62 SP	Oxygen Box	Boeing
417N3130-63 SP	Oxygen Box	Boeing
417N3130-64 SP	Oxygen Box	Boeing
417N3130-65 SP	Oxygen Box	Boeing
417N3130-66 SP	Oxygen Box	Boeing
417N3130-71 SP	Oxygen Box	Boeing
417N3130-72 SP	Oxygen Box	Boeing
417N3130-73 SP	Oxygen Box	Boeing
417N3130-74 SP	Oxygen Box	Boeing
417N3130-75 SP	Oxygen Box	Boeing
417N3130-76 SP	Oxygen Box	Boeing
417N3130-77 SP	Oxygen Box	Boeing
417N3130-78 SP	Oxygen Box	Boeing
417N3130-79 SP	Oxygen Box	Boeing
417N3130-8 SP	Oxygen Box	Boeing
417N3130-80 SP	Oxygen Box	Boeing
417N3130-81 SP	Oxygen Box	Boeing
417N3130-82 SP	Oxygen Box	Boeing
417N3130-83 SP	Oxygen Box	Boeing
417N3130-84 SP	Oxygen Box	Boeing
417N3130-85 SP	Oxygen Box	Boeing
417N3130-86 SP	Oxygen Box	Boeing
417N3130-87 SP	Oxygen Box	Boeing
417N3130-88 SP	Oxygen Box	Boeing
417N3130-89 SP	Oxygen Box	Boeing
417N3130-9 SP	Oxygen Box	Boeing
417N3130-90 SP	Oxygen Box	Boeing
417N3130-92 SP	Oxygen Box	Boeing
417N3130-93 SP	Oxygen Box	Boeing
417N3130-94 SP	Oxygen Box	Boeing
417N3130-96 SP	Oxygen Box	Boeing
417N3130-97 SP	Oxygen Box	Boeing
417N3130-98 SP	Oxygen Box	Boeing
417N3130-99 SP	Oxygen Box	Boeing
417N3700-1	Underbin Attendant Service Unit	Boeing
417N3700-11	Underbin Attendant Service Unit	Boeing
417N3700-12	Underbin Attendant Service Unit	Boeing
417N3700-16	Underbin Attendant Service Unit	Boeing
417N3700-17	Underbin Attendant Service Unit	Boeing
417N3700-18	Underbin Attendant Service Unit	Boeing
417N3700-19	Underbin Attendant Service Unit	Boeing
417N3700-2	Underbin Attendant Service Unit	Boeing
417N3700-20	Underbin Attendant Service Unit	Boeing
417N3700-21	Underbin Attendant Service Unit	Boeing
417N3700-22	Underbin Attendant Service Unit	Boeing
417N3700-3	Underbin Attendant Service Unit	Boeing
417N3700-4	Underbin Attendant Service Unit	Boeing
417N3810-1 SP	Attendants Serv.Unit & Lav. Oxyg. Box	Boeing
417N3810-10 SP	Attendants Service Unit Oxygen Box	Boeing
417N3810-100 SP	Attendants Serv.Unit & Lav. Oxyg. Box	Boeing
417N3810-102 SP	Attendants Serv.Unit & Lav. Oxyg. Box	Boeing

Repair_Capability_List_Excel

417U3106-13	Oxygen Module and Panel	Boeing
417U3106-14	Oxygen Module and Panel	Boeing
417U3106-15	Oxygen Module and Panel	Boeing
417U3106-16	Oxygen Module and Panel	Boeing
417U3106-17	Oxygen Module and Panel	Boeing
417U3106-18	Oxygen Module and Panel	Boeing
417U3106-3	Oxygen Module and Panel	Boeing
417U3106-4	Oxygen Module and Panel	Boeing
41800831001	Back-up Yaw Damper Unit	SFIM
41800831002	Back-up Yaw Damper Unit	SFIM
41800831100	Back-up Yaw Damper Unit	SFIM
41800834002	Yam Damper Electronic Box	SFIM
418-01104	Pressure Transmitter	Meggitt
418-01124	Oil Pressure Transmitter	Meggitt
41802362001	Microgeneration	SFIM
418-04104	Oil Pressure Transmitter	Meggitt
418-05104	Oil Pressure Transmitter	Meggitt
418-06104	Oil Pressure Transmitter	Meggitt
418-07104	Oil Pressure Transmitter	Meggitt
418-08104	Oil Pressure Transmitter	Meggitt
418-09104	Oil Pressure Transmitter	Meggitt
418-15054	Pressure Transmitter	Meggitt
418-16054	Pressure Transmitter	Meggitt
418-17054	Fuel Pressure Transmitter	Meggitt
418-20044	Pressure Transmitter	Meggitt
418-24054	Fuel Pressure Transmitter	Meggitt
41850A	Light assy	Grimes Aerospace
418575	Hydraulic Motor	Vickers
4188-00	Static Inverter	Diehl
4189898	Taxi & Take-off Floodlight	ECE
4189904	Wing Scan Light	ECE
4189904C	Wing Scan Light	ECE
4189911	Wing Scan Light	ECE
4189911C	Wing Scan Light	ECE
4189927	Engine Scan Light	ECE
4189934	Engine Scan Light	ECE
4190-00	Static Inverter	DLE
4191695	Retractable Landing Light	ECE
4191695E	Retractable Landing Light	ECE
4192274	Drive Flexible Shaft	ECE
4192683	Motor	ECE
4195738	Depressurization Control Valve	ECE
41C989	Actuator	Weston Aerospace
41SG118-1	Pressure Transducer	Eaton
41SG118-2	Pressure Transducer	Eaton
41SG265-1	Pressure Transducer	Eaton
41SG272-3	Pressure Transducer	Eaton
41SG272-5	Pressure Transducer	Eaton
41SG381-1	Pressure Transducer	Eaton
4200128	Interlock Reverser Control Cable	ECE
420032	Ignition Lead	Unison
420033	Ignition Lead	Unison
420035-1	Valve assy	Meggitt
420035-2	Valve assy	Meggitt
420035-3	Valve assy	Meggitt
42011	Hydraulic Pump	Abex
42015	Hydraulic Pump & Motor ay	Abex
42015-01	Hydraulic Pump & Motor ay	Abex

Repair_Capability_List_Excel

4202171	Mechanical Converter	ECE
4202187	Mechanical Converter	ECE
4203-40-80-01	Flaps Position Indicator	Thales Avionics
4203501	Hydraulic Motor	Abex
4203502	Hydraulic Motor	Abex
4203503	Hydraulic Motor	Abex
420365-1	Air Shut-Off Valve	Meggitt
4203H2	Filter Manifold Pressure	Fairey Hydraulics
42049	Hydraulic Motor	Abex
420496	Stator	Vickers
4205-002-000	Cycle De-Icing Switch	Teddington
4205-003-000	Cycle De-Icing Switch	Teddington
42053	Hydraulic Pump	Abex
42054	Hydraulic Pump	Abex
4205400	Hydraulic Pump	Parker Hannifin
4205401	Hydraulic Pump	Parker Hannifin
42054-01	Hydraulic Pump	Parker Hannifin
4205601	Motor Pump assy	Abex
4205602	Motor Pump assy	Abex
4205H1	Filter	Fairey Hydraulics
420609	Hydraulic Pump	Vickers
420745-3	Valve assy	Whittaker
420745-4	Valve assy	Whittaker
42075308-11	Alternating Current Motor	EADS Sogerma
4207902	Hydraulic Pump	Abex
42-091-3	Spoiler Control Box	Hydro-Aire
4209455	Wing Icing Inspection Light	ECE
4209462	Wing Icing Inspection Light	ECE
420A200-2	Filter Demister	Le Bozec
420A200-4	Filter Demister	Le Bozec
4211067	Wiper Blade	ECE
4211885	Unlocking Door Control	ECE
4213699	Wing Icing Inspection Light	ECE
4213705	Wing Icing Inspection Light	ECE
421370M02	Rudder Dynamometric Rod	Sarma
42-139-3	Skid Control	Hydro-Aire
42-139-4	Skid Control	Hydro-Aire
42-139-5	Skid Control	Hydro-Aire
42-139-6	Skid Control	Hydro-Aire
4213966	Logo Light	ECE
4213973	Taxi & Take-Off Light	ECE
4213989	Landing Light	ECE
4215935	Toilet Drain Control	ECE
4216009	Motor Converter	ECE
4216009A	Motor Converter	ECE
4216016	Motor Converter	ECE
4216016A	Motor Converter	ECE
4216023	Wiper Arm	ECE
4216039	Wiper Arm	ECE
42164R10	Gearbox assy	Goodrich Control Systems
42164R12	Gearbox assy	Goodrich Control Systems
42164R13	Gearbox assy	Goodrich Control Systems
42-189-7	Control Unit	Hydro-Aire
421CC02	Single Pole Contactor	ECE
422081-100	Transducer	Lucas Air Equipement
422082-400	Actuator	Lucas Air Equipement
4221T100-1	Trailing Edge Flap Actuator	Telair International
4221T100-3	Trailing Edge Flap Actuator	Telair International

Repair_Capability_List_Excel

4221T100-5	Trailing Edge Flap Actuator	Telair International
4223306	Taxi & Take-off Floodlight	ECE
42-265	Anti-Skid Controller	Crane
4227766	Wiper Arm	ECE
4227796	Wiper Arm	ECE
42284R1	Actuator	ECE
42284R10	Actuator	ECE
42284R2	Actuator	ECE
42284R67	Actuator	ECE
42284R68	Actuator	ECE
42284R9	Actuator	ECE
4230016	Ram Air Control	ECE
4230023	Ram Air Control	ECE
42-307	Antiskid Control Box	Hydro-Aire
42-307-1	Antiskid Control Box	Hydro-Aire
42-319-3	Control Unit	Hydro-Aire
4233241	Lift Block	ECE
4233257	Bearing Block	ECE
4233488	Take-Off Light	ECE
4234000-2	Feedback Cable Actuator	Parker Hannifin
4234000-3	Feedback Cable Actuator	Parker Hannifin
4236534A	Turn-off Light	ECE
4236564	Light	ECE
4237084	Motor assy	ECE
4237091	Motor assy	ECE
4239172	Wiper Blade	ECE
42-411	Control Panel	Hydro-Aire
4242018	Wiper Blade	ECE
4242025	Lift Block	ECE
424244	Variable Disp. Hydraulic Pump	Vickers
424B200-3	Air Filter	Le Bozec
424B200-4	Air Filter	Le Bozec
42-527C	Shield Control	Hydro-Aire
42-527D	Shield Control	Hydro-Aire
42540	Valve assy	Sterer
4-254-02	Battery Charger	Crane
4-254-03	Battery Charger	Crane
4-254-04	Battery Charger	Crane
425700	Indicator	BHL Electronics
425A200-3	Filter Demister	Le Bozec
42-607-1	Control Box	Crane
4261212A	Push/Pull Throttle assy Cable	ECE
4262461	Linear Actuator	ECE
42-629	Antiskid Auto Brake Control	Crane
42-629-1	Antiskid Auto Brake Control	Crane
42-629-23	Antiskid Auto Brake Control	Crane
4263H1	Sampling Valve	Fairey Hydraulics
426583	Indicator	BHL Electronics
4267812	Wing Icing Inspection Light	ECE
42-719-01	Skid Control	Hydro-Aire
42-719-02	Skid Control	Hydro-Aire
4271A010101	Pressure Switch	Liebherr Aerospace
4271A020101	Pressure Switch	Liebherr Aerospace
4273511	Turn-off Taxi Light	ECE
4273527	Turn-off Taxi Light	ECE
42-767	Anti-Skid Brake Control Unit	Crane
42-767-1	Anti-Skid Brake Control Unit	Crane
42-767-2	Anti-Skid Brake Control Unit	Crane

Repair_Capability_List_Excel

4279198	Motor Converter	ECE
4279204	Motor Converter	ECE
4279874	Wiper Arm	ECE
4279881	Wiper Arm	ECE
42-807	Anti-Skid Control	Hydro-Aire
428153	Hydraulic Motorpump assy	Vickers
42-831	Control Panel	Hydro-Aire
4285098	Wing Icing Inspection Light	ECE
4285104	Wing Icing Inspection Light	ECE
42-86V12	Gyroscopic Horizon Indicator	Thales
42-877	Anti-Skid Brake Control Unit	Crane
42-877-1	Anti-Skid Brake Control Unit	Crane
4289468	Wing Scan Light	Teleflex Controls
42895A16870	Rotating Beacon	Grimes Aerospace
42895A17-16870	Tandem Oscillating Light	Grimes Aerospace
42895A7-16870	Tandem Oscillating Light	Grimes Aerospace
4291004	Wiper Motor Converter	ECE
4291011	Wiper Motor Converter	ECE
4292209	Landing Light	Teleflex Controls
4292915	Landing Light	ECE
4295018	Wiper Arm	ECE
4295025	Wiper Arm	ECE
4295747	Taxi & Take-Off Light	ECE
4297515A	Push Pull Engine Cable	ECE
4297522A	Push Pull Rotor Cable	ECE
42D185	Pressure Switch	Custom Control Sensors
42D362	Differential Pressure Switch	Custom Control Sensors
42D394	Differential Pressure Switch	Custom Control Sensors
42D395	Differential Pressure Switch	Custom Control Sensors
42G304	Pressure Switch	Custom Control Sensors
4300-1	Toilet	Monogram Systems
4300-13	Toilet assy	Monogram
4300167	Logo Light	Intertechnique
4300174	Logo Light	Intertechnique
4300181	Logo Light	Intertechnique
4300181A	Logo Light	Intertechnique
4300197	Logo Light	Intertechnique
4300197A	Logo Light	Intertechnique
4300-2	Toilet	Monogram Systems
4300-25	Toilet assy	Monogram
4300-26	Toilet assy	Monogram
4300-3	Toilet assy	Monogram
430035	Ignition Exciter	Unison
4300-4	Toilet assy	Monogram
430138	Ignition Exciter	Unison
430141	Ignition Exciter	Unison
430184	Permanent Magnet Alternator	Unison
4302202	By-Pass Valve	ECE
430249	Permanent Magnet Alternator	Unison
430250	Permanent Magnet Alternator	Unison
430263	Permanent Magnet Alternator	Unison
4303236	Engine Control Harness assy	Hamilton Sundstrand
4305790340	Thermocouple Transducer	Messier-Bugatti
430579340	Thermocouple Transducer	Messier-Bugatti
4305890050	TPIS Transmitter	Labinal
4305901170	Pressure Sensor Holder	Labinal
4305901210	Pressure Sensor Holder	Labinal
4305990070	TPIS Transducer	Labinal

Repair_Capability_List_Excel

4305990071	TPIS Transducer	Labinal
4308DA	Valve assy	Sargent
4308DA-2	Valve assy	Sargent
4308DA-3	Valve assy	Sargent
4308DA-4	Valve assy	Sargent
430ZN01Y03	Trim Actuation Detector	ECE
43-1-1100	Air Intake Flap Actuator	Elektro Metall Exp.
4315245	Ram Air Control	ECE
4315252	Ram Air Control	ECE
4315542	Retractable Landing Light	ECE
4318024	Push/Pull Throttle assy	ECE
4318746	Logo Light	Intertechnique
4318769	Logo Light	Intertechnique
4319586	Landing Light	ECE
4321554	Logo Light	Intertechnique
4321561	Logo Light	Intertechnique
4321577	Logo Light	Intertechnique
4321584	Logo Light	Intertechnique
4322245	Logo Light	Intertechnique
4322252	Logo Light	Intertechnique
4322258	Logo Light	Intertechnique
4322275	Logo Light	Intertechnique
4333302	Logo Light	Intertechnique
4333318	Logo Light	Intertechnique
4333325	Logo Light	Intertechnique
4333332	Logo Light	Intertechnique
4333EA	Valve assy	Sargent
4334EA-2	Uplock Valve	Sargent
4334EA-3	Uplock Valve	Sargent
4336731001-xxxx	Lighted Pushbutton Switch	Korry Electronics
4336731004-xxxx	Lighted Pushbutton Switch	Korry Electronics
4340028	Wiper Blade	ECE
4340-050-00-00	Aileron Trim Position Indicator	Thales Avionics
4342555	Wiper Arm	ECE
4342562	Wiper Arm	ECE
4343253	Wiper Blade	ECE
4343853	Wiper Blade	ECE
434-674-1005-1xxx	Annunciator Light assy	Korry Electronics
434-674-1007-1019	Annunciator Light assy	Korry Electronics
434-674-1009-1xxx	Annunciator Light assy	Korry Electronics
434-674-1031-2xxx	Annunciator Light assy	Korry Electronics
434-674-1032-2019	Annunciator Light assy	Korry Electronics
434-674-1033-2xxx	Annunciator Light assy	Korry Electronics
43489-2	Switch	Honeywell
43489-3	Switch	Honeywell
43489-5	Switch	Honeywell
4349-150-80-10	Rudder Trim Position Indicator	Thales Avionics
4350-150-80-10	Aileron Trim Position Indicator	Thales Avionics
4357619	Wiper Arm	ECE
4357626	Wiper Arm	ECE
4359596	Wiper Blade	ECE
4359797	Wiper Arm	ECE
4359803	Wiper Arm	ECE
4359826	Control Switch	ECE
4361251	Motor Converter	ECE
4361267	Motor Converter	ECE
4361653	Wiper Arm	ECE
4361669	Wiper Arm	ECE

Repair_Capability_List_Excel

4364686	Electrical Harness	ECE
436MK1A	Fuel Booster Pump	Goodrich Control Systems
436MK2	Fuel Booster Pump	Goodrich Control Systems
4370645	Wiper Arm	ECE
4370652	Wiper Arm	ECE
4371-672-M	Clamp	Aeroquip
4387H2	Damper Flutter Aileron	Fairey Hydraulics
43925	Ignition Exciter	Simmonds Precision
440027-1	Distribution Manifold	Intertechnique
440027-2	Distribution Manifold	Intertechnique
440100-550	Non-Return Valve Flexible Hose	Intertechnique
440EP01	Solenoid Stick Lock	ECE
4413-8	Lube & Scavenge Pump	Parker Hannifin
441648	Hydromechanical Unit	Honeywell
441680	Hydromechanical Unit	Honeywell
441681	Hydromechanical Unit	Honeywell
441729	Hydromechanical Unit	Honeywell
441730	Hydromechanical Unit	Honeywell
441754	Hydromechanical Unit	Honeywell
441755	Hydromechanical Unit	Honeywell
441789	Hydromechanical Unit	Honeywell
441790	Hydromechanical Unit	Honeywell
4426-425-00-00	Position Indicator	Thales Avionics
4428-150-80-11	Flaps Position Indicator	Thales Avionics
442920-1	Distribution Manifold	Intertechnique
44302	Ignition Exciter	Simmonds Precision
444-00489-100	Low Pressure Transmitter	Intertechnique
444-00521-300	Low Pressure Indicator	Intertechnique
444-00522-300	High Pressure Indicator	Intertechnique
444-00522-500	Oxygen Indicator	Eros
444-00522-700	Filling Indicator	Intertechnique
44430-1	Steering Relief Valve	Eaton Aerospace
44520	Hydraulic Valve	Sterer
44530	Hydraulic Valve	Sterer
44540	Hydraulic Valve	Sterer
44560	Hydraulic Valve	Sterer
44570	Hydraulic Valve	Sterer
446469	Fuel Heater	Pratt & Whitney
4472R155	Brake Stabilizer	Lucas Western
4472R165	Brake Stabilizer	Lucas Western
4472R170	Brake Stabilizer	Lucas Western
4472R180	Brake Stabilizer	Lucas Western
44933	Ignition Exciter	Simmonds Precision
44E10-2A	Water Separator	Lucas
44E10-2B	Water Separator	Lucas
44E10-2C	Water Separator	Lucas
45000	Total Pressure Probe	Thales Avionics
4500133	Cooling Fan	Hamilton Sundstrand
45-0057-1	Light assy	Grimes Aerospace
45-0057-3	Landing Light	Grimes Aerospace
45-0060-10	Retractable Landing Light	Grimes Aerospace
45-0060-11	Retractable Landing Light	Grimes Aerospace
45-0060-12	Retractable Landing Light	Grimes Aerospace
45-0060-13	Retractable Landing Light	Grimes Aerospace
45-0060-6	Retractable Landing Light	Grimes Aerospace
45-0060-7	Retractable Landing Light	Grimes Aerospace
45-0068-1	Retractable Landing Light	Grimes Aerospace
45-0068-3	Retractable Landing Light	Grimes Aerospace

Repair_Capability_List_Excel

45-0068-5	Retractable Landing Light	Grimes Aerospace
45-0068-7	Retractable Landing Light	Grimes Aerospace
45-0083-1	Light	Grimes Aerospace
45-0083-2	Light	Grimes Aerospace
45-0083-3	Light	Grimes Aerospace
45-0083-5	Light	Grimes Aerospace
45-0083-7	Light	Grimes Aerospace
4502160	Engine Control Harness assy	Hamilton Sundstrand
45-0234-1	Landing Light	Grimes Aerospace
45-0234-3	Landing Light	Grimes Aerospace
45-0234-5	Landing Light	Grimes Aerospace
4502687	Fuel Pump assy	Hamilton Sundstrand
4502904	Fan assy	Hamilton Sundstrand
4503090	Engine Control Harness assy	Hamilton Sundstrand
4503093	Fadec Interconnect Harness assy	Hamilton Sundstrand
45031	PRESSURE SWITCH	CUSTOM COMPONENT
4503140	Fuel Pump assy	Hamilton Sundstrand
45032	PRESSURE SWITCH	CUSTOM COMPONENT
45033	PRESSURE SWITCH	CUSTOM COMPONENT
4503978	Engine Control Harness assy	Hamilton Sundstrand
4504015	Acceleration Control assy	Hamilton Sundstrand
4504051	Engine Control Harness assy	Hamilton Sundstrand
4504185	Dual Hall Effect Speed Sensor	Hamilton Sundstrand
4504196	Pressure & Temp. Sensor assy	Hamilton Sundstrand
4504230	Electronic Control Harness assy	Hamilton Sundstrand
4505006	Electronic Starter Control assy	Hamilton Sundstrand
4505006A	Electronic Starter Control assy	Hamilton Sundstrand
4505006B	Electronic Starter Control assy	Hamilton Sundstrand
4505006C	Electronic Starter Control assy	Hamilton Sundstrand
4505008	Fuel Module assy	Hamilton Sundstrand
4505-1	PRESS SWITCH	CUSTOM
4505113	Engine Control Harness assy	Hamilton Sundstrand
4505-2	PRESS SWITCH	CUSTOM
4505296	Harness assy	Hamilton Sundstrand
4505305	Harness assy	Hamilton Sundstrand
4505716	Acceleration Control assy	Hamilton Sundstrand
45080	3 Way Solenoid Valve	Parker Hannifin
45080-1	3 Way Solenoid Valve	Parker Hannifin
450EP01	Rudder Artificial Feel Solenoid	ECE
450EP01Y	Rudder Artificial Feel Solenoid	ECE
45122	Thermo Resistor	Normalair
45122-2	Thermo Resistor	Normalair
45150320	AOA Sensor	Thales Avionics
45150340	AOA Sensor	Thales Avionics
45150561	AOA Sensor	Thales
45150563	AOA Sensor	Thales
451T1003-1	Roller Tray ay	Goodrich
451T1003-10	Roller Tray ay	Goodrich
451T1003-100	Roller Tray ay	Goodrich
451T1003-101	Roller Tray ay	Goodrich
451T1003-102	Roller Tray ay	Goodrich
451T1003-11	Roller Tray ay	Goodrich
451T1003-12	Roller Tray ay	Goodrich
451T1003-13	Roller Tray ay	Goodrich
451T1003-14	Roller Tray ay	Goodrich
451T1003-15	Roller Tray ay	Goodrich
451T1003-16	Roller Tray ay	Goodrich
451T1003-17	Roller Tray ay	Goodrich

Repair_Capability_List_Excel

451T1003-18	Roller Tray ay	Goodrich
451T1003-21	Roller Tray ay	Goodrich
451T1003-24	Roller Tray ay	Goodrich
451T1003-25	Roller Tray ay	Goodrich
451T1003-26	Roller Tray ay	Goodrich
451T1003-27	Roller Tray ay	Goodrich
451T1003-28	Roller Tray ay	Goodrich
451T1003-29	Roller Tray ay	Goodrich
451T1003-3	Roller Tray ay	Goodrich
451T1003-30	Roller Tray ay	Goodrich
451T1003-301	Roller Tray ay	Goodrich
451T1003-302	Roller Tray ay	Goodrich
451T1003-303	Roller Tray ay	Goodrich
451T1003-304	Roller Tray ay	Goodrich
451T1003-305	Roller Tray ay	Goodrich
451T1003-306	Roller Tray ay	Goodrich
451T1003-307	Roller Tray ay	Goodrich
451T1003-308	Roller Tray ay	Goodrich
451T1003-309	Roller Tray ay	Goodrich
451T1003-31	Roller Tray ay	Goodrich
451T1003-310	Roller Tray ay	Goodrich
451T1003-311	Roller Tray ay	Goodrich
451T1003-312	Roller Tray ay	Goodrich
451T1003-314	Roller Tray ay	Goodrich
451T1003-315	Roller Tray ay	Goodrich
451T1003-316	Roller Tray ay	Goodrich
451T1003-317	Roller Tray ay	Goodrich
451T1003-318	Roller Tray ay	Goodrich
451T1003-319	Roller Tray ay	Goodrich
451T1003-320	Roller Tray ay	Goodrich
451T1003-321	Roller Tray ay	Goodrich
451T1003-322	Roller Tray ay	Goodrich
451T1003-323	Roller Tray ay	Goodrich
451T1003-324	Roller Tray ay	Goodrich
451T1003-325	Roller Tray ay	Goodrich
451T1003-326	Roller Tray ay	Goodrich
451T1003-329	Roller Tray ay	Goodrich
451T1003-33	Roller Tray ay	Goodrich
451T1003-330	Roller Tray ay	Goodrich
451T1003-333	Roller Tray ay	Goodrich
451T1003-334	Roller Tray ay	Goodrich
451T1003-335	Roller Tray ay	Goodrich
451T1003-336	Roller Tray ay	Goodrich
451T1003-339	Roller Tray ay	Goodrich
451T1003-34	Roller Tray ay	Goodrich
451T1003-340	Roller Tray ay	Goodrich
451T1003-342	Roller Tray ay	Goodrich
451T1003-344	Roller Tray ay	Goodrich
451T1003-346	Roller Tray ay	Goodrich
451T1003-347	Roller Tray ay	Goodrich
451T1003-35	Roller Tray ay	Goodrich
451T1003-351	Roller Tray ay	Goodrich
451T1003-352	Roller Tray ay	Goodrich
451T1003-357	Roller Tray ay	Goodrich
451T1003-358	Roller Tray ay	Goodrich
451T1003-36	Roller Tray ay	Goodrich
451T1003-363	Roller Tray ay	Goodrich
451T1003-364	Roller Tray ay	Goodrich

Repair_Capability_List_Excel

451T1003-365	Roller Tray ay	Goodrich
451T1003-366	Roller Tray ay	Goodrich
451T1003-369	Roller Tray ay	Goodrich
451T1003-370	Roller Tray ay	Goodrich
451T1003-371	Roller Tray ay	Goodrich
451T1003-372	Roller Tray ay	Goodrich
451T1003-375	Roller Tray ay	Goodrich
451T1003-378	Roller Tray ay	Goodrich
451T1003-379	Roller Tray ay	Goodrich
451T1003-380	Roller Tray ay	Goodrich
451T1003-381	Roller Tray ay	Goodrich
451T1003-382	Roller Tray ay	Goodrich
451T1003-383	Roller Tray ay	Goodrich
451T1003-384	Roller Tray ay	Goodrich
451T1003-385	Roller Tray ay	Goodrich
451T1003-386	Roller Tray ay	Goodrich
451T1003-387	Roller Tray ay	Goodrich
451T1003-388	Roller Tray ay	Goodrich
451T1003-389	Roller Tray ay	Goodrich
451T1003-39	Roller Tray ay	Goodrich
451T1003-390	Roller Tray ay	Goodrich
451T1003-391	Roller Tray ay	Goodrich
451T1003-392	Roller Tray ay	Goodrich
451T1003-393	Roller Tray ay	Goodrich
451T1003-394	Roller Tray ay	Goodrich
451T1003-395	Roller Tray ay	Goodrich
451T1003-396	Roller Tray ay	Goodrich
451T1003-397	Roller Tray ay	Goodrich
451T1003-398	Roller Tray ay	Goodrich
451T1003-399	Roller Tray ay	Goodrich
451T1003-4	Roller Tray ay	Goodrich
451T1003-40	Roller Tray ay	Goodrich
451T1003-41	Roller Tray ay	Goodrich
451T1003-45	Roller Tray ay	Goodrich
451T1003-46	Roller Tray ay	Goodrich
451T1003-47	Roller Tray ay	Goodrich
451T1003-48	Roller Tray ay	Goodrich
451T1003-49	Roller Tray ay	Goodrich
451T1003-5	Roller Tray ay	Goodrich
451T1003-50	Roller Tray ay	Goodrich
451T1003-51	Roller Tray ay	Goodrich
451T1003-53	Roller Tray ay	Goodrich
451T1003-54	Roller Tray ay	Goodrich
451T1003-55	Roller Tray ay	Goodrich
451T1003-56	Roller Tray ay	Goodrich
451T1003-57	Roller Tray ay	Goodrich
451T1003-58	Roller Tray ay	Goodrich
451T1003-6	Roller Tray ay	Goodrich
451T1003-60	Roller Tray ay	Goodrich
451T1003-601	Roller Tray ay	Goodrich
451T1003-602	Roller Tray ay	Goodrich
451T1003-603	Roller Tray ay	Goodrich
451T1003-604	Roller Tray ay	Goodrich
451T1003-605	Roller Tray ay	Goodrich
451T1003-606	Roller Tray ay	Goodrich
451T1003-607	Roller Tray ay	Goodrich
451T1003-608	Roller Tray ay	Goodrich
451T1003-609	Roller Tray ay	Goodrich

Repair_Capability_List_Excel

451T1003-61	Roller Tray ay	Goodrich
451T1003-610	Roller Tray ay	Goodrich
451T1003-611	Roller Tray ay	Goodrich
451T1003-612	Roller Tray ay	Goodrich
451T1003-613	Roller Tray ay	Goodrich
451T1003-614	Roller Tray ay	Goodrich
451T1003-615	Roller Tray ay	Goodrich
451T1003-616	Roller Tray ay	Goodrich
451T1003-617	Roller Tray ay	Goodrich
451T1003-618	Roller Tray ay	Goodrich
451T1003-619	Roller Tray ay	Goodrich
451T1003-62	Roller Tray ay	Goodrich
451T1003-620	Roller Tray ay	Goodrich
451T1003-621	Roller Tray ay	Goodrich
451T1003-622	Roller Tray ay	Goodrich
451T1003-623	Roller Tray ay	Goodrich
451T1003-624	Roller Tray ay	Goodrich
451T1003-625	Roller Tray ay	Goodrich
451T1003-626	Roller Tray ay	Goodrich
451T1003-627	Roller Tray ay	Goodrich
451T1003-628	Roller Tray ay	Goodrich
451T1003-629	Roller Tray ay	Goodrich
451T1003-63	Roller Tray ay	Goodrich
451T1003-630	Roller Tray ay	Goodrich
451T1003-631	Roller Tray ay	Goodrich
451T1003-632	Roller Tray ay	Goodrich
451T1003-633	Roller Tray ay	Goodrich
451T1003-634	Roller Tray ay	Goodrich
451T1003-635	Roller Tray ay	Goodrich
451T1003-636	Roller Tray ay	Goodrich
451T1003-637	Roller Tray ay	Goodrich
451T1003-638	Roller Tray ay	Goodrich
451T1003-639	Roller Tray ay	Goodrich
451T1003-64	Roller Tray ay	Goodrich
451T1003-640	Roller Tray ay	Goodrich
451T1003-641	Roller Tray ay	Goodrich
451T1003-642	Roller Tray ay	Goodrich
451T1003-643	Roller Tray ay	Goodrich
451T1003-644	Roller Tray ay	Goodrich
451T1003-645	Roller Tray ay	Goodrich
451T1003-646	Roller Tray ay	Goodrich
451T1003-647	Roller Tray ay	Goodrich
451T1003-648	Roller Tray ay	Goodrich
451T1003-649	Roller Tray ay	Goodrich
451T1003-65	Roller Tray ay	Goodrich
451T1003-650	Roller Tray ay	Goodrich
451T1003-659	Roller Tray ay	Goodrich
451T1003-66	Roller Tray ay	Goodrich
451T1003-660	Roller Tray ay	Goodrich
451T1003-661	Roller Tray ay	Goodrich
451T1003-662	Roller Tray ay	Goodrich
451T1003-663	Roller Tray ay	Goodrich
451T1003-664	Roller Tray ay	Goodrich
451T1003-665	Roller Tray ay	Goodrich
451T1003-67	Roller Tray ay	Goodrich
451T1003-68	Roller Tray ay	Goodrich
451T1003-69	Roller Tray ay	Goodrich
451T1003-7	Roller Tray ay	Goodrich

Repair_Capability_List_Excel

451T1003-70	Roller Tray ay	Goodrich
451T1003-701	Roller Tray ay	Goodrich
451T1003-702	Roller Tray ay	Goodrich
451T1003-703	Roller Tray ay	Goodrich
451T1003-704	Roller Tray ay	Goodrich
451T1003-705	Roller Tray ay	Goodrich
451T1003-706	Roller Tray ay	Goodrich
451T1003-707	Roller Tray ay	Goodrich
451T1003-708	Roller Tray ay	Goodrich
451T1003-709	Roller Tray ay	Goodrich
451T1003-71	Roller Tray ay	Goodrich
451T1003-710	Roller Tray ay	Goodrich
451T1003-711	Roller Tray ay	Goodrich
451T1003-712	Roller Tray ay	Goodrich
451T1003-713	Roller Tray ay	Goodrich
451T1003-714	Roller Tray ay	Goodrich
451T1003-715	Roller Tray ay	Goodrich
451T1003-716	Roller Tray ay	Goodrich
451T1003-717	Roller Tray ay	Goodrich
451T1003-718	Roller Tray ay	Goodrich
451T1003-72	Roller Tray ay	Goodrich
451T1003-720	Roller Tray ay	Goodrich
451T1003-721	Roller Tray ay	Goodrich
451T1003-725	Roller Tray ay	Goodrich
451T1003-726	Roller Tray ay	Goodrich
451T1003-727	Roller Tray ay	Goodrich
451T1003-728	Roller Tray ay	Goodrich
451T1003-729	Roller Tray ay	Goodrich
451T1003-73	Roller Tray ay	Goodrich
451T1003-730	Roller Tray ay	Goodrich
451T1003-731	Roller Tray ay	Goodrich
451T1003-732	Roller Tray ay	Goodrich
451T1003-733	Roller Tray ay	Goodrich
451T1003-734	Roller Tray ay	Goodrich
451T1003-735	Roller Tray ay	Goodrich
451T1003-736	Roller Tray ay	Goodrich
451T1003-739	Roller Tray ay	Goodrich
451T1003-74	Roller Tray ay	Goodrich
451T1003-740	Roller Tray ay	Goodrich
451T1003-75	Roller Tray ay	Goodrich
451T1003-76	Roller Tray ay	Goodrich
451T1003-77	Roller Tray ay	Goodrich
451T1003-78	Roller Tray ay	Goodrich
451T1003-79	Roller Tray ay	Goodrich
451T1003-8	Roller Tray ay	Goodrich
451T1003-80	Roller Tray ay	Goodrich
451T1003-9	Roller Tray ay	Goodrich
451T1003-91	Roller Tray ay	Goodrich
451T1003-92	Roller Tray ay	Goodrich
451T1003-93	Roller Tray ay	Goodrich
451T1003-94	Roller Tray ay	Goodrich
451T1003-96	Roller Tray ay	Goodrich
451T1003-99	Roller Tray ay	Goodrich
451T1502-1	Roller Tray ay	Goodrich
451T1502-11	Roller Tray ay	Goodrich
451T1502-110	Roller Tray ay	Goodrich
451T1502-111	Roller Tray ay	Goodrich
451T1502-112	Roller Tray ay	Goodrich

Repair_Capability_List_Excel

451T1502-113	Roller Tray ay	Goodrich
451T1502-114	Roller Tray ay	Goodrich
451T1502-115	Roller Tray ay	Goodrich
451T1502-116	Roller Tray ay	Goodrich
451T1502-117	Roller Tray ay	Goodrich
451T1502-118	Roller Tray ay	Goodrich
451T1502-119	Roller Tray ay	Goodrich
451T1502-12	Roller Tray ay	Goodrich
451T1502-120	Roller Tray ay	Goodrich
451T1502-121	Roller Tray ay	Goodrich
451T1502-122	Roller Tray ay	Goodrich
451T1502-123	Roller Tray ay	Goodrich
451T1502-125	Roller Tray ay	Goodrich
451T1502-14	Roller Tray ay	Goodrich
451T1502-19	Roller Tray ay	Goodrich
451T1502-2	Roller Tray ay	Goodrich
451T1502-20	Roller Tray ay	Goodrich
451T1502-21	Roller Tray ay	Goodrich
451T1502-22	Roller Tray ay	Goodrich
451T1502-23	Roller Tray ay	Goodrich
451T1502-24	Roller Tray ay	Goodrich
451T1502-3	Roller Tray ay	Goodrich
451T1502-301	Roller Tray ay	Goodrich
451T1502-302	Roller Tray ay	Goodrich
451T1502-303	Roller Tray ay	Goodrich
451T1502-304	Roller Tray ay	Goodrich
451T1502-305	Roller Tray ay	Goodrich
451T1502-306	Roller Tray ay	Goodrich
451T1502-307	Roller Tray ay	Goodrich
451T1502-309	Roller Tray ay	Goodrich
451T1502-310	Roller Tray ay	Goodrich
451T1502-313	Roller Tray ay	Goodrich
451T1502-314	Roller Tray ay	Goodrich
451T1502-315	Roller Tray ay	Goodrich
451T1502-316	Roller Tray ay	Goodrich
451T1502-317	Roller Tray ay	Goodrich
451T1502-318	Roller Tray ay	Goodrich
451T1502-319	Roller Tray ay	Goodrich
451T1502-320	Roller Tray ay	Goodrich
451T1502-321	Roller Tray ay	Goodrich
451T1502-322	Roller Tray ay	Goodrich
451T1502-323	Roller Tray ay	Goodrich
451T1502-324	Roller Tray ay	Goodrich
451T1502-325	Roller Tray ay	Goodrich
451T1502-326	Roller Tray ay	Goodrich
451T1502-327	Roller Tray ay	Goodrich
451T1502-329	Roller Tray ay	Goodrich
451T1502-330	Roller Tray ay	Goodrich
451T1502-331	Roller Tray ay	Goodrich
451T1502-332	Roller Tray ay	Goodrich
451T1502-333	Roller Tray ay	Goodrich
451T1502-334	Roller Tray ay	Goodrich
451T1502-335	Roller Tray ay	Goodrich
451T1502-336	Roller Tray ay	Goodrich
451T1502-337	Roller Tray ay	Goodrich
451T1502-348	Roller Tray ay	Goodrich
451T1502-349	Roller Tray ay	Goodrich
451T1502-350	Roller Tray ay	Goodrich

Repair_Capability_List_Excel

451T1502-351	Roller Tray ay	Goodrich
451T1502-352	Roller Tray ay	Goodrich
451T1502-353	Roller Tray ay	Goodrich
451T1502-36	Roller Tray ay	Goodrich
451T1502-4	Roller Tray ay	Goodrich
451T1502-45	Roller Tray ay	Goodrich
451T1502-48	Roller Tray ay	Goodrich
451T1502-49	Roller Tray ay	Goodrich
451T1502-5	Roller Tray ay	Goodrich
451T1502-50	Roller Tray ay	Goodrich
451T1502-51	Roller Tray ay	Goodrich
451T1502-52	Roller Tray ay	Goodrich
451T1502-53	Roller Tray ay	Goodrich
451T1502-54	Roller Tray ay	Goodrich
451T1502-55	Roller Tray ay	Goodrich
451T1502-56	Roller Tray ay	Goodrich
451T1502-57	Roller Tray ay	Goodrich
451T1502-6	Roller Tray ay	Goodrich
451T1502-61	Roller Tray ay	Goodrich
451T1502-62	Roller Tray ay	Goodrich
451T1502-7	Roller Tray ay	Goodrich
451T1502-700	Roller Tray ay	Goodrich
451T1502-701	Roller Tray ay	Goodrich
451T1502-702	Roller Tray ay	Goodrich
451T1502-703	Roller Tray ay	Goodrich
451T1502-704	Roller Tray ay	Goodrich
451T1502-705	Roller Tray ay	Goodrich
451T1502-706	Roller Tray ay	Goodrich
451T1502-707	Roller Tray ay	Goodrich
451T1502-708	Roller Tray ay	Goodrich
451T1502-709	Roller Tray ay	Goodrich
451T1502-710	Roller Tray ay	Goodrich
451T1502-711	Roller Tray ay	Goodrich
451T1502-712	Roller Tray ay	Goodrich
451T1502-713	Roller Tray ay	Goodrich
451T1502-714	Roller Tray ay	Goodrich
451T1502-715	Roller Tray ay	Goodrich
451T1502-716	Roller Tray ay	Goodrich
451T1502-717	Roller Tray ay	Goodrich
451T1502-718	Roller Tray ay	Goodrich
451T1502-719	Roller Tray ay	Goodrich
451T1502-720	Roller Tray ay	Goodrich
451T1502-721	Roller Tray ay	Goodrich
451T1502-722	Roller Tray ay	Goodrich
451T1502-723	Roller Tray ay	Goodrich
451T1502-724	Roller Tray ay	Goodrich
451T1502-725	Roller Tray ay	Goodrich
451T1502-8	Roller Tray ay	Goodrich
451T1502-87	Roller Tray ay	Goodrich
451T1502-88	Roller Tray ay	Goodrich
451T1502-89	Roller Tray ay	Goodrich
451T1502-90	Roller Tray ay	Goodrich
451T1502-91	Roller Tray ay	Goodrich
451T1502-92	Roller Tray ay	Goodrich
451T1502-93	Roller Tray ay	Goodrich
451T1502-94	Roller Tray ay	Goodrich
451T1502-95	Roller Tray ay	Goodrich
451T1502-96	Roller Tray ay	Goodrich

Repair_Capability_List_Excel

451T1703-2	Sill Roller ay	Goodrich
451T1703-3	Sill Roller ay	Goodrich
451T1721-1	Door Sill Roller ay	Goodrich
451T1721-2	Door Sill Roller ay	Goodrich
451W0173-1	Auxiliary Guide ay	Goodrich
451W0173-2	Center Guide ay	Goodrich
451W1011-1	Roller Tray ay	Goodrich
451W1011-10	Roller Tray ay	Goodrich
451W1011-104	Roller Tray ay	Goodrich
451W1011-105	Roller Tray ay	Goodrich
451W1011-106	Roller Tray ay	Goodrich
451W1011-107	Roller Tray ay	Goodrich
451W1011-108	Roller Tray ay	Goodrich
451W1011-109	Roller Tray ay	Goodrich
451W1011-115	Roller Tray ay	Goodrich
451W1011-116	Roller Tray ay	Goodrich
451W1011-117	Roller Tray ay	Goodrich
451W1011-118	Roller Tray ay	Goodrich
451W1011-12	Roller Tray ay	Goodrich
451W1011-121	Roller Tray ay	Goodrich
451W1011-122	Roller Tray ay	Goodrich
451W1011-123	Roller Tray ay	Goodrich
451W1011-124	Roller Tray ay	Goodrich
451W1011-125	Roller Tray ay	Goodrich
451W1011-126	Roller Tray ay	Goodrich
451W1011-127	Roller Tray ay	Goodrich
451W1011-128	Roller Tray ay	Goodrich
451W1011-129	Roller Tray ay	Goodrich
451W1011-13	Roller Tray ay	Goodrich
451W1011-130	Roller Tray ay	Goodrich
451W1011-131	Roller Tray ay	Goodrich
451W1011-132	Roller Tray ay	Goodrich
451W1011-133	Roller Tray ay	Goodrich
451W1011-134	Roller Tray ay	Goodrich
451W1011-135	Roller Tray ay	Goodrich
451W1011-136	Roller Tray ay	Goodrich
451W1011-137	Roller Tray ay	Goodrich
451W1011-138	Roller Tray ay	Goodrich
451W1011-139	Roller Tray ay	Goodrich
451W1011-14	Roller Tray ay	Goodrich
451W1011-140	Roller Tray ay	Goodrich
451W1011-141	Roller Tray ay	Goodrich
451W1011-15	Roller Tray ay	Goodrich
451W1011-16	Roller Tray ay	Goodrich
451W1011-160	Roller Tray ay	Goodrich
451W1011-161	Roller Tray ay	Goodrich
451W1011-162	Roller Tray ay	Goodrich
451W1011-163	Roller Tray ay	Goodrich
451W1011-164	Roller Tray ay	Goodrich
451W1011-165	Roller Tray ay	Goodrich
451W1011-166	Roller Tray ay	Goodrich
451W1011-167	Roller Tray ay	Goodrich
451W1011-168	Roller Tray ay	Goodrich
451W1011-169	Roller Tray ay	Goodrich
451W1011-17	Roller Tray ay	Goodrich
451W1011-170	Roller Tray ay	Goodrich
451W1011-171	Roller Tray ay	Goodrich
451W1011-172	Roller Tray ay	Goodrich

Repair_Capability_List_Excel

451W1011-173	Roller Tray ay	Goodrich
451W1011-174	Roller Tray ay	Goodrich
451W1011-175	Roller Tray ay	Goodrich
451W1011-176	Roller Tray ay	Goodrich
451W1011-177	Roller Tray ay	Goodrich
451W1011-19	Roller Tray ay	Goodrich
451W1011-25	Roller Tray ay	Goodrich
451W1011-26	Roller Tray ay	Goodrich
451W1011-3	Roller Tray ay	Goodrich
451W1011-30	Roller Tray ay	Goodrich
451W1011-31	Roller Tray ay	Goodrich
451W1011-32	Roller Tray ay	Goodrich
451W1011-35	Roller Tray ay	Goodrich
451W1011-36	Roller Tray ay	Goodrich
451W1011-37	Roller Tray ay	Goodrich
451W1011-38	Roller Tray ay	Goodrich
451W1011-39	Roller Tray ay	Goodrich
451W1011-40	Roller Tray ay	Goodrich
451W1011-41	Roller Tray ay	Goodrich
451W1011-42	Roller Tray ay	Goodrich
451W1011-43	Roller Tray ay	Goodrich
451W1011-44	Roller Tray ay	Goodrich
451W1011-45	Roller Tray ay	Goodrich
451W1011-46	Roller Tray ay	Goodrich
451W1011-47	Roller Tray ay	Goodrich
451W1011-48	Roller Tray ay	Goodrich
451W1011-49	Roller Tray ay	Goodrich
451W1011-5	Roller Tray ay	Goodrich
451W1011-50	Roller Tray ay	Goodrich
451W1011-51	Roller Tray ay	Goodrich
451W1011-52	Roller Tray ay	Goodrich
451W1011-53	Roller Tray ay	Goodrich
451W1011-54	Roller Tray ay	Goodrich
451W1011-55	Roller Tray ay	Goodrich
451W1011-56	Roller Tray ay	Goodrich
451W1011-57	Roller Tray ay	Goodrich
451W1011-58	Roller Tray ay	Goodrich
451W1011-59	Roller Tray ay	Goodrich
451W1011-6	Roller Tray ay	Goodrich
451W1011-60	Roller Tray ay	Goodrich
451W1011-61	Roller Tray ay	Goodrich
451W1011-62	Roller Tray ay	Goodrich
451W1011-63	Roller Tray ay	Goodrich
451W1011-64	Roller Tray ay	Goodrich
451W1011-65	Roller Tray ay	Goodrich
451W1011-66	Roller Tray ay	Goodrich
451W1011-67	Roller Tray ay	Goodrich
451W1011-68	Roller Tray ay	Goodrich
451W1011-69	Roller Tray ay	Goodrich
451W1011-7	Roller Tray ay	Goodrich
451W1011-70	Roller Tray ay	Goodrich
451W1011-71	Roller Tray ay	Goodrich
451W1011-74	Roller Tray ay	Goodrich
451W1011-75	Roller Tray ay	Goodrich
451W1011-76	Roller Tray ay	Goodrich
451W1011-77	Roller Tray ay	Goodrich
451W1011-78	Roller Tray ay	Goodrich
451W1011-79	Roller Tray ay	Goodrich

Repair_Capability_List_Excel

451W1011-8	Roller Tray ay	Goodrich
451W1011-80	Roller Tray ay	Goodrich
451W1011-81	Roller Tray ay	Goodrich
451W1011-82	Roller Tray ay	Goodrich
451W1011-83	Roller Tray ay	Goodrich
451W1011-84	Roller Tray ay	Goodrich
451W1011-85	Roller Tray ay	Goodrich
451W1011-9	Roller Tray ay	Goodrich
451W1011-95	Roller Tray ay	Goodrich
451W1011-96	Roller Tray ay	Goodrich
451W1011-97	Roller Tray ay	Goodrich
451W1011-98	Roller Tray ay	Goodrich
451W1011-99	Roller Tray ay	Goodrich
451W1021-1	Roller Tray ay	Goodrich
451W1021-10	Roller Tray ay	Goodrich
451W1021-109	Roller Tray ay	Goodrich
451W1021-11	Roller Tray ay	Goodrich
451W1021-110	Roller Tray ay	Goodrich
451W1021-111	Roller Tray ay	Goodrich
451W1021-112	Roller Tray ay	Goodrich
451W1021-113	Roller Tray ay	Goodrich
451W1021-114	Roller Tray ay	Goodrich
451W1021-115	Roller Tray ay	Goodrich
451W1021-116	Roller Tray ay	Goodrich
451W1021-117	Roller Tray ay	Goodrich
451W1021-118	Roller Tray ay	Goodrich
451W1021-119	Roller Tray ay	Goodrich
451W1021-12	Roller Tray ay	Goodrich
451W1021-120	Roller Tray ay	Goodrich
451W1021-13	Roller Tray ay	Goodrich
451W1021-14	Roller Tray ay	Goodrich
451W1021-15	Roller Tray ay	Goodrich
451W1021-166	Roller Tray ay	Goodrich
451W1021-167	Roller Tray ay	Goodrich
451W1021-168	Roller Tray ay	Goodrich
451W1021-169	Roller Tray ay	Goodrich
451W1021-17	Roller Tray ay	Goodrich
451W1021-178	Roller Tray ay	Goodrich
451W1021-179	Roller Tray ay	Goodrich
451W1021-18	Roller Tray ay	Goodrich
451W1021-180	Roller Tray ay	Goodrich
451W1021-181	Roller Tray ay	Goodrich
451W1021-182	Roller Tray ay	Goodrich
451W1021-183	Roller Tray ay	Goodrich
451W1021-184	Roller Tray ay	Goodrich
451W1021-185	Roller Tray ay	Goodrich
451W1021-186	Roller Tray ay	Goodrich
451W1021-187	Roller Tray ay	Goodrich
451W1021-19	Roller Tray ay	Goodrich
451W1021-2	Roller Tray ay	Goodrich
451W1021-20	Roller Tray ay	Goodrich
451W1021-21	Roller Tray ay	Goodrich
451W1021-22	Roller Tray ay	Goodrich
451W1021-23	Roller Tray ay	Goodrich
451W1021-24	Roller Tray ay	Goodrich
451W1021-25	Roller Tray ay	Goodrich
451W1021-26	Roller Tray ay	Goodrich
451W1021-27	Roller Tray ay	Goodrich

Repair_Capability_List_Excel

451W1021-28	Roller Tray ay	Goodrich
451W1021-29	Roller Tray ay	Goodrich
451W1021-30	Roller Tray ay	Goodrich
451W1021-34	Roller Tray ay	Goodrich
451W1021-35	Roller Tray ay	Goodrich
451W1021-36	Roller Tray ay	Goodrich
451W1021-37	Roller Tray ay	Goodrich
451W1021-38	Roller Tray ay	Goodrich
451W1021-39	Roller Tray ay	Goodrich
451W1021-40	Roller Tray ay	Goodrich
451W1021-41	Roller Tray ay	Goodrich
451W1021-42	Roller Tray ay	Goodrich
451W1021-43	Roller Tray ay	Goodrich
451W1021-44	Roller Tray ay	Goodrich
451W1021-45	Roller Tray ay	Goodrich
451W1021-46	Roller Tray ay	Goodrich
451W1021-47	Roller Tray ay	Goodrich
451W1021-48	Roller Tray ay	Goodrich
451W1021-49	Roller Tray ay	Goodrich
451W1021-50	Roller Tray ay	Goodrich
451W1021-51	Roller Tray ay	Goodrich
451W1021-52	Roller Tray ay	Goodrich
451W1021-53	Roller Tray ay	Goodrich
451W1021-54	Roller Tray ay	Goodrich
451W1021-55	Roller Tray ay	Goodrich
451W1021-56	Roller Tray ay	Goodrich
451W1021-57	Roller Tray ay	Goodrich
451W1021-58	Roller Tray ay	Goodrich
451W1021-59	Roller Tray ay	Goodrich
451W1021-6	Roller Tray ay	Goodrich
451W1021-60	Roller Tray ay	Goodrich
451W1021-61	Roller Tray ay	Goodrich
451W1021-62	Roller Tray ay	Goodrich
451W1021-63	Roller Tray ay	Goodrich
451W1021-64	Roller Tray ay	Goodrich
451W1021-65	Roller Tray ay	Goodrich
451W1021-66	Roller Tray ay	Goodrich
451W1021-67	Roller Tray ay	Goodrich
451W1021-68	Roller Tray ay	Goodrich
451W1021-69	Roller Tray ay	Goodrich
451W1021-7	Roller Tray ay	Goodrich
451W1021-70	Roller Tray ay	Goodrich
451W1021-73	Roller Tray ay	Goodrich
451W1021-74	Roller Tray ay	Goodrich
451W1021-75	Roller Tray ay	Goodrich
451W1021-76	Roller Tray ay	Goodrich
451W1021-77	Roller Tray ay	Goodrich
451W1021-8	Roller Tray ay	Goodrich
451W1021-81	Roller Tray ay	Goodrich
451W1021-82	Roller Tray ay	Goodrich
451W1021-83	Roller Tray ay	Goodrich
451W1021-84	Roller Tray ay	Goodrich
451W1021-85	Roller Tray ay	Goodrich
451W1021-86	Roller Tray ay	Goodrich
451W1021-87	Roller Tray ay	Goodrich
451W1021-88	Roller Tray ay	Goodrich
451W1021-89	Roller Tray ay	Goodrich
451W1021-9	Roller Tray ay	Goodrich

Repair_Capability_List_Excel

451W1021-90	Roller Tray ay	Goodrich
451W1021-91	Roller Tray ay	Goodrich
451W1021-92	Roller Tray ay	Goodrich
451W1021-93	Roller Tray ay	Goodrich
451W1021-94	Roller Tray ay	Goodrich
451W1021-95	Roller Tray ay	Goodrich
451W1021-96	Roller Tray ay	Goodrich
451W1021-97	Roller Tray ay	Goodrich
451W1021-98	Roller Tray ay	Goodrich
451W1310-1	Cargo System Guide Roller ay	Goodrich
451W1310-2	Cargo System Guide Roller ay	Goodrich
451W1315-1	Sill Roller ay	Goodrich
451W1315-2	Sill Roller ay	Goodrich
451W1315-3	Sill Roller ay	Goodrich
451W1315-4	Sill Roller ay	Goodrich
451W1320-5	Cargo System Guide Roller ay	Goodrich
451W1320-6	Cargo System Guide Roller ay	Goodrich
451W1330-11	Stop and Lock ay	Goodrich
451W1330-12	Stop and Lock ay	Goodrich
451W1330-6	Stop and Lock ay	Goodrich
451W1330-7	Stop and Lock ay	Goodrich
451W1330-8	Stop and Lock ay	Goodrich
451W1330-9	Stop and Lock ay	Goodrich
451W1360-7	Retractable Guide Roller/Lock ay	Goodrich
451W1360-8	Retractable Guide Roller/Lock ay	Goodrich
451W1360-9	Retractable Guide Roller/Lock ay	Goodrich
451W1370-1	Retractable Guide Roller/Lock ay	Goodrich
451W1370-3	Retractable Guide Roller/Lock ay	Goodrich
451W1370-4	Retractable Guide Roller/Lock ay	Goodrich
451W1380-1	Stop and Lock ay	Goodrich
451W1380-2	Stop and Lock ay	Goodrich
451W1380-3	Stop and Lock ay	Goodrich
451W1380-4	Stop and Lock ay	Goodrich
451W1420-1	Guide Roller ay	Goodrich
451W1420-2	Guide Roller ay	Goodrich
451W1420-4	Guide Roller ay	Goodrich
451W3120-1	Stop ay	Goodrich
451W3130-1	Side Pallet Lock ay	Goodrich
451W3130-2	Side Pallet Lock ay	Goodrich
451W3140-1	Pallet Lock ay	Goodrich
451W3140-2	Pallet Lock ay	Goodrich
451W3150-1	Stop and Lock ay	Goodrich
451W3190-1	Pallet Lock ay	Goodrich
451W3190-2	Pallet Lock ay	Goodrich
451W3190-3	Pallet Lock ay	Goodrich
451W3190-4	Pallet Lock ay	Goodrich
451W3220-1	Stop ay	Goodrich
451W3260-1	Stop ay	Goodrich
451W3270-1	Stop and Lock ay	Goodrich
451W3276-1	Stop and Lock ay	Goodrich
451W3320-1	Stop ay	Goodrich
451W4110-11	Side Guide Rail ay	Goodrich
451W4110-12	Side Guide Rail ay	Goodrich
451W4110-13	Side Guide Rail ay	Goodrich
451W4110-15	Side Guide Rail ay	Goodrich
451W4110-16	Side Guide Rail ay	Goodrich
451W4110-17	Side Guide Rail ay	Goodrich
451W4110-18	Side Guide Rail ay	Goodrich

Repair_Capability_List_Excel

451W4110-19	Side Guide Rail ay	Goodrich
451W4110-20	Side Guide Rail ay	Goodrich
451W4110-21	Side Guide Rail ay	Goodrich
451W4110-22	Side Guide Rail ay	Goodrich
451W4110-23	Side Guide Rail ay	Goodrich
451W4110-25	Side Guide Rail ay	Goodrich
451W4110-26	Side Guide Rail ay	Goodrich
451W4110-27	Side Guide Rail ay	Goodrich
451W4110-28	Side Guide Rail ay	Goodrich
451W4110-29	Side Guide Rail ay	Goodrich
451W4110-30	Side Guide Rail ay	Goodrich
451W4110-31	Side Guide Rail ay	Goodrich
451W4110-32	Side Guide Rail ay	Goodrich
451W4110-33	Side Guide Rail ay	Goodrich
451W4110-34	Side Guide Rail ay	Goodrich
451W4110-35	Side Guide Rail ay	Goodrich
451W4110-36	Side Guide Rail ay	Goodrich
451W4110-37	Side Guide Rail ay	Goodrich
451W4110-38	Side Guide Rail ay	Goodrich
451W4110-39	Side Guide Rail ay	Goodrich
451W4110-40	Side Guide Rail ay	Goodrich
451W4110-41	Side Guide Rail ay	Goodrich
451W4110-42	Side Guide Rail ay	Goodrich
451W4110-43	Side Guide Rail ay	Goodrich
451W4140-1	Guide ay	Goodrich
451W4140-2	Guide ay	Goodrich
451W4140-3	Guide ay	Goodrich
451W4140-4	Guide ay	Goodrich
451W4140-5	Guide ay	Goodrich
451W4140-6	Guide ay	Goodrich
451W4150-7	Center Guide ay	Goodrich
451W4150-8	Center Guide ay	Goodrich
451W4169-1	Auxiliary Guide ay	Goodrich
451W4169-2	Auxiliary Guide ay	Goodrich
451W4169-3	Auxiliary Guide ay	Goodrich
451W4169-4	Auxiliary Guide ay	Goodrich
451W4169-5	Auxiliary Guide ay	Goodrich
451W4169-6	Auxiliary Guide ay	Goodrich
451W4170-3	Auxiliary Guide ay	Goodrich
451W4170-4	Auxiliary Guide ay	Goodrich
451W4170-5	Auxiliary Guide ay	Goodrich
451W4170-6	Auxiliary Guide ay	Goodrich
451W4210-12	Side Guide Rail ay	Goodrich
451W4210-13	Side Guide Rail ay	Goodrich
451W4210-14	Side Guide Rail ay	Goodrich
451W4210-15	Side Guide Rail ay	Goodrich
451W4210-16	Side Guide Rail ay	Goodrich
451W4210-17	Side Guide Rail ay	Goodrich
451W4210-18	Side Guide Rail ay	Goodrich
451W4210-19	Side Guide Rail ay	Goodrich
451W4210-20	Side Guide Rail ay	Goodrich
451W4210-21	Side Guide Rail ay	Goodrich
451W4210-22	Side Guide Rail ay	Goodrich
451W4210-23	Side Guide Rail ay	Goodrich
451W4210-24	Side Guide Rail ay	Goodrich
451W4210-25	Side Guide Rail ay	Goodrich
451W4210-26	Side Guide Rail ay	Goodrich
451W4210-27	Side Guide Rail ay	Goodrich

Repair_Capability_List_Excel

451W4210-28	Side Guide Rail ay	Goodrich
451W4210-29	Side Guide Rail ay	Goodrich
451W4210-30	Side Guide Rail ay	Goodrich
451W4210-31	Side Guide Rail ay	Goodrich
451W4210-32	Side Guide Rail ay	Goodrich
451W4210-33	Side Guide Rail ay	Goodrich
451W4210-34	Side Guide Rail ay	Goodrich
451W4210-35	Side Guide Rail ay	Goodrich
451W4210-36	Side Guide Rail ay	Goodrich
451W4210-37	Side Guide Rail ay	Goodrich
451W4210-38	Side Guide Rail ay	Goodrich
451W4210-39	Side Guide Rail ay	Goodrich
451W4210-40	Side Guide Rail ay	Goodrich
451W4210-41	Side Guide Rail ay	Goodrich
451W4210-43	Side Guide Rail ay	Goodrich
451W4210-44	Side Guide Rail ay	Goodrich
451W4210-45	Side Guide Rail ay	Goodrich
451W4210-46	Side Guide Rail ay	Goodrich
451W4210-47	Side Guide Rail ay	Goodrich
451W4210-48	Side Guide Rail ay	Goodrich
451W4210-55	Side Guide Rail ay	Goodrich
451W4210-56	Side Guide Rail ay	Goodrich
451W4210-57	Side Guide Rail ay	Goodrich
451W4210-58	Side Guide Rail ay	Goodrich
451W4210-59	Side Guide Rail ay	Goodrich
451W4210-60	Side Guide Rail ay	Goodrich
451W4210-61	Side Guide Rail ay	Goodrich
451W4310-3	Lateral Guide ay	Goodrich
451W4310-4	Lateral Guide ay	Goodrich
451W4310-5	Lateral Guide ay	Goodrich
451W4310-6	Lateral Guide ay	Goodrich
451W4310-7	Lateral Guide ay	Goodrich
451W4310-8	Lateral Guide ay	Goodrich
451W4360-10	Auxiliary Stop/Lock ay	Goodrich
451W4360-15	Auxiliary Stop/Lock ay	Goodrich
451W4360-16	Auxiliary Stop/Lock ay	Goodrich
451W4360-17	Auxiliary Stop/Lock ay	Goodrich
451W4360-18	Auxiliary Stop/Lock ay	Goodrich
451W4360-7	Auxiliary Stop/Lock ay	Goodrich
451W4360-8	Auxiliary Stop/Lock ay	Goodrich
451W4360-9	Auxiliary Stop/Lock ay	Goodrich
451W4380-1	Auxiliary Stop/Lock ay	Goodrich
451W4380-2	Auxiliary Stop/Lock ay	Goodrich
451W4410-10	Lateral Guide ay	Goodrich
451W4410-5	Lateral Guide ay	Goodrich
451W4410-6	Lateral Guide ay	Goodrich
451W4410-7	Lateral Guide ay	Goodrich
451W4410-8	Lateral Guide ay	Goodrich
451W4410-9	Lateral Guide ay	Goodrich
451W4412-1	Lateral Guide ay	Goodrich
451W4440-13	Lateral Guide ay	Goodrich
451W4440-14	Lateral Guide ay	Goodrich
451W4440-15	Lateral Guide ay	Goodrich
451W4440-16	Lateral Guide ay	Goodrich
451W4440-20	Lateral Guide ay	Goodrich
451W4440-21	Lateral Guide ay	Goodrich
451W4470-4	Stop and Lock ay	Goodrich
451W4470-5	Stop and Lock ay	Goodrich

Repair_Capability_List_Excel

451W4475-1	Stop and Lock ay	Goodrich
451W4475-2	Stop and Lock ay	Goodrich
451W4475-3	Stop and Lock ay	Goodrich
451W4475-4	Stop and Lock ay	Goodrich
452100-01	Mode Selector Unit	Litton Systems
452100-01BLK	Mode Selector Unit	Litton Systems
452100-02	Mode Selector Unit	Litton Systems
452100-02-03	Mode Selector Unit	Litton Systems
452100-02BLK	Mode Selector Unit	Litton Systems
45220-4	Thermo Resistor	Normalair
45220-9	Thermo Resistor	Normalair
4524-3001	Displacement Transducer	Ametek
4524-3002	Displacement Transducer	Ametek
4524-3003	Displacement Transducer	Ametek
4524-3004	Displacement Transducer	Ametek
4524-3005	Displacement Transducer	Ametek
4524-3006	Displacement Transducer	Ametek
4524-3007	Displacement Transducer	Ametek
4524-3401	Displacement Transducer	Ametek
4524-3402	Displacement Transducer	Ametek
4524-3403	Displacement Transducer	Ametek
4524-3404	Displacement Transducer	Ametek
4524-3405	Displacement Transducer	Ametek
4524-3406	Displacement Transducer	Ametek
4524-3407	Displacement Transducer	Ametek
4527-1	Relief Valve	Pneudraulics
452T1003-2	Stop ay	Goodrich
452T1003-3	Stop ay	Goodrich
452T1003-4	Stop ay	Goodrich
452T1003-5	Stop ay	Goodrich
452T1003-6	Stop ay	Goodrich
452T1003-7	Stop ay	Goodrich
452T1004-2	Retractable Stop ay	Goodrich
452T1004-4	Retractable Stop ay	Goodrich
452T1016-1	Lock ay	Goodrich
452T1016-2	Lock ay	Goodrich
452T1021-2	Stop ay	Goodrich
452T1021-3	Stop ay	Goodrich
452T1030-1	Stop ay	Goodrich
452T1030-2	Stop ay	Goodrich
452T1030-3	Stop ay	Goodrich
452T1030-4	Stop ay	Goodrich
452T1037-1	Stop ay	Goodrich
452T1040-1	Stop ay	Goodrich
452T1053-1	Lock ay	Goodrich
452T1054-1	Stop ay	Goodrich
452T1055-1	Stop ay	Goodrich
452T1103-1	Stop ay	Goodrich
452T1104-10	Stop and Lock ay	Goodrich
452T1104-11	Stop and Lock ay	Goodrich
452T1104-12	Stop and Lock ay	Goodrich
452T1104-5	Stop and Lock ay	Goodrich
452T1104-6	Stop and Lock ay	Goodrich
452T1104-7	Stop and Lock ay	Goodrich
452T1104-8	Stop and Lock ay	Goodrich
452T1104-9	Stop and Lock ay	Goodrich
452T1131-1	Lock ay	Goodrich
452T1131-4	Lock ay	Goodrich

Repair_Capability_List_Excel

452T1131-6	Lock ay	Goodrich
452T1141-1	Pallet Lock and Stop Lock ay	Goodrich
452T1141-2	Pallet Lock and Stop Lock ay	Goodrich
452T1141-3	Pallet Lock and Stop Lock ay	Goodrich
452T1147-1	Lock ay	Goodrich
452T1147-2	Lock ay	Goodrich
452T1147-3	Lock ay	Goodrich
452T1152-3	Stop ay	Goodrich
452T1152-4	Stop ay	Goodrich
452T1159-1	Lock ay	Goodrich
452T1159-2	Lock ay	Goodrich
452T1201-15	Stop/Lock ay	Goodrich
452T1201-16	Stop/Lock ay	Goodrich
452T1201-17	Stop/Lock ay	Goodrich
452T1201-18	Stop/Lock ay	Goodrich
452T1201-7	Stop/Lock ay	Goodrich
452T1201-9	Stop/Lock ay	Goodrich
452T1202-15	Auxiliary Stop/Lock ay	Goodrich
452T1202-16	Auxiliary Stop/Lock ay	Goodrich
452T1202-17	Auxiliary Stop/Lock ay	Goodrich
452T1202-18	Auxiliary Stop/Lock ay	Goodrich
452T1202-7	Auxiliary Stop/Lock ay	Goodrich
452T1202-9	Auxiliary Stop/Lock ay	Goodrich
452T1603-17	Stop ay	Goodrich
452T1603-18	Stop ay	Goodrich
452T1603-19	Stop ay	Goodrich
452T1603-20	Stop ay	Goodrich
452T1603-25	Stop ay	Goodrich
452T1603-26	Stop ay	Goodrich
452T1603-27	Stop ay	Goodrich
452T1603-28	Stop ay	Goodrich
452T1603-29	Stop ay	Goodrich
452T1603-30	Stop ay	Goodrich
452T1603-31	Stop ay	Goodrich
452T1603-32	Stop ay	Goodrich
452T1603-33	Stop ay	Goodrich
452T1603-34	Stop ay	Goodrich
452T1603-35	Stop ay	Goodrich
452T1603-36	Stop ay	Goodrich
452T1603-37	Stop ay	Goodrich
452T1603-38	Stop ay	Goodrich
452T1630-10	Stop ay	Goodrich
452T1630-11	Stop ay	Goodrich
452T1630-4	Stop ay	Goodrich
452T1630-5	Stop ay	Goodrich
452T1630-6	Stop ay	Goodrich
452T1630-7	Stop ay	Goodrich
452T1630-8	Stop ay	Goodrich
452T1630-9	Stop ay	Goodrich
452T2003-1	Guide Rail ay	Goodrich
452T2003-10	Guide Rail ay	Goodrich
452T2003-100	Guide Rail ay	Goodrich
452T2003-101	Guide Rail ay	Goodrich
452T2003-102	Guide Rail ay	Goodrich
452T2003-103	Guide Rail ay	Goodrich
452T2003-104	Guide Rail ay	Goodrich
452T2003-105	Guide Rail ay	Goodrich
452T2003-106	Guide Rail ay	Goodrich

Repair_Capability_List_Excel

452T2003-107	Guide Rail ay	Goodrich
452T2003-108	Guide Rail ay	Goodrich
452T2003-109	Guide Rail ay	Goodrich
452T2003-11	Guide Rail ay	Goodrich
452T2003-110	Guide Rail ay	Goodrich
452T2003-112	Guide Rail ay	Goodrich
452T2003-113	Guide Rail ay	Goodrich
452T2003-114	Guide Rail ay	Goodrich
452T2003-115	Guide Rail ay	Goodrich
452T2003-116	Guide Rail ay	Goodrich
452T2003-117	Guide Rail ay	Goodrich
452T2003-118	Guide Rail ay	Goodrich
452T2003-119	Guide Rail ay	Goodrich
452T2003-12	Guide Rail ay	Goodrich
452T2003-120	Guide Rail ay	Goodrich
452T2003-121	Guide Rail ay	Goodrich
452T2003-122	Guide Rail ay	Goodrich
452T2003-123	Guide Rail ay	Goodrich
452T2003-124	Guide Rail ay	Goodrich
452T2003-125	Guide Rail ay	Goodrich
452T2003-126	Guide Rail ay	Goodrich
452T2003-127	Guide Rail ay	Goodrich
452T2003-128	Guide Rail ay	Goodrich
452T2003-129	Guide Rail ay	Goodrich
452T2003-130	Guide Rail ay	Goodrich
452T2003-131	Guide Rail ay	Goodrich
452T2003-132	Guide Rail ay	Goodrich
452T2003-133	Guide Rail ay	Goodrich
452T2003-134	Guide Rail ay	Goodrich
452T2003-135	Guide Rail ay	Goodrich
452T2003-136	Guide Rail ay	Goodrich
452T2003-15	Guide Rail ay	Goodrich
452T2003-2	Guide Rail ay	Goodrich
452T2003-20	Guide Rail ay	Goodrich
452T2003-21	Guide Rail ay	Goodrich
452T2003-22	Guide Rail ay	Goodrich
452T2003-25	Guide Rail ay	Goodrich
452T2003-26	Guide Rail ay	Goodrich
452T2003-27	Guide Rail ay	Goodrich
452T2003-28	Guide Rail ay	Goodrich
452T2003-29	Guide Rail ay	Goodrich
452T2003-30	Guide Rail ay	Goodrich
452T2003-31	Guide Rail ay	Goodrich
452T2003-32	Guide Rail ay	Goodrich
452T2003-33	Guide Rail ay	Goodrich
452T2003-34	Guide Rail ay	Goodrich
452T2003-35	Guide Rail ay	Goodrich
452T2003-36	Guide Rail ay	Goodrich
452T2003-37	Guide Rail ay	Goodrich
452T2003-38	Guide Rail ay	Goodrich
452T2003-39	Guide Rail ay	Goodrich
452T2003-40	Guide Rail ay	Goodrich
452T2003-42	Guide Rail ay	Goodrich
452T2003-43	Guide Rail ay	Goodrich
452T2003-45	Guide Rail ay	Goodrich
452T2003-46	Guide Rail ay	Goodrich
452T2003-47	Guide Rail ay	Goodrich
452T2003-48	Guide Rail ay	Goodrich

Repair_Capability_List_Excel

452T2003-49	Guide Rail ay	Goodrich
452T2003-5	Guide Rail ay	Goodrich
452T2003-50	Guide Rail ay	Goodrich
452T2003-51	Guide Rail ay	Goodrich
452T2003-52	Guide Rail ay	Goodrich
452T2003-53	Guide Rail ay	Goodrich
452T2003-54	Guide Rail ay	Goodrich
452T2003-55	Guide Rail ay	Goodrich
452T2003-56	Guide Rail ay	Goodrich
452T2003-57	Guide Rail ay	Goodrich
452T2003-58	Guide Rail ay	Goodrich
452T2003-59	Guide Rail ay	Goodrich
452T2003-6	Guide Rail ay	Goodrich
452T2003-60	Guide Rail ay	Goodrich
452T2003-61	Guide Rail ay	Goodrich
452T2003-62	Guide Rail ay	Goodrich
452T2003-63	Guide Rail ay	Goodrich
452T2003-64	Guide Rail ay	Goodrich
452T2003-65	Guide Rail ay	Goodrich
452T2003-66	Guide Rail ay	Goodrich
452T2003-67	Guide Rail ay	Goodrich
452T2003-68	Guide Rail ay	Goodrich
452T2003-69	Guide Rail ay	Goodrich
452T2003-7	Guide Rail ay	Goodrich
452T2003-70	Guide Rail ay	Goodrich
452T2003-71	Guide Rail ay	Goodrich
452T2003-72	Guide Rail ay	Goodrich
452T2003-73	Guide Rail ay	Goodrich
452T2003-74	Guide Rail ay	Goodrich
452T2003-75	Guide Rail ay	Goodrich
452T2003-76	Guide Rail ay	Goodrich
452T2003-77	Guide Rail ay	Goodrich
452T2003-79	Guide Rail ay	Goodrich
452T2003-80	Guide Rail ay	Goodrich
452T2003-81	Guide Rail ay	Goodrich
452T2003-83	Guide Rail ay	Goodrich
452T2003-84	Guide Rail ay	Goodrich
452T2003-85	Guide Rail ay	Goodrich
452T2003-86	Guide Rail ay	Goodrich
452T2003-88	Guide Rail ay	Goodrich
452T2003-89	Guide Rail ay	Goodrich
452T2003-9	Guide Rail ay	Goodrich
452T2003-90	Guide Rail ay	Goodrich
452T2003-91	Guide Rail ay	Goodrich
452T2003-92	Guide Rail ay	Goodrich
452T2003-94	Guide Rail ay	Goodrich
452T2003-95	Guide Rail ay	Goodrich
452T2003-96	Guide Rail ay	Goodrich
452T2003-97	Guide Rail ay	Goodrich
452T2003-98	Guide Rail ay	Goodrich
452T2003-99	Guide Rail ay	Goodrich
452T2103-1	Guide Roller ay	Goodrich
452T2103-10	Guide Roller ay	Goodrich
452T2103-2	Guide Roller ay	Goodrich
452T2103-3	Guide Roller ay	Goodrich
452T2103-4	Guide Roller ay	Goodrich
452T2103-7	Guide Roller ay	Goodrich
452T2103-8	Guide Roller ay	Goodrich

Repair_Capability_List_Excel

452T2103-9	Guide Roller ay	Goodrich
452T2107-10	Retractable Guide Roller ay	Goodrich
452T2107-11	Retractable Guide Roller ay	Goodrich
452T2107-12	Retractable Guide Roller ay	Goodrich
452T2107-3	Retractable Guide Roller ay	Goodrich
452T2107-4	Retractable Guide Roller ay	Goodrich
452T2107-5	Retractable Guide Roller ay	Goodrich
452T2107-6	Retractable Guide Roller ay	Goodrich
452T2107-7	Retractable Guide Roller ay	Goodrich
452T2107-8	Retractable Guide Roller ay	Goodrich
452T2107-9	Retractable Guide Roller ay	Goodrich
452T2123-2	Vertical Restraint ay	Goodrich
452T2130-1	Side Guide Base ay	Goodrich
452T2130-12	Side Guide Base ay	Goodrich
452T2130-13	Side Guide Base ay	Goodrich
452T2130-14	Side Guide Base ay	Goodrich
452T2130-15	Side Guide Base ay	Goodrich
452T2130-2	Side Guide Base ay	Goodrich
452T2130-20	Side Guide Base ay	Goodrich
452T2130-21	Side Guide Base ay	Goodrich
452T2130-23	Side Guide Base ay	Goodrich
452T2130-24	Side Guide Base ay	Goodrich
452T2130-25	Side Guide Base ay	Goodrich
452T2130-26	Side Guide Base ay	Goodrich
452T2130-3	Side Guide Base ay	Goodrich
452T2130-4	Side Guide Base ay	Goodrich
452T2130-5	Side Guide Base ay	Goodrich
452T2130-6	Side Guide Base ay	Goodrich
452T2130-9	Side Guide Base ay	Goodrich
452T2200-5	Guide Roller ay	Goodrich
452T2200-6	Guide Roller ay	Goodrich
452T2200-7	Guide Roller ay	Goodrich
452T2200-8	Guide Roller ay	Goodrich
452T2201-6	Guide Roller ay	Goodrich
452T2204-1	Pallet Guide Roller ay	Goodrich
452T2204-10	Pallet Guide Roller ay	Goodrich
452T2204-2	Pallet Guide Roller ay	Goodrich
452T2204-3	Pallet Guide Roller ay	Goodrich
452T2204-4	Pallet Guide Roller ay	Goodrich
452T2204-7	Pallet Guide Roller ay	Goodrich
452T2204-8	Pallet Guide Roller ay	Goodrich
452T2204-9	Pallet Guide Roller ay	Goodrich
452T2301-10	Auxiliary Guide ay	Goodrich
452T2301-11	Auxiliary Guide ay	Goodrich
452T2301-13	Auxiliary Guide ay	Goodrich
452T2301-14	Auxiliary Guide ay	Goodrich
452T2301-16	Auxiliary Guide ay	Goodrich
452T2301-17	Auxiliary Guide ay	Goodrich
452T2603-11	Lateral Guide ay	Goodrich
452T2603-13	Lateral Guide ay	Goodrich
452T2603-20	Lateral Guide ay	Goodrich
452T2603-22	Lateral Guide ay	Goodrich
452T2603-23	Lateral Guide ay	Goodrich
452T2603-7	Lateral Guide ay	Goodrich
452T2603-9	Lateral Guide ay	Goodrich
452T2633-1	Lateral Guide ay	Goodrich
452T2633-11	Lateral Guide ay	Goodrich
452T2633-13	Lateral Guide ay	Goodrich

Repair_Capability_List_Excel

452T2633-15	Lateral Guide ay	Goodrich
452T2633-16	Lateral Guide ay	Goodrich
452T2633-17	Lateral Guide ay	Goodrich
452T2633-18	Lateral Guide ay	Goodrich
452T2633-19	Lateral Guide ay	Goodrich
452T2633-20	Lateral Guide ay	Goodrich
452T2633-21	Lateral Guide ay	Goodrich
452T2633-22	Lateral Guide ay	Goodrich
452T2633-24	Lateral Guide ay	Goodrich
452T2633-27	Lateral Guide ay	Goodrich
452T2633-28	Lateral Guide ay	Goodrich
452T2633-29	Lateral Guide ay	Goodrich
452T2633-3	Lateral Guide ay	Goodrich
452T2633-30	Lateral Guide ay	Goodrich
452T2633-31	Lateral Guide ay	Goodrich
452T2633-34	Lateral Guide ay	Goodrich
452T2633-35	Lateral Guide ay	Goodrich
452T2633-37	Lateral Guide ay	Goodrich
452T2633-5	Lateral Guide ay	Goodrich
452T2633-7	Lateral Guide ay	Goodrich
452T2633-9	Lateral Guide ay	Goodrich
452T3216-10	Bulk Cargo Door Protector Strut	Boeing
452T3216-11	Bulk Cargo Door Protector Strut	Boeing
452T3216-12	Bulk Cargo Door Protector Strut	Boeing
452T3216-7	Bulk Cargo Door Protector Strut	Boeing
452T3216-8	Bulk Cargo Door Protector Strut	Boeing
452T3216-9	Bulk Cargo Door Protector Strut	Boeing
452U1012-2	Roller Guide ay	Goodrich
452U1012-3	Roller Guide ay	Goodrich
452U1013-1	Roller Guide ay	Goodrich
452U1014-1	Roller Guide ay	Goodrich
452U1014-2	Roller Guide ay	Goodrich
452U1022-1	Stop ay	Goodrich
452U1022-2	Stop ay	Goodrich
452U1033-1	Stop ay	Goodrich
452U1033-2	Stop ay	Goodrich
452U1040-1	Retractable Container Stop ay	Goodrich
452U1040-2	Retractable Container Stop ay	Goodrich
452U2004-1	Guide Rail ay	Goodrich
452U2004-10	Guide Rail ay	Goodrich
452U2004-11	Guide Rail ay	Goodrich
452U2004-12	Guide Rail ay	Goodrich
452U2004-13	Guide Rail ay	Goodrich
452U2004-14	Guide Rail ay	Goodrich
452U2004-15	Guide Rail ay	Goodrich
452U2004-16	Guide Rail ay	Goodrich
452U2004-17	Guide Rail ay	Goodrich
452U2004-18	Guide Rail ay	Goodrich
452U2004-19	Guide Rail ay	Goodrich
452U2004-2	Guide Rail ay	Goodrich
452U2004-21	Guide Rail ay	Goodrich
452U2004-22	Guide Rail ay	Goodrich
452U2004-23	Guide Rail ay	Goodrich
452U2004-24	Guide Rail ay	Goodrich
452U2004-25	Guide Rail ay	Goodrich
452U2004-26	Guide Rail ay	Goodrich
452U2004-27	Guide Rail ay	Goodrich
452U2004-28	Guide Rail ay	Goodrich

Repair_Capability_List_Excel

452U2004-29	Guide Rail ay	Goodrich
452U2004-3	Guide Rail ay	Goodrich
452U2004-30	Guide Rail ay	Goodrich
452U2004-31	Guide Rail ay	Goodrich
452U2004-32	Guide Rail ay	Goodrich
452U2004-33	Guide Rail ay	Goodrich
452U2004-34	Guide Rail ay	Goodrich
452U2004-35	Guide Rail ay	Goodrich
452U2004-36	Guide Rail ay	Goodrich
452U2004-37	Guide Rail ay	Goodrich
452U2004-38	Guide Rail ay	Goodrich
452U2004-39	Guide Rail ay	Goodrich
452U2004-4	Guide Rail ay	Goodrich
452U2004-5	Guide Rail ay	Goodrich
452U2004-6	Guide Rail ay	Goodrich
452U2004-7	Guide Rail ay	Goodrich
452U2004-8	Guide Rail ay	Goodrich
452U2004-9	Guide Rail ay	Goodrich
452U2101-1	Retractable Guide Rail ay	Goodrich
452U2300-1	Retractable Center Guide ay	Goodrich
4550	Fire & Overheat Detector	Whittaker
4550-01	Fire & Overheat Detector	Whittaker
4554-1	Crew Door Latch assy	Adams Rite
4554-3	Crew Door Latch assy	Adams Rite
457T2101-2	Stop ay	Goodrich
457T2102-2	Stop ay	Goodrich
457T2103-1	Stop ay	Goodrich
457T2103-2	Stop ay	Goodrich
457T2201-1	Pallet Lock ay	Goodrich
457T2201-2	Pallet Lock ay	Goodrich
457T2201-3	Pallet Lock ay	Goodrich
457T2201-4	Pallet Lock ay	Goodrich
457T2201-5	Pallet Lock ay	Goodrich
457T2202-2	Lock ay	Goodrich
457T2310-2	Guide ay	Goodrich
457T2331-1	Guide Rail Support ay	Goodrich
457T2331-2	Guide Rail Support ay	Goodrich
457T2331-3	Guide Rail Support ay	Goodrich
457T2331-4	Guide Rail Support ay	Goodrich
457T2331-5	Guide Rail Support ay	Goodrich
457T2331-6	Guide Rail Support ay	Goodrich
457T2332-1	Guide Rail ay	Goodrich
457T2332-2	Guide Rail ay	Goodrich
457T2332-3	Guide Rail ay	Goodrich
457T2332-4	Guide Rail ay	Goodrich
457T2332-5	Guide Rail ay	Goodrich
457T2332-6	Guide Rail ay	Goodrich
457T2332-7	Guide Rail ay	Goodrich
457T2332-8	Guide Rail ay	Goodrich
457T2332-9	Guide Rail ay	Goodrich
457T2361-1	Guide Rail ay	Goodrich
457T2361-10	Guide Rail ay	Goodrich
457T2361-11	Guide Rail ay	Goodrich
457T2361-12	Guide Rail ay	Goodrich
457T2361-13	Guide Rail ay	Goodrich
457T2361-14	Guide Rail ay	Goodrich
457T2361-15	Guide Rail ay	Goodrich
457T2361-16	Guide Rail ay	Goodrich

Repair_Capability_List_Excel

457T2361-17	Guide Rail ay	Goodrich
457T2361-18	Guide Rail ay	Goodrich
457T2361-19	Guide Rail ay	Goodrich
457T2361-2	Guide Rail ay	Goodrich
457T2361-20	Guide Rail ay	Goodrich
457T2361-21	Guide Rail ay	Goodrich
457T2361-22	Guide Rail ay	Goodrich
457T2361-23	Guide Rail ay	Goodrich
457T2361-24	Guide Rail ay	Goodrich
457T2361-25	Guide Rail ay	Goodrich
457T2361-3	Guide Rail ay	Goodrich
457T2361-4	Guide Rail ay	Goodrich
457T2361-5	Guide Rail ay	Goodrich
457T2361-6	Guide Rail ay	Goodrich
457T2361-7	Guide Rail ay	Goodrich
457T2361-8	Guide Rail ay	Goodrich
457T2361-9	Guide Rail ay	Goodrich
457T2362-1	Guide Rail Support ay	Goodrich
457T2362-2	Guide Rail Support ay	Goodrich
457T2362-3	Guide Rail Support ay	Goodrich
457T2362-4	Guide Rail Support ay	Goodrich
457T2362-5	Guide Rail Support ay	Goodrich
457T2362-7	Guide Rail Support ay	Goodrich
457T2362-8	Guide Rail Support ay	Goodrich
457T2368-1	Guide Rail Roller ay	Goodrich
457T2368-2	Guide Rail Roller ay	Goodrich
457T2400-1	Guide ay	Goodrich
457T2415-1	Retractable Guide Rail ay	Goodrich
457T2415-2	Retractable Guide Rail ay	Goodrich
457T2415-3	Retractable Guide Rail ay	Goodrich
457T2415-4	Retractable Guide Rail ay	Goodrich
457T2415-5	Retractable Guide Rail ay	Goodrich
457T2415-6	Retractable Guide Rail ay	Goodrich
457T2415-7	Retractable Guide Rail ay	Goodrich
457T2415-8	Retractable Guide Rail ay	Goodrich
457T2501-3	Guide ay	Goodrich
457T2501-4	Guide ay	Goodrich
457T2601-1	Stop ay	Goodrich
457T2701-1	Retractable Pivot ay	Goodrich
457T3201-1	Roller Tray ay	Goodrich
457T3201-2	Roller Tray ay	Goodrich
457T3201-3	Roller Tray ay	Goodrich
457T3201-4	Roller Tray ay	Goodrich
457T3201-5	Roller Tray ay	Goodrich
457T3201-6	Roller Tray ay	Goodrich
457T3201-7	Roller Tray ay	Goodrich
457T3201-8	Roller Tray ay	Goodrich
457T3201-9	Roller Tray ay	Goodrich
457T3301-1	Ball Tube ay	Goodrich
457T3301-2	Ball Tube ay	Goodrich
457T3301-3	Ball Tube ay	Goodrich
457T3301-4	Ball Tube ay	Goodrich
457U1033-1	Guide Rail ay	Goodrich
457U1033-2	Guide Rail ay	Goodrich
457U1039-1	Guide Rail ay	Goodrich
457U1039-2	Guide Rail ay	Goodrich
457U1039-3	Guide Rail ay	Goodrich
457U1039-4	Guide Rail ay	Goodrich

Repair_Capability_List_Excel

457U1039-5	Guide Rail ay	Goodrich
457U1039-6	Guide Rail ay	Goodrich
457U1039-7	Guide Rail ay	Goodrich
457U1047-1	Guide and Restraint ay	Goodrich
457U1047-10	Guide and Restraint ay	Goodrich
457U1047-11	Guide and Restraint ay	Goodrich
457U1047-12	Guide and Restraint ay	Goodrich
457U1047-13	Guide and Restraint ay	Goodrich
457U1047-14	Guide and Restraint ay	Goodrich
457U1047-15	Guide and Restraint ay	Goodrich
457U1047-2	Guide and Restraint ay	Goodrich
457U1047-4	Guide and Restraint ay	Goodrich
457U1047-5	Guide and Restraint ay	Goodrich
457U1047-6	Guide and Restraint ay	Goodrich
457U1047-7	Guide and Restraint ay	Goodrich
457U1047-8	Guide and Restraint ay	Goodrich
457U1047-9	Guide and Restraint ay	Goodrich
457U1048-1	Caster and Guide ay	Goodrich
457U1048-10	Caster and Guide ay	Goodrich
457U1048-15	Caster and Guide ay	Goodrich
457U1048-16	Caster and Guide ay	Goodrich
457U1048-2	Caster and Guide ay	Goodrich
457U1048-21	Caster and Guide ay	Goodrich
457U1048-22	Caster and Guide ay	Goodrich
457U1048-27	Caster and Guide ay	Goodrich
457U1048-28	Caster and Guide ay	Goodrich
457U1048-9	Caster and Guide ay	Goodrich
457U1103-1	Restraint ay	Goodrich
457U1103-3	Restraint ay	Goodrich
457U1103-4	Restraint ay	Goodrich
457U1105-1	Directional Guide Panel ay	Goodrich
457U1105-2	Directional Guide Panel ay	Goodrich
457U1105-3	Directional Guide Panel ay	Goodrich
457U1110-1	Stop ay	Goodrich
457U1110-2	Stop ay	Goodrich
457U1147-1	Caster Support ay	Goodrich
457U1147-2	Caster Support ay	Goodrich
457U1147-3	Caster Support ay	Goodrich
457U1147-4	Caster Support ay	Goodrich
457U2100-10	Power Drive Unit ay	Goodrich
457U2100-12	Power Drive Unit ay	Goodrich
457U2418-1	Guide Rail ay	Goodrich
457U2418-2	Guide Rail ay	Goodrich
457U2419-1	Guide Rail ay	Goodrich
457U2419-2	Guide Rail ay	Goodrich
457U2419-3	Guide Rail ay	Goodrich
457U2419-4	Guide Rail ay	Goodrich
457U2420-1	Guide Rail ay	Goodrich
457U2420-2	Guide Rail ay	Goodrich
457U2450-1	Guide Rail ay	Goodrich
457U2450-2	Guide Rail ay	Goodrich
457U2492-1	Guide Support ay	Goodrich
457U2515-1	Park Rail ay	Goodrich
457U2616-1	Lock Tray ay	Goodrich
457U2617-1	Stop ay	Goodrich
457U2618-1	Lock Tray ay	Goodrich
457U2618-2	Lock Tray ay	Goodrich
457U2618-3	Lock Tray ay	Goodrich

Repair_Capability_List_Excel

457U2618-4	Lock Tray ay	Goodrich
457U2618-6	Lock Tray ay	Goodrich
457U2618-7	Lock Tray ay	Goodrich
457U2619-1	Lock Tray ay	Goodrich
457U2619-2	Lock Tray ay	Goodrich
457U2619-3	Lock Tray ay	Goodrich
457U2626-1	Lock Tray ay	Goodrich
457U2626-2	Lock Tray ay	Goodrich
457U2627-1	Lock Roller Tray ay	Goodrich
457U2627-2	Lock Roller Tray ay	Goodrich
457U2658-1	Stop ay	Goodrich
45980	Priority Valve	Sterer
45980-1	Priority Valve	Sterer
45980J	Priority Valve	Sterer
45990	Priority Valve	Sterer
45990-1	Priority Valve	Sterer
45990G	Priority Valve	Sterer
45D16-1	Switch assy	Custom Control Sensors
45D31-2	Pressure Switch	Custom Control Sensors
45D32	Pressure Switch	Custom Control Sensors
45D33	Pressure Switch	Custom Control Sensors
45D34	Pressure Switch	Custom Control Sensors
45D5-1	Switch	Custom Control Sensors
4-60000H000-00	Mast Drain	Airbus Industrie
4-60000H440-00	Mast Drain	Airbus Industrie
4-60000H800-00	Mast Drain	Airbus Industrie
4-60000H840-00	Drain Mast Assy	Daimler-Benz
4-60000H880-00	Mast Drain	Airbus Industrie
4-60000H882-00	Mast Drain	Airbus Industrie
4-60000H883-00	Mast Drain	Airbus Industrie
4-60007H440-00	Mast Drain	Airbus Industrie
4-60007H800-00	Mast Drain	Airbus Industrie
4-60007H840-00	Mast Drain	Airbus Industrie
4603KPS23-5	Pressure Switch	Vibro-Meter
4603KPS27-40	Pressure Switch	Vibro-Meter
46074	Permanent Magnet Alternator	Unison
46074-2	Permanent Magnet Alternator	Unison
46075	Permanent Magnet Alternator	Unison
46075-1	Permanent Magnet Alternator	Unison
46075-2	Permanent Magnet Alternator	Unison
460PS01D5A	Push-Button Switch	ECE
4611024900	Fan Motor assy	Technofan
4611025900	Brake Fan assy	Technofan
461-424	Temperature Indicator	Hickok Electrical Inst
461-424-1	Temperature Indicator	Hickok Electrical Inst
4626-1	Valve assy	Pneudraulics
462650-1	Cargo Control Unit	Goodrich
462650-11	Cargo Control Unit	Goodrich
462650-12	Cargo Control Unit	Goodrich
462650-13	Cargo Control Unit	Goodrich
462650-2	Cargo Control Unit	Goodrich
462650-21	Cargo Control Unit	Goodrich
462650-22	Cargo Control Unit	Goodrich
462650-23	Cargo Control Unit	Goodrich
462650-3	Cargo Control Unit	Goodrich
46339-1	Alternating Current Motor	Honeywell
46362-1	Motor assy	Honeywell
46362-2	Motor assy	Honeywell

Repair_Capability_List_Excel

46363-1	Motor assy	Honeywell
46366-1	Alternating Current Motor	Honeywell
46366-2	Alternating Current Motor	Honeywell
46368-1	Motor assy	Honeywell
465220-1	Pendant ay	Goodrich
465250-1	Control Unit	Goodrich
465550-1	Cargo System Control Unit	Goodrich
465550-2	Cargo System Control Unit	Goodrich
4663	Valve assy	Kaiser Aerospace
4663-1	Valve assy	Kaiser Aerospace
4663-2	Valve assy	Kaiser Aerospace
4663-4	Valve assy	Kaiser Aerospace
4663-5	Valve assy	Kaiser Aerospace
4663-7	Valve assy	Kaiser Aerospace
4663-8	Valve assy	Kaiser Aerospace
4663S1	Valve assy	Kaiser Aerospace
4663S2	Valve assy	Kaiser Aerospace
4663S4	Valve assy	Kaiser Aerospace
4663S7	Valve assy	Kaiser Aerospace
4663S8	Valve assy	Kaiser Aerospace
4665	Valve assy	Kaiser Aerospace
466-8	Temperature Sensor	BF Goodrich
467250-1	Interface Unit ay	Goodrich
467330-100	Guide ay	Goodrich
4679-750-80-11	Flaps Position Indicator	Thales Avionics
4679-751-80-11	Flaps Position Indicator	Thales Avionics
4679-754-80-10	Flaps Position Indicator	Thales Avionics
4679-764-80-10	Flaps Position Indicator	Thales Avionics
46947	Ignition Lead	Unison
46948	Ignition Lead	Unison
47010-01	Electro Hydraulic Servo Valve	Abex
47014-81	Penant Control assy	Western
4702-6	Hydraulic Selector Valve	Tactair
4709-3	Toilet Flush Coupling	Kaiser Aerospace
471-0001-5	Water Boiler	FL Aerospace
47142-203	THS Actuator	Goodrich Control Systems
47142-303	THS Actuator	Goodrich Control Systems
47145-010	THS Actuator	Goodrich Control Systems
47145-020	THS Actuator	Goodrich Control Systems
47145-021	THS Actuator	Goodrich Control Systems
47145-030	THS Actuator	Goodrich Control Systems
47145-031	THS Actuator	Goodrich Control Systems
47145-100	THS Actuator	Goodrich Control Systems
47145-110	THS Actuator	Goodrich Control Systems
47145-120	THS Actuator	Goodrich Control Systems
47145-121	THS Actuator	Goodrich Control Systems
47145-130	THS Actuator	Goodrich Control Systems
47145-131	THS Actuator	Goodrich Control Systems
47145-132	THS Actuator	Goodrich Control Systems
47145-133	THS Actuator	Goodrich Control Systems
47147-100	THS Actuator	Goodrich Control Systems
47147-200	THS Actuator	Goodrich Control Systems
47147-210	THS Actuator	Goodrich Control Systems
47147-300	THS Actuator	Goodrich Control Systems
47147-303	THS Actuator	Goodrich Control Systems
47147-350	THS Actuator	Goodrich Control Systems
47147-400	THS Actuator	Goodrich Control Systems
47147-500	THS Actuator	Goodrich Control Systems

Repair_Capability_List_Excel

47170-2	Electric Motor	Liebherr Aerotechnik
47172	THS Actuator	Goodrich Control Systems
47172-300	THS Actuator	Goodrich Control Systems
472123	Fan Speed Sensor	Simmonds Precision
472183	Tachymeter Transmitter	Simmonds Precision
472222	Fan Speed Sensor	Simmonds Precision
472266	Control Card	Kidde Aerospace
472266-01	Control Card	Kidde Aerospace
472266A	Control Card	Kidde Aerospace
472331	Fan Speed Sensor	Simmonds Precision
472332	Fan Speed Sensor	Simmonds Precision
472404	Tachymeter Transmitter	Simmonds Precision
472565	Fire Detectors	Kidde Aerospace
472566	Fire Detectors	Kidde Aerospace
472567	Fire Detectors	Kidde Aerospace
472568	Fire Detectors	Kidde Aerospace
472568-1	Fire Detectors	Kidde Aerospace
472568-1M	Fire Detectors	Kidde Aerospace
472569	Fire Detectors	Kidde Aerospace
472570	Fire Detectors	Kidde Aerospace
472571	Fire Detectors	Kidde Aerospace
472572	Fire Detectors	Kidde Aerospace
472573	Fire Detectors	Kidde Aerospace
472574	Fire Detectors	Kidde Aerospace
472575	Fire Detectors	Kidde Aerospace
472576	Fire Detectors	Kidde Aerospace
472585	Fire Detectors	Kidde Aerospace
472586	Fire Detectors	Kidde Aerospace
473271	Sensor	Simmonds Precision
473597-4	Smoke Detector	Kidde Aerospace
473597-4-01	Smoke Detector	Kidde Aerospace
473597-4-02	Smoke Detector	Kidde Aerospace
473597-4-03	Smoke Detector	Kidde Aerospace
473597-4-04	Smoke Detector	Kidde Aerospace
473597-4-05	Smoke Detector	Kidde Aerospace
473597-4-06	Smoke Detector	Kidde Aerospace
473597-4-07	Smoke Detector	Kidde Aerospace
4739-12-4	Filling Coupling	Kaiser Aerospace
475C55N	Drain Valve	Auro Valve
475C55NW	Valve assy	Auro Valve
475C55NWP	Drain Valve	Auro Valve
475C55NWPX	Drain Valve	Auro Valve
47710	Electric Motor	Liebherr Aerotechnik
4777667-5503	Hydraulic Cylinder	Douglas
477CA01C1502Y3	Contactora	ECE
477CA01C15-02Y3	Contactora	ECE
478W1610-4	Waste Water Drain Mast	Boeing
478W1610-5	Waste Water Drain Mast	Boeing
478W1610-6	Waste Water Drain Mast	Boeing
478W1610-7	Waste Water Drain Mast	Boeing
4805362	Ball Bearing Control assy	ECE
48114-1030	Oil Cooler	Serk Aviation
48114-1135	IDG Cooler	Serck Aviation
481950-1	Cargo Control Unit	Goodrich
481950-2	Cargo Control Unit	Goodrich
481950-3	Cargo Control Unit	Goodrich
48-2-2401	Joystick	Elektro Metall Exp.
48287-3-2	DC Motor	Honeywell

Repair_Capability_List_Excel

48287-4-1	DC Motor	Honeywell
48348	Engine Starter Motor	Honeywell
48364-1-1	Starter Motor	Honeywell
48364-1-3	Starter Motor	Honeywell
48364-1-4	Starter Motor	Honeywell
48364-1-5	Starter Motor	Honeywell
48364-1-6	Starter Motor	Honeywell
48378-1-1	Motor Starter	Honeywell
48378-2-10	Motor Starter	Honeywell
48378-2-11	Motor Starter	Honeywell
48378-2-12	Motor Starter	Honeywell
48378-2-2	Motor Starter	Honeywell
48378-2-3	Motor Starter	Honeywell
48378-2-4	Motor Starter	Honeywell
48378-2-5	Motor Starter	Honeywell
48378-2-6	Motor Starter	Honeywell
48378-2-7	Motor Starter	Honeywell
48378-2-8	Motor Starter	Honeywell
48378-2-9	Motor Starter	Honeywell
48378-3-1	Motor Starter	Honeywell
48378-4-1	Motor Starter	Honeywell
484101-1	Latch ay	Goodrich
484MK1	Fuel Canister	Goodrich Control Systems
485000-12	Hydraulic Pulsation Dampener	Essex Industries
485000-3	Hydraulic Pulsation Dampener	Essex Industries
485000-4	Hydraulic Pulsation Dampener	Essex Industries
485000-5	Hydraulic Pulsation Dampener	Essex Industries
485000-9	Hydraulic Pulsation Dampener	Essex Industries
48-60V5	ADI	Thales Avionics
486-10D1-1-4	Check Valve	Teledyne
4863-221-80-00	Trim Indicator	Thales Avionics
4863-222-80-00	Trim Indicator	Thales Avionics
4863-223-80-00	Trim Indicator	Thales Avionics
4863-224-80-00	Trim Indicator	Thales Avionics
4863-226-80-00	Trim Indicator	Thales Avionics
4863-228-80-00	Trim Indicator	Thales Avionics
4863-229-80-00	Trim Indicator	Thales Avionics
4863-230-80-00	Trim Indicator	Thales Avionics
4863-231-80-00	Trim Indicator	Thales Avionics
4863-502-80-10	Trim Indicator	Thales Avionics
4863-503-80-10	Trim Indicator	Thales Avionics
4863-503-80-11	Trim Indicator	Thales Avionics
4863-504-80-11	Trim Indicator	Thales Avionics
486-6D1-1-4	Check Valve	Teledyne
488-10D1-1-4	Check Valve	Teledyne
488-12D1-1	Check Valve	Teledyne
488-16D1-1-4	Check Valve	Teledyne
488-32-6	Filling Cap Coupler	Shaw Aero Devices
488-4D1-1-4	Check Valve	Teledyne
488-4D1-15	Check Valve	Teledyne
488-4SS1-1-1-2	Check Valve	Teledyne
488-6D1-1	Check Valve	Teledyne
488-8D1-1-4	Check Valve	Teledyne
49310-31	Cabin Pressure Indicator	Thales Avionics
49380	Probe Pitot	Thales Avionics
494814	Transformer	Oeco Corporation
494MK3	Srewjack	Goodrich Control Systems
494MK4	Srewjack	Goodrich Control Systems

Repair_Capability_List_Excel

4950029	Starter Motor	Hamilton Sundstrand
4950037	Fuel Pump assy	Hamilton Sundstrand
4950250	Fuel Pump	Hamilton Sundstrand
4950251	Fuel Pump assy	Hamilton Sundstrand
4950491	Anti-Surge Valve	Hamilton Sundstrand
4950552	Fuel Pump assy	Hamilton Sundstrand
4950745	Ignition Exciter	Hamilton Sundstrand
4950760	Oil Temperature Sensor	Hamilton Sundstrand
4950795	Anti-Surge Valve assy	Hamilton Sundstrand
4950899	Anti-Surge Valve assy	Hamilton Sundstrand
4950929	Air/Oil Cooler assy	Hamilton Sundstrand
4950958	Bleed Air Valve	Hamilton Sundstrand
4951026	Fuel Pump assy	Hamilton Sundstrand
4951030	Oil Cooler assy	Hamilton Sundstrand
4951090	Bleed Air Valve	Hamilton Sundstrand
4951304	Fuel Pump assy	Hamilton Sundstrand
4951339	Fuel Pump	Hamilton Sundstrand
4951431	Flow Divider	Hamilton Sundstrand
4951486	Flow Divider	Hamilton Sundstrand
4951513	Oil Fill Tube assy	Hamilton Sundstrand
4951680	Servo Controlled Bleed Air Valve	Hamilton Sundstrand
4951690-1	Thermocouple	Hamilton Sundstrand
4951690-2	Thermocouple	Hamilton Sundstrand
4951693-1	Igniter Cable assy	Hamilton Sundstrand
4951693-2	Igniter Cable assy	Hamilton Sundstrand
4951694	Dual Coil Speed Sensor	Hamilton Sundstrand
4951695	Dual Oil Pressure Sensor	Hamilton Sundstrand
4951700	Oil Cooler assy	Hamilton Sundstrand
4951701	Anti-Surge Valve assy	Hamilton Sundstrand
4951707	Primary Fuel Manifold assy	Hamilton Sundstrand
4951708	Secondary Fuel Manifold assy	Hamilton Sundstrand
4951714	Ignition Exciter	Hamilton Sundstrand
4951799	Starter Motor	Hamilton Sundstrand
4951948	Simplex Fuel Injector	Hamilton Sundstrand
4951949	Duplex Fuel Injector	Hamilton Sundstrand
4951957	Starter Motor	Hamilton Sundstrand
4952304	Servo Controlled Bleed Air Valve	Hamilton Sundstrand
4952361	Bleed Air Valve	Hamilton Sundstrand
4952370	Permanent Magnet Starter Stator ay	Hamilton Sundstrand
4952375	Servo Controlled Bleed Air Valve	Hamilton Sundstrand
49540-02	Static Probe	Thales Avionics
495MK8	Tail Trim Actuator	Goodrich Control Systems
49B16	Temperature Indicator	Honeywell
49B3	Temperature Indicator	Honeywell
4A136-81	Actuator	Allen Aircraft
4E3133-1	Controller	Goodrich
4L83-046	Valve	Intertechnique
4L95-132	Safety Disk	Intertechnique
4L95-160	Safety Disk	Intertechnique
500012-01	INS Battery	Saft
5000268-1	MLG Brake Unit	ABS
5000268-2	MLG Brake Unit	ABS
5000268-3	MLG Brake Unit	ABS
5000268-5	MLG Brake Unit	ABS
5000A	Outlet Shaver	ECE
500-1-04118-001	Fuel Trim Actuator	Plessey
50-0122-1	Take-Off & Taxi Light assy	Grimes Aerospace
50-0122-5	Take-Off & Taxi Light assy	Grimes Aerospace

Repair_Capability_List_Excel

500210009	VOR Controller	Airbus Industrie
500-2100-009	VOR/DME Control Unit	Thales Avionics
5002343	Shut-Off Valve	Fokker
50-0291-1	Taxi & Landing Light	Grimes Aerospace
5003086	MLG Brake Unit	ABS
5003086-1	MLG Brake Unit	ABS
5003086-2	MLG Brake Unit	ABS
5004069	Wheel assy	Goodyear International Corp
5004070	MLG Brake assy	ABS
5004070-1	MLG Brake assy	ABS
5004070-2	MLG Brake assy	ABS
50044-501	Folding Retainer	Pemco Engineers
5005786	Stator	Abex
5006002	Main Fuel Boost Pump	Hamilton Sundstrand
5006003B	Pumping Unit assy	Hamilton Sundstrand
5006003C	Pumping Unit assy	Hamilton Sundstrand
5006005	Housing Unit assy	Hamilton Sundstrand
5006005A	Housing Unit assy	Hamilton Sundstrand
5006005B	Housing Unit assy	Hamilton Sundstrand
5006005C	Housing Unit assy	Hamilton Sundstrand
5006150	Discharge Check Valve assy	Hamilton Sundstrand
5006150A	Discharge Check Valve assy	Hamilton Sundstrand
5006151	Motive Flow & Screen Valve assy	Hamilton Sundstrand
5006151A	Motive Flow & Screen Valve assy	Hamilton Sundstrand
5006283	Override Fuel Boost Pump	Hamilton Sundstrand
5006284	Housing Unit assy	Hamilton Sundstrand
5006286	Pumping Unit assy	Hamilton Sundstrand
5006286A	Pumping Unit assy	Hamilton Sundstrand
5006286B	Pumping Unit assy	Hamilton Sundstrand
5006286C	Pumping Unit assy	Hamilton Sundstrand
5006286D	Pumping Unit assy	Hamilton Sundstrand
5006286E	Pumping Unit assy	Hamilton Sundstrand
5006286F	Pumping Unit assy	Hamilton Sundstrand
5006348	Motive Flow & Screen Valve assy	Hamilton Sundstrand
5006349	Discharge Check Valve assy	Hamilton Sundstrand
5006397	Geared Rotary Actuator	Hamilton Sundstrand
5006397-H	Geared Rotary Actuator	Hamilton Sundstrand
5006397J	Geared Rotary Actuator	Hamilton Sundstrand
5006397-J	Geared Rotary Actuator	Hamilton Sundstrand
5006397K	Geared Rotary Actuator	Hamilton Sundstrand
5006397-K	Geared Rotary Actuator	Hamilton Sundstrand
5006397L	Geared Rotary Actuator	Hamilton Sundstrand
5006397-L	Geared Rotary Actuator	Hamilton Sundstrand
5006397M	Geared Rotary Actuator	Hamilton Sundstrand
5006397-M	Geared Rotary Actuator	Hamilton Sundstrand
5006397N	Geared Rotary Actuator	Hamilton Sundstrand
5006397P	Geared Rotary Actuator	Hamilton Sundstrand
5006397R	Geared Rotary Actuator	Hamilton Sundstrand
5006398	Geared Rotary Actuator	Hamilton Sundstrand
5006398-F	Geared Rotary Actuator	Hamilton Sundstrand
5006398-G	Geared Rotary Actuator	Hamilton Sundstrand
5006398H	Geared Rotary Actuator	Hamilton Sundstrand
5006398-H	Geared Rotary Actuator	Hamilton Sundstrand
5006398J	Geared Rotary Actuator	Hamilton Sundstrand
5006398-J	Geared Rotary Actuator	Hamilton Sundstrand
5006398K	Geared Rotary Actuator	Hamilton Sundstrand
5006398-K	Geared Rotary Actuator	Hamilton Sundstrand
5006398L	Geared Rotary Actuator	Hamilton Sundstrand

Repair_Capability_List_Excel

5006398M	Geared Rotary Actuator	Hamilton Sundstrand
5006398N	Geared Rotary Actuator	Hamilton Sundstrand
5006834D	Fuel Gear Pump assy	Hamilton Sundstrand
5006834E	Fuel Gear Pump assy	Hamilton Sundstrand
5006834F	Fuel Gear Pump assy	Hamilton Sundstrand
5006834G	Fuel Gear Pump assy	Hamilton Sundstrand
5006834H	Fuel Gear Pump assy	Hamilton Sundstrand
5006834J	Fuel Gear Pump assy	Hamilton Sundstrand
5006834K	Fuel Gear Pump assy	Hamilton Sundstrand
5006834L	Fuel Gear Pump assy	Hamilton Sundstrand
5006834M	Fuel Gear Pump assy	Hamilton Sundstrand
500702-4620	Mixed Flow Fan	Hamilton Sundstrand
500702-5211	Fan	Hamilton Sundstrand
5007246A	Main Fuel Pump	Hamilton Sundstrand
5007246B	Main Fuel Pump	Hamilton Sundstrand
5007436	Lubrication & Scavenge Oil Pump	Hamilton Sundstrand
5007436A	Lubrication & Scavenge Oil Pump	Hamilton Sundstrand
5007436B	Lubrication & Scavenge Oil Pump	Hamilton Sundstrand
5007436C	Lubrication & Scavenge Oil Pump	Hamilton Sundstrand
5007996-1	MLG Brake Unit	ABS
5008367	Shuttle Valve	ABS
5008367-1	Shuttle Valve	ABS
5008437	Lubrication & Scavenge Oil Pump	Hamilton Sundstrand
5008589	Fan assy	Technofan
5008589-1	Fan assy	Technofan
5008589-2	Fan assy	Technofan
5008589-3	Fan assy	Technofan
5008589-3R1	Fan assy	Technofan
5008589-3R2	Fan assy	Technofan
5008589-3R3	Fan assy	Technofan
5008589R	Fan assy	Technofan
50086-003	Circuit Breaker	Lear Siegler
5008735D	LP/HP Fuel Pump	Hamilton Sundstrand
5008735E	LP/HP Fuel Pump	Hamilton Sundstrand
5008735F	LP/HP Fuel Pump	Hamilton Sundstrand
50090	Actuator	Triumph Accessories
50090-1	Actuator	Triumph Accessories
5009656	Override Jettison Pump	Hamilton Sundstrand
5009726	Discharge Check Valve assy	Hamilton Sundstrand
5009740	Override Jettison Pump	Hamilton Sundstrand
5009776D	Fuel Gear Pump assy	Hamilton Sundstrand
5009776E	Fuel Gear Pump assy	Hamilton Sundstrand
5009776F	Fuel Gear Pump assy	Hamilton Sundstrand
5009776G	Fuel Gear Pump assy	Hamilton Sundstrand
5009913B	Fuel Pump	Hamilton Standard
5009913C	Fuel Pump	Hamilton Standard
5009913D	Fuel Pump	Hamilton Standard
5009913E	Fuel Pump	Hamilton Standard
5009913F	Fuel Pump	Hamilton Standard
5009913G	Fuel Pump	Hamilton Standard
500A0000-01	Solenoid Valve	Goodrich Control Systems
500A0000-02	Solenoid Valve	Goodrich Control Systems
500A0000-03	Solenoid Valve	Goodrich Control Systems
5010216C	LP/HP Fuel Pump	Hamilton Sundstrand
5010216D	LP/HP Fuel Pump	Hamilton Sundstrand
5010216E	LP/HP Fuel Pump	Hamilton Sundstrand
5010216G	LP/HP Fuel Pump	Hamilton Sundstrand
5010220-2	Brake Assy	ABS

Repair_Capability_List_Excel

5010224	Main Fuel Pump	Hamilton Sundstrand
5010224A	Main Fuel Pump	Hamilton Sundstrand
5010320	Cooling Fan	ABSC
5010320-1	Cooling Fan	ABSC
5010321	Weel Tire Pressure	ABS
5010330	Brake Assy	ABS
5010406	Motor Fan Axle Kit	Technofan
501-1568-38	Attitude Indicator	Goodrich
5011705	Body Fan Axle Kit	Technofan
501-1770-03	Stick Pusher Actuator	Thales Avionics
501-1770-04	Stick Pusher Actuator	Thales Avionics
501-1771-02	Stick Pusher Capstan	Thales Avionics
501-1771-04	Stick Pusher Capstan	Thales Avionics
501240-1	Ignition Exciter	Unison
50-1-3100-00	Pressure Switch	Elektro Metall Exp.
5018-753-00-00	Audio Mixing Amplifier	Thales Avionics
501MK3	Screwjack	Goodrich Control Systems
502042	Compressor Bleed Valve	Pratt & Whitney
50-2-3100-00	Switch Pressure	Elektro Metall Exp.
50-2-3110-00	Pressure Switch	Elektro Metall Exp.
502MK3	Screwjack	Goodrich Control Systems
502MK4	Screwjack	Goodrich Control Systems
50354	Surge Valve	Textron
50356	Surge Valve	Textron
50360	Surge Valve	Textron
5039-200	Rain Repellent Gage	Intertechnique
503CA02F1	Contactora	ECE
503CA02F102Y1	Contactora	ECE
503CA02F1-02Y1	Contactora	ECE
503MK3	Screwjack	Goodrich Control Systems
504-0016-902	Directional Gyro	AIM Aviation
504MK5	Rudder Feel Simulator	Goodrich Control Systems
504MK6	Rudder Feel Simulator	Goodrich Control Systems
504MK7	Rudder Feel Simulator	Goodrich Control Systems
5050243-9	Flight Mode Annunciator	Honeywell
5053000	Pressure Switch	Elektro Metall Exp.
505MK5	Elevator Feel Simulator	Goodrich Control Systems
506	Volt/Amp Meter	Weston Aerospace
506001-27-0	Pressure Switch	Bristol Babcock
506001-28-8	Pressure Switch	Bristol Babcock
506002-27-6	Pressure Switch	Bristol Babcock
5060D100-15	Boost Pump Electric Motor	Eaton
5060D100-7	Boost Pump Electric Motor	Eaton
5060D100-9	Boost Pump Electric Motor	Eaton
50620	Pitot Probe	Thales Avionics
50620-10	Pitot Probe	Thales Avionics
50648	Transmitter assy	Rogerson
50648-1	Transmitter assy	Rogerson
50648-23	Transmitter assy	Rogerson
50648-27	Transmitter assy	Rogerson
50-6875	Flap Valve	Boeing
50-6875-1	Valve	Boeing
5068D100-3	E-M Rotary Actuator	Eaton
5068D100-5	E-M Rotary Actuator	Eaton
5068D100-7	E-M Rotary Actuator	Eaton
5076D100-11	RAT Electric Motor	Eaton
5076D100-17	RAT Electric Motor	Eaton
5076D100-5	RAT Electric Motor	Eaton

Repair_Capability_List_Excel

5076D100-7	RAT Electric Motor	Eaton
5076D100-9	RAT Electric Motor	Eaton
50-7945-1	Forward Entry Door	Boeing
50-7945-105	Forward Entry Door	Boeing
50-7945-114	Forward Entry Door	Boeing
50-7945-119	Forward Entry Door	Boeing
50-7945-125	Forward Entry Door	Boeing
50-7945-150	Forward Entry Door	Boeing
50-7945-151	Forward Entry Door	Boeing
50-7945-152	Forward Entry Door	Boeing
50-7945-153	Forward Entry Door	Boeing
50-7945-155	Forward Entry Door	Boeing
50-7945-176	Forward Entry Door	Boeing
50-7945-177	Forward Entry Door	Boeing
50-7945-178	Forward Entry Door	Boeing
50-7945-194	Forward Entry Door	Boeing
50-7945-195	Forward Entry Door	Boeing
50-7945-196	Forward Entry Door	Boeing
50-7945-197	Forward Entry Door	Boeing
50-7945-264	Forward Entry Door	Boeing
50-7945-272	Forward Entry Door	Boeing
50-7945-299	Forward Entry Door	Boeing
50-7945-88	Forward Entry Door	Boeing
50-7945-90	Forward Entry Door	Boeing
50-7945-93	Forward Entry Door	Boeing
50-7945-95	Forward Entry Door	Boeing
50-7978-113	Emergency Hatch	Boeing
50-7978-128	Emergency Hatch	Boeing
50-7978-129	Emergency Hatch	Boeing
50-7978-145	Emergency Hatch	Boeing
50-7978-146	Emergency Hatch	Boeing
50-7978-175	Emergency Hatch	Boeing
50-7978-178	Emergency Hatch	Boeing
50-7978-180	Emergency Hatch	Boeing
50-7978-33	Emergency Hatch	Boeing
50-7978-46	Emergency Hatch	Boeing
50-7978-90	Emergency Hatch	Boeing
50-7978-92	Emergency Hatch	Boeing
50-7978-97	Emergency Hatch	Boeing
50-8725-4	Valve	Boeing
50-8725-5	Valve	Boeing
51010-1109	Cabin Altitude Indicator	Aerosonic
51085	Pump	Abex
510ZN01	Sensor	ECE
511A0000-02	Slat Control Unit	Goodrich Control Systems
511A0000-03	Slat Control Unit	Goodrich Control Systems
511A0000-04	Slat Control Unit	Goodrich Control Systems
511A0000-05	Slat Control Unit	Goodrich Control Systems
511A0000-06	Slat Control Unit	Goodrich Control Systems
511A0000-07	Slat Control Unit	Goodrich Control Systems
511A0100-01	Pressure-Off Brake	Goodrich Control Systems
511A0100-02	Pressure-Off Brake	Goodrich Control Systems
511A0100-03	Pressure-Off Brake	Goodrich Control Systems
51200-11	Multifunction Spoiler Power Control Unit	Thales Avionics
5126-220-80-11	Fuel Temperature Indicator	Thales Avionics
5126-223-80-11	Fuel Temperature Indicator	Thales Avionics
512A0000-2	Block Valve	Goodrich Control Systems
512A0000-3	Block Valve	Goodrich Control Systems

Repair_Capability_List_Excel

512A0000-4	Block Valve	Goodrich Control Systems
513CA01C1-02Y1	Contactora	ECE
513CA02F1-02Y1	Three Pole Contactora	ECE
51400-1	Ground Spoiler Actuator	Thales Avionics
5147-211-400	Cockpit Heater	Fokker Aircraft
5147-211-401	Cockpit Heater	Fokker Aircraft
5147-211-901	Cockpit Heater	Fokker Aircraft
514A0000-2	Block Valve	Goodrich Control Systems
514A0000-3	Block Valve	Goodrich Control Systems
514A0000-4	Block Valve	Goodrich Control Systems
514B0000-01	Block Valve	Goodrich Control Systems
515A0000-02	Tee Gearbox	Liebherr Aerotechnik
515A0000-03	Tee Gearbox	Goodrich Control Systems
51600-9	Ground Spoiler Selector Valve	Thales Avionics
516023-1	Alternating Current Motor	Honeywell
516023-2	Alternating Current Motor	Honeywell
516029-2-1	Alternating Current Motor	Honeywell
516038-1	Alternative Current Motor	Honeywell
516038-2	Alternative Current Motor	Honeywell
516038-3	Alternative Current Motor	Honeywell
516038-4	Alternative Current Motor	Honeywell
51653-027	Fire Detection Controller	Kidde Aeospace
516538-3	Motor assy	Honeywell
516538-4	Motor assy	Honeywell
516A0000-02	Torque Limiter	Goodrich Control Systems
516MK5	Screwjack	Goodrich Control Systems
516MK6	Screwjack	Goodrich Control Systems
5179-323-401	Asymmetry Amplifier	Fokker Aircraft
5179-323-405	Asymmetry Amplifier	Fokker Aircraft
5179-323-901	Asymmetry Amplifier	Fokker Aircraft
517A0000-02	Wing Root Gearbox	Goodrich Control Systems
517A0000-03	Wing Root Gearbox	Goodrich Control Systems
517MK6	Screwjack	Goodrich Control Systems
517MK7	Screwjack	Goodrich Control Systems
517MK8	Screwjack	Goodrich Control Systems
517MK9	Screwjack	Goodrich Control Systems
518150	Motor assy	Vickers
518157	Motor assy	Vickers
518203	Hydraulic Pump	Vickers
518210-5	FUEL/OIL EXCHANGERS	GARRET AIRESEARCH
518210-6	FUEL/OIL EXCHANGERS	GARRET AIRESEARCH
518210-7	FUEL/OIL EXCHANGERS	GARRET AIRESEARCH
518210-8	FUEL/OIL EXCHANGERS	GARRET AIRESEARCH
518-28007-205	Encoding Altimeter	Kollsman
518-28007-207	Encoding Altimeter	Kollsman
518735	Hydraulic Motor Pump	Vickers
518A0000-02	Slat Screwjack	Liebherr Aerotechnik
518A5001-01	BALL ASSY	LIEBHERR
518B0000-01	Slat Screwjack	Liebherr Aerotechnik
518B0000-02	Slat Screwjack	Liebherr Aerotechnik
518B0000-03	Screwjack	Goodrich Control Systems
518C0000-01	Slat Screwjack	Liebherr Aerotechnik
519022-3	Motor	Honeywell
519022-4	Motor	Honeywell
519022-5	Motor	Honeywell
519022-6	Motor	Honeywell
519022-7	Motor	Honeywell
519022-8	Motor	Honeywell

Repair_Capability_List_Excel

519802-2	Starter Motor	Honeywell
519802-3	Starter Motor	Honeywell
519802-4	Starter Motor	Honeywell
519802-5	Starter Motor	Honeywell
519802-6	Starter Motor	Honeywell
519804-10	Starter Motor	Honeywell
519804-5	Starter Motor	Honeywell
519804-6	Starter Motor	Honeywell
519804-7	Starter Motor	Honeywell
519804-8	Starter Motor	Honeywell
519804-9	Starter Motor	Honeywell
519806-1	Starter Motor	Honeywell
519806-2	Starter Motor	Honeywell
519806-3	Starter Motor	Honeywell
519852-2	Starter Motor	Honeywell
519852-3	Starter Motor	Honeywell
519852-4	Starter Motor	Honeywell
519858-1	Starter Motor	Honeywell
519858-2	Starter Motor	Honeywell
519858-3	Starter Motor	Honeywell
519858-4	Starter Motor	Honeywell
519858-5	Starter Motor	Honeywell
519858-6	Starter Motor	Honeywell
519858-7	Starter Motor	Honeywell
519858-8	Starter Motor	Honeywell
519A0000-02	Line Gearbox	Goodrich Control Systems
519A0000-03	Line Gearbox	Liebherr Aerotechnik
51B2411	Voltmeter	A.I.D.
51B2620	Frequency Meter	A.I.D.
51U711	Differential Pressure Switch	Pratt & Whitney
520109	Volt/Amperemeter	Weston
520136	Volt/Amperemeter	Weston
520249	Volt/Amperemeter	Weston
520-3337-213	Radio Magnetic Indicator	Poly Scientific
520415	AC Volts Indicator	Ametek
520416	Compt Duct Inlet Temperature	Ametek
520418	Temperature Indicator	Weston Instruments
520420	Pneumatic Temperature	Ametek
520423	DC Loadmeter Indicator	Ametek
520424	AC Load Meter	Ametek
520445	Engine Vibration Monitor Indic.	Ametek
520479	Volt/Amperemeter	Weston
5205	Door Lock	SIREN
520525	Crew Oxygen Pressure Indicator	Ametek
520550	Hydraulic Pump	Vickers
520575	Fuel Temperature Indicator	Ametek
520576	Oil Temperature Indicator	Ametek
520577	Oil Temperature Indicator	Ametek
520579	Temperature Indicator	Weston Instruments
520580	APU N1 Tachometer Indicator	Ametek
520587	Temperature Indicator	Weston Instruments
520642	Surface Position Indicator	Ametek
520690	Ram Air Indicator	Ametek
520759	Mach Indicator	Ametek
520768	APU N2 Tachometer Indicator	Ametek
520805	Hydraulic Motor	Vickers
520831	AC Driven Motorpump assy	Vickers
520898	Ambient & Inlet Cabin Indicator	Weston Instruments

Repair_Capability_List_Excel

520912	Constant Speed Generator	Vickers
520913	Constant Speed Generator	Vickers
520915	Generator Control Unit	Vickers
520973	APU N1 Tachometer	Ametek
520974	APU N1 Tachometer	Ametek
520A0000-04	Brake Wing Tip	Liebherr Aerotechnik
520A0000-05	Brake Wing Tip	Liebherr Aerotechnik
520A0000-06	Brake Wing Tip	Liebherr Aerotechnik
520A0000-07	Brake Wing Tip	Liebherr Aerotechnik
520A0000-08	Brake Wing Tip	Liebherr Aerotechnik
521141	APU EGT Indicator	Ametek
521142	Tachometer Indicator	Ametek
521143	APU N2 Tachometer Indicator	Ametek
521159	APU EGT Indicator	Ametek
521192	Nacelle Temperature Indicator	Weston Instruments
521198	Fuel Temperature Indicator	Ametek
521199	Fuel Temperature Indicator	Ametek
521200	Engine Oil Temperature	Ametek
521201	Oil Temperature Indicator	Ametek
521203	Temperature Indicator	Weston Instruments
521204	Temperature Indicator	Weston Instruments
521205	Pneumatic Temperature Indicator	Ametek
521206	Temperature Indicator	Weston Instruments
521237	APU Shaft Speed Indicator	Ametek
521241	APU Turbine Gas Indicator	Ametek
521248	Hydraulic Temperature Indicator	Ametek
521249	Hydraulic Temperature Indicator	Ametek
521271	Temperature Indicator	Weston Aerospace
521285	APU EGT Indicator	Ametek
521286	APU N1 Tachometer	Ametek
521287	APU N2 Tachometer	Ametek
521301	Hydraulic Oil Qty Indicator	Ametek
521303	A/C Pack Outlet Indicator	Ametek
521349	AC Frequency Meter	Ametek
521424	Hydraulic Motor	Vickers
521469	APU EGT Indicator	Ametek
521470	APU N2 Tachometer	Ametek
521471	APU N1 Tachometer	Ametek
521530	DC Volt Ammeter Indicator	Ametek
521537	Nacelle Temperature Indicator	Ametek
521602	AC Frequency Indicator	Ametek
521873	AC Ammeter	Weston
521894	Frequency Meter	Weston
521914	Voltmeter	Weston
521916	Fuel Temperature Indicator	Ametek
521918	Fuel Temperature Indicator	Ametek
521A0000-01	Detection Unit	Liebherr Aerotechnik
521A0100-01	Shaft Assembly	Liebherr Aerotechnik
521A0200-01	Adapter ay PPU	Liebherr Aerotechnik
522-1261-00	HF Communication Control Panel	Rockwell-Collins
522168	Mach Feel Indicator	Ametek
522-1836-00	ADF Receiver	Rockwell-Collins
522-1836-013	ADF Receiver	Rockwell-Collins
522211	Cabin Air Supply Temp.Indic.	Ametek
522213	Cabin Air Supply Temp.Indic.	Ametek
522215	Pressure Indicator	Ametek
522-2213-00	HF Communication Control Panel	Rockwell-Collins
522-2213-011	HF Communication Control Panel	Rockwell-Collins

Repair_Capability_List_Excel

522-2213-049	HF Communication Control Panel	Rockwell-Collins
522-2357-000	ADF Control Unit	Rockwell-Collins
522-2357-011	ADF Control Unit	Rockwell-Collins
522-2357-012	ADF Control Unit	Rockwell-Collins
522-2357-013	ADF Control Unit	Rockwell-Collins
522-2357-014	ADF Control Unit	Rockwell-Collins
522-2357-015	ADF Control Unit	Rockwell-Collins
522-2357-016	ADF Control Unit	Rockwell-Collins
522-2357-017	ADF Control Unit	Rockwell-Collins
522-2357-018	ADF Control Unit	Rockwell-Collins
522-2357-019	ADF Control Unit	Rockwell-Collins
522-2357-021	ADF Control Unit	Rockwell-Collins
522-2357-022	ADF Control Unit	Rockwell-Collins
522-2357-024	ADF Control Unit	Rockwell-Collins
522-2357-026	ADF Control Unit	Rockwell-Collins
522-2357-028	ADF Control Unit	Rockwell-Collins
522-2357-031	ADF Control Unit	Rockwell-Collins
522-2357-032	ADF Control Unit	Rockwell-Collins
522-2357-035	ADF Control Unit	Rockwell-Collins
522-2357-036	ADF Control Unit	Rockwell-Collins
522-2357-037	ADF Control Unit	Rockwell-Collins
522-2357-038	ADF Control Unit	Rockwell-Collins
522-2357-039	ADF Control Unit	Rockwell-Collins
522-2447-005	Nav Comm Control Panel	Rockwell-Collins
522-2447-015	Nav Comm Control Panel	Rockwell-Collins
522-2447-050	Nav Comm Control Panel	Rockwell-Collins
522-2447-205	Nav Comm Control Panel	Rockwell-Collins
522-2447-215	Nav Comm Control Panel	Rockwell-Collins
522-2447-225	Nav Comm Control Panel	Rockwell-Collins
522-2447-250	Nav Comm Control Panel	Rockwell-Collins
522-2447-256	Nav Comm Control Panel	Rockwell-Collins
522-2447-257	Nav Comm Control Panel	Rockwell-Collins
522-2447-260	Nav Comm Control Panel	Rockwell-Collins
522-2448-005	Nav Comm Control Panel	Rockwell-Collins
522-2448-015	Nav Comm Control Panel	Rockwell-Collins
522-2448-025	Nav Comm Control Panel	Rockwell-Collins
522-2448-035	Nav Comm Control Panel	Rockwell-Collins
522-2448-045	Nav Comm Control Panel	Rockwell-Collins
522-2448-055	Nav Comm Control Panel	Rockwell-Collins
522-2448-245	Nav Comm Control Panel	Rockwell-Collins
522-2448-255	Nav Comm Control Panel	Rockwell-Collins
522-2448-267	Nav Comm Control Panel	Rockwell-Collins
522-2450-000	VOR/ILS Receiver	Rockwell-Collins
522-2450-011	VOR/ILS Receiver	Rockwell-Collins
522-2450-012	VOR/ILS Receiver	Rockwell-Collins
522-2450-014	VOR/ILS Receiver	Rockwell-Collins
522-2450-015	VOR/ILS Receiver	Rockwell-Collins
522-2450-016	VOR/ILS Receiver	Rockwell-Collins
522-2450-020	VOR/ILS Receiver	Rockwell-Collins
522-2450-114	VOR/ILS Receiver	Rockwell-Collins
522-2450-115	VOR/ILS Receiver	Rockwell-Collins
522-2450-116	VOR/ILS Receiver	Rockwell-Collins
522-2450-120	VOR/ILS Receiver	Rockwell-Collins
522-2457-00	HF Communication Control Panel	Rockwell-Collins
522-2457-030	HF Communication Control Panel	Rockwell-Collins
522-2457-031	HF Communication Control Panel	Rockwell-Collins
522-2457-036	HF Control Unit	Rockwell-Collins
522-2457-037	HF Control Unit	Rockwell-Collins

Repair_Capability_List_Excel

522-2457-040	HF Control Unit	Rockwell-Collins
522-2466-004	VHF Comm Transceiver	Rockwell-Collins
522-2587-00	ADF Receiver	Rockwell-Collins
522-2587-013	ADF Receiver	Rockwell-Collins
522-2587-015	ADF Receiver	Rockwell-Collins
522-2615-005	Fixed Loop Antenna	Rockwell Collins
522-2638-000	Course Indicator	Rockwell-Collins
522-2638-001	Course Indicator	Rockwell-Collins
522-2638-002	Course Indicator	Rockwell-Collins
522-2638-003	Course Indicator	Rockwell-Collins
522-2638-004	Course Indicator	Rockwell-Collins
522-2638-005	Course Indicator	Rockwell-Collins
522-2638-006	Course Indicator	Rockwell-Collins
522-2638-007	Course Indicator	Rockwell-Collins
522-2638-008	Course Indicator	Rockwell-Collins
522-2644-011	Slaving Accessory	Rockwell-Collins
522-2703-000	ATC Transponder	Rockwell-Collins
522-2703-012	ATC Transponder	Rockwell-Collins
522-2703-013	ATC Transponder	Rockwell-Collins
522-2754-004	VHF Comm Transceiver	Rockwell-Collins
522-2775-011	VOR/LOC Navigation Unit	Collins
522-2775-012	VOR/LOC Navigation Unit	Collins
522-2775-013	VOR/LOC Navigation Unit	Collins
522-2775-019	VOR/LOC Navigation Unit	Collins
522-2775-100	VOR/LOC Navigation Unit	Collins
522-2775-111	VOR/LOC Navigation Unit	Collins
522-2775-112	VOR/LOC Navigation Unit	Collins
522-2775-114	VOR/LOC Navigation Unit	Collins
522-2775-119	VOR/LOC Navigation Unit	Collins
522-2782-004	Course Indicator	Collins
522-2782-034	Course Indicator	Rockwell-Collins
522-2996-000	Marker Beacon Receiver	Rockwell-Collins
522-2996-011	Marker Beacon Receiver	Rockwell-Collins
522-2996-012	Marker Beacon Receiver	Rockwell-Collins
522-2996-013	Marker Beacon Receiver	Rockwell-Collins
522-2996-014	Marker Beacon Receiver	Rockwell-Collins
522-2996-015	Marker Beacon Receiver	Rockwell-Collins
522-2996-016	Marker Beacon Receiver	Rockwell-Collins
522-2996-017	Marker Beacon Receiver	Rockwell-Collins
522-2996-018	Marker Beacon Receiver	Rockwell-Collins
522-3120-004	Amplifier	Rockwell-Collins
522-3132-004	VHF Comm Transceiver	Rockwell-Collins
522-3206-005	Flight Director Indicator	Collins
522-3617-000	VHF Control Panel	Rockwell-Collins
522-3617-001	VHF Control Panel	Rockwell-Collins
522-3617-002	VHF Control Panel	Rockwell-Collins
522-3617-003	VHF Control Panel	Rockwell-Collins
522-4088-001	VHF Transceiver	Rockwell-Collins
522-4088-003	VHF Transceiver	Rockwell-Collins
522-4088-004	VHF Transceiver	Rockwell-Collins
522-4088-006	VHF Transceiver	Rockwell-Collins
522-4088-007	VHF Transceiver	Rockwell-Collins
522-4088-009	VHF Transceiver	Rockwell-Collins
522-4088-010	VHF Transceiver	Rockwell-Collins
522-4088-201	VHF Transceiver	Rockwell-Collins
522-4088-203	VHF Transceiver	Rockwell-Collins
522-4088-204	VHF Transceiver	Rockwell-Collins
522-4088-206	VHF Transceiver	Rockwell-Collins

Repair_Capability_List_Excel

522-4088-207	VHF Transceiver	Rockwell-Collins
522-4088-209	VHF Transceiver	Rockwell-Collins
522-4088-210	VHF Transceiver	Rockwell-Collins
522-4089-001	VHF Transceiver	Rockwell-Collins
522-4089-002	VHF Transceiver	Rockwell-Collins
522-4089-004	VHF Transceiver	Rockwell-Collins
522-4089-005	VHF Transceiver	Rockwell-Collins
522-4089-006	VHF Transceiver	Rockwell-Collins
522-4089-008	VHF Transceiver	Rockwell-Collins
522-4089-009	VHF Transceiver	Rockwell-Collins
522-4089-010	VHF Transceiver	Rockwell-Collins
522-4089-011	VHF Transceiver	Rockwell-Collins
522-4089-201	VHF Transceiver	Rockwell-Collins
522-4089-202	VHF Transceiver	Rockwell-Collins
522-4089-204	VHF Transceiver	Rockwell-Collins
522-4089-205	VHF Transceiver	Rockwell-Collins
522-4089-206	VHF Transceiver	Rockwell-Collins
522-4089-208	VHF Transceiver	Rockwell-Collins
522-4089-209	VHF Transceiver	Rockwell-Collins
522-4114-003	Radio Altitude Indicator	Rockwell-Collins
522-4114-006	Radio Altitude Indicator	Rockwell-Collins
522-4280-001	VOR/ILS Receiver	Rockwell-Collins
522-4280-002	VOR/ILS Receiver	Rockwell-Collins
522-4280-003	VOR/ILS Receiver	Rockwell-Collins
522-4280-004	VOR/ILS Receiver	Rockwell-Collins
522-4280-005	VOR/ILS Receiver	Rockwell-Collins
522-4280-006	VOR/ILS Receiver	Rockwell-Collins
522-4280-007	VOR/ILS Receiver	Rockwell-Collins
522-4280-008	VOR/ILS Receiver	Rockwell-Collins
522-4280-009	VOR/ILS Receiver	Rockwell-Collins
522-4280-101	VOR/ILS Receiver	Rockwell-Collins
522-4280-102	VOR/ILS Receiver	Rockwell-Collins
522-4280-104	VOR/ILS Receiver	Rockwell-Collins
522-4280-105	VOR/ILS Receiver	Rockwell-Collins
522-4280-106	VOR/ILS Receiver	Rockwell-Collins
522-4280-107	VOR/ILS Receiver	Rockwell-Collins
522-4280-108	VOR/ILS Receiver	Rockwell-Collins
522-4280-109	VOR/ILS Receiver	Rockwell-Collins
522-4280-110	VOR/ILS Receiver	Rockwell-Collins
522-4353-001	Amplifier	Rockwell-Collins
522-4430-005	Flight Direction Indicator	Rockwell-Collins
522-4538-002	Amplifier	Rockwell-Collins
522-4538-003	Amplifier	Rockwell-Collins
522-4538-004	Amplifier	Rockwell-Collins
522-4538-005	Amplifier	Rockwell-Collins
522-4654-001	Controller Altimeter	Rockwell-Collins
522-4798-001	Controller Altimeter	Rockwell-Collins
522-4798-003	Controller Altimeter	Rockwell-Collins
522-4825-001	Radio Altitude Indicator	Rockwell-Collins
522-4825-002	Radio-Altitude Indicator	Rockwell-Collins
522-4825-004	Radio-Altitude Indicator	Rockwell-Collins
522-4825-005	Radio-Altitude Indicator	Rockwell-Collins
522-4825-006	Radio-Altitude Indicator	Rockwell-Collins
522-4825-007	Radio-Altitude Indicator	Rockwell-Collins
522-4825-008	Radio-Altitude Indicator	Rockwell-Collins
522-4977-001	VOR/ILS Receiver	Rockwell-Collins
522649	Fuel Heater	Pratt & Whitney
5227	Locking assy	SIREN

Repair_Capability_List_Excel

522714	Water Qty Indicator (Gal)	Ametek
522719	Water Qty Indicator	Ametek
5228	Locking assy	SIREN
522829	Fuel Heater	Pratt & Whitney
5229	Handle assy	SIREN
522A0100-02	Shaft Assembly	Goodrich Control Systems
522A0100-03	Shaft Assembly	Goodrich Control Systems
522A0100-04	Shaft Assembly	Goodrich Control Systems
522A0200-02	Universal Joint	Goodrich Control Systems
522A0200-03	Universal Joint	Goodrich Control Systems
522A0500-01	Universal Joint	Goodrich Control Systems
522A0500-02	Universal Joint	Goodrich Control Systems
522A0500-03	Universal Joint	Goodrich Control Systems
522A0700-01	Shaft Assembly	Goodrich Control Systems
522A0700-02	Shaft Assembly	Goodrich Control Systems
522A0900-01	Universal Joint	Goodrich Control Systems
522A0900-02	Universal Joint	Goodrich Control Systems
522A0900-03	Universal Joint	Goodrich Control Systems
522A7100-01	Shaft Assembly	Goodrich Control Systems
522A7300-01	Shaft Assembly	Goodrich Control Systems
523156	Brake Pressure Indicator	Weston
523222	Engine Oil Pressure Indicator	Weston
523298	Oxygen Pressure Indicator	Ametek
523A0100-01	Universal Joint	Goodrich Control Systems
523A0100-02	Universal Joint	Goodrich Control Systems
523A0500-01	Universal Joint	Goodrich Control Systems
523A0500-02	Universal Joint	Goodrich Control Systems
523A1000-01	Shaft Assembly	Goodrich Control Systems
523A1000-02	Shaft Assembly	Goodrich Control Systems
523A1100-01	Universal Joint	Goodrich Control Systems
523A1100-02	Universal Joint	Goodrich Control Systems
523A1100-03	Universal Joint	Goodrich Control Systems
523A1100-04	Universal Joint	Goodrich Control Systems
523A1100-05	Universal Joint	Goodrich Control Systems
523A1400-01	Shaft Assembly	Goodrich Control Systems
523A1700-01	Shaft Assembly	Goodrich Control Systems
523A1700-02	Shaft Assembly	Goodrich Control Systems
523A1800-01	Shaft Assembly	Goodrich Control Systems
523A1800-02	Shaft Assembly	Goodrich Control Systems
523A1900-01	Shaft Assembly	Goodrich Control Systems
523A2000-01	Universal Joint	Goodrich Control Systems
523A2000-02	Universal Joint	Goodrich Control Systems
523A2000-03	Universal Joint	Goodrich Control Systems
523A2000-04	Universal Joint	Goodrich Control Systems
523A2000-05	Universal Joint	Goodrich Control Systems
523A2300-01	Shaft Assembly	Goodrich Control Systems
523A2300-02	Shaft Assembly	Goodrich Control Systems
523A2500-01	Shaft Assembly	Goodrich Control Systems
523A2600-01	Shaft Assembly	Goodrich Control Systems
523A2700-01	Shaft Assembly	Goodrich Control Systems
523A2700-02	Shaft Assembly	Goodrich Control Systems
523A2800-01	Shaft Assembly	Goodrich Control Systems
523A2800-02	Shaft Assembly	Goodrich Control Systems
523A2900-01	Shaft Assembly	Goodrich Control Systems
523A2900-02	Shaft Assembly	Goodrich Control Systems
523A3000-01	Shaft Assembly	Goodrich Control Systems
523A3000-02	Shaft Assembly	Goodrich Control Systems
523A3100-01	Shaft Assembly	Goodrich Control Systems

Repair_Capability_List_Excel

523A3100-02	Shaft Assembly	Goodrich Control Systems
523A3200-01	Shaft Assembly	Goodrich Control Systems
523A3200-02	Shaft Assembly	Goodrich Control Systems
523A3300-01	Shaft Assembly	Goodrich Control Systems
523A3300-02	Shaft Assembly	Goodrich Control Systems
523A3400-01	Shaft Assembly	Goodrich Control Systems
523A3400-02	Shaft Assembly	Goodrich Control Systems
523A3500-01	Shaft Assembly	Goodrich Control Systems
523A3500-02	Shaft Assembly	Goodrich Control Systems
523A3600-01	Shaft Assembly	Goodrich Control Systems
523A3600-02	Shaft Assembly	Goodrich Control Systems
523A3700-01	Shaft Assembly	Goodrich Control Systems
523A3700-02	Shaft Assembly	Goodrich Control Systems
523A4000-01	Universal Joint	Goodrich Control Systems
523A4100-01	Universal Joint	Goodrich Control Systems
523A7300-01	Shaft Assembly	Goodrich Control Systems
523A7400-01	Shaft Assembly	Goodrich Control Systems
523A7500-01	Shaft Assembly	Goodrich Control Systems
523A7800-01	Shaft Assembly	Goodrich Control Systems
523A7900-01	Shaft Assembly	Goodrich Control Systems
523A9100-01	Shaft Assembly	Goodrich Control Systems
523A9200-01	Shaft Assembly	Goodrich Control Systems
523A9500-01	Shaft Assembly	Goodrich Control Systems
523A9600-01	Shaft Assembly	Goodrich Control Systems
523A9700-01	Shaft Assembly	Goodrich Control Systems
523A9800-01	Shaft Assembly	Goodrich Control Systems
523A9900-01	Shaft Assembly	Goodrich Control Systems
524425	DC Ammeter	Ametek
524A0000-03	Screwjack	Liebherr Aerotechnik
524A5001	BALL ASSY	LIEBHERR
524A5001-01	Ballscrew assy	Liebherr Aerotechnik
524A5002-01	Ball Screw assy	Liebherr Aerospace
524B0000-01	Screwjack	Liebherr Aerotechnik
524B0000-03	Screwjack	Liebherr Aerotechnik
524C0000-01	Screwjack	Liebherr Aerotechnik
524C0000-03	Screwjack	Liebherr Aerotechnik
5250 L/R	Spinlock assy	I.S.E.
5250-102	Brake Temperature Sensor	Thales Avionics
5250-103	Brake Temperature Sensor	Thales Avionics
5250-104	Brake Temperature Sensor	Thales Avionics
5250-120	Brake Temperature Sensor	Thales Avionics
525068-2	Linear Actuator	Honeywell
525374	Rotary Actuator	Honeywell
525458	Electro-Mechanical Actuator	Allied Signal
525458-2	Electro-Mechanical Actuator	Allied Signal
525A0200-01	Shaft Assembly	Goodrich Control Systems
525A0200-02	Shaft Assembly	Goodrich Control Systems
525A0200-03	Shaft Assembly	Goodrich Control Systems
525A0300-01	Shaft Assembly	Goodrich Control Systems
525A0300-02	Shaft Assembly	Goodrich Control Systems
525A0300-03	Shaft Assembly	Goodrich Control Systems
525A0400-01	Universal Joint	Goodrich Control Systems
525A0400-02	Universal Joint	Goodrich Control Systems
525A0800-01	Universal Joint assy	Goodrich Control Systems
525A1200-01	Universal Joint assy	Goodrich Control Systems
525A1300-02	Shaft Assembly	Goodrich Control Systems
525A1300-03	Shaft Assembly	Goodrich Control Systems
525A1600-02	Shaft Assembly	Goodrich Control Systems

Repair_Capability_List_Excel

525CA01C1-02Y1	Contactors	ECE
5261-1	Audio Control Panel	Avtech
527-000001-181	Static Inverter	Douglas
527-000001-191	Static Inverter	Douglas
527-000001-51	Static Inverter	Douglas
527-000001-81	Static Inverter	Douglas
527-000001-91	Static Inverter	Douglas
528-20	Navigation Light	Air Precision
528210-11	FUEL/OIL EXCHANGERS	GARRET AIRESEARCH
528210-14	FUEL/OIL EXCHANGERS	GARRET AIRESEARCH
528210-16	FUEL/OIL EXCHANGERS	GARRET AIRESEARCH
528210-18	FUEL/OIL EXCHANGERS	GARRET AIRESEARCH
528-30	Navigation Light	Air Precision
528-70	Navigation Light	Air Precision
528-80	Navigation Light	Air Precision
5289-1	Control Panel	Avtech Corporation
530AL01	Power Supply Decoupling Unit	ECE
531B0000-02	Flap Control Unit	Goodrich Control Systems
531B0000-03	Flap Control Unit	Goodrich Control Systems
531B0000-04	Flap Control Unit	Goodrich Control Systems
531B0000-05	Flap Control Unit	Goodrich Control Systems
531B0000-06	Flap Control Unit	Goodrich Control Systems
531B0000-07	Flap Control Unit	Goodrich Control Systems
532A0000-02	Torque Limiter	Goodrich Control Systems
532A0000-03	Torque Limiter	Goodrich Control Systems
532A0000-04	Torque Limiter	Goodrich Control Systems
533A0000-02	Angle Gearbox	Goodrich Control Systems
533A0000-03	Angle Gearbox	Goodrich Control Systems
534096	Oil Cooler	Pratt & Whitney
5346-210-8	Temperature Indicator	Thales Avionics
5346-220-80-10	Cabin/Duct Temperature Indicator	Thales Avionics
5347-700-80-10	Dual Low Pressure Rotor Indicator	Thales Avionics
5348-200-80-10	Fuel Tank Temperature Indicator	Thales Avionics
5364-50A	Cockpit Door Lock	SIREN
5364A	Cockpit Door Lock	SIREN
53721-3	NLG Door Strut assy	Avibank
5372C070	Overtemperature Switch	Honeywell
537C0000-01	Flap Screwjack	Goodrich Control Systems
537C0000-02	Flap Screwjack	Goodrich Control Systems
537D0000-01	Flap Screwjack	Goodrich Control Systems
537E0000-01	Flap Screwjack	Goodrich Control Systems
537E0000-02	Flap Screwjack	Goodrich Control Systems
537E0000-03	Flap Screwjack	Goodrich Control Systems
537E0000-04	Flap Screwjack	Goodrich Control Systems
537G0000-01	Flap Screwjack	Goodrich Control Systems
537G0000-02	Flap Screwjack	Goodrich Control Systems
537G0000-03	Flap Screwjack	Goodrich Control Systems
537G0000-04	Flap Screwjack	Goodrich Control Systems
538304-4-2	Mach Trim Control	Honeywell
538A0100-02	Adapter	Goodrich Control Systems
538A0200-02	Adapter	Goodrich Control Systems
53942100021GC0A	Clogging Indicator	Sofrance
53942100021JC0A	Clogging Indicator	Sofrance
53942100021MC0A	Clogging Indicator	Sofrance
53942100021PC0A	Clogging Indicator	Sofrance
53942100021RC0A	Clogging Indicator	Sofrance
53942100021YC0A	Clogging Indicator	Sofrance
53943100021PC0A	Clogging Indicator	Sofrance

Repair_Capability_List_Excel

540-0712-1	Shut-Off Valve assy	Grimes Aerospace
540-0715-1	Engine Air Shut-Off Valve	Honeywell
540-0715-2	Engine Air Shut-Off Valve	Honeywell
54032-003	Ball Screw assy	Sabinaw
54032-004	Ball Screw assy	Sabinaw
54032-005	Ball Screw assy	Sabinaw
54032-006	Ball Screw assy	Sabinaw
540594-3	Rotary Electromechanical Actuator	Honeywell
540742-3	Actuator	Honeywell
540742-4-1	Actuator	Honeywell
54-079	Accumulator	Kenngo Magnaghi
540930-2-2	Mechanism	Honeywell
540930-3-1	Mechanism	Honeywell
540930-3-2	Mechanism	Honeywell
540930-3-3	Mechanism	Honeywell
541208-1	Electromechanical Linear Actuator	Honeywell
541208-2	Electromechanical Linear Actuator	Honeywell
541248-1	Rotary Actuator	Honeywell
541248-2-1	Rotary Actuator	Honeywell
541248-3	Rotary Actuator	Honeywell
541248-7	Rotary Actuator	Honeywell
541296-3-1	Rotary Electromechanical Actuator	Honeywell
541296-4-1	Rotary Electromechanical Actuator	Honeywell
541460-3-1	Actuator	Honeywell
541560	Rotary Actuator	Honeywell
541560-1-1	Rotary Actuator	Honeywell
541664-1-1	Rotary Actuator	Honeywell
541674-1-1	Linear Actuator	Honeywell
541674-3	Linear Actuator	Honeywell
541674-4	Linear Actuator	Honeywell
541674-5	Linear Actuator	Honeywell
541674-6	Linear Actuator	Honeywell
541736-2-1	Actuator	Honeywell
541740-1	Temp Control Actuator	Honeywell
541740-1-1	Rotary Actuator	Honeywell
541740-1-2	Rotary Actuator	Honeywell
541740-1-3	Rotary Actuator	Honeywell
541932-1-1	Rotary Actuator	Honeywell
541962-1-1	Rotary Electromechanical Actuator	Honeywell
541962-4	Rotary Actuator	Honeywell
541962-5	Rotary Actuator	Honeywell
541962-6	Rotary Actuator	Honeywell
5426-214-8	Indicator	Thales Avionics
5426-215-8	Indicator	Thales Avionics
54262168	Indicator	Brion Leroux
5426-216-8	Indicator	Thales Avionics
5426-406-00-10	Reservoir Filling Correction Indicator	Mors
5427-115-80-10	Hydraulic Pressure Indicator	Thales Avionics
5427-116-80-10	Dual Deicing Pressure Indicator	Thales Avionics
5427-218-80-10	Dual Fuel Temperature Indicator	Thales Avionics
5427-361-80-10	Dual Oil Temperature Indicator	Thales Avionics
5427-404-80-10	Compt/Duct Dual Indicator	Thales Avionics
5428-150-80-10	Park Brake Hyd. Press. Indicator	Thales Avionics
54-3301120-02	RAF Actuator	Liebherr
54392	Wiring Harness	Hamilton Sundstrand
544286-2-1	Elec-Mech. Actuator	Honeywell
544286-2-2	Elec-Mech. Actuator	Honeywell
544286-3-1	Elec-Mech. Actuator	Honeywell

Repair_Capability_List_Excel

544286-4	Elec-Mech. Actuator	Honeywell
544286-5	Elec-Mech. Actuator	Honeywell
544286-6	Elec-Mech. Actuator	Honeywell
544286-7	Elec-Mech. Actuator	Honeywell
544372-1-1	Rotary Actuator	Honeywell
544472-1-1	Actuator	Honeywell
544472-2-1	Actuator	Honeywell
544472-2-2	Actuator	Honeywell
544494-1-1	Actuator	Honeywell
544622-2	Elec-Mech. Actuator	Honeywell
544646-1	Rotary Actuator	Moog
544646-10	Rotary Actuator	Moog
544646-11	Rotary Actuator	Moog
544646-3	Rotary Actuator	Moog
544646-7	Rotary Actuator	Moog
544646-8	Rotary Actuator	Moog
544646-9	Rotary Actuator	Moog
544654-2	Rotary Actuator	Honeywell
544654-3	Rotary Actuator	Honeywell
544654-4	Rotary Actuator	Honeywell
544654-5	Rotary Actuator	Honeywell
544654-5-1	Rotary Actuator	Honeywell
544654-6	Rotary Actuator	Honeywell
544666-1	Brake Torque Limiting	Moog
544666-10	Brake Torque Limiting	Moog
544666-102-2	Brake Torque Limiting	Moog
544666-104-2	Brake Torque Limiting	Moog
544666-108-1	Brake Torque Limiting	Moog
544666-11	Brake Torque Limiting	Moog
544666-12	Brake Torque Limiting	Moog
544666-13	Brake Torque Limiting	Moog
544666-16	Brake Torque Limiting	Moog
544666-2	Brake Torque Limiting	Moog
544666-3	Brake Torque Limiting	Moog
544666-4	Brake Torque Limiting	Moog
544666-5	Brake Torque Limiting	Moog
544666-8	Brake Torque Limiting	Moog
544666-9	Brake Torque Limiting	Moog
54-472	MLG Axle Sleeve	BF Goodrich
54-477	CLG Axle Sleeve	BF Goodrich
54-480	NLG Axle Sleeve	BF Goodrich
544800-x	Main Deck Cargo PDU Actuator	Telair International
544820-1	Actuator	Honeywell
544820-2	Actuator	Honeywell
544822-1	Gearbox assy	Honeywell
544852-4	Rotary Actuator	Honeywell
544886-1	Rotary Actuator	Honeywell
544886-2	Rotary Actuator	Honeywell
544886-3	Rotary Actuator	Honeywell
544886-4	Rotary Actuator	Honeywell
544952-2	Rotary Actuator	Moog
544952-3	Rotary Actuator	Moog
544964-1	Rotary Actuator	Honeywell
54540400-01	Adapter	Liebherr Aerospace
545A0000-01	Detection Unit	Liebherr Aerotechnik
545A400-01	Adapter	Liebherr Aerotechnik
5467	Latch	SIREN
5467-1	Isolator	Barry Controls

Repair_Capability_List_Excel

5467-1SA1	Isolator	Barry Controls
5467-1SA2	Isolator	Barry Controls
5467-1SA3	Isolator	Barry Controls
5468	Electrical Release Strike	SIREN
5468A	Electrical Release Strike	SIREN
5470L	Lavatory Door Bolt Ay	SIREN
5470R	Lavatory Door Bolt Ay	SIREN
5472L	Lavatory Door Bolt Ay	SIREN
5472R	Lavatory Door Bolt Ay	SIREN
547C0000-01	Flap Screwjack	Goodrich Control Systems
547C0000-02	Flap Screwjack	Goodrich Control Systems
547C0000-03	Flap Screwjack	Goodrich Control Systems
547D0000-01	Flap Screwjack	Goodrich Control Systems
547E0000-01	Flap Screwjack	Goodrich Control Systems
547F0000-01	Flap Screwjack	Goodrich Control Systems
547F0000-02	Flap Screwjack	Goodrich Control Systems
547F0000-03	Flap Screwjack	Goodrich Control Systems
547G0000-01	Flap Screwjack	Goodrich Control Systems
547G0000-02	Flap Screwjack	Goodrich Control Systems
547G0000-03	Flap Screwjack	Goodrich Control Systems
547MK3	Screwjack	Goodrich Control Systems
547MK4	Screwjack	Goodrich Control Systems
548003	Oil Cooler	Pratt & Whitney
5480404-3	Temp Controller	Honeywell
548367-3	Temperature Control	Honeywell
548376-3	Controller	Honeywell
548376-3 S4	Temp Cont	Honeywell
548376-3 S5	Temp Cont	Honeywell
548376-4	Temperature Control	Honeywell
548376-4SER1	Temperature Control	Honeywell
548376-5	Temperature Control	Honeywell
548376-5SER1	Temperature Control	Honeywell
548376-6	Temperature Control	Honeywell
548376-6SER3	Temperature Control	Honeywell
548380-2	Temp Selector	Honeywell
548382-2	Temp Selector	Honeywell
548384-1	Anticipator Temp Sensor	Honeywell
548386-1	Anticipator Temp Sensor	Honeywell
548388-1	Anticipator Temp Sensor	Honeywell
548392-1	Anticipator Temp Sensor	Honeywell
548394-2	Temp Selector	Honeywell
548404-3	Temp Controller	Honeywell
548404-3-1	Temperature Control Box	Honeywell
548482-4-1	Temp Controller	Honeywell
548482-4-2	Temp Controller	Honeywell
548620-1	Thermostatic Switch	Honeywell
548620-2	Thermostatic Switch	Honeywell
548620-6	Thermostatic Switch	Honeywell
5487	Door Latch	I.S.E.
5487A	Cockpit Door Lock	SIREN
5487R	Cockpit Door Lock	SIREN
548C0000-01	Flap Screwjack	Goodrich Control Systems
548C0000-02	Flap Screwjack	Goodrich Control Systems
548C0000-03	Flap Screwjack	Goodrich Control Systems
548D0000-01	Flap Screwjack	Goodrich Control Systems
548E0000-01	Flap Screwjack	Goodrich Control Systems
548F0000-01	Flap Screwjack	Goodrich Control Systems
548F0000-02	Flap Screwjack	Goodrich Control Systems

Repair_Capability_List_Excel

548F0000-03	Flap Screwjack	Goodrich Control Systems
548F0000-04	Flap Screwjack	Goodrich Control Systems
548G0000-01	Flap Screwjack	Goodrich Control Systems
548G0000-02	Flap Screwjack	Goodrich Control Systems
548G0000-03	Flap Screwjack	Goodrich Control Systems
549C0000-01	Flap Screwjack	Goodrich Control Systems
549C0000-02	Flap Screwjack	Goodrich Control Systems
549C0000-03	Flap Screwjack	Goodrich Control Systems
549D0000-01	Flap Screwjack	Goodrich Control Systems
549E0000-01	Flap Screwjack	Goodrich Control Systems
549E0000-02	Flap Screwjack	Goodrich Control Systems
549F0000-01	Flap Screwjack	Goodrich Control Systems
549F0000-02	Flap Screwjack	Goodrich Control Systems
549F0000-03	Flap Screwjack	Goodrich Control Systems
549F0000-04	Flap Screwjack	Goodrich Control Systems
549G0000-01	Flap Screwjack	Goodrich Control Systems
549G0000-02	Flap Screwjack	Goodrich Control Systems
549G0000-03	Flap Screwjack	Goodrich Control Systems
549G0000-04	Flap Screwjack	Goodrich Control Systems
5500300-1	Outboard Aileron Lockout Actuator	Nabtesco
5500300-1 Mod A	Outboard Aileron Lockout Actuator	Nabtesco
5500300-11	Outboard Aileron Lockout Actuator	Nabtesco
5500300-13	Outboard Aileron Lockout Actuator	Nabtesco
5500300-15	Outboard Aileron Lockout Actuator	Nabtesco
5500300-17	Outboard Aileron Lockout Actuator	Nabtesco
5500300-17D	Outboard Aileron Lockout Actuator	Nabtesco
5500300-19	Outboard Aileron Lockout Actuator	Nabtesco
5500300-21	Outboard Aileron Lockout Actuator	Nabtesco
5500300-3	Outboard Aileron Lockout Actuator	Nabtesco
5500300-5	Outboard Aileron Lockout Actuator	Nabtesco
5500300-501	Outboard Aileron Lockout Actuator	Nabtesco
5500300-505	Outboard Aileron Lockout Actuator	Nabtesco
5500300-507	Outboard Aileron Lockout Actuator	Nabtesco
5500300-7	Outboard Aileron Lockout Actuator	Nabtesco
5500400-1	Nose Gear Linear Actuator	Nabtesco
5500400-1 Mod A	Nose Gear Linear Actuator	Nabtesco
5500400-3	Nose Gear Linear Actuator	Nabtesco
5500400-5	Nose Gear Linear Actuator	Nabtesco
5500400-7	Nose Gear Linear Actuator	Nabtesco
5500400-701	Nose Gear Linear Actuator	Nabtesco
5500400-9	Nose Gear Linear Actuator	Nabtesco
5500400-901	Nose Gear Linear Actuator	Nabtesco
5500500-1	Flap Load Relief Linear Actuator	Nabtesco
5500500-1 Mod A	Flap Load Relief Linear Actuator	Nabtesco
5500500-101	Flap Load Relief Linear Actuator	Nabtesco
5500500-103	Flap Load Relief Linear Actuator	Nabtesco
5500500-3	Flap Load Relief Linear Actuator	Nabtesco
5500500-301	Flap Load Relief Linear Actuator	Nabtesco
5500500-303	Flap Load Relief Linear Actuator	Nabtesco
5500500-305	Flap Load Relief Linear Actuator	Nabtesco
5500700-1	Flap Load Relief Linear Actuator	Nabtesco
5500700-1 Mod A	Flap Load Relief Linear Actuator	Nabtesco
5500700-101	Flap Load Relief Linear Actuator	Nabtesco
5500700-103	Flap Load Relief Linear Actuator	Nabtesco
5500700-3	Flap Load Relief Linear Actuator	Nabtesco
5500700-301	Flap Load Relief Linear Actuator	Nabtesco
5500700-303	Flap Load Relief Linear Actuator	Nabtesco
5500800-1	Flap Load Relief Linear Actuator	Nabtesco

Repair_Capability_List_Excel

550121736	Deicing Pump	Plessey
55-0723	Light	Grimes Aerospace
55076	Hydraulic Pump	Parker Hannifin
55076-02	Hydraulic Pump	Parker Hannifin
55076-03	Hydraulic Pump	Parker Hannifin
55097	Hydraulic Pump	Abex
55097-01	Hydraulic Pump	Abex
55097-02	Hydraulic Pump	Abex
55097-03	Hydraulic Pump	Abex
55098	Hydraulic Pump	Parker Hannifin
55098-01	Hydraulic Pump	Parker Hannifin
55098-04	Hydraulic Pump	Parker Hannifin
55098-05	Hydraulic Pump	Parker Hannifin
55098-06	Hydraulic Pump	Parker Hannifin
55098-07	Hydraulic Pump	Parker Hannifin
55098-08	Hydraulic Pump	Parker Hannifin
550A0000-01	Kink Steady Bearing	Goodrich Control Systems
55120	Rod-connecting	Sarma
55188	Pressure Differential Indicator	Hamilton Sundstrand
551A0200-01	Joint assy	Goodrich Control Systems
551A0400-03	Steady Bearing	Goodrich Control Systems
551A0400-04	Steady Bearing	Goodrich Control Systems
551A0400-05	Steady Bearing	Goodrich Control Systems
551A0600-01	Steady Bearing	Goodrich Control Systems
551A0600-02	Steady Bearing	Goodrich Control Systems
551A0600-03	Steady Bearing	Goodrich Control Systems
551A0700-03	Universal Joint	Goodrich Control Systems
551A0900-01	Shaft Assembly	Goodrich Control Systems
551A1000-01	Shaft Assembly	Goodrich Control Systems
551A1100-01	Shaft Assembly	Goodrich Control Systems
551A1200-01	Shaft Assembly	Goodrich Control Systems
551A1300-01	Shaft Assembly	Goodrich Control Systems
551A1400-01	Shaft Assembly	Goodrich Control Systems
551A3600-01	Shaft Assembly	Goodrich Control Systems
551A3700-01	Shaft Assembly	Goodrich Control Systems
551A3800-01	Shaft Assembly	Goodrich Control Systems
551A3900-01	Shaft Assembly	Goodrich Control Systems
551A4000-01	Shaft Assembly	Goodrich Control Systems
551A4300-01	Shaft Assembly	Goodrich Control Systems
551A4400-01	Shaft Assembly	Goodrich Control Systems
551A4500-01	Steady Bearing	Goodrich Control Systems
551A4500-02	Steady Bearing	Goodrich Control Systems
551A4500-03	Steady Bearing	Goodrich Control Systems
551A4600-01	Shaft Assembly	Goodrich Control Systems
551A5700-01	Shaft Assembly	Goodrich Control Systems
551A5800-01	Shaft Assembly	Goodrich Control Systems
551A9400-01	Shaft Assembly	Goodrich Control Systems
551B01	Non-Return Valve Cap	Bronzavia-Air Equipement
551B0400-01	Steady Bearing	Goodrich Control Systems
551B0600-01	Steady Bearing	Goodrich Control Systems
551B3600-01	Shaft Assembly	Goodrich Control Systems
551B3700-01	Shaft Assembly	Goodrich Control Systems
551B4500-01	Steady Bearing	Goodrich Control Systems
551C0200-01	Joint assy	Goodrich Control Systems
551C0700-01	Plunging Joint assy	Goodrich Control Systems
551C3600-01	Shaft Assembly	Goodrich Control Systems
551C3700-01	Shaft Assembly	Goodrich Control Systems
551C3800-01	Shaft Assembly	Goodrich Control Systems

Repair_Capability_List_Excel

551C3900-01	Shaft Assembly	Goodrich Control Systems
551C4000-01	Shaft Assembly	Goodrich Control Systems
551C4300-01	Shaft Assembly	Goodrich Control Systems
551C4400-01	Shaft Assembly	Goodrich Control Systems
551C4600-01	Shaft Assembly	Goodrich Control Systems
551C5800-01	Shaft Assembly	Goodrich Control Systems
551CA01	Electrically Held Contactor	Intertechnique
55220	Rod-connecting	Sarma
5530-16582-2	Manual Motor	Nord-Micro
554264	Ball Screw assy	Umbrac Cuscinetti
554264-1	Ball Screw assy	Umbrac Cuscinetti
554265	Ball Screw assy	Umbrac Cuscinetti
554265-1	Ball Screw assy	Umbrac Cuscinetti
554266	Ball Screw assy	Umbrac Cuscinetti
554266-1	Ball Screw assy	Umbrac Cuscinetti
554267	Ball Screw assy	Umbrac Cuscinetti
554267-1	Ball Screw assy	Umbrac Cuscinetti
554A01	Non-Return Valve Cap	Bronzavia-Air Equipement
55640	Pressure Differential Indicator	Hamilton Sundstrand
5565A	Door Latch	I.S.E.
557-17E	Air Check Valve	Bendix
557-17F	Air Check Valve	Bendix
558CA01	Three-Pole Contactor	ECE
558CA01Y1	Three-Pole Contactor	ECE
559CA01Y1	Three-Pole Contactor	ECE
56017	Tube	Sarma
56019-003	Rotary Actuator	Lear Siegler Inc
56019-005	Rotary Actuator	Lear Siegler Inc
56024-002	Rotary Actuator	Lear Siegler
56024-003	Rotary Actuator	Lear Siegler
56024-004	Rotary Actuator	Lear Siegler
560A0000-01	Sensor	Goodrich Control Systems
560A0000-02	Sensor	Goodrich Control Systems
5618C000	Turbine Inlet Control Valve	Honeywell
56217	Pressure Differential Indicator	Hamilton Sundstrand
562MK1	Screwjack	Goodrich Control Systems
562MK2	Screwjack	Goodrich Control Systems
56332K	Temperature Transducer	Goodrich
563A11	Temperature Transducer	Goodrich
563MK2	Screwjack	Goodrich Control Systems
563MK3	Screwjack	Goodrich Control Systems
564CA01Y1	Three-Pole Contactor	ECE
564CA02FY1	Three-Pole Contactor	ECE
564CA04A01Y00	Three-Pole Contactor	ECE
564CA04A21Y00	Three-Pole Contactor	ECE
564MK1	Screwjack	Goodrich Control Systems
564MK2	Screwjack	Goodrich Control Systems
566MK2	Screwjack	Goodrich Control Systems
566MK3	Screwjack	Goodrich Control Systems
566MK4	Screwjack	Goodrich Control Systems
566MK5	Screwjack	Goodrich Control Systems
567219	Oil Cooler	Pratt & Whitney
5672-781-8	Engine Vibration Indicator	Thales Avionics
5674-146-80-10	Brake Pressure Indicator	Thales Avionics
5677-406-80-13	Dual Oil/Temp Pressure Indicator	Thales Avionics
5677-409-80-10	Dual Oil/Temp Pressure Indicator	Thales Avionics
5677-420-80-10	Temp/Press Oil Indicator	Thales Avionics
5677-705-80-10	NH Indicator	Thales Avionics

Repair_Capability_List_Excel

5677-750-80-11	Torque Indicator	Thales Avionics
5677-755-80-11	Torque Indicator	Thales Avionics
5677-756-80-10	Torque Indicator	Thales Avionics
5677-765-80-10	Torque Indicator	Thales Avionics
5677-766-80-10	Torque Indicator	Thales Avionics
5677-767-80-10	Torque Indicator	Thales Avionics
5678-553-80-12	Turbine Temperature Indicator	Thales Avionics
5678-555-80-10	Turbine Temperature Indicator	Thales Avionics
5678-559-80-10	Turbine Temperature Indicator	Thales Avionics
5678-704-80-11	NH Indicator	Thales Avionics
5678-705-80-12	NH Indicator	Thales Avionics
5678-711-80-10	NP Indicator	Thales Avionics
5678-713-80-10	NP Indicator	Thales Avionics
5678-715-80-10	NP Indicator	Thales Avionics
5678-716-80-10	NP Propeller Indicator	Thales Avionics
567MK1	Screwjack	Goodrich Control Systems
567MK2	Screwjack	Goodrich Control Systems
568-1-26713-001	Booster Pump	Plessey
568-1-26713-002	Booster Pump	Plessey
568-1-26713-003	Booster Pump	Plessey
568-1-26713-004	Booster Pump	Plessey
568-1-26713-005	Booster Pump	Plessey
568-1-27170-001	Fuel Transfer Pump	GEC-Marconi
568-1-27170-002	Fuel Transfer Pump	GEC-Marconi
568-1-27202-001	Fuel Pump	GEC-Marconi
568-1-27202-002	Fuel Pump	GEC-Marconi
568-1-27202-005	Fuel Pump	GEC-Marconi
568-1-27203-001	Canister	GEC-Marconi
568-1-27203-002	Canister	GEC-Marconi
568-1-27244-001	Canister	GEC-Marconi
568-1-27244-002	Canister	GEC-Marconi
568-1-28300-001	Fuel Pump	FR Hitemp
568-1-28300-002	Fuel Pump	FR Hitemp
568-1-28300-003	Fuel Pump	FR Hitemp
568-1-28300-004	Fuel Pump	FR Hitemp
568-1-28301-003	Canister	FR Hitemp
568-1-28405-001	Jet Pump	FR Hitemp
568-1-29115-001/2	Fuel Pump	FR Hitemp
568-1-29116-001/2	Canister	FR Hitemp
568-1-29117-001/2	Fuel Pump	FR Hitemp
568-1-29118-001/2	Canister	FR Hitemp
568-1-29407-001/2	Fuel Pump	FR Hitemp
568-1-29408-001/2	Canister	FR Hitemp
568-1-29507-001/2	Canister	FR Hitemp
569653	Hydraulic Pump	Vickers
569668	Constant Displacement Hydraulic Motor	Vickers
569670	Hydraulic Motor	Vickers
569672	Hydraulic Motor	Vickers
569911	Stator	Vickers
56B17A6	Temperature Sensor	Horizon Aerospace
56B17C	Temperature Sensor	Goodrich
56B17E	Temperature Sensor	Goodrich
56B24	Sensor	Honeywell
5700740	Ball Screw assy	Saginaw
5700821	Ball Screw assy	Sabinaw
5700822	Ball Screw assy	Sabinaw
5700823	Ball Screw assy	Sabinaw
5700824	Ball Screw assy	Sabinaw

Repair_Capability_List_Excel

5701801	Ball Screw assy	Thomson Saginaw
5701802	Screwjack	Boeing
5701803	Screwjack	Boeing
570-21400-11	Altimeter Alerter	Kollsman
570-21400-12	Altimeter Alerter	Kollsman
570-21400-13	Altimeter Alerter	Kollsman
570-21400-14	Altimeter Alerter	Kollsman
570-21400-15	Altimeter Alerter	Kollsman
570-21400-16	Altimeter Alerter	Kollsman
570-21400-17	Altimeter Alerter	Kollsman
570-21400-18	Altimeter Alerter	Kollsman
5702224	Screwjack	Boeing
5702225	Ball Screw assy	Thomson Saginaw
5702226	Ball Screw assy	Thomson Saginaw
5702401	Ball Screw assy	Saginaw
5702402	Ball Screw assy	Saginaw
5702403	Ball Screw assy	Saginaw
5702405	Ball Screw assy	Saginaw
5702471	Ball Screw assy	Sabinaw
5702472	Ball Screw assy	Sabinaw
5702473	Ball Screw assy	Sabinaw
5702474	Ball Screw assy	Sabinaw
5702805	Ball Screw assy	Sabinaw
5702806	Ball Screw assy	Sabinaw
5702807	Ball Screw assy	Sabinaw
5702808	Ball Screw assy	Sabinaw
5703117	Ball Screw assy	Sabinaw
5703118	Ball Screw assy	Sabinaw
5703119	Ball Screw assy	Sabinaw
5703120	Ball Screw assy	Sabinaw
570347	Variable Disp.Hydraulic Motorpump	Eaton
5703700	Ball Screw assy	Saginaw
5703747	Ball Screw assy	Saginaw
570796	Variable Displacement Hyd. Pump	Vickers
5708461	Ball Screw assy	Saginaw
5708462	Ball Screw assy	Saginaw
5708463	Ball Screw assy	Saginaw
5709635	Ball Screw assy	Saginaw
571191	Power Transfer Unit	Vickers
57126	Pump assy	Abex
57150	Pump	Abex
57150AP1V9	Pump	Abex
57186	Pump & Motor	Parker Hannifin
57186-01	Pump & Motor	Parker Hannifin
57186-02	Pump & Motor	Parker Hannifin
57186-03	Pump & Motor	Parker Hannifin
57186-04	Pump & Motor	Parker Hannifin
57186-05	Pump & Motor	Parker Hannifin
57186-06	Pump & Motor	Parker Hannifin
57186-07	Pump & Motor	Parker Hannifin
57186-10	Pump & Motor	Parker Hannifin
571MK2	Screwjack	Goodrich Control Systems
571MK3	Screwjack	Goodrich Control Systems
572756	Switch	ITT Aerospace Ctrlis
572756-1	Thermal Switch	Honeywell
572757-1	Turbine Inlet Thermal Switch	Honeywell
572MK2	Screwjack	Goodrich Control Systems
572MK3	Screwjack	Goodrich Control Systems

Repair_Capability_List_Excel

57435	Pressure Differential Indicator	Hamilton Sundstrand
57514-02	Filter Body	Le Bozec
57514-04	Filter Body	Le Bozec
57514-31	Filter Body	Le Bozec
575-25850-200	Mach Airspeed Indicator	Kollsman
575-25850-300	Mach Airspeed Indicator	Kollsman
575-26320	Mach Airspeed Indicator	Kollsman
575-29846-200	Mach Airspeed Indicator	Kollsman
575-29846-300	Mach Airspeed Indicator	Kollsman
575-30680-401	Mach Airspeed Indicator	Kollsman
575-30680-402	Mach Airspeed Indicator	Kollsman
575-30680-406	Mach Airspeed Indicator	Kollsman
575-30680-409	Mach Airspeed Indicator	Kollsman
575-30680-417	Mach Airspeed Indicator	Kollsman
575-30680-501	Mach Airspeed Indicator	Kollsman
575-30680-502	Mach Airspeed Indicator	Kollsman
575-30680-506	Mach Airspeed Indicator	Kollsman
575-30680-509	Mach Airspeed Indicator	Kollsman
575-30680-517	Mach Airspeed Indicator	Kollsman
575-30680-807	Mach Airspeed Indicator	Kollsman
575-30680-825	Mach Airspeed Indicator	Kollsman
575-30680-855	Mach Airspeed Indicator	Kollsman
575-30680-907	Mach Airspeed Indicator	Kollsman
575-30680-925	Mach Airspeed Indicator	Kollsman
575-30680-955	Mach Airspeed Indicator	Kollsman
575-33075-240	Mach Airspeed Indicator	Kollsman
575-33075-241	Mach Airspeed Indicator	Kollsman
575-33075-285	Mach Airspeed Indicator	Kollsman
575-33075-340	Mach Airspeed Indicator	Kollsman
575-33075-341	Mach Airspeed Indicator	Kollsman
575-33075-385	Mach Airspeed Indicator	Kollsman
575-33075-440	Mach Airspeed Indicator	Kollsman
575-33075-441	Mach Airspeed Indicator	Kollsman
575-33075-540	Mach Airspeed Indicator	Kollsman
575-33075-541	Mach Airspeed Indicator	Kollsman
575-35900-400	Mach Airspeed Indicator	Kollsman
575-35900-500	Mach Airspeed Indicator	Kollsman
575-35900-600	Mach Airspeed Indicator	Kollsman
575-35900-700	Mach Airspeed Indicator	Kollsman
5765017-501	Rudder Damper	Douglas
5765017-503	Rudder Damper	Douglas
577MK1	Screwjack	Goodrich Control Systems
579B0000-01	Power Control Unit	Goodrich Control Systems
579B0000-02	Power Control Unit	Goodrich Control Systems
579B0000-03	Power Control Unit	Goodrich Control Systems
579B0000-04	Power Control Unit	Goodrich Control Systems
579FL	Desynn Pressure Indicator	Smiths Industries
579FLCP	Desynn Pressure Indicator	Smiths Industries
579FLSB	Desynn Pressure Indicator	Smiths Industries
57PT2103-5	Hand Held Microphone	Holmberg
57PT2103F6	Hand Held Microphone	Holmberg
580-218-1	Cable assy	Cablecraft
580-218-2	Cable assy	Cablecraft
580-218-3	Cable assy	Cablecraft
580-218-4	Cable assy	Cablecraft
580-219-1	Cable assy	Cablecraft
580-219-2	Cable assy	Cablecraft
580-219-3	Cable assy	Cablecraft

Repair_Capability_List_Excel

580-219-4	Cable assy	Cablecraft
580-235-001	By-Pass Feedback Valve Cable	Cablecraft
580-235-002	By-Pass Feedback Valve Cable	Cablecraft
580-235-003	By-Pass Feedback Valve Cable	Cablecraft
580-258-002	By-Pass Feedback Valve Cable	Cablecraft
580-258-003	By-Pass Feedback Valve Cable	Cablecraft
580-278-002	Variable Stator Cable	Cablecraft
580-278-005	Variable Stator Cable	Cablecraft
580-292-040	Interlock Reverser Control Cable	Cablecraft
580-292-041	Interlock Reverser Control Cable	Cablecraft
580B0000-01	Power Control Unit	Goodrich Control Systems
580B0000-02	Power Control Unit	Goodrich Control Systems
580B0000-03	Power Control Unit	Goodrich Control Systems
580B0000-04	Power Control Unit	Goodrich Control Systems
580SE01Y1	Three Pole Base Contactor	ECE
580SE01Y2	Three Pole Base Contactor	ECE
58120	Actuator	Sterer-Vickers
58120-1	Actuator	Sterer-Vickers
58120-2	Actuator	Sterer-Vickers
58137	Hydraulic Pump	Abex
58172	Hydraulic Motor	Abex
58172-01	Hydraulic Motor	Abex
58173	Hydraulic Motor	Abex
581B0000-01	Block Valve	Goodrich Control Systems
581B0000-02	Block Valve	Goodrich Control Systems
581SE01	Three Pole Base Contactor	ECE
581SE01Y2	Three Pole Base Contactor	ECE
5822-21	Emergency Light Supply	LSI
5822-7	Power Supply	Luminescent Systems
582SE01	Three Pole Base Contactor	ECE
5830201-106	TCC Actuator	Parker Hannifin
5830201-107	TCC Actuator	Parker Hannifin
5830201-108	TCC Actuator	Parker Hannifin
5830201-109	TCC Actuator	Parker Hannifin
5830201-110	TCC Actuator	Parker Hannifin
5830201-111	TCC Actuator	Parker Hannifin
5830202-101	LPTCC Valve	Parker Hannifin
5830202-102	LPTCC Valve	Parker Hannifin
5830202-103	LPTCC Valve	Parker Hannifin
5830202-104	LPTCC Valve	Parker Hannifin
5830202-105	LPTCC Valve	Parker Hannifin
5830202-106	LPTCC Valve	Parker Hannifin
5830202-108	LPTCC Valve	Parker Hannifin
5830203-101	HPTCC Valve	Parker Hannifin
5830203-102	HPTCC Valve	Parker Hannifin
5830203-103	HPTCC Valve	Parker Hannifin
5830203-104	HPTCC Valve	Parker Hannifin
5830205-101	Valve assy	Parker Hannifin
5830205-102	Valve assy	Parker Hannifin
5830212-101	Valve	Parker Hannifin
5830212-102	Valve	Parker Hannifin
5830212-104	Valve	Parker Hannifin
58-380084-3	Gauge	EDO-Aire
5840207-103	Valve	Parker Hannifin
5840207-104	Valve	Parker Hannifin
585SE01Y1	Three Pole Base Contactor	ECE
5867-8	Power Supply	Luminescent Systems
586SE01	Three Pole Base Contactor	ECE

Repair_Capability_List_Excel

587-00107-001	Pressure Switch	Thales Avionics
587-00501-000	Pressure Switch	Thales Avionics
5870141-105	Bore Cooling Valve	Parker Hannifin
587A0000-01	Tee Gearbox	Goodrich Control Systems
587A0000-02	Tee Gearbox	Goodrich Control Systems
587SE01	Three Pole Base Contactor	ECE
5880357-106	Turbing Cooling Valve Actuator	Parker Hannifin
5899-03	Electrical Harness	L'Hotellier
5899-10	Electrical Harness	L'Hotellier
5905587	Filter Element	Pratt & Whitney
5906733	Current Transformer	Hamilton Sundstrand
5906734	Current Transformer assy	Goodrich Control Systems
5907775	Current Transformer assy	Goodrich Control Systems
5908281	RAT Stow Panel	Hamilton Sundstrand
590SE01	Base Contactor	ECE
59100-5009	Rudder Package	Parker-Hannifin
59100-5013	Rudder Package	Parker-Hannifin
59100-5015	Rudder Package	Parker-Hannifin
59100-5017	Rudder Package	Parker-Hannifin
5910962-1	Stab. Actuator assy	Douglas
5910962-13	Screw Support assy	Douglas
5910962-15	Long Trim Actuator assy	Douglas
5910962-17	Long Trim Actuator assy	Douglas
5910962-19	Long Trim Actuator assy	Douglas
5910962-21	Long Trim Actuator assy	Douglas
5910962-23	Long Trim Actuator assy	Douglas
5910962-25	Long Trim Actuator assy	Douglas
5910962-27	Long Trim Actuator assy	Douglas
5910962-29	Screw Support assy	Douglas
5910962-3	Screw Support assy	Douglas
5910962-31	Screw Support assy	Douglas
5910962-33	Screw Support assy	Douglas
5910962-35	Screw Support assy	Douglas
5910962-37	Screw Support assy	Douglas
5910962-39	Long Trim Actuator assy	Douglas
5910962-41	Long Trim Actuator assy	Douglas
5910962-43	Long Trim Actuator assy	Douglas
5910962-45	Long Trim Actuator assy	Douglas
5910962-47	Long Trim Actuator assy	Douglas
5910962-49	Long Trim Actuator assy	Douglas
5910962-5	Screwjack	Douglas
5910962-501	Stab. Actuator assy	Douglas
5910962-503	Stab. Actuator assy	Douglas
5910962-505	Stab. Actuator assy	Douglas
5910962-507	Stab. Actuator assy	Douglas
5910962-509	Stab. Actuator assy	Douglas
5910962-51	Long Trim Actuator assy	Douglas
5910962-511	Stab. Actuator assy	Douglas
5910962-513	Stab. Actuator assy	Douglas
5910962-515	Stab. Actuator assy	Douglas
5910962-517	Stab. Actuator assy	Douglas
5910962-519	Stab. Actuator assy	Douglas
5910962-521	Stab. Actuator assy	Douglas
5910962-525	Stab. Actuator assy	Douglas
5910962-53	Screw Support assy	Douglas
5910962-55	Long Trim Actuator assy	Douglas
5910962-57	Screw Support assy	Douglas
5910962-59	Screw Support assy	Douglas

Repair_Capability_List_Excel

5910962-61	Screw Support assy	Douglas
5910962-63	Screw Support assy	Douglas
5910962-65	Screw Support assy	Douglas
5910962-67	Screw Support assy	Douglas
5910962-69	Screw Support assy	Douglas
5910962-7	Screw Support assy	Douglas
5910962-71	Screw Support assy	Douglas
5910962-73	Long Trim Actuator assy	Douglas
5910962-75	Screw Support assy	Douglas
5910962-77	Screw Support assy	Douglas
5910962-79	Screw Support assy	Douglas
5910962-81	Screw Support assy	Douglas
5910962-83	Screw Support assy	Douglas
5910962-9	Screw Support assy	Douglas
5911249	RAT Manifold assy	Liebherr Aerotechnik
5911326	RAT Actuator	Liebherr Aerotechnik
5911330	Slats and Flaps Lever	Hamilton Sundstrand
5911360	Drive Shaft assy	Hamilton Sundstrand
5911560	Drive Shaft assy	Hamilton Sundstrand
5911605	Inboard & Outboard Flap Screw Sensor	Hamilton Sundstrand
591200-31	Coupling	Parker Hannifin
591200-41	Coupling	Parker Hannifin
591200-51	Coupling	Parker Hannifin
5912505	Electrical Motor	Hamilton Sundstrand
5912560	Inboard & Outboard Flap Screw Sensor	Hamilton Sundstrand
5912576	Drive Shaft assy	Hamilton Sundstrand
5912577	Drive Shaft assy	Hamilton Sundstrand
5912578	Drive Shaft assy	Hamilton Sundstrand
5912617	Slat Brake Position Sensor Unit	Hamilton Sundstrand
5912618	Flap Brake Position Sensor Unit	Hamilton Sundstrand
5912647-01	Contactora	Hamilton Sundstrand
5912648-01	Single Pole Contactora	Hamilton Sundstrand
5912652-01	Power Relay	Hamilton Sundstrand
5912833	APU Generator	Hamilton Sundstrand
5912868	Torque Tube assy	Hamilton Sundstrand
5912869	Torque Tube assy	Hamilton Sundstrand
5912870	Torque Tube assy	Hamilton Sundstrand
5912949	Torque Tube assy	Hamilton Sundstrand
5912999	Slat Brake Position Sensor Unit	Hamilton Sundstrand
5913000	Flap Brake Position Sensor Unit	Hamilton Sundstrand
5913003	Torque Tube assy	Hamilton Sundstrand
5913005	Torque Tube assy	Hamilton Sundstrand
5913016-4	DC Power Supply Module	Hamilton Sundstrand
5913107	Inboard & Outboard Flap Screw Sensor	Hamilton Sundstrand
5913108	Inboard & Outboard Flap Screw Sensor	Hamilton Sundstrand
5913144	Slat & Flap PDU DC Motor	Hamilton Sundstrand
5913148-2	Transformer Rectifier Unit	Hamilton Sundstrand
5913149	LH Integrated Control Center	Hamilton Sundstrand
5913150-01	RH Integrated Control Center	Hamilton Sundstrand
5913159	Flap Actuator	Hamilton Sundstrand
5913202-01-01	Contactora	Hamilton Sundstrand
5913447	Restow Pump	Hamilton Sundstrand
5913469	Torque Tube assy	Hamilton Sundstrand
5913470	Torque Tube assy	Hamilton Sundstrand
5913838-1	Single Pole Contactora	Hamilton Sundstrand
5913900-5505	Spoiler Actuator	Douglas
5913900-5507	Spoiler Actuator	Douglas
5913900-5509	Spoiler Actuator	Douglas

Repair_Capability_List_Excel

5913900-5511	Spoiler Actuator	Douglas
5913900-5513	Spoiler Actuator	Douglas
5913900-5515	Spoiler Actuator	Douglas
5913900-5517	Spoiler Actuator	Douglas
5913900-5519	Spoiler Actuator	Douglas
5913900-5521	Spoiler Actuator	Douglas
5913900-5523	Spoiler Actuator	Douglas
5913900-5525	Spoiler Actuator	Douglas
5914066-5501	Rudder Power Control Actuator	Douglas
5914066-5505	Rudder Power Control Actuator	Douglas
5914066-5507	Rudder Power Control Actuator	Douglas
5914066-5509	Rudder Power Control Actuator	Douglas
5914066-5511	Rudder Power Control Actuator	Douglas
5914066-5513	Rudder Power Control Actuator	Douglas
5914066-5515	Rudder Power Control Actuator	Douglas
5914066-5517	Rudder Power Control Actuator	Douglas
5914066-5519	Rudder Power Control Actuator	Douglas
5914066-5521	Rudder Power Control Actuator	Douglas
5914066-5523	Rudder Power Control Actuator	Douglas
5914066-5525	Rudder Power Control Actuator	Douglas
5914066-5527	Rudder Power Control Actuator	Douglas
5914066-5529	Rudder Power Control Actuator	Douglas
5914066-5531	Rudder Power Control Actuator	Douglas
5914066-5533	Rudder Power Control Actuator	Douglas
5914066-5535	Rudder Power Control Actuator	Douglas
5914066-5537	Rudder Power Control Actuator	Douglas
5914066-5539	Rudder Power Control Actuator	Douglas
5914066-5541	Rudder Power Control Actuator	Douglas
5914066-5543	Rudder Power Control Actuator	Douglas
5914066-5545	Rudder Power Control Actuator	Douglas
5914066-5547	Rudder Power Control Actuator	Douglas
5914066-5549	Rudder Power Control Actuator	Douglas
5914066-5551	Rudder Power Control Actuator	Douglas
5914066-5553	Rudder Power Control Actuator	Douglas
5914066-5555	Rudder Power Control Actuator	Douglas
5914066-5557	Rudder Power Control Actuator	Douglas
5914066-5559	Rudder Power Control Actuator	Douglas
5914066-5561	Rudder Power Control Actuator	Douglas
5914066-5563	Rudder Power Control Actuator	Douglas
5914066-5565	Rudder Power Control Actuator	Douglas
5914066-5567	Rudder Power Control Actuator	Douglas
5914066-5569	Rudder Power Control Actuator	Douglas
5914066-5571	Rudder Power Control Actuator	Douglas
5914066-5573	Rudder Power Control Actuator	Douglas
5914066-5575	Rudder Power Control Actuator	Douglas
5914066-5577	Rudder Power Control Actuator	Douglas
5914066-5581	Rudder Power Control Actuator	Douglas
5914190-5001	Manifold Valve	Douglas
5914190-5501	Manifold Valve	Douglas
5914190-5503	Manifold Valve	Douglas
5914296-5503	Valve assy	Douglas
5914296-5505	Valve assy	Douglas
5914296-5507	Valve assy	Douglas
5914296-5509	Valve assy	Douglas
5914387-505	Actuator	Douglas
5914387-507	Actuator	Douglas
5914387-509	Actuator	Douglas
5914387-511	Actuator	Douglas

Repair_Capability_List_Excel

5914387-513	Actuator	Douglas
5914387-515	Actuator	Douglas
5914387-517	Actuator	Douglas
5914387-519	Actuator	Douglas
5914387-521	Actuator	Douglas
5914387-523	Actuator	Douglas
5914387-525	Actuator	Douglas
5914387-527	Actuator	Douglas
5916460-5505	Valve assy	Boeing
5916460-5507	Valve assy	Boeing
5916460-5509	Valve assy	Boeing
5917267-5503	Tail Cone Hydraulic Valve	Douglas
5917267-5505	Tail Cone Hydraulic Valve	Douglas
5917267-5507	Tail Cone Hydraulic Valve	Douglas
5917267-5509	Tail Cone Hydraulic Valve	Douglas
5918125-1	Damper	Douglas
5918125-501	Damper	Douglas
5918161-5503	Power Control Valve	Douglas
5918161-5505	Power Control Valve	Douglas
5918161-5507	Power Control Valve	Douglas
5918161-5509	Power Control Valve	Douglas
591SE01	Base Contactor	ECE
5923142-5001	Hydraulic Damper	Douglas
5923142-5501	Hydraulic Damper	Douglas
5923142-5503	Hydraulic Damper	Douglas
5923142-5505	Hydraulic Damper	Douglas
5923142-5507	Hydraulic Damper	Douglas
5923142-5509	Hydraulic Damper	Douglas
5923142-5511	Hydraulic Damper	Douglas
5923142-5513	Hydraulic Damper	Douglas
5924225-1	Gearbox assy	Douglas
5925-6	Power Supply	Luminescent Systems
5934212-5001	Cylinder	Douglas
5934212-5501	Cylinder	Douglas
5935212-501	Auto Spoiler Box	Douglas
59364-3272602-3	Actuator	Honeywell
5936965-5001	Spoiler Cylinder	Douglas
5936965-5501	Spoiler Cylinder	Douglas
5936965-5503	Spoiler Cylinder	Douglas
5936971-5503	Spoiler Valve	Douglas
5937021-5503	Slat Cylinder	Boeing
5937036-5001	MLG Cylinder	Douglas
5937036-5501	MLG Cylinder	Douglas
5937036-5503	MLG Cylinder	Douglas
5937036-5505	MLG Cylinder	Douglas
5937036-5507	MLG Cylinder	Douglas
5937052-5001	Cylinder Actuator	Douglas
593-8655-001	HF Communication Control Panel	Rockwell-Collins
5938801-501	Slat Drive Control	Douglas
5938801-503	Slat Drive Control	Douglas
5938801-505	Slat Drive Control	Douglas
5938801-507	Slat Drive Control	Douglas
5938801-509	Slat Drive Control	Douglas
5939074-5501	Cylinder Actuator	Douglas
5940560-1	Stab. Actuator assy	Douglas
5940560-3	Screw Support assy	Douglas
5940560-5	Long Trim Actuator assy	Douglas
5940560-501	Stab. Actuator assy	Douglas

Repair_Capability_List_Excel

5940560-85	Long Trim Actuator assy	Douglas
5940560-87	Long Trim Actuator assy	Douglas
5940560-9	Long Trim Actuator assy	Douglas
5956101-5501	Valve assy	Douglas
5-95631-11	Rudder Pedal	Boeing
5-95631-12	Rudder Pedal	Boeing
5-95631-13	Rudder Pedal	Boeing
5-95631-14	Rudder Pedal	Boeing
5-95631-15	Rudder Pedal	Boeing
5-95631-16	Rudder Pedal	Boeing
5-95631-17	Rudder Pedal	Boeing
5-95631-18	Rudder Pedal	Boeing
5-95631-3029	Rudder Pedal	Boeing
5-95631-3030	Rudder Pedal	Boeing
5-95631-3031	Rudder Pedal	Boeing
5-95631-3032	Rudder Pedal	Boeing
5-95631-3033	Rudder Pedal	Boeing
5-95631-3034	Rudder Pedal	Boeing
5-95631-3035	Rudder Pedal	Boeing
5-95631-3036	Rudder Pedal	Boeing
5-95631-3039	Rudder Pedal	Boeing
5-95631-3040	Rudder Pedal	Boeing
5-95631-3041	Rudder Pedal	Boeing
5-95631-3042	Rudder Pedal	Boeing
5-95631-3047	Rudder Pedal	Boeing
5-95631-3048	Rudder Pedal	Boeing
5-95631-3049	Rudder Pedal	Boeing
5-95631-3050	Rudder Pedal	Boeing
5-95631-3053	Rudder Pedal	Boeing
5-95631-3054	Rudder Pedal	Boeing
5-95631-3055	Rudder Pedal	Boeing
5-95631-3056	Rudder Pedal	Boeing
5956888-1	Light Control assy	McDonnell Douglas
5956888-501	Light Control assy	McDonnell Douglas
5956888-503	Light Control assy	McDonnell Douglas
5956888-505	Light Control assy	McDonnell Douglas
5956888-507	Light Control assy	McDonnell Douglas
5956888-509	Light Control assy	McDonnell Douglas
5956888-511	Light Control assy	McDonnell Douglas
5958-92B-15-A	Pressure Indicator	Pioneer
5958-96B-15-A	Pressure Indicator	Pioneer
59600-5003	Solenoid Valve	Parker Hannifin
59600-5004	Solenoid Valve	Parker Hannifin
59600-5005	Solenoid Valve	Parker Hannifin
59600-5006	Solenoid Valve	Parker Hannifin
59600-5007	Solenoid Valve	Parker Hannifin
59600-5008	Solenoid Valve	Parker Hannifin
59600-5009	Solenoid Valve	Parker Hannifin
59600-5010	Solenoid Valve	Parker Hannifin
59600-5011	Solenoid Valve	Parker Hannifin
5960-101-00-13	Brake Temperature Monitor Unit	Thales Avionics
5961892-5001	Stairway Cylinder	Douglas
5-97613-3009	Rudder Controls Jackshaft	Boeing
5-97613-3010	Rudder Controls Jackshaft	Boeing
5-97613-3011	Rudder Controls Jackshaft	Boeing
5-97613-3012	Rudder Controls Jackshaft	Boeing
5-97613-3013	Rudder Controls Jackshaft	Boeing
5-97613-3014	Rudder Controls Jackshaft	Boeing

Repair_Capability_List_Excel

5-97613-3017	Rudder Controls Jackshaft	Boeing
5-97613-3018	Rudder Controls Jackshaft	Boeing
5-97613-3019	Rudder Controls Jackshaft	Boeing
5-97613-3020	Rudder Controls Jackshaft	Boeing
59793	Pressure Differential Indicator	Hamilton Sundstrand
598420CL2	Valve assy	.
59880	Pressure Differential Indicator	Hamilton Sundstrand
598MK1	Elevator Feel Simulator	Goodrich Control Systems
5A2901-1	Aspirator	Goodrich Aerospace
5A2901-2	Aspirator	Goodrich Aerospace
5ACA	Clock	Smiths Industries
5XA005032-00	Lighting Controller	Hella
5XA005032-01	Lighting Controller	Hella
5XA005033-00	Lighting Controller	Hella
5XA005224-00	Lighting Controller	Hella
5XA005382-00	Lighting Controller	Hella
5XA005385-00	Lighting Controller	Hella
6000001-4	A/S Control Unit	ABS
6000001-5	A/S Control Unit	ABS
6000001-7	A/S Control Unit	ABS
6000002-6	Hydraulic Module	ABS
6000002-7	Hydraulic Module	ABS
6000070-3	Shut-Off Valve	ABS
6000071-2	Hydraulic Fuse	ABS
6000174C1A	Transducer	ABS
6000174C1B	Transducer	ABS
6000174C1C	Transducer	ABS
6000177-1	Parking Valve	ABS
6000177-1CIA	Parking Valve	ABS
6000177-1CIB	Parking Valve	ABS
6000177-1CIC	Parking Valve	ABS
6000189	VALVE ASSY	ABSC
6000189-2	VALVE ASSY	ABSC
6000189-3	Solenoid Valve	ABS
6000189-4	Solenoid Valve	ABS
6000745	Manifold	ABS
6000765	Hydraulic Fuse assy	ABS
6000767	MLG Manifold	ABS
6000800-3	Shut-Off Valve	ABS
6000827	Drive Wheel Cap	ABS
600102	Control Box	Goodyear International Corp
6001078	Manifold	ABS
6001102	A/S Control Unit	ABS
6001452	Wheel Speed Sensor	ABS
6001453-1	Drive Cap	ABS
6001535	Coupling	ABS
6002089-1	Brake Temperature Monitor	Aircraft Braking Syst.
6002342-1	Cap assy	Fokker
6002730	Shuttle Valve Module	ABS
6002731-1	Control Valve	ABS
6002732	Pressure Switch	ABS
6002733	Pressure Switch	ABS
6002738-1	Hydraulic Module	ABS
6002739-2	Electrical Control Unit	ABS
6002779-1	Shut-Off Valve	ABS
6002868	Manifold	ABS
6002869	Manifold	ABS
6002881-3	Hydraulic Module	ABS

Repair_Capability_List_Excel

6002881-4	Hydraulic Module	ABS
6002991	Wiring Harness	ABS
6003088	Manifold	ABS
6004123-1	Wheel Speed Sensor	ABS
6004272-3	Skid Control Unit	ABS
6004272-4	Skid Control Unit	ABS
6004272-5	Skid Control Unit	ABS
6004272-6	Skid Control Unit	ABS
6004272-7	Skid Control Unit	ABS
6004273-1	Dual Skid Control Valve	ABS
6004274-1	Dual Skid Control Valve	ABS
6004275-1	Wheel Speed Sensor	ABS
6004275-2	Wheel Speed Sensor	ABS
6004816	A/S Control Unit Test Set	ABS
60055B01	Shut-Off Valve	Liebherr Aerospace
600611-00-504	Heat Controller	Nord-Micro
600611-00-505	Heat Controller	Nord-Micro
600611-00-506	Heat Controller	Nord-Micro
600611-00-600	Heat Controller	Nord-Micro
600611-00-601	Heat Controller	Nord-Micro
600612-00-500	Temperature Sensor	Nord-Micro
600612-00-510	Temperature Sensor	Nord-Micro
600615-00-502	Vent Controller	Nord-Micro
600615-00-503	Vent Controller	Nord-Micro
600615-01-500	Cargo Vent. Controller	Nord-Micro
600615-01-501	Cargo Vent. Controller	Nord-Micro
600622-00-500	Joystick	Nord-Micro
600622-00-501	Joystick	Nord-Micro
600622-00-502	Joystick	Nord-Micro
600622-00-600	Joystick	Nord-Micro
600623-60-601	Controller	Nord-Micro
600623-70-601	Controller	Nord-Micro
600623-70-602	Controller	Nord-Micro
600629-00-500	Control Box	Nord-Micro
600700-00-500	Trim Air Valve	Bavaria A.T.
600700-00-501	Trim Air Valve	Bavaria A.T.
600701-00-500	Trim Valve	Nord-Micro
60-0883-1	Emergency Exit Light	Grimes Aerospace
60-0883-1LB	Emergency Exit Light	Grimes Aerospace
60-0883-3	Emergency Exit Light	Grimes Aerospace
60-0883-3LB	Emergency Exit Light	Grimes Aerospace
60-0890-1	Battery Power Supply	Grimes Aerospace
60-0890-3	Battery Power Supply	Grimes Aerospace
60-0890-5	Battery Power Supply	Grimes Aerospace
600MK1	Screwjack	Goodrich Control Systems
600SE01	Base Contactor	ECE
600SE04A021Y00	Base Contactor	ECE
600SE04A022Y00	Base Contactor	ECE
600SE04A031Y00	Base Contactor	ECE
600SE04A041Y00	Base Contactor	ECE
600SE04A042Y00	Base Contactor	ECE
60-1	Transformer	Auxilec
6010N0001-02	Autoslat Actuator	Vickers
6010N0001-03	Autoslat Actuator	Vickers
6010N0001-04	Autoslat Actuator	Vickers
601200-02	Linear Actuator	Vickers
60121-000-1	Encoding Altimeter	Thales Avionics
60121-001-1	Encoding Altimeter	Thales Avionics

Repair_Capability_List_Excel

6012A-1	Linear Actuator	Vickers
601300-04	Linear Actuator	Eaton Aerospace
601300-05	Linear Actuator	Eaton Aerospace
601300-09	Linear Actuator	Eaton Aerospace
601300-11	Linear Actuator	Eaton Aerospace
60-1321-1	Emergency Exit Light Power Supply	Grimes Aerospace
60-1321-1LB	Emergency Exit Light Power Supply	Grimes Aerospace
60-1321-5	Emergency Exit Light Power Supply	Grimes Aerospace
60-1321-5LB	Emergency Exit Light Power Supply	Grimes Aerospace
60-1321-7	Emergency Exit Light Power Supply	Grimes Aerospace
60-1321-7LB	Emergency Exit Light Power Supply	Grimes Aerospace
6013J0001-01	Linear Actuator	Eaton Aerospace
6013K0001-01	Linear Actuator	Eaton Aerospace
6013L0001-01	Linear Actuator	Eaton Aerospace
60160	Press Fuelling Shut-Off Valve	Argo-Tech
60160-1	Press Fuelling Shut-Off Valve	Argo-Tech
60160-2	Press Fuelling Shut-Off Valve	Argo-Tech
60160-4	Press Fuelling Shut-Off Valve	Argo-Tech
60160-5	Press Fuelling Shut-Off Valve	Argo-Tech
60160-55	Press Fuelling Shut-Off Valve	Argo-Tech
60160-7	Press Fuelling Shut-Off Valve	Argo-Tech
60-1750-3	Flashtube Power Supply	Grimes Aerospace
60-1750-7	Flashtube Power Supply	Grimes Aerospace
601MK1	Screwjack	Goodrich Control Systems
602	Temperature Indicator	Weston Aerospace
602000-20	Cargo Door Actuator	HR Textron
602000-21	Cargo Door Actuator	HR Textron
602000-22	Cargo Door Actuator	HR Textron
602-09-4-001	Light	Boeing
602260005	Gearbox	Dowty Aerospace
602260006	Gearbox	Dowty Aerospace
6023100-1	Spoiler Actuator	Scot
6023100-2	Spoiler Actuator	Scot
602600-01	Cargo Door Latch Actuator	Eaton Aerospace
6026C0001-01	Cargo Door Latch Actuator	Vickers
6026D0001-01	Cargo Door Actuator	Vickers
6026E0001-01	Cargo Door Actuator	Vickers
6026F0001-01	Cargo Door Latch Actuator	Eaton Aerospace
6032H0101	Cooling Air Valve	Liebherr Aerospace
60-3368-7	Strobe Light Power Supply	Grimes Aerospace
603MK1	Screwjack	Goodrich Control Systems
60-4028-1	Power Supply	Grimes Aerospace
60-4065-1	Power Step Down Transformer	Grimes Aerospace
60-4068-1	Emergency Exit Light Power Supply	Grimes Aerospace
60-4068-1LB	Emergency Exit Light Power Supply	Grimes Aerospace
60470	Thrust Reverser Actuator	Eaton Aerospace
60-4915-1	Battery Power Supply	Grimes Aerospace
604-ECU/1	Temperature Control Amplifier	Smiths Industries
604MK1	Screwjack	Goodrich Control Systems
605290-1-1	Fan	Honeywell
605290-3-1	Fan	Honeywell
605290-3-2	Fan	Honeywell
605290-4-1	Fan	Honeywell
605290-4-2	Fan	Honeywell
605457-2	Fan	Honeywell
605457-3	Fan	Honeywell
605457-7	Fan	Honeywell
605457-8	Fan	Honeywell

Repair_Capability_List_Excel

605675-1	Vaneaxial Fan	Honeywell
605675-2	Vaneaxial Fan	Honeywell
60571-120-1	Transducer	Thales Avionics
605827-1	Driven Vane Axial Motor Fan	Honeywell
60592	Reservoir	Aircruiser
6064	Actuator	Aviac
6064-1	Actuator	Aviac
6064-2	Actuator	Aviac
606515-1	Vacuum Blower By-pass Valve	Honeywell
606622-00-502	JOYSTICK	NORD MICRO
606622-1	Cabin Air Recirculation Fan	Honeywell
606622-2	Cabin Air Recirculation Fan	Honeywell
606622-3	Cabin Air Recirculation Fan	Honeywell
606622-4	Cabin Air Recirculation Fan	Honeywell
606707-1	Fan	Honeywell
606772-1	Fan	Honeywell
606772-2	Fan	Honeywell
606772-3	Fan	Honeywell
606802-2	Waste System Vacuum Blower	Honeywell
6068-1	Actuator	Aviac
606850-1	Motor Driven Fan	Honeywell
606850-2	Motor Driven Fan	Honeywell
607.ECU/1	Temperature Control Amplifier	Smiths Industries
6070148-1	Compartment Temp Sensor	Honeywell
607148-1-1	Temperature Sensor	Honeywell
607148-2	Temperature Sensor	Honeywell
607148-2-1	Temperature Sensor	Honeywell
607148-3	Temperature Sensor	Honeywell
607152-1-1	Temperature Selector	Honeywell
60730-000-1	Mach Transducer	Thales Avionics
607300-1-1	Temp Sensor	Honeywell
607300-2	Temp Sensor	Honeywell
607300-2-1	Sensor	Goodrich Control Systems
607400-1	Temp Selector	Honeywell
607400-1-1	Temperature Selector	Honeywell
607400-2	Temp Selector	Honeywell
607400-2-1	Temperature Selector	Honeywell
607400-3-1	Temperature Selector	Honeywell
607510-2	Temperature Control	Honeywell
607510-2 S3	Temp Cont	Honeywell
607510-3	Temperature Control	Honeywell
607510-3S2	Temperature Control	Honeywell
607512-1	Anticipator Temp Sensor	Honeywell
607518-2	Temperature Control	Honeywell
607518-2S2	Temperature Control	Honeywell
607518-2S3	Temperature Control	Honeywell
607518-2S4	Temperature Control	Honeywell
60-755	Fuel Booster Pump	Hydro-Aire
60-75501	Fuel Booster Pump	Hydro-Aire
60-75501-1	Fuel Booster Pump	Hydro-Aire
60-75502	Housing	Hydro-Aire
60-75503	Fuel Booster Pump	Hydro-Aire
60-75503-1	Fuel Booster Pump	Hydro-Aire
60-75504	Fuel Booster Pump	Hydro-Aire
60-755-1	Fuel Booster Pump	Hydro-Aire
60-755100	Fuel Booster Pump	Hydro-Aire
60-755100-2	Fuel Booster Pump	Hydro-Aire
60-755-2	Fuel Booster Pump	Hydro-Aire

Repair_Capability_List_Excel

607616-1	Temperature Selector	Honeywell
607618-1	Temperature Selector	Honeywell
607690-1	Emergency Locator Xmtr	Honeywell
607690-2	Emergency Locator Xmtr	Honeywell
607690-5	Emergency Locator Xmtr	Honeywell
607698-2	Static Inverter	Honeywell
607698-2-1	Static Inverter	Honeywell
607700-1	Actuator	HR Textron
607700-2	Actuator	HR Textron
608048	Temp Controller	Honeywell
60-847-1A	Booster Pump	Hydro-Aire
60-847-2	Booster Pump	Hydro-Aire
60-847-3	Booster Pump	Hydro-Aire
60896-3	Accumulator	Teledyne
60896-4	Accumulator	Teledyne
60896-5	Accumulator	Teledyne
60944-1	Accumulator	Parker Hannifin
60944-2	Accumulator	Parker Hannifin
60946-3	Accumulator	Parker Hannifin
60946-4	Accumulator	Parker Hannifin
60946-5	Accumulator	Parker Hannifin
60B00021-9	Pressure Switch	Consolidated Controls
60-B00143-101	TEMP INDICATOR	SMITHS
60-B00143-109	TEMP INDICATOR	SMITHS
60-B00143-113	TEMP INDICATOR	SMITHS
60-B00143-19	TEMP INDICATOR	SMITHS
60-B00143-2	TEMP INDICATOR	SMITHS
60-B00143-31	TEMP INDICATOR	SMITHS
60-B00143-32	TEMP INDICATOR	SMITHS
60-B00143-37	TEMP INDICATOR	SMITHS
60B00223-1	STEERING ACTUATOR	SMITHS
60B00223-2	STEERING ACTUATOR	SMITHS
60B00256-10	Hydraulic Pump	Parker Hannifin
60B40031-10	Valve assy	Boeing
60B40031-11	Valve assy	Boeing
60B40031-12	Valve assy	Boeing
60B40031-4	Valve assy	Boeing
61	Lighting Transformer	Auxilec
610010004	Alternator	Dowty Aerospace
610020004	Corrector Motor	Dowty Aerospace
610020008	Corrector Motor	Dowty Aerospace
61013-387-1	APU Oil Quantity Indicator	Thales Avionics
61013-397-2	APU Exhaust Gas Temp. Indicator	Thales Avionics
61014-398-2	APU N1 N2 Indicator	Thales Avionics
61040-102	Artificial Feel Computer	Thales
610SE01	Base Contactor	ECE
610SE04A032Y00	Base Contactor	ECE
610SE04A042Y00	Base Contactor	ECE
611-2A1	Transmitter	Smiths Industries
61163	Fuel Valve	J.C. Carter
61322-091-2	Encoding Altimeter	Thales Avionics
61322-610-1	Altitude Repeater	Thales Avionics
6137-3	Rudder Trim Actuator	Aviac
6137-4	Rudder Trim Actuator	Aviac
6-1404-0000-4	Hydraulic Hand Pump	AEG
6-1404-0102-4	Hydraulic Pump Handle	AEG
61-47-1	Ballast	Day-Ray Products
61472-404-1	N2 Indicator	Thales Avionics

Repair_Capability_List_Excel

61472-404-2	N2 Indicator	Thales Avionics
614937-5	Compass Rack	Sperry
614937-9	Compass Rack	Sperry
615000-1001	Actuator	Parker Hannifin
615000-1002	Actuator	Parker Hannifin
615035	Compass Amplifier	Sperry
61531-000-1	Indicator Temp	Thales Avionics
61531-005-1	Indicator Temp	Thales Avionics
61531-006-1	Indicator Temp	Thales Avionics
61531-007-1	Indicator Temp	Thales Avionics
615401	Gyroscopic Horizon Indicator	Sperry
615401-2	Gyroscopic Horizon Indicator	Sperry
61550-000-3	Flap & Slat Position Indicator	Thales Avionics
61550-000-4	Flap & Slat Position Indicator	Thales Avionics
61550-000-5	Flap & Slat Position Indicator	Thales Avionics
61550-000-6	Flap & Slat Position Indicator	Thales Avionics
61550-000-7	Flap & Slat Position Indicator	Thales Avionics
61550-001-2	Flap & Slat Position Indicator	Thales Avionics
61550-001-4	Flap & Slat Position Indicator	Thales Avionics
61550-001-5	Flap & Slat Position Indicator	Thales Avionics
61550-001-6	Flap & Slat Position Indicator	Thales Avionics
61550-001-7	Flap & Slat Position Indicator	Thales Avionics
61550-007-1	Flap & Slat Position Indicator	Thales Avionics
61550-007-2	Flap & Slat Position Indicator	Thales Avionics
61550-007-3	Flap & Slat Position Indicator	Thales Avionics
61551-101-1	Flap & Slat Position Indicator	Thales Avionics
61551-101-2	Flap & Slat Position Indicator	Thales Avionics
616530	Compressor Bleed Valve	Pratt & Whitney
617002-1-1	Temperature Control Box	Honeywell
617002-2-1	Temperature Control Box	Honeywell
617004-1-1	Temperature Sensor	Honeywell
617166-1	Temp Sensor	Honeywell
617502-1	Sensor	Honeywell
617508-1	Sensor	Honeywell
617510-1	Temperature Control Selector	Honeywell
617512-3	Temp Control Unit	Honeywell
617786-2	Sensor	Honeywell
617852-1	Temperature Control Selector	Honeywell
617924-3	Control assy	Honeywell
618-24-4	Clock	Wakmann Watch
618-24-6-10	Clock	Wakmann Watch
6197	Hydraulic Volumetric Fuse	PneuDrualics
6197- 1	Hydraulic Volumetric Fuse	PneuDrualics
6197-1	Rudder Trim Actuator	Aviac
6197-2	Rudder Trim Actuator	Aviac
61A	Lighting Transformer	Auxilec
620914	Drain Valve assy	Monogram Systems
620SE01	Base Contactor	ECE
620SE01Y1	Base Contactor	ECE
6210-20173-1	Sensor	Nord-Micro
621396211	Standby Compass	Thales Avionics
621396221	Standby Compass	Thales Avionics
621396231	Standby Compass	Thales Avionics
622-0277-001	Antenna Coupler	Rockwell-Collins
622-0277-002	Antenna Coupler	Rockwell-Collins
622-0965-003	Trim Servo	Rockwell-Collins
622-1181-001	VHF Comm Transceiver	Rockwell-Collins
622-1181-002	VHF Comm Transceiver	Rockwell-Collins

Repair_Capability_List_Excel

622-1181-003	VHF Comm Transceiver	Rockwell-Collins
622-1181-004	VHF Comm Transceiver	Rockwell-Collins
622-1181-010	VHF Comm Transceiver	Rockwell-Collins
622-1334-002	VHF Comm Transceiver	Rockwell-Collins
622-1396-001	VHF Comm Transceiver	Rockwell-Collins
622-1396-002	VHF Comm Transceiver	Rockwell-Collins
622-1396-101	VHF Comm Transceiver	Rockwell-Collins
622176-2	Temperature Controller	Honeywell
622-1879-001	VHF Comm Transceiver	Rockwell-Collins
622-1879-002	VHF Comm Transceiver	Rockwell-Collins
622199	Hydraulic Motor Pump	Vickers
622-2224-001	ATC Transponder	Rockwell-Collins
622-2224-002	ATC Transponder	Rockwell-Collins
622-2224-003	ATC Transponder	Rockwell-Collins
622-2224-101	ATC Transponder	Rockwell-Collins
622-2224-201	ATC Transponder	Rockwell-Collins
622-3255-001	VHF Navigation Receiver	Rockwell-Collins
622-3255-002	VHF Navigation Receiver	Rockwell-Collins
622-3255-003	VHF Navigation Receiver	Rockwell-Collins
622-3257-001	VHF Navigation Receiver	Rockwell-Collins
622-3259-001	VHF Navigation Receiver	Rockwell-Collins
622-3259-002	VHF Navigation Receiver	Rockwell-Collins
622-3259-003	VHF Navigation Receiver	Rockwell-Collins
622-3259-004	VHF Navigation Receiver	Rockwell-Collins
622-3259-005	VHF Navigation Receiver	Rockwell-Collins
622-3372-001	HF Transceiver	Rockwell-Collins
622362	Power Transfer Hydraulic Motorpump	Vickers
622-4096-001	Amplifier	Rockwell-Collins
622-4096-002	Amplifier	Rockwell-Collins
622-4096-003	Amplifier	Rockwell-Collins
622-4298-001	Horizontal Situation Indicator	Rockwell-Collins
622-4487-001	PA AMPLIFIER	COLLINS
622-4540-001	Interrogator DME	Rockwell-Collins
622-4540-002	Interrogator DME	Rockwell-Collins
622-4540-020	DME Interrogator	Rockwell-Collins
622-4540-021	Interrogator DME	Rockwell-Collins
622-4540-022	DME Interrogator	Rockwell-Collins
622-4540-023	Interrogator DME	Rockwell-Collins
622-4540-120	Interrogator DME	Rockwell-Collins
622-4540-121	Interrogator DME	Rockwell-Collins
622-4540-122	Interrogator DME	Rockwell-Collins
622-4540-123	Interrogator DME	Rockwell-Collins
622-4717-003	Mode Control Panels	Rockwell-Collins
622-4717-004	Mode Control Panels	Rockwell-Collins
622492-1	Temperature Selector	Honeywell
622496-1	Temperature Selector	Honeywell
622-5001-104	Radio Distance Magnetic Indicator	Rockwell-Collins
622-5001-106	Radio Distance Magnetic Indicator	Rockwell-Collins
622-5001-107	Radio Distance Magnetic Indicator	Rockwell-Collins
622-5001-108	Radio Distance Magnetic Indicator	Rockwell-Collins
622-5001-109	Radio Distance Magnetic Indicator	Rockwell-Collins
622-5001-110	Radio Distance Magnetic Indicator	Rockwell-Collins
622-5001-111	Radio Distance Magnetic Indicator	Rockwell-Collins
622-5001-112	Radio Distance Magnetic Indicator	Rockwell-Collins
622-5001-113	Radio Distance Magnetic Indicator	Rockwell-Collins
622-5001-114	Radio Distance Magnetic Indicator	Rockwell-Collins
622-5001-701	Radio Magnetic Indicator	Rockwell-Collins
622-5002-701	Radio Magnetic Indicator	Rockwell-Collins

Repair_Capability_List_Excel

622-5139-001	Attitude Director Indicator	Rockwell-Collins
622-5139-002	Attitude Director Indicator	Rockwell-Collins
622-5139-003	Attitude Director Indicator	Rockwell-Collins
622-5139-004	Attitude Director Indicator	Rockwell-Collins
622-5219-001	VHF Communication Transceiver	Rockwell-Collins
622-5219-002	VHF Communication Transceiver	Rockwell-Collins
622-5219-003	VHF Communication Transceiver	Rockwell-Collins
622-5219-004	VHF Communication Transceiver	Rockwell-Collins
622-5219-005	VHF Communication Transceiver	Rockwell-Collins
622-5220-001	VOR/ILS Receiver	Rockwell-Collins
622-5220-002	VOR/ILS Receiver	Rockwell-Collins
622-5220-102	VOR/ILS Receiver	Rockwell-Collins
622-5220-103	VOR/ILS Receiver	Rockwell-Collins
622-5221-002	ILS Receiver	Rockwell-Collins
622-5222-001	ADF Receiver	Rockwell-Collins
622-5222-002	ADF Receiver	Rockwell-Collins
622-5222-020	ADF Receiver	Rockwell-Collins
622-5222-102	ADF Receiver	Rockwell-Collins
622-5222-120	ADF Receiver	Rockwell-Collins
622-5222-420	ADF Receiver	Rockwell-Collins
622-5272-001	HF Receiver Transmitter	Rockwell-Collins
622-5272-003	HF Receiver Transmitter	Rockwell-Collins
622-5272-020	HF Receiver Transmitter	Rockwell-Collins
622-5272-023	HF Receiver Transmitter	Rockwell-Collins
622-5272-120	HF Receiver Transmitter	Rockwell-Collins
622532	Hydraulic Power Transfer Unit	Eaton
622-5342-001	Passenger Address Unit	Rockwell-Collins
622-5342-101	Passenger Address Unit	Rockwell-Collins
622-5404-001	ADF Antenna	Rockwell-Collins
622-5404-002	ADF Antenna	Rockwell-Collins
622-5404-003	ADF Antenna	Rockwell-Collins
622-5405-001	ADF Antenna	Rockwell-Collins
622-5432-002	HF Frequency Panel	Rockwell-Collins
622-5446-001	ATC Transponder	Rockwell-Collins
622-5446-002	ATC Transponder	Rockwell-Collins
622-5446-101	ATC Transponder	Rockwell-Collins
622-5446-102	ATC Transponder	Rockwell-Collins
622-5734-002	Servo	Rockwell-Collins
622-5812-001	Flux Valve	Thales Avionics
622-5812-002	Flux Valve	Thales Avionics
622-5812-003	Flux Valve	Thales Avionics
622-5812-004	Flux Valve	Thales Avionics
622-5812-005	Flux Valve	Thales Avionics
622-5812-006	Flux Valve	Thales Avionics
622-6089-101	Display Select Panel	Rockwell-Collins
622-6089-102	Display Select Panel	Rockwell-Collins
622634	Constant Displacement Hydraulic Motor	Vickers
622-6520-003	VHF Control Unit	Rockwell-Collins
622-6521-011	VOR/ILS/DME Control Unit	Rockwell-Collins
622-6522-003	ADF Control Unit	Rockwell-Collins
622-6524-003	DME Indicator	Rockwell-Collins
622-6614-001	HF Control Unit	Rockwell-Collins
622-6614-021	HF Control Unit	Rockwell-Collins
622664-1	Flow Sensor	Honeywell
622-6827-001	HF Frequency Panel	Rockwell-Collins
622-6827-002	HF Frequency Panel	Rockwell-Collins
622-6827-021	HF Frequency Panel	Rockwell-Collins
622-6827-022	HF Frequency Panel	Rockwell-Collins

Repair_Capability_List_Excel

622-6828-001	Transponder Panel	Rockwell-Collins
622-6828-011	Transponder Panel	Rockwell-Collins
622-6828-021	Transponder Panel	Rockwell-Collins
622-6828-022	Transponder Panel	Rockwell-Collins
622-6830-001	ADF Frequency Panel	Rockwell-Collins
622-6830-011	ADF Frequency Panel	Rockwell-Collins
622-6830-021	ADF Frequency Panel	Rockwell-Collins
622-6830-022	ADF Frequency Panel	Rockwell-Collins
622-6831-001	VHF COMM Frequency Panel	Rockwell-Collins
622-6831-002	VHF COMM Frequency Panel	Rockwell-Collins
622-6831-021	VHF COMM Frequency Panel	Rockwell-Collins
622-6831-022	VHF COMM Frequency Panel	Rockwell-Collins
622-7309-101	DME	Rockwell-Collins
622-7477-301	Flight Mode Panel	Rockwell-Collins
622-7477-401	Flight Mode Panel	Rockwell-Collins
622-7477-501	Flight Mode Panel	Rockwell-Collins
622-7477-502	Flight Mode Panel	Rockwell-Collins
622-7480-301	Remote Maintenance Panel	Rockwell-Collins
622-7486-301	Altimeter Select Panel	Rockwell-Collins
622-7925-301	Servo Mounting	Rockwell-Collins
622-7925-302	Servo Mounting	Rockwell-Collins
622-7925-303	Servo Mounting	Rockwell-Collins
622-7925-401	Servo Mounting	Rockwell-Collins
622-7926-301	Servo Mounting	Rockwell-Collins
622-7926-302	Servo Mounting	Rockwell-Collins
622-7926-303	Servo Mounting	Rockwell-Collins
622-7927-104	Servo Mounting	Rockwell-Collins
622-7927-201	Servo Mounting	Rockwell-Collins
622-7927-301	Servo Mounting	Rockwell-Collins
622-8069-301	Servo Mounting	Rockwell-Collins
622-8069-302	Servo Mounting	Rockwell-Collins
622-8069-303	Servo Mounting	Rockwell-Collins
622-8069-304	Servo Mounting	Rockwell-Collins
622-8069-401	Servo Mounting	Rockwell-Collins
622878-1	Duct Air Temp Sensor	Honeywell
622878-2	Duct Air Temperature Sensor	Honeywell
622-9738-220	ILS Receiver	Rockwell-Collins
622-9738-420	ILS Receiver	Rockwell-Collins
623272	Variable Disp.Hydraulic Pump	Vickers
6233	Accelerometer Pick-Up	Endevco
623303	Hydraulic Motor Pump	Vickers
623337	Variable Disp. Hydraulic Pump	Vickers
623339	Variable Disp. Hydraulic Pump	Vickers
623859	Variable Disp.Electric Motorpump	Eaton
623977	Hydraulic Pump	Vickers
623V100-1	Bleed Valve	Midland Ross
623V100-2	Bleed Valve	Midland Ross
624014-1	Pack Temperature Sensor	Honeywell
624014-2	Pack Temperature Sensor	Honeywell
624016-1	Duct Air Temp. Sensor	Honeywell
624016-2	Duct Air Temperature Sensor	Honeywell
624018-1	Cabin Zone Temp Sensor	Honeywell
624066-3	Window Heat Control Unit	Honeywell
624066-4	Window Heat Control Unit	Honeywell
624066-5	Window Heat Control Unit	Honeywell
624284-1	Pack Stand-By Controller	Honeywell
624372	Hydraulic Pump	Vickers
624820-1	Temperature Controller	Honeywell

Repair_Capability_List_Excel

624918-1	Cabin Temperature Control	Honeywell
624958-4	Temperature Control	Honeywell
624MK1	Screwjack	Goodrich Control Systems
625704-1	Temperature Sensor	Honeywell
625704-2	Temperature Sensor	Honeywell
625718-1	Temperature Selector	Honeywell
625868-1	Cabin Zone Temp Selector	Honeywell
625868-1 S1	Temperature Selector	Honeywell
625878-1	Switch	Honeywell
625928-2	Compressor Outlet Temp. Sensor	Honeywell
625928-3	Compressor Outlet Temp Sensor	Honeywell
625946-10	Temperature Control	Honeywell
625946-8	Temperature Control	Honeywell
625946-9	Temperature Control	Honeywell
625994-1	Temperature Sensor	Honeywell
6268-10	Shut-Off Valve	Pneudraulics
6268-12	Shut-Off Valve	Pneudraulics
62702	Position Indicating Switch	Haydon
62702-1	Position Indicating Switch	Haydon
627098-4	Pressure Sensor	Honeywell
627098-5	Pressure sensor	Honeywell
627100-3	Regulator Pressure Sensor	Honeywell
627100-4	Regulator Pressure Sensor	Honeywell
62716	Position Indicating Switch	Haydon
62716-1	Position Indicating Switch	Haydon
62716-2	Position Indicating Switch	Haydon
62716-5	Position Indicating Switch	Haydon
62716-6	Position Indicating Switch	Haydon
62721	Position Indicating Switch	Haydon
62721-1	Position Indicating Switch	Haydon
627248-1	Controller	Honeywell
627248-2	Controller	Honeywell
627248-3	Controller	Honeywell
62726-1	Position Indicating Switch	Haydon
62735	A/C Motor	Parker Hannifin
627396-1	Zone Temperature Controller	Honeywell
62740	Position Indicating Switch	Haydon
627412-2	Sensor	Honeywell
627412-3	Sensor	Honeywell
627416-1	Probe	Honeywell
62742	Position Indicating Switch	Haydon
62742-1	Position Indicating Switch	Haydon
62743	Position Indicating Switch	Haydon
62744	Position Indicating Switch	Haydon
62744-1	Position Indicating Switch	Haydon
62744-3	Position Indicating Switch	Haydon
627562-1	Switch	Honeywell
627570-1	Anticipator Temp Sensor	Honeywell
627962-1	Temperature Sensor	Honeywell
627962-2	Temperature Sensor	Honeywell
628038-1	Temp Cont Test Set	Honeywell
629MK3	Flap Control Unit	Goodrich Control Systems
629MK4	Flap Control Unit	Goodrich Control Systems
630300-04	Rotary Actuator	Eaton Aerospace
630300-05	Rotary Actuator	Eaton Aerospace
630300-06	Rotary Actuator	Eaton Aerospace
63035	Pump & Motor	Abex
63041-05	Hydraulic Motor Pump	Parker Hannifin

Repair_Capability_List_Excel

63041-06	Hydraulic Motor Pump	Parker Hannifin
630500-02	Cargo Door Actuator	Eaton Aerospace
630500-04	Cargo Door Actuator	Eaton Aerospace
630500-06	Cargo Door Actuator	Eaton Aerospace
630500-07	Cargo Door Actuator	Eaton Aerospace
6305J0001-01	Cargo Door Actuator	Eaton Aerospace
630900-01	Rotary Actuator	Eaton Aerospace
630900-02	Self Retracting Powered Roller	Eaton Aerospace
630CC01	Single Pole DC Contactor	ECE
630CC01Y1	Single Pole DC Contactor	ECE
630CC04	Single Pole DC Contactor	ECE
630CC04A1Y00	Single Pole DC Contactor	ECE
630CC04A2Y00	Single Pole DC Contactor	ECE
630MK2	Tail Trim Actuator	Goodrich Control Systems
630MK3	Tail Trim Actuator	Goodrich Control Systems
631500-01	Self Retracting Powered Roller	Eaton Aerospace
631500-02	Spring Loaded Powered Roller	Eaton Aerospace
631500-03	Self Retracting Powered Roller	Eaton Aerospace
631500-04	Spring Loaded Powered Roller	Eaton Aerospace
6315E0001-01	Self Retracting Powered Roller	Vickers
6315F0001-01	Self Retracting Powered Roller	Vickers
6315G0001-01	Spring Loaded Powered Roller	Vickers
6315H0001-01	Self Retracting Powered Roller	Vickers
6315J0001-01	Spring Loaded Powered Roller	Vickers
63169	Hydraulic Power Transfer Unit	Parker Hannifin
63178	Generator	Parker
631900-01	Cargo Shuttle Drive Unit	Vickers
6319A0001-02	Cargo Shuttle Drive Unit	Vickers
632002001	Corrector Motor	Dowty Aerospace
6322A0001-02	Passenger Door Actuator	Eaton Aerospace
6322A0001-04	Passenger Door Actuator	Eaton Aerospace
6323A0001-01	Spoiler Controller Actuator	Vickers
6323A0001-02	Spoiler Controller Actuator	Vickers
6329A0001-01	Engine Condition Actuator	Eaton Aerospace
6329B0001-01	Engine Condition Actuator	Eaton Aerospace
6329C0001-01	Engine Condition Actuator	Eaton Aerospace
6329D0001-01	Engine Condition Actuator	Eaton Aerospace
6329E0001-01	Engine Condition Actuator	Eaton Aerospace
6329F0001-01	Engine Condition Actuator	Eaton Aerospace
6331-16639-3	Electronic Box	Nord-Micro
6331-16639-3 Amdt A	Electronic Box	Nord-Micro
6331-16639-4	Electronic Box	Nord-Micro
6333-014-21AOA	Light assy	Messier-Dowty
6338A0001-02	Fuel Shut-Off Control	Eaton Aerospace
6338A0001-03	Fuel Shut-Off Control	Eaton Aerospace
6338A0001-05	Fuel Shut-Off Control	Eaton Aerospace
6338A0001-07	Fuel Shut-Off Control	Eaton Aerospace
6338B0001-02	Fuel Shut-Off Control	Eaton Aerospace
6343-16917	Gearbox	Nord-Micro
6343-16917-1	Gearbox	Nord-Micro
6343-16917-2	Gearbox	Nord-Micro
6343-20209	Gearbox	Nord Micro
634995	Compressor Bleed Valve	Pratt & Whitney
635	Temperature Indicator	Weston Aerospace
6350-01	Fire & Overheat Detector	Whittaker
6350-02	Fire & Overheat Detector	Whittaker
6350-03	Fire & Overheat Detector	Whittaker
6351A0001-01	Powered Roller Turntable	Eaton Aerospace

Repair_Capability_List_Excel

6351A0001-02	Powered Roller Turntable	Eaton Aerospace
6351A0001-03	Powered Roller Turntable	Eaton Aerospace
6351A0001-04	Powered Roller Turntable	Eaton Aerospace
6351A0001-05	Powered Roller Turntable	Eaton Aerospace
6351A0001-06	Powered Roller Turntable	Eaton Aerospace
63540-031-2	RMI ADF Indicator	Thales Avionics
63540-040-1	RMI ADF Indicator	Thales Avionics
63540-041-2	RMI ADF	Thales Avionics
63540-156-2	RMI VOR DME Indicator	Thales Avionics
63540-156-3	RMI VOR DME Indicator	Thales Avionics
63540-170-2	RMI VOR DME Indicator	Thales Avionics
63543-270-1	Distance Bearing Indicator	Thales Avionics
63543-280-1	Distance Bearing Indicator	Thales Avionics
63543-280-2	Distance Bearing Indicator	Thales Avionics
6355B0001-01	Stabilizer Trim Motor	Eaton Corp
6355B0001-02	Stabilizer Trim Motor	Eaton Corp
6355B0001-03	Stabilizer Trim Motor	Eaton Corp
6355C0001-01	Stabilizer Trim Motor	Eaton Corp
6356A0001-02	Power Drive Unit	Eaton Aerospace
6356B0001-02	Power Drive Unit	Eaton Aerospace
63600-050-2	Fuel Flow Indicator	Thales Avionics
63600-051-2	Fuel Flow Indicator	Thales Avionics
63600-051-3	Fuel Flow Indicator	Thales Avionics
63600-250-2	EGT Indicator	Thales Avionics
63600-251-2	EGT Indicator	Thales Avionics
63600-252-2	EGT Indicator	Thales Avionics
63600-253-2	EGT Indicator	Thales Avionics
63600-254-1	EGT Indicator	Thales Avionics
63600-255-1	EGT Indicator	Thales Avionics
63600-257-1	EGT Indicator	Thales Avionics
63600-258-1	EGT Indicator	Thales Avionics
63600-259-1	EGT Indicator	Thales Avionics
63600-260-1	EGT Indicator	Thales Avionics
63600-261-1	EGT Indicator	Thales Avionics
63600-270-2	EGT Indicator	Thales Avionics
63600-271-1	EGT Indicator	Thales Avionics
63600-280-1	EGT Indicator	Thales Avionics
63600-450-2	N1 Indicator	Thales Avionics
63600-451-2	N2 Indicator	Thales Avionics
63600-452-2	N2 Indicator	Thales Avionics
63600-453-2	N2 Indicator	Thales Avionics
63600-454-1	N2 Indicator	Thales Avionics
63600-455-1	N2 Indicator	Thales Avionics
63600-456-1	N1 Indicator	Thales Avionics
63600-456-2	N1 Indicator	Thales Avionics
63600-457-1	N2 Indicator	Thales Avionics
63600-458-1	Indicator	Thales Avionics
63600-459-1	Indicator	Thales Avionics
63601-450-2	Indicator	Thales Avionics
63601-451-1	Indicator	Thales Avionics
63601-460-1	Indicator	Thales Avionics
63601-650-2	EPR Indicator	Thales Avionics
63601-651-1	EPR Indicator	Thales Avionics
63604-210-1	ITT Indicator	Thales Avionics
63604-210-2	ITT Indicator	Thales Avionics
63604-410-2	N1 Indicator	Thales Avionics
63604-410-3	N1 Indicator	Thales Avionics
6361-16639-5	Electronic Box	Nord-Micro

Repair_Capability_List_Excel

6361-16639-6	Electronic Box	Nord-Micro
63940	Valve assy	Sterer
63950	Valve assy	Sterer
63B12087-1	Trailing Edge Flap Drive	Boeing
63B12087-2	Transmission assy	Boeing
64040-560-1	Airspeed Indicator	Thales Avionics
64040-800-1	Standby Airspeed Indicator	Thales Avionics
64040-860-1	Airspeed Indicator	Thales Avionics
64040-861-1	Airspeed Indicator	Thales Avionics
64040-862-1	Airspeed Indicator	Thales Avionics
64040-863-1	Airspeed Indicator	Thales Avionics
64050-660-1	Airspeed Indicator	Thales Avionics
64050-661-1	Airspeed Indicator	Thales Avionics
64050-662-1	Airspeed Indicator	Thales Avionics
64050-663-1	Airspeed Indicator	Thales Avionics
64050-802-1	Anemometer	Thales Avionics
64050-860-1	Airspeed Indicator	Thales Avionics
64050-862-1	Airspeed Indicator	Thales Avionics
64050-866-1	Airspeed Indicator	Thales Avionics
64050-868-1	Airspeed Indicator	Thales Avionics
64060-890-1	Max.Allow A/S Indicator	Thales Avionics
64089-360-1	Vertical Speed Indicator	Thales Avionics
640CC01	Single Pole DC Contactor	ECE
640CC01Y1	Single Pole DC Contactor	ECE
640CC04A2Y00	Single Pole DC Contactor	ECE
641100-1	Thermostatic Switch	Honeywell
641100-2	Thermostatic Switch	Honeywell
641109-1	Thermal Switch	Honeywell
641109-2	Thermal Switch	Honeywell
641109-3	Thermal Switch	Honeywell
641109-4	Thermal Switch	Honeywell
641109-5	Thermal Switch	Honeywell
64111-301-1	Encoding Altimeter	Thales
64111-790-1	Encoding Counter/Pointer Altimeter	Thales Avionics
64111-900-1	Counter/Pointer Altimeter	Thales Avionics
64111-950-1	Counter/Pointer Altimeter	Thales Avionics
64111-951-1	Counter/Pointer Altimeter	Thales Avionics
64111-960-1	Counter/Pointer Altimeter	Thales Avionics
64111-990-2	Counter/Pointer Altimeter	Thales Avionics
64111-992-1	Counter/Pointer Altimeter	Thales Avionics
641121-1	Overheat Zone Duct Switch	Honeywell
641127-1	Pack Overheat Switch	Honeywell
641134-3	Overtemperature Switch	Honeywell
641134-4	Overtemperature Switch	Honeywell
641137-1	Compressor Disch Overheat Switch	Honeywell
641172-1	Pack Disch Overheat Switch	Honeywell
64131-560-1	Standby Altimeter	Thales Avionics
64131-760-1	Standby Altimeter	Thales Avionics
64141-360-1	Standby Altimeter	Thales Avionics
64141-362-1	Standby Altimeter	Thales Avionics
64141-370-1	Standby Altimeter	Thales Avionics
64141-372-1	Standby Altimeter	Thales Avionics
64141-564-1	Indicator	Thales Avionics
64141-580-1	Indicator	Thales Avionics
64141-582-1	Indicator	Thales Avionics
64141-590-1	Indicator	Thales Avionics
64161-230-1	Indicator	Thales Avionics
64161-233-1	Counter Pointer Altimeter	Thales

Repair_Capability_List_Excel

64161-234-1	Indicator	Thales Avionics
64161-237-1	Indicator	Thales Avionics
64250-005-1	Hydraulic Pressure Transmitter	Thales Avionics
64250-005-2	Hydraulic Pressure Transmitter	Thales Avionics
64250-043-1	Hydraulic Pressure Transmitter	Thales Avionics
64251-204-1	Pressure Transmitter	Thales Avionics
64251-205-1	Pressure Transmitter	Thales Avionics
643-24-101	Clock	Wakmann Watch
64400-000	Headset	Telex Com
6445	Control Card assy	Meggitt
6445-01	Control Card assy	Meggitt
645055-1	Fan	Honeywell
645055-2	Fan	Honeywell
645055-3	Fan	Honeywell
645150-1	Vacuum Generator	Honeywell
645150-2	Vacuum Generator	Honeywell
645150-4	Vacuum Generator	Honeywell
645150-5	Vacuum Generator	Honeywell
645405-1	Cabin Air Recirculation Fan	Honeywell
645405-2	Cabin Air Recirculation Fan	Honeywell
645670-1	Motor Driven Fan	Honeywell
645705-1	Recirculation Fan	Honeywell
645705-2	Recirculation Fan	Honeywell
645705-3	Recirculation Fan	Honeywell
645940-1	Cabin Recirculation Fan	Honeywell
64660-506-1	Sensor	Thales Avionics
64752-003-1	Gauge Transmitter	Thales Avionics
64752-004-1	Gauge Transmitter	Thales Avionics
64752-005-2	Gauge Transmitter	Thales Avionics
64752-006-1	Gauge Transmitter	Thales Avionics
64752-007-1	Gauge Transmitter	Thales Avionics
64752-008-2	Gauge Transmitter	Thales Avionics
64752-015-1	Gauge Transmitter	Thales Avionics
64752-016-1	Gauge Transmitter	Thales Avionics
64752-017-1	Gauge Transmitter	Thales Avionics
64752-018-1	Gauge Transmitter	Thales Avionics
64752-019-1	Gauge Transmitter	Thales Avionics
64752-020-1	Gauge Transmitter	Thales Avionics
64752-023-1	Gauge Transmitter	Thales Avionics
64752-026-1	Gauge Transmitter	Thales Avionics
64752-075-1	Gauge Transmitter	Sextant Avionique
64757-138-1	Gauge Transmitter	Thales Avionics
64757-138-3	Gauge Transmitter	Thales Avionics
64757-138-4	Gauge Transmitter	Thales Avionics
64757-138-5	Gauge Transmitter	Thales Avionics
64757-139-1	Gauge Transmitter	Thales Avionics
64757-139-3	Gauge Transmitter	Thales Avionics
64757-139-4	Gauge Transmitter	Thales Avionics
64757-139-5	Gauge Transmitter	Thales Avionics
64757-140-1	Gauge Transmitter	Thales Avionics
64757-140-3	Gauge Transmitter	Thales Avionics
64757-140-4	Gauge Transmitter	Thales Avionics
64757-140-5	Gauge Transmitter	Thales Avionics
64801-006-1	Pressure Indicator	Thales Avionics
64801-018-1	Pressure Indicator	Thales Avionics
64801-024-1	Pressure Indicator	Thales Avionics
64809-401-2	Oil Pressure Indicator	Thales Avionics
64820-408-1	Fuel Pressure Indicator	Thales Avionics

Repair_Capability_List_Excel

64820-409-1	Oil Pressure Indicator	Thales Avionics
64820-410-1	Fuel Pressure Indicator	Thales Avionics
64820-411-1	Oil Pressure Indicator	Thales Avionics
64820-418-1	Oil Pressure Indicator	Thales Avionics
64820-420-1	Oil Pressure Indicator	Thales Avionics
64822-421-1	Nacelle Temperature Indicator	Thales Avionics
64822-424-1	Oil Indicator	Thales Avionics
64822-425-1	RPM Indicator	Thales Avionics
64822-426-1	EGT Indicator	Thales Avionics
64822-430-1	Nacelle Temperature Indicator	Thales Avionics
64857-407-1	Pack/Turbine Temperature Indicator	Thales Avionics
64857-412-1	Fuel Temperature Indicator	Thales Avionics
64878-000-1	Brake Indicator	Thales Avionics
64880-400-2	INDICATOR	SEXTANT AVIOMIQUE
64880-403-2	Press/Qty Oil Indicator	Thales Avionics
64880-413-1	Differential Pressure Oil Filter Indicator	Thales Avionics
64880-415-1	Oil Quantity Indicator	Thales Avionics
64880-418-1	Oil Quantity Indicator	Thales Avionics
64880-419-1	Dual Oil Quantity Indicator	Thales Avionics
64880-420-1	Press/Qty Oil Indicator	Thales Avionics
64882-202-1	Hydraulic Pressure Indicator	Thales Avionics
64882-203-1	Hydraulic Pressure Indicator	Thales Avionics
64882-206-1	Brake Pressure Indicator	Thales Avionics
64882-407-1	OIL TEMP IND	THOMSON CSF
64882-408-1	OIL INDICATOR	THOMSON CSF
64882-409-1	OIL TEMP IND	THOMSON CSF
64882-413-1	OIL INDICATOR	THOMSON CSF
64882-420-1	OIL INDICATOR	THOMSON CSF
64882-428-1	OIL INDICATOR	THOMSON CSF
64882-433-1	OIL INDICATOR	THOMSON CSF
64882-900-1	TEMP INDICATOR	SEXTANT AVIOMIQUE
64891-001-1	Position Indicator	Thales Avionics
64891-002-1	Position Indicator	Thales Avionics
64891-002-2	Position Indicator	Thales Avionics
64891-002-3	Position Indicator	Thales Avionics
64891-002-4	Position Indicator	Thales Avionics
64901-005-1	Position Indicator	Thales Avionics
64901-006-1	Trim Air Valve Position Indicator	Thales Avionics
64902-001-1	Air Conditionning Pack Indicator	Thales Avionics
64902-002-2	Quantity Indicator	Thales Avionics
64902-003-2	Hydraulic Quantity Indicator	Thales Avionics
64902-004-2	Hydraulic Quantity Indicator	Thales Avionics
64902-012-1	Quantity Indicator	Thales Avionics
64902-013-1	Quantity Indicator	Thales Avionics
64902-014-1	Quantity Indicator	Thales Avionics
64902-015-1	Quantity Indicator	Thales Avionics
64902-016-1	Quantity Indicator	Thales Avionics
64902-051-1	Pack Indicator	Thales Avionics
64902-052-1	Quantity Indicator	Thales Avionics
64902-053-1	Quantity Indicator	Thales Avionics
64902-054-1	Quantity Indicator	Thales Avionics
64902-055-1	Quantity Indicator	Thales Avionics
64902-056-1	Quantity Indicator	Thales Avionics
64902-057-1	Quantity Indicator	Thales Avionics
64902-062-1	Quantity Indicator	Thales Avionics
64902-063-1	Quantity Indicator	Thales Avionics
64902-064-1	Quantity Indicator	Thales Avionics
64902-065-1	Quantity Indicator	Thales Avionics

Repair_Capability_List_Excel

64902-067-1	Quantity Indicator	Thales Avionics
64902-100-1	Quantity Indicator	Thales Avionics
64902-101-1	Quantity Indicator	Thales Avionics
64952-001-1	Temperature Indicator	Thales Avionics
64952-002-2	Pack Outlet Temperature Indicator	Thales Avionics
64952-004-2	Turbine Inlet Temperature Indicator	Thales Avionics
64953-026-1	Speed Ground Indicator	Thales Avionics
64WE07501	Hydraulic Pump	Dynapower
65001	Hydraulic Pump	Parker Hannifin
65001-01	Hydraulic Pump	Parker Hannifin
65001-02	Hydraulic Pump	Parker Hannifin
65001-03	Hydraulic Pump	Parker Hannifin
65066-05	Pump assy	Abex
65066-06	Pump assy	Abex
65075-01	Hydraulic Pump	Parker Hannifin
65075-02	Hydraulic Pump	Parker Hannifin
65075-03	Hydraulic Pump	Parker Hannifin
65075-04	Hydraulic Pump	Parker Hannifin
65075-05	Hydraulic Pump	Parker Hannifin
65075-06	Hydraulic Pump	Parker Hannifin
650CC01	Single Pole DC Contactor	ECE
65-11711-11	Thrust Reverser Actuator assy	Boeing
65-11711-14	Thrust Reverser Actuator assy	Boeing
65-11711-5	Thrust Reverser Actuator assy	Boeing
65-11711-6	Thrust Reverser Actuator assy	Boeing
65-11711-7	Thrust Reverser Actuator assy	Boeing
65-11711-8	Thrust Reverser Actuator assy	Boeing
651300-07	Rotary Actuator	Vickers
651300-08	Rotary Actuator	Vickers
65139-02	Ram Air Turbine Pump	Parker Hannifin
65-14106-1	Landing Gear Hyd.Transfer Cylinder	Boeing
65-14106-2	Landing Gear Hyd.Transfer Cylinder	Boeing
65-14106-3	Landing Gear Hyd.Transfer Cylinder	Boeing
65-14106-4	Landing Gear Hyd.Transfer Cylinder	Boeing
65-14106-5	Landing Gear Hyd.Transfer Cylinder	Boeing
65-14106-6	Landing Gear Hyd.Transfer Cylinder	Boeing
65-14106-7	Landing Gear Hyd.Transfer Cylinder	Boeing
65-1754-4	Landing Gear Control Lever	Boeing
65-1754-5	Landing Gear Control Lever	Boeing
65-1754-6	Landing Gear Control Lever	Boeing
65-1754-7	Landing Gear Control Lever	Boeing
65-17568-1	Door Mechanism	Boeing
65-17809-1	Door Actuator	Boeing
65-17810-11	Lock Actuator	Boeing
65-17810-5	Lock Actuator	Boeing
65-17812-10	Actuator	Boeing
65-17812-12	Actuator	Boeing
65-17812-13	Actuator	Boeing
65-17812-9	Actuator	Boeing
65-17813-2	Actuator	Boeing
65-17814-10	Steering Cylinder	Boeing
65-17814-12	Steering Cylinder	Boeing
65-17815-1	Hydraulic Reservoir	Boeing
65-17818-12	Actuator	Boeing
65-17818-14	Actuator	Boeing
65-17818-19	Actuator	Boeing
65-17818-20	Actuator	Boeing
65-17818-22	Actuator	Boeing

Repair_Capability_List_Excel

65-17818-23	Actuator	Boeing
65-17819-1	Main Gear Lock Actuator	Boeing
65-17819-10	Main Gear Lock Actuator	Boeing
65-17819-11	Main Gear Lock Actuator	Boeing
65-17819-12	Main Gear Lock Actuator	Boeing
65-17819-14	Main Gear Lock Actuator	Boeing
65-17819-15	Main Gear Lock Actuator	Boeing
65-17819-4	Main Gear Lock Actuator	Boeing
65-17819-6	Main Gear Lock Actuator	Boeing
65-17819-7	Main Gear Lock Actuator	Boeing
65-17819-8	Main Gear Lock Actuator	Boeing
65-17820-1	Actuator	Boeing
65-17820-2	Actuator	Boeing
65-17820-4	Actuator	Boeing
65-17821-1	System A Hydraulic Modular Package	Boeing
65-17821-10	System A Hydraulic Modular Package	Boeing
65-17821-11	System A Hydraulic Modular Package	Boeing
65-17821-12	System A Hydraulic Modular Package	Boeing
65-17821-14	System A Hydraulic Modular Package	Boeing
65-17821-15	System A Hydraulic Modular Package	Boeing
65-17821-17	System A Hydraulic Modular Package	Boeing
65-17821-18	Hydraulic Modular Package	Boeing
65-17821-19	System A Hydraulic Modular Package	Boeing
65-17821-2	System A Hydraulic Modular Package	Boeing
65-17821-20	Hydraulic Modular Package	Boeing
65-17821-21	Hydraulic Modular Package	Boeing
65-17821-3	System A Hydraulic Modular Package	Boeing
65-17821-4	System A Hydraulic Modular Package	Boeing
65-17821-5	System A Hydraulic Modular Package	Boeing
65-17821-6	System A Hydraulic Modular Package	Boeing
65-17821-7	System A Hydraulic Modular Package	Boeing
65-17821-8	System A Hydraulic Modular Package	Boeing
65-17821-9	System A Hydraulic Modular Package	Boeing
65-17822-1	System B Hydraulic Modular Package	Boeing
65-17822-10	System B Hydraulic Modular Package	Boeing
65-17822-2	System B Hydraulic Modular Package	Boeing
65-17822-3	System B Hydraulic Modular Package	Boeing
65-17822-4	System B Hydraulic Modular Package	Boeing
65-17822-5	System B Hydraulic Modular Package	Boeing
65-17822-6	System B Hydraulic Modular Package	Boeing
65-17822-8	System B Hydraulic Modular Package	Boeing
65-17822-9	System B Hydraulic Modular Package	Boeing
65-17823-1	Modular Package	Boeing
65-17823-2	Modular Package	Boeing
65-17823-4	Modular Package	Boeing
65-17823-5	Modular Package	Boeing
65-17826-2	Modular Package	Boeing
65-17826-4	Modular Package	Boeing
65-17826-8	Modular Package	Boeing
65-17826-9	Modular Package	Boeing
65-17830-10	Main Gear Actuator	Boeing
65-17830-12	Main Gear Actuator	Boeing
65-17830-13	Main Gear Actuator	Boeing
65-17830-4	Main Gear Actuator	Boeing
65-17830-7	Main Gear Actuator	Boeing
65-17830-8	Main Gear Actuator	Boeing
65-17832-2	Landing Gear Hyd.Transfer Cylinder	Boeing
65-17832-3	Landing Gear Hyd.Transfer Cylinder	Boeing

Repair_Capability_List_Excel

65-17851-12	System B Hydraulic Modular Package	Boeing
65-17851-27	System B Hydraulic Modular Package	Boeing
65-17851-30	System B Hydraulic Modular Package	Boeing
65-17851-31	System B Hydraulic Modular Package	Boeing
65-17851-33	System B Hydraulic Modular Package	Boeing
65-17851-34	System B Hydraulic Modular Package	Boeing
65-17851-35	System B Hydraulic Modular Package	Boeing
65-17851-36	System B Hydraulic Modular Package	Boeing
65-17851-37	System B Hydraulic Modular Package	Boeing
65-17851-44	System B Hydraulic Modular Package	Boeing
65-17851-46	System B Hydraulic Modular Package	Boeing
65-17851-47	System B Hydraulic Modular Package	Boeing
65-17851-48	System B Hydraulic Modular Package	Boeing
65-17851-7	System B Hydraulic Modular Package	Boeing
65-17858-5	Hydraulic Actuator	Boeing
65-17862-11	System A Hydraulic Modular Package	Boeing
65-17862-14	System A Hydraulic Modular Package	Boeing
65-17862-16	System A Hydraulic Modular Package	Boeing
65-17862-18	System A Hydraulic Modular Package	Boeing
65-17862-19	System A Hydraulic Modular Package	Boeing
65-17862-20	System A Hydraulic Modular Package	Boeing
65-17862-23	System A Hydraulic Modular Package	Boeing
65-17862-24	System A Hydraulic Modular Package	Boeing
65-17862-25	System A Hydraulic Modular Package	Boeing
65-17862-26	System A Hydraulic Modular Package	Boeing
65-17862-28	System A Hydraulic Modular Package	Boeing
65-17862-29	System A Hydraulic Modular Package	Boeing
65-17862-33	System A Hydraulic Modular Package	Boeing
65-17862-34	System A Hydraulic Modular Package	Boeing
65-17862-37	System A Hydraulic Modular Package	Boeing
65-17862-8	System A Hydraulic Modular Package	Boeing
65-17882-12	Main Gear Lock Actuator	Boeing
65-17882-13	Main Gear Lock Actuator	Boeing
65-17882-14	Main Gear Lock Actuator	Boeing
65-17882-17	Main Gear Lock Actuator	Boeing
65-17882-18	Main Gear Lock Actuator	Boeing
65-17882-21	Main Gear Lock Actuator	Boeing
65-17882-22	Main Gear Lock Actuator	Boeing
65-17882-24	Main Gear Lock Actuator	Boeing
65-17882-3	Main Gear Lock Actuator	Boeing
65-17882-5	Main Gear Lock Actuator	Boeing
65-17882-7	Main Gear Lock Actuator	Boeing
65-18599-1	Inboard Flap Carriage assy	Boeing
65-18599-11	Inboard Flap Carriage assy	Boeing
65-18599-12	Inboard Flap Carriage assy	Boeing
65-18599-14	Inboard Flap Carriage assy	Boeing
65-18599-15	Inboard Flap Carriage assy	Boeing
65-18599-16	Inboard Flap Carriage assy	Boeing
65-18599-17	Inboard Flap Carriage assy	Boeing
65-18599-18	Inboard Flap Carriage assy	Boeing
65-18599-19	Inboard Flap Carriage assy	Boeing
65-18599-20	Inboard Flap Carriage assy	Boeing
65-18599-21	Inboard Flap Carriage assy	Boeing
65-18599-22	Inboard Flap Carriage assy	Boeing
65-18599-23	Inboard Flap Carriage assy	Boeing
65-18599-24	Inboard Flap Carriage assy	Boeing
65-18599-25	Inboard Flap Carriage assy	Boeing
65-18599-26	Inboard Flap Carriage assy	Boeing

Repair_Capability_List_Excel

65-18599-27	Inboard Flap Carriage assy	Boeing
65-18599-28	Inboard Flap Carriage assy	Boeing
65-18599-29	Inboard Flap Carriage assy	Boeing
65-18599-30	Inboard Flap Carriage assy	Boeing
65-18599-31	Inboard Flap Carriage assy	Boeing
65-18599-32	Inboard Flap Carriage assy	Boeing
65-18599-33	Inboard Flap Carriage assy	Boeing
65-18599-4	Inboard Flap Carriage assy	Boeing
65-18599-5	Inboard Flap Carriage assy	Boeing
65-18599-6	Inboard Flap Carriage assy	Boeing
65-19202-10	Outboard Flap Carriage assy	Boeing
65-19202-11	Outboard Flap Carriage assy	Boeing
65-19202-12	Outboard Flap Carriage assy	Boeing
65-19202-13	Outboard Flap Carriage assy	Boeing
65-19202-14	Outboard Flap Carriage assy	Boeing
65-19202-15	Outboard Flap Carriage assy	Boeing
65-19202-16	Outboard Flap Carriage assy	Boeing
65-19202-17	Outboard Flap Carriage assy	Boeing
65-19202-18	Outboard Flap Carriage assy	Boeing
65-19202-19	Outboard Flap Carriage assy	Boeing
65-19202-20	Outboard Flap Carriage assy	Boeing
65-19202-6	Outboard Flap Carriage assy	Boeing
65-19202-7	Outboard Flap Carriage assy	Boeing
65-19202-8	Outboard Flap Carriage assy	Boeing
65-19202-9	Outboard Flap Carriage assy	Boeing
65-19482-11	Stabilizer Trim Jackscrew Gearbox ay	Boeing
65-19482-13	Stabilizer Trim Jackscrew Gearbox ay	Boeing
65-19482-14	Stabilizer Trim Jackscrew Gearbox ay	Boeing
65-19482-16	Stabilizer Trim Jackscrew Gearbox ay	Boeing
65-19482-17	Stabilizer Trim Jackscrew Gearbox ay	Boeing
65-19482-18	Stabilizer Trim Jackscrew Gearbox ay	Boeing
65-19482-19	Stabilizer Trim Jackscrew Gearbox ay	Boeing
65-19482-20	Stabilizer Trim Jackscrew Gearbox ay	Boeing
65-19482-21	Stabilizer Trim Jackscrew Gearbox ay	Boeing
65-19482-22	Stabilizer Trim Jackscrew Gearbox ay	Boeing
65-19482-4	Stabilizer Trim Jackscrew Gearbox ay	Boeing
65-19482-5	Stabilizer Trim Jackscrew Gearbox ay	Boeing
65-19482-7	Stabilizer Trim Jackscrew Gearbox ay	Boeing
65-19482-8	Stabilizer Trim Jackscrew Gearbox ay	Boeing
65-19482-9	Stabilizer Trim Jackscrew Gearbox ay	Boeing
65-19811-4	Lower Strut	Boeing
65-19811-5	Lower Strut	Boeing
65-19811-8	Lower Strut	Boeing
65205-211-2	Altimeter	Thales Avionics
65205-211-3	Altimeter	Thales Avionics
65205-211-4	Altimeter	Thales Avionics
65205-230-1	Altimeter	Thales Avionics
65205-230-2	Altimeter	Thales Avionics
65205-230-3	Altimeter	Thales Avionics
65205-235-1	Altimeter	Thales Avionics
65205-240-1	Altimeter	Thales Avionics
65-21831-10	Rudder Trim Actuator	Boeing
65-21831-12	Rudder Trim Actuator	Boeing
65-21831-14	Rudder Trim Actuator	Boeing
65-21831-15	Rudder Trim Actuator	Boeing
65-21831-16	Rudder Trim Actuator	Boeing
65-21831-17	Rudder Trim Actuator	Boeing
65-21831-19	Rudder Trim Actuator	Boeing

Repair_Capability_List_Excel

65-21831-20	Rudder Trim Actuator	Boeing
65-21831-21	Rudder Trim Actuator	Boeing
65-21831-22	Rudder Trim Actuator	Boeing
65-21831-23	Rudder Trim Actuator	Boeing
65-21831-24	Rudder Trim Actuator	Boeing
65-21831-25	Rudder Trim Actuator	Boeing
65-21831-26	Rudder Trim Actuator	Boeing
65-21831-27	Rudder Trim Actuator	Boeing
65-21831-28	Rudder Trim Actuator	Boeing
65-21831-29	Rudder Trim Actuator	Boeing
65-21831-30	Rudder Trim Actuator	Boeing
65-21831-9	Rudder Trim Actuator	Boeing
65-21836-1	Nose Gear Actuator assy	Boeing
65-21890-1	Valve	Boeing
65-21945-10	PDU Gearbox assy	Boeing
65-21945-11	PDU Gearbox assy	Boeing
65-21945-12	PDU Gearbox assy	Boeing
65-21945-2	PDU Gearbox assy	Boeing
65-21945-3	PDU Gearbox assy	Boeing
65-21945-4	PDU Gearbox assy	Boeing
65-21945-5	PDU Gearbox assy	Boeing
65-21945-6	PDU Gearbox assy	Boeing
65-21945-7	PDU Gearbox assy	Boeing
65-21945-8	PDU Gearbox assy	Boeing
65-22216-113	Lower Body Forward Access Door	Boeing
65-22216-155	Lower Body Forward Access Door	Boeing
65-22216-174	Lower Body Forward Access Door	Boeing
65-22216-2	Lower Body Forward Access Door	Boeing
65-22216-57	Lower Body Forward Access Door	Boeing
65-22509-2	Valve Air Selector	Boeing
65-22509-3	Valve Air Selector	Boeing
65-22509-4	Valve Air Selector	Boeing
65-22509-5	Valve Air Selector	Boeing
65-22509-6	Valve Air Selector	Boeing
65-22509-7	Valve Air Selector	Boeing
65-22732-10	Stabilizer Trim Forward Mechanism	Boeing
65-22732-11	Stabilizer Trim Forward Mechanism	Boeing
65-22732-15	Stabilizer Trim Forward Mechanism	Boeing
65-22732-16	Stabilizer Trim Forward Mechanism	Boeing
65-22732-17	Stabilizer Trim Forward Mechanism	Boeing
65-22732-18	Stabilizer Trim Forward Mechanism	Boeing
65-22732-2	Stabilizer Trim Forward Mechanism	Boeing
65-22732-20	Stabilizer Trim Forward Mechanism	Boeing
65-22732-21	Stabilizer Trim Forward Mechanism	Boeing
65-22732-22	Stabilizer Trim Forward Mechanism	Boeing
65-22732-3	Stabilizer Trim Forward Mechanism	Boeing
65-22732-4	Stabilizer Trim Forward Mechanism	Boeing
65-22732-5	Stabilizer Trim Forward Mechanism	Boeing
65-22732-6	Stabilizer Trim Forward Mechanism	Boeing
65-22732-7	Stabilizer Trim Forward Mechanism	Boeing
65-22732-9	Stabilizer Trim Forward Mechanism	Boeing
65-22819-1	Offset Gearbox assy	Boeing
65-22819-10	Offset Gearbox assy	Boeing
65-22819-11	Offset Gearbox assy	Boeing
65-22819-12	Offset Gearbox assy	Boeing
65-22819-13	Offset Gearbox assy	Boeing
65-22819-14	Offset Gearbox assy	Boeing
65-22819-15	Offset Gearbox assy	Boeing

Repair_Capability_List_Excel

65-22819-16	Offset Gearbox assy	Boeing
65-22819-3	Offset Gearbox assy	Boeing
65-22819-4	Offset Gearbox assy	Boeing
65-22819-5	Offset Gearbox assy	Boeing
65-22819-6	Offset Gearbox assy	Boeing
65-22819-7	Offset Gearbox assy	Boeing
65-22819-8	Offset Gearbox assy	Boeing
65-22819-9	Offset Gearbox assy	Boeing
65-22944-1	Angle Gearbox assy	Boeing
65-22944-2	Angle Gearbox assy	Boeing
65-22944-3	Angle Gearbox assy	Boeing
65-22944-4	Angle Gearbox assy	Boeing
65-22944-5	Angle Gearbox assy	Boeing
65-22944-6	Angle Gearbox assy	Boeing
65-22944-7	Angle Gearbox assy	Boeing
65-22944-8	Angle Gearbox assy	Boeing
65-22944-9	Angle Gearbox assy	Boeing
65-2346-1	Galley Door Snubber	Boeing
65-2346-3	Galley Door Snubber	Boeing
65-2346-5	Galley Door Snubber	Boeing
65-23467-1	Angle Gearbox assy	Boeing
65-23467-2	Angle Gearbox assy	Boeing
65-23467-3	Angle Gearbox assy	Boeing
65-23467-4	Angle Gearbox assy	Boeing
65-23467-5	Angle Gearbox assy	Boeing
65-23467-6	Angle Gearbox assy	Boeing
65-23557-1	Gearbox assy	Boeing
65-23557-2	Gearbox assy	Boeing
65-23557-3	Gearbox assy	Boeing
65-23557-4	Gearbox assy	Boeing
65-23557-5	Gearbox assy	Boeing
65-23557-6	Gearbox assy	Boeing
65-23557-7	Gearbox assy	Boeing
65-23557-8	Gearbox assy	Boeing
65-23559-11	Transmission B/S assy	Boeing
65-23559-12	Transmission B/S assy	Boeing
65-23559-15	Transmission B/S assy	Boeing
65-23559-16	Transmission B/S assy	Boeing
65-23559-17	Transmission B/S assy	Boeing
65-23559-18	Transmission B/S assy	Boeing
65-23559-19	Ball Screw assy	Boeing
65-23559-21	Transmission B/S assy	Boeing
65-23559-22	Transmission B/S assy	Boeing
65-23559-23	Transmission B/S assy	Boeing
65-23559-24	Transmission B/S assy	Boeing
65-23559-25	Ball Screw assy	Boeing
65-23559-27	Transmission B/S assy	Boeing
65-23559-28	Transmission B/S assy	Boeing
65-23559-29	Transmission B/S assy	Boeing
65-23559-3	Ball Screw assy	Boeing
65-23559-30	Transmission B/S assy	Boeing
65-23559-31	Transmission B/S assy	Boeing
65-23559-32	Transmission B/S assy	Boeing
65-23559-33	Transmission B/S assy	Boeing
65-23559-34	Transmission B/S assy	Boeing
65-23559-35	Transmission B/S assy	Boeing
65-23559-36	Transmission B/S assy	Boeing
65-23559-37	Transmission B/S assy	Boeing

Repair_Capability_List_Excel

65-23559-38	Transmission B/S assy	Boeing
65-23559-41	Transmission B/S assy	Boeing
65-23559-42	Transmission B/S assy	Boeing
65-23560-11	Transmission B/S assy	Boeing
65-23560-12	Transmission B/S assy	Boeing
65-23560-15	Transmission B/S assy	Boeing
65-23560-16	Transmission B/S assy	Boeing
65-23560-17	Transmission B/S assy	Boeing
65-23560-18	Transmission B/S assy	Boeing
65-23560-19	Ball Screw assy	Boeing
65-23560-21	Transmission B/S assy	Boeing
65-23560-22	Transmission B/S assy	Boeing
65-23560-23	Transmission B/S assy	Boeing
65-23560-24	Transmission B/S assy	Boeing
65-23560-25	Ball Screw assy	Boeing
65-23560-26	Ball Screw assy	Boeing
65-23560-27	Transmission B/S assy	Boeing
65-23560-28	Transmission B/S assy	Boeing
65-23560-29	Transmission B/S assy	Boeing
65-23560-3	Ball Screw assy	Boeing
65-23560-30	Transmission B/S assy	Boeing
65-23560-31	Ball Screw assy	Boeing
65-23560-33	Transmission B/S assy	Boeing
65-23560-34	Transmission B/S assy	Boeing
65-23560-35	Transmission B/S assy	Boeing
65-23560-36	Transmission B/S assy	Boeing
65-23560-37	Transmission B/S assy	Boeing
65-23560-38	Transmission B/S assy	Boeing
65-23560-39	Transmission B/S assy	Boeing
65-23560-40	Transmission B/S assy	Boeing
65-23560-41	Transmission B/S assy	Boeing
65-23560-42	Transmission B/S assy	Boeing
65-23560-43	Transmission B/S assy	Boeing
65-23560-44	Transmission B/S assy	Boeing
65-23560-45	Transmission B/S assy	Boeing
65-23560-46	Transmission B/S assy	Boeing
65-23560-49	Transmission B/S assy	Boeing
65-23560-50	Transmission B/S assy	Boeing
65-23564-16	Transmitter assy	Boeing
65-23564-19	Transmitter assy	Boeing
65-23564-23	Transmitter assy	Boeing
65-23564-24	Transmitter assy	Boeing
65-23564-25	Transmitter assy	Boeing
65-23564-26	Transmitter assy	Boeing
65-23564-27	Transmitter assy	Boeing
65-23564-34	Transmitter assy	Boeing
65-23564-38	Transmitter assy	Boeing
65-23564-39	Transmitter assy	Boeing
65-23971-1	Ram Air Actuator	Boeing
65-23971-2	Ram Air Actuator	Boeing
65-23971-3	Ram Air Actuator	Boeing
65-24271-1	Light	Boeing
65-24400-11	Aileron Lockout Gearbox	Boeing
65-24400-12	Aileron Lockout Gearbox	Boeing
65-24400-13	Aileron Lockout Gearbox	Boeing
65-24400-14	Aileron Lockout Gearbox	Boeing
65-24400-17	Aileron Lockout Gearbox	Boeing
65-24400-18	Aileron Lockout Gearbox	Boeing

Repair_Capability_List_Excel

65-24400-19	Aileron Lockout Gearbox	Boeing
65-24400-20	Aileron Lockout Gearbox	Boeing
65-24400-21	Aileron Lockout Gearbox	Boeing
65-24400-22	Aileron Lockout Gearbox	Boeing
65-24400-23	Aileron Lockout Gearbox	Boeing
65-24400-24	Aileron Lockout Gearbox	Boeing
65-24400-7	Aileron Lockout Gearbox	Boeing
65-24400-8	Aileron Lockout Gearbox	Boeing
65-24525-10	Gearbox assy	Boeing
65-24525-11	Gearbox assy	Boeing
65-24525-12	Gearbox assy	Boeing
65-24525-13	Gearbox assy	Boeing
65-24525-14	Gearbox assy	Boeing
65-24525-15	Gearbox assy	Boeing
65-24525-16	Gearbox assy	Boeing
65-24525-3	Gearbox assy	Boeing
65-24525-4	Gearbox assy	Boeing
65-24525-5	Gearbox assy	Boeing
65-24525-6	Gearbox assy	Boeing
65-24525-7	Gearbox assy	Boeing
65-24525-8	Gearbox assy	Boeing
65-24525-9	Gearbox assy	Boeing
65-24790-11	Transmission assy	Boeing
65-24790-12	Transmission assy	Boeing
65-24790-13	Transmission assy	Boeing
65-24790-14	Transmission assy	Boeing
65-24790-17	Transmission assy	Boeing
65-24790-18	Transmission assy	Boeing
65-24790-19	Transmission assy	Boeing
65-24790-20	Transmission assy	Boeing
65-24790-21	Transmission assy	Boeing
65-24790-22	Transmission assy	Boeing
65-24790-23	Transmission assy	Boeing
65-24790-24	Transmission assy	Boeing
65-24790-25	Transmission assy	Boeing
65-24790-26	Transmission assy	Boeing
65-24790-27	Transmission assy	Boeing
65-24790-28	Transmission assy	Boeing
65-24790-29	Transmission assy	Boeing
65-24790-30	Transmission assy	Boeing
65-24790-31	Transmission assy	Boeing
65-24790-32	Transmission assy	Boeing
65-24790-33	Transmission assy	Boeing
65-24790-34	Transmission assy	Boeing
65-24790-35	Transmission assy	Boeing
65-24790-36	Transmission assy	Boeing
65-24790-7	Transmission assy	Boeing
65-24790-8	Transmission assy	Boeing
65-24917-117	Accessory Unit	Boeing
65-24917-123	Accessory Unit	Boeing
65-24917-137	Accessory Unit	Boeing
65-24917-142	Accessory Unit	Boeing
65-24917-146	Accessory Unit	Boeing
65-24917-152	Accessory Unit	Boeing
65-24917-194	Accessory Unit	Boeing
65-24917-213	Accessory Unit	Boeing
65-24917-214	Accessory Unit	Boeing
65-24917-230	Accessory Unit	Boeing

Repair_Capability_List_Excel

65-24917-238	Accessory Unit	Boeing
65-24917-254	Accessory Unit	Boeing
65-24917-269	Accessory Unit	Boeing
65-24917-276	Accessory Unit	Boeing
65-24917-281	Accessory Unit	Boeing
65-24917-284	Accessory Unit	Boeing
65-24917-290	Accessory Unit	Boeing
65-24917-295	Accessory Unit	Boeing
65-24917-308	Accessory Unit	Boeing
65-24917-323	Accessory Unit	Boeing
65-24917-332	Accessory Unit	Boeing
65-24917-355	Accessory Unit	Boeing
65-24917-359	Accessory Unit	Boeing
65-24917-363	Accessory Unit	Boeing
65-24917-374	Accessory Unit	Boeing
65-24917-50	Auto Pilot Accessory	Boeing
65-24920-3	Fire Detector	Boeing
65-25627-1	Torque Brake assy	Boeing
65-25627-3	Torque Brake assy	Boeing
65-25747-10	Ail.& Elev. Control Column & Wheel	Boeing
65-25747-13	Ail.& Elev. Control Column & Wheel	Boeing
65-25747-14	Ail.& Elev. Control Column & Wheel	Boeing
65-25747-17	Ail.& Elev. Control Column & Wheel	Boeing
65-25747-18	Ail.& Elev. Control Column & Wheel	Boeing
65-25747-19	Ail.& Elev. Control Column & Wheel	Boeing
65-25747-20	Ail.& Elev. Control Column & Wheel	Boeing
65-25747-21	Ail.& Elev. Control Column & Wheel	Boeing
65-25747-22	Ail.& Elev. Control Column & Wheel	Boeing
65-25747-23	Ail.& Elev. Control Column & Wheel	Boeing
65-25747-24	Ail.& Elev. Control Column & Wheel	Boeing
65-25747-3	Ail.& Elev. Control Column & Wheel	Boeing
65-25747-4	Ail.& Elev. Control Column & Wheel	Boeing
65-25747-5	Ail.& Elev. Control Column & Wheel	Boeing
65-25747-6	Ail.& Elev. Control Column & Wheel	Boeing
65-25747-9	Ail.& Elev. Control Column & Wheel	Boeing
65-25765-11	Transmission assy	Boeing
65-25765-12	Transmission assy	Boeing
65-25765-13	Transmission assy	Boeing
65-25765-14	Transmission assy	Boeing
65-25765-17	Transmission assy	Boeing
65-25765-18	Transmission assy	Boeing
65-25765-19	Transmission assy	Boeing
65-25765-20	Transmission assy	Boeing
65-25765-27	Transmission assy	Boeing
65-25765-28	Transmission assy	Boeing
65-25765-29	Transmission assy	Boeing
65-25765-30	Transmission assy	Boeing
65-25765-31	Transmission assy	Boeing
65-25765-32	Transmission assy	Boeing
65-25765-33	Transmission assy	Boeing
65-25765-34	Transmission assy	Boeing
65-25765-35	Transmission assy	Boeing
65-25765-36	Transmission assy	Boeing
65-25765-37	Transmission assy	Boeing
65-25765-38	Transmission assy	Boeing
65-25765-39	Transmission assy	Boeing
65-25765-40	Transmission assy	Boeing
65-25765-41	Transmission assy	Boeing

Repair_Capability_List_Excel

65-25765-42	Transmission assy	Boeing
65-25765-43	Transmission assy	Boeing
65-25765-44	Transmission assy	Boeing
65-25765-7	Transmission assy	Boeing
65-25765-8	Transmission assy	Boeing
65-25767-11	Transmission assy	Boeing
65-25767-12	Transmission assy	Boeing
65-25767-13	Transmission assy	Boeing
65-25767-14	Transmission assy	Boeing
65-25767-17	Transmission assy	Boeing
65-25767-18	Transmission assy	Boeing
65-25767-19	Transmission assy	Boeing
65-25767-20	Transmission assy	Boeing
65-25767-21	Transmission assy	Boeing
65-25767-22	Transmission assy	Boeing
65-25767-23	Transmission assy	Boeing
65-25767-24	Transmission assy	Boeing
65-25767-25	Transmission assy	Boeing
65-25767-26	Transmission assy	Boeing
65-25767-27	Transmission assy	Boeing
65-25767-28	Transmission assy	Boeing
65-25767-29	Transmission assy	Boeing
65-25767-30	Transmission assy	Boeing
65-25767-31	Transmission assy	Boeing
65-25767-32	Transmission assy	Boeing
65-25767-33	Transmission assy	Boeing
65-25767-34	Transmission assy	Boeing
65-25767-7	Transmission assy	Boeing
65-25767-8	Transmission assy	Boeing
65-26174-12	Rudder Pedal Steering System	Boeing
65-26174-14	Rudder Pedal Steering System	Boeing
65-26174-16	Rudder Pedal Steering System	Boeing
65-26174-18	Rudder Pedal Steering System	Boeing
65-26174-19	Rudder Pedal Steering System	Boeing
65-26174-20	Rudder Pedal Steering System	Boeing
65-26174-21	Rudder Pedal Steering System	Boeing
65-26174-23	Rudder Pedal Steering System	Boeing
65-26174-25	Rudder Pedal Steering System	Boeing
65-26174-27	Rudder Pedal Steering System	Boeing
65-26174-30	Rudder Pedal Steering System	Boeing
65-26174-32	Rudder Pedal Steering System	Boeing
65-26174-7	Rudder Pedal Steering System	Boeing
65-26174-9	Rudder Pedal Steering System	Boeing
65-26277-1	Aft Attendant's Oxygen Service Unit	Boeing
65-26277-2	Aft Attendant's Oxygen Service Unit	Boeing
65-26277-3	Aft Attendant's Oxygen Service Unit	Boeing
65-26277-4	Aft Attendant's Oxygen Service Unit	Boeing
65-26277-5	Aft Attendant's Oxygen Service Unit	Boeing
65-26277-6	Aft Attendant's Oxygen Service Unit	Boeing
65-26277-7	Aft Attendant's Oxygen Service Unit	Boeing
65-26277-8	Aft Attendant's Oxygen Service Unit	Boeing
65-26277-9	Aft Attendant's Oxygen Service Unit	Boeing
65-26350-11	Transmission assy	Boeing
65-26350-12	Transmission assy	Boeing
65-26350-13	Transmission assy	Boeing
65-26350-14	Transmission assy	Boeing
65-26350-17	Transmission assy	Boeing
65-26350-18	Transmission assy	Boeing

Repair_Capability_List_Excel

65-26350-19	Transmission assy	Boeing
65-26350-20	Transmission assy	Boeing
65-26350-21	Transmission assy	Boeing
65-26350-22	Transmission assy	Boeing
65-26350-23	Transmission assy	Boeing
65-26350-24	Transmission assy	Boeing
65-26350-25	Transmission assy	Boeing
65-26350-26	Transmission assy	Boeing
65-26350-27	Transmission assy	Boeing
65-26350-28	Transmission assy	Boeing
65-26350-29	Transmission assy	Boeing
65-26350-30	Transmission assy	Boeing
65-26350-33	Transmission assy	Boeing
65-26350-34	Transmission assy	Boeing
65-26350-35	Transmission assy	Boeing
65-26350-36	Transmission assy	Boeing
65-26350-37	Transmission assy	Boeing
65-26350-38	Transmission assy	Boeing
65-26350-39	Transmission assy	Boeing
65-26350-40	Transmission assy	Boeing
65-26350-41	Transmission assy	Boeing
65-26350-42	Transmission assy	Boeing
65-26350-43	Transmission assy	Boeing
65-26350-44	Transmission assy	Boeing
65-26350-45	Transmission assy	Boeing
65-26350-46	Transmission assy	Boeing
65-26350-49	Transmission assy	Boeing
65-26350-50	Transmission assy	Boeing
65-26350-51	Transmission assy	Boeing
65-26350-52	Transmission assy	Boeing
65-26350-7	Transmission assy	Boeing
65-26350-8	Transmission assy	Boeing
65-26545-1	Sequencing Carriage assy	Boeing
65-26545-11	Sequencing Carriage assy	Boeing
65-26545-13	Sequencing Carriage assy	Boeing
65-26545-15	Sequencing Carriage assy	Boeing
65-26545-8	Sequencing Carriage assy	Boeing
65-26546-1	Toggle assy	Boeing
65-26546-4	Toggle assy	Boeing
65-26546-6	Toggle assy	Boeing
65-26613-10	Transmission B/S assy	Boeing
65-26613-13	Transmission B/S assy	Boeing
65-26613-14	Transmission B/S assy	Boeing
65-26613-15	Transmission B/S assy	Boeing
65-26613-16	Transmission B/S assy	Boeing
65-26613-17	Ball Screw assy	Boeing
65-26613-19	Transmission B/S assy	Boeing
65-26613-20	Transmission B/S assy	Boeing
65-26613-21	Transmission B/S assy	Boeing
65-26613-22	Transmission B/S assy	Boeing
65-26613-23	Ball Screw assy	Boeing
65-26613-25	Transmission B/S assy	Boeing
65-26613-26	Transmission B/S assy	Boeing
65-26613-27	Transmission B/S assy	Boeing
65-26613-28	Transmission B/S assy	Boeing
65-26613-29	Transmission B/S assy	Boeing
65-26613-3	Ball Screw assy	Boeing
65-26613-30	Transmission B/S assy	Boeing

Repair_Capability_List_Excel

65-26613-31	Transmission B/S assy	Boeing
65-26613-32	Transmission B/S assy	Boeing
65-26613-33	Transmission B/S assy	Boeing
65-26613-34	Transmission B/S assy	Boeing
65-26613-35	Transmission B/S assy	Boeing
65-26613-36	Transmission B/S assy	Boeing
65-26613-39	Transmission B/S assy	Boeing
65-26613-40	Transmission B/S assy	Boeing
65-26613-9	Transmission B/S assy	Boeing
65-26614-10	Transmission B/S assy	Boeing
65-26614-13	Transmission B/S assy	Boeing
65-26614-14	Transmission B/S assy	Boeing
65-26614-15	Transmission B/S assy	Boeing
65-26614-16	Transmission B/S assy	Boeing
65-26614-17	Ball Screw assy	Boeing
65-26614-18	Ball Screw assy	Boeing
65-26614-21	Transmission B/S assy	Boeing
65-26614-22	Transmission B/S assy	Boeing
65-26614-23	Transmission B/S assy	Boeing
65-26614-24	Transmission B/S assy	Boeing
65-26614-25	Transmission B/S assy	Boeing
65-26614-26	Transmission B/S assy	Boeing
65-26614-27	Transmission B/S assy	Boeing
65-26614-28	Transmission B/S assy	Boeing
65-26614-29	Transmission B/S assy	Boeing
65-26614-30	Transmission B/S assy	Boeing
65-26614-31	Ball Screw assy	Boeing
65-26614-33	Transmission B/S assy	Boeing
65-26614-34	Transmission B/S assy	Boeing
65-26614-37	Transmission B/S assy	Boeing
65-26614-38	Transmission B/S assy	Boeing
65-26614-39	Transmission B/S assy	Boeing
65-26614-40	Transmission B/S assy	Boeing
65-26614-41	Transmission B/S assy	Boeing
65-26614-42	Transmission B/S assy	Boeing
65-26614-45	Transmission B/S assy	Boeing
65-26614-46	Transmission B/S assy	Boeing
65-26614-47	Transmission B/S assy	Boeing
65-26614-48	Transmission B/S assy	Boeing
65-26614-49	Transmission B/S assy	Boeing
65-26614-50	Transmission B/S assy	Boeing
65-26614-51	Transmission B/S assy	Boeing
65-26614-52	Transmission B/S assy	Boeing
65-26614-53	Transmission B/S assy	Boeing
65-26614-54	Transmission B/S assy	Boeing
65-26614-55	Ball Screw assy	Boeing
65-26614-57	Transmission B/S assy	Boeing
65-26614-58	Transmission B/S assy	Boeing
65-26614-59	Transmission B/S assy	Boeing
65-26614-60	Transmission B/S assy	Boeing
65-26614-63	Transmission B/S assy	Boeing
65-26614-64	Transmission B/S assy	Boeing
65-26614-65	Transmission B/S assy	Boeing
65-26614-66	Transmission B/S assy	Boeing
65-26614-9	Transmission B/S assy	Boeing
65-26766-3	Sequencing Carriage assy	Boeing
65-26766-4	Sequencing Carriage assy	Boeing
65-26766-5	Sequencing Carriage assy	Boeing

Repair_Capability_List_Excel

65-26766-6	Sequencing Carriage assy	Boeing
65-26767-4	Toggle assy	Boeing
65-27677-1	Tube	Boeing
65-27804-16	Actuator	Boeing
65-27804-17	Actuator	Boeing
65-27804-18	Actuator	Boeing
65-27804-19	Actuator	Boeing
65-27804-20	Actuator	Boeing
65-27804-21	Actuator	Boeing
65-27935-3	Actuator	Boeing
65-27942-177	Forward Airstair Door	Boeing
65-27942-2	Forward Airstair Door	Boeing
65-27942-83	Forward Airstair Door	Boeing
65-27942-91	Forward Airstair Door	Boeing
65-27999-3	Actuator	Boeing
65-28441-2	Actuator	Boeing
65285-220-2	Vertical Speed Indicator	Thales Avionics
65285-230-1	Vertical Speed Indicator	Thales Avionics
65285-230-3	Vertical Speed Indicator	Thales Avionics
65-28700-2	Absorber	Boeing
65-28700-3	Absorber	Boeing
65-28919-3	Actuator	Boeing
65-28919-4	Actuator	Boeing
65-28919-5	Actuator	Boeing
65-28919-6	Actuator	Boeing
65-28943-2	Cargo Door Actuator	Boeing
65-29994-10	Entry Door Guide Arm	Boeing
65-29994-11	Entry Door Guide Arm	Boeing
65-29994-12	Entry Door Guide Arm	Boeing
65-29994-13	Entry Door Guide Arm	Boeing
65-29994-14	Entry Door Guide Arm	Boeing
65-29994-2	Entry Door Guide Arm	Boeing
65-29994-4	Entry Door Guide Arm	Boeing
65-29994-5	Entry Door Guide Arm	Boeing
65-29994-501	Entry Door Guide Arm	Boeing
65-29994-6	Entry Door Guide Arm	Boeing
65-29994-7	Entry Door Guide Arm	Boeing
65-29994-8	Entry Door Guide Arm	Boeing
65-29994-9	Entry Door Guide Arm	Boeing
65-32603-1	Waste water Drain Mast	Boeing
65-32603-3	Waste water Drain Mast	Boeing
65-33942-1	Cargo System Roller Tray & Tiedown	Boeing
65-34679-10	Antenna Disconnect	Boeing
65-34679-4	Antenna Disconnect	Boeing
65-37244-1	Cargo System Side Restraint Guide	Boeing
65-37244-11	Cargo System Side Restraint Guide	Boeing
65-37244-12	Cargo System Side Restraint Guide	Boeing
65-37244-2	Cargo System Side Restraint Guide	Boeing
65-37244-21	Cargo System Side Restraint Guide	Boeing
65-37244-22	Cargo System Side Restraint Guide	Boeing
65-37244-23	Cargo System Side Restraint Guide	Boeing
65-37244-24	Cargo System Side Restraint Guide	Boeing
65-37244-25	Cargo System Side Restraint Guide	Boeing
65-37244-26	Cargo System Side Restraint Guide	Boeing
65-37244-27	Cargo System Side Restraint Guide	Boeing
65-37244-29	Cargo System Side Restraint Guide	Boeing
65-37244-3	Cargo System Side Restraint Guide	Boeing
65-37244-4	Cargo System Side Restraint Guide	Boeing

Repair_Capability_List_Excel

65-37244-5	Cargo System Side Restraint Guide	Boeing
65-37244-7	Cargo System Side Restraint Guide	Boeing
65-37244-9	Cargo System Side Restraint Guide	Boeing
65-37251-1	Palletized Cargo System Pallet Lock	Boeing
65-37251-3	Palletized Cargo System Pallet Lock	Boeing
65-37251-4	Palletized Cargo System Pallet Lock	Boeing
65-37251-5	Palletized Cargo System Pallet Lock	Boeing
65-37251-6	Palletized Cargo System Pallet Lock	Boeing
65-37288-1	Cargo System Retractable Side Guide	Boeing
65-37288-10	Cargo System Retractable Side Guide	Boeing
65-37288-11	Cargo System Retractable Side Guide	Boeing
65-37288-12	Cargo System Retractable Side Guide	Boeing
65-37288-15	Cargo System Retractable Side Guide	Boeing
65-37288-16	Cargo System Retractable Side Guide	Boeing
65-37288-17	Cargo System Retractable Side Guide	Boeing
65-37288-18	Cargo System Retractable Side Guide	Boeing
65-37288-19	Cargo System Retractable Side Guide	Boeing
65-37288-2	Cargo System Retractable Side Guide	Boeing
65-37288-20	Cargo System Retractable Side Guide	Boeing
65-37288-21	Cargo System Retractable Side Guide	Boeing
65-37288-25	Cargo System Retractable Side Guide	Boeing
65-37288-3	Cargo System Retractable Side Guide	Boeing
65-37288-4	Cargo System Retractable Side Guide	Boeing
65-37288-5	Cargo System Retractable Side Guide	Boeing
65-37288-8	Cargo System Retractable Side Guide	Boeing
65-37288-9	Cargo System Retractable Side Guide	Boeing
65-37289-3	Palletized Cargo System Brake	Boeing
65-37289-6	Palletized Cargo System Brake	Boeing
65-37558-1	Actuator	Boeing
65-37558-2	Actuator	Boeing
65-37568-17	Control Unit	Boeing
65-37568-22	Control Unit	Boeing
65-37568-25	Control Unit	Boeing
65-37568-31	Control Unit	Boeing
65-37568-46	Control Unit	Boeing
65-37568-48	Control Unit	Boeing
65-37568-51	Control Unit	Boeing
65-37568-52	Control Unit	Boeing
65-37568-53	Control Unit	Boeing
65-37568-55	Control Unit	Boeing
65-37568-56	Control Unit	Boeing
65-37851-7	Lockout Actuator	Boeing
65-37851-8	Lockout Actuator	Boeing
65-37920-1	Thrust Reverser Actuator	Boeing
65-37920-10	Thrust Reverser Actuator	Boeing
65-37920-26	Thrust Reverser Actuator	Boeing
65-37920-28	Thrust Reverser Actuator	Boeing
65-37920-36	Thrust Reverser Actuator	Boeing
65-38560-41	Tube	Boeing
653894-2B	Gyrosyn Compass Indicator	Honeywell
653895	Gyrosyn Compass Indicator	Honeywell
653897-2B	Gyrosyn Compass Indicator	Honeywell
653897-6B	Gyrosyn Compass Indicator	Honeywell
653MK1	Rudder Feel Simulator	Goodrich Control Systems
653MK2	Rudder Feel Simulator	Goodrich Control Systems
653MK3	Rudder Feel Simulator	Goodrich Control Systems
65-40178-108	Accessory Unit	Boeing
65-40178-117	Accessory Unit	Boeing

Repair_Capability_List_Excel

65-40178-130	Accessory Unit	Boeing
65-40178-80	Accessory Unit	Boeing
65-40178-99	Accessory Unit	Boeing
65-40180-1	Accessory Unit	Boeing
65-40449-1	Valve	Boeing
65-40449-3	Valve	Boeing
65-40449-4	Valve	Boeing
65-40467-4	Lock Actuator	Boeing
65-40467-6	Lock Actuator	Boeing
65-40514-1	Chassis Assy	Boeing
65-40514-11	Chassis Assy	Boeing
65-40514-17	Chassis Assy	Boeing
65-40514-18	Chassis Assy	Boeing
65-40514-20	Chassis Assy	Boeing
65-40514-28	Chassis Assy	Boeing
65-40514-30	Chassis Assy	Boeing
65-40514-33	Chassis Assy	Boeing
65-40514-34	Chassis Assy	Boeing
65-40514-37	Chassis Assy	Boeing
65-40514-42	Chassis Assy	Boeing
65-40514-44	Chassis Assy	Boeing
65-40514-46	Chassis Assy	Boeing
65-40514-6	Chassis Assy	Boeing
65-40514-9	Chassis Assy	Boeing
65-41332-1	Toggle assy	Boeing
65-41333-1	Toggle assy	Boeing
65-42163	Autothrottle gearbox	Boeing
65-42163-1	Autothrottle Gearbox assy	Boeing
65-42342-10	Transmitter assy	Boeing
65-42342-11	Transmitter assy	Boeing
65-42342-12	Transmitter assy	Boeing
65-42342-13	Transmitter assy	Boeing
65-42342-14	Transmitter assy	Boeing
65-42342-3	Transmitter assy	Boeing
65-42342-4	Transmitter assy	Boeing
65-42342-5	Transmitter assy	Boeing
65-42342-6	Transmitter assy	Boeing
65-42342-7	Transmitter assy	Boeing
65-42342-8	Transmitter assy	Boeing
65-42342-9	Transmitter assy	Boeing
65-42354-1	Autothrottle Clutch and Cam	Boeing
65-42354-10	Autothrottle Clutch and Cam	Boeing
65-42354-5	Autothrottle Clutch and Cam	Boeing
65-42354-7	Autothrottle Clutch and Cam	Boeing
65-42355-1	Autothrottle Clutch and Cam	Boeing
65-42355-17	Autothrottle Clutch and Cam	Boeing
65-42355-18	Autothrottle Clutch and Cam	Boeing
65-42355-19	Autothrottle Clutch and Cam	Boeing
65-42355-2	Autothrottle Clutch and Cam	Boeing
65-42355-20	Autothrottle Clutch and Cam	Boeing
65-42355-27	Autothrottle Clutch and Cam	Boeing
65-42355-28	Autothrottle Clutch and Cam	Boeing
65-42355-29	Autothrottle Clutch and Cam	Boeing
65-42355-3	Autothrottle Clutch and Cam	Boeing
65-42355-30	Autothrottle Clutch and Cam	Boeing
65-42355-31	Autothrottle Clutch and Cam	Boeing
65-42355-32	Autothrottle Clutch and Cam	Boeing
65-42355-34	Autothrottle Clutch and Cam	Boeing

Repair_Capability_List_Excel

65-42355-36	Autothrottle Clutch and Cam	Boeing
65-42355-37	Autothrottle Clutch and Cam	Boeing
65-42355-38	Autothrottle Clutch and Cam	Boeing
65-42355-39	Autothrottle Clutch and Cam	Boeing
65-42355-4	Autothrottle Clutch and Cam	Boeing
65-42355-41	Autothrottle Clutch and Cam	Boeing
65-42355-42	Autothrottle Clutch and Cam	Boeing
65-42355-43	Autothrottle Clutch and Cam	Boeing
65-42355-44	Autothrottle Clutch and Cam	Boeing
65-42355-47	Autothrottle Clutch and Cam	Boeing
65-42355-48	Autothrottle Clutch and Cam	Boeing
65-42355-49	Autothrottle Clutch and Cam	Boeing
65-42355-5	Autothrottle Clutch and Cam	Boeing
65-42355-50	Autothrottle Clutch and Cam	Boeing
65-42355-51	Autothrottle Clutch and Cam	Boeing
65-42355-52	Autothrottle Clutch and Cam	Boeing
65-42355-53	Autothrottle Clutch and Cam	Boeing
65-42355-54	Autothrottle Clutch and Cam	Boeing
65-42355-55	Autothrottle Clutch and Cam	Boeing
65-42355-56	Autothrottle Clutch and Cam	Boeing
65-42355-57	Autothrottle Clutch and Cam	Boeing
65-42355-58	Autothrottle Clutch and Cam	Boeing
65-42355-59	Autothrottle Clutch and Cam	Boeing
65-42355-6	Autothrottle Clutch and Cam	Boeing
65-42355-60	Autothrottle Clutch and Cam	Boeing
65-42355-61	Autothrottle Clutch and Cam	Boeing
65-42355-62	Autothrottle Clutch and Cam	Boeing
65-42355-63	Autothrottle Clutch and Cam	Boeing
65-42355-64	Autothrottle Clutch and Cam	Boeing
65-42355-65	Autothrottle Clutch and Cam	Boeing
65-42355-66	Autothrottle Clutch and Cam	Boeing
65-42355-67	Autothrottle Clutch and Cam	Boeing
65-42355-68	Autothrottle Clutch and Cam	Boeing
65-42355-7	Autothrottle Clutch and Cam	Boeing
65-42355-8	Autothrottle Clutch and Cam	Boeing
65-42500-2	Palletized Cargo System Pallet Lock	Boeing
65-42500-3	Cargo System Roller Tray & Tiedown	Boeing
65-42500-4	Cargo System Roller Tray & Tiedown	Boeing
65-42500-5	Cargo System Roller Tray & Tiedown	Boeing
65-42500-6	Cargo System Roller Tray & Tiedown	Boeing
65-42500-7	Cargo System Roller Tray & Tiedown	Boeing
65-42500-8	Cargo System Roller Tray & Tiedown	Boeing
65-42500-9	Cargo System Roller Tray & Tiedown	Boeing
65-42638-11	Cargo System Roller Tray & Tiedown	Boeing
65-42638-14	Cargo System Roller Tray & Tiedown	Boeing
65-42638-15	Cargo System Roller Tray & Tiedown	Boeing
65-42638-16	Cargo System Roller Tray & Tiedown	Boeing
65-42638-18	Cargo System Roller Tray & Tiedown	Boeing
65-42638-2	Cargo System Roller Tray & Tiedown	Boeing
65-42638-23	Cargo System Roller Tray & Tiedown	Boeing
65-42638-24	Cargo System Roller Tray & Tiedown	Boeing
65-42638-25	Cargo System Roller Tray & Tiedown	Boeing
65-42638-26	Cargo System Roller Tray & Tiedown	Boeing
65-42638-27	Cargo System Roller Tray & Tiedown	Boeing
65-42638-28	Cargo System Roller Tray & Tiedown	Boeing
65-42638-3	Cargo System Roller Tray & Tiedown	Boeing
65-42638-33	Cargo System Roller Tray & Tiedown	Boeing
65-42638-34	Cargo System Roller Tray & Tiedown	Boeing

Repair_Capability_List_Excel

65-42638-35	Cargo System Roller Tray & Tiedown	Boeing
65-42638-36	Cargo System Roller Tray & Tiedown	Boeing
65-42638-37	Cargo System Roller Tray & Tiedown	Boeing
65-42638-38	Cargo System Roller Tray & Tiedown	Boeing
65-42638-4	Cargo System Roller Tray & Tiedown	Boeing
65-42638-5	Cargo System Roller Tray & Tiedown	Boeing
65-42638-54	Cargo System Roller Tray & Tiedown	Boeing
65-42638-6	Cargo System Roller Tray & Tiedown	Boeing
65-42638-64	Cargo System Roller Tray & Tiedown	Boeing
65-42638-7	Cargo System Roller Tray & Tiedown	Boeing
65-42638-74	Cargo System Roller Tray & Tiedown	Boeing
65-42638-8	Cargo System Roller Tray & Tiedown	Boeing
65-44290-10	Transmitter assy	Boeing
65-44290-5	Transmitter assy	Boeing
65-44290-7	Transmitter assy	Boeing
65-44290-9	Transmitter assy	Boeing
65-44331-1	Galley/Sevice Door Guide Arm	Boeing
65-44331-2	Galley/Sevice Door Guide Arm	Boeing
65-44331-3	Galley/Sevice Door Guide Arm	Boeing
65-44503-10	Feel Actuator Cylinder	Boeing
65-44503-3	Rudder & Elevator Feel Actuator Cyl.	Boeing
65-44503-4	Rudder & Elevator Feel Actuator Cyl.	Boeing
65-44503-5	Rudder & Elevator Feel Actuator Cyl.	Boeing
65-44503-6	Rudder & Elevator Feel Actuator Cyl.	Boeing
65-44503-7	Feel Actuator Cylinder	Boeing
65-44503-8	Feel Actuator Cylinder	Boeing
65-44503-9	Rudder & Elevator Feel Actuator Cyl.	Boeing
65-44504-1	Main Gear Damper	Boeing
65-44504-2	Main Gear Damper	Boeing
65-44504-3	Main Gear Damper	Boeing
65-44504-5	Main Gear Damper	Boeing
65-44521-4	Brake Valve	Boeing
65-44521-5	Brake Valve	Boeing
65-44521-6	Brake Valve	Boeing
65-44531-3	Thrust Reverser Hyd. Control Valve	Boeing
65-44531-4	Thrust Reverser Hyd. Control Valve	Boeing
65-44550-14	Leading Edge Flap Actuator	Boeing
65-44550-15	Leading Edge Flap Actuator	Boeing
65-44550-16	Leading Edge Flap Actuator	Boeing
65-44550-18	Leading Edge Flap Actuator	Boeing
65-44550-20	Leading Edge Flap Actuator	Boeing
65-44551-5	Leading Edge Flap Actuator	Boeing
65-44551-6	Leading Edge Flap Actuator	Boeing
65-44551-7	Leading Edge Flap Actuator	Boeing
65-44551-9	Leading Edge Flap Actuator	Boeing
65-44560-6	Nose Gear Gravel Deflector	Boeing
65-44561-10	Flight Spoiler Power Control Unit	Boeing
65-44561-11	Flight Spoiler Power Control Unit	Boeing
65-44561-12	Flight Spoiler Power Control Unit	Boeing
65-44561-13	Actuator	Boeing
65-44561-14	Flight Spoiler Power Control Unit	Boeing
65-44561-15	Flight Spoiler Power Control Unit	Boeing
65-44561-5	Flight Spoiler Power Control Unit	Boeing
65-44561-6	Flight Spoiler Power Control Unit	Boeing
65-44561-7	Flight Spoiler Power Control Unit	Boeing
65-44561-8	Flight Spoiler Power Control Unit	Boeing
65-44561-9	Flight Spoiler Power Control Unit	Boeing
65-44580-10	System A Hydraulic Modular Package	Boeing

Repair_Capability_List_Excel

65-44580-11	System A Hydraulic Modular Package	Boeing
65-44580-14	System A Hydraulic Modular Package	Boeing
65-44580-15	Hydraulic Modular Package	Boeing
65-44580-16	System A Hydraulic Modular Package	Boeing
65-44580-17	Hydraulic Modular Package	Boeing
65-44580-18	System A Hydraulic Modular Package	Boeing
65-44580-19	Hydraulic Modular Package	Boeing
65-44580-2	System A Hydraulic Modular Package	Boeing
65-44580-3	System A Hydraulic Modular Package	Boeing
65-44580-6	System A Hydraulic Modular Package	Boeing
65-44580-7	System A Hydraulic Modular Package	Boeing
65-44580-8	System A Hydraulic Modular Package	Boeing
65-44580-9	System A Hydraulic Modular Package	Boeing
65-44581-1	Shut-Off Valve Modular Package	Boeing
65-44581-2	Shut-Off Valve Modular Package	Boeing
65-44581-3	Shut-Off Valve Modular Package	Boeing
65-44581-4	Shut-Off Valve Modular Package	Boeing
65-44581-5	Shut-Off Valve Modular Package	Boeing
65-44581-6	Shut-Off Valve Modular Package	Boeing
65-44581-7	Shut-Off Valve Modular Package	Boeing
65-44590-2	System B Hydraulic Modular Package	Boeing
65-44590-3	System B Hydraulic Modular Package	Boeing
65-44590-4	System B Hydraulic Modular Package	Boeing
65-44590-5	System B Hydraulic Modular Package	Boeing
65-44590-6	System B Hydraulic Modular Package	Boeing
65-44590-9	System B Hydraulic Modular Package	Boeing
65-44600-11	System A Hydraulic Reservoir	Boeing
65-44600-13	System A Hydraulic Reservoir	Boeing
65-44600-14	System A Hydraulic Reservoir	Boeing
65-44600-15	System A Hydraulic Reservoir	Boeing
65-44600-16	System A Hydraulic Reservoir	Boeing
65-44600-17	System A Hydraulic Reservoir	Boeing
65-44600-19	System A Hydraulic Reservoir	Boeing
65-44600-2	System A Hydraulic Reservoir	Boeing
65-44600-20	System A Hydraulic Reservoir	Boeing
65-44600-22	System A Hydraulic Reservoir	Boeing
65-44600-23	System A Hydraulic Reservoir	Boeing
65-44600-24	System A Hydraulic Reservoir	Boeing
65-44600-3	System A Hydraulic Reservoir	Boeing
65-44600-4	System A Hydraulic Reservoir	Boeing
65-44600-7	System A Hydraulic Reservoir	Boeing
65-44600-8	System A Hydraulic Reservoir	Boeing
65-44601-1	System A Hydraulic Reservoir	Boeing
65-44601-10	System A Hydraulic Reservoir	Boeing
65-44601-11	System A Hydraulic Reservoir	Boeing
65-44601-13	System A Hydraulic Reservoir	Boeing
65-44601-21	System A Hydraulic Reservoir	Boeing
65-44601-22	System A Hydraulic Reservoir	Boeing
65-44601-23	System A Hydraulic Reservoir	Boeing
65-44601-7	System A Hydraulic Reservoir	Boeing
65-44601-9	System A Hydraulic Reservoir	Boeing
65-44610-3	Nose Gear Hydraulic Actuator	Boeing
65-44610-4	Nose Gear Hydraulic Actuator	Boeing
65-44625-10	Main Gear Lock Actuator	Boeing
65-44625-11	Nose Gear Hydraulic Actuator	Boeing
65-44625-14	Main Gear Lock Actuator	Boeing
65-44625-18	Nose Gear Lock Actuator	Boeing
65-44625-4	Main Gear Lock Actuator	Boeing

Repair_Capability_List_Excel

65-44625-5	Nose Gear Hydraulic Actuator	Boeing
65-44625-6	Main Gear Lock Actuator	Boeing
65-44625-8	Nose Gear Hydraulic Actuator	Boeing
65-44625-9	Nose Gear Hydraulic Actuator	Boeing
65-44631-1	Trailing Edge Flaps Control Valve	Boeing
65-44650-16	Leading Edge Slat Actuator	Boeing
65-44650-17	Leading Edge Slat Actuator	Boeing
65-44650-18	Leading Edge Slat Actuator	Boeing
65-44650-19	Leading Edge Slat Actuator	Boeing
65-44650-23	Leading Edge Slat Actuator	Boeing
65-44650-24	Leading Edge Slat Actuator	Boeing
65-44650-25	Leading Edge Slat Actuator	Boeing
65-44650-26	Leading Edge Slat Actuator	Boeing
65-44650-27	Leading Edge Slat Actuator	Boeing
65-44650-28	Leading Edge Slat Actuator	Boeing
65-44650-29	Leading Edge Slat Actuator	Boeing
65-44650-30	Leading Edge Slat Actuator	Boeing
65-44651-11	Leading Edge Slat Actuator	Boeing
65-44651-13	Leading Edge Slat Actuator	Boeing
65-44651-14	Leading Edge Slat Actuator	Boeing
65-44651-15	Leading Edge Slat Actuator	Boeing
65-44651-16	Leading Edge Slat Actuator	Boeing
65-44651-17	Leading Edge Slat Actuator	Boeing
65-44651-6	Leading Edge Slat Actuator	Boeing
65-44651-7	Leading Edge Slat Actuator	Boeing
65-44651-8	Leading Edge Slat Actuator	Boeing
65-44651-9	Leading Edge Slat Actuator	Boeing
65-44660-4	Gravel Deflector Actuator	Boeing
65-44660-5	Gravel Deflector Actuator	Boeing
65-44676-2	System A Hydraulic Reservoir	Boeing
65-44680-10	Standby System Modular Package	Boeing
65-44680-11	Standby System Modular Package	Boeing
65-44680-12	Standby System Modular Package	Boeing
65-44680-14	Standby System Modular Package	Boeing
65-44680-15	Standby System Modular Package	Boeing
65-44680-16	Standby System Modular Package	Boeing
65-44680-17	Standby System Modular Package	Boeing
65-44680-18	Standby System Modular Package	Boeing
65-44680-2	Standby System Modular Package	Boeing
65-44680-4	Standby System Modular Package	Boeing
65-44680-5	Standby System Modular Package	Boeing
65-44680-6	Standby System Modular Package	Boeing
65-44680-7	Standby System Modular Package	Boeing
65-44681-1	Standby System Modular Package	Boeing
65-44681-10	Standby System Modular Package	Boeing
65-44681-11	Standby System Modular Package	Boeing
65-44681-14	Standby System Modular Package	Boeing
65-44681-15	Standby System Modular Package	Boeing
65-44681-16	Standby System Modular Package	Boeing
65-44681-17	Standby System Modular Package	Boeing
65-44681-3	Standby System Modular Package	Boeing
65-44681-4	Standby System Modular Package	Boeing
65-44681-5	Standby System Modular Package	Boeing
65-44681-6	Standby System Modular Package	Boeing
65-44681-9	Standby System Modular Package	Boeing
65-44690-10	Landing Gear Hyd.Transfer Cylinder	Boeing
65-44690-11	Landing Gear Hyd.Transfer Cylinder	Boeing
65-44690-15	Landing Gear Hyd.Transfer Cylinder	Boeing

Repair_Capability_List_Excel

65-44690-16	Landing Gear Hyd.Transfer Cylinder	Boeing
65-44690-4	Landing Gear Hyd.Transfer Cylinder	Boeing
65-44690-8	Landing Gear Hyd.Transfer Cylinder	Boeing
65-44691-3	Landing Gear Modular Package	Boeing
65-44691-4	Landing Gear Modular Package	Boeing
65-44691-5	Landing Gear Modular Package	Boeing
65-44691-6	Landing Gear Modular Package	Boeing
65-44699-2	Air Manifold Assy	Boeing
65-44699-5	Air Manifold Assy	Boeing
65-44699-9	Air Manifold Assy	Boeing
65-44710-2	Nose Wheel Steering Cylinder	Boeing
65-44710-3	Nose Wheel Steering Cylinder	Boeing
65-44710-4	Nose Wheel Steering Cylinder	Boeing
65-44710-5	Nose Wheel Steering Cylinder	Boeing
65-44710-6	Nose Wheel Steering Cylinder	Boeing
65-44710-7	Nose Wheel Steering Cylinder	Boeing
65-44710-8	Nose Wheel Steering Cylinder	Boeing
65-44710-9	Nose Wheel Steering Cylinder	Boeing
65-44725-10	Leading Edge Slat Actuator	Boeing
65-44725-101	Slat Actuator	Boeing
65-44725-102	Slat Actuator	Boeing
65-44725-103	Slat Actuator	Boeing
65-44725-104	Slat Actuator	Boeing
65-44725-105	Slat Actuator	Boeing
65-44725-11	Leading Edge Slat Actuator	Boeing
65-44725-12	Leading Edge Slat Actuator	Boeing
65-44725-13	Leading Edge Slat Actuator	Boeing
65-44725-15	Leading Edge Slat Actuator	Boeing
65-44725-16	Leading Edge Slat Actuator	Boeing
65-44725-17	Leading Edge Slat Actuator	Boeing
65-44725-18	Leading Edge Slat Actuator	Boeing
65-44725-19	Leading Edge Slat Actuator	Boeing
65-44725-20	Leading Edge Slat Actuator	Boeing
65-44725-21	Leading Edge Slat Actuator	Boeing
65-44725-22	Leading Edge Slat Actuator	Boeing
65-44725-23	Leading Edge Slat Actuator	Boeing
65-44725-25	Leading Edge Slat Actuator	Boeing
65-44725-3	Leading Edge Slat Actuator	Boeing
65-44725-33	Leading Edge Slat Actuator	Boeing
65-44725-34	Leading Edge Slat Actuator	Boeing
65-44725-35	Leading Edge Slat Actuator	Boeing
65-44725-36	Leading Edge Slat Actuator	Boeing
65-44725-37	Leading Edge Slat Actuator	Boeing
65-44725-38	Leading Edge Slat Actuator	Boeing
65-44725-39	Leading Edge Slat Actuator	Boeing
65-44725-4	Leading Edge Slat Actuator	Boeing
65-44725-40	Leading Edge Slat Actuator	Boeing
65-44725-41	Leading Edge Slat Actuator	Boeing
65-44725-42	Leading Edge Slat Actuator	Boeing
65-44725-43	Leading Edge Slat Actuator	Boeing
65-44725-44	Leading Edge Slat Actuator	Boeing
65-44725-45	Leading Edge Slat Hyd. Actuator	Boeing
65-44725-47	Leading Edge Slat Hyd. Actuator	Boeing
65-44725-48	Leading Edge Slat Hyd. Actuator	Boeing
65-44725-5	Leading Edge Slat Actuator	Boeing
65-44725-50	Leading Edge Slat Hyd. Actuator	Boeing
65-44725-52	Leading Edge Slat Hyd. Actuator	Boeing
65-44725-54	Leading Edge Slat Hyd. Actuator	Boeing

Repair_Capability_List_Excel

65-44725-55	Leading Edge Slat Hyd. Actuator	Boeing
65-44725-57	Leading Edge Slat Hyd. Actuator	Boeing
65-44725-58	Leading Edge Slat Hyd. Actuator	Boeing
65-44725-59	Leading Edge Slat Hyd. Actuator	Boeing
65-44725-6	Leading Edge Slat Actuator	Boeing
65-44725-60	Leading Edge Slat Hyd. Actuator	Boeing
65-44725-61	Leading Edge Slat Hyd. Actuator	Boeing
65-44725-62	Leading Edge Slat Hyd. Actuator	Boeing
65-44725-63	Leading Edge Slat Hyd. Actuator	Boeing
65-44725-64	Leading Edge Slat Hyd. Actuator	Boeing
65-44725-65	Leading Edge Slat Hyd. Actuator	Boeing
65-44725-76	Leading Edge Slat Hyd. Actuator	Boeing
65-44725-77	Leading Edge Slat Hyd. Actuator	Boeing
65-44725-79	Leading Edge Slat Hyd. Actuator	Boeing
65-44725-85	Leading Edge Slat Hyd. Actuator	Boeing
65-44725-86	Leading Edge Slat Hyd. Actuator	Boeing
65-44725-87	Leading Edge Slat Hyd. Actuator	Boeing
65-44725-88	Leading Edge Slat Hyd. Actuator	Boeing
65-44725-89	Leading Edge Slat Hyd. Actuator	Boeing
65-44725-90	Leading Edge Slat Hyd. Actuator	Boeing
65-44725-91	Leading Edge Slat Hyd. Actuator	Boeing
65-44725-92	Leading Edge Slat Hyd. Actuator	Boeing
65-44725-93	Leading Edge Slat Hyd. Actuator	Boeing
65-44725-94	Leading Edge Slat Hyd. Actuator	Boeing
65-44725-95	Leading Edge Slat Hyd. Actuator	Boeing
65-44725-96	Leading Edge Slat Hyd. Actuator	Boeing
65-44725-97	Leading Edge Slat Hyd. Actuator	Boeing
65-44725-98	Leading Edge Slat Hyd. Actuator	Boeing
65-44725-99	Leading Edge Slat Hyd. Actuator	Boeing
65-44751-1	Tab Lock Actuator	Boeing
65-44751-2	Tab Lock Actuator	Boeing
65-44751-3	Tab Lock Actuator	Boeing
65-44760-10	Leading Edge Slat Hyd. Actuator	Boeing
65-44760-11	Leading Edge Slat Hyd. Actuator	Boeing
65-44760-12	Leading Edge Slat Hyd. Actuator	Boeing
65-44760-13	Leading Edge Slat Hyd. Actuator	Boeing
65-44760-14	Leading Edge Slat Hyd. Actuator	Boeing
65-44760-15	Leading Edge Slat Hyd. Actuator	Boeing
65-44760-22	Leading Edge Slat Hyd. Actuator	Boeing
65-44760-23	Leading Edge Slat Hyd. Actuator	Boeing
65-44760-24	Leading Edge Slat Hyd. Actuator	Boeing
65-44760-25	Actuator	Boeing
65-44760-26	Actuator	Boeing
65-44760-27	Actuator	Boeing
65-44760-5	Leading Edge Slat Hyd. Actuator	Boeing
65-44760-7	Leading Edge Slat Hyd. Actuator	Boeing
65-44760-8	Leading Edge Slat Hyd. Actuator	Boeing
65-44761-10	Ail.& Elev. Power Control Unit	Boeing
65-44761-12	Ail.& Elev. Power Control Unit	Boeing
65-44761-14	Ail.& Elev. Power Control Unit	Boeing
65-44761-15	Ail.& Elev. Power Control Unit	Boeing
65-44761-16	Ail.& Elev. Power Control Unit	Boeing
65-44761-17	Ail.& Elev. Power Control Unit	Boeing
65-44761-18	Ail.& Elev. Power Control Unit	Boeing
65-44761-19	Ail.& Elev. Power Control Unit	Boeing
65-44761-20	Ail.& Elev. Power Control Unit	Boeing
65-44761-21	Ail.& Elev. Power Control Unit	Boeing
65-44761-22	Ail.& Elev. Power Control Unit	Boeing

Repair_Capability_List_Excel

65-44761-8	Ail.& Elev. Power Control Unit	Boeing
65-44761-9	Ail.& Elev. Power Control Unit	Boeing
65-44771-2	Main Gear Damper	Boeing
65-44771-3	Main Gear Damper	Boeing
65-44771-4	Main Gear Damper	Boeing
65-44800-10	Standby Hydraulic System Reservoir	Boeing
65-44800-3	Standby Hydraulic System Reservoir	Boeing
65-44800-5	Standby Hydraulic System Reservoir	Boeing
65-44800-6	Standby Hydraulic System Reservoir	Boeing
65-44800-7	Standby Hydraulic System Reservoir	Boeing
65-44800-8	Standby Hydraulic System Reservoir	Boeing
65-44801-11	Standby Hydraulic System Reservoir	Boeing
65-44801-14	Standby Hydraulic System Reservoir	Boeing
65-44801-4	Standby Hydraulic System Reservoir	Boeing
65-44801-7	Standby Hydraulic System Reservoir	Boeing
65-44801-8	Standby Hydraulic System Reservoir	Boeing
65-44801-9	Standby Hydraulic System Reservoir	Boeing
65-44810-3	Main Gear Lock Actuator	Boeing
65-44810-4	Main Gear Lock Actuator	Boeing
65-44810-5	Main Gear Lock Actuator	Boeing
65-44810-6	Main Gear Lock Actuator	Boeing
65-44821-1	Trailing Edge Flap Control Valve	Boeing
65-44821-2	Trailing Edge Flap Control Valve	Boeing
65-44821-3	Trailing Edge Flap Control Valve	Boeing
65-44821-4	Trailing Edge Flap Control Valve	Boeing
65-44825-10	Main Gear Lock Actuator	Boeing
65-44825-11	Main Gear Lock Actuator	Boeing
65-44825-12	Main Gear Lock Actuator	Boeing
65-44825-13	Main Gear Lock Actuator	Boeing
65-44825-14	Main Gear Lock Actuator	Boeing
65-44825-15	Main Gear Lock Actuator	Boeing
65-44825-16	Main Gear Lock Actuator	Boeing
65-44825-17	Main Gear Lock Actuator	Boeing
65-44825-18	Main Gear Lock Actuator	Boeing
65-44825-7	Main Gear Lock Actuator	Boeing
65-44825-8	Main Gear Lock Actuator	Boeing
65-44825-9	Main Gear Lock Actuator	Boeing
65-44851	Actuator	Boeing
65-44851-10	Ground Spoiler Locking Actuator	Boeing
65-44851-12	Ground Spoiler Locking Actuator	Boeing
65-44851-13	Ground Spoiler Locking Actuator	Boeing
65-44851-14	Ground Spoiler Locking Actuator	Boeing
65-44851-3	Ground Spoiler Locking Actuator	Boeing
65-44851-4	Ground Spoiler Locking Actuator	Boeing
65-44851-5	Ground Spoiler Locking Actuator	Boeing
65-44851-6	Ground Spoiler Locking Actuator	Boeing
65-44851-7	Ground Spoiler Locking Actuator	Boeing
65-44861-10	Rudder Power Control Unit	Boeing
65-44861-11	Rudder Power Control Unit	Boeing
65-44861-12	Rudder Power Control Unit	Boeing
65-44861-2	Rudder Power Control Unit	Boeing
65-44861-3	Rudder Power Control Unit	Boeing
65-44861-4	Rudder Power Control Unit	Boeing
65-44861-5	Rudder Power Control Unit	Boeing
65-44861-6	Rudder Power Control Unit	Boeing
65-44861-7	Rudder Power Control Unit	Boeing
65-44861-8	Rudder Power Control Unit	Boeing
65-44861-9	Rudder Power Control Unit	Boeing

Repair_Capability_List_Excel

65-44891-1	Flight Control Modular Package	Boeing
65-44891-3	Flight Control Modular Package	Boeing
65-44891-4	Flight Control Modular Package	Boeing
65-44891-5	Flight Control Modular Package	Boeing
65-44891-7	Flight Control Modular Package	Boeing
65-44896-10	Shut-Off Valve Modular Package	Boeing
65-44896-11	Shut-Off Valve Modular Package	Boeing
65-44896-2	Shut-Off Valve Modular Package	Boeing
65-44896-4	Shut-Off Valve Modular Package	Boeing
65-44896-5	Shut-Off Valve Modular Package	Boeing
65-44896-6	Shut-Off Valve Modular Package	Boeing
65-44896-7	Shut-Off Valve Modular Package	Boeing
65-44896-9	Shut-Off Valve Modular Package	Boeing
65-44897-2	Landing Gear Hyd.Transfer Cylinder	Boeing
65-44897-3	Landing Gear Hyd.Transfer Cylinder	Boeing
65-44897-4	Landing Gear Hyd.Transfer Cylinder	Boeing
65-44897-5	Landing Gear Hyd.Transfer Cylinder	Boeing
65-44898-2	Main Gear Damper	Boeing
65-44898-3	Main Gear Damper	Boeing
65-44898-5	Main Gear Damper	Boeing
65-44898-7	Main Gear Damper	Boeing
65-44898-8	Main Gear Damper	Boeing
65-44910-11	Main Gear Actuator	Boeing
65-44910-12	Main Gear Actuator	Boeing
65-44910-13	Main Gear Actuator	Boeing
65-44910-27	Main Gear Actuator	Boeing
65-44910-28	Main Gear Actuator	Boeing
65-44910-29	Main Gear Actuator	Boeing
65-44910-30	Main Gear Actuator	Boeing
65-44910-31	Main Gear Actuator	Boeing
65-44910-32	Main Gear Actuator	Boeing
65-44910-6	Main Gear Actuator	Boeing
65-44910-7	Main Gear Actuator	Boeing
65-44910-8	Main Gear Actuator	Boeing
65-44910-9	Main Gear Actuator	Boeing
65-44925-11	Main Gear Actuator	Boeing
65-44925-12	Main Gear Actuator	Boeing
65-44925-15	Main Gear Actuator	Boeing
65-44925-16	Main Gear Actuator	Boeing
65-44925-21	Main Gear Actuator	Boeing
65-44925-22	Main Gear Actuator	Boeing
65-44925-27	Main Landing Gear Retract Actuator	Boeing
65-44925-28	Main Gear Actuator	Boeing
65-44925-29	Main Gear Actuator	Boeing
65-44925-30	Main Gear Actuator	Boeing
65-44925-31	Main Gear Actuator	Boeing
65-44925-32	Main Landing Gear Retract Actuator	Boeing
65-44925-33	Main Gear Actuator	Boeing
65-44925-34	Main Gear Actuator	Boeing
65-44925-35	Main Landing Gear Retract Actuator	Boeing
65-44925-36	Main Gear Actuator	Boeing
65-44925-41	Main Gear Actuator	Boeing
65-44925-42	Main Gear Actuator	Boeing
65-44925-7	Main Gear Actuator	Boeing
65-44925-8	Main Gear Actuator	Boeing
65-44925-9	Main Gear Actuator	Boeing
65-44931-10	Feel Actuator & Brake Metering Valve	Boeing
65-44931-11	Feel Actuator & Brake Metering Valve	Boeing

Repair_Capability_List_Excel

65-44931-12	Feel Actuator & Brake Metering Valve	Boeing
65-44931-3	Feel Actuator & Brake Metering Valve	Boeing
65-44931-4	Feel Actuator & Brake Metering Valve	Boeing
65-44931-5	Feel Actuator & Brake Metering Valve	Boeing
65-44931-6	Feel Actuator & Brake Metering Valve	Boeing
65-44931-8	Feel Actuator & Brake Metering Valve	Boeing
65-44931-9	Feel Actuator & Brake Metering Valve	Boeing
65-44951	Ground Spoiler Actuator	Boeing
65-44960-10	Outb.Ground Spoiler Locking Actuator	Boeing
65-44960-11	Outb.Ground Spoiler Locking Actuator	Boeing
65-44960-13	Outb.Ground Spoiler Locking Actuator	Boeing
65-44960-15	Outb.Ground Spoiler Locking Actuator	Boeing
65-44960-2	Outb.Ground Spoiler Locking Actuator	Boeing
65-44960-23	Outboard Ground Spoiler Actuator	Boeing
65-44960-24	Outboard Ground Spoiler Actuator	Boeing
65-44960-25	Outboard Ground Spoiler Actuator	Boeing
65-44960-27	Outboard Ground Spoiler Actuator	Boeing
65-44960-28	Outboard Ground Spoiler Actuator	Boeing
65-44960-29	Outb.Ground Spoiler Locking Actuator	Boeing
65-44960-30	Outb.Ground Spoiler Locking Actuator	Boeing
65-44960-4	Outb.Ground Spoiler Locking Actuator	Boeing
65-44960-5	Outb.Ground Spoiler Locking Actuator	Boeing
65-44960-6	Outb.Ground Spoiler Locking Actuator	Boeing
65-44960-8	Outb.Ground Spoiler Locking Actuator	Boeing
65-44960-9	Outb.Ground Spoiler Locking Actuator	Boeing
65-44961-10	Outb.Ground Spoiler Locking Actuator	Boeing
65-44961-12	Outb.Ground Spoiler Locking Actuator	Boeing
65-44961-14	Outb.Ground Spoiler Locking Actuator	Boeing
65-44961-16	Outb.Ground Spoiler Locking Actuator	Boeing
65-44961-2	Outb.Ground Spoiler Locking Actuator	Boeing
65-44961-3	Outb.Ground Spoiler Locking Actuator	Boeing
65-44961-4	Outb.Ground Spoiler Locking Actuator	Boeing
65-44961-5	Outb.Ground Spoiler Locking Actuator	Boeing
65-44961-6	Outb.Ground Spoiler Locking Actuator	Boeing
65-44961-7	Outb.Ground Spoiler Locking Actuator	Boeing
65-44975-3	Steering Depressurization Valve	Boeing
65-44975-5	Steering Depressurization Valve	Boeing
65-44980-13	Ground Service Disc.Modular Package	Boeing
65-44980-14	Ground Service Disc.Modular Package	Boeing
65-44980-2	Ground Service Disc.Modular Package	Boeing
65-44980-7	Ground Service Disc.Modular Package	Boeing
65-44980-9	Ground Service Disc.Modular Package	Boeing
65-44981-1	Ground Service Disc.Modular Package	Boeing
65-44981-4	Ground Service Disc.Modular Package	Boeing
65-44981-5	Ground Service Disc.Modular Package	Boeing
65-44981-6	Ground Service Disc.Modular Package	Boeing
65-44981-7	Ground Service Disc.Modular Package	Boeing
65-44990-5	Hydraulic System Isol.Valve Modular	Boeing
65-44990-6	Hydraulic System Isol.Valve Modular	Boeing
65-44991-1	Hydraulic System Isol.Valve Modular	Boeing
65-44991-2	Hydraulic System Isol.Valve Modular	Boeing
65-44991-3	Hydraulic System Isol.Valve Modular	Boeing
65-45120-12	Rudder Pedal	Boeing
65-45120-13	Rudder Pedal	Boeing
65-45120-14	Rudder Pedal	Boeing
65-45120-15	Rudder Pedal	Boeing
65-45120-16	Rudder Pedal	Boeing
65-45120-17	Rudder Pedal	Boeing

Repair_Capability_List_Excel

65-45125-37	Control Stand Upper Mechanism	Boeing
65-45125-38	Control Stand Upper Mechanism	Boeing
65-45125-39	Control Stand Upper Mechanism	Boeing
65-45125-40	Control Stand Upper Mechanism	Boeing
65-45125-41	Control Stand Upper Mechanism	Boeing
65-45125-42	Control Stand Upper Mechanism	Boeing
65-45125-43	Control Stand Upper Mechanism	Boeing
65-45125-44	Control Stand Upper Mechanism	Boeing
65-45125-45	Control Stand Upper Mechanism	Boeing
65-45125-46	Control Stand Upper Mechanism	Boeing
65-45125-47	Control Stand Upper Mechanism	Boeing
65-45125-48	Control Stand Upper Mechanism	Boeing
65-45125-49	Control Stand Upper Mechanism	Boeing
65-45125-51	Control Stand Upper Mechanism	Boeing
65-45125-54	Control Stand Upper Mechanism	Boeing
65-45125-55	Control Stand Upper Mechanism	Boeing
65-45125-58	Control Stand Upper Mechanism	Boeing
65-45125-62	Control Stand Upper Mechanism	Boeing
65-45125-63	Control Stand Upper Mechanism	Boeing
65-45125-66	Control Stand Upper Mechanism	Boeing
65-45125-67	Control Stand Upper Mechanism	Boeing
65-45125-68	Control Stand Upper Mechanism	Boeing
65-45125-69	Control Stand Upper Mechanism	Boeing
65-45125-70	Control Stand Upper Mechanism	Boeing
65-45125-71	Control Stand Upper Mechanism	Boeing
65-45125-72	Control Stand Upper Mechanism	Boeing
65-45125-73	Control Stand Upper Mechanism	Boeing
65-45125-74	Control Stand Upper Mechanism	Boeing
65-45125-75	Control Stand Upper Mechanism	Boeing
65-45125-76	Control Stand Upper Mechanism	Boeing
65-45125-77	Control Stand Upper Mechanism	Boeing
65-45125-79	Control Stand Upper Mechanism	Boeing
65-45125-81	Control Stand Upper Mechanism	Boeing
65-45125-82	Control Stand Upper Mechanism	Boeing
65-45125-85	Control Stand Upper Mechanism	Boeing
65-45125-86	Control Stand Upper Mechanism	Boeing
65-45133-10	Elevator & Rudder Centering Unit	Boeing
65-45133-11	Elevator & Rudder Centering Unit	Boeing
65-45133-12	Elevator & Rudder Centering Unit	Boeing
65-45133-13	Elevator & Rudder Centering Unit	Boeing
65-45133-14	Elevator & Rudder Centering Unit	Boeing
65-45133-8	Elevator & Rudder Centering Unit	Boeing
65-45133-9	Elevator & Rudder Centering Unit	Boeing
65-45134-3	Rudder & Elevator Feel Actuator Cyl.	Boeing
65-45140-5	Rudder & Elevator Feel Actuator Cyl.	Boeing
65-45142-3	Rudder Control Torque Tube	Boeing
65-45142-4	Rudder Control Torque Tube	Boeing
65-45142-6	Rudder Control Torque Tube	Boeing
65-45142-8	Rudder Control Torque Tube	Boeing
65-45142-9	Rudder Control Torque Tube	Boeing
65-45150	Rudder Control Quadrant	Boeing
65-45160-12	Rudder Power Control Unit	Boeing
65-45160-13	Rudder Power Control Unit	Boeing
65-45160-15	Rudder Power Control Unit	Boeing
65-45160-17	Rudder Power Control Unit	Boeing
65-45160-19	Rudder Power Control Unit	Boeing
65-45160-21	Rudder Power Control Unit	Boeing
65-45160-3	Rudder Power Control Unit	Boeing

Repair_Capability_List_Excel

65-45160-4	Rudder Power Control Unit	Boeing
65-45160-5	Rudder Power Control Unit	Boeing
65-45160-6	Rudder Power Control Unit	Boeing
65-45160-8	Rudder Power Control Unit	Boeing
65-45166-1	Vernier Adjustment Control Rod	Boeing
65-45166-12	Vernier Adjustment Control Rod	Boeing
65-45166-14	Vernier Adjustment Control Rod	Boeing
65-45166-16	Vernier Adjustment Control Rod	Boeing
65-45166-17	Vernier Adjustment Control Rod	Boeing
65-45166-4	Vernier Adjustment Control Rod	Boeing
65-45166-7	Vernier Adjustment Control Rod	Boeing
65-45166-8	Vernier Adjustment Control Rod	Boeing
65-45171-10	Potentiometer Drive Assy	Boeing
65-45171-12	Potentiometer Drive Assy	Boeing
65-45171-16	Potentiometer Drive Assy	Boeing
65-45171-2	Potentiometer Drive Assy	Boeing
65-45171-3	Potentiometer Drive Assy	Boeing
65-45171-7	Potentiometer Drive Assy	Boeing
65-45180-13	Ail.& Elev. Power Control Unit	Boeing
65-45180-18	Ail.& Elev. Power Control Unit	Boeing
65-45180-19	Ail.& Elev. Power Control Unit	Boeing
65-45180-2	Ail.& Elev. Power Control Unit	Boeing
65-45180-22	Ail.& Elev. Power Control Unit	Boeing
65-45180-23	Ail.& Elev. Power Control Unit	Boeing
65-45180-27	Ail.& Elev. Power Control Unit	Boeing
65-45180-29	Ail.& Elev. Power Control Unit	Boeing
65-45180-30	Ail.& Elev. Power Control Unit	Boeing
65-45180-31	Ail.& Elev. Power Control Unit	Boeing
65-45180-34	Ail.& Elev. Power Control Unit	Boeing
65-45180-35	Ail.& Elev. Power Control Unit	Boeing
65-45180-4	Ail.& Elev. Power Control Unit	Boeing
65-45180-5	Ail.& Elev. Power Control Unit	Boeing
65-45180-7	Ail.& Elev. Power Control Unit	Boeing
65-45180-8	Ail.& Elev. Power Control Unit	Boeing
65-45187-10	Elevator Control Torque Tube	Boeing
65-45187-11	Elevator Control Torque Tube	Boeing
65-45187-12	Elevator Control Torque Tube	Boeing
65-45187-13	Elevator Control Torque Tube	Boeing
65-45187-14	Elevator Control Torque Tube	Boeing
65-45187-17	Elevator Control Torque Tube	Boeing
65-45187-2	Elevator Control Torque Tube	Boeing
65-45187-20	Elevator Control Torque Tube	Boeing
65-45187-21	Elevator Control Torque Tube	Boeing
65-45187-22	Elevator Control Torque Tube	Boeing
65-45187-3	Elevator Control Torque Tube	Boeing
65-45187-4	Elevator Control Torque Tube	Boeing
65-45187-501	Elevator Control Torque Tube	Boeing
65-45187-7	Elevator Control Torque Tube	Boeing
65-45187-8	Elevator Control Torque Tube	Boeing
65-45187-9	Elevator Control Torque Tube	Boeing
65-45190-10	Tab Lock Actuator	Boeing
65-45190-3	Elevator Tab Control Mechanism	Boeing
65-45190-4	Tab Lock Actuator	Boeing
65-45190-5	Elevator Tab Control Mechanism	Boeing
65-45190-9	Tab Lock Actuator	Boeing
65-45260-101	Passenger Service Unit	Boeing
65-45260-102	Passenger Service Unit	Boeing
65-45260-103	Passenger Service Unit	Boeing

Repair_Capability_List_Excel

65-45260-192	Passenger Service Unit	Boeing
65-45260-193	Passenger Service Unit	Boeing
65-45260-194	Passenger Service Unit	Boeing
65-45260-195	Passenger Service Unit	Boeing
65-45260-196	Passenger Service Unit	Boeing
65-45260-197	Passenger Service Unit	Boeing
65-45260-198	Passenger Service Unit	Boeing
65-45260-199	Passenger Service Unit	Boeing
65-45260-200	Passenger Service Unit	Boeing
65-45260-201	Passenger Service Unit	Boeing
65-45260-202	Passenger Service Unit	Boeing
65-45398-1	Gearbox assy	Boeing
65-45830-118	Equipment Access Door	Boeing
65-45830-123	Equipment Access Door	Boeing
65-45830-129	Equipment Access Door	Boeing
65-45830-131	Equipment Access Door	Boeing
65-45830-40	Equipment Access Door	Boeing
65-45830-42	Equipment Access Door	Boeing
65-45830-503	Equipment Access Door	Boeing
65-45830-511	Equipment Access Door	Boeing
65-45830-513	Equipment Access Door	Boeing
65-45830-53	Equipment Access Door	Boeing
65-45830-64	Equipment Access Door	Boeing
65-45830-66	Equipment Access Door	Boeing
65-45849-139	Aft Entry/ Galley Door Torque Tube	Boeing
65-45849-159	Aft Galley Door	Boeing
65-45849-160	Aft Entry/ Galley Door Torque Tube	Boeing
65-45849-166	Aft Galley Door	Boeing
65-45849-169	Aft Galley Door	Boeing
65-45849-170	Aft Galley Door	Boeing
65-45849-2	Aft Galley Door	Boeing
65-45849-91	Aft Entry/ Galley Door Torque Tube	Boeing
65-45871-102	FWD Galley Door Torque Tube	Boeing
65-45871-113	FWD Galley Door Torque Tube	Boeing
65-45871-114	Forward Galley Door	Boeing
65-45871-124	Forward Galley Door	Boeing
65-45871-132	Forward Galley Door	Boeing
65-45871-133	Forward Galley Door	Boeing
65-45871-142	FWD Galley Door Torque Tube	Boeing
65-45871-2	Forward Galley Door	Boeing
65-45871-517	Forward Galley Door	Boeing
65-45871-523	Forward Galley Door	Boeing
65-45871-88	FWD Galley Door Torque Tube	Boeing
65-45953-1	Cargo Net Stanchion	Boeing
65-45953-2	Cargo Net Stanchion	Boeing
65-45953-3	Cargo Net Stanchion	Boeing
65-45953-4	Cargo Net Stanchion	Boeing
65-46100-10	Main Gear Shock Strut	Boeing
65-46100-11	Main Gear Shock Strut	Boeing
65-46100-12	Main Gear Shock Strut	Boeing
65-46100-13	Main Gear Shock Strut	Boeing
65-46100-14	Main Gear Shock Strut	Boeing
65-46100-15	Main Gear Shock Strut	Boeing
65-46100-16	Main Gear Shock Strut	Boeing
65-46100-17	Main Gear Shock Strut	Boeing
65-46100-18	Main Gear Shock Strut	Boeing
65-46100-19	Main Gear Shock Strut	Boeing
65-46100-20	Main Gear Shock Strut	Boeing

Repair_Capability_List_Excel

65-46100-21	Main Gear Shock Strut	Boeing
65-46100-22	Main Gear Shock Strut	Boeing
65-46100-23	Main Gear Shock Strut	Boeing
65-46100-24	Main Gear Shock Strut	Boeing
65-46100-25	Main Gear Shock Strut	Boeing
65-46100-26	Main Gear Shock Strut	Boeing
65-46100-27	Main Gear Shock Strut	Boeing
65-46100-28	Main Gear Shock Strut	Boeing
65-46100-29	Main Gear Shock Strut	Boeing
65-46100-30	Main Gear Shock Strut	Boeing
65-46100-31	Main Gear Shock Strut	Boeing
65-46100-33	Main Gear Shock Strut	Boeing
65-46100-34	Main Gear Shock Strut	Boeing
65-46100-35	Main Gear Shock Strut	Boeing
65-46100-36	Main Gear Shock Strut	Boeing
65-46100-37	Main Gear Shock Strut	Boeing
65-46100-38	Main Gear Shock Strut	Boeing
65-46100-39	Main Gear Shock Strut	Boeing
65-46100-40	Main Gear Shock Strut	Boeing
65-46100-41	Main Gear Shock Strut	Boeing
65-46100-42	Main Gear Shock Strut	Boeing
65-46100-43	Main Gear Shock Strut	Boeing
65-46100-44	Main Gear Shock Strut	Boeing
65-46100-45	Main Gear Shock Strut	Boeing
65-46100-46	Main Gear Shock Strut	Boeing
65-46100-47	Main Gear Shock Strut	Boeing
65-46100-48	Main Gear Shock Strut	Boeing
65-46100-49	Main Gear Shock Strut	Boeing
65-46100-5	Main Gear Shock Strut	Boeing
65-46100-50	Main Gear Shock Strut	Boeing
65-46100-51	Main Gear Shock Strut	Boeing
65-46100-52	Main Gear Shock Strut	Boeing
65-46100-53	Main Gear Shock Strut	Boeing
65-46100-54	Main Gear Shock Strut	Boeing
65-46100-55	Main Gear Shock Strut	Boeing
65-46100-56	Main Gear Shock Strut	Boeing
65-46100-57	Main Gear Shock Strut	Boeing
65-46100-58	Main Gear Shock Strut	Boeing
65-46100-59	Main Gear Shock Strut	Boeing
65-46100-6	Main Gear Shock Strut	Boeing
65-46100-60	Main Gear Shock Strut	Boeing
65-46100-61	Main Gear Shock Strut	Boeing
65-46100-62	Main Gear Shock Strut	Boeing
65-46100-63	Main Gear Shock Strut	Boeing
65-46100-64	Main Gear Shock Strut	Boeing
65-46100-65	Main Gear Shock Strut	Boeing
65-46100-66	Main Gear Shock Strut	Boeing
65-46100-67	Main Gear Shock Strut	Boeing
65-46100-68	Main Gear Shock Strut	Boeing
65-46100-69	Main Gear Shock Strut	Boeing
65-46100-70	Main Gear Shock Strut	Boeing
65-46100-71	Main Gear Shock Strut	Boeing
65-46100-72	Main Gear Shock Strut	Boeing
65-46100-73	Main Gear Shock Strut	Boeing
65-46100-74	Main Gear Shock Strut	Boeing
65-46100-75	Main Gear Shock Strut	Boeing
65-46100-76	Main Gear Shock Strut	Boeing
65-46100-77	Main Gear Shock Strut	Boeing

Repair_Capability_List_Excel

65-46100-78	Main Gear Shock Strut	Boeing
65-46100-79	Main Gear Shock Strut	Boeing
65-46100-9	Main Gear Shock Strut	Boeing
65-46141-10	Main Gear Uplock	Boeing
65-46141-11	Main Gear Uplock	Boeing
65-46141-12	Main Gear Uplock	Boeing
65-46141-13	MLG Uplock	Boeing
65-46141-14	MLG Uplock	Boeing
65-46141-15	Main Gear Uplock	Boeing
65-46141-16	Main Gear Uplock	Boeing
65-46141-17	Main Gear Uplock	Boeing
65-46141-18	Main Gear Uplock	Boeing
65-46141-19	Main Gear Uplock	Boeing
65-46141-20	Main Gear Uplock	Boeing
65-46141-21	Main Gear Uplock	Boeing
65-46141-22	Main Gear Uplock	Boeing
65-46141-23	Main Gear Uplock	Boeing
65-46141-24	Main Gear Uplock	Boeing
65-46141-25	Main Gear Uplock	Boeing
65-46141-26	Main Gear Uplock	Boeing
65-46141-5	Main Gear Uplock	Boeing
65-46141-6	Main Gear Uplock	Boeing
65-46141-7	Main Gear Uplock	Boeing
65-46141-8	Main Gear Uplock	Boeing
65-46141-9	Main Gear Uplock	Boeing
65-46204-4	Nose Minor Components	Boeing
65-46205-1	Nose Minor Components	Boeing
65-46205-7	Nose Minor Components	Boeing
65-46205-9	Nose Minor Components	Boeing
65-46230-1	Nose Minor Components	Boeing
65-46230-11	Nose Minor Components	Boeing
65-46230-13	Nose Minor Components	Boeing
65-46230-5	Nose Minor Components	Boeing
65-46230-7	Nose Minor Components	Boeing
65-46230-8	Nose Minor Components	Boeing
65-46232-1	Nose Minor Components	Boeing
65-46232-3	Nose Minor Components	Boeing
65-46232-5	Nose Minor Components	Boeing
65-46232-6	Nose Minor Components	Boeing
65-46245-1	Nose Gear Lock Link	Boeing
65-46245-10	Nose Gear Lock Link	Boeing
65-46245-11	Nose Gear Lock Link	Boeing
65-46245-12	Nose Gear Lock Link	Boeing
65-46245-13	Nose Gear Lock Link	Boeing
65-46245-14	Nose Gear Lock Link	Boeing
65-46245-3	Nose Gear Lock Link	Boeing
65-46245-4	Nose Gear Lock Link	Boeing
65-46245-5	Nose Gear Lock Link	Boeing
65-46245-6	Nose Gear Lock Link	Boeing
65-46245-7	Nose Gear Lock Link	Boeing
65-46245-8	Nose Gear Lock Link	Boeing
65-46245-9	Nose Gear Lock Link	Boeing
65-46329-12	Mechanism	Boeing
65-46329-13	Mechanism	Boeing
65-46329-15	Mechanism	Boeing
65-46329-17	Mechanism	Boeing
65-46329-19	Mechanism	Boeing
65-46329-2	Mechanism	Boeing

Repair_Capability_List_Excel

65-46329-21	Mechanism	Boeing
65-46329-6	Mechanism	Boeing
65-46360-2	Spoiler Mixer	Boeing
65-46360-3	Spoiler Mixer	Boeing
65-46360-4	Spoiler Mixer	Boeing
65-46360-5	Spoiler Mixer	Boeing
65-46360-6	Spoiler Mixer	Boeing
65-46360-7	Spoiler Mixer	Boeing
65-46370-10	Ratio Changer Assy	Boeing
65-46370-11	Ratio Changer Assy	Boeing
65-46370-12	Ratio Changer Assy	Boeing
65-46370-13	Ratio Changer Assy	Boeing
65-46370-14	Ratio Changer Assy	Boeing
65-46370-15	Ratio Changer Assy	Boeing
65-46370-16	Ratio Changer Assy	Boeing
65-46370-17	Ratio Changer Assy	Boeing
65-46370-18	Ratio Changer Assy	Boeing
65-46370-19	Ratio Changer Assy	Boeing
65-46370-20	Ratio Changer Assy	Boeing
65-46370-21	Ratio Changer assy	Boeing
65-46370-23	Ratio Changer assy	Boeing
65-46370-3	Ratio Changer Assy	Boeing
65-46370-4	Ratio Changer Assy	Boeing
65-46370-5	Ratio Changer Assy	Boeing
65-46370-6	Ratio Changer Assy	Boeing
65-46370-7	Ratio Changer Assy	Boeing
65-46370-8	Ratio Changer Assy	Boeing
65-46370-9	Ratio Changer Assy	Boeing
65-46375-12	Brake Pedal Bus	Boeing
65-46375-13	Brake Pedal Bus	Boeing
65-46375-14	Brake Pedal Bus	Boeing
65-46375-15	Brake Pedal Bus	Boeing
65-46375-16	Brake Pedal Bus	Boeing
65-46375-17	Brake Pedal Bus	Boeing
65-46375-19	Brake Pedal Bus	Boeing
65-46375-20	Brake Pedal Bus	Boeing
65-46375-21	Brake Pedal Bus	Boeing
65-46375-22	Brake Pedal Bus	Boeing
65-46375-3	Brake Pedal Bus	Boeing
65-46375-4	Brake Pedal Bus	Boeing
65-46375-503	Brake Pedal Bus	Boeing
65-46375-504	Brake Pedal Bus	Boeing
65-46375-505	Brake Pedal Bus	Boeing
65-46375-506	Brake Pedal Bus	Boeing
65-46428-1	Flap Track assy	Boeing
65-46428-11	Flap Track assy	Boeing
65-46428-14	Flap Track assy	Boeing
65-46428-15	Flap Track assy	Boeing
65-46428-16	Flap Track assy	Boeing
65-46428-17	Flap Track assy	Boeing
65-46428-18	Flap Track assy	Boeing
65-46428-19	Flap Track assy	Boeing
65-46428-2	Flap Track assy	Boeing
65-46428-20	Flap Track assy	Boeing
65-46428-21	Flap Track assy	Boeing
65-46428-22	Flap Track assy	Boeing
65-46428-23	Flap Track assy	Boeing
65-46428-24	Flap Track assy	Boeing

Repair_Capability_List_Excel

65-46428-25	Flap Track assy	Boeing
65-46428-3	Flap Track assy	Boeing
65-46428-30	Flap Track assy	Boeing
65-46428-31	Flap Track assy	Boeing
65-46428-32	Flap Track assy	Boeing
65-46428-33	Flap Track assy	Boeing
65-46428-34	Flap Track assy	Boeing
65-46428-35	Flap Track assy	Boeing
65-46428-4	Flap Track assy	Boeing
65-46428-5	Flap Track assy	Boeing
65-46428-6	Flap Track assy	Boeing
65-46428-7	Flap Track assy	Boeing
65-46428-8	Flap Track assy	Boeing
65-46428-9	Flap Track assy	Boeing
65-46435-237 SP	Aft Flap	Boeing
65-46435-238 SP	Aft Flap	Boeing
65-46435-273 SP	Aft Flap	Boeing
65-46435-274 SP	Aft Flap	Boeing
65-46435-277 SP	Aft Flap	Boeing
65-46435-278 SP	Aft Flap	Boeing
65-46435-281 SP	Aft Flap	Boeing
65-46435-282 SP	Aft Flap	Boeing
65-46435-303 SP	Aft Flap	Boeing
65-46435-304 SP	Aft Flap	Boeing
65-46435-317 SP	Aft Flap	Boeing
65-46435-318 SP	Aft Flap	Boeing
65-46435-329 SP	Aft Flap	Boeing
65-46435-330 SP	Aft Flap	Boeing
65-46435-331 SP	Aft Flap	Boeing
65-46435-332 SP	Aft Flap	Boeing
65-46435-333 SP	Aft Flap	Boeing
65-46435-334 SP	Aft Flap	Boeing
65-46435-335 SP	Aft Flap	Boeing
65-46435-336 SP	Aft Flap	Boeing
65-46435-337 SP	Aft Flap	Boeing
65-46435-338 SP	Aft Flap	Boeing
65-46436-11	Inboard Trailing Edge Flap	Boeing
65-46436-12	Inboard Trailing Edge Flap	Boeing
65-46436-13	Inboard Trailing Edge Flap	Boeing
65-46436-14	Inboard Trailing Edge Flap	Boeing
65-46436-15	Inboard Trailing Edge Flap	Boeing
65-46436-16	Inboard Trailing Edge Flap	Boeing
65-46436-17	Inboard Trailing Edge Flap	Boeing
65-46436-18	Inboard Trailing Edge Flap	Boeing
65-46436-19	Inboard Trailing Edge Flap	Boeing
65-46436-20	Inboard Trailing Edge Flap	Boeing
65-46436-21	Inboard Trailing Edge Flap	Boeing
65-46436-22	Inboard Trailing Edge Flap	Boeing
65-46436-23	Inboard Trailing Edge Flap	Boeing
65-46436-24	Inboard Trailing Edge Flap	Boeing
65-46436-31	Inboard Trailing Edge Flap	Boeing
65-46436-32	Inboard Trailing Edge Flap	Boeing
65-46436-33 SP	Inboard Trailing Edge Flap	Boeing
65-46436-34 SP	Inboard Trailing Edge Flap	Boeing
65-46436-35 SP	Inboard Trailing Edge Flap	Boeing
65-46436-36 SP	Inboard Trailing Edge Flap	Boeing
65-46436-39 SP	Inboard Trailing Edge Flap	Boeing
65-46436-40 SP	Inboard Trailing Edge Flap	Boeing

Repair_Capability_List_Excel

65-46436-41 SP	Inboard Trailing Edge Flap	Boeing
65-46436-42 SP	Inboard Trailing Edge Flap	Boeing
65-46436-43 SP	Inboard Trailing Edge Flap	Boeing
65-46436-44 SP	Inboard Trailing Edge Flap	Boeing
65-46436-45 SP	Inboard Trailing Edge Flap	Boeing
65-46436-46 SP	Inboard Trailing Edge Flap	Boeing
65-46436-5	Inboard Trailing Edge Flap	Boeing
65-46436-51 SP	Inboard Trailing Edge Flap	Boeing
65-46436-52 SP	Inboard Trailing Edge Flap	Boeing
65-46436-53 SP	Inboard Trailing Edge Flap	Boeing
65-46436-54 SP	Inboard Trailing Edge Flap	Boeing
65-46436-55 SP	Inboard Trailing Edge Flap	Boeing
65-46436-56 SP	Inboard Trailing Edge Flap	Boeing
65-46436-57 SP	Inboard Trailing Edge Flap	Boeing
65-46436-58 SP	Inboard Trailing Edge Flap	Boeing
65-46436-59	Inboard Trailing Edge Flap	Boeing
65-46436-6	Inboard Trailing Edge Flap	Boeing
65-46436-60	Inboard Trailing Edge Flap	Boeing
65-46436-61 SP	Inboard Trailing Edge Flap	Boeing
65-46436-62 SP	Inboard Trailing Edge Flap	Boeing
65-46436-63 SP	Inboard Trailing Edge Flap	Boeing
65-46436-64 SP	Inboard Trailing Edge Flap	Boeing
65-46436-65 SP	Inboard Trailing Edge Flap	Boeing
65-46436-66 SP	Inboard Trailing Edge Flap	Boeing
65-46436-69 SP	Inboard Trailing Edge Flap	Boeing
65-46436-7	Inboard Trailing Edge Flap	Boeing
65-46436-70 SP	Inboard Trailing Edge Flap	Boeing
65-46436-71 SP	Inboard Trailing Edge Flap	Boeing
65-46436-72 SP	Inboard Trailing Edge Flap	Boeing
65-46436-8	Inboard Trailing Edge Flap	Boeing
65-46437-1	Outboard Trailing Edge Flap	Boeing
65-46437-10	Outboard Trailing Edge Flap	Boeing
65-46437-11	Outboard Trailing Edge Flap	Boeing
65-46437-12	Outboard Trailing Edge Flap	Boeing
65-46437-13	Outboard Trailing Edge Flap	Boeing
65-46437-14	Outboard Trailing Edge Flap	Boeing
65-46437-15	Outboard Trailing Edge Flap	Boeing
65-46437-16	Outboard Trailing Edge Flap	Boeing
65-46437-17	Outboard Trailing Edge Flap	Boeing
65-46437-18	Outboard Trailing Edge Flap	Boeing
65-46437-19	Outboard Trailing Edge Flap	Boeing
65-46437-2	Outboard Trailing Edge Flap	Boeing
65-46437-20	Outboard Trailing Edge Flap	Boeing
65-46437-25	Outboard Trailing Edge Flap	Boeing
65-46437-26	Outboard Trailing Edge Flap	Boeing
65-46437-3	Outboard Trailing Edge Flap	Boeing
65-46437-31	Outboard Trailing Edge Flap	Boeing
65-46437-32	Outboard Trailing Edge Flap	Boeing
65-46437-37	Outboard Trailing Edge Flap	Boeing
65-46437-38	Outboard Trailing Edge Flap	Boeing
65-46437-4	Outboard Trailing Edge Flap	Boeing
65-46437-5	Outboard Trailing Edge Flap	Boeing
65-46437-6	Outboard Trailing Edge Flap	Boeing
65-46437-7	Outboard Trailing Edge Flap	Boeing
65-46437-8	Outboard Trailing Edge Flap	Boeing
65-46437-9	Outboard Trailing Edge Flap	Boeing
65-46438-1	Flap Track assy	Boeing
65-46438-10	Flap Track assy	Boeing

Repair_Capability_List_Excel

65-46438-11	Flap Track assy	Boeing
65-46438-12	Flap Track assy	Boeing
65-46438-13	Flap Track assy	Boeing
65-46438-14	Flap Track assy	Boeing
65-46438-15	Flap Track assy	Boeing
65-46438-2	Flap Track assy	Boeing
65-46438-4	Flap Track assy	Boeing
65-46438-5	Flap Track assy	Boeing
65-46438-6	Flap Track assy	Boeing
65-46438-7	Flap Track assy	Boeing
65-46438-8	Flap Track assy	Boeing
65-46438-9	Flap Track assy	Boeing
65-46439-1	Flap Track assy	Boeing
65-46439-10	Flap Track assy	Boeing
65-46439-11	Flap Track assy	Boeing
65-46439-12	Flap Track assy	Boeing
65-46439-14	Flap Track assy	Boeing
65-46439-15	Flap Track assy	Boeing
65-46439-16	Flap Track assy	Boeing
65-46439-17	Flap Track assy	Boeing
65-46439-18	Flap Track assy	Boeing
65-46439-19	Flap Track assy	Boeing
65-46439-2	Flap Track assy	Boeing
65-46439-20	Flap Track assy	Boeing
65-46439-21	Flap Track assy	Boeing
65-46439-22	Flap Track assy	Boeing
65-46439-23	Flap Track assy	Boeing
65-46439-24	Flap Track assy	Boeing
65-46439-25	Flap Track assy	Boeing
65-46439-26	Flap Track assy	Boeing
65-46439-27	Flap Track assy	Boeing
65-46439-28	Flap Track assy	Boeing
65-46439-3	Flap Track assy	Boeing
65-46439-4	Flap Track assy	Boeing
65-46439-5	Flap Track assy	Boeing
65-46439-6	Flap Track assy	Boeing
65-46439-7	Flap Track assy	Boeing
65-46439-8	Flap Track assy	Boeing
65-46481-1	Carriage assy	Boeing
65-46481-101	Carriage assy	Boeing
65-46481-102	Carriage assy	Boeing
65-46481-103	Carriage assy	Boeing
65-46481-104	Carriage assy	Boeing
65-46481-105	Carriage assy	Boeing
65-46481-106	Carriage assy	Boeing
65-46481-107	Carriage assy	Boeing
65-46481-108	Carriage assy	Boeing
65-46481-109	Carriage assy	Boeing
65-46481-11	Carriage assy	Boeing
65-46481-110	Carriage assy	Boeing
65-46481-111	Carriage assy	Boeing
65-46481-112	Carriage assy	Boeing
65-46481-113	Carriage assy	Boeing
65-46481-114	Carriage assy	Boeing
65-46481-115	Carriage assy	Boeing
65-46481-116	Carriage assy	Boeing
65-46481-117	Carriage assy	Boeing
65-46481-118	Carriage assy	Boeing

Repair_Capability_List_Excel

65-46481-119	Carriage assy	Boeing
65-46481-12	Carriage assy	Boeing
65-46481-120	Carriage assy	Boeing
65-46481-121	Carriage assy	Boeing
65-46481-122	Carriage assy	Boeing
65-46481-123	Carriage assy	Boeing
65-46481-124	Carriage assy	Boeing
65-46481-13	Carriage assy	Boeing
65-46481-133	Carriage assy	Boeing
65-46481-134	Carriage assy	Boeing
65-46481-135	Carriage assy	Boeing
65-46481-136	Carriage assy	Boeing
65-46481-14	Carriage assy	Boeing
65-46481-15	Carriage assy	Boeing
65-46481-16	Carriage assy	Boeing
65-46481-17	Carriage assy	Boeing
65-46481-18	Carriage assy	Boeing
65-46481-19	Carriage assy	Boeing
65-46481-20	Carriage assy	Boeing
65-46481-21	Carriage assy	Boeing
65-46481-22	Carriage assy	Boeing
65-46481-23	Carriage assy	Boeing
65-46481-24	Carriage assy	Boeing
65-46481-25	Carriage assy	Boeing
65-46481-26	Carriage assy	Boeing
65-46481-27	Carriage assy	Boeing
65-46481-28	Carriage assy	Boeing
65-46481-31	Carriage assy	Boeing
65-46481-32	Carriage assy	Boeing
65-46481-33	Carriage assy	Boeing
65-46481-34	Carriage assy	Boeing
65-46481-37	Carriage assy	Boeing
65-46481-38	Carriage assy	Boeing
65-46481-39	Carriage assy	Boeing
65-46481-40	Carriage assy	Boeing
65-46481-41	Carriage assy	Boeing
65-46481-42	Carriage assy	Boeing
65-46481-45	Carriage assy	Boeing
65-46481-46	Carriage assy	Boeing
65-46481-47	Carriage assy	Boeing
65-46481-48	Carriage assy	Boeing
65-46481-49	Carriage assy	Boeing
65-46481-50	Carriage assy	Boeing
65-46481-51	Carriage assy	Boeing
65-46481-52	Carriage assy	Boeing
65-46481-53	Carriage assy	Boeing
65-46481-54	Carriage assy	Boeing
65-46481-55	Carriage assy	Boeing
65-46481-56	Carriage assy	Boeing
65-46481-57	Carriage assy	Boeing
65-46481-58	Carriage assy	Boeing
65-46481-59	Carriage assy	Boeing
65-46481-60	Carriage assy	Boeing
65-46481-61	Carriage assy	Boeing
65-46481-62	Carriage assy	Boeing
65-46481-63	Carriage assy	Boeing
65-46481-64	Carriage assy	Boeing
65-46481-65	Carriage assy	Boeing

Repair_Capability_List_Excel

65-46481-66	Carriage assy	Boeing
65-46481-67	Carriage assy	Boeing
65-46481-68	Carriage assy	Boeing
65-46481-69	Carriage assy	Boeing
65-46481-70	Carriage assy	Boeing
65-46481-72	Carriage assy	Boeing
65-46481-73	Carriage assy	Boeing
65-46481-74	Carriage assy	Boeing
65-46481-75	Carriage assy	Boeing
65-46481-76	Carriage assy	Boeing
65-46481-77	Carriage assy	Boeing
65-46481-78	Carriage assy	Boeing
65-46481-79	Carriage assy	Boeing
65-46481-8	Carriage assy	Boeing
65-46481-80	Carriage assy	Boeing
65-46481-81	Carriage assy	Boeing
65-46481-82	Carriage assy	Boeing
65-46481-83	Carriage assy	Boeing
65-46481-84	Carriage assy	Boeing
65-46481-85	Carriage assy	Boeing
65-46481-86	Carriage assy	Boeing
65-46481-87	Carriage assy	Boeing
65-46481-88	Carriage assy	Boeing
65-46481-89	Carriage assy	Boeing
65-46481-90	Carriage assy	Boeing
65-46481-91	Carriage assy	Boeing
65-46481-92	Carriage assy	Boeing
65-46481-93	Carriage assy	Boeing
65-46481-94	Carriage assy	Boeing
65-46481-95	Carriage assy	Boeing
65-46481-96	Carriage assy	Boeing
65-46481-97	Carriage assy	Boeing
65-46481-98	Carriage assy	Boeing
65-46492-1	Carriage assy	Boeing
65-46492-2	Carriage assy	Boeing
65-46591-1	Aft Cargo Door	Boeing
65-46591-523	Aft Cargo Door	Boeing
65-46921-1	Forward Cargo Door	Boeing
65-46921-132	Forward Cargo Door	Boeing
65-46921-160	Forward Cargo Door	Boeing
65-46921-225	Forward Cargo Door	Boeing
65-46921-230	Forward Cargo Door	Boeing
65-46921-528	Forward Cargo Door	Boeing
65-47836-12	Outb.Flap Sequencing Carriage & Toggle	Boeing
65-47836-8	Outb.Flap Sequencing Carriage & Toggle	Boeing
65-47836-9	Outb.Flap Sequencing Carriage & Toggle	Boeing
65-47890-SERIES	Tack assy	Boeing
65-47894-3	Tack assy	Boeing
65-47901-1	Tack assy	Boeing
65-47952-1	Aft Cargo Door	Boeing
65-47952-166	Aft Cargo Door	Boeing
65-47952-183	Aft Cargo Door	Boeing
65-47952-230	Aft Cargo Door	Boeing
65-47952-337	Aft Cargo Door	Boeing
65-47952-340	Aft Cargo Door	Boeing
65-47952-358	Aft Cargo Door	Boeing
65-47952-524	Aft Cargo Door	Boeing
65-49110-1	Cargo System Roller Tray	Boeing

Repair_Capability_List_Excel

65-49110-10	Cargo System Roller Tray	Boeing
65-49110-11	Cargo System Roller Tray	Boeing
65-49110-12	Cargo System Roller Tray	Boeing
65-49110-13	Cargo System Roller Tray	Boeing
65-49110-14	Cargo System Roller Tray	Boeing
65-49110-15	Cargo System Roller Tray	Boeing
65-49110-16	Cargo System Roller Tray	Boeing
65-49110-17	Cargo System Roller Tray	Boeing
65-49110-18	Cargo System Roller Tray	Boeing
65-49110-19	Cargo System Roller Tray	Boeing
65-49110-2	Cargo System Roller Tray	Boeing
65-49110-23	Cargo System Roller Tray	Boeing
65-49110-25	Cargo System Roller Tray	Boeing
65-49110-26	Cargo System Roller Tray	Boeing
65-49110-3	Cargo System Roller Tray	Boeing
65-49110-33	Cargo System Roller Tray	Boeing
65-49110-35	Cargo System Roller Tray	Boeing
65-49110-36	Cargo System Roller Tray	Boeing
65-49110-4	Cargo System Roller Tray	Boeing
65-49110-45	Cargo System Roller Tray	Boeing
65-49110-46	Cargo System Roller Tray	Boeing
65-49110-5	Cargo System Roller Tray	Boeing
65-49110-53	Cargo System Roller Tray	Boeing
65-49110-55	Cargo System Roller Tray	Boeing
65-49110-56	Cargo System Roller Tray	Boeing
65-49110-6	Cargo System Roller Tray	Boeing
65-49110-7	Cargo System Roller Tray	Boeing
65-49110-8	Cargo System Roller Tray	Boeing
65-49110-9	Cargo System Roller Tray	Boeing
65-49115-1	Cargo Pallet Lock	Boeing
65-49115-10	Cargo Pallet Lock	Boeing
65-49115-11	Cargo Pallet Lock	Boeing
65-49115-12	Cargo Pallet Lock	Boeing
65-49115-13	Cargo Pallet Lock	Boeing
65-49115-15	Cargo Pallet Lock	Boeing
65-49115-16	Cargo Pallet Lock	Boeing
65-49115-17	Cargo Pallet Lock	Boeing
65-49115-18	Cargo Pallet Lock	Boeing
65-49115-19	Cargo Pallet Lock	Boeing
65-49115-2	Cargo Pallet Lock	Boeing
65-49115-20	Cargo Pallet Lock	Boeing
65-49115-21	Cargo Pallet Lock	Boeing
65-49115-22	Cargo Pallet Lock	Boeing
65-49115-23	Cargo Pallet Lock	Boeing
65-49115-24	Cargo Pallet Lock	Boeing
65-49115-25	Cargo Pallet Lock	Boeing
65-49115-26	Cargo Pallet Lock	Boeing
65-49115-27	Cargo Pallet Lock	Boeing
65-49115-28	Cargo Pallet Lock	Boeing
65-49115-29	Cargo Pallet Lock	Boeing
65-49115-3	Cargo Pallet Lock	Boeing
65-49115-30	Cargo Pallet Lock	Boeing
65-49115-31	Cargo Pallet Lock	Boeing
65-49115-32	Cargo Pallet Lock	Boeing
65-49115-33	Cargo Pallet Lock	Boeing
65-49115-34	Cargo Pallet Lock	Boeing
65-49115-35	Cargo Pallet Lock	Boeing
65-49115-36	Cargo Pallet Lock	Boeing

Repair_Capability_List_Excel

65-49115-37	Cargo Pallet Lock	Boeing
65-49115-38	Cargo Pallet Lock	Boeing
65-49115-4	Cargo Pallet Lock	Boeing
65-49115-5	Cargo Pallet Lock	Boeing
65-49115-6	Cargo Pallet Lock	Boeing
65-49115-7	Cargo Pallet Lock	Boeing
65-49115-8	Cargo Pallet Lock	Boeing
65-49115-9	Cargo Pallet Lock	Boeing
65-49116-1	QC Cargo System Pallet Lock	Boeing
65-49116-10	QC Cargo System Pallet Lock	Boeing
65-49116-11	QC Cargo System Pallet Lock	Boeing
65-49116-18	QC Cargo System Pallet Lock	Boeing
65-49116-19	QC Cargo System Pallet Lock	Boeing
65-49116-2	QC Cargo System Pallet Lock	Boeing
65-49116-20	QC Cargo System Pallet Lock	Boeing
65-49116-21	QC Cargo System Pallet Lock	Boeing
65-49116-22	QC Cargo System Pallet Lock	Boeing
65-49116-3	QC Cargo System Pallet Lock	Boeing
65-49116-4	QC Cargo System Pallet Lock	Boeing
65-49116-5	QC Cargo System Pallet Lock	Boeing
65-49116-6	QC Cargo System Pallet Lock	Boeing
65-49116-7	QC Cargo System Pallet Lock	Boeing
65-49116-8	QC Cargo System Pallet Lock	Boeing
65-49116-9	QC Cargo System Pallet Lock	Boeing
65-49118-1	QC Cargo System Seat Pallet Latch	Boeing
65-49118-10	QC Cargo System Seat Pallet Latch	Boeing
65-49118-11	QC Cargo System Seat Pallet Latch	Boeing
65-49118-12	QC Cargo System Seat Pallet Latch	Boeing
65-49118-13	QC Cargo System Seat Pallet Latch	Boeing
65-49118-14	QC Cargo System Seat Pallet Latch	Boeing
65-49118-15	QC Cargo System Seat Pallet Latch	Boeing
65-49118-16	QC Cargo System Seat Pallet Latch	Boeing
65-49118-17	QC Cargo System Seat Pallet Latch	Boeing
65-49118-19	QC Cargo System Seat Pallet Latch	Boeing
65-49118-2	QC Cargo System Seat Pallet Latch	Boeing
65-49118-20	QC Cargo System Seat Pallet Latch	Boeing
65-49118-21	QC Cargo System Seat Pallet Latch	Boeing
65-49118-22	QC Cargo System Seat Pallet Latch	Boeing
65-49118-23	QC Cargo System Seat Pallet Latch	Boeing
65-49118-24	QC Cargo System Seat Pallet Latch	Boeing
65-49118-25	QC Cargo System Seat Pallet Latch	Boeing
65-49118-26	QC Cargo System Seat Pallet Latch	Boeing
65-49118-27	QC Cargo System Seat Pallet Latch	Boeing
65-49118-3	QC Cargo System Seat Pallet Latch	Boeing
65-49118-5	QC Cargo System Seat Pallet Latch	Boeing
65-49118-6	QC Cargo System Seat Pallet Latch	Boeing
65-49118-7	QC Cargo System Seat Pallet Latch	Boeing
65-49118-8	QC Cargo System Seat Pallet Latch	Boeing
65-49118-9	QC Cargo System Seat Pallet Latch	Boeing
65-49140-1	QC Cargo System Side Restraint	Boeing
65-49140-10	QC Cargo System Side Restraint	Boeing
65-49140-11	QC Cargo System Side Restraint	Boeing
65-49140-12	QC Cargo System Side Restraint	Boeing
65-49140-13	QC Cargo System Side Restraint	Boeing
65-49140-14	QC Cargo System Side Restraint	Boeing
65-49140-15	QC Cargo System Side Restraint	Boeing
65-49140-16	QC Cargo System Side Restraint	Boeing
65-49140-17	QC Cargo System Side Restraint	Boeing

Repair_Capability_List_Excel

65-49140-18	QC Cargo System Side Restraint	Boeing
65-49140-19	QC Cargo System Side Restraint	Boeing
65-49140-2	QC Cargo System Side Restraint	Boeing
65-49140-20	QC Cargo System Side Restraint	Boeing
65-49140-21	QC Cargo System Side Restraint	Boeing
65-49140-22	QC Cargo System Side Restraint	Boeing
65-49140-23	QC Cargo System Side Restraint	Boeing
65-49140-24	QC Cargo System Side Restraint	Boeing
65-49140-25	QC Cargo System Side Restraint	Boeing
65-49140-26	QC Cargo System Side Restraint	Boeing
65-49140-27	QC Cargo System Side Restraint	Boeing
65-49140-28	QC Cargo System Side Restraint	Boeing
65-49140-29	QC Cargo System Side Restraint	Boeing
65-49140-3	QC Cargo System Side Restraint	Boeing
65-49140-30	QC Cargo System Side Restraint	Boeing
65-49140-31	QC Cargo System Side Restraint	Boeing
65-49140-32	QC Cargo System Side Restraint	Boeing
65-49140-4	QC Cargo System Side Restraint	Boeing
65-49140-5	QC Cargo System Side Restraint	Boeing
65-49140-6	QC Cargo System Side Restraint	Boeing
65-49140-7	QC Cargo System Side Restraint	Boeing
65-49140-8	QC Cargo System Side Restraint	Boeing
65-49140-9	QC Cargo System Side Restraint	Boeing
65-49389-1	Chassis Assy	Boeing
65-49389-17	Chassis Assy	Boeing
65-49389-2	Chassis Assy	Boeing
65-49389-22	Chassis Assy	Boeing
65-49389-23	Chassis Assy	Boeing
65-49389-31	Chassis Assy	Boeing
65-49389-9	Chassis Assy	Boeing
65-49529-11	Bellcrank assy	Boeing
65-49529-12	Bellcrank assy	Boeing
65-49529-15	Bellcrank assy	Boeing
65-49529-16	Bellcrank assy	Boeing
65-49529-17	Bellcrank assy	Boeing
65-49529-18	Bellcrank assy	Boeing
65-49529-19	Bellcrank assy	Boeing
65-49529-20	Bellcrank assy	Boeing
65-49529-21	Bellcrank assy	Boeing
65-49529-22	Bellcrank assy	Boeing
65-49529-23	Bellcrank assy	Boeing
65-49529-24	Bellcrank assy	Boeing
65-49580-11	Flight Spoiler Power Control Unit	Boeing
65-49580-12	Flight Spoiler Power Control Unit	Boeing
65-49580-13	Flight Spoiler Power Control Unit	Boeing
65-49580-14	Flight Spoiler Power Control Unit	Boeing
65-49580-15	Flight Spoiler Power Control Unit	Boeing
65-49580-16	Flight Spoiler Power Control Unit	Boeing
65-49580-17	Flight Spoiler Power Control Unit	Boeing
65-49580-18	Flight Spoiler Power Control Unit	Boeing
65-49580-19	Flight Spoiler Power Control Unit	Boeing
65-49580-20	Flight Spoiler Power Control Unit	Boeing
65-49580-21	Flight Spoiler Power Control Unit	Boeing
65-49582-10	Aileron Control Shaft Assy	Boeing
65-49582-11	Aileron Control Shaft Assy	Boeing
65-49582-12	Aileron Control Shaft Assy	Boeing
65-49582-16	Aileron Control Shaft Assy	Boeing
65-49582-17	Aileron Control Shaft Assy	Boeing

Repair_Capability_List_Excel

65-49582-18	Aileron Control Shaft Assy	Boeing
65-49582-19	Aileron Control Shaft Assy	Boeing
65-49582-2	Aileron Control Shaft Assy	Boeing
65-49582-20	Aileron Control Shaft Assy	Boeing
65-49582-21	Aileron Control Shaft Assy	Boeing
65-49582-22	Aileron Control Shaft Assy	Boeing
65-49582-23	Aileron Control Shaft Assy	Boeing
65-49582-6	Aileron Control Shaft Assy	Boeing
65-49582-8	Aileron Control Shaft Assy	Boeing
65-49582-9	Aileron Control Shaft Assy	Boeing
65-49662-1	Passenger Water System Tank	Boeing
65-49662-10	Passenger Water System Tank	Boeing
65-49662-12	Passenger Water System Tank	Boeing
65-49662-13	Passenger Water System Tank	Boeing
65-49662-14	Passenger Water System Tank	Boeing
65-49662-15	Passenger Water System Tank	Boeing
65-49662-17	Passenger Water System Tank	Boeing
65-49662-18	Passenger Water System Tank	Boeing
65-49662-19	Passenger Water System Tank	Boeing
65-49662-2	Passenger Water System Tank	Boeing
65-49662-21	Passenger Water System Tank	Boeing
65-49662-24	Passenger Water System Tank	Boeing
65-49662-25	Passenger Water System Tank	Boeing
65-49662-26	Passenger Water System Tank	Boeing
65-49662-27	Passenger Water System Tank	Boeing
65-49662-28	Passenger Water System Tank	Boeing
65-49662-29	Passenger Water System Tank	Boeing
65-49662-3	Passenger Water System Tank	Boeing
65-49662-30	Passenger Water System Tank	Boeing
65-49662-31	Passenger Water System Tank	Boeing
65-49662-32	Passenger Water System Tank	Boeing
65-49662-33	Passenger Water System Tank	Boeing
65-49662-34	Passenger Water System Tank	Boeing
65-49662-35	Passenger Water System Tank	Boeing
65-49662-36	Passenger Water System Tank	Boeing
65-49662-37	Passenger Water System Tank	Boeing
65-49662-4	Passenger Water System Tank	Boeing
65-49662-5	Passenger Water System Tank	Boeing
65-49662-6	Passenger Water System Tank	Boeing
65-49662-7	Passenger Water System Tank	Boeing
65-49662-8	Passenger Water System Tank	Boeing
65-49662-9	Passenger Water System Tank	Boeing
65-49808-1	Relay Module	Boeing
65-49808-16	Relay Module	Boeing
65-49808-18	Relay Module	Boeing
65-49808-19	Relay Module	Boeing
65-49808-21	Relay Module	Boeing
65-49808-24	Relay Module	Boeing
65-49808-26	Relay Module	Boeing
65-49808-29	Relay Module	Boeing
65-49808-30	Relay Module	Boeing
65-49808-31	Relay Module	Boeing
65-49808-32	Relay Module	Boeing
65-49808-33	Relay Module	Boeing
65-49808-34	Relay Module	Boeing
65-49808-35	Relay Module	Boeing
65-49808-36	Relay Module	Boeing
65-49808-4	Relay Module	Boeing

Repair_Capability_List_Excel

65-49808-9	Relay Module	Boeing
65-49874-10	Hyd.System Aileron Power Control	Boeing
65-49874-11	Hyd.System Aileron Power Control	Boeing
65-49874-15	Ail.& Elev. Power Control Unit	Boeing
65-49874-16	Hyd.System Aileron Power Control	Boeing
65-49874-17	Hyd.System Aileron Power Control	Boeing
65-49874-21	Hyd.System Aileron Power Control	Boeing
65-49874-22	Hyd.System Aileron Power Control	Boeing
65-49874-23	Hyd.System Aileron Power Control	Boeing
65-49874-24	Hyd.System Aileron Power Control	Boeing
65-49874-28	Ail.& Elev. Power Control Unit	Boeing
65-49874-29	Ail.& Elev. Power Control Unit	Boeing
65-49874-30	Ail.& Elev. Power Control Unit	Boeing
65-49874-32	Ail.& Elev. Power Control Unit	Boeing
65-49874-34	Ail.& Elev. Power Control Unit	Boeing
65-49874-37	Ail.& Elev. Power Control Unit	Boeing
65-49874-39	Ail.& Elev. Power Control Unit	Boeing
65-49874-40	Ail.& Elev. Power Control Unit	Boeing
65-49874-43	Ail.& Elev. Power Control Unit	Boeing
65-49874-44	Ail.& Elev. Power Control Unit	Boeing
65-49874-47	Ail.& Elev. Power Control Unit	Boeing
65-49874-48	Ail.& Elev. Power Control Unit	Boeing
65-49874-49	Ail.& Elev. Power Control Unit	Boeing
65-49874-50	Ail.& Elev. Power Control Unit	Boeing
65-49874-52	Ail.& Elev. Power Control Unit	Boeing
65-49874-54	Ail.& Elev. Power Control Unit	Boeing
65-49874-56	Hyd.System Aileron Power Control	Boeing
65-49874-57	Hyd.System Aileron Power Control	Boeing
65-49874-60	Hyd.System Aileron Power Control	Boeing
65-49874-61	Hyd.System Aileron Power Control	Boeing
65-49874-62	Hyd.System Aileron Power Control	Boeing
65-49874-63	Hyd.System Aileron Power Control	Boeing
65-49874-64	Hyd.System Aileron Power Control	Boeing
65-49970-1	Stabilizer Trim Actuator	Boeing
65-49970-10	Stabilizer Trim Actuator	Boeing
65-49970-12	Stabilizer Trim Actuator	Boeing
65-49970-13	Stabilizer Trim Actuator	Boeing
65-49970-14	Stabilizer Trim Actuator	Boeing
65-49970-15	Stabilizer Trim Actuator	Boeing
65-49970-17	Stabilizer Trim Actuator	Boeing
65-49970-18	Stabilizer Trim Actuator	Boeing
65-49970-19	Stabilizer Trim Actuator	Boeing
65-49970-2	Stabilizer Trim Actuator	Boeing
65-49970-20	Stabilizer Trim Actuator	Boeing
65-49970-21	Stabilizer Trim Actuator	Boeing
65-49970-22	Stabilizer Trim Actuator	Boeing
65-49970-23	Stabilizer Trim Actuator	Boeing
65-49970-24	Stabilizer Trim Actuator	Boeing
65-49970-25	Stabilizer Trim Actuator	Boeing
65-49970-26	Stabilizer Trim Actuator	Boeing
65-49970-3	Stabilizer Trim Actuator	Boeing
65-49970-5	Stabilizer Trim Actuator	Boeing
65-49970-7	Stabilizer Trim Actuator	Boeing
65-49970-9	Stabilizer Trim Actuator	Boeing
654T0387-10	Slat Drive Offset Gearbox	Boeing
654T0387-13	Slat Drive Offset Gearbox	Boeing
654T0387-14	Slat Drive Offset Gearbox	Boeing
654T0387-15	Slat Drive Offset Gearbox	Boeing

Repair_Capability_List_Excel

654T0387-16	Slat Drive Offset Gearbox	Boeing
654T0387-17	Slat Drive Offset Gearbox	Boeing
654T0387-18	Slat Drive Offset Gearbox	Boeing
654T0387-20	Slat Drive Offset Gearbox	Boeing
654T0387-23	Slat Drive Offset Gearbox	Boeing
654T0387-24	Slat Drive Offset Gearbox	Boeing
654T0387-25	Slat Drive Offset Gearbox	Boeing
654T0387-26	Slat Drive Offset Gearbox	Boeing
654T0387-27	Slat Drive Offset Gearbox	Boeing
654T0387-28	Slat Drive Offset Gearbox	Boeing
65-50251-2	Flap Drive Transmission	Boeing
65-50251-4	Flap Drive Transmission	Boeing
65-50251-5	Flap Drive Transmission	Boeing
65-50251-6	Flap Drive Transmission	Boeing
65-50251-7	Flap Drive Transmission	Boeing
65-50252-2	Flap Drive Transmission	Boeing
65-50252-4	Flap Drive Transmission	Boeing
65-50252-5	Flap Drive Transmission	Boeing
65-50252-6	Flap Drive Transmission	Boeing
65-50252-7	Flap Drive Transmission	Boeing
65-50252-8	Flap Drive Transmission	Boeing
65-50253-2	Flap Drive Transmission	Boeing
65-50253-4	Flap Drive Transmission	Boeing
65-50253-5	Flap Drive Transmission	Boeing
65-50253-6	Flap Drive Transmission	Boeing
65-50253-7	Flap Drive Transmission	Boeing
65-50253-8	Flap Drive Transmission	Boeing
65-50254-2	Flap Drive Transmission	Boeing
65-50254-4	Flap Drive Transmission	Boeing
65-50254-5	Flap Drive Transmission	Boeing
65-50254-6	Flap Drive Transmission	Boeing
65-50255-2	Flap Drive Transmission	Boeing
65-50255-4	Flap Drive Transmission	Boeing
65-50255-5	Flap Drive Transmission	Boeing
65-50255-6	Flap Drive Transmission	Boeing
65-50256-2	Flap Drive Transmission	Boeing
65-50256-4	Flap Drive Transmission	Boeing
65-50256-5	Flap Drive Transmission	Boeing
65-50256-6	Flap Drive Transmission	Boeing
65-50256-7	Flap Drive Transmission	Boeing
65-50256-8	Flap Drive Transmission	Boeing
65-50257-2	Flap Drive Transmission	Boeing
65-50257-4	Flap Drive Transmission	Boeing
65-50257-5	Flap Drive Transmission	Boeing
65-50257-6	Flap Drive Transmission	Boeing
65-50257-7	Flap Drive Transmission	Boeing
65-50257-8	Flap Drive Transmission	Boeing
65-50258-2	Flap Drive Transmission	Boeing
65-50258-3	Flap Drive Transmission	Boeing
65-50258-4	Flap Drive Transmission	Boeing
65-50258-5	Flap Drive Transmission	Boeing
65-50258-6	Flap Drive Transmission	Boeing
65-50258-7	Flap Drive Transmission	Boeing
65-50301-2	Flap Drive Transmission	Boeing
65-50301-3	Flap Drive Transmission	Boeing
65-50301-4	Flap Drive Transmission	Boeing
65-50302-2	Flap Drive Transmission	Boeing
65-50302-3	Flap Drive Transmission	Boeing

Repair_Capability_List_Excel

65-50302-4	Flap Drive Transmission	Boeing
65-50302-5	Flap Drive Transmission	Boeing
65-50302-6	Flap Drive Transmission	Boeing
65-50302-7	Flap Drive Transmission	Boeing
65-50303-2	Flap Drive Transmission	Boeing
65-50303-3	Flap Drive Transmission	Boeing
65-50303-4	Flap Drive Transmission	Boeing
65-50304-2	Tee Gearbox	Boeing
65-50304-3	Tee Gearbox	Boeing
65-50305-2	Tee Gearbox	Boeing
65-50305-3	Tee Gearbox	Boeing
65-50306-2	Flap Drive Transmission	Boeing
65-50306-3	Flap Drive Transmission	Boeing
65-50306-4	Flap Drive Transmission	Boeing
65-50307-2	Flap Drive Transmission	Boeing
65-50307-3	Flap Drive Transmission	Boeing
65-50307-4	Flap Drive Transmission	Boeing
65-50307-5	Flap Drive Transmission	Boeing
65-50307-6	Flap Drive Transmission	Boeing
65-50307-7	Flap Drive Transmission	Boeing
65-50308-2	Flap Drive Transmission	Boeing
65-50308-3	Flap Drive Transmission	Boeing
65-50308-4	Flap Drive Transmission	Boeing
65-50321-1	Flap Drive Transmission	Boeing
65-50321-2	Flap Drive Transmission	Boeing
65-50321-3	Flap Drive Transmission	Boeing
65-50321-4	Flap Drive Transmission	Boeing
65-50321-5	Flap Drive Transmission	Boeing
65-50321-6	Flap Drive Transmission	Boeing
65-50321-7	Flap Drive Transmission	Boeing
65-50322-10	Flap Drive Transmission	Boeing
65-50322-11	Flap Drive Transmission	Boeing
65-50322-12	Flap Drive Transmission	Boeing
65-50322-14	Flap Drive Transmission	Boeing
65-50322-2	Flap Drive Transmission	Boeing
65-50322-3	Flap Drive Transmission	Boeing
65-50322-4	Flap Drive Transmission	Boeing
65-50322-5	Flap Drive Transmission	Boeing
65-50322-6	Flap Drive Transmission	Boeing
65-50322-7	Flap Drive Transmission	Boeing
65-50322-8	Flap Drive Transmission	Boeing
65-50322-9	Flap Drive Transmission	Boeing
65-50323-1	Flap Drive Transmission	Boeing
65-50323-2	Flap Drive Transmission	Boeing
65-50323-3	Flap Drive Transmission	Boeing
65-50323-4	Flap Drive Transmission	Boeing
65-50323-5	Flap Drive Transmission	Boeing
65-50323-6	Flap Drive Transmission	Boeing
65-50324-1	Tee Gearbox	Boeing
65-50324-2	Tee Gearbox	Boeing
65-50324-3	Tee Gearbox	Boeing
65-50324-4	Tee Gearbox	Boeing
65-50324-5	Tee Gearbox	Boeing
65-50325-1	Tee Gearbox	Boeing
65-50325-2	Tee Gearbox	Boeing
65-50325-3	Tee Gearbox	Boeing
65-50325-4	Tee Gearbox	Boeing
65-50325-5	Tee Gearbox	Boeing

Repair_Capability_List_Excel

65-50326-1	Flap Drive Transmission	Boeing
65-50326-2	Flap Drive Transmission	Boeing
65-50326-3	Flap Drive Transmission	Boeing
65-50326-4	Flap Drive Transmission	Boeing
65-50326-5	Flap Drive Transmission	Boeing
65-50326-6	Flap Drive Transmission	Boeing
65-50327-10	Flap Drive Transmission	Boeing
65-50327-11	Flap Drive Transmission	Boeing
65-50327-12	Flap Drive Transmission	Boeing
65-50327-14	Flap Drive Transmission	Boeing
65-50327-2	Flap Drive Transmission	Boeing
65-50327-3	Flap Drive Transmission	Boeing
65-50327-4	Flap Drive Transmission	Boeing
65-50327-5	Flap Drive Transmission	Boeing
65-50327-6	Flap Drive Transmission	Boeing
65-50327-7	Flap Drive Transmission	Boeing
65-50327-8	Flap Drive Transmission	Boeing
65-50327-9	Flap Drive Transmission	Boeing
65-50328-1	Flap Drive Transmission	Boeing
65-50328-2	Flap Drive Transmission	Boeing
65-50328-3	Flap Drive Transmission	Boeing
65-50328-4	Flap Drive Transmission	Boeing
65-50328-5	Flap Drive Transmission	Boeing
65-50328-6	Flap Drive Transmission	Boeing
65-50328-7	Flap Drive Transmission	Boeing
65-50746-1	Tack assy	Boeing
65-508587-1	Drive Shaft assy	Boeing
65-508587-3	Drive Shaft assy	Boeing
65-508587-4	Drive Shaft assy	Boeing
65-50904-2	APU Access Door	Boeing
65-50904-271	APU Access Door	Boeing
65-50904-625	APU Access Door	Boeing
65-50909-12	Fire Control Auxiliary Power Unit	Boeing
65-50909-13	Fire Control Auxiliary Power Unit	Boeing
65-50909-2	Fire Control Auxiliary Power Unit	Boeing
65-50909-3	Fire Control Auxiliary Power Unit	Boeing
65-50909-5	Fire Control Auxiliary Power Unit	Boeing
65-50909-7	Fire Control Auxiliary Power Unit	Boeing
65-50909-8	Fire Control Auxiliary Power Unit	Boeing
65-50909-9	Fire Control Auxiliary Power Unit	Boeing
65-5093-4	Pump & Lock Ring	Nash-Gec.
65-50949-1	Pneumatic Actuator	Boeing
65-50949-3	Pneumatic Actuator	Boeing
65-50949-5	Pneumatic Actuator	Boeing
65-51500-2	PDU Gearbox assy	Boeing
65-51500-3	PDU Gearbox assy	Boeing
65-51500-4	PDU Gearbox assy	Boeing
65-51500-6	PDU Gearbox assy	Boeing
65-5150-2	Flap Drive Power Unit	Boeing
65-5150-3	Flap Drive Power Unit	Boeing
65-5150-4	Flap Drive Power Unit	Boeing
65-5150-6	Flap Drive Power Unit	Boeing
65-51510-1	Gearbox Assy LH	Boeing
65-51510-2	Gearbox Assy RH	Boeing
65-51513-1	Gearbox Assy-LH	Boeing
65-51513-2	Gearbox Assy-RH	Boeing
65-51513-3	Gearbox Assy-LH	Boeing
65-51513-4	Gearbox Assy-RH	Boeing

Repair_Capability_List_Excel

65-51530-2	Aft Airstair Entry Door	Boeing
65-51530-216	Aft Airstair Entry Door	Boeing
65-51600-11	Flap Control Input Quadrant Support	Boeing
65-51600-12	Flap Control Input Quadrant Support	Boeing
65-51600-14	Flap Control Input Quadrant Support	Boeing
65-51600-15	Flap Control Input Quadrant Support	Boeing
65-51600-16	Flap Control Input Quadrant Support	Boeing
65-51600-19	Flap Control Input Quadrant Support	Boeing
65-51600-2	Flap Control Input Quadrant Support	Boeing
65-51600-8	Flap Control Input Quadrant Support	Boeing
65-51600-9	Flap Control Input Quadrant Support	Boeing
65-51602-10	LE & TE Flaps Control	Boeing
65-51602-11	Trailing Edge Flaps Control Valve	Boeing
65-51602-2	Trailing Edge Flap Control Valve	Boeing
65-51602-20	LE & TE Flaps Control	Boeing
65-51602-21	LE & TE Flaps Control	Boeing
65-51602-27	LE & TE Flaps Control	Boeing
65-51602-29	Trailing Edge Flap Control Valve	Boeing
65-51602-30	Trailing Edge Flap Control Valve	Boeing
65-51602-31	LE & TE Flaps Control	Boeing
65-51602-32	LE & TE Flaps Control	Boeing
65-51602-33	LE & TE Flaps Control	Boeing
65-51602-35	LE & TE Flaps Control	Boeing
65-51602-39	Control assy	Boeing
65-51602-43	Control assy	Boeing
65-51602-47	Control assy	Boeing
65-51602-49	Control assy	Boeing
65-51602-5	LE & TE Flaps Control	Boeing
65-51602-51	Control assy	Boeing
65-51602-53	Control assy	Boeing
65-51602-6	LE & TE Flaps Control	Boeing
65-51602-7	LE & TE Flaps Control	Boeing
65-51602-8	LE & TE Flaps Control	Boeing
65-51602-9	LE & TE Flaps Control	Boeing
65-51705-1	Cargo System Side Restraint Guide	Boeing
65-51705-10	Cargo System Side Restraint Guide	Boeing
65-51705-11	Cargo System Side Restraint Guide	Boeing
65-51705-12	Cargo System Side Restraint Guide	Boeing
65-51705-13	Cargo System Side Restraint Guide	Boeing
65-51705-14	Cargo System Side Restraint Guide	Boeing
65-51705-15	Cargo System Side Restraint Guide	Boeing
65-51705-16	Cargo System Side Restraint Guide	Boeing
65-51705-2	Cargo System Side Restraint Guide	Boeing
65-51705-3	Cargo System Side Restraint Guide	Boeing
65-51705-4	Cargo System Side Restraint Guide	Boeing
65-51705-5	Cargo System Side Restraint Guide	Boeing
65-51705-6	Cargo System Side Restraint Guide	Boeing
65-51705-7	Cargo System Side Restraint Guide	Boeing
65-51705-8	Cargo System Side Restraint Guide	Boeing
65-51705-9	Cargo System Side Restraint Guide	Boeing
65-51719-22	QC Cargo System Seat Pallet Latch	Boeing
65-51719-23	QC Cargo System Seat Pallet Latch	Boeing
65-51719-24	QC Cargo System Seat Pallet Latch	Boeing
65-51719-25	QC Cargo System Seat Pallet Latch	Boeing
65-51719-26	QC Cargo System Seat Pallet Latch	Boeing
65-51719-27	QC Cargo System Seat Pallet Latch	Boeing
65-51719-28	QC Cargo System Seat Pallet Latch	Boeing
65-51719-29	QC Cargo System Seat Pallet Latch	Boeing

Repair_Capability_List_Excel

65-51719-30	QC Cargo System Seat Pallet Latch	Boeing
65-51719-31	QC Cargo System Seat Pallet Latch	Boeing
65-51719-32	QC Cargo System Seat Pallet Latch	Boeing
65-51719-33	QC Cargo System Seat Pallet Latch	Boeing
65-51719-34	QC Cargo System Seat Pallet Latch	Boeing
65-51719-35	QC Cargo System Seat Pallet Latch	Boeing
65-51719-36	QC Cargo System Seat Pallet Latch	Boeing
65-51719-37	QC Cargo System Seat Pallet Latch	Boeing
65-51719-38	QC Cargo System Seat Pallet Latch	Boeing
65-51719-39	QC Cargo System Seat Pallet Latch	Boeing
65-51719-40	QC Cargo System Seat Pallet Latch	Boeing
65-51719-41	QC Cargo System Seat Pallet Latch	Boeing
65-51719-42	QC Cargo System Seat Pallet Latch	Boeing
65-51719-43	QC Cargo System Seat Pallet Latch	Boeing
65-51719-44	QC Cargo System Seat Pallet Latch	Boeing
65-51719-45	QC Cargo System Seat Pallet Latch	Boeing
65-51719-46	QC Cargo System Seat Pallet Latch	Boeing
65-51719-49	QC Cargo System Seat Pallet Latch	Boeing
65-51719-50	QC Cargo System Seat Pallet Latch	Boeing
65-51719-51	QC Cargo System Seat Pallet Latch	Boeing
65-51719-52	QC Cargo System Seat Pallet Latch	Boeing
65-51719-55	QC Cargo System Seat Pallet Latch	Boeing
65-51719-57	QC Cargo System Seat Pallet Latch	Boeing
65-52201-1	Main Gear Inner Door	Boeing
65-52201-2	Main Gear Inner Door	Boeing
65-52201-221	Main Gear Inner Door	Boeing
65-52201-222	Main Gear Inner Door	Boeing
65-52201-229	Main Gear Inner Door	Boeing
65-52201-230	Main Gear Inner Door	Boeing
65-52201-251	Main Gear Inner Door	Boeing
65-52201-252	Main Gear Inner Door	Boeing
65-52201-259	Main Gear Inner Door	Boeing
65-52201-260	Main Gear Inner Door	Boeing
65-52201-265	Main Gear Inner Door	Boeing
65-52201-266	Main Gear Inner Door	Boeing
65-52201-87	Main Gear Inner Door	Boeing
65-52201-88	Main Gear Inner Door	Boeing
65-52202-1	Main Landing Gear Center Door	Boeing
65-52202-17	Main Landing Gear Center Door	Boeing
65-52202-18	Main Landing Gear Center Door	Boeing
65-52202-2	Main Landing Gear Center Door	Boeing
65-52202-35	Main Landing Gear Center Door	Boeing
65-52202-36	Main Landing Gear Center Door	Boeing
65-52202-53	Main Landing Gear Center Door	Boeing
65-52202-54	Main Landing Gear Center Door	Boeing
65-52202-67	Main Landing Gear Center Door	Boeing
65-52202-68	Main Landing Gear Center Door	Boeing
65-52202-73	Main Landing Gear Center Door	Boeing
65-52202-74	Main Landing Gear Center Door	Boeing
65-52202-85	Main Landing Gear Center Door	Boeing
65-52202-86	Main Landing Gear Center Door	Boeing
65-52246-1	Carriage assy	Boeing
65-52246-2	Carriage assy	Boeing
65-52246-7	Carriage assy	Boeing
65-52246-8	Carriage assy	Boeing
65-52283-6	Aileron Centering Mechanism	Boeing
65-52284-5	Aileron Geared trim	Boeing
65-52284-6	Aileron Geared trim	Boeing

Repair_Capability_List_Excel

65-52284-8	Aileron Geared trim	Boeing
65-52284-9	Aileron Geared trim	Boeing
65-52800-1	Chassis Assy	Boeing
65-52800-15	Chassis Assy	Boeing
65-52800-23	Chassis Assy	Boeing
65-52800-26	Chassis Assy	Boeing
65-52800-29	Chassis Assy	Boeing
65-52800-31	Chassis Assy	Boeing
65-52800-33	Chassis Assy	Boeing
65-52800-37	Chassis Assy	Boeing
65-52800-38	Chassis Assy	Boeing
65-52800-41	Chassis Assy	Boeing
65-52800-43	Chassis Assy	Boeing
65-52800-44	Chassis Assy	Boeing
65-52802-1	Autopilot Switching Accessory Unit	Boeing
65-52803-1	Window Heat Accessory Unit	Boeing
65-52803-10	Window Heat Accessory Unit	Boeing
65-52803-2	Window Heat Accessory Unit	Boeing
65-52803-6	Window Heat Accessory Unit	Boeing
65-52803-8	Window Heat Controller	Boeing
65-52804-1	Audio Accessory Unit	Boeing
65-52804-1 MOD A	Audio Accessory Unit	Boeing
65-52804-101	Audio Accessory Unit	Boeing
65-52804-101 MOD A	Audio Accessory Unit	Boeing
65-52804-109	Audio Accessory Unit	Boeing
65-52804-109 MOD A	Audio Accessory Unit	Boeing
65-52804-11	Audio Accessory Unit	Boeing
65-52804-11 MOD A	Audio Accessory Unit	Boeing
65-52804-112	Audio Accessory Unit	Boeing
65-52804-116	Audio Accessory Unit	Boeing
65-52804-118	Audio Accessory Unit	Boeing
65-52804-118 MOD A	Audio Accessory Unit	Boeing
65-52804-122	Audio Accessory Unit	Boeing
65-52804-122 MOD A	Audio Accessory Unit	Boeing
65-52804-124	Audio Accessory Unit	Boeing
65-52804-124 MOD A	Audio Accessory Unit	Boeing
65-52804-125	Audio Accessory Unit	Boeing
65-52804-127	Audio Accessory Unit	Boeing
65-52804-129	Audio Accessory Unit	Boeing
65-52804-129 MOD A	Audio Accessory Unit	Boeing
65-52804-131	Audio Accessory Unit	Boeing
65-52804-133	Audio Accessory Unit	Boeing
65-52804-135	Audio Accessory Unit	Boeing
65-52804-137	Audio Accessory Unit	Boeing
65-52804-139	Audio Accessory Unit	Boeing
65-52804-139 MOD A	Audio Accessory Unit	Boeing
65-52804-142	Audio Accessory Unit	Boeing
65-52804-144	Audio Accessory Unit	Boeing
65-52804-146	Audio Accessory Unit	Boeing
65-52804-148	Audio Accessory Unit	Boeing
65-52804-148 MOD A	Audio Accessory Unit	Boeing
65-52804-15	Audio Accessory Unit	Boeing
65-52804-15 MOD A	Audio Accessory Unit	Boeing
65-52804-152	Audio Accessory Unit	Boeing
65-52804-152 MOD A	Audio Accessory Unit	Boeing
65-52804-154	Audio Accessory Unit	Boeing
65-52804-154 MOD A	Audio Accessory Unit	Boeing
65-52804-158	Audio Accessory Unit	Boeing

Repair_Capability_List_Excel

65-52804-158 MOD A	Audio Accessory Unit	Boeing
65-52804-159	Audio Accessory Unit	Boeing
65-52804-159 MOD A	Audio Accessory Unit	Boeing
65-52804-161	Audio Accessory Unit	Boeing
65-52804-161 MOD A	Audio Accessory Unit	Boeing
65-52804-163	Audio Accessory Unit	Boeing
65-52804-163 MOD A	Audio Accessory Unit	Boeing
65-52804-165	Audio Accessory Unit	Boeing
65-52804-167	Audio Accessory Unit	Boeing
65-52804-169	Audio Accessory Unit	Boeing
65-52804-171	Audio Accessory Unit	Boeing
65-52804-171 MOD A	Audio Accessory Unit	Boeing
65-52804-173	Audio Accessory Unit	Boeing
65-52804-175	Audio Accessory Unit	Boeing
65-52804-177	Audio Accessory Unit	Boeing
65-52804-177 MOD A	Audio Accessory Unit	Boeing
65-52804-179	Audio Accessory Unit	Boeing
65-52804-179 MOD A	Audio Accessory Unit	Boeing
65-52804-181	Audio Accessory Unit	Boeing
65-52804-183	Audio Accessory Unit	Boeing
65-52804-185	Audio Accessory Unit	Boeing
65-52804-187	Audio Accessory Unit	Boeing
65-52804-189	Audio Accessory Unit	Boeing
65-52804-189 MOD A	Audio Accessory Unit	Boeing
65-52804-191	Audio Accessory Unit	Boeing
65-52804-193	Audio Accessory Unit	Boeing
65-52804-195	Audio Accessory Unit	Boeing
65-52804-197	Audio Accessory Unit	Boeing
65-52804-199	Audio Accessory Unit	Boeing
65-52804-201	Audio Accessory Unit	Boeing
65-52804-203	Audio Accessory Unit	Boeing
65-52804-203 MOD A	Audio Accessory Unit	Boeing
65-52804-207	Audio Accessory Unit	Boeing
65-52804-207 MOD A	Audio Accessory Unit	Boeing
65-52804-209	Audio Accessory Unit	Boeing
65-52804-209 MOD A	Audio Accessory Unit	Boeing
65-52804-211	Audio Accessory Unit	Boeing
65-52804-211 MOD A	Audio Accessory Unit	Boeing
65-52804-215	Audio Accessory Unit	Boeing
65-52804-215 MOD A	Audio Accessory Unit	Boeing
65-52804-217	Audio Accessory Unit	Boeing
65-52804-217 MOD A	Audio Accessory Unit	Boeing
65-52804-219	Audio Accessory Unit	Boeing
65-52804-219 MOD A	Audio Accessory Unit	Boeing
65-52804-223	Audio Accessory Unit	Boeing
65-52804-223 MOD A	Audio Accessory Unit	Boeing
65-52804-227	Audio Accessory Unit	Boeing
65-52804-227 MOD A	Audio Accessory Unit	Boeing
65-52804-229	Audio Accessory Unit	Boeing
65-52804-229 MOD A	Audio Accessory Unit	Boeing
65-52804-23	Audio Accessory Unit	Boeing
65-52804-23 MOD A	Audio Accessory Unit	Boeing
65-52804-241	Audio Accessory Unit	Boeing
65-52804-241 MOD A	Audio Accessory Unit	Boeing
65-52804-243	Audio Accessory Unit	Boeing
65-52804-243 MOD A	Audio Accessory Unit	Boeing
65-52804-25	Audio Accessory Unit	Boeing
65-52804-25 MOD A	Audio Accessory Unit	Boeing

Repair_Capability_List_Excel

65-52804-251	Audio Accessory Unit	Boeing
65-52804-251 MOD A	Audio Accessory Unit	Boeing
65-52804-253	Audio Accessory Unit	Boeing
65-52804-253 MOD A	Audio Accessory Unit	Boeing
65-52804-258	Audio Accessory Unit	Boeing
65-52804-258 MOD A	Audio Accessory Unit	Boeing
65-52804-260	Audio Accessory Unit	Boeing
65-52804-260 MOD A	Audio Accessory Unit	Boeing
65-52804-262	Audio Accessory Unit	Boeing
65-52804-262 MOD A	Audio Accessory Unit	Boeing
65-52804-29	Audio Accessory Unit	Boeing
65-52804-32	Audio Accessory Unit	Boeing
65-52804-32 MOD A	Audio Accessory Unit	Boeing
65-52804-34	Audio Accessory Unit	Boeing
65-52804-34 MOD A	Audio Accessory Unit	Boeing
65-52804-38	Audio Accessory Unit	Boeing
65-52804-38 MOD A	Audio Accessory Unit	Boeing
65-52804-42	Audio Accessory Unit	Boeing
65-52804-42 MOD A	Audio Accessory Unit	Boeing
65-52804-43	Audio Accessory Unit	Boeing
65-52804-43 MOD A	Audio Accessory Unit	Boeing
65-52804-45	Audio Accessory Unit	Boeing
65-52804-45 MOD A	Audio Accessory Unit	Boeing
65-52804-47	Audio Accessory Unit	Boeing
65-52804-47 MOD A	Audio Accessory Unit	Boeing
65-52804-49	Audio Accessory Unit	Boeing
65-52804-49 MOD A	Audio Accessory Unit	Boeing
65-52804-51	Audio Accessory Unit	Boeing
65-52804-51 MOD A	Audio Accessory Unit	Boeing
65-52804-53	Audio Accessory Unit	Boeing
65-52804-53 MOD A	Audio Accessory Unit	Boeing
65-52804-55	Audio Accessory Unit	Boeing
65-52804-55 MOD A	Audio Accessory Unit	Boeing
65-52804-57	Audio Accessory Unit	Boeing
65-52804-59	Audio Accessory Unit	Boeing
65-52804-59 MOD A	Audio Accessory Unit	Boeing
65-52804-61	Audio Accessory Unit	Boeing
65-52804-61 MOD A	Audio Accessory Unit	Boeing
65-52804-63	Audio Accessory Unit	Boeing
65-52804-63 MOD A	Audio Accessory Unit	Boeing
65-52804-65	Audio Accessory Unit	Boeing
65-52804-65 MOD A	Audio Accessory Unit	Boeing
65-52804-67	Audio Accessory Unit	Boeing
65-52804-69	Audio Accessory Unit	Boeing
65-52804-69 MOD A	Audio Accessory Unit	Boeing
65-52804-71	Audio Accessory Unit	Boeing
65-52804-71 MOD A	Audio Accessory Unit	Boeing
65-52804-79	Audio Accessory Unit	Boeing
65-52804-79 MOD A	Audio Accessory Unit	Boeing
65-52804-81	Audio Accessory Unit	Boeing
65-52804-81 MOD A	Audio Accessory Unit	Boeing
65-52804-87	Audio Accessory Unit	Boeing
65-52804-87 MOD A	Audio Accessory Unit	Boeing
65-52804-91	Audio Accessory Unit	Boeing
65-52804-91 MOD A	Audio Accessory Unit	Boeing
65-52804-97	Audio Accessory Unit	Boeing
65-52804-97 MOD A	Audio Accessory Unit	Boeing
65-52805	Flight Instrument Accessory Unit	Boeing

Repair_Capability_List_Excel

65-52806-421 MOD A	Solid-State Switching Accessory Unit	Boeing
65-52806-442	Solid-State Switching Accessory Unit	Boeing
65-52806-444	Solid-State Switching Accessory Unit	Boeing
65-52806-445	Solid-State Switching Accessory Unit	Boeing
65-52806-446	Solid-State Switching Accessory Unit	Boeing
65-52806-447	Solid-State Switching Accessory Unit	Boeing
65-52806-45	Solid-State Switching Accessory Unit	Boeing
65-52806-452	Solid-State Switching Accessory Unit	Boeing
65-52806-456	Solid-State Switching Accessory Unit	Boeing
65-52806-457	Solid-State Switching Accessory Unit	Boeing
65-52806-457 MOD A	Solid-State Switching Accessory Unit	Boeing
65-52806-459	Solid-State Switching Accessory Unit	Boeing
65-52806-460	Solid-State Switching Accessory Unit	Boeing
65-52806-463	Solid-State Switching Accessory Unit	Boeing
65-52806-466	Solid-State Switching Accessory Unit	Boeing
65-52806-468	Solid-State Switching Accessory Unit	Boeing
65-52806-470	Solid-State Switching Accessory Unit	Boeing
65-52806-48	Solid-State Switching Accessory Unit	Boeing
65-52806-50	Solid-State Switching Accessory Unit	Boeing
65-52806-56	Solid-State Switching Accessory Unit	Boeing
65-52806-71	Solid-State Switching Accessory Unit	Boeing
65-52806-73	Solid-State Switching Accessory Unit	Boeing
65-52806-90	Solid-State Switching Accessory Unit	Boeing
65-52806-91	Solid-State Switching Accessory Unit	Boeing
65-52806-92	Solid-State Switching Accessory Unit	Boeing
65-52806-93	Solid-State Switching Accessory Unit	Boeing
65-52806-94	Solid-State Switching Accessory Unit	Boeing
65-52806-95	Solid-State Switching Accessory Unit	Boeing
65-52806-96	Solid-State Switching Accessory Unit	Boeing
65-52806-97	Solid-State Switching Accessory Unit	Boeing
65-52806-98	Solid-State Switching Accessory Unit	Boeing
65-52806-99	Solid-State Switching Accessory Unit	Boeing
65-52807-12	Flap & Slat Position Indicator	Boeing
65-52807-13	Flap & Slat Position Indicator	Boeing
65-52807-14	Flap & Slat Position Indicator	Boeing
65-52807-15	Flap & Slat Position Indicator	Boeing
65-52807-16	Flap & Slat Position Indicator	Boeing
65-52807-18	Flap & Slat Position Indicator	Boeing
65-52807-19	Flap & Slat Position Indicator	Boeing
65-52807-21	Flap & Slat Position Indicator	Boeing
65-52807-26	Flap & Slat Position Indicator	Boeing
65-52807-26 MOD A	Flap & Slat Position Indicator	Boeing
65-52807-33	Flap & Slat Position Indicator	Boeing
65-52807-35	Flap & Slat Position Indicator	Boeing
65-52807-37	Flap & Slat Position Indicator	Boeing
65-52807-39	Flap & Slat Position Indicator	Boeing
65-52807-39 MOD A	Flap & Slat Position Indicator	Boeing
65-52807-43	Flap & Slat Position Indicator	Boeing
65-52807-50	Flap & Slat Position Indicator	Boeing
65-52807-52	Flap & Slat Position Indicator	Boeing
65-52807-54	Flap & Slat Position Indicator	Boeing
65-52807-55	Flap & Slat Position Indicator	Boeing
65-52807-56	Flap & Slat Position Indicator	Boeing
65-52807-57	Flap & Slat Position Indicator	Boeing
65-52807-58	Flap & Slat Position Indicator	Boeing
65-52807-59	Flap & Slat Position Indicator	Boeing
65-52807-60	Flap & Slat Position Indicator	Boeing
65-52807-62	Flap & Slat Position Indicator	Boeing

Repair_Capability_List_Excel

65-52807-63	Flap & Slat Position Indicator	Boeing
65-52807-65	Flap & Slat Position Indicator	Boeing
65-52807-66	Flap & Slat Position Indicator	Boeing
65-52807-69	Flap & Slat Position Indicator	Boeing
65-52807-7	Flap & Slat Position Indicator	Boeing
65-52807-71	Flap & Slat Position Indicator	Boeing
65-52807-73	Flap/Slat Position Indicator	Boeing
65-52807-74	Flap & Slat Position Indicator	Boeing
65-52807-76	Flap & Slat Position Indicator	Boeing
65-52807-9	Flap & Slat Position Indicator	Boeing
65-52808-3	Compartment Overheat Accessory Unit	Boeing
65-52808-3 MOD A	Compartment Overheat Accessory Unit	Boeing
65-52808-3 MOD B	Compartment Overheat Accessory Unit	Boeing
65-52808-3 MOD C	Compartment Overheat Accessory Unit	Boeing
65-52808-3 MOD D	Compartment Overheat Accessory Unit	Boeing
65-52808-6	Compartment Overheat Accessory Unit	Boeing
65-52808-6 MOD A	Compartment Overheat Accessory Unit	Boeing
65-52808-6 MOD B	Compartment Overheat Accessory Unit	Boeing
65-52808-6 MOD C	Compartment Overheat Accessory Unit	Boeing
65-52808-6 MOD D	Compartment Overheat Accessory Unit	Boeing
65-52808-7	Compartment Overheat Accessory Unit	Boeing
65-52808-7 MOD A	Compartment Overheat Accessory Unit	Boeing
65-52808-7 MOD B	Compartment Overheat Accessory Unit	Boeing
65-52808-7 MOD C	Compartment Overheat Accessory Unit	Boeing
65-52808-7 MOD D	Compartment Overheat Accessory Unit	Boeing
65-52808-9	Compartment Overheat Accessory Unit	Boeing
65-52809-13	Fire Detection Accessory Unit	Boeing
65-52809-15	Fire Detection Accessory Unit	Boeing
65-52810-1	Air Conditioning Accessory Unit	Boeing
65-52810-19	Air Conditioning Accessory Unit	Boeing
65-52810-21	Air Conditioning Accessory Unit	Boeing
65-52810-22	Air Conditioning Accessory Unit	Boeing
65-52810-25	Air Conditioning Accessory Unit	Boeing
65-52810-28	Air Conditioning Accessory Unit	Boeing
65-52810-35	Air Conditioning Accessory Unit	Boeing
65-52810-37	Air Conditioning Accessory Unit	Boeing
65-52810-39	Air Conditioning Accessory Unit	Boeing
65-52810-43	Air Conditioning Accessory Unit	Boeing
65-52810-46	Air Conditioning Accessory Unit	Boeing
65-52810-50	Air Conditioning Accessory Unit	Boeing
65-52810-57	Air Conditioning Accessory Unit	Boeing
65-52810-59	Air Conditioning Accessory Unit	Boeing
65-52810-6	Air Conditioning Accessory Unit	Boeing
65-52810-64	Accessory Unit	Boeing
65-52810-8	Air Conditioning Accessory Unit	Boeing
65-52811-100	Landing Gear Accessory Unit	Boeing
65-52811-101	Landing Gear Accessory Unit	Boeing
65-52811-103	Landing Gear Accessory Unit	Boeing
65-52811-109	Landing Gear Accessory Unit	Boeing
65-52811-110	Landing Gear Accessory Unit	Boeing
65-52811-111	Landing Gear Accessory Unit	Boeing
65-52811-113	Landing Gear Accessory Unit	Boeing
65-52811-115	Landing Gear Accessory Unit	Boeing
65-52811-117	Accessory Unit	Boeing
65-52811-118	Accessory Unit	Boeing
65-52811-119	Accessory Unit	Boeing
65-52811-120	Accessory Unit	Boeing
65-52811-121	Accessory Unit	Boeing

Repair_Capability_List_Excel

65-52811-122	Landing Gear Accessory Unit	Boeing
65-52811-123	Landing Gear Accessory Unit	Boeing
65-52811-126	Landing Gear Accessory Unit	Boeing
65-52811-127	Landing Gear Accessory Unit	Boeing
65-52811-133	Landing Gear Accessory Unit	Boeing
65-52811-134	Landing Gear Accessory Unit	Boeing
65-52811-135	Accessory Unit	Boeing
65-52811-137	Accessory Unit	Boeing
65-52811-139	Landing Gear Accessory Unit	Boeing
65-52811-140	Landing Gear Accessory Unit	Boeing
65-52811-142	Landing Gear Accessory Unit	Boeing
65-52811-143	Landing Gear Accessory Unit	Boeing
65-52811-144	Accessory Unit	Boeing
65-52811-145	Accessory Unit	Boeing
65-52811-146	Accessory Unit	Boeing
65-52811-147	Accessory Unit	Boeing
65-52811-148	Accessory Unit	Boeing
65-52811-149	Landing Gear Accessory Unit	Boeing
65-52811-151	Accessory Unit	Boeing
65-52811-155	Landing Gear Accessory Unit	Boeing
65-52811-156	Landing Gear Accessory Unit	Boeing
65-52811-162	Landing Gear Accessory Unit	Boeing
65-52811-164	Landing Gear Accessory Unit	Boeing
65-52811-165	Landing Gear Accessory Unit	Boeing
65-52811-166	Landing Gear Accessory Unit	Boeing
65-52811-167	Landing Gear Accessory Unit	Boeing
65-52811-169	Landing Gear Accessory Unit	Boeing
65-52811-175	Landing Gear Accessory Unit	Boeing
65-52811-176	Landing Gear Accessory Unit	Boeing
65-52811-179	Landing Gear Accessory Unit	Boeing
65-52811-181	Landing Gear Accessory Unit	Boeing
65-52811-183	Landing Gear Accessory Unit	Boeing
65-52811-184	Landing Gear Accessory Unit	Boeing
65-52811-187	Landing Gear Accessory Unit	Boeing
65-52811-21	Accessory Unit	Boeing
65-52811-23	Accessory Unit	Boeing
65-52811-25	Accessory Unit	Boeing
65-52811-30	Accessory Unit	Boeing
65-52811-31	Accessory Unit	Boeing
65-52811-32	Landing Gear Accessory Unit	Boeing
65-52811-34	Landing Gear Accessory Unit	Boeing
65-52811-40	Landing Gear Accessory Unit	Boeing
65-52811-42	Landing Gear Accessory Unit	Boeing
65-52811-44	Accessory Unit	Boeing
65-52811-49	Landing Gear Accessory Unit	Boeing
65-52811-50	Landing Gear Accessory Unit	Boeing
65-52811-51	Accessory Unit	Boeing
65-52811-54	Accessory Unit	Boeing
65-52811-58	Landing Gear Accessory Unit	Boeing
65-52811-60	Landing Gear Accessory Unit	Boeing
65-52811-62	Landing Gear Accessory Unit	Boeing
65-52811-64	Landing Gear Accessory Unit	Boeing
65-52811-66	Landing Gear Accessory Unit	Boeing
65-52811-70	Landing Gear Accessory Unit	Boeing
65-52811-71	Landing Gear Accessory Unit	Boeing
65-52811-73	Accessory Unit	Boeing
65-52811-74	Accessory Unit	Boeing
65-52811-75	Accessory Unit	Boeing

Repair_Capability_List_Excel

65-52811-76	Accessory Unit	Boeing
65-52811-77	Accessory Unit	Boeing
65-52811-78	Landing Gear Accessory Unit	Boeing
65-52811-82	Landing Gear Accessory Unit	Boeing
65-52811-83	Landing Gear Accessory Unit	Boeing
65-52811-84	Accessory Unit	Boeing
65-52811-85	Accessory Unit	Boeing
65-52811-89	Landing Gear Accessory Unit	Boeing
65-52811-90	Landing Gear Accessory Unit	Boeing
65-52811-96	Landing Gear Accessory Unit	Boeing
65-52811-98	Landing Gear Accessory Unit	Boeing
65-52811-99	Landing Gear Accessory Unit	Boeing
65-52812-104	Autopilot Accessory Unit	Boeing
65-52812-107	Autopilot Accessory Unit	Boeing
65-52812-112	Autopilot Accessory Unit	Boeing
65-52812-114	Autopilot Accessory Unit	Boeing
65-52812-120	Autopilot Accessory Unit	Boeing
65-52812-124	Autopilot Accessory Unit	Boeing
65-52812-131	Autopilot Accessory Unit	Boeing
65-52812-133	Autopilot Accessory Unit	Boeing
65-52812-137	Autopilot Accessory Unit	Boeing
65-52812-140	Autopilot Accessory Unit	Boeing
65-52812-142	Autopilot Accessory Unit	Boeing
65-52812-144	Autopilot Accessory Unit	Boeing
65-52812-149	Autopilot Accessory Unit	Boeing
65-52812-155	Autopilot Accessory Unit	Boeing
65-52812-157	Autopilot Accessory Unit	Boeing
65-52812-159	Autopilot Accessory Unit	Boeing
65-52812-171	Autopilot Accessory Unit	Boeing
65-52812-179	Autopilot Accessory Unit	Boeing
65-52812-181	Autopilot Accessory Unit	Boeing
65-52812-183	Autopilot Accessory Unit	Boeing
65-52812-191	Autopilot Accessory Unit	Boeing
65-52812-193	Autopilot Accessory Unit	Boeing
65-52812-195	Autopilot Accessory Unit	Boeing
65-52812-197	Autopilot Accessory Unit	Boeing
65-52812-199	Autopilot Accessory Unit	Boeing
65-52812-201	Autopilot Accessory Unit	Boeing
65-52812-203	Autopilot Accessory Unit	Boeing
65-52812-206	Autopilot Accessory Unit	Boeing
65-52812-207	Autopilot Accessory Unit	Boeing
65-52812-210	Autopilot Accessory Unit	Boeing
65-52812-211	Autopilot Accessory Unit	Boeing
65-52812-214	Autopilot Accessory Unit	Boeing
65-52812-216	Autopilot Accessory Unit	Boeing
65-52812-221	Autopilot Accessory Unit	Boeing
65-52812-223	Autopilot Accessory Unit	Boeing
65-52812-225	Autopilot Accessory Unit	Boeing
65-52812-227	Autopilot Accessory Unit	Boeing
65-52812-228	Autopilot Accessory Unit	Boeing
65-52812-229	Autopilot Accessory Unit	Boeing
65-52812-230	Autopilot Accessory Unit	Boeing
65-52812-231	Autopilot Accessory Unit	Boeing
65-52812-232	Autopilot Accessory Unit	Boeing
65-52812-234	Autopilot Accessory Unit	Boeing
65-52812-235	Autopilot Accessory Unit	Boeing
65-52812-236	Autopilot Accessory Unit	Boeing
65-52812-241	Autopilot Accessory Unit	Boeing

Repair_Capability_List_Excel

65-52812-243	Autopilot Accessory Unit	Boeing
65-52812-245	Autopilot Accessory Unit	Boeing
65-52812-246	Autopilot Accessory Unit	Boeing
65-52812-247	Autopilot Accessory Unit	Boeing
65-52812-248	Autopilot Accessory Unit	Boeing
65-52812-32	Autopilot Accessory Unit	Boeing
65-52812-33	Autopilot Accessory Unit	Boeing
65-52812-34	Autopilot Accessory Unit	Boeing
65-52812-35	Autopilot Accessory Unit	Boeing
65-52812-36	Autopilot Accessory Unit	Boeing
65-52812-37	Autopilot Accessory Unit	Boeing
65-52812-52	Autopilot Accessory Unit	Boeing
65-52812-53	Autopilot Accessory Unit	Boeing
65-52812-54	Autopilot Accessory Unit	Boeing
65-52812-55	Autopilot Accessory Unit	Boeing
65-52812-56	Autopilot Accessory Unit	Boeing
65-52812-57	Autopilot Accessory Unit	Boeing
65-52812-58	Autopilot Accessory Unit	Boeing
65-52812-61	Autopilot Accessory Unit	Boeing
65-52812-65	Autopilot Accessory Unit	Boeing
65-52812-72	Autopilot Accessory Unit	Boeing
65-52812-74	Autopilot Accessory Unit	Boeing
65-52812-75	Autopilot Accessory Unit	Boeing
65-52812-76	Autopilot Accessory Unit	Boeing
65-52812-77	Autopilot Accessory Unit	Boeing
65-52812-79	Autopilot Accessory Unit	Boeing
65-52812-80	Autopilot Accessory Unit	Boeing
65-52812-82	Autopilot Accessory Unit	Boeing
65-52812-84	Autopilot Accessory Unit	Boeing
65-52812-88	Autopilot Accessory Unit	Boeing
65-52813	AC/DC Power Syst.Test Accessory Unit	Boeing
65-52815-1	Pax Entertainment Accessory unit	Boeing
65-52817-17	Auto. Flight Controls Accessory Unit	Boeing
65-52817-5	Auto. Flight Controls Accessory Unit	Boeing
65-52817-9	Auto. Flight Controls Accessory Unit	Boeing
65-52854-1	Galley/Sevice Door Guide Arm	Boeing
65-52854-501	Galley/Sevice Door Guide Arm	Boeing
65-52873-156	Aft Entry/ Galley Door Torque Tube	Boeing
65-52873-157	Aft Entry/ Galley Door Torque Tube	Boeing
65-52873-159	Aft Entry Door	Boeing
65-52873-167	Aft Entry Door	Boeing
65-52873-168	Aft Entry Door	Boeing
65-52873-169	Aft Entry/ Galley Door Torque Tube	Boeing
65-52873-176	Aft Entry Door	Boeing
65-52873-180	Aft Entry Door	Boeing
65-52873-182	Aft Entry Door	Boeing
65-52873-2	Aft Entry Door	Boeing
65-52873-528	Aft Entry/ Galley Door Torque Tube	Boeing
65-52873-567	Aft Entry Door	Boeing
65-52873-91	Aft Entry/ Galley Door Torque Tube	Boeing
65-52925-13	Shaft Assembly	Boeing
65-52925-15	Shaft Assembly	Boeing
65-52925-19	Shaft Assembly	Boeing
65-52925-20	Shaft Assembly	Boeing
65-52925-21	Shaft Assembly	Boeing
65-52925-22	Shaft Assembly	Boeing
65-52925-23	Shaft Assembly	Boeing
65-52925-3	Shaft Assembly	Boeing

Repair_Capability_List_Excel

65-52925-32	Shaft Assembly	Boeing
65-52925-34	Shaft Assembly	Boeing
65-52925-35	Shaft Assembly	Boeing
65-52925-36	Shaft Assembly	Boeing
65-52925-37	Shaft Assembly	Boeing
65-52925-4	Shaft Assembly	Boeing
65-52925-42	Shaft Assembly	Boeing
65-52925-43	Shaft Assembly	Boeing
65-52925-44	Flap Drive Components	Boeing
65-52925-46	Shaft Assembly	Boeing
65-52925-47	Shaft Assembly	Boeing
65-52925-5	Shaft Assembly	Boeing
65-52925-50	Shaft Assembly	Boeing
65-52925-51	Shaft Assembly	Boeing
65-52925-52	Shaft Assembly	Boeing
65-52925-53	Shaft Assembly	Boeing
65-52925-6	Shaft Assembly	Boeing
65-52970-1	Cargo Net Stanchion	Boeing
65-52970-15	Cargo Net Stanchion	Boeing
65-52970-16	Cargo Net Stanchion	Boeing
65-52970-17	Cargo Net Stanchion	Boeing
65-52970-18	Cargo Net Stanchion	Boeing
65-52970-2	Cargo Net Stanchion	Boeing
65-52970-6	Cargo Net Stanchion	Boeing
65-53521-1	Aft Lavatory Service Unit	Boeing
65-53521-2	Aft Lavatory Service Unit	Boeing
65-53521-3	Aft Lavatory Service Unit	Boeing
65-53521-4	Aft Lavatory Service Unit	Boeing
65-53544-2	Aft Attendant's Oxygen Service Unit	Boeing
65-53788-2	Aileron Power Control Spring Cartridge	Boeing
65-53788-3	Aileron Power Control Spring Cartridge	Boeing
65-53882-1	Cargo Net Stanchion	Boeing
65-53882-2	Cargo Net Stanchion	Boeing
65-53882-21	Cargo Net Stanchion	Boeing
65-53882-22	Cargo Net Stanchion	Boeing
65-53882-23	Cargo Net Stanchion	Boeing
65-53882-24	Cargo Net Stanchion	Boeing
65-53882-25	Cargo Net Stanchion	Boeing
65-53882-26	Cargo Net Stanchion	Boeing
65-53882-3	Cargo Net Stanchion	Boeing
65-53882-33	Cargo Net Stanchion	Boeing
65-53882-34	Cargo Net Stanchion	Boeing
65-53882-39	Cargo Net Stanchion	Boeing
65-53882-4	Cargo Net Stanchion	Boeing
65-53882-40	Cargo Net Stanchion	Boeing
65-53882-5	Cargo Net Stanchion	Boeing
65-53882-501	Cargo Net Stanchion	Boeing
65-53882-502	Cargo Net Stanchion	Boeing
65-53882-503	Cargo Net Stanchion	Boeing
65-53882-504	Cargo Net Stanchion	Boeing
65-53882-505	Cargo Net Stanchion	Boeing
65-53882-506	Cargo Net Stanchion	Boeing
65-53882-6	Cargo Net Stanchion	Boeing
65-54137-1	Cargo Syst.Main Cargo Door Threshold	Boeing
65-54137-10	Cargo Syst.Main Cargo Door Threshold	Boeing
65-54137-11	Cargo Syst.Main Cargo Door Threshold	Boeing
65-54137-12	Cargo Syst.Main Cargo Door Threshold	Boeing
65-54137-2	Cargo Syst.Main Cargo Door Threshold	Boeing

Repair_Capability_List_Excel

65-54137-3	Cargo Syst.Main Cargo Door Threshold	Boeing
65-54137-4	Cargo Syst.Main Cargo Door Threshold	Boeing
65-54137-5	Cargo Syst.Main Cargo Door Threshold	Boeing
65-54137-6	Cargo Syst.Main Cargo Door Threshold	Boeing
65-54137-7	Cargo Syst.Main Cargo Door Threshold	Boeing
65-54137-8	Cargo Syst.Main Cargo Door Threshold	Boeing
65-54137-9	Cargo Syst.Main Cargo Door Threshold	Boeing
65-54200-12	Aileron Control Transfer Mechanism	Boeing
65-54200-14	Aileron Control Transfer Mechanism	Boeing
65-54200-15	Aileron Control Transfer Mechanism	Boeing
65-54200-16	Aileron Control Transfer Mechanism	Boeing
65-54200-4	Aileron Control Transfer Mechanism	Boeing
65-54200-5	Aileron Control Transfer Mechanism	Boeing
65-54200-6	Aileron Control Transfer Mechanism	Boeing
65-54200-7	Aileron Control Transfer Mechanism	Boeing
65-54200-8	Aileron Control Transfer Mechanism	Boeing
65-54204-1	Elevator Control Quadrant	Boeing
65-54204-10	Elevator Control Quadrant	Boeing
65-54204-12	Elevator Control Quadrant	Boeing
65-54204-14	Elevator Control Quadrant	Boeing
65-54204-16	Elevator Control Quadrant	Boeing
65-54204-3	Elevator Control Quadrant	Boeing
65-54204-4	Elevator Control Quadrant	Boeing
65-54204-6	Elevator Control Quadrant	Boeing
65-54204-8	Elevator Control Quadrant	Boeing
65-54219-13	Landing Gear Control Lever	Boeing
65-54219-15	Landing Gear Control Lever	Boeing
65-54219-21	Landing Gear Control Lever	Boeing
65-54219-24	Landing Gear Control Lever	Boeing
65-54219-25	Landing Gear Control Lever	Boeing
65-54219-27	Landing Gear Control Lever	Boeing
65-54219-30	Landing Gear Control Lever	Boeing
65-54219-31	Landing Gear Control Lever	Boeing
65-54219-32	Landing Gear Control Lever	Boeing
65-54219-35	Landing Gear Control Lever	Boeing
65-54219-36	Landing Gear Control Lever	Boeing
65-54219-37	Landing Gear Control Lever	Boeing
65-54219-38	Landing Gear Control Lever	Boeing
65-54219-40	Landing Gear Control Lever	Boeing
65-54219-5	Landing Gear Control Lever	Boeing
65-54219-5001	Landing Gear Control Lever	Boeing
65-54219-5002	Landing Gear Control Lever	Boeing
65-54219-5003	Landing Gear Control Lever	Boeing
65-54219-5004	Landing Gear Control Lever	Boeing
65-54219-5005	Landing Gear Control Lever	Boeing
65-54219-5006	Landing Gear Control Lever	Boeing
65-54219-5007	Landing Gear Control Lever	Boeing
65-54219-5008	Landing Gear Control Lever	Boeing
65-54219-5009	Landing Gear Control Lever	Boeing
65-54219-5010	Landing Gear Control Lever	Boeing
65-54219-5011	Landing Gear Control Lever	Boeing
65-54219-5012	Landing Gear Control Lever	Boeing
65-54219-5013	Landing Gear Control Lever	Boeing
65-54219-5014	Landing Gear Control Lever	Boeing
65-54219-5015	Landing Gear Control Lever	Boeing
65-54219-5016	Landing Gear Control Lever	Boeing
65-54219-5017	Landing Gear Control Lever	Boeing
65-54219-7	Landing Gear Control Lever	Boeing

Repair_Capability_List_Excel

65-54220-1	Nose Gear Spring Cartridge	Boeing
65-54220-2	Nose Gear Spring Cartridge	Boeing
65-54220-3	Nose Gear Spring Cartridge	Boeing
65-54221-1	Landing Gear Control Lever	Boeing
65-54221-2	Landing Gear Control Lever	Boeing
65-54221-8	Landing Gear Control Lever	Boeing
65-54499-12	Aural Warning Box	Boeing
65-54499-15	Aural Warning Box	Boeing
65-54499-17	Aural Warning Box	Boeing
65-54499-21	Aural Warning Box	Boeing
65-54499-23	Aural Warning Box	Boeing
65-54499-25	Aural Warning Box	Boeing
65-54499-26	Aural Warning Box	Boeing
65-54499-27	Aural Warning Box	Boeing
65-54499-28	Aural Warning Box	Boeing
65-54499-29	Aural Warning Box	Boeing
65-54499-32	Aural Warning Box	Boeing
65-54499-34	Aural Warning Box	Boeing
65-54499-36	Aural Warning Box	Boeing
65-54499-38	Aural Warning Box	Boeing
65-54499-40	Aural Warning Box	Boeing
65-54499-41	Aural Warning Box	Boeing
65-54499-42	Aural Warning Box	Boeing
65-54600-1	Landing Gear Hyd.Transfer Cylinder	Boeing
65-54600-2	Landing Gear Hyd.Transfer Cylinder	Boeing
65-54600-3	Landing Gear Hyd.Transfer Cylinder	Boeing
65-54600-4	Landing Gear Hyd.Transfer Cylinder	Boeing
65-54916-2	Main Cargo Door	Boeing
65-54916-501	Main Cargo Door	Boeing
65-55550-5	Drum assy	Boeing
65-55552-4	Bellcrank assy	Boeing
65-55552-6	Bellcrank assy	Boeing
65-55731-12	Control Wheel Steering Aileron Drum	Boeing
65-55731-14	Control Wheel Steering Aileron Drum	Boeing
65-55731-15	Control Wheel Steering Aileron Drum	Boeing
65-55731-21	Control Wheel Steering Aileron Drum	Boeing
65-55731-23	Control Wheel Steering Aileron Drum	Boeing
65-55731-24	Control Wheel Steering Aileron Drum	Boeing
65-55731-26	Control Wheel Steering Aileron Drum	Boeing
65-55731-27	Control Wheel Steering Aileron Drum	Boeing
65-55731-35	Control Wheel Steering Aileron Drum	Boeing
65-55731-5	Control Wheel Steering Aileron Drum	Boeing
65-55731-54	Control Wheel Steering Aileron Drum	Boeing
65-55731-55	Control Wheel Steering Aileron Drum	Boeing
65-55731-56	Control Wheel Steering Aileron Drum	Boeing
65-55731-57	Control Wheel Steering Aileron Drum	Boeing
65-55731-62	Control Wheel Steering Aileron Drum	Boeing
65-55731-63	Control Wheel Steering Aileron Drum	Boeing
65-55731-64	Control Wheel Steering Aileron Drum	Boeing
65-55731-65	Control Wheel Steering Aileron Drum	Boeing
65-55731-66	Control Wheel Steering Aileron Drum	Boeing
65-55731-70	Control Wheel Steering Aileron Drum	Boeing
65-55731-73	Control Wheel Steering Aileron Drum	Boeing
65-55835-5	Control Cable	Controlex
65-55896	Annunciator Lights Module	Boeing
65-56600-2	Flap Asymmetry Shutoff Mechanism	Boeing
65-56600-6	Flap Asymmetry Shutoff Mechanism	Boeing
65-57177-1	Cargo System Retractable Side Guide	Boeing

Repair_Capability_List_Excel

65-57177-2	Cargo System Retractable Side Guide	Boeing
65-57177-3	Cargo System Retractable Side Guide	Boeing
65-57177-4	Cargo System Retractable Side Guide	Boeing
65-57177-7	Cargo System Retractable Side Guide	Boeing
65-57910-1	Valve	Boeing
65-57910-2	Valve	Boeing
65-57926-14	Absorber	Boeing
65-58116-3	Aft Airstairs Mech.Reduction Gearbox	Boeing
65-58116-4	Aft Airstairs Mech.Reduction Gearbox	Boeing
65-58255-1	Fwd Lavatory Oxyg.Service Unit Install	Boeing
65-58255-3	Fwd Lavatory Oxyg.Service Unit Install	Boeing
65-59359-100	Main Instrument Panel Lighting Module	Boeing
65-59359-101	Main Instrument Panel Lighting Module	Boeing
65-59359-14	Main Instrument Panel Lighting Module	Boeing
65-59359-78	Main Instrument Panel Lighting Module	Boeing
65-59359-84	Main Instrument Panel Lighting Module	Boeing
65-59359-86	Main Instrument Panel Lighting Module	Boeing
65-59359-88	Main Instrument Panel Lighting Module	Boeing
65-59359-90	Main Instrument Panel Lighting Module	Boeing
65-59359-92	Main Instrument Panel Lighting Module	Boeing
65-59359-94	Main Instrument Panel Lighting Module	Boeing
65-59359-95	Main Instrument Panel Lighting Module	Boeing
65-59359-96	Main Instrument Panel Lighting Module	Boeing
65-59359-98	Main Instrument Panel Lighting Module	Boeing
65-59642-1	Aft Airstairs Governor	Boeing
65-59642-2	Aft Airstairs Governor	Boeing
655B01	Actuator	Liebherr Aerospace
655B01B	Thrust Reverser Interlock Actuator	Liebherr Aerospace
655CC01	Single Pole DC Contactor	ECE
655CC01Y1	Single Pole DC Contactor	ECE
655CC01Y2	Single Pole DC Contactor	ECE
65-60210-12	Audio Accessory Unit	Boeing
65-60210-13	Audio Accessory Unit	Boeing
65-60210-13 MOD A	Audio Accessory Unit	Boeing
65-60210-14	Audio Accessory Unit	Boeing
65-60210-15	Audio Accessory Unit	Boeing
65-60210-32	Audio Accessory	Boeing
65-60210-36	Audio Accessory Unit	Boeing
65-60211-10	Accessory Unit	Boeing
65-60211-11	Accessory Unit	Boeing
65-60211-13	Accessory Unit	Boeing
65-60211-15	Accessory Unit	Boeing
65-60211-17	Accessory Unit	Boeing
65-60211-19	Accessory Unit	Boeing
65-60211-20	Accessory Unit	Boeing
65-60211-21	Accessory Unit	Boeing
65-60211-23	Accessory Unit	Boeing
65-60211-25	Accessory Unit	Boeing
65-60211-27	Accessory Unit	Boeing
65-60211-28	Accessory Unit	Boeing
65-60211-30	Accessory Unit	Boeing
65-60211-32	Accessory Unit	Boeing
65-60211-34	Accessory Unit	Boeing
65-60211-36	Accessory Unit	Boeing
65-60211-38	Accessory Unit	Boeing
65-60211-40	Accessory Unit	Boeing
65-60211-41	Accessory Unit	Boeing
65-60211-42	Accessory Unit	Boeing

Repair_Capability_List_Excel

65-60211-43	Accessory Unit	Boeing
65-60211-44	Accessory Unit	Boeing
65-60211-45	Accessory Unit	Boeing
65-60211-46	Accessory Unit	Boeing
65-60211-48	Accessory Unit	Boeing
65-60211-49	Accessory Unit	Boeing
65-60211-54	Accessory Unit	Boeing
65-60211-56	Accessory Unit	Boeing
65-60211-9	Accessory Unit	Boeing
65-60214-12	Accessory Unit	Boeing
65-60214-155	Accessory Unit	Boeing
65-60488-1	Transmitter assy	Boeing
65-60488-10	Transmitter assy	Boeing
65-60488-11	Transmitter assy	Boeing
65-60488-12	Transmitter assy	Boeing
65-60488-13	Transmitter assy	Boeing
65-60488-14	Transmitter assy	Boeing
65-60488-15	Transmitter assy	Boeing
65-60488-16	Transmitter assy	Boeing
65-60488-17	Transmitter assy	Boeing
65-60488-18	Transmitter assy	Boeing
65-60488-19	Transmitter assy	Boeing
65-60488-2	Transmitter assy	Boeing
65-60488-20	Transmitter assy	Boeing
65-60488-21	Transmitter assy	Boeing
65-60488-22	Transmitter assy	Boeing
65-60488-3	Transmitter assy	Boeing
65-60488-4	Transmitter assy	Boeing
65-60488-5	Transmitter assy	Boeing
65-60488-6	Transmitter assy	Boeing
65-60488-7	Transmitter assy	Boeing
65-60488-8	Transmitter assy	Boeing
65-60488-9	Transmitter assy	Boeing
65-60500-1	Aft Airstairs Ctrl Console Mechanism	Boeing
65-60586-1	Elev. Ctrl Feel & Centering Tube & Crank	Boeing
6562	Valve	J.C. Carter
65-62238-1	Cargo Door Latch Actuator	Boeing
65-62575-1	APU Exhaust Duct Muffler	Boeing
65-62575-21	APU Exhaust Duct Muffler	Boeing
65-62575-22	APU Exhaust Duct Muffler	Boeing
65-62575-29	APU Exhaust Duct Muffler	Boeing
65-62575-31	APU Exhaust Duct Muffler	Boeing
65-62575-32	APU Exhaust Duct Muffler	Boeing
65-62575-45	APU Exhaust Duct Muffler	Boeing
65-62575-46	APU Exhaust Duct Muffler	Boeing
65-62598-5	APU Fire Warning Horn	Boeing
65-62790-2	Flap & Slat Position Indicator	Boeing
6563	Shut-Off Valve	J.C. Carter
65-63413-1	Outb.Flap Sequencing Carriage & Toggle	Boeing
65-63413-4	Outb.Flap Sequencing Carriage & Toggle	Boeing
65-63415-1	MLG Installation Components	Boeing
65-63415-2	MLG Installation Components	Boeing
65-63415-7	MLG Installation Components	Boeing
65-63415-8	MLG Installation Components	Boeing
65-63416-1	Main Gear Inner Door	Boeing
65-63416-2	Main Gear Inner Door	Boeing
65-63629-1	Cargo System Canted Track Pallet Lock	Boeing
65-63629-10	Cargo System Canted Track Pallet Lock	Boeing

Repair_Capability_List_Excel

65-63629-11	Cargo System Canted Track Pallet Lock	Boeing
65-63629-12	Cargo System Canted Track Pallet Lock	Boeing
65-63629-2	Cargo System Canted Track Pallet Lock	Boeing
65-63629-3	Cargo System Canted Track Pallet Lock	Boeing
65-63629-4	Cargo System Canted Track Pallet Lock	Boeing
65-63629-5	Cargo System Canted Track Pallet Lock	Boeing
65-63629-6	Cargo System Canted Track Pallet Lock	Boeing
65-63629-7	Cargo System Canted Track Pallet Lock	Boeing
65-63629-8	Cargo System Canted Track Pallet Lock	Boeing
65-63630-1	Cargo System Canted Track Pallet Lock	Boeing
65-63630-2	Cargo System Canted Track Pallet Lock	Boeing
65-63630-3	Cargo System Canted Track Pallet Lock	Boeing
65-63630-4	Cargo System Canted Track Pallet Lock	Boeing
65-63630-5	Cargo System Canted Track Pallet Lock	Boeing
65-63630-6	Cargo System Canted Track Pallet Lock	Boeing
65-63630-7	Cargo System Canted Track Pallet Lock	Boeing
65-63630-8	Cargo System Canted Track Pallet Lock	Boeing
65-63639-1	Cargo System Side Restraint Guide	Boeing
65-63639-2	Cargo System Side Restraint Guide	Boeing
65-63639-3	Cargo System Side Restraint Guide	Boeing
65-63642-1	Cargo System Side Restraint Guide	Boeing
65-63642-2	Cargo System Side Restraint Guide	Boeing
65-63642-3	Cargo System Side Restraint Guide	Boeing
65-63642-4	Cargo System Side Restraint Guide	Boeing
65-63642-5	Cargo System Side Restraint Guide	Boeing
65-63851-1	Flap Drive Power Unit	Boeing
65-63851-12	Flap Drive Power Unit	Boeing
65-63851-13	Flap Drive Power Unit	Boeing
65-63851-2	Flap Drive Power Unit	Boeing
65-63851-3	Flap Drive Power Unit	Boeing
65-63851-4	Flap Drive Power Unit	Boeing
65-63851-5	Flap Drive Power Unit	Boeing
65-63851-6	Flap Drive Power Unit	Boeing
65-63851-7	Flap Drive Power Unit	Boeing
65-63851-8	Flap Drive Power Unit	Boeing
65-63851-9	Flap Drive Power Unit	Boeing
65-64953-1	Audio Accessory Unit	Boeing
65-64960-3	Annunciator Lights Module	Boeing
65-64960-5	Annunciator Lights Module	Boeing
65-64960-7	Annunciator Lights Module	Boeing
65-65310-10	Elevator Buss Assy	Boeing
65-65310-11	Elevator Buss Assy	Boeing
65-65310-12	Elevator Buss Assy	Boeing
65-65310-13	Elevator Buss Assy	Boeing
65-65310-14	Elevator Buss Assy	Boeing
65-65310-15	Elevator Buss Assy	Boeing
65-65310-16	Elevator Buss Assy	Boeing
65-65310-17	Elevator Buss Assy	Boeing
65-65310-18	Elevator Buss Assy	Boeing
65-65310-19	Elevator Buss Assy	Boeing
65-65310-2	Elevator Buss Assy	Boeing
65-65310-3	Elevator Buss Assy	Boeing
65-65310-4	Elevator Buss Assy	Boeing
65-65310-5	Elevator Buss Assy	Boeing
65-65310-7	Elevator Buss Assy	Boeing
65-65310-8	Elevator Buss Assy	Boeing
65-65310-9	Elevator Buss Assy	Boeing
65-65382-11	Center Wing Tank Sump Drain	Boeing

Repair_Capability_List_Excel

65-65382-12	Center Wing Tank Sump Drain	Boeing
65-65382-14	Center Wing Tank Sump Drain	Boeing
65-65382-16	Center Wing Tank Sump Drain	Boeing
65-65382-19	Center Wing Tank Sump Drain	Boeing
65-65382-8	Center Wing Tank Sump Drain	Boeing
65-65382-9	Center Wing Tank Sump Drain	Boeing
65-66218-1	APU Cooling Air Valve	Boeing
65-66218-2	APU Cooling Air Valve	Boeing
65-66218-3	APU Cooling Air Valve	Boeing
65-66245-1	Vane	Airbus Industrie
65-67158-1	Flap Track assy	Boeing
65-67158-2	Flap Track assy	Boeing
65-67158-3	Flap Track assy	Boeing
65-67158-5	Flap Track assy	Boeing
65-67158-6	Flap Track assy	Boeing
65-67194-1	Main Gear Outboard Door	Boeing
65-67194-10	Main Gear Outboard Door	Boeing
65-67194-2	Main Gear Outboard Door	Boeing
65-67194-3	Main Gear Outboard Door	Boeing
65-67194-4	Main Gear Outboard Door	Boeing
65-67194-5	Main Gear Outboard Door	Boeing
65-67194-6	Main Gear Outboard Door	Boeing
65-67194-7	Main Gear Outboard Door	Boeing
65-67194-8	Main Gear Outboard Door	Boeing
65-67194-9	Main Gear Outboard Door	Boeing
65-67303-5	Drive Emerg.Ext.Latch & Lockout Mech	Boeing
65-67303-6	Drive Emerg.Ext.Latch & Lockout Mech	Boeing
65-67303-7	Drive Emerg.Ext.Latch & Lockout Mech	Boeing
65-67303-9	Drive Emerg.Ext.Latch & Lockout Mech	Boeing
65-67832-3	Cargo Syst.Main Cargo Door Threshold	Boeing
65-67832-4	Cargo Syst.Main Cargo Door Threshold	Boeing
65-67832-5	Cargo Syst.Main Cargo Door Threshold	Boeing
65-67906-4	Ram Air Deflector Extension Link	Boeing
65-68297-1	Carriage assy	Boeing
65-68297-13	Carriage assy	Boeing
65-68297-14	Carriage assy	Boeing
65-68297-15	Carriage assy	Boeing
65-68297-16	Carriage assy	Boeing
65-68297-17	Carriage assy	Boeing
65-68297-18	Carriage assy	Boeing
65-68297-2	Carriage assy	Boeing
65-68297-3	Carriage assy	Boeing
65-68297-4	Carriage assy	Boeing
65-68297-5	Carriage assy	Boeing
65-68297-6	Carriage assy	Boeing
65-68297-7	Carriage assy	Boeing
65-68297-8	Carriage assy	Boeing
65-68935-1	APU Cooling Air Valve	Boeing
65-68935-2	APU Cooling Air Valve	Boeing
65-68935-3	APU Cooling Air Valve	Boeing
65-68935-4	APU Cooling Air Valve	Boeing
65-68935-5	APU Cooling Air Valve	Boeing
65-68935-7	APU Cooling Air Valve	Boeing
65-68945-1	APU Fire Warning Horn	Boeing
65-68945-6	APU Fire Warning Horn	Boeing
65-68945-8	APU Fire Warning Horn	Boeing
65-68967-3	Aft Attendant's Oxygen Service Unit	Boeing
65691-005-1	Fuel Flow Indicator	Thales Avionics

Repair_Capability_List_Excel

65691-006-1	Fuel Flow Indicator	Thales Avionics
65691-099-1	Fuel Flow Indicator	Thales Avionics
65691-100-1	EGT Indicator	Thales Avionics
65691-100-2	EGT Indicator	Thales Avionics
65691-100-3	EGT Indicator	Thales Avionics
65691-103-1	EGT Indicator	Thales Avionics
65691-122-1	EGT Indicator	Thales Avionics
65691-204-1	N1 Indicator	Thales Avionics
65691-255-1	Indicator	Thales Avionics
65691-256-1	N1 Indicator	Thales Avionics
65691-257-1	N2 Indicator	Thales Avionics
65691-301-1	Pressure Indicator	Thales Avionics
65691-400-1	Pressure Indicator	Thales Avionics
65-70973-2	Rudder Controls Centering Unit	Boeing
65-70973-3	Rudder Controls Centering Unit	Boeing
65-70973-4	Rudder Controls Centering Unit	Boeing
65-70973-6	Rudder Controls Centering Unit	Boeing
65-71680-1	Actuator	Boeing
65-71680-2	Actuator	Boeing
65-71940-15	Inboard Trailing Edge Flap	Boeing
65-71940-16	Inboard Trailing Edge Flap	Boeing
65-71940-17	Inboard Trailing Edge Flap	Boeing
65-71940-18	Inboard Trailing Edge Flap	Boeing
65-71940-27	Inboard Trailing Edge Flap	Boeing
65-71940-28	Inboard Trailing Edge Flap	Boeing
65-71940-35	Inboard Trailing Edge Flap	Boeing
65-71940-36	Inboard Trailing Edge Flap	Boeing
65-71969-1	Inboard Trailing Edge Flap	Boeing
65-71969-2	Inboard Trailing Edge Flap	Boeing
65-71969-3	Inboard Trailing Edge Flap	Boeing
65-71969-4	Inboard Trailing Edge Flap	Boeing
65-71972-1	Outboard Trailing Edge Flap	Boeing
65-71972-2	Outboard Trailing Edge Flap	Boeing
65-71972-3	Outboard Trailing Edge Flap	Boeing
65-71972-4	Outboard Trailing Edge Flap	Boeing
65-72067-1	Auto Flight Ctrl Syst.Floodlight Ctrl Mod.	Boeing
65-72067-11	Auto Flight Ctrl Syst.Floodlight Ctrl Mod.	Boeing
65-72067-5	Auto Flight Ctrl Syst.Floodlight Ctrl Mod.	Boeing
65-72067-8	Auto Flight Ctrl Syst.Floodlight Ctrl Mod.	Boeing
65-72719-101	Light assy	Boeing
65-73271-1	Shaft Assembly	Boeing
65-73271-13	Shaft Assembly	Boeing
65-73271-15	Shaft Assembly	Boeing
65-73271-17	Shaft Assembly	Boeing
65-73271-2	Shaft Assembly	Boeing
65-73271-3	Shaft Assembly	Boeing
65-73271-4	Shaft Assembly	Boeing
65-73271-5	Shaft Assembly	Boeing
65-73271-6	Shaft Assembly	Boeing
65-73271-7	Shaft Assembly	Boeing
65-73675-4	Thrust Reverser Hyd. Control Valve	Boeing
65-73675-5	Thrust Reverser Hyd. Control Valve	Boeing
65-73698-1	ATR Hinged Chassis	Boeing
65-73698-17	ATR Hinged Chassis	Boeing
65-73698-25	ATR Hinged Chassis	Boeing
65-73698-32	ATR Hinged Chassis	Boeing
65-73698-54	ATR Hinged Chassis	Boeing
65-73698-55	ATR Hinged Chassis	Boeing

Repair_Capability_List_Excel

65-73698-58	ATR Hinged Chassis	Boeing
65-73698-59	ATR Hinged Chassis	Boeing
65-73698-71	ATR Hinged Chassis	Boeing
65-73698-72	ATR Hinged Chassis	Boeing
65-73698-73	ATR Hinged Chassis	Boeing
65-73698-76	ATR Hinged Chassis	Boeing
65-73698-93	ATR Hinged Chassis	Boeing
65-73732-19	Outb.Flap Sequencing Carriage & Toggle	Boeing
65-73732-20	Outb.Flap Sequencing Carriage & Toggle	Boeing
65-73732-21	Outb.Flap Sequencing Carriage & Toggle	Boeing
65-73732-22	Outb.Flap Sequencing Carriage & Toggle	Boeing
65-73732-5	Outb.Flap Sequencing Carriage & Toggle	Boeing
65-73732-6	Outb.Flap Sequencing Carriage & Toggle	Boeing
65-73761-103	Main Gear Side Strut	Boeing
65-73761-105	Main Gear Side Strut	Boeing
65-73761-106	Main Gear Side Strut	Boeing
65-73761-111	Main Gear Side Strut	Boeing
65-73761-112	Main Gear Side Strut	Boeing
65-73761-113	Main Gear Side Strut	Boeing
65-73761-114	Main Gear Side Strut	Boeing
65-73761-123	Main Gear Side Strut	Boeing
65-73761-124	Main Gear Side Strut	Boeing
65-73761-21	Main Gear Side Strut	Boeing
65-73761-22	Main Gear Side Strut	Boeing
65-73761-23	Main Gear Side Strut	Boeing
65-73761-24	Main Gear Side Strut	Boeing
65-73761-25	Main Gear Side Strut	Boeing
65-73761-26	Main Gear Side Strut	Boeing
65-73761-43	Main Gear Side Strut	Boeing
65-73761-44	Main Gear Side Strut	Boeing
65-73761-45	Main Gear Side Strut	Boeing
65-73761-46	Main Gear Side Strut	Boeing
65-73761-47	Main Gear Side Strut	Boeing
65-73761-48	Main Gear Side Strut	Boeing
65-73761-49	Main Gear Side Strut	Boeing
65-73761-50	Main Gear Side Strut	Boeing
65-73761-55	Main Gear Side Strut	Boeing
65-73761-56	Main Gear Side Strut	Boeing
65-73761-77	Main Gear Side Strut	Boeing
65-73761-78	Main Gear Side Strut	Boeing
65-73761-85	Main Gear Side Strut	Boeing
65-73761-86	Main Gear Side Strut	Boeing
65-73761-93	Main Gear Side Strut	Boeing
65-73761-94	Main Gear Side Strut	Boeing
65-73761-95	Main Gear Side Strut	Boeing
65-73761-96	Main Gear Side Strut	Boeing
65-73874-2	System B Hydraulic Modular Package	Boeing
65-75960-12	Aileron Centering Mechanism	Boeing
65-75960-14	Aileron Centering Mechanism	Boeing
65-75960-17	Aileron Centering Mechanism	Boeing
65-75960-18	Aileron Centering Mechanism	Boeing
65-75960-19	Aileron Centering Mechanism	Boeing
65-75960-2	Aileron Centering Mechanism	Boeing
65-75960-20	Aileron Centering Mechanism	Boeing
65-75960-22	Aileron Centering Mechanism	Boeing
65-75960-23	Aileron Centering Mechanism	Boeing
65-75960-25	Aileron Centering Mechanism	Boeing
65-75960-4	Aileron Centering Mechanism	Boeing

Repair_Capability_List_Excel

65-75960-5	Aileron Centering Mechanism	Boeing
65-75960-6	Aileron Centering Mechanism	Boeing
65-75960-8	Aileron Centering Mechanism	Boeing
65-76611-26	Nose Gear Gravel Deflector	Boeing
65-76611-28	Nose Gear Gravel Deflector	Boeing
65-76611-43	Nose Gear Gravel Deflector	Boeing
65-76942-1	Cargo System Roller Tray & Tiedown	Boeing
65-76942-16	Cargo System Roller Tray & Tiedown	Boeing
65-76942-2	Cargo System Roller Tray & Tiedown	Boeing
65-76942-3	Cargo System Roller Tray & Tiedown	Boeing
65-76942-4	Cargo System Roller Tray & Tiedown	Boeing
65-76942-5	Cargo System Roller Tray & Tiedown	Boeing
65-76942-6	Cargo System Roller Tray & Tiedown	Boeing
65-76944-1	Seat Pallet Attach Fitting	Boeing
65-76944-10	Seat Pallet Attach Fitting	Boeing
65-76944-14	Seat Pallet Attach Fitting	Boeing
65-76944-16	Seat Pallet Attach Fitting	Boeing
65-76944-18	Seat Pallet Attach Fitting	Boeing
65-76944-19	Seat Pallet Attach Fitting	Boeing
65-76944-2	Seat Pallet Attach Fitting	Boeing
65-76944-22	Seat Pallet Attach Fitting	Boeing
65-76944-23	Seat Pallet Attach Fitting	Boeing
65-76944-25	Seat Pallet Attach Fitting	Boeing
65-76944-26	Seat Pallet Attach Fitting	Boeing
65-76944-27	Seat Pallet Attach Fitting	Boeing
65-76944-28	Seat Pallet Attach Fitting	Boeing
65-76944-3	Seat Pallet Attach Fitting	Boeing
65-76944-36	Seat Pallet Attach Fitting	Boeing
65-76944-38	Seat Pallet Attach Fitting	Boeing
65-76944-39	Seat Pallet Attach Fitting	Boeing
65-76944-4	Seat Pallet Attach Fitting	Boeing
65-76944-41	Seat Pallet Attach Fitting	Boeing
65-76944-5	Seat Pallet Attach Fitting	Boeing
65-76944-6	Seat Pallet Attach Fitting	Boeing
65-76944-7	Seat Pallet Attach Fitting	Boeing
65-76944-8	Seat Pallet Attach Fitting	Boeing
65-76944-9	Seat Pallet Attach Fitting	Boeing
6577	Vaneaxial Fan assy	Hamilton Sundstrand
6577-1	Vaneaxial Fan assy	Hamilton Sundstrand
6577-2	Vaneaxial Fan assy	Hamilton Sundstrand
65-77496-10	Main Gear Actuator	Boeing
65-77496-11	Main Gear Actuator	Boeing
65-77496-12	Main Gear Actuator	Boeing
65-77496-13	Main Gear Actuator	Boeing
65-77496-14	Main Gear Actuator	Boeing
65-77496-17	Main Gear Actuator	Boeing
65-77496-18	Main Gear Actuator	Boeing
65-77496-19	Main Gear Actuator	Boeing
65-77496-20	Main Gear Actuator	Boeing
65-77496-21	Main Gear Actuator	Boeing
65-77496-22	Main Gear Actuator	Boeing
65-77496-23	Main Gear Actuator	Boeing
65-77496-26	Main Gear Actuator	Boeing
65-77496-27	Main Gear Actuator	Boeing
65-77496-28	Main Gear Actuator	Boeing
65-77496-29	Main Gear Actuator	Boeing
65-77496-30	Main Gear Actuator	Boeing
65-77496-5	Main Gear Actuator	Boeing

Repair_Capability_List_Excel

65-77496-6	Main Gear Actuator	Boeing
65-77496-7	Main Gear Actuator	Boeing
65-77496-8	Main Gear Actuator	Boeing
65-77496-9	Main Gear Actuator	Boeing
6577-7	Vaneaxial Fan	Hamilton Sundstrand
65-77729-10	Auto Flight Ctrl Syst.Floodlight Ctrl Mod.	Boeing
65-78987-9	Pneumatic Actuator	Boeing
65-79164-100	Passenger Service Unit	Boeing
65-79164-101	Passenger Service Unit	Boeing
65-79164-102	Passenger Service Unit	Boeing
65-79164-103	Passenger Service Unit	Boeing
65-79164-104	Passenger Service Unit	Boeing
65-79164-105	Passenger Service Unit	Boeing
65-79164-106	Passenger Service Unit	Boeing
65-79164-109	Passenger Service Unit	Boeing
65-79164-110	Passenger Service Unit	Boeing
65-79164-111	Passenger Service Unit	Boeing
65-79164-112	Passenger Service Unit	Boeing
65-79164-113	Passenger Service Unit	Boeing
65-79164-114	Passenger Service Unit	Boeing
65-79164-115	Passenger Service Unit	Boeing
65-79164-116	Passenger Service Unit	Boeing
65-79164-117	Passenger Service Unit	Boeing
65-79164-118	Passenger Service Unit	Boeing
65-79164-119	Passenger Service Unit	Boeing
65-79164-120	Passenger Service Unit	Boeing
65-79164-121	Passenger Service Unit	Boeing
65-79164-122	Passenger Service Unit	Boeing
65-79164-123	Passenger Service Unit	Boeing
65-79164-124	Passenger Service Unit	Boeing
65-79164-125	Passenger Service Unit	Boeing
65-79164-126	Passenger Service Unit	Boeing
65-79164-127	Passenger Service Unit	Boeing
65-79164-128	Passenger Service Unit	Boeing
65-79164-129	Passenger Service Unit	Boeing
65-79164-13	Passenger Service Unit	Boeing
65-79164-130	Passenger Service Unit	Boeing
65-79164-131	Passenger Service Unit	Boeing
65-79164-132	Passenger Service Unit	Boeing
65-79164-133	Passenger Service Unit	Boeing
65-79164-134	Passenger Service Unit	Boeing
65-79164-135	Passenger Service Unit	Boeing
65-79164-136	Passenger Service Unit	Boeing
65-79164-14	Passenger Service Unit	Boeing
65-79164-15	Passenger Service Unit	Boeing
65-79164-159	Passenger Service Unit	Boeing
65-79164-16	Passenger Service Unit	Boeing
65-79164-160	Passenger Service Unit	Boeing
65-79164-161	Passenger Service Unit	Boeing
65-79164-162	Passenger Service Unit	Boeing
65-79164-17	Passenger Service Unit	Boeing
65-79164-175	Passenger Service Unit	Boeing
65-79164-176	Passenger Service Unit	Boeing
65-79164-18	Passenger Service Unit	Boeing
65-79164-19	Passenger Service Unit	Boeing
65-79164-20	Passenger Service Unit	Boeing
65-79164-21	Passenger Service Unit	Boeing
65-79164-22	Passenger Service Unit	Boeing

Repair_Capability_List_Excel

65-79165-60	Passenger Service Unit	Boeing
65-79165-61	Passenger Service Unit	Boeing
65-79165-62	Passenger Service Unit	Boeing
65-79165-69	Passenger Service Unit	Boeing
65-79165-70	Passenger Service Unit	Boeing
65-79425-2	Elevator Tab Control Mechanism	Boeing
65-79425-3	Elevator Tab Control Mechanism	Boeing
65-79425-4	Elevator Tab Control Mechanism	Boeing
65-79425-5	Elevator Tab Control Mechanism	Boeing
65-79425-6	Elevator Tab Control Mechanism	Boeing
65-79474-2	Engine Controls Drum and Brake	Boeing
65-79475-11	Engine Controls Drum and Brake	Boeing
65-79475-12	Engine Controls Drum and Brake	Boeing
65-79475-14	Engine Controls Drum and Brake	Boeing
65-79475-15	Engine Controls Drum and Brake	Boeing
65-79475-19	Engine Controls Drum and Brake	Boeing
65-79475-2	Engine Controls Drum and Brake	Boeing
65-79475-20	Engine Controls Drum and Brake	Boeing
65-79475-3	Engine Controls Drum and Brake	Boeing
65-79475-5	Engine Controls Drum and Brake	Boeing
65-79475-6	Engine Controls Drum and Brake	Boeing
65-79475-8	Engine Controls Drum and Brake	Boeing
65-79475-9	Engine Controls Drum and Brake	Boeing
65-79479-5	Automatic Brake Accessory Unit	Boeing
65-79479-7	Automatic Brake Accessory Unit	Boeing
65-79949-1	Carriage assy	Boeing
65-79949-2	Carriage assy	Boeing
65-79949-3	Carriage assy	Boeing
65-79949-4	Carriage assy	Boeing
65-79949-5	Carriage assy	Boeing
65-79949-6	Carriage assy	Boeing
65-79949-7	Carriage assy	Boeing
65-79949-8	Carriage assy	Boeing
65-80021-3	Air Conditioning Accessory Unit	Boeing
65-80021-4	Air Conditioning Accessory Unit	Boeing
65-80025-4	Autothrottle Clutch and Cam	Boeing
65-80025-5	Autothrottle Clutch and Cam	Boeing
65-80025-6	Autothrottle Clutch and Cam	Boeing
65-80025-7	Autothrottle Clutch and Cam	Boeing
65-80025-8	Autothrottle Clutch and Cam	Boeing
65-80025-9	Autothrottle Clutch and Cam	Boeing
65-80051-1	Nose Minor Components	Boeing
65-80051-10	Nose Minor Components	Boeing
65-80051-11	Nose Minor Components	Boeing
65-80051-13	Nose Minor Components	Boeing
65-80051-14	Nose Minor Components	Boeing
65-80051-18	Nose Minor Components	Boeing
65-80051-20	Nose Minor Components	Boeing
65-80051-3	Nose Minor Components	Boeing
65-80051-5	Nose Minor Components	Boeing
65-80051-6	Nose Minor Components	Boeing
65-80051-7	Nose Minor Components	Boeing
65-80051-8	Nose Minor Components	Boeing
65-80055-1	Gearbox assy	Boeing
65-80055-4	Gearbox assy	Boeing
65-80055-5	Gearbox assy	Boeing
65-800555-1	Flap Pos.& Stall Warning Xmtr Gearbox	Boeing
65-800555-4	Flap Pos.& Stall Warning Xmtr Gearbox	Boeing

Repair_Capability_List_Excel

65-800555-5	Flap Pos.& Stall Warning Xmtr Gearbox	Boeing
65-800555-6	Flap Pos.& Stall Warning Xmtr Gearbox	Boeing
65-80055-6	Gearbox assy	Boeing
65-80145-1	Stowage Compartment Snubber	Boeing
65-80145-2	Stowage Compartment Snubber	Boeing
65-80213-15	Cargo System Side Restraint Guide	Boeing
65-80213-20	Cargo System Side Restraint Guide	Boeing
65-80213-7	Cargo System Side Restraint Guide	Boeing
65805-800-1	Clock	Thales Avionics
65806-002-1	Electronic Clock	Thales
65807-040-1	Electronic Clock	Thales Avionics
65807-051-1	Electronic Clock	Thales Avionics
65-80922-2	Landing Gear Accessory Unit	Boeing
65-80930	Nose Gear Spring Cartridge	Boeing
65-81432-15	Cargo Pallet Lock	Boeing
65-81432-16	Cargo Pallet Lock	Boeing
65-81432-17	Cargo System Roller Tray	Boeing
65-82493-2E	Light	Boeing
65-825010-00	Filter	Airbus Industrie
65-82721-1	Partial Sect. Passenger Service Unit	Boeing
65-82721-19	Partial Sect. Passenger Service Unit	Boeing
65-82721-2	Partial Sect. Passenger Service Unit	Boeing
65-82721-23	Partial Sect. Passenger Service Unit	Boeing
65-82721-24	Partial Sect. Passenger Service Unit	Boeing
65-82721-25	Partial Sect. Passenger Service Unit	Boeing
65-82721-26	Partial Sect. Passenger Service Unit	Boeing
65-82721-27	Partial Sect. Passenger Service Unit	Boeing
65-82721-28	Partial Sect. Passenger Service Unit	Boeing
65-82721-29	Partial Sect. Passenger Service Unit	Boeing
65-82721-3	Partial Sect. Passenger Service Unit	Boeing
65-82721-30	Partial Sect. Passenger Service Unit	Boeing
65-82721-37	Partial Sect. Passenger Service Unit	Boeing
65-82721-38	Partial Sect. Passenger Service Unit	Boeing
65-82721-39	Partial Sect. Passenger Service Unit	Boeing
65-82721-4	Partial Sect. Passenger Service Unit	Boeing
65-82721-40	Partial Sect. Passenger Service Unit	Boeing
65-82721-45	Partial Sect. Passenger Service Unit	Boeing
65-82721-46	Partial Sect. Passenger Service Unit	Boeing
65-82721-47	Partial Sect. Passenger Service Unit	Boeing
65-82721-48	Partial Sect. Passenger Service Unit	Boeing
65-82721-49	Partial Sect. Passenger Service Unit	Boeing
65-82721-5	Partial Sect. Passenger Service Unit	Boeing
65-82721-50	Partial Sect. Passenger Service Unit	Boeing
65-82721-51	Partial Sect. Passenger Service Unit	Boeing
65-82721-52	Partial Sect. Passenger Service Unit	Boeing
65-82721-53	Partial Sect. Passenger Service Unit	Boeing
65-82721-54	Partial Sect. Passenger Service Unit	Boeing
65-82721-6	Partial Sect. Passenger Service Unit	Boeing
65-82721-67	Partial Sect. Passenger Service Unit	Boeing
65-82721-68	Partial Sect. Passenger Service Unit	Boeing
65-82721-69	Partial Sect. Passenger Service Unit	Boeing
65-82721-7	Partial Sect. Passenger Service Unit	Boeing
65-82721-70	Partial Sect. Passenger Service Unit	Boeing
65-82721-71	Partial Sect. Passenger Service Unit	Boeing
65-82721-72	Partial Sect. Passenger Service Unit	Boeing
65-82721-75	Partial Sect. Passenger Service Unit	Boeing
65-82721-77	Partial Sect. Passenger Service Unit	Boeing
65-82721-78	Partial Sect. Passenger Service Unit	Boeing

Repair_Capability_List_Excel

65-82721-79	Partial Sect. Passenger Service Unit	Boeing
65-82721-8	Partial Sect. Passenger Service Unit	Boeing
65-82721-83	Partial Sect. Passenger Service Unit	Boeing
65-82721-84	Partial Sect. Passenger Service Unit	Boeing
65-82721-87	Partial Sect. Passenger Service Unit	Boeing
65-82721-88	Partial Sect. Passenger Service Unit	Boeing
65-82721-89	Partial Sect. Passenger Service Unit	Boeing
65-82721-90	Partial Sect. Passenger Service Unit	Boeing
65-82721-91	Partial Sect. Passenger Service Unit	Boeing
65-82721-92	Partial Sect. Passenger Service Unit	Boeing
65-82721-93	Partial Sect. Passenger Service Unit	Boeing
65840000-01	Block assy	Liebherr Aerospace
65840000-02	Block assy	Liebherr Aerospace
65-84163-1	Nose Minor Components	Boeing
65-84209-1	Auto Speed Brake Ctrl Accessory Unit	Boeing
65-84209-11	Auto Speed Brake Ctrl Accessory Unit	Boeing
65-84209-13	Auto Speed Brake Ctrl Accessory Unit	Boeing
65-84209-17	Auto Speed Brake Ctrl Accessory Unit	Boeing
65-84209-19	Auto Speed Brake Ctrl Accessory Unit	Boeing
65-84209-21	Auto Speed Brake Ctrl Accessory Unit	Boeing
65-84209-3	Auto Speed Brake Ctrl Accessory Unit	Boeing
65-84209-5	Auto Speed Brake Ctrl Accessory Unit	Boeing
65-84209-7	Auto Speed Brake Ctrl Accessory Unit	Boeing
65-84209-8	Auto Speed Brake Ctrl Accessory Unit	Boeing
65-85316-11	Audio Accessory Unit	Boeing
65-85316-5	Audio Accessory Unit	Boeing
65-85316-9	Audio Accessory Unit	Boeing
65-86412-1	Passenger Service Unit	Boeing
65-86412-10	Passenger Service Unit	Boeing
65-86412-2	Passenger Service Unit	Boeing
65-86412-21	Passenger Service Unit	Boeing
65-86412-22	Passenger Service Unit	Boeing
65-86412-23	Passenger Service Unit	Boeing
65-86412-24	Passenger Service Unit	Boeing
65-86412-3	Passenger Service Unit	Boeing
65-86412-4	Passenger Service Unit	Boeing
65-86412-5	Passenger Service Unit	Boeing
65-86412-6	Passenger Service Unit	Boeing
65-86412-7	Passenger Service Unit	Boeing
65-86412-8	Passenger Service Unit	Boeing
65-86412-9	Passenger Service Unit	Boeing
65-86413-1	Passenger Service Unit	Boeing
65-86413-10	Passenger Service Unit	Boeing
65-86413-100	Passenger Service Unit	Boeing
65-86413-101	Passenger Service Unit	Boeing
65-86413-102	Passenger Service Unit	Boeing
65-86413-103	Passenger Service Unit	Boeing
65-86413-104	Passenger Service Unit	Boeing
65-86413-106	Passenger Service Unit	Boeing
65-86413-11	Passenger Service Unit	Boeing
65-86413-12	Passenger Service Unit	Boeing
65-86413-13	Passenger Service Unit	Boeing
65-86413-14	Passenger Service Unit	Boeing
65-86413-15	Passenger Service Unit	Boeing
65-86413-16	Passenger Service Unit	Boeing
65-86413-17	Passenger Service Unit	Boeing
65-86413-18	Passenger Service Unit	Boeing
65-86413-19	Passenger Service Unit	Boeing

Repair_Capability_List_Excel

65-86413-8	Passenger Service Unit	Boeing
65-86413-80	Passenger Service Unit	Boeing
65-86413-81	Passenger Service Unit	Boeing
65-86413-82	Passenger Service Unit	Boeing
65-86413-83	Passenger Service Unit	Boeing
65-86413-84	Passenger Service Unit	Boeing
65-86413-85	Passenger Service Unit	Boeing
65-86413-86	Passenger Service Unit	Boeing
65-86413-87	Passenger Service Unit	Boeing
65-86413-88	Passenger Service Unit	Boeing
65-86413-89	Passenger Service Unit	Boeing
65-86413-9	Passenger Service Unit	Boeing
65-86413-90	Passenger Service Unit	Boeing
65-86413-91	Passenger Service Unit	Boeing
65-86413-92	Passenger Service Unit	Boeing
65-86413-93	Passenger Service Unit	Boeing
65-86413-94	Passenger Service Unit	Boeing
65-86413-95	Passenger Service Unit	Boeing
65-86413-97	Passenger Service Unit	Boeing
65-86413-98	Passenger Service Unit	Boeing
65-86413-99	Passenger Service Unit	Boeing
65-86747-1	Nose Gear Gravel Deflector	Boeing
65-86762-1	Nose Gear Gravel Deflector	Boeing
65-86762-5	Nose Gear Gravel Deflector	Boeing
65-86762-6	Nose Gear Gravel Deflector	Boeing
65-86762-7	Nose Gear Gravel Deflector	Boeing
658A0000-01	Block Valve	Goodrich Control Systems
658A0000-02	Block Valve	Goodrich Control Systems
658D100-1	Rudder Trim Actuator	Eaton
658D100-3	Rudder Trim Actuator	Eaton
658D100-5	Rudder Trim Actuator	Eaton
658D100-7	Rudder Trim Actuator	Eaton
658D100-9	Rudder Trim Actuator	Eaton
65907-103-2	Airspeed Indicator	Thales Avionics
65-98491-1	Transmitter assy	Boeing
65-98491-2	Transmitter assy	Boeing
65-98491-3	Transmitter assy	Boeing
65-98491-4	Transmitter assy	Boeing
65-98491-5	Transmitter assy	Boeing
65B01500-5	Retracting Actuator	Boeing
65B01500-6	Retracting Actuator	Boeing
65B01500-7	Retracting Actuator	Boeing
65B01501-10	Actuator	Boeing
65B01501-11	Actuator	Boeing
65B01501-12	Actuator	Boeing
65B01501-7	Actuator	Boeing
65B01501-9	Actuator	Boeing
65B01502-11	Actuator	Boeing
65B01502-12	Actuator	Boeing
65B01502-14	Actuator	Boeing
65B01502-3	Actuator	Boeing
65B01502-4	Actuator	Boeing
65B01502-5	Actuator	Boeing
65B01502-7	Actuator	Boeing
65B01502-8	Actuator	Boeing
65B01502-9	Actuator	Boeing
65B01503-10	Actuator	Boeing
65B01503-11	Actuator	Boeing

Repair_Capability_List_Excel

65B01503-12	Actuator	Boeing
65B01503-16	Actuator	Boeing
65B01503-4	Actuator	Boeing
65B01503-5	Actuator	Boeing
65B01503-7	Actuator	Boeing
65B01504-11	Actuator	Boeing
65B01504-12	Actuator	Boeing
65B01504-13	Actuator	Boeing
65B01504-14	Actuator	Boeing
65B01504-15	Actuator	Boeing
65B01504-16	Actuator	Boeing
65B01504-17	Actuator	Boeing
65B01504-18	Actuator	Boeing
65B01504-21	Actuator	Boeing
65B01504-22	Actuator	Boeing
65B01504-23	Actuator	Boeing
65B01504-24	Actuator	Boeing
65B01504-3	Actuator	Boeing
65B01504-4	Actuator	Boeing
65B01538-1	Actuator	Boeing
65B01538-2	Actuator	Boeing
65B01539-3	Actuator	Boeing
65B01539-5	Actuator	Boeing
65B01539-7	Actuator	Boeing
65B01539-8	Actuator	Boeing
65B01539-9	Actuator	Boeing
65B01540-1	Actuator	Boeing
65B01540-10	Actuator	Boeing
65B01540-11	Actuator	Boeing
65B01540-12	Actuator	Boeing
65B01540-13	Actuator	Boeing
65B01540-14	Actuator	Boeing
65B01540-15	Actuator	Boeing
65B01540-16	Actuator	Boeing
65B01540-17	Actuator	Boeing
65B01540-18	Actuator	Boeing
65B01540-19	Actuator	Boeing
65B01540-2	Actuator	Boeing
65B01540-20	Actuator	Boeing
65B01540-3	Actuator	Boeing
65B01540-4	Actuator	Boeing
65B01540-5	Actuator	Boeing
65B01540-6	Actuator	Boeing
65B01540-7	Actuator	Boeing
65B01540-8	Actuator	Boeing
65B01540-9	Actuator	Boeing
65B01550-7	Retracting Actuator	Boeing
65B01550-8	Retracting Actuator	Boeing
65B01550-9	Retracting Actuator	Boeing
65B01551-10	Retracting Actuator	Boeing
65B01551-11	Retracting Actuator	Boeing
65B01551-12	Retracting Actuator	Boeing
65B01551-8	Retracting Actuator	Boeing
65B01551-9	Retracting Actuator	Boeing
65B01552-10	Retracting Actuator	Boeing
65B01552-11	Retracting Actuator	Boeing
65B01552-13	Retracting Actuator	Boeing
65B01552-21	Retracting Actuator	Boeing

Repair_Capability_List_Excel

65B01552-22	Retracting Actuator	Boeing
65B01552-3	Retracting Actuator	Boeing
65B01552-7	Retracting Actuator	Boeing
65B01552-8	Retracting Actuator	Boeing
65B01552-9	Retracting Actuator	Boeing
65B01570-2	MLG Retract Actuator	Boeing
65B01570-3	MLG Retract Actuator	Boeing
65B01570-4	MLG Retract Actuator	Boeing
65B01570-5	MLG Retract Actuator	Boeing
65B01570-6	MLG Retract Actuator	Boeing
65B01570-7	MLG Retract Actuator	Boeing
65B01570-8	MLG Retract Actuator	Boeing
65B01570-9	MLG Retract Actuator	Boeing
65B01980-1	Spindle	Boeing
65B01980-10	Spindle	Boeing
65B01980-11	Spindle	Boeing
65B01980-13	Spindle	Boeing
65B01980-14	Spindle	Boeing
65B01980-15	Spindle	Boeing
65B01980-17	Spindle	Boeing
65B01980-18	Spindle	Boeing
65B01980-2	Spindle	Boeing
65B01980-21	Spindle	Boeing
65B01980-22	Spindle	Boeing
65B01980-24	Spindle	Boeing
65B01980-4	Spindle	Boeing
65B01980-5	Spindle	Boeing
65B01980-7	Spindle	Boeing
65B01980-9	Spindle	Boeing
65B08021-17	Sequencing Carriage assy	Boeing
65B08021-18	Sequencing Carriage assy	Boeing
65B08021-19	Sequencing Carriage assy	Boeing
65B08021-20	Sequencing Carriage assy	Boeing
65B08021-21	Sequencing Carriage assy	Boeing
65B08021-22	Sequencing Carriage assy	Boeing
65B08021-23	Sequencing Carriage assy	Boeing
65B08021-24	Sequencing Carriage assy	Boeing
65B08021-25	Sequencing Carriage assy	Boeing
65B08021-26	Sequencing Carriage assy	Boeing
65B08021-27	Sequencing Carriage assy	Boeing
65B08021-28	Sequencing Carriage assy	Boeing
65B08021-29	Sequencing Carriage assy	Boeing
65B08021-30	Sequencing Carriage assy	Boeing
65B08021-31	Sequencing Carriage assy	Boeing
65B08021-32	Sequencing Carriage assy	Boeing
65B08021-33	Sequencing Carriage assy	Boeing
65B08021-34	Sequencing Carriage assy	Boeing
65B08021-35	Sequencing Carriage assy	Boeing
65B08021-36	Sequencing Carriage assy	Boeing
65B08027-10	Carriage assy	Boeing
65B08027-11	Carriage assy	Boeing
65B08027-13	Carriage assy	Boeing
65B08027-14	Carriage assy	Boeing
65B08027-15	Carriage assy	Boeing
65B08027-16	Carriage assy	Boeing
65B08027-17	Carriage assy	Boeing
65B08027-18	Carriage assy	Boeing
65B08027-19	Carriage assy	Boeing

Repair_Capability_List_Excel

65B08027-20	Carriage assy	Boeing
65B08027-21	Carriage assy	Boeing
65B08027-22	Carriage assy	Boeing
65B08027-23	Carriage assy	Boeing
65B08027-24	Carriage assy	Boeing
65B08027-25	Carriage assy	Boeing
65B08027-26	Carriage assy	Boeing
65B08027-27	Carriage assy	Boeing
65B08027-33	Carriage assy	Boeing
65B08027-34	Carriage assy	Boeing
65B08027-35	Carriage assy	Boeing
65B08027-36	Carriage assy	Boeing
65B08027-37	Carriage assy	Boeing
65B08027-38	Carriage assy	Boeing
65B08027-39	Carriage assy	Boeing
65B08027-40	Carriage assy	Boeing
65B08027-41	Carriage assy	Boeing
65B08027-42	Carriage assy	Boeing
65B08027-43	Carriage assy	Boeing
65B08027-44	Carriage assy	Boeing
65B08027-45	Carriage assy	Boeing
65B08027-46	Carriage assy	Boeing
65B08027-47	Carriage assy	Boeing
65B08027-49	Carriage assy	Boeing
65B08027-50	Carriage assy	Boeing
65B08027-51	Carriage assy	Boeing
65B08027-52	Carriage assy	Boeing
65B08027-9	Carriage assy	Boeing
65B09269-1	Spring Tube assy	Boeing
65B09269-4	Spring Tube assy	Boeing
65B10187-13	Carriage assy	Boeing
65B10187-14	Carriage assy	Boeing
65B10187-15	Carriage assy	Boeing
65B10187-16	Carriage assy	Boeing
65B10187-17	Carriage assy	Boeing
65B10187-18	Carriage assy	Boeing
65B10187-19	Carriage assy	Boeing
65B10187-20	Carriage assy	Boeing
65B10187-25	Carriage assy	Boeing
65B10187-26	Carriage assy	Boeing
65B10187-27	Carriage assy	Boeing
65B10187-28	Carriage assy	Boeing
65B10187-29	Carriage assy	Boeing
65B10187-30	Carriage assy	Boeing
65B10187-33	Carriage assy	Boeing
65B10187-34	Carriage assy	Boeing
65B10187-35	Carriage assy	Boeing
65B10187-36	Carriage assy	Boeing
65B10187-37	Carriage assy	Boeing
65B10187-38	Carriage assy	Boeing
65B10187-39	Carriage assy	Boeing
65B10187-40	Carriage assy	Boeing
65B10187-41	Carriage assy	Boeing
65B10187-42	Carriage assy	Boeing
65B10187-43	Carriage assy	Boeing
65B10187-44	Carriage assy	Boeing
65B10187-45	Carriage assy	Boeing
65B10187-46	Carriage assy	Boeing

Repair_Capability_List_Excel

65B10187-47	Carriage assy	Boeing
65B10187-48	Carriage assy	Boeing
65B10187-49	Carriage assy	Boeing
65B10187-50	Carriage assy	Boeing
65B10187-51	Carriage assy	Boeing
65B10187-52	Carriage assy	Boeing
65B10187-53	Carriage assy	Boeing
65B10187-54	Carriage assy	Boeing
65B10187-55	Carriage assy	Boeing
65B10187-56	Carriage assy	Boeing
65B10187-57	Carriage assy	Boeing
65B10187-61	Carriage assy	Boeing
65B10187-62	Carriage assy	Boeing
65B10187-63	Carriage assy	Boeing
65B11598-11	Sequencing Carriage assy	Boeing
65B11598-12	Sequencing Carriage assy	Boeing
65B11598-17	Sequencing Carriage assy	Boeing
65B11598-18	Sequencing Carriage assy	Boeing
65B11598-21	Sequencing Carriage assy	Boeing
65B11598-22	Sequencing Carriage assy	Boeing
65B11598-23	Sequencing Carriage assy	Boeing
65B11598-24	Sequencing Carriage assy	Boeing
65B11598-25	Sequencing Carriage assy	Boeing
65B11598-26	Sequencing Carriage assy	Boeing
65B11598-27	Sequencing Carriage assy	Boeing
65B11598-28	Sequencing Carriage assy	Boeing
65B11598-29	Sequencing Carriage assy	Boeing
65B11598-30	Sequencing Carriage assy	Boeing
65B11598-31	Sequencing Carriage assy	Boeing
65B11598-32	Sequencing Carriage assy	Boeing
65B11598-33	Sequencing Carriage assy	Boeing
65B11598-34	Sequencing Carriage assy	Boeing
65B11598-35	Sequencing Carriage assy	Boeing
65B11598-36	Sequencing Carriage assy	Boeing
65B11598-37	Sequencing Carriage assy	Boeing
65B11598-38	Sequencing Carriage assy	Boeing
65B11598-39	Sequencing Carriage assy	Boeing
65B11598-40	Sequencing Carriage assy	Boeing
65B11598-41	Sequencing Carriage assy	Boeing
65B11598-42	Sequencing Carriage assy	Boeing
65B11598-43	Sequencing Carriage assy	Boeing
65B11598-44	Sequencing Carriage assy	Boeing
65B11598-45	Sequencing Carriage assy	Boeing
65B11598-46	Sequencing Carriage assy	Boeing
65B16628-15	Carriage assy	Boeing
65B16628-16	Carriage assy	Boeing
65B16628-17	Carriage assy	Boeing
65B16628-18	Carriage assy	Boeing
65B17198-1	Sequencing Carriage assy	Boeing
65B17198-10	Sequencing Carriage assy	Boeing
65B17198-11	Sequencing Carriage assy	Boeing
65B17198-12	Sequencing Carriage assy	Boeing
65B17198-2	Sequencing Carriage assy	Boeing
65B17198-3	Sequencing Carriage assy	Boeing
65B17198-4	Sequencing Carriage assy	Boeing
65B17198-5	Sequencing Carriage assy	Boeing
65B17198-6	Sequencing Carriage assy	Boeing
65B17198-7	Sequencing Carriage assy	Boeing

Repair_Capability_List_Excel

65B17198-8	Sequencing Carriage assy	Boeing
65B17198-9	Sequencing Carriage assy	Boeing
65B20426-2	Control Panel	Boeing
65B20427-2	Control Panel	Boeing
65B21034-2	Accessory Box	Boeing
65B21034-502	Accessory Box	Boeing
65B27591-1	Guide and Restraint ay	Goodrich
65B27591-2	Guide and Restraint ay	Goodrich
65B28321-2	Control Panel	Boeing
65B28321-3	Control Panel	Boeing
65B40605-14	Control Panel	Boeing
65B40605-15	Control Panel	Boeing
65B40605-19	Control Panel	Boeing
65B40605-2	Control Panel	Boeing
65B40605-20	Control Panel	Boeing
65B40605-7	Control Panel	Boeing
65B40647-11	Control Panel	Boeing
65B40647-13	Control Panel	Boeing
65B40647-15	Control Panel	Boeing
65B40647-17	Control Panel	Boeing
65B40647-19	Control Panel	Boeing
65B40647-20	Control Panel	Boeing
65B40647-23	Control Panel	Boeing
65B40647-24	Control Panel	Boeing
65B40647-25	Control Panel	Boeing
65B40647-26	Control Panel	Boeing
65B40647-30	Control Panel	Boeing
65B40647-31	Control Panel	Boeing
65B40647-32	Control Panel	Boeing
65B40647-33	Control Panel	Boeing
65B40647-34	Control Panel	Boeing
65B40647-35	Control Panel	Boeing
65B40647-36	Control Panel	Boeing
65B40647-40	Control Panel	Boeing
65B40647-45	Control Panel	Boeing
65B40647-46	Control Panel	Boeing
65B40647-47	Control Panel	Boeing
65B40647-48	Control Panel	Boeing
65B40647-50	Control Panel	Boeing
65B40647-51	Control Panel	Boeing
65B40647-53	Control Panel	Boeing
65B40647-54	Control Panel	Boeing
65B40647-55	Control Panel	Boeing
65B40647-56	Control Panel	Boeing
65B40647-56 Mod A	Control Panel	Boeing
65B40650-11	Control Panel	Boeing
65B40650-12	Control Panel	Boeing
65B40650-15	Control Panel	Boeing
65B40650-17	Control Panel	Boeing
65B40650-18	Control Panel	Boeing
65B40650-19	Control Panel	Boeing
65B40650-23	Control Panel	Boeing
65B40650-24	Control Panel	Boeing
65B40650-25	Control Panel	Boeing
65B40650-26	Control Panel	Boeing
65B40650-30	Control Panel	Boeing
65B40650-31	Control Panel	Boeing
65B40650-35	Control Panel	Boeing

Repair_Capability_List_Excel

65B40650-37	Control Panel	Boeing
65B40650-38	Control Panel	Boeing
65B40661-10	Control Panel	Boeing
65B40661-14	Control Panel	Boeing
65B40661-15	Control Panel	Boeing
65B40661-16	Control Panel	Boeing
65B40661-19	Control Panel	Boeing
65B40661-20	Control Panel	Boeing
65B40661-21	Control Panel	Boeing
65B40661-22	Control Panel	Boeing
65B40661-9	Control Panel	Boeing
65B40665-15	Control Panel	Boeing
65B40665-18	Control Panel	Boeing
65B40665-21	Control Panel	Boeing
65B40665-27	Control Panel	Boeing
65B40665-30	Control Panel	Boeing
65B40666-11	Control Panel	Boeing
65B40666-14	Control Panel	Boeing
65B40666-17	Control Panel	Boeing
65B40666-5	Control Panel	Boeing
65B40666-8	Control Panel	Boeing
65B42434-1	Control Panel	Boeing
65B42434-2	Control Panel	Boeing
65B43704-1	Filter assy	Boeing
65B46055-21	Accessory Box	Boeing
65B46133-4	Module Annunciator	Boeing
65B47511-104	Accessory Box	Boeing
65B47511-106	Accessory Box	Boeing
65B47511-108	Accessory Box	Boeing
65B47511-110	Accessory Box	Boeing
65B47511-112	Accessory Box	Boeing
65B47511-113	Accessory Box	Boeing
65B47511-115	Accessory Box	Boeing
65B47511-117	Accessory Box	Boeing
65B47511-119	Accessory Box	Boeing
65B47511-121	Accessory Box	Boeing
65B47511-123	Accessory Box	Boeing
65B47511-125	Accessory Box	Boeing
65B47511-127	Accessory Box	Boeing
65B47511-129	Accessory Box	Boeing
65B47511-131	Accessory Box	Boeing
65B47511-133	Accessory Box	Boeing
65B47511-135	Accessory Box	Boeing
65B47511-147	Accessory Box	Boeing
65B47511-152	Accessory Box	Boeing
65B47511-154	Accessory Box	Boeing
65B47511-156	Accessory Box	Boeing
65B47511-158	Accessory Box	Boeing
65B47511-162	Accessory Box	Boeing
65B47511-166	Accessory Box	Boeing
65B47511-168	Accessory Box	Boeing
65B47511-170	Accessory Box	Boeing
65B47511-171	Accessory Box	Boeing
65B47511-28	Accessory Box	Boeing
65B47511-30	Accessory Box	Boeing
65B47511-32	Accessory Box	Boeing
65B47511-34	Accessory Box	Boeing
65B47511-36	Accessory Box	Boeing

Repair_Capability_List_Excel

65B47511-38	Accessory Box	Boeing
65B47511-40	Accessory Box	Boeing
65B47511-42	Accessory Box	Boeing
65B47511-45	Accessory Box	Boeing
65B47511-47	Accessory Box	Boeing
65B47511-51	Accessory Box	Boeing
65B47511-53	Accessory Box	Boeing
65B47511-55	Accessory Box	Boeing
65B47511-57	Accessory Box	Boeing
65B47511-59	Accessory Box	Boeing
65B47511-61	Accessory Box	Boeing
65B47511-65	Accessory Box	Boeing
65B47511-67	Accessory Box	Boeing
65B47511-69	Accessory Box	Boeing
65B47511-71	Accessory Box	Boeing
65B47511-73	Accessory Box	Boeing
65B47514-1	Accessory Box	Boeing
65B47514-26	Accessory Box	Boeing
65B47514-28	Accessory Box	Boeing
65B47514-32	Accessory Box	Boeing
65B47514-34	Accessory Box	Boeing
65B47514-36	Accessory Box	Boeing
65B47514-40	Accessory Box	Boeing
65B47514-42	Accessory Box	Boeing
65B47514-46	Accessory Box	Boeing
65B47514-50	Accessory Box	Boeing
65B47514-57	Accessory Box	Boeing
65B47514-63	Accessory Box	Boeing
65B47514-67	Accessory Box	Boeing
65B47514-69	Accessory Box	Boeing
65B47514-71	Accessory Box	Boeing
65B47514-73	Accessory Box	Boeing
65B47514-75	Accessory Box	Boeing
65B47514-77	Accessory Box	Boeing
65B47514-79	Accessory Box	Boeing
65B47514-83	Accessory Box	Boeing
65B47514-85	Accessory Box	Boeing
65B47514-87	Accessory Box	Boeing
65B47514-89	Accessory Box	Boeing
65B47514-91	Accessory Box	Boeing
65B47519-11	Trim Stabilizer	Boeing
65B47519-9	Trim Stabilizer	Boeing
65B47522-14	Control Box	Boeing
65B47522-17	Control Box	Boeing
65B47522-18	Control Box	Boeing
65B47522-22	Control Box	Boeing
65B47522-24	Control Box	Boeing
65B47522-26	Control Box	Boeing
65B47522-28	Control Box	Boeing
65B47522-30	Control Box	Boeing
65B47522-32	Control Box	Boeing
65B47522-34	Control Box	Boeing
65B47522-36	Control Box	Boeing
65B47522-37	Control Box	Boeing
65B47522-39	Control Box	Boeing
65B47523-12	Accessory Box	Boeing
65B47523-14	Accessory Box	Boeing
65B47523-16	Accessory Box	Boeing

Repair_Capability_List_Excel

65B47523-18	Accessory Box	Boeing
65B47523-19	Accessory Box	Boeing
65B47538-1	Relay assy	Boeing
65B47564-1	Control assy	Boeing
65B47564-3	Control assy	Boeing
65B47564-5	Control assy	Boeing
65B47564-7	Control assy	Boeing
65B47566-1	Control Panel	Boeing
65B47566-10	Control assy	Boeing
65B47566-6	Control assy	Boeing
65B47571-4	Trim Interface	Boeing
65B47573-100	Accessory Box	Boeing
65B47573-101	Accessory Box	Boeing
65B47573-102	Accessory Box	Boeing
65B47573-103	Accessory Box	Boeing
65B47573-104	Accessory Box	Boeing
65B47573-105	Accessory Box	Boeing
65B47573-11	Accessory Box	Boeing
65B47573-113	Accessory Box	Boeing
65B47573-12	Accessory Box	Boeing
65B47573-14	Accessory Box	Boeing
65B47573-16	Accessory Box	Boeing
65B47573-17	Accessory Box	Boeing
65B47573-19	Accessory Box	Boeing
65B47573-21	Accessory Box	Boeing
65B47573-23	Accessory Box	Boeing
65B47573-25	Accessory Box	Boeing
65B47573-27	Accessory Box	Boeing
65B47573-29	Accessory Box	Boeing
65B47573-31	Accessory Box	Boeing
65B47573-33	Accessory Box	Boeing
65B47573-35	Accessory Box	Boeing
65B47573-37	Accessory Box	Boeing
65B47573-39	Accessory Box	Boeing
65B47573-41	Accessory Box	Boeing
65B47573-43	Accessory Box	Boeing
65B47573-45	Accessory Box	Boeing
65B47573-47	Accessory Box	Boeing
65B47573-49	Accessory Box	Boeing
65B47573-51	Accessory Box	Boeing
65B47573-53	Accessory Box	Boeing
65B47573-55	Accessory Box	Boeing
65B47573-57	Accessory Box	Boeing
65B47573-59	Accessory Box	Boeing
65B47573-61	Accessory Box	Boeing
65B47573-63	Accessory Box	Boeing
65B47573-7	Accessory Box	Boeing
65B47573-83	Accessory Box	Boeing
65B47573-84	Accessory Box	Boeing
65B47573-85	Accessory Box	Boeing
65B47573-86	Accessory Box	Boeing
65B47573-87	Accessory Box	Boeing
65B47573-88	Accessory Box	Boeing
65B47573-99	Accessory Box	Boeing
65B47577-102	Accessory Box	Boeing
65B47577-103	Accessory Box	Boeing
65B47577-107	Accessory Box	Boeing
65B47577-11	Accessory Box	Boeing

Repair_Capability_List_Excel

65B47577-110	Accessory Box	Boeing
65B47577-114	Accessory Box	Boeing
65B47577-116	Accessory Box	Boeing
65B47577-120	Accessory Box	Boeing
65B47577-123	Accessory Box	Boeing
65B47577-126	Accessory Box	Boeing
65B47577-129	Accessory Box	Boeing
65B47577-134	Accessory Box	Boeing
65B47577-135	Accessory Box	Boeing
65B47577-136	Accessory Box	Boeing
65B47577-14	Accessory Box	Boeing
65B47577-144	Accessory Box	Boeing
65B47577-147	Accessory Box	Boeing
65B47577-150	Accessory Box	Boeing
65B47577-154	Accessory Box	Boeing
65B47577-17	Accessory Box	Boeing
65B47577-20	Accessory Box	Boeing
65B47577-22	Accessory Box	Boeing
65B47577-25	Accessory Box	Boeing
65B47577-28	Accessory Box	Boeing
65B47577-30	Accessory Box	Boeing
65B47577-33	Accessory Box	Boeing
65B47577-35	Accessory Box	Boeing
65B47577-42	Accessory Box	Boeing
65B47577-45	Accessory Box	Boeing
65B47577-47	Accessory Box	Boeing
65B47577-49	Accessory Box	Boeing
65B47577-55	Accessory Box	Boeing
65B47577-58	Accessory Box	Boeing
65B47577-62	Accessory Box	Boeing
65B47577-66	Accessory Box	Boeing
65B47577-68	Accessory Box	Boeing
65B47577-71	Accessory Box	Boeing
65B47577-74	Accessory Box	Boeing
65B47577-76	Accessory Box	Boeing
65B47577-78	Accessory Box	Boeing
65B47577-8	Accessory Box	Boeing
65B47577-82	Accessory Box	Boeing
65B47577-85	Accessory Box	Boeing
65B47577-89	Accessory Box	Boeing
65B47577-92	Accessory Box	Boeing
65B47577-96	Accessory Box	Boeing
65B47577-99	Accessory Box	Boeing
65B47582-6	Device assy	Boeing
65B47582-8	Device assy	Boeing
65B47583-5	Device assy	Boeing
65B47591-1	Control assy	Boeing
65B47603-5	Control assy	Boeing
65B47603-6	Control assy	Boeing
65B47626-1	Accessory Box	Boeing
65B47626-6	Accessory Box	Boeing
65B47627-11	Control assy	Boeing
65B47627-13	Control assy	Boeing
65B47627-15	Control assy	Boeing
65B47627-23	Control assy	Boeing
65B47627-28	Control assy	Boeing
65B47627-30	Control assy	Boeing
65B47627-32	Control assy	Boeing

Repair_Capability_List_Excel

65B47627-34	Control assy	Boeing
65B47627-37	Control assy	Boeing
65B47627-39	Control assy	Boeing
65B47627-43	Control assy	Boeing
65B47636-1	Accessory Box	Boeing
65B47636-3	Accessory Box	Boeing
65B47664-3	Autothrottle Adapter	Boeing
65B47664-9	Autothrottle Adapter	Boeing
65B47666-1	Interphone assy	Boeing
65B47674-1	Accessory Box	Boeing
65B47674-3	Accessory Box	Boeing
65B47676-11	Controller	Boeing
65B47676-3	Controller	Boeing
65B47676-5	Controller	Boeing
65B47676-7	Controller	Boeing
65B47694-1	Projector Switch	Boeing
65B47694-3	Projector Switch	Boeing
65B47694-5	Projector Switch	Boeing
65B47694-7	Projector Switch	Boeing
65B56140-15	Cover	Boeing
65B60024-1	Retractable Guide ay	Goodrich
65B60024-3	Retractable Guide ay	Goodrich
65B60027-1	Cargo Retractable Restraint ay	Goodrich
65B60034-1	Linear Actuator ay	Goodrich
65B60034-10	Linear Actuator ay	Goodrich
65B60034-11	Linear Actuator ay	Goodrich
65B60034-12	Linear Actuator ay	Goodrich
65B60034-13	Linear Actuator ay	Goodrich
65B60034-14	Linear Actuator ay	Goodrich
65B60034-15	Linear Actuator ay	Goodrich
65B60034-16	Linear Actuator ay	Goodrich
65B60034-17	Linear Actuator ay	Goodrich
65B60034-18	Linear Actuator ay	Goodrich
65B60034-19	Linear Actuator ay	Goodrich
65B60034-2	Linear Actuator ay	Goodrich
65B60034-20	Linear Actuator ay	Goodrich
65B60034-21	Linear Actuator ay	Goodrich
65B60034-22	Linear Actuator ay	Goodrich
65B60034-23	Linear Actuator ay	Goodrich
65B60034-24	Linear Actuator ay	Goodrich
65B60034-25	Linear Actuator ay	Goodrich
65B60034-3	Linear Actuator ay	Goodrich
65B60034-4	Linear Actuator ay	Goodrich
65B60034-5	Linear Actuator ay	Goodrich
65B60034-9	Linear Actuator ay	Goodrich
65B60036-14	Cargo Retractable Restraint ay	Goodrich
65B60036-15	Cargo Retractable Restraint ay	Goodrich
65B60036-16	Cargo Retractable Restraint ay	Goodrich
65B60036-17	Cargo Retractable Restraint ay	Goodrich
65B60044-1	Gearbox assy	Boeing
65B60048-1	Torque Tube ay	Goodrich
65B60048-14	Torque Tube ay	Goodrich
65B60048-2	Torque Tube ay	Goodrich
65B60048-3	Torque Tube ay	Goodrich
65B60048-4	Torque Tube ay	Goodrich
65B60048-5	Torque Tube ay	Goodrich
65B60049-5	Retractable Restraint ay	Goodrich
65B60049-7	Retractable Restraint ay	Goodrich

Repair_Capability_List_Excel

65B60104-1	Guide ay	Goodrich
65B60109-1	Stop ay	Goodrich
65B60109-2	Stop ay	Goodrich
65B60123-18	Drive Shaft ay	Goodrich
65B60123-7	Drive Shaft ay	Goodrich
65B60124-117	Fixed Wheel Drive ay	Goodrich
65B60124-42	Fixed Wheel Drive ay	Goodrich
65B60124-61	Fixed Wheel Drive ay	Goodrich
65B60124-7	Fixed Wheel Drive ay	Goodrich
65B60125-12	Drive Shaft ay	Goodrich
65B60125-5	Drive Shaft ay	Goodrich
65B60125-6	Drive Shaft ay	Goodrich
65B60125-7	Drive Shaft ay	Goodrich
65B60125-8	Drive Shaft ay	Goodrich
65B60125-9	Drive Shaft ay	Goodrich
65B60126-10	Drive Shaft ay	Goodrich
65B60126-2	Drive Shaft ay	Goodrich
65B60126-4	Drive Shaft ay	Goodrich
65B60126-5	Drive Shaft ay	Goodrich
65B60126-6	Drive Shaft ay	Goodrich
65B60126-9	Drive Shaft ay	Goodrich
65B60127-10	Retractable Wheel Drive ay	Goodrich
65B60127-12	Retractable Wheel Drive ay	Goodrich
65B60127-13	Retractable Wheel Drive ay	Goodrich
65B60127-14	Retractable Wheel Drive ay	Goodrich
65B60127-15	Retractable Wheel Drive ay	Goodrich
65B60127-16	Retractable Wheel Drive ay	Goodrich
65B60127-19	Retractable Wheel Drive ay	Goodrich
65B60127-2	Retractable Wheel Drive ay	Goodrich
65B60127-20	Retractable Wheel Drive ay	Goodrich
65B60127-21	Retractable Wheel Drive ay	Goodrich
65B60127-22	Retractable Wheel Drive ay	Goodrich
65B60127-24	Retractable Wheel Drive ay	Goodrich
65B60127-25	Retractable Wheel Drive ay	Goodrich
65B60127-26	Retractable Wheel Drive ay	Goodrich
65B60127-27	Retractable Wheel Drive ay	Goodrich
65B60127-28	Retractable Wheel Drive ay	Goodrich
65B60127-29	Retractable Wheel Drive ay	Goodrich
65B60127-30	Retractable Wheel Drive ay	Goodrich
65B60127-32	Retractable Wheel Drive ay	Goodrich
65B60127-33	Retractable Wheel Drive ay	Goodrich
65B60127-34	Retractable Wheel Drive ay	Goodrich
65B60127-35	Retractable Wheel Drive ay	Goodrich
65B60127-36	Retractable Wheel Drive ay	Goodrich
65B60127-39	Retractable Wheel Drive ay	Goodrich
65B60127-40	Retractable Wheel Drive ay	Goodrich
65B60127-41	Retractable Wheel Drive ay	Goodrich
65B60127-42	Retractable Wheel Drive ay	Goodrich
65B60127-43	Retractable Wheel Drive ay	Goodrich
65B60127-5	Retractable Wheel Drive ay	Goodrich
65B60127-6	Retractable Wheel Drive ay	Goodrich
65B60127-7	Retractable Wheel Drive ay	Goodrich
65B60127-8	Retractable Wheel Drive ay	Goodrich
65B60127-9	Retractable Wheel Drive ay	Goodrich
65B60128-10	Retractable Wheel Drive ay	Goodrich
65B60128-11	Retractable Wheel Drive ay	Goodrich
65B60128-12	Retractable Wheel Drive ay	Goodrich
65B60128-13	Retractable Wheel Drive ay	Goodrich

Repair_Capability_List_Excel

65B60128-18	Retractable Wheel Drive ay	Goodrich
65B60128-2	Retractable Wheel Drive ay	Goodrich
65B60128-21	Retractable Wheel Drive ay	Goodrich
65B60128-22	Retractable Wheel Drive ay	Goodrich
65B60128-23	Retractable Wheel Drive ay	Goodrich
65B60128-24	Retractable Wheel Drive ay	Goodrich
65B60128-25	Retractable Wheel Drive ay	Goodrich
65B60128-29	Retractable Wheel Drive ay	Goodrich
65B60128-3	Retractable Wheel Drive ay	Goodrich
65B60128-30	Retractable Wheel Drive ay	Goodrich
65B60128-31	Retractable Wheel Drive ay	Goodrich
65B60128-32	Retractable Wheel Drive ay	Goodrich
65B60128-33	Retractable Wheel Drive ay	Goodrich
65B60128-35	Retractable Wheel Drive ay	Goodrich
65B60128-36	Retractable Wheel Drive ay	Goodrich
65B60128-4	Retractable Wheel Drive ay	Goodrich
65B60128-5	Retractable Wheel Drive ay	Goodrich
65B60162-1	Cargo Track Ball Unit ay	Goodrich
65B60162-2	Cargo Track Ball Unit ay	Goodrich
65B60162-3	Cargo Track Ball Unit ay	Goodrich
65B60162-4	Cargo Track Ball Unit ay	Goodrich
65B60162-5	Cargo Track Ball Unit ay	Goodrich
65B60176-1	Roller Tray ay	Goodrich
65B60176-10	Roller Tray ay	Goodrich
65B60176-100	Roller Tray ay	Goodrich
65B60176-101	Roller Tray ay	Goodrich
65B60176-11	Roller Tray ay	Goodrich
65B60176-12	Roller Tray ay	Goodrich
65B60176-13	Roller Tray ay	Goodrich
65B60176-14	Roller Tray ay	Goodrich
65B60176-15	Roller Tray ay	Goodrich
65B60176-16	Roller Tray ay	Goodrich
65B60176-17	Roller Tray ay	Goodrich
65B60176-18	Roller Tray ay	Goodrich
65B60176-19	Roller Tray ay	Goodrich
65B60176-2	Roller Tray ay	Goodrich
65B60176-20	Roller Tray ay	Goodrich
65B60176-21	Roller Tray ay	Goodrich
65B60176-22	Roller Tray ay	Goodrich
65B60176-23	Roller Tray ay	Goodrich
65B60176-24	Roller Tray ay	Goodrich
65B60176-25	Roller Tray ay	Goodrich
65B60176-26	Roller Tray ay	Goodrich
65B60176-27	Roller Tray ay	Goodrich
65B60176-29	Roller Tray ay	Goodrich
65B60176-3	Roller Tray ay	Goodrich
65B60176-30	Roller Tray ay	Goodrich
65B60176-31	Roller Tray ay	Goodrich
65B60176-32	Roller Tray ay	Goodrich
65B60176-37	Roller Tray ay	Goodrich
65B60176-39	Roller Tray ay	Goodrich
65B60176-4	Roller Tray ay	Goodrich
65B60176-42	Roller Tray ay	Goodrich
65B60176-43	Roller Tray ay	Goodrich
65B60176-44	Roller Tray ay	Goodrich
65B60176-45	Roller Tray ay	Goodrich
65B60176-46	Roller Tray ay	Goodrich
65B60176-47	Roller Tray ay	Goodrich

Repair_Capability_List_Excel

65B60176-48	Roller Tray ay	Goodrich
65B60176-49	Roller Tray ay	Goodrich
65B60176-5	Roller Tray ay	Goodrich
65B60176-50	Roller Tray ay	Goodrich
65B60176-55	Roller Tray ay	Goodrich
65B60176-56	Roller Tray ay	Goodrich
65B60176-57	Roller Tray ay	Goodrich
65B60176-58	Roller Tray ay	Goodrich
65B60176-59	Roller Tray ay	Goodrich
65B60176-6	Roller Tray ay	Goodrich
65B60176-62	Roller Tray ay	Goodrich
65B60176-63	Roller Tray ay	Goodrich
65B60176-64	Roller Tray ay	Goodrich
65B60176-65	Roller Tray ay	Goodrich
65B60176-66	Roller Tray ay	Goodrich
65B60176-67	Roller Tray ay	Goodrich
65B60176-68	Roller Tray ay	Goodrich
65B60176-69	Roller Tray ay	Goodrich
65B60176-7	Roller Tray ay	Goodrich
65B60176-70	Roller Tray ay	Goodrich
65B60176-71	Roller Tray ay	Goodrich
65B60176-72	Roller Tray ay	Goodrich
65B60176-73	Roller Tray ay	Goodrich
65B60176-75	Roller Tray ay	Goodrich
65B60176-76	Roller Tray ay	Goodrich
65B60176-77	Roller Tray ay	Goodrich
65B60176-78	Roller Tray ay	Goodrich
65B60176-8	Roller Tray ay	Goodrich
65B60176-80	Roller Tray ay	Goodrich
65B60176-81	Roller Tray ay	Goodrich
65B60176-82	Roller Tray ay	Goodrich
65B60176-83	Roller Tray ay	Goodrich
65B60176-84	Roller Tray ay	Goodrich
65B60176-85	Roller Tray ay	Goodrich
65B60176-86	Roller Tray ay	Goodrich
65B60176-87	Roller Tray ay	Goodrich
65B60176-88	Roller Tray ay	Goodrich
65B60176-89	Roller Tray ay	Goodrich
65B60176-9	Roller Tray ay	Goodrich
65B60176-90	Roller Tray ay	Goodrich
65B60176-91	Roller Tray ay	Goodrich
65B60176-92	Roller Tray ay	Goodrich
65B60176-93	Roller Tray ay	Goodrich
65B60176-94	Roller Tray ay	Goodrich
65B60176-95	Roller Tray ay	Goodrich
65B60176-96	Roller Tray ay	Goodrich
65B60176-97	Roller Tray ay	Goodrich
65B60176-98	Roller Tray ay	Goodrich
65B60176-99	Roller Tray ay	Goodrich
65B60200-5	Splitter rail ay	Goodrich
65B60200-6	Splitter rail ay	Goodrich
65B60291-1	Roller Side Guide ay	Goodrich
65B60291-2	Roller Side Guide ay	Goodrich
65B60291-3	Roller Side Guide ay	Goodrich
65B60291-4	Roller Side Guide ay	Goodrich
65B60291-5	Roller Side Guide ay	Goodrich
65B60291-6	Roller Side Guide ay	Goodrich
65B60380-1	Cargo Track Ball Unit ay	Goodrich

Repair_Capability_List_Excel

65B60400-1	Single Pallet Lock ay	Goodrich
65B60401-1	Double Pallet Lock ay	Goodrich
65B60402-1	Retractable Container Stop ay	Goodrich
65B60402-3	Retractable Container Stop ay	Goodrich
65B60402-4	Retractable Container Stop ay	Goodrich
65B60427-1	Retractable Vertical Guide ay	Goodrich
65B60427-10	Retractable Vertical Guide ay	Goodrich
65B60427-11	Retractable Vertical Guide ay	Goodrich
65B60427-13	Retractable Vertical Guide ay	Goodrich
65B60427-14	Retractable Vertical Guide ay	Goodrich
65B60427-15	Retractable Vertical Guide ay	Goodrich
65B60427-2	Retractable Vertical Guide ay	Goodrich
65B60427-3	Retractable Vertical Guide ay	Goodrich
65B60427-4	Retractable Vertical Guide ay	Goodrich
65B60427-5	Retractable Vertical Guide ay	Goodrich
65B60427-6	Retractable Vertical Guide ay	Goodrich
65B60427-7	Retractable Vertical Guide ay	Goodrich
65B60427-8	Retractable Vertical Guide ay	Goodrich
65B60427-9	Retractable Vertical Guide ay	Goodrich
65B60428-1	Vertical Guide ay	Goodrich
65B60428-2	Vertical Guide ay	Goodrich
65B60428-3	Vertical Guide ay	Goodrich
65B60428-4	Vertical Guide ay	Goodrich
65B60428-5	Vertical Guide ay	Goodrich
65B60428-6	Vertical Guide ay	Goodrich
65B60428-7	Vertical Guide ay	Goodrich
65B60428-8	Vertical Guide ay	Goodrich
65B60436-3	Retractable Restraint ay	Goodrich
65B60444-7	Cargo Retractable Restraint ay	Goodrich
65B60444-8	Cargo Retractable Restraint ay	Goodrich
65B60473-10	Knockdown Guide ay	Goodrich
65B60473-11	Knockdown Guide ay	Goodrich
65B60473-12	Knockdown Guide ay	Goodrich
65B60473-13	Knockdown Guide ay	Goodrich
65B60473-14	Knockdown Guide ay	Goodrich
65B60473-15	Knockdown Guide ay	Goodrich
65B60473-2	Knockdown Guide ay	Goodrich
65B60473-3	Knockdown Guide ay	Goodrich
65B60473-4	Knockdown Guide ay	Goodrich
65B60473-5	Knockdown Guide ay	Goodrich
65B60473-6	Knockdown Guide ay	Goodrich
65B60473-7	Knockdown Guide ay	Goodrich
65B60473-8	Knockdown Guide ay	Goodrich
65B60473-9	Knockdown Guide ay	Goodrich
65B60490-1	Retractable Guide ay	Goodrich
65B60537-1	Cargo Track Ball Unit ay	Goodrich
65B60537-2	Cargo Track Ball Unit ay	Goodrich
65B60537-5	Cargo Track Ball Unit ay	Goodrich
65B60537-6	Cargo Track Ball Unit ay	Goodrich
65B60538-1	Cargo Track Ball Unit ay	Goodrich
65B60538-2	Cargo Track Ball Unit ay	Goodrich
65B60539-1	Cargo Track Ball Unit ay	Goodrich
65B60540-1	Cargo Track Ball Unit ay	Goodrich
65B60642-1	Retractable Stop ay	Goodrich
65B60649-1	Retractable Stop ay	Goodrich
65B60653-1	Retractable Restraint ay	Goodrich
65B60653-2	Retractable Restraint ay	Goodrich
65B60661-1	Retractable Guide ay	Goodrich

Repair_Capability_List_Excel

65B60671-1	Guide ay	Goodrich
65B60671-2	Guide ay	Goodrich
65B60696-1	Retractable Guide ay	Goodrich
65B60696-2	Retractable Guide ay	Goodrich
65B60696-3	Retractable Guide ay	Goodrich
65B60696-4	Retractable Guide ay	Goodrich
65B60696-5	Retractable Guide ay	Goodrich
65B60696-6	Retractable Guide ay	Goodrich
65B60730-1	Stop ay	Goodrich
65B60760-1	Threshold Conveyo ay	Goodrich
65B60900-10	Semi-Automatic Restraint ay	Goodrich
65B60900-11	Semi-Automatic Restraint ay	Goodrich
65B60900-4	Semi-Automatic Restraint ay	Goodrich
65B60900-5	Semi-Automatic Restraint ay	Goodrich
65B60900-6	Semi-Automatic Restraint ay	Goodrich
65B60900-7	Semi-Automatic Restraint ay	Goodrich
65B60900-8	Semi-Automatic Restraint ay	Goodrich
65B60900-9	Semi-Automatic Restraint ay	Goodrich
65B60983-1	Roller Tray ay	Goodrich
65B60983-10	Roller Tray ay	Goodrich
65B60983-11	Roller Tray ay	Goodrich
65B60983-12	Roller Tray ay	Goodrich
65B60983-13	Roller Tray ay	Goodrich
65B60983-14	Roller Tray ay	Goodrich
65B60983-15	Roller Tray ay	Goodrich
65B60983-16	Roller Tray ay	Goodrich
65B60983-18	Roller Tray ay	Goodrich
65B60983-19	Roller Tray ay	Goodrich
65B60983-2	Roller Tray ay	Goodrich
65B60983-20	Roller Tray ay	Goodrich
65B60983-21	Roller Tray ay	Goodrich
65B60983-22	Roller Tray ay	Goodrich
65B60983-25	Roller Tray ay	Goodrich
65B60983-26	Roller Tray ay	Goodrich
65B60983-27	Roller Tray ay	Goodrich
65B60983-28	Roller Tray ay	Goodrich
65B60983-6	Roller Tray ay	Goodrich
65B60983-9	Roller Tray ay	Goodrich
65B61003-11	Drive Shaft ay	Goodrich
65B61003-12	Drive Shaft ay	Goodrich
65B61003-13	Drive Shaft ay	Goodrich
65B61004-11	Fixed Wheel Drive ay	Goodrich
65B61004-12	Fixed Wheel Drive ay	Goodrich
65B61004-13	Fixed Wheel Drive ay	Goodrich
65B61004-14	Fixed Wheel Drive ay	Goodrich
65B61004-15	Fixed Wheel Drive ay	Goodrich
65B61004-16	Fixed Wheel Drive ay	Goodrich
65B61004-18	Fixed Wheel Drive ay	Goodrich
65B61070-1	Roller Tray ay	Goodrich
65B61070-2	Roller Tray ay	Goodrich
65B61070-3	Roller Tray ay	Goodrich
65B61070-4	Roller Tray ay	Goodrich
65B61070-5	Roller Tray ay	Goodrich
65B61070-6	Roller Tray ay	Goodrich
65B61072-1	Roller Tray ay	Goodrich
65B61072-3	Roller Tray ay	Goodrich
65B61072-6	Roller Tray ay	Goodrich
65B61072-8	Roller Tray ay	Goodrich

Repair_Capability_List_Excel

65B61074-1	Roller Tray ay	Goodrich
65B61074-2	Roller Tray ay	Goodrich
65B61074-3	Roller Tray ay	Goodrich
65B61074-4	Roller Tray ay	Goodrich
65B61074-5	Roller Tray ay	Goodrich
65B61130-1	Retractable Guide ay	Goodrich
65B61130-11	Retractable Guide ay	Goodrich
65B61130-3	Retractable Guide ay	Goodrich
65B61130-5	Retractable Guide ay	Goodrich
65B61130-7	Retractable Guide ay	Goodrich
65B61130-9	Retractable Guide ay	Goodrich
65B61131-1	Semi-Automatic Restraint ay	Goodrich
65B61131-2	Semi-Automatic Restraint ay	Goodrich
65B61131-3	Semi-Automatic Restraint ay	Goodrich
65B61131-4	Semi-Automatic Restraint ay	Goodrich
65B61131-5	Semi-Automatic Restraint ay	Goodrich
65B61131-6	Semi-Automatic Restraint ay	Goodrich
65B61141-1	Retractable Guide ay	Goodrich
65B61141-2	Retractable Guide ay	Goodrich
65B61141-3	Retractable Guide ay	Goodrich
65B61141-4	Retractable Guide ay	Goodrich
65B61141-5	Retractable Guide ay	Goodrich
65B61141-6	Retractable Guide ay	Goodrich
65B61143-5	Guide ay	Goodrich
65B61143-6	Guide ay	Goodrich
65B61143-7	Guide ay	Goodrich
65B61262-1	Double Pallet Lock ay	Goodrich
65B61262-3	Double Pallet Lock ay	Goodrich
65B61262-4	Double Pallet Lock ay	Goodrich
65B61262-5	Double Pallet Lock ay	Goodrich
65B61262-6	Double Pallet Lock ay	Goodrich
65B61262-7	Double Pallet Lock ay	Goodrich
65B61263-1	Single Pallet Lock ay	Goodrich
65B61263-2	Single Pallet Lock ay	Goodrich
65B61263-3	Single Pallet Lock ay	Goodrich
65B62006-1	Steerable PDU Switch ay	Goodrich
65B62006-11	Steerable PDU Switch ay	Goodrich
65B62006-12	Steerable PDU Switch ay	Goodrich
65B62006-13	Steerable PDU Switch ay	Goodrich
65B62006-14	Steerable PDU Switch ay	Goodrich
65B62006-15	Steerable PDU Switch ay	Goodrich
65B62006-16	Steerable PDU Switch ay	Goodrich
65B62006-17	Steerable PDU Switch ay	Goodrich
65B62006-18	Steerable PDU Switch ay	Goodrich
65B62006-2	Steerable PDU Switch ay	Goodrich
65B62006-3	Steerable PDU Switch ay	Goodrich
65B62006-4	Steerable PDU Switch ay	Goodrich
65B62006-5	Steerable PDU Switch ay	Goodrich
65B62006-6	Steerable PDU Switch ay	Goodrich
65B62006-7	Steerable PDU Switch ay	Goodrich
65B62006-8	Steerable PDU Switch ay	Goodrich
65B62106-10	Steerable Power Drive Unit ay	Goodrich
65B62106-11	Power Drive Unit ay	Goodrich
65B62106-12	Steerable Power Drive Unit ay	Goodrich
65B62106-13	Power Drive Unit ay	Goodrich
65B62106-14	Steerable Power Drive Unit ay	Goodrich
65B62106-16	Steerable Power Drive Unit ay	Goodrich
65B62106-17	Power Drive Unit ay	Goodrich

Repair_Capability_List_Excel

65B62106-5	Power Drive Unit ay	Goodrich
65B62106-6	Steerable Power Drive Unit ay	Goodrich
65B62106-7	Power Drive Unit ay	Goodrich
65B62106-8	Steerable Power Drive Unit ay	Goodrich
65B62106-9	Power Drive Unit ay	Goodrich
65B62185-1	Caster Support ay	Goodrich
65B62191-10	Caster Tray ay	Goodrich
65B62191-11	Caster Tray ay	Goodrich
65B62191-12	Caster Tray ay	Goodrich
65B62191-13	Caster Tray ay	Goodrich
65B62191-14	Caster Tray ay	Goodrich
65B62191-15	Caster Tray ay	Goodrich
65B62191-16	Caster Tray ay	Goodrich
65B62191-17	Caster Tray ay	Goodrich
65B62191-18	Caster Tray ay	Goodrich
65B62191-19	Caster Tray ay	Goodrich
65B62191-2	Caster Tray ay	Goodrich
65B62191-20	Caster Tray ay	Goodrich
65B62191-21	Caster Tray ay	Goodrich
65B62191-3	Caster Tray ay	Goodrich
65B62191-4	Caster Tray ay	Goodrich
65B62191-5	Caster Tray ay	Goodrich
65B62191-6	Caster Tray ay	Goodrich
65B62191-7	Caster Tray ay	Goodrich
65B62191-8	Caster Tray ay	Goodrich
65B62191-9	Caster Tray ay	Goodrich
65B62206-1	Retractable Power Drive Unit ay	Goodrich
65B62206-10	Retractable Power Drive Unit ay	Goodrich
65B62206-11	Retractable Power Drive Unit ay	Goodrich
65B62206-12	Retractable Power Drive Unit ay	Goodrich
65B62206-13	Retractable Power Drive Unit ay	Goodrich
65B62206-14	Retractable Power Drive Unit ay	Goodrich
65B62206-9	Retractable Power Drive Unit ay	Goodrich
65B62215-42	Steerable PDU Switch ay	Goodrich
65B62215-43	Steerable PDU Switch ay	Goodrich
65B62215-44	Steerable PDU Switch ay	Goodrich
65B62215-6	Steerable PDU Switch ay	Goodrich
65B63100-3	Guide ay	Goodrich
65B63100-4	Guide ay	Goodrich
65B63101-3	Guide Rail ay	Goodrich
65B63101-4	Guide Rail ay	Goodrich
65B63101-5	Guide Rail ay	Goodrich
65B63101-6	Guide Rail ay	Goodrich
65B63101-7	Guide Rail ay	Goodrich
65B63102-10	Adjustable Guide ay	Goodrich
65B63102-11	Adjustable Guide ay	Goodrich
65B63102-12	Adjustable Guide ay	Goodrich
65B63102-13	Adjustable Guide ay	Goodrich
65B63102-14	Adjustable Guide ay	Goodrich
65B63102-15	Adjustable Guide ay	Goodrich
65B63102-4	Adjustable Guide ay	Goodrich
65B63102-5	Adjustable Guide ay	Goodrich
65B63102-6	Adjustable Guide ay	Goodrich
65B63102-7	Adjustable Guide ay	Goodrich
65B63102-8	Adjustable Guide ay	Goodrich
65B63102-9	Adjustable Guide ay	Goodrich
65B63103-11	Guide and Restraint Rail ay	Goodrich
65B63103-12	Guide and Restraint Rail ay	Goodrich

Repair_Capability_List_Excel

65B63103-19	Guide and Restraint Rail ay	Goodrich
65B63103-2	Guide and Restraint Rail ay	Goodrich
65B63103-24	Guide and Restraint Rail ay	Goodrich
65B63103-25	Guide and Restraint Rail ay	Goodrich
65B63103-3	Guide and Restraint Rail ay	Goodrich
65B63103-501	Guide and Restraint Rail ay	Goodrich
65B63103-7	Guide and Restraint Rail ay	Goodrich
65B63104-10	Restraint and Caster ay	Goodrich
65B63104-11	Restraint and Caster ay	Goodrich
65B63104-16	Restraint and Caster ay	Goodrich
65B63104-17	Restraint and Caster ay	Goodrich
65B63104-18	Restraint and Caster ay	Goodrich
65B63104-19	Restraint and Caster ay	Goodrich
65B63104-2	Restraint and Caster ay	Goodrich
65B63104-20	Restraint and Caster ay	Goodrich
65B63104-21	Restraint and Caster ay	Goodrich
65B63104-22	Restraint and Caster ay	Goodrich
65B63104-23	Restraint and Caster ay	Goodrich
65B63104-24	Restraint and Caster ay	Goodrich
65B63104-25	Restraint and Caster ay	Goodrich
65B63104-26	Restraint and Caster ay	Goodrich
65B63104-27	Restraint and Caster ay	Goodrich
65B63104-28	Restraint and Caster ay	Goodrich
65B63104-29	Restraint and Caster ay	Goodrich
65B63104-3	Restraint and Caster ay	Goodrich
65B63104-30	Restraint and Caster ay	Goodrich
65B63104-31	Restraint and Caster ay	Goodrich
65B63104-32	Restraint and Caster ay	Goodrich
65B63104-33	Restraint and Caster ay	Goodrich
65B63104-34	Restraint and Caster ay	Goodrich
65B63104-35	Restraint and Caster ay	Goodrich
65B63104-36	Restraint and Caster ay	Goodrich
65B63104-37	Restraint and Caster ay	Goodrich
65B63104-38	Restraint and Caster ay	Goodrich
65B63104-39	Restraint and Caster ay	Goodrich
65B63104-4	Restraint and Caster ay	Goodrich
65B63104-40	Restraint and Caster ay	Goodrich
65B63104-41	Restraint and Caster ay	Goodrich
65B63104-42	Restraint and Caster ay	Goodrich
65B63104-43	Restraint and Caster ay	Goodrich
65B63104-44	Restraint and Caster ay	Goodrich
65B63104-45	Restraint and Caster ay	Goodrich
65B63104-46	Restraint and Caster ay	Goodrich
65B63104-47	Restraint and Caster ay	Goodrich
65B63104-48	Restraint and Caster ay	Goodrich
65B63104-49	Restraint and Caster ay	Goodrich
65B63104-5	Restraint and Caster ay	Goodrich
65B63104-50	Restraint and Caster ay	Goodrich
65B63104-501	Restraint ay	Goodrich
65B63104-51	Restraint and Caster ay	Goodrich
65B63104-52	Restraint and Caster ay	Goodrich
65B63104-53	Restraint and Caster ay	Goodrich
65B63104-54	Restraint and Caster ay	Goodrich
65B63104-55	Restraint and Caster ay	Goodrich
65B63104-56	Restraint and Caster ay	Goodrich
65B63104-8	Restraint and Caster ay	Goodrich
65B63104-9	Restraint and Caster ay	Goodrich
65B63150-1	Puller ay	Goodrich

Repair_Capability_List_Excel

65B63150-2	Puller ay	Goodrich
65B63160-1	Rail Support ay	Goodrich
65B63160-2	Rail Support ay	Goodrich
65B63160-3	Rail Support ay	Goodrich
65B63160-4	Rail Support ay	Goodrich
65B63160-5	Rail Support ay	Goodrich
65B63160-6	Rail Support ay	Goodrich
65B63160-7	Rail Support ay	Goodrich
65B63160-8	Rail Support ay	Goodrich
65B63160-9	Rail Support ay	Goodrich
65B63164-10	Guide and Restraint ay	Goodrich
65B63164-11	Guide and Restraint ay	Goodrich
65B63164-12	Guide and Restraint ay	Goodrich
65B63164-13	Guide and Restraint ay	Goodrich
65B63164-14	Guide and Restraint ay	Goodrich
65B63164-15	Guide and Restraint ay	Goodrich
65B63164-16	Guide and Restraint ay	Goodrich
65B63164-17	Guide and Restraint ay	Goodrich
65B63164-18	Guide and Restraint ay	Goodrich
65B63164-19	Guide and Restraint ay	Goodrich
65B63164-3	Guide and Restraint ay	Goodrich
65B63164-4	Guide and Restraint ay	Goodrich
65B63164-5	Guide and Restraint ay	Goodrich
65B63164-6	Guide and Restraint ay	Goodrich
65B63164-7	Guide and Restraint ay	Goodrich
65B63164-8	Guide and Restraint ay	Goodrich
65B63164-9	Guide and Restraint ay	Goodrich
65B63167-2	Guide and Support ay	Goodrich
65B63178-1	Lock Roller ay	Goodrich
65B63178-10	Lock Roller ay	Goodrich
65B63178-11	Lock Roller ay	Goodrich
65B63178-2	Lock Roller ay	Goodrich
65B63178-5	Lock Roller ay	Goodrich
65B63178-6	Lock Roller ay	Goodrich
65B63178-7	Lock Roller ay	Goodrich
65B63178-8	Lock Roller ay	Goodrich
65B63178-9	Lock Roller ay	Goodrich
65B63185-2	Stop ay	Goodrich
65B63186-2	Stop ay	Goodrich
65B63187-2	Stop ay	Goodrich
65B63188-2	Stop ay	Goodrich
65B63192-1	Lock ay	Goodrich
65B63192-2	Lock ay	Goodrich
65B63192-3	Lock ay	Goodrich
65B63192-4	Lock ay	Goodrich
65B63192-5	Lock ay	Goodrich
65B63220-1	Retractable End Stop ay	Goodrich
65B63220-3	Retractable End Stop ay	Goodrich
65B63220-5	Retractable End Stop ay	Goodrich
65B63223-21	Guide Rail ay	Goodrich
65B63223-22	Guide Rail ay	Goodrich
65B63223-23	Guide Rail ay	Goodrich
65B63223-24	Guide Rail ay	Goodrich
65B63223-25	Guide Rail ay	Goodrich
65B63223-26	Guide Rail ay	Goodrich
65B63223-27	Guide Rail ay	Goodrich
65B63223-28	Guide Rail ay	Goodrich
65B63223-29	Guide Rail ay	Goodrich

Repair_Capability_List_Excel

65B63223-30	Guide Rail ay	Goodrich
65B63223-31	Guide Rail ay	Goodrich
65B63223-32	Guide Rail ay	Goodrich
65B63223-34	Guide Rail ay	Goodrich
65B63223-35	Guide Rail ay	Goodrich
65B63223-36	Guide Rail ay	Goodrich
65B63223-37	Guide Rail ay	Goodrich
65B63223-38	Guide Rail ay	Goodrich
65B63223-39	Guide Rail ay	Goodrich
65B63223-40	Guide Rail ay	Goodrich
65B63223-41	Guide Rail ay	Goodrich
65B63223-42	Guide Rail ay	Goodrich
65B63223-43	Guide Rail ay	Goodrich
65B63223-44	Guide Rail ay	Goodrich
65B63223-45	Guide Rail ay	Goodrich
65B63223-46	Guide Rail ay	Goodrich
65B63223-47	Guide Rail ay	Goodrich
65B63223-48	Guide Rail ay	Goodrich
65B63223-50	Guide Rail ay	Goodrich
65B63223-51	Guide Rail ay	Goodrich
65B63223-52	Guide Rail ay	Goodrich
65B63223-53	Guide Rail ay	Goodrich
65B63223-54	Guide Rail ay	Goodrich
65B63223-55	Guide Rail ay	Goodrich
65B63223-56	Guide Rail ay	Goodrich
65B63223-57	Guide Rail ay	Goodrich
65B63223-58	Guide Rail ay	Goodrich
65B63223-59	Guide Rail ay	Goodrich
65B63223-60	Guide Rail ay	Goodrich
65B63223-61	Guide Rail ay	Goodrich
65B63223-62	Guide Rail ay	Goodrich
65B63223-63	Guide Rail ay	Goodrich
65B63223-64	Guide Rail ay	Goodrich
65B63223-65	Guide Rail ay	Goodrich
65B63223-66	Guide Rail ay	Goodrich
65B63223-67	Guide Rail ay	Goodrich
65B63223-68	Guide Rail ay	Goodrich
65B63223-75	Guide Rail ay	Goodrich
65B63223-76	Guide Rail ay	Goodrich
65B63223-77	Guide Rail ay	Goodrich
65B63223-78	Guide Rail ay	Goodrich
65B63223-79	Guide Rail ay	Goodrich
65B63223-80	Guide Rail ay	Goodrich
65B63223-81	Guide Rail ay	Goodrich
65B63223-82	Guide Rail ay	Goodrich
65B63223-83	Guide Rail ay	Goodrich
65B63223-84	Guide Rail ay	Goodrich
65B63223-85	Guide Rail ay	Goodrich
65B63223-86	Guide Rail ay	Goodrich
65B63223-87	Guide Rail ay	Goodrich
65B63223-88	Guide Rail ay	Goodrich
65B63223-89	Guide Rail ay	Goodrich
65B63223-90	Guide Rail ay	Goodrich
65B63223-91	Guide Rail ay	Goodrich
65B63223-92	Guide Rail ay	Goodrich
65B63223-93	Guide Rail ay	Goodrich
65B63223-94	Guide Rail ay	Goodrich
65B63223-95	Guide Rail ay	Goodrich

Repair_Capability_List_Excel

65B63227-1	Directional Guide Panel ay	Goodrich
65B63227-2	Directional Guide Panel ay	Goodrich
65B63227-4	Directional Guide Panel ay	Goodrich
65B63227-5	Directional Guide Panel ay	Goodrich
65B63227-6	Directional Guide Panel ay	Goodrich
65B63227-7	Directional Guide Panel ay	Goodrich
65B63228-1	Guide and Restraint ay	Goodrich
65B63228-2	Guide and Restraint ay	Goodrich
65B63228-5	Guide and Restraint ay	Goodrich
65B63250-1	Stop ay	Goodrich
65B63250-3	Stop ay	Goodrich
65B63250-5	Stop ay	Goodrich
65B63250-6	Stop ay	Goodrich
65B63250-7	Stop ay	Goodrich
65B63258-1	Roller Frame ay	Goodrich
65B63258-2	Roller Frame ay	Goodrich
65B63260-1	Caster Support ay	Goodrich
65B63260-2	Caster Support ay	Goodrich
65B63260-3	Caster Support ay	Goodrich
65B63260-4	Caster Support ay	Goodrich
65B63260-5	Caster Support ay	Goodrich
65B63260-501	Caster Support ay	Goodrich
65B63260-502	Caster Support ay	Goodrich
65B63266-1	Lock Roller ay	Goodrich
65B63266-3	Lock Roller ay	Goodrich
65B63266-4	Lock Roller ay	Goodrich
65B63271-100	Caster Tray ay	Goodrich
65B63271-101	Caster Tray ay	Goodrich
65B63271-102	Caster Tray ay	Goodrich
65B63271-103	Caster Tray ay	Goodrich
65B63271-104	Caster Tray ay	Goodrich
65B63271-105	Caster Tray ay	Goodrich
65B63271-106	Caster Tray ay	Goodrich
65B63271-107	Caster Tray ay	Goodrich
65B63271-108	Caster Tray ay	Goodrich
65B63271-109	Caster Tray ay	Goodrich
65B63271-110	Caster Tray ay	Goodrich
65B63271-111	Caster Tray ay	Goodrich
65B63271-112	Caster Tray ay	Goodrich
65B63271-113	Caster Tray ay	Goodrich
65B63271-114	Caster Tray ay	Goodrich
65B63271-115	Caster Tray ay	Goodrich
65B63271-116	Caster Tray ay	Goodrich
65B63271-117	Caster Tray ay	Goodrich
65B63271-118	Caster Tray ay	Goodrich
65B63271-119	Caster Tray ay	Goodrich
65B63271-120	Caster Tray ay	Goodrich
65B63271-121	Caster Tray ay	Goodrich
65B63271-122	Caster Tray ay	Goodrich
65B63271-123	Caster Tray ay	Goodrich
65B63271-124	Caster Tray ay	Goodrich
65B63271-125	Caster Tray ay	Goodrich
65B63271-126	Caster Tray ay	Goodrich
65B63271-127	Caster Tray ay	Goodrich
65B63271-128	Caster Tray ay	Goodrich
65B63271-129	Caster Tray ay	Goodrich
65B63271-130	Caster Tray ay	Goodrich
65B63271-131	Caster Tray ay	Goodrich

Repair_Capability_List_Excel

65B63271-132	Caster Tray ay	Goodrich
65B63271-133	Caster Tray ay	Goodrich
65B63271-134	Caster Tray ay	Goodrich
65B63271-135	Caster Tray ay	Goodrich
65B63271-136	Caster Tray ay	Goodrich
65B63271-137	Caster Tray ay	Goodrich
65B63271-138	Caster Tray ay	Goodrich
65B63271-139	Caster Tray ay	Goodrich
65B63271-140	Caster Tray ay	Goodrich
65B63271-141	Caster Tray ay	Goodrich
65B63271-142	Caster Tray ay	Goodrich
65B63271-143	Caster Tray ay	Goodrich
65B63271-144	Caster Tray ay	Goodrich
65B63271-145	Caster Tray ay	Goodrich
65B63271-146	Caster Tray ay	Goodrich
65B63271-147	Caster Tray ay	Goodrich
65B63271-148	Caster Tray ay	Goodrich
65B63271-28	Caster Tray ay	Goodrich
65B63271-29	Caster Tray ay	Goodrich
65B63271-30	Caster Tray ay	Goodrich
65B63271-31	Caster Tray ay	Goodrich
65B63271-32	Caster Tray ay	Goodrich
65B63271-33	Caster Tray ay	Goodrich
65B63271-34	Caster Tray ay	Goodrich
65B63271-35	Caster Tray ay	Goodrich
65B63271-36	Caster Tray ay	Goodrich
65B63271-37	Caster Tray ay	Goodrich
65B63271-38	Caster Tray ay	Goodrich
65B63271-39	Caster Tray ay	Goodrich
65B63271-40	Caster Tray ay	Goodrich
65B63271-41	Caster Tray ay	Goodrich
65B63271-42	Caster Tray ay	Goodrich
65B63271-43	Caster Tray ay	Goodrich
65B63271-44	Caster Tray ay	Goodrich
65B63271-45	Caster Tray ay	Goodrich
65B63271-46	Caster Tray ay	Goodrich
65B63271-47	Caster Tray ay	Goodrich
65B63271-48	Caster Tray ay	Goodrich
65B63271-49	Caster Tray ay	Goodrich
65B63271-50	Caster Tray ay	Goodrich
65B63271-51	Caster Tray ay	Goodrich
65B63271-52	Caster Tray ay	Goodrich
65B63271-53	Caster Tray ay	Goodrich
65B63271-54	Caster Tray ay	Goodrich
65B63271-55	Caster Tray ay	Goodrich
65B63271-56	Caster Tray ay	Goodrich
65B63271-57	Caster Tray ay	Goodrich
65B63271-58	Caster Tray ay	Goodrich
65B63271-59	Caster Tray ay	Goodrich
65B63271-60	Caster Tray ay	Goodrich
65B63271-61	Caster Tray ay	Goodrich
65B63271-62	Caster Tray ay	Goodrich
65B63271-63	Caster Tray ay	Goodrich
65B63271-64	Caster Tray ay	Goodrich
65B63271-65	Caster Tray ay	Goodrich
65B63271-66	Caster Tray ay	Goodrich
65B63271-67	Caster Tray ay	Goodrich
65B63271-68	Caster Tray ay	Goodrich

Repair_Capability_List_Excel

65B63271-69	Caster Tray ay	Goodrich
65B63271-70	Caster Tray ay	Goodrich
65B63271-71	Caster Tray ay	Goodrich
65B63271-72	Caster Tray ay	Goodrich
65B63271-73	Caster Tray ay	Goodrich
65B63271-74	Caster Tray ay	Goodrich
65B63271-75	Caster Tray ay	Goodrich
65B63271-76	Caster Tray ay	Goodrich
65B63271-77	Caster Tray ay	Goodrich
65B63271-78	Caster Tray ay	Goodrich
65B63271-79	Caster Tray ay	Goodrich
65B63271-80	Caster Tray ay	Goodrich
65B63271-81	Caster Tray ay	Goodrich
65B63271-82	Caster Tray ay	Goodrich
65B63271-83	Caster Tray ay	Goodrich
65B63271-84	Caster Tray ay	Goodrich
65B63271-85	Caster Tray ay	Goodrich
65B63271-86	Caster Tray ay	Goodrich
65B63271-87	Caster Tray ay	Goodrich
65B63271-88	Caster Tray ay	Goodrich
65B63271-89	Caster Tray ay	Goodrich
65B63271-90	Caster Tray ay	Goodrich
65B63271-91	Caster Tray ay	Goodrich
65B63271-92	Caster Tray ay	Goodrich
65B63271-93	Caster Tray ay	Goodrich
65B63271-94	Caster Tray ay	Goodrich
65B63271-96	Caster Tray ay	Goodrich
65B63271-97	Caster Tray ay	Goodrich
65B63271-98	Caster Tray ay	Goodrich
65B63271-99	Caster Tray ay	Goodrich
65B63279-1	Lock Roller Tray ay	Goodrich
65B63279-3	Lock Roller Tray ay	Goodrich
65B63279-4	Lock Roller Tray ay	Goodrich
65B63279-5	Lock Roller Tray ay	Goodrich
65B63280-1	Lock Roller ay	Goodrich
65B63280-3	Lock Roller ay	Goodrich
65B63280-4	Lock Roller ay	Goodrich
65B63280-5	Lock Roller ay	Goodrich
65B63281-1	Lock Roller ay	Goodrich
65B63281-3	Lock Roller ay	Goodrich
65B63281-4	Lock Roller ay	Goodrich
65B63281-5	Lock Roller ay	Goodrich
65B63282-1	Lock Roller ay	Goodrich
65B63282-3	Lock Roller ay	Goodrich
65B63282-4	Lock Roller ay	Goodrich
65B63282-5	Lock Roller ay	Goodrich
65B63283-1	Lock Roller ay	Goodrich
65B63283-3	Lock Roller ay	Goodrich
65B63283-4	Lock Roller ay	Goodrich
65B63283-5	Lock Roller ay	Goodrich
65B63292-1	Bumper ay	Goodrich
65B63292-3	Bumper ay	Goodrich
65B63295-10	Roller Tray ay	Goodrich
65B63295-11	Roller Tray ay	Goodrich
65B63295-12	Roller Tray ay	Goodrich
65B63295-13	Roller Tray ay	Goodrich
65B63295-14	Roller Tray ay	Goodrich
65B63295-15	Roller Tray ay	Goodrich

Repair_Capability_List_Excel

65B63295-16	Roller Tray ay	Goodrich
65B63295-17	Roller Tray ay	Goodrich
65B63295-18	Roller Tray ay	Goodrich
65B63295-19	Roller Tray ay	Goodrich
65B63295-3	Roller Tray ay	Goodrich
65B63295-4	Roller Tray ay	Goodrich
65B63295-5	Roller Tray ay	Goodrich
65B63295-6	Roller Tray ay	Goodrich
65B63295-7	Roller Tray ay	Goodrich
65B63295-8	Roller Tray ay	Goodrich
65B63295-9	Roller Tray ay	Goodrich
65B63306-10	Lock Tray ay	Goodrich
65B63306-11	Lock Tray ay	Goodrich
65B63306-12	Lock Tray ay	Goodrich
65B63306-13	Lock Tray ay	Goodrich
65B63306-14	Lock Tray ay	Goodrich
65B63306-15	Lock Tray ay	Goodrich
65B63306-16	Lock Tray ay	Goodrich
65B63306-17	Lock Tray ay	Goodrich
65B63306-18	Lock Tray ay	Goodrich
65B63306-19	Lock Tray ay	Goodrich
65B63306-20	Lock Tray ay	Goodrich
65B63306-21	Lock Tray ay	Goodrich
65B63306-22	Lock Tray ay	Goodrich
65B63306-7	Lock Tray ay	Goodrich
65B63306-8	Lock Tray ay	Goodrich
65B63306-9	Lock Tray ay	Goodrich
65B63313-1	Guide ay	Goodrich
65B63313-2	Guide ay	Goodrich
65B63322-1	Lock Roller ay	Goodrich
65B63322-2	Lock Roller ay	Goodrich
65B63322-3	Lock Roller ay	Goodrich
65B63333-1	Guide ay	Goodrich
65B63333-3	Guide ay	Goodrich
65B63366-1	Restraint ay	Goodrich
65B63376-1	Guide Rail ay	Goodrich
65B63376-10	Guide Rail ay	Goodrich
65B63376-12	Guide Rail ay	Goodrich
65B63376-13	Guide Rail ay	Goodrich
65B63376-14	Guide Rail ay	Goodrich
65B63376-15	Guide Rail ay	Goodrich
65B63376-16	Guide Rail ay	Goodrich
65B63376-17	Guide Rail ay	Goodrich
65B63376-18	Guide Rail ay	Goodrich
65B63376-19	Guide Rail ay	Goodrich
65B63376-2	Guide Rail ay	Goodrich
65B63376-20	Guide Rail ay	Goodrich
65B63376-21	Guide Rail ay	Goodrich
65B63376-22	Guide Rail ay	Goodrich
65B63376-23	Guide Rail ay	Goodrich
65B63376-24	Guide Rail ay	Goodrich
65B63376-25	Guide Rail ay	Goodrich
65B63376-26	Guide Rail ay	Goodrich
65B63376-3	Guide Rail ay	Goodrich
65B63376-4	Guide Rail ay	Goodrich
65B63376-5	Guide Rail ay	Goodrich
65B63376-6	Guide Rail ay	Goodrich
65B63376-7	Guide Rail ay	Goodrich

Repair_Capability_List_Excel

65B63376-8	Guide Rail ay	Goodrich
65B63376-9	Guide Rail ay	Goodrich
65B63377-1	Sill Roller and Guide ay	Goodrich
65B63377-13	Sill Roller and Guide ay	Goodrich
65B63377-14	Sill Roller and Guide ay	Goodrich
65B63377-17	Sill Roller and Guide ay	Goodrich
65B63377-18	Sill Roller and Guide ay	Goodrich
65B63377-2	Sill Roller and Guide ay	Goodrich
65B63377-21	Sill Roller and Guide ay	Goodrich
65B63377-22	Sill Roller and Guide ay	Goodrich
65B63377-7	Sill Roller and Guide ay	Goodrich
65B63377-8	Sill Roller and Guide ay	Goodrich
65B63390-1	Restraint ay	Goodrich
65B63400-1	Caster Support ay	Goodrich
65B63400-2	Caster Support ay	Goodrich
65B63406-1	Guide and Restraint ay	Goodrich
65B63406-10	Guide and Restraint ay	Goodrich
65B63406-12	Guide and Restraint ay	Goodrich
65B63406-13	Guide and Restraint ay	Goodrich
65B63406-17	Guide and Restraint ay	Goodrich
65B63406-2	Guide and Restraint ay	Goodrich
65B63406-21	Guide and Restraint ay	Goodrich
65B63406-22	Guide and Restraint ay	Goodrich
65B63406-23	Guide and Restraint ay	Goodrich
65B63406-24	Guide and Restraint ay	Goodrich
65B63406-25	Guide and Restraint ay	Goodrich
65B63406-26	Guide and Restraint ay	Goodrich
65B63406-27	Guide and Restraint ay	Goodrich
65B63406-28	Guide and Restraint ay	Goodrich
65B63406-29	Guide and Restraint ay	Goodrich
65B63406-3	Guide and Restraint ay	Goodrich
65B63406-30	Guide and Restraint ay	Goodrich
65B63406-31	Guide and Restraint ay	Goodrich
65B63406-32	Guide and Restraint ay	Goodrich
65B63406-33	Guide and Restraint ay	Goodrich
65B63406-4	Guide and Restraint ay	Goodrich
65B63406-41	Guide and Restraint ay	Goodrich
65B63406-42	Guide and Restraint ay	Goodrich
65B63406-43	Guide and Restraint ay	Goodrich
65B63406-44	Guide and Restraint ay	Goodrich
65B63406-45	Guide and Restraint ay	Goodrich
65B63406-46	Guide and Restraint ay	Goodrich
65B63406-47	Guide and Restraint ay	Goodrich
65B63406-48	Guide and Restraint ay	Goodrich
65B63406-49	Guide and Restraint ay	Goodrich
65B63406-5	Guide and Restraint ay	Goodrich
65B63406-50	Guide and Restraint ay	Goodrich
65B63406-51	Guide and Restraint ay	Goodrich
65B63406-52	Guide and Restraint ay	Goodrich
65B63406-53	Guide and Restraint ay	Goodrich
65B63406-56	Guide and Restraint ay	Goodrich
65B63406-57	Guide and Restraint ay	Goodrich
65B63406-58	Guide and Restraint ay	Goodrich
65B63406-59	Guide and Restraint ay	Goodrich
65B63406-6	Guide and Restraint ay	Goodrich
65B63406-60	Guide and Restraint ay	Goodrich
65B63406-61	Guide and Restraint ay	Goodrich
65B63406-62	Guide and Restraint ay	Goodrich

Repair_Capability_List_Excel

65B63406-63	Guide and Restraint ay	Goodrich
65B63406-64	Guide and Restraint ay	Goodrich
65B63406-65	Guide and Restraint ay	Goodrich
65B63406-66	Guide and Restraint ay	Goodrich
65B63406-67	Guide and Restraint ay	Goodrich
65B63406-68	Guide and Restraint ay	Goodrich
65B63406-7	Guide and Restraint ay	Goodrich
65B63406-76	Guide and Restraint ay	Goodrich
65B63406-8	Guide and Restraint ay	Goodrich
65B63406-9	Guide and Restraint ay	Goodrich
65B63414-1	Lock ay	Goodrich
65B63414-2	Lock ay	Goodrich
65B63414-3	Lock ay	Goodrich
65B63414-4	Lock ay	Goodrich
65B63424-2	Stop ay	Goodrich
65B63424-3	Stop ay	Goodrich
65B63424-4	Stop ay	Goodrich
65B63429-2	Guide and Restraint ay	Goodrich
65B63429-3	Guide and Restraint ay	Goodrich
65B63429-4	Guide and Restraint ay	Goodrich
65B63434-2	Guide ay	Goodrich
65B63434-3	Guide ay	Goodrich
65B63440-1	Rail Support ay	Goodrich
65B63455-1	Caster Tray ay	Goodrich
65B63455-2	Caster Tray ay	Goodrich
65B63456-1	Caster Panel ay	Goodrich
65B63456-33	Caster Panel ay	Goodrich
65B63456-34	Caster Panel ay	Goodrich
65B63456-35	Caster Panel ay	Goodrich
65B63456-36	Caster Panel ay	Goodrich
65B63456-37	Caster Panel ay	Goodrich
65B63456-38	Caster Panel ay	Goodrich
65B63456-39	Caster Panel ay	Goodrich
65B63456-40	Caster Panel ay	Goodrich
65B63456-41	Caster Panel ay	Goodrich
65B63456-42	Caster Panel ay	Goodrich
65B63456-43	Caster Panel ay	Goodrich
65B63456-44	Caster Panel ay	Goodrich
65B63456-45	Caster Panel ay	Goodrich
65B63456-46	Caster Panel ay	Goodrich
65B63456-47	Caster Panel ay	Goodrich
65B63456-48	Caster Panel ay	Goodrich
65B63456-49	Caster Panel ay	Goodrich
65B63456-50	Caster Panel ay	Goodrich
65B63456-51	Caster Panel ay	Goodrich
65B63456-52	Caster Panel ay	Goodrich
65B63456-53	Caster Panel ay	Goodrich
65B63456-54	Caster Panel ay	Goodrich
65B63456-55	Caster Panel ay	Goodrich
65B63456-56	Caster Panel ay	Goodrich
65B63456-57	Caster Panel ay	Goodrich
65B63456-58	Caster Panel ay	Goodrich
65B63456-59	Caster Panel ay	Goodrich
65B63456-6	Caster Panel ay	Goodrich
65B63456-60	Caster Panel ay	Goodrich
65B63456-61	Caster Panel ay	Goodrich
65B63456-62	Caster Panel ay	Goodrich
65B63456-63	Caster Panel ay	Goodrich

Repair_Capability_List_Excel

65B63456-64	Caster Panel ay	Goodrich
65B63456-65	Caster Panel ay	Goodrich
65B63456-66	Caster Panel ay	Goodrich
65B63456-67	Caster Panel ay	Goodrich
65B63456-68	Caster Panel ay	Goodrich
65B63456-69	Caster Panel ay	Goodrich
65B63456-7	Caster Panel ay	Goodrich
65B63456-70	Caster Panel ay	Goodrich
65B63456-71	Caster Panel ay	Goodrich
65B63456-72	Caster Panel ay	Goodrich
65B63456-73	Caster Panel ay	Goodrich
65B63456-74	Caster Panel ay	Goodrich
65B63456-75	Caster Panel ay	Goodrich
65B63456-76	Caster Panel ay	Goodrich
65B63456-77	Caster Panel ay	Goodrich
65B63456-78	Caster Panel ay	Goodrich
65B63456-79	Caster Panel ay	Goodrich
65B63456-8	Caster Panel ay	Goodrich
65B63456-80	Caster Panel ay	Goodrich
65B63456-81	Caster Panel ay	Goodrich
65B63456-82	Caster Panel ay	Goodrich
65B63456-83	Caster Panel ay	Goodrich
65B63456-84	Caster Panel ay	Goodrich
65B63456-85	Caster Panel ay	Goodrich
65B63456-86	Caster Panel ay	Goodrich
65B63456-87	Caster Panel ay	Goodrich
65B63456-9	Caster Panel ay	Goodrich
65B63460-1	Guide Rail ay	Goodrich
65B63460-10	Guide Rail ay	Goodrich
65B63460-11	Guide Rail ay	Goodrich
65B63460-12	Guide Rail ay	Goodrich
65B63460-13	Guide Rail ay	Goodrich
65B63460-14	Guide Rail ay	Goodrich
65B63460-15	Guide Rail ay	Goodrich
65B63460-16	Guide Rail ay	Goodrich
65B63460-17	Guide Rail ay	Goodrich
65B63460-18	Guide Rail ay	Goodrich
65B63460-19	Guide Rail ay	Goodrich
65B63460-2	Guide Rail ay	Goodrich
65B63460-3	Guide Rail ay	Goodrich
65B63460-4	Guide Rail ay	Goodrich
65B63460-5	Guide Rail ay	Goodrich
65B63460-6	Guide Rail ay	Goodrich
65B63460-7	Guide Rail ay	Goodrich
65B63460-8	Guide Rail ay	Goodrich
65B63460-9	Guide Rail ay	Goodrich
65B63487-1	Caster Panel ay	Goodrich
65B63487-2	Caster Panel ay	Goodrich
65B63487-6	Caster Panel ay	Goodrich
65B63500-1	Lock Tray ay	Goodrich
65B63500-7	Lock Tray ay	Goodrich
65B63501-1	Lock Tray ay	Goodrich
65B63502-1	Lock Tray ay	Goodrich
65B63503-1	Lock Tray ay	Goodrich
65B63544-1	Guide Rail ay	Goodrich
65B63547-1	Anchor Rail ay	Goodrich
65B63547-2	Anchor Rail ay	Goodrich
65B63560-1	Locking Guide ay	Goodrich

Repair_Capability_List_Excel

65B63560-6	Locking Guide ay	Goodrich
65B63570-1	Lock Tray ay	Goodrich
65B63570-2	Lock Tray ay	Goodrich
65B63583-1	Park Rail ay	Goodrich
65B63583-7	Park Rail ay	Goodrich
65B63584-1	Fixed Guide Rail ay	Goodrich
65B63584-2	Fixed Guide Rail ay	Goodrich
65B63603-1	Lock Tray ay	Goodrich
65B63607-1	Lock Tray ay	Goodrich
65B63607-501	Lock Tray ay	Goodrich
65B63611-1	Caster Tray ay	Goodrich
65B63611-10	Caster Tray ay	Goodrich
65B63611-2	Caster Tray ay	Goodrich
65B63611-3	Caster Tray ay	Goodrich
65B63611-4	Caster Tray ay	Goodrich
65B63611-501	Caster Tray ay	Goodrich
65B63611-502	Caster Tray ay	Goodrich
65B63611-503	Caster Tray ay	Goodrich
65B63611-504	Caster Tray ay	Goodrich
65B63611-6	Caster Tray ay	Goodrich
65B63611-7	Caster Tray ay	Goodrich
65B63611-8	Caster Tray ay	Goodrich
65B63611-9	Caster Tray ay	Goodrich
65B63621-501	Restraint ay	Goodrich
65B63621-502	Restraint ay	Goodrich
65B63621-503	Restraint ay	Goodrich
65B63629-14	Restraint Rail ay	Goodrich
65B63629-15	Restraint Rail ay	Goodrich
65B63629-16	Restraint Rail ay	Goodrich
65B63629-17	Restraint Rail ay	Goodrich
65B63629-501	Restraint Rail ay	Goodrich
65B63629-502	Restraint Rail ay	Goodrich
65B63629-503	Restraint Rail ay	Goodrich
65B63629-504	Restraint Rail ay	Goodrich
65B63629-505	Restraint Rail ay	Goodrich
65B63629-506	Restraint Rail ay	Goodrich
65B63629-507	Restraint Rail ay	Goodrich
65B63629-508	Restraint Rail ay	Goodrich
65B63629-6	Restraint Rail ay	Goodrich
65B63629-7	Restraint Rail ay	Goodrich
65B63629-8	Restraint Rail ay	Goodrich
65B63662-1	Restraint ay	Goodrich
65B63662-2	Restraint ay	Goodrich
65B63662-3	Restraint ay	Goodrich
65B63662-4	Restraint ay	Goodrich
65B63662-5	Restraint ay	Goodrich
65B63662-501	Restraint ay	Goodrich
65B63662-502	Restraint ay	Goodrich
65B63662-503	Restraint ay	Goodrich
65B63662-504	Restraint ay	Goodrich
65B63662-505	Restraint ay	Goodrich
65B63662-506	Restraint ay	Goodrich
65B63662-507	Restraint ay	Goodrich
65B63662-508	Restraint ay	Goodrich
65B63662-509	Restraint ay	Goodrich
65B63662-510	Restraint ay	Goodrich
65B63662-511	Restraint ay	Goodrich
65B63662-512	Restraint ay	Goodrich

Repair_Capability_List_Excel

65B63662-6	Restraint ay	Goodrich
65B63664-1	Restraint Rail ay	Goodrich
65B63664-2	Restraint Rail ay	Goodrich
65B63664-3	Restraint Rail ay	Goodrich
65B63664-501	Restraint Rail ay	Goodrich
65B63664-502	Restraint Rail ay	Goodrich
65B63671-1	Stop ay	Goodrich
65B63672-1	Stop ay	Goodrich
65B63673-1	Stop ay	Goodrich
65B63675-1	Stop ay	Goodrich
65B63680-1	Lock Tray ay	Goodrich
65B63680-2	Lock Tray ay	Goodrich
65B63694-1	Restraint ay	Goodrich
65B63694-501	Restraint ay	Goodrich
65B63694-502	Restraint ay	Goodrich
65B63710-1	Rail Support ay	Goodrich
65B63710-2	Rail Support ay	Goodrich
65B63710-501	Rail Support ay	Goodrich
65B63712-1	Guide Rail and Restraint ay	Goodrich
65B63712-2	Guide Rail and Restraint ay	Goodrich
65B63712-501	Guide Rail and Restraint ay	Goodrich
65B63713-1	Guide Rail and Restraint ay	Goodrich
65B63713-10	Guide Rail and Restraint ay	Goodrich
65B63713-11	Guide Rail and Restraint ay	Goodrich
65B63713-12	Guide Rail and Restraint ay	Goodrich
65B63713-2	Guide Rail and Restraint ay	Goodrich
65B63713-3	Guide Rail and Restraint ay	Goodrich
65B63713-4	Guide Rail and Restraint ay	Goodrich
65B63713-504	Guide Rail and Restraint ay	Goodrich
65B63713-505	Guide Rail and Restraint ay	Goodrich
65B63713-506	Guide Rail and Restraint ay	Goodrich
65B63713-507	Guide Rail and Restraint ay	Goodrich
65B63713-508	Guide Rail and Restraint ay	Goodrich
65B63713-509	Guide Rail and Restraint ay	Goodrich
65B63713-510	Guide Rail and Restraint ay	Goodrich
65B63713-511	Guide Rail and Restraint ay	Goodrich
65B63713-512	Guide Rail and Restraint ay	Goodrich
65B63713-513	Guide Rail and Restraint ay	Goodrich
65B63713-514	Guide Rail and Restraint ay	Goodrich
65B63713-515	Guide Rail and Restraint ay	Goodrich
65B63713-516	Guide Rail and Restraint ay	Goodrich
65B63713-517	Guide Rail and Restraint ay	Goodrich
65B63713-8	Guide Rail and Restraint ay	Goodrich
65B63713-9	Guide Rail and Restraint ay	Goodrich
65B63717-1	Rail Support ay	Goodrich
65B63725-1	Bumper ay	Goodrich
65B63725-2	Retractable Bumper ay	Goodrich
65B63725-3	Retractable Bumper ay	Goodrich
65B63725-501	Retractable Bumper ay	Goodrich
65B63725-502	Retractable Bumper ay	Goodrich
65B63726-1	Guide Rail Support ay	Goodrich
65B63726-2	Guide Rail Support ay	Goodrich
65B63733-1	Caster and Guide ay	Goodrich
65B63733-11	Caster and Guide ay	Goodrich
65B63733-12	Caster and Guide ay	Goodrich
65B63733-19	Caster and Guide ay	Goodrich
65B63733-2	Caster and Guide ay	Goodrich
65B63733-20	Caster and Guide ay	Goodrich

Repair_Capability_List_Excel

65B63733-23	Caster and Guide ay	Goodrich
65B63733-24	Caster and Guide ay	Goodrich
65B63733-27	Caster and Guide ay	Goodrich
65B63733-28	Caster and Guide ay	Goodrich
65B63733-31	Caster and Guide ay	Goodrich
65B63733-32	Caster and Guide ay	Goodrich
65B63733-7	Caster and Guide ay	Goodrich
65B63733-8	Caster and Guide ay	Goodrich
65B63747-1	Retracting Stop ay	Goodrich
65B63747-2	Retracting Stop ay	Goodrich
65B63747-501	Retracting Stop ay	Goodrich
65B63747-502	Retracting Stop ay	Goodrich
65B63747-503	Retracting Stop ay	Goodrich
65B63754-1	Retractable Stop ay	Goodrich
65B63754-2	Retractable Stop ay	Goodrich
65B63754-3	Retractable Stop ay	Goodrich
65B63754-4	Retractable Stop ay	Goodrich
65B63754-501	Retractable Stop ay	Goodrich
65B63765-1	Guide Rail ay	Goodrich
65B63765-2	Guide Rail ay	Goodrich
65B63765-3	Guide Rail ay	Goodrich
65B63765-4	Guide Rail ay	Goodrich
65B63765-5	Guide Rail ay	Goodrich
65B63765-6	Guide Rail ay	Goodrich
65B63788-1	Stop ay	Goodrich
65B63788-501	Stop ay	Goodrich
65B63792-1	Lock Tray ay	Goodrich
65B63792-2	Lock Tray ay	Goodrich
65B63804-1	Retractable Power Drive Unit ay	Goodrich
65B63890-1	Lock ay	Goodrich
65B63890-2	Lock ay	Goodrich
65B63893-4	Guide and Restraint ay	Goodrich
65B79164-139	Passenger Service Unit	Boeing
65B79164-140	Passenger Service Unit	Boeing
65B79164-141	Passenger Service Unit	Boeing
65B79164-142	Passenger Service Unit	Boeing
65B79164-143	Passenger Service Unit	Boeing
65B79164-144	Passenger Service Unit	Boeing
65B79164-145	Passenger Service Unit	Boeing
65B79164-146	Passenger Service Unit	Boeing
65B79164-147	Passenger Service Unit	Boeing
65B79164-148	Passenger Service Unit	Boeing
65B79164-149	Passenger Service Unit	Boeing
65B79164-150	Passenger Service Unit	Boeing
65B79164-151	Passenger Service Unit	Boeing
65B79164-152	Passenger Service Unit	Boeing
65B79164-153	Passenger Service Unit	Boeing
65B79164-154	Passenger Service Unit	Boeing
65B79164-155	Passenger Service Unit	Boeing
65B79164-156	Passenger Service Unit	Boeing
65B79164-165	Passenger Service Unit	Boeing
65B79164-166	Passenger Service Unit	Boeing
65B79164-167	Passenger Service Unit	Boeing
65B79164-168	Passenger Service Unit	Boeing
65B79164-169	Passenger Service Unit	Boeing
65B79164-170	Passenger Service Unit	Boeing
65B79164-171	Passenger Service Unit	Boeing
65B79164-172	Passenger Service Unit	Boeing

Repair_Capability_List_Excel

65B79164-173	Passenger Service Unit	Boeing
65B79164-174	Passenger Service Unit	Boeing
65B80199-8	Valve assy	Boeing
65B80199-9	Valve assy	Boeing
65B80213-10	Filter Module	Boeing
65B80213-5	Filter Module	Boeing
65B80213-6	Filter Module	Boeing
65B80213-9	Filter Module	Boeing
65B80273-11	Filter Module	Boeing
65B80273-7	Filter Module	Boeing
65B80326-4	Crank assy	Boeing
65B80326-5	Crank assy	Boeing
65B80326-6	Crank assy	Boeing
65B80440-1	TE Flap Drive	Boeing
65B80440-10	TE Flap Drive	Boeing
65B80440-11	TE Flap Drive	Boeing
65B80440-12	TE Flap Drive	Boeing
65B80440-13	TE Flap Drive	Boeing
65B80440-14	TE Flap Drive	Boeing
65B80440-15	TE Flap Drive	Boeing
65B80440-16	TE Flap Drive	Boeing
65B80440-2	TE Flap Drive	Boeing
65B80440-3	TE Flap Drive	Boeing
65B80440-4	TE Flap Drive	Boeing
65B80440-9	TE Flap Drive	Boeing
65B80510-3	Mechanism	Boeing
65B80510-4	Mechanism	Boeing
65B80552-1	Differential	Boeing
65B80562-10	Stabilizer Trim Drive Mechanism ay	Boeing
65B80562-12	Stabilizer Trim Drive Mechanism ay	Boeing
65B80562-16	Stabilizer Trim Drive Mechanism ay	Boeing
65B80562-18	Stabilizer Trim Drive Mechanism ay	Boeing
65B80562-19	Stabilizer Trim Drive Mechanism ay	Boeing
65B80562-20	Stabilizer Trim Drive Mechanism ay	Boeing
65B80562-24	Stabilizer Trim Drive Mechanism ay	Boeing
65B80562-25	Stabilizer Trim Drive Mechanism ay	Boeing
65B80562-26	Stabilizer Trim Drive Mechanism ay	Boeing
65B80562-27	Stabilizer Trim Drive Mechanism ay	Boeing
65B80562-28	Stabilizer Trim Drive Mechanism ay	Boeing
65B80562-29	Stabilizer Trim Drive Mechanism ay	Boeing
65B80562-30	Stabilizer Trim Drive Mechanism ay	Boeing
65B80562-31	Stabilizer Trim Drive Mechanism ay	Boeing
65B80562-33	Stabilizer Trim Drive Mechanism ay	Boeing
65B80562-34	Stabilizer Trim Drive Mechanism ay	Boeing
65B80562-35	Stabilizer Trim Drive Mechanism ay	Boeing
65B80562-36	Stabilizer Trim Drive Mechanism ay	Boeing
65B80562-37	Stabilizer Trim Drive Mechanism ay	Boeing
65B80562-39	Stabilizer Trim Drive Mechanism ay	Boeing
65B80562-42	Stabilizer Trim Drive Mechanism ay	Boeing
65B80562-43	Stabilizer Trim Drive Mechanism ay	Boeing
65B80562-44	Stabilizer Trim Drive Mechanism ay	Boeing
65B80562-7	Stabilizer Trim Drive Mechanism ay	Boeing
65B80562-8	Stabilizer Trim Drive Mechanism ay	Boeing
65B80562-9	Stabilizer Trim Drive Mechanism ay	Boeing
65B80799-1	Drag Brake	Boeing
65B80799-3	Drag Brake	Boeing
65B80799-5	Drag Brake	Boeing
65B80799-6	Drag Brake	Boeing

Repair_Capability_List_Excel

65B80799-7	Drag Brake	Boeing
65B80799-8	Drag Brake	Boeing
65B80836-2	Spoiler Mechanism assy	Boeing
65B80836-3	Spoiler Mechanism assy	Boeing
65B80836-4	Spoiler Mechanism assy	Boeing
65B80859-1	Speed Brake Mechanism	Boeing
65B80859-10	Speed Brake Mechanism	Boeing
65B80859-11	Speed Brake Mechanism	Boeing
65B80859-12	Speed Brake Mechanism	Boeing
65B80859-13	Speed Brake Mechanism	Boeing
65B80859-14	Speed Brake Mechanism	Boeing
65B80859-2	Speed Brake Mechanism	Boeing
65B80859-3	Speed Brake Mechanism	Boeing
65B80859-4	Speed Brake Mechanism	Boeing
65B80859-5	Speed Brake Mechanism	Boeing
65B80859-6	Speed Brake Mechanism	Boeing
65B80859-7	Speed Brake Mechanism	Boeing
65B80859-8	Speed Brake Mechanism	Boeing
65B80859-9	Speed Brake Mechanism	Boeing
65B80934-3	Lockout Aileron Gearbox	Boeing
65B80934-4	Lockout Aileron Gearbox	Boeing
65B81011-112	Control Rod	Boeing
65B81011-304	Control Rod	Boeing
65B81011-308	Control Rod	Boeing
65B81011-309	Control Rod	Boeing
65B81011-310	Control Rod	Boeing
65B81011-311	Control Rod	Boeing
65B81120-1	Angle Gearbox assy	Boeing
65B81120-2	Angle Gearbox assy	Boeing
65B81120-3	Angle Gearbox assy	Boeing
65B81120-4	Angle Gearbox assy	Boeing
65B81120-5	Angle Gearbox assy	Boeing
65B81120-6	Angle Gearbox assy	Boeing
65B81121-1	Angle Gearbox assy	Boeing
65B81121-10	Angle Gearbox assy	Boeing
65B81121-11	Gearbox assy	Boeing
65B81121-12	Angle Gearbox assy	Boeing
65B81121-13	Angle Gearbox assy	Boeing
65B81121-2	Angle Gearbox assy	Boeing
65B81121-3	Angle Gearbox assy	Boeing
65B81121-4	Angle Gearbox assy	Boeing
65B81121-5	Angle Gearbox assy	Boeing
65B81121-6	Angle Gearbox assy	Boeing
65B81121-7	Angle Gearbox assy	Boeing
65B81121-8	Angle Gearbox assy	Boeing
65B81121-9	Angle Gearbox assy	Boeing
65B81126-1	Trailing Edge Flap Drive	Boeing
65B81126-101	Trailing Edge Flap Drive	Boeing
65B81126-102	Trailing Edge Flap Drive	Boeing
65B81126-103	Trailing Edge Flap Drive	Boeing
65B81126-104	Trailing Edge Flap Drive	Boeing
65B81126-105	Trailing Edge Flap Drive	Boeing
65B81126-106	Trailing Edge Flap Drive	Boeing
65B81126-107	Trailing Edge Flap Drive	Boeing
65B81126-108	Trailing Edge Flap Drive	Boeing
65B81126-109	Trailing Edge Flap Drive	Boeing
65B81126-110	Trailing Edge Flap Drive	Boeing
65B81126-111	Trailing Edge Flap Drive	Boeing

Repair_Capability_List_Excel

65B81128-31	Trailing Edge Flap Drive	Boeing
65B81128-4	Trailing Edge Flap Drive	Boeing
65B81128-5	Trailing Edge Flap Drive	Boeing
65B81128-6	Trailing Edge Flap Drive	Boeing
65B81128-7	Trailing Edge Flap Drive	Boeing
65B81128-8	Trailing Edge Flap Drive	Boeing
65B81128-9	Trailing Edge Flap Drive	Boeing
65B81129-1	Transmission assy	Boeing
65B81129-10	Trailing Edge Flap Drive	Boeing
65B81129-101	Transmission assy	Boeing
65B81129-102	Transmission assy	Boeing
65B81129-103	Trailing Edge Flap Drive	Boeing
65B81129-104	Trailing Edge Flap Drive	Boeing
65B81129-105	Trailing Edge Flap Drive	Boeing
65B81129-106	Trailing Edge Flap Drive	Boeing
65B81129-107	Trailing Edge Flap Drive	Boeing
65B81129-108	Trailing Edge Flap Drive	Boeing
65B81129-109	Trailing Edge Flap Drive	Boeing
65B81129-110	Trailing Edge Flap Drive	Boeing
65B81129-111	Trailing Edge Flap Drive	Boeing
65B81129-112	Trailing Edge Flap Drive	Boeing
65B81129-113	Trailing Edge Flap Drive	Boeing
65B81129-114	Trailing Edge Flap Drive	Boeing
65B81129-115	Trailing Edge Flap Drive	Boeing
65B81129-116	Trailing Edge Flap Drive	Boeing
65B81129-117	Trailing Edge Flap Drive	Boeing
65B81129-118	Trailing Edge Flap Drive	Boeing
65B81129-119	Trailing Edge Flap Drive	Boeing
65B81129-120	Trailing Edge Flap Drive	Boeing
65B81129-121	Trailing Edge Flap Drive	Boeing
65B81129-122	Trailing Edge Flap Drive	Boeing
65B81129-123	Trailing Edge Flap Drive	Boeing
65B81129-124	Trailing Edge Flap Drive	Boeing
65B81129-125	Trailing Edge Flap Drive	Boeing
65B81129-126	Trailing Edge Flap Drive	Boeing
65B81129-127	Trailing Edge Flap Drive	Boeing
65B81129-128	Trailing Edge Flap Drive	Boeing
65B81129-129	Trailing Edge Flap Drive	Boeing
65B81129-130	Trailing Edge Flap Drive	Boeing
65B81129-131	Trailing Edge Flap Drive	Boeing
65B81129-132	Trailing Edge Flap Drive	Boeing
65B81129-133	Trailing Edge Flap Drive	Boeing
65B81129-134	Trailing Edge Flap Drive	Boeing
65B81129-135	Trailing Edge Flap Drive	Boeing
65B81129-136	Trailing Edge Flap Drive	Boeing
65B81129-139	Trailing Edge Flap Drive	Boeing
65B81129-140	Trailing Edge Flap Drive	Boeing
65B81129-141	Trailing Edge Flap Drive	Boeing
65B81129-142	Trailing Edge Flap Drive	Boeing
65B81129-143	Trailing Edge Flap Drive	Boeing
65B81129-144	Trailing Edge Flap Drive	Boeing
65B81129-145	Trailing Edge Flap Drive	Boeing
65B81129-146	Trailing Edge Flap Drive	Boeing
65B81129-147	Trailing Edge Flap Drive	Boeing
65B81129-148	Trailing Edge Flap Drive	Boeing
65B81129-149	Trailing Edge Flap Drive	Boeing
65B81129-150	Trailing Edge Flap Drive	Boeing
65B81129-151	Trailing Edge Flap Drive	Boeing

Repair_Capability_List_Excel

65B81129-152	Trailing Edge Flap Drive	Boeing
65B81129-153	Trailing Edge Flap Drive	Boeing
65B81129-154	Trailing Edge Flap Drive	Boeing
65B81129-155	Trailing Edge Flap Drive	Boeing
65B81129-156	Trailing Edge Flap Drive	Boeing
65B81129-157	Trailing Edge Flap Drive	Boeing
65B81129-158	Trailing Edge Flap Drive	Boeing
65B81129-159	Trailing Edge Flap Drive	Boeing
65B81129-160	Trailing Edge Flap Drive	Boeing
65B81129-161	Trailing Edge Flap Drive	Boeing
65B81129-162	Trailing Edge Flap Drive	Boeing
65B81129-163	Trailing Edge Flap Drive	Boeing
65B81129-164	Trailing Edge Flap Drive	Boeing
65B81129-165	Trailing Edge Flap Drive	Boeing
65B81129-166	Trailing Edge Flap Drive	Boeing
65B81129-167	Trailing Edge Flap Drive	Boeing
65B81129-168	Trailing Edge Flap Drive	Boeing
65B81129-169	Trailing Edge Flap Drive	Boeing
65B81129-170	Trailing Edge Flap Drive	Boeing
65B81129-171	Trailing Edge Flap Drive	Boeing
65B81129-172	Trailing Edge Flap Drive	Boeing
65B81129-175	Trailing Edge Flap Drive	Boeing
65B81129-176	Trailing Edge Flap Drive	Boeing
65B81129-177	Trailing Edge Flap Drive	Boeing
65B81129-178	Trailing Edge Flap Drive	Boeing
65B81129-179	Trailing Edge Flap Drive	Boeing
65B81129-180	Trailing Edge Flap Drive	Boeing
65B81129-181	Trailing Edge Flap Drive	Boeing
65B81129-182	Trailing Edge Flap Drive	Boeing
65B81129-183	Trailing Edge Flap Drive	Boeing
65B81129-184	Trailing Edge Flap Drive	Boeing
65B81129-185	Trailing Edge Flap Drive	Boeing
65B81129-186	Trailing Edge Flap Drive	Boeing
65B81129-187	Trailing Edge Flap Drive	Boeing
65B81129-188	Trailing Edge Flap Drive	Boeing
65B81129-189	Trailing Edge Flap Drive	Boeing
65B81129-190	Trailing Edge Flap Drive	Boeing
65B81129-191	Transmission assy	Boeing
65B81129-192	Transmission assy	Boeing
65B81129-193	Trailing Edge Flap Drive	Boeing
65B81129-194	Trailing Edge Flap Drive	Boeing
65B81129-195	Trailing Edge Flap Drive	Boeing
65B81129-196	Trailing Edge Flap Drive	Boeing
65B81129-197	Transmission assy	Boeing
65B81129-198	Transmission assy	Boeing
65B81129-199	Trailing Edge Flap Drive	Boeing
65B81129-2	Transmission assy	Boeing
65B81129-200	Trailing Edge Flap Drive	Boeing
65B81129-201	Trailing Edge Flap Drive	Boeing
65B81129-202	Trailing Edge Flap Drive	Boeing
65B81129-203	Transmission assy	Boeing
65B81129-204	Transmission assy	Boeing
65B81129-205	Trailing Edge Flap Drive	Boeing
65B81129-206	Trailing Edge Flap Drive	Boeing
65B81129-207	Trailing Edge Flap Drive	Boeing
65B81129-208	Trailing Edge Flap Drive	Boeing
65B81129-209	Transmission assy	Boeing
65B81129-210	Transmission assy	Boeing

Repair_Capability_List_Excel

65B81129-211	Trailing Edge Flap Drive	Boeing
65B81129-212	Trailing Edge Flap Drive	Boeing
65B81129-213	Trailing Edge Flap Drive	Boeing
65B81129-214	Trailing Edge Flap Drive	Boeing
65B81129-3	Trailing Edge Flap Drive	Boeing
65B81129-4	Trailing Edge Flap Drive	Boeing
65B81129-5	Trailing Edge Flap Drive	Boeing
65B81129-6	Trailing Edge Flap Drive	Boeing
65B81129-7	Trailing Edge Flap Drive	Boeing
65B81129-8	Trailing Edge Flap Drive	Boeing
65B81129-9	Trailing Edge Flap Drive	Boeing
65B81130-1	Angle Gearbox assy	Boeing
65B81130-10	Angle Gearbox assy	Boeing
65B81130-2	Angle Gearbox assy	Boeing
65B81130-3	Angle Gearbox assy	Boeing
65B81130-4	Angle Gearbox assy	Boeing
65B81130-5	Angle Gearbox assy	Boeing
65B81130-6	Angle Gearbox assy	Boeing
65B81130-7	Angle Gearbox assy	Boeing
65B81130-8	Angle Gearbox assy	Boeing
65B81130-9	Angle Gearbox assy	Boeing
65B81131-10	Angle Gearbox assy	Boeing
65B81131-11	Angle Gearbox assy	Boeing
65B81131-12	Angle Gearbox assy	Boeing
65B81131-13	Angle Gearbox assy	Boeing
65B81131-14	Angle Gearbox assy	Boeing
65B81131-5	Angle Gearbox assy	Boeing
65B81131-6	Angle Gearbox assy	Boeing
65B81131-7	Angle Gearbox assy	Boeing
65B81131-8	Angle Gearbox assy	Boeing
65B81131-9	Angle Gearbox assy	Boeing
65B81132-1	PDU Gearbox assy	Boeing
65B81132-2	PDU Gearbox assy	Boeing
65B81132-3	PDU Gearbox assy	Boeing
65B81132-4	PDU Gearbox assy	Boeing
65B81132-5	PDU Gearbox assy	Boeing
65B81133-1	PDU Gearbox assy	Boeing
65B81133-2	PDU Gearbox assy	Boeing
65B81133-3	PDU Gearbox assy	Boeing
65B81133-4	PDU Gearbox assy	Boeing
65B81133-5	PDU Gearbox assy	Boeing
65B81276-2	Drive Unit	Boeing
65B81277-10	Drive Unit	Boeing
65B81277-3	Drive Unit	Boeing
65B81277-4	Drive Unit	Boeing
65B81277-5	Drive Unit	Boeing
65B81277-6	Drive Unit	Boeing
65B81277-7	Drive Unit	Boeing
65B81277-8	Drive Unit	Boeing
65B81277-9	Drive Unit	Boeing
65B81562-8	TE Flap Drive	Boeing
65B81562-9	TE Flap Drive	Boeing
65B81563-1	TE Flap Drive	Boeing
65B81563-11	Torque Tube	Boeing
65B81563-12	Torque Tube	Boeing
65B81563-13	Torque Tube	Boeing
65B81563-14	Torque Tube	Boeing
65B81563-2	TE Flap Drive	Boeing

Repair_Capability_List_Excel

65B81563-7	Torque Tube	Boeing
65B81563-8	Torque Tube	Boeing
65B81573-100	Shaft Assembly	Boeing
65B81573-103	Shaft Assembly	Boeing
65B81573-105	Shaft Assembly	Boeing
65B81573-107	Shaft Assembly	Boeing
65B81573-108	Shaft Assembly	Boeing
65B81573-109	Shaft Assembly	Boeing
65B81573-110	Shaft Assembly	Boeing
65B81573-111	Shaft Assembly	Boeing
65B81573-13	Shaft Assembly	Boeing
65B81573-14	Shaft Assembly	Boeing
65B81573-2	Shaft Assembly	Boeing
65B81573-3	Shaft Assembly	Boeing
65B81573-33	Shaft Assembly	Boeing
65B81573-34	Shaft Assembly	Boeing
65B81573-39	Shaft Assembly	Boeing
65B81573-40	Shaft Assembly	Boeing
65B81573-41	Shaft Assembly	Boeing
65B81573-42	Shaft Assembly	Boeing
65B81573-43	Shaft Assembly	Boeing
65B81573-44	Shaft Assembly	Boeing
65B81573-45	Shaft Assembly	Boeing
65B81573-46	Shaft Assembly	Boeing
65B81573-47	Shaft Assembly	Boeing
65B81573-5	Shaft Assembly	Boeing
65B81573-51	Shaft Assembly	Boeing
65B81573-52	Shaft Assembly	Boeing
65B81573-53	Shaft Assembly	Boeing
65B81573-58	Shaft Assembly	Boeing
65B81573-59	Shaft Assembly	Boeing
65B81573-60	Shaft Assembly	Boeing
65B81573-61	Shaft Assembly	Boeing
65B81573-62	Shaft Assembly	Boeing
65B81573-63	Shaft Assembly	Boeing
65B81573-64	Shaft Assembly	Boeing
65B81573-65	Shaft Assembly	Boeing
65B81573-66	Shaft Assembly	Boeing
65B81573-69	Shaft Assembly	Boeing
65B81573-7	Shaft Assembly	Boeing
65B81573-70	Shaft Assembly	Boeing
65B81573-75	Shaft Assembly	Boeing
65B81573-76	Shaft Assembly	Boeing
65B81573-77	Shaft Assembly	Boeing
65B81573-78	Shaft Assembly	Boeing
65B81573-8	Shaft Assembly	Boeing
65B81573-82	Shaft Assembly	Boeing
65B81573-83	Shaft Assembly	Boeing
65B81573-84	Shaft Assembly	Boeing
65B81573-85	Shaft Assembly	Boeing
65B81573-86	Shaft Assembly	Boeing
65B81573-87	Shaft Assembly	Boeing
65B81573-88	Shaft Assembly	Boeing
65B81573-89	Shaft Assembly	Boeing
65B81573-9	Shaft Assembly	Boeing
65B81573-90	Shaft Assembly	Boeing
65B81573-91	Shaft Assembly	Boeing
65B81573-92	Shaft Assembly	Boeing

Repair_Capability_List_Excel

65B81573-93	Shaft Assembly	Boeing
65B81573-94	Shaft Assembly	Boeing
65B81573-95	Shaft Assembly	Boeing
65B81573-98	Shaft Assembly	Boeing
65B81667-10	Control assy	Boeing
65B81667-11	Control assy	Boeing
65B81667-12	Control assy	Boeing
65B81667-15	Control assy	Boeing
65B81667-16	Control assy	Boeing
65B81667-17	Control assy	Boeing
65B81667-18	Control assy	Boeing
65B81667-19	Control assy	Boeing
65B81667-21	Control assy	Boeing
65B81667-22	Control assy	Boeing
65B81667-23	Control assy	Boeing
65B81667-24	Control assy	Boeing
65B81667-26	Control assy	Boeing
65B81667-33	Control assy	Boeing
65B81667-34	Control assy	Boeing
65B81667-35	Control assy	Boeing
65B81667-37	Control assy	Boeing
65B81667-38	Control assy	Boeing
65B81667-39	Control assy	Boeing
65B81667-40	Control assy	Boeing
65B81667-41	Control assy	Boeing
65B81667-42	Control assy	Boeing
65B81667-43	Control assy	Boeing
65B81667-44	Control assy	Boeing
65B81667-45	Control assy	Boeing
65B81667-46	Control assy	Boeing
65B81667-47	Control assy	Boeing
65B81667-48	Control assy	Boeing
65B81667-49	Control assy	Boeing
65B81667-50	Control assy	Boeing
65B81667-52	Control assy	Boeing
65B81667-9	Control assy	Boeing
65B81875-1	Feel Actuator Cylinder	Boeing
65B81875-2	Feel Actuator Cylinder	Boeing
65B82234-1	Differential	Boeing
65B82234-14	Differential	Boeing
65B82234-15	Differential	Boeing
65B82234-2	Differential	Boeing
65B82234-3	Differential	Boeing
65B82234-4	Differential	Boeing
65B82558-1	Actuator	Boeing
65B82558-10	Actuator	Boeing
65B82558-2	Actuator	Boeing
65B82558-3	Actuator	Boeing
65B82558-4	Actuator	Boeing
65B82558-5	Actuator	Boeing
65B82558-6	Actuator	Boeing
65B82558-7	Actuator	Boeing
65B82558-8	Actuator	Boeing
65B82558-9	Actuator	Boeing
65B82562-1	Torque Tube	Boeing
65B82562-2	Torque Tube	Boeing
65B82562-3	Torque Tube	Boeing
65B82578-1	Brake Valve	Boeing

Repair_Capability_List_Excel

65B82578-2	Brake Valve	Boeing
65B82584-2	NLG Actuator	Boeing
65B82584-3	NLG Actuator	Boeing
65B82584-5	NLG Actuator	Boeing
65B82584-6	NLG Actuator	Boeing
65B82585-1	NLG Actuator	Boeing
65B82585-2	NLG Actuator	Boeing
65B82585-3	NLG Actuator	Boeing
65B82585-4	NLG Actuator	Boeing
65B82591-1	Steering Actuator	Boeing
65B82591-2	Steering Actuator	Boeing
65B82693-2	Drive Unit	Boeing
65B82693-3	Drive Unit	Boeing
65B82693-4	Drive Unit	Boeing
65B82693-5	Drive Unit	Boeing
65B82693-6	Drive Unit	Boeing
65B82749-3	Compensator	Boeing
65B82749-4	Compensator	Boeing
65B82749-5	Compensator	Boeing
65B82986-1	Gearbox assy	Boeing
65B82986-2	Gearbox assy	Boeing
65B83205-10	MLG Actuator	Boeing
65B83205-13	MLG Actuator	Boeing
65B83205-14	MLG Actuator	Boeing
65B83205-19	MLG Actuator	Boeing
65B83205-20	MLG Actuator	Boeing
65B83205-23	MLG Actuator	Boeing
65B83205-24	MLG Actuator	Boeing
65B83205-3	MLG Actuator	Boeing
65B83205-5	MLG Actuator	Boeing
65B83205-6	MLG Actuator	Boeing
65B83205-7	MLG Actuator	Boeing
65B83205-8	MLG Actuator	Boeing
65B83205-9	MLG Actuator	Boeing
65B83258-3	Housing assy	Boeing
65B83258-6	Housing assy	Boeing
65B83258-7	Housing assy	Boeing
65B83258-8	Housing assy	Boeing
65B83285-1	Actuator	Boeing
65B83287-1	Actuator	Boeing
65B83435-1	Actuator	Boeing
65B83637-1	Gearbox assy	Boeing
65B83637-2	Gearbox assy	Boeing
65B83637-3	Gearbox assy	Boeing
65B83637-4	Side Cargo Door Manual Drive Gearbox	Boeing
65B83637-6	Side Cargo Door Manual Drive Gearbox	Boeing
65B83644-13	Gearbox & Brake	Boeing
65B83644-14	Gearbox & Brake	Boeing
65B83644-15	Gearbox & Brake	Boeing
65B83644-16	Gearbox & Brake	Boeing
65B83644-3	Gearbox & Brake	Boeing
65B83644-4	Gearbox & Brake	Boeing
65B83644-5	Gearbox & Brake	Boeing
65B83644-6	Gearbox & Brake	Boeing
65B83644-7	Gearbox & Brake	Boeing
65B83644-8	Gearbox & Brake	Boeing
65B83644-9	Gearbox & Brake	Boeing
65B83664-3	Control assy	Boeing

Repair_Capability_List_Excel

65B83664-4	Control assy	Boeing
65B83664-5	Control assy	Boeing
65B83664-6	Control assy	Boeing
65B83664-7	Control assy	Boeing
65B83664-8	Control assy	Boeing
65B83864-3	Gearbox assy	Boeing
65B83864-4	Gearbox assy	Boeing
65B83864-5	Gearbox assy	Boeing
65B83865-1	Gearbox assy	Boeing
65B83865-2	Gearbox assy	Boeing
65B83865-3	Gearbox assy	Boeing
65B83866-2	Gearbox assy	Boeing
65B83866-3	Gearbox assy	Boeing
65B83866-4	Gearbox assy	Boeing
65B83879-2	Torque Limiter	Boeing
65B83879-3	Torque Limiter	Boeing
65B83881-1	Shaft Assembly	Boeing
65B83881-10	Shaft Assembly	Boeing
65B83881-11	Shaft Assembly	Boeing
65B83881-12	Shaft Assembly	Boeing
65B83881-13	Shaft Assembly	Boeing
65B83881-14	Shaft Assembly	Boeing
65B83881-15	Shaft Assembly	Boeing
65B83881-16	Shaft Assembly	Boeing
65B83881-17	Shaft Assembly	Boeing
65B83881-18	Shaft Assembly	Boeing
65B83881-19	Shaft Assembly	Boeing
65B83881-2	Shaft Assembly	Boeing
65B83881-21	Shaft Assembly	Boeing
65B83881-22	Shaft Assembly	Boeing
65B83881-23	Shaft Assembly	Boeing
65B83881-26	Shaft Assembly	Boeing
65B83881-27	Shaft Assembly	Boeing
65B83881-28	Shaft Assembly	Boeing
65B83881-3	Shaft Assembly	Boeing
65B83881-4	Shaft Assembly	Boeing
65B83881-5	Shaft Assembly	Boeing
65B83881-6	Shaft Assembly	Boeing
65B83881-7	Shaft Assembly	Boeing
65B83881-8	Shaft Assembly	Boeing
65B83881-9	Shaft Assembly	Boeing
65B84780-3	Retracting Power Drive Unit ay	Goodrich
65B84780-4	Retracting Power Drive Unit ay	Goodrich
65B84780-7	Retracting Power Drive Unit ay	Goodrich
65B84780-9	Retracting Power Drive Unit ay	Goodrich
65B84816-2	Brake assy	Boeing
65B88781-1	Actuator	Boeing
65B88802-2	Screwjack	Boeing
65B88803-1	Gearbox assy	Boeing
65B88818-1	Drive assy	Boeing
65B88833-1	Drive assy	Boeing
65BE0914-1	Accessory Box	Boeing
65C10321-1	Modified Passenger Service Unit	Boeing
65C10321-2	Modified Passenger Service Unit	Boeing
65C10321-21	Modified Passenger Service Unit	Boeing
65C10321-23	Modified Passenger Service Unit	Boeing
65C10321-27	Modified Passenger Service Unit	Boeing
65C10321-28	Modified Passenger Service Unit	Boeing

Repair_Capability_List_Excel

65C10321-3	Modified Passenger Service Unit	Boeing
65C10321-32	Modified Passenger Service Unit	Boeing
65C10321-33	Modified Passenger Service Unit	Boeing
65C10321-34	Modified Passenger Service Unit	Boeing
65C10321-35	Modified Passenger Service Unit	Boeing
65C10321-36	Modified Passenger Service Unit	Boeing
65C10321-42	Modified Passenger Service Unit	Boeing
65C10321-44	Modified Passenger Service Unit	Boeing
65C10321-45	Modified Passenger Service Unit	Boeing
65C10321-46	Modified Passenger Service Unit	Boeing
65C10321-47	Modified Passenger Service Unit	Boeing
65C10321-51	Modified Passenger Service Unit	Boeing
65C10321-53	Modified Passenger Service Unit	Boeing
65C10321-54	Modified Passenger Service Unit	Boeing
65C10321-55	Modified Passenger Service Unit	Boeing
65C10321-59	Modified Passenger Service Unit	Boeing
65C10585-1	Oxygen Drop Service Unit	Boeing
65C10585-17	Oxygen Drop Service Unit	Boeing
65C10585-28	Oxygen Drop Service Unit	Boeing
65C10585-29	Oxygen Drop Service Unit	Boeing
65C10585-30	Oxygen Drop Service Unit	Boeing
65C10590-1	Partial Sect. Passenger Service Unit	Boeing
65C10590-4	Partial Sect. Passenger Service Unit	Boeing
65C10590-5	Partial Sect. Passenger Service Unit	Boeing
65C10590-6	Partial Sect. Passenger Service Unit	Boeing
65C12930-12	Audio/Communications Accessory Unit	Boeing
65C12930-17	Audio/Communications Accessory Unit	Boeing
65C12930-19	Audio/Communications Accessory Unit	Boeing
65C12930-21	Audio/Communications Accessory Unit	Boeing
65C12930-23	Audio/Communications Accessory Unit	Boeing
65C12930-24	Audio/Communications Accessory Unit	Boeing
65C12930-26	Audio/Communications Accessory Unit	Boeing
65C12930-28	Audio/Communications Accessory Unit	Boeing
65C12930-30	Audio/Communications Accessory Unit	Boeing
65C12930-31	Audio/Communications Accessory Unit	Boeing
65C12930-33	Audio/Communications Accessory Unit	Boeing
65C12930-35	Audio/Communications Accessory Unit	Boeing
65C12933-1	Aut.Perform. Reserve Accessory Unit	Boeing
65C12933-3	Aut.Perform. Reserve Accessory Unit	Boeing
65C12933-4	Aut.Perform. Reserve Accessory Unit	Boeing
65C14098-11	Autothrottle Clutch and Cam	Boeing
65C14098-12	Autothrottle Clutch and Cam	Boeing
65C14098-13	Autothrottle Clutch and Cam	Boeing
65C14098-15	Autothrottle Clutch and Cam	Boeing
65C14098-16	Autothrottle Clutch and Cam	Boeing
65C14098-17	Autothrottle Clutch and Cam	Boeing
65C16228-11	Ball Screw assy	Boeing
65C16228-15	Transmission B/S assy	Boeing
65C16228-16	Transmission B/S assy	Boeing
65C16228-3	Transmission B/S assy	Boeing
65C16228-4	Transmission B/S assy	Boeing
65C16245-7	Actuator	Boeing
65C16300-1	Spoiler Actuator	Boeing
65C16300-2	Spoiler Actuator	Boeing
65C16839-1	Carry All Passenger Service Unit	Boeing
65C16839-10	Carry All Passenger Service Unit	Boeing
65C16839-100	Carry All Passenger Service Unit	Boeing
65C16839-105	Carry All Passenger Service Unit	Boeing

Repair_Capability_List_Excel

65C16839-303	Carry All Passenger Service Unit	Boeing
65C16839-304	Carry All Passenger Service Unit	Boeing
65C16839-305	Carry All Passenger Service Unit	Boeing
65C16839-306	Carry All Passenger Service Unit	Boeing
65C16839-307	Carry All Passenger Service Unit	Boeing
65C16839-31	Carry All Passenger Service Unit	Boeing
65C16839-32	Carry All Passenger Service Unit	Boeing
65C16839-33	Carry All Passenger Service Unit	Boeing
65C16839-34	Carry All Passenger Service Unit	Boeing
65C16839-35	Carry All Passenger Service Unit	Boeing
65C16839-36	Carry All Passenger Service Unit	Boeing
65C16839-39	Carry All Passenger Service Unit	Boeing
65C16839-4	Carry All Passenger Service Unit	Boeing
65C16839-40	Carry All Passenger Service Unit	Boeing
65C16839-41	Carry All Passenger Service Unit	Boeing
65C16839-42	Carry All Passenger Service Unit	Boeing
65C16839-43	Carry All Passenger Service Unit	Boeing
65C16839-44	Carry All Passenger Service Unit	Boeing
65C16839-45	Carry All Passenger Service Unit	Boeing
65C16839-46	Carry All Passenger Service Unit	Boeing
65C16839-47	Carry All Passenger Service Unit	Boeing
65C16839-48	Carry All Passenger Service Unit	Boeing
65C16839-49	Carry All Passenger Service Unit	Boeing
65C16839-5	Carry All Passenger Service Unit	Boeing
65C16839-50	Carry All Passenger Service Unit	Boeing
65C16839-51	Carry All Passenger Service Unit	Boeing
65C16839-52	Carry All Passenger Service Unit	Boeing
65C16839-6	Carry All Passenger Service Unit	Boeing
65C16839-61	Carry All Passenger Service Unit	Boeing
65C16839-62	Carry All Passenger Service Unit	Boeing
65C16839-7	Carry All Passenger Service Unit	Boeing
65C16839-8	Carry All Passenger Service Unit	Boeing
65C16839-85	Carry All Passenger Service Unit	Boeing
65C16839-86	Carry All Passenger Service Unit	Boeing
65C16839-9	Carry All Passenger Service Unit	Boeing
65C16839-95	Carry All Passenger Service Unit	Boeing
65C18257-101	Control Stand Thrust Handle	Boeing
65C18257-102	Control Stand Thrust Handle	Boeing
65C18257-103	Control Stand Thrust Handle	Boeing
65C18257-109	Control Stand Thrust Handle	Boeing
65C18257-11	Control Stand Thrust Handle	Boeing
65C18257-110	Control Stand Thrust Handle	Boeing
65C18257-111	Control Stand Thrust Handle	Boeing
65C18257-112	Control Stand Thrust Handle	Boeing
65C18257-113	Control Stand Thrust Handle	Boeing
65C18257-114	Control Stand Thrust Handle	Boeing
65C18257-115	Control Stand Thrust Handle	Boeing
65C18257-116	Control Stand Thrust Handle	Boeing
65C18257-118	Control Stand Thrust Handle	Boeing
65C18257-12	Control Stand Thrust Handle	Boeing
65C18257-122	Control Stand Thrust Handle	Boeing
65C18257-123	Control Stand Thrust Handle	Boeing
65C18257-124	Control Stand Thrust Handle	Boeing
65C18257-125	Control Stand Thrust Handle	Boeing
65C18257-126	Control Stand Thrust Handle	Boeing
65C18257-129	Control Stand Thrust Handle	Boeing
65C18257-13	Control Stand Thrust Handle	Boeing
65C18257-130	Control Stand Thrust Handle	Boeing

Repair_Capability_List_Excel

65C18257-66	Control Stand Thrust Handle	Boeing
65C18257-67	Control Stand Thrust Handle	Boeing
65C18257-68	Control Stand Thrust Handle	Boeing
65C18257-69	Control Stand Thrust Handle	Boeing
65C18257-7	Control Stand Thrust Handle	Boeing
65C18257-70	Control Stand Thrust Handle	Boeing
65C18257-71	Control Stand Thrust Handle	Boeing
65C18257-72	Control Stand Thrust Handle	Boeing
65C18257-73	Control Stand Thrust Handle	Boeing
65C18257-74	Control Stand Thrust Handle	Boeing
65C18257-75	Control Stand Thrust Handle	Boeing
65C18257-76	Control Stand Thrust Handle	Boeing
65C18257-77	Control Stand Thrust Handle	Boeing
65C18257-78	Control Stand Thrust Handle	Boeing
65C18257-79	Control Stand Thrust Handle	Boeing
65C18257-8	Control Stand Thrust Handle	Boeing
65C18257-91	Control Stand Thrust Handle	Boeing
65C18257-92	Control Stand Thrust Handle	Boeing
65C20204-21	Two-Link Articulated Hinge	Boeing
65C20204-22	Two-Link Articulated Hinge	Boeing
65C20204-23	Two-Link Articulated Hinge	Boeing
65C20204-24	Two-Link Articulated Hinge	Boeing
65C20204-25	Two-Link Articulated Hinge	Boeing
65C20204-26	Two-Link Articulated Hinge	Boeing
65C20204-27	Two-Link Articulated Hinge	Boeing
65C20204-28	Two-Link Articulated Hinge	Boeing
65C21854-2	Aural Warning Box	Boeing
65C22117-4	Control Stand Thrust Handle	Boeing
65C22117-5	Control Stand Thrust Handle	Boeing
65C25410-1	Rudder Controls Centering Unit	Boeing
65C25410-2	Rudder Controls Centering Unit	Boeing
65C25410-4	Rudder Controls Centering Unit	Boeing
65C25410-5	Rudder Controls Centering Unit	Boeing
65C25410-6	Rudder Controls Centering Unit	Boeing
65C25465-10	Elevator Control Feel & Centering Unit	Boeing
65C25465-11	Elevator Control Feel & Centering Unit	Boeing
65C25465-12	Elevator Control Feel & Centering Unit	Boeing
65C25465-15	Elevator Control Feel & Centering Unit	Boeing
65C25465-16	Elevator Control Feel & Centering Unit	Boeing
65C25465-17	Elevator Control Feel & Centering Unit	Boeing
65C25465-2	Elevator Control Feel & Centering Unit	Boeing
65C25465-4	Elevator Control Feel & Centering Unit	Boeing
65C25465-8	Elevator Control Feel & Centering Unit	Boeing
65C25503-1	Control Stand Upper Mechanism	Boeing
65C25503-11	Control Stand Upper Mechanism	Boeing
65C25503-2	Control Stand Upper Mechanism	Boeing
65C25503-3	Control Stand Upper Mechanism	Boeing
65C25529-11	Stab.Trim Ctrl Column Actuated Switch	Boeing
65C25529-12	Stab.Trim Ctrl Column Actuated Switch	Boeing
65C25529-15	Stab.Trim Ctrl Column Actuated Switch	Boeing
65C25529-16	Stab.Trim Ctrl Column Actuated Switch	Boeing
65C25529-19	Stab.Trim Ctrl Column Actuated Switch	Boeing
65C25529-21	Stab.Trim Ctrl Column Actuated Switch	Boeing
65C25529-22	Stab.Trim Ctrl Column Actuated Switch	Boeing
65C25529-23	Stab.Trim Ctrl Column Actuated Switch	Boeing
65C25529-24	Stab.Trim Ctrl Column Actuated Switch	Boeing
65C25529-25	Stab.Trim Ctrl Column Actuated Switch	Boeing
65C25529-26	Stab.Trim Ctrl Column Actuated Switch	Boeing

Repair_Capability_List_Excel

65C26320-32 SP	Outboard Wing Trailing Edge Midflap	Boeing
65C26320-33 SP	Outboard Wing Trailing Edge Midflap	Boeing
65C26320-34 SP	Outboard Wing Trailing Edge Midflap	Boeing
65C26320-4 SP	Outboard Wing Trailing Edge Midflap	Boeing
65C26320-5 SP	Outboard Wing Trailing Edge Midflap	Boeing
65C26320-6 SP	Outboard Wing Trailing Edge Midflap	Boeing
65C26320-7 SP	Outboard Wing Trailing Edge Midflap	Boeing
65C26320-8 SP	Outboard Wing Trailing Edge Midflap	Boeing
65C26343-1	Carriage assy	Boeing
65C26343-10	Carriage assy	Boeing
65C26343-11	Carriage assy	Boeing
65C26343-12	Carriage assy	Boeing
65C26343-13	Carriage assy	Boeing
65C26343-14	Carriage assy	Boeing
65C26343-15	Carriage assy	Boeing
65C26343-16	Carriage assy	Boeing
65C26343-17	Carriage assy	Boeing
65C26343-18	Carriage assy	Boeing
65C26343-2	Carriage assy	Boeing
65C26343-3	Carriage assy	Boeing
65C26343-4	Carriage assy	Boeing
65C26343-5	Carriage assy	Boeing
65C26343-6	Carriage assy	Boeing
65C26343-9	Carriage assy	Boeing
65C26816-2	Isol. Valve & Alt.Brake Select.Valve	Boeing
65C26816-3	Isol. Valve & Alt.Brake Select.Valve	Boeing
65C26816-4	Isol. Valve & Alt.Brake Select.Valve	Boeing
65C26816-5	Isol. Valve & Alt.Brake Select.Valve	Boeing
65C26816-6	Isol. Valve & Alt.Brake Select.Valve	Boeing
65C26816-7	Isol. Valve & Alt.Brake Select.Valve	Boeing
65C26816-8	Isol. Valve & Alt.Brake Select.Valve	Boeing
65C26816-9	Isol. Valve & Alt.Brake Select.Valve	Boeing
65C26833-2	Steering Depressurization Valve	Boeing
65C26833-3	Steering Depressurization Valve	Boeing
65C26859-1	Brake Feel Actuator	Boeing
65C26860-10	System B Hydraulic Reservoir	Boeing
65C26860-11	System B Hydraulic Reservoir	Boeing
65C26860-12	System B Hydraulic Reservoir	Boeing
65C26860-13	System B Hydraulic Reservoir	Boeing
65C26860-14	System B Hydraulic Reservoir	Boeing
65C26860-15	System B Hydraulic Reservoir	Boeing
65C26860-4	System B Hydraulic Reservoir	Boeing
65C26860-5	System B Hydraulic Reservoir	Boeing
65C26860-7	System B Hydraulic Reservoir	Boeing
65C26860-9	System B Hydraulic Reservoir	Boeing
65C26861-10	System B Hydraulic Reservoir	Boeing
65C26861-11	System B Hydraulic Reservoir	Boeing
65C26861-7	System B Hydraulic Reservoir	Boeing
65C26861-9	System B Hydraulic Reservoir	Boeing
65C26864-1	Outboard Ground Spoiler Actuator	Boeing
65C26864-2	Outboard Ground Spoiler Actuator	Boeing
65C26864-3	Outboard Ground Spoiler Actuator	Boeing
65C26869-2	Auto Slat Control Valve	Boeing
65C26870-3	Auto Slat Control Valve	Boeing
65C26873-3	Hydraulic Modular Package	Boeing
65C26873-4	Hydraulic Modular Package	Boeing
65C26873-5	Hydraulic Modular Package	Boeing
65C26885-5	Steering Depressurization Valve	Boeing

Repair_Capability_List_Excel

65C26885-6	Steering Depressurization Valve	Boeing
65C27298-5	LE & TE Flaps Control	Boeing
65C27298-6	LE & TE Flaps Control	Boeing
65C27298-7	LE & TE Flaps Control	Boeing
65C27360-1	Nose Minor Components	Boeing
65C27360-11	Nose Minor Components	Boeing
65C27360-12	Nose Minor Components	Boeing
65C27360-5	Nose Minor Components	Boeing
65C27360-7	Nose Minor Components	Boeing
65C27360-9	Nose Minor Components	Boeing
65C27383-13 SP	Attendant's Service Unit	Boeing
65C27383-14 SP	Attendant's Service Unit	Boeing
65C27383-15 SP	Attendant's Service Unit	Boeing
65C27383-16 SP	Attendant's Service Unit	Boeing
65C27383-17 SP	Attendant's Service Unit	Boeing
65C27383-23 SP	Attendant's Service Unit	Boeing
65C27383-28 SP	Attendant's Service Unit	Boeing
65C27383-29 SP	Attendant's Service Unit	Boeing
65C27383-3 SP	Attendant's Service Unit	Boeing
65C27383-34 SP	Attendant's Service Unit	Boeing
65C27383-38 SP	Attendant's Service Unit	Boeing
65C27383-39 SP	Attendant's Service Unit	Boeing
65C27383-40 SP	Attendant's Service Unit	Boeing
65C27383-43 SP	Attendant's Service Unit	Boeing
65C27383-44 SP	Attendant's Service Unit	Boeing
65C27501-1	Trailing Edge Flap Drive	Boeing
65C27501-2	Trailing Edge Flap Drive	Boeing
65C27501-3	Trailing Edge Flap Drive	Boeing
65C27502-3	Trailing Edge Flap Drive	Boeing
65C27502-4	Trailing Edge Flap Drive	Boeing
65C27502-5	Trailing Edge Flap Drive	Boeing
65C27503-1	Trailing Edge Flap Drive	Boeing
65C27503-2	Trailing Edge Flap Drive	Boeing
65C27503-3	Trailing Edge Flap Drive	Boeing
65C27506-1	Trailing Edge Flap Drive	Boeing
65C27506-2	Trailing Edge Flap Drive	Boeing
65C27506-3	Trailing Edge Flap Drive	Boeing
65C27507-1	Transmission assy	Curtiss-Wright
65C27507-3	Trailing Edge Flap Drive	Boeing
65C27507-4	Trailing Edge Flap Drive	Boeing
65C27507-8	Trailing Edge Flap Drive	Boeing
65C27508-1	Trailing Edge Flap Drive	Boeing
65C27508-2	Trailing Edge Flap Drive	Boeing
65C27508-3	Trailing Edge Flap Drive	Boeing
65C28167-15	Main Gear Outboard Door	Boeing
65C28167-16	Main Gear Outboard Door	Boeing
65C28176-10	Main Landing Gear Center Door	Boeing
65C28176-11	Main Landing Gear Center Door	Boeing
65C28176-12	Main Landing Gear Center Door	Boeing
65C28176-13	Main Landing Gear Center Door	Boeing
65C28176-14	Main Landing Gear Center Door	Boeing
65C28176-7	Main Landing Gear Center Door	Boeing
65C28176-8	Main Landing Gear Center Door	Boeing
65C28176-9	Main Landing Gear Center Door	Boeing
65C28178-19	Main Landing Gear Inner Door	Boeing
65C28178-20	Main Landing Gear Inner Door	Boeing
65C28178-29	Main Landing Gear Inner Door	Boeing
65C28178-30	Main Landing Gear Inner Door	Boeing

Repair_Capability_List_Excel

65C30846-1	Bellcrank assy	Boeing
65C30846-10	Bellcrank assy	Boeing
65C30846-11	Bellcrank assy	Boeing
65C30846-12	Bellcrank assy	Boeing
65C30846-13	Bellcrank assy	Boeing
65C30846-14	Bellcrank assy	Boeing
65C30846-15	Bellcrank assy	Boeing
65C30846-16	Bellcrank assy	Boeing
65C30846-17	Bellcrank assy	Boeing
65C30846-18	Bellcrank assy	Boeing
65C30846-2	Bellcrank assy	Boeing
65C30846-21	Bellcrank assy	Boeing
65C30846-22	Bellcrank assy	Boeing
65C30846-23	Bellcrank assy	Boeing
65C30846-24	Bellcrank assy	Boeing
65C30846-3	Bellcrank assy	Boeing
65C30846-4	Bellcrank assy	Boeing
65C30846-7	Bellcrank assy	Boeing
65C30846-8	Bellcrank assy	Boeing
65C30846-9	Bellcrank assy	Boeing
65C30878-1	Elevator Tab Ctrl Gearing Mech.Crank	Boeing
65C31099-1	Nose Gear Lock Actuator	Boeing
65C31332-1	Main Gear Minor Components	Boeing
65C31332-2	Main Gear Minor Components	Boeing
65C31332-3	Main Gear Minor Components	Boeing
65C31332-4	Main Gear Minor Components	Boeing
65C31332-5	Main Gear Minor Components	Boeing
65C31332-6	Main Gear Minor Components	Boeing
65C31503-1	Control Stand Upper Mechanism	Boeing
65C31503-14	Control Stand Upper Mechanism	Boeing
65C31503-18	Control Stand Upper Mechanism	Boeing
65C31503-19	Control Stand Upper Mechanism	Boeing
65C31503-20	Control Stand Upper Mechanism	Boeing
65C31503-21	Control Stand Upper Mechanism	Boeing
65C31503-22	Control Stand Upper Mechanism	Boeing
65C31503-23	Control Stand Upper Mechanism	Boeing
65C31503-26	Control Stand Upper Mechanism	Boeing
65C31503-27	Control Stand Upper Mechanism	Boeing
65C31503-28	Control Stand Upper Mechanism	Boeing
65C31503-29	Control Stand Upper Mechanism	Boeing
65C31503-30	Control Stand Upper Mechanism	Boeing
65C31503-31	Control Stand Upper Mechanism	Boeing
65C31503-32	Control Stand Upper Mechanism	Boeing
65C32649-1	Main Gear Minor Components	Boeing
65C32649-2	Main Gear Minor Components	Boeing
65C32649-3	Main Gear Minor Components	Boeing
65C32649-4	Main Gear Minor Components	Boeing
65C32649-5	Main Gear Minor Components	Boeing
65C32956-1	Main Landing Gear Retract Actuator	Boeing
65C32956-3	Main Landing Gear Retract Actuator	Boeing
65C32956-4	Main Landing Gear Retract Actuator	Boeing
65C32956-6	Main Landing Gear Retract Actuator	Boeing
65C33219-1	Main Landing Gear Center Door	Boeing
65C33219-2	Main Landing Gear Center Door	Boeing
65C33219-7	Main Landing Gear Center Door	Boeing
65C33219-8	Main Landing Gear Center Door	Boeing
65C33221-1	Main Gear Outboard Door	Boeing
65C33221-2	Main Gear Outboard Door	Boeing

Repair_Capability_List_Excel

65C33409-1	Dimming Relay Module	Boeing
65C33730-1	Main Gear Outboard Door	Boeing
65C33730-10	Main Gear Outboard Door	Boeing
65C33730-2	Main Gear Outboard Door	Boeing
65C33730-5	Main Gear Outboard Door	Boeing
65C33730-6	Main Gear Outboard Door	Boeing
65C33730-9	Main Gear Outboard Door	Boeing
65C34015-1	Outb.Flap Sequencing Carriage & Toggle	Boeing
65C34015-3	Outb.Flap Sequencing Carriage & Toggle	Boeing
65C34314-1	Outb.Flap Sequencing Carriage & Toggle	Boeing
65C34314-3	Outb.Flap Sequencing Carriage & Toggle	Boeing
65C34483-5	Carriage assy	Boeing
65C34483-6	Carriage assy	Boeing
65C34483-7	Carriage assy	Boeing
65C34483-8	Carriage assy	Boeing
65C34751-10	Stabilizer Trim Actuator	Boeing
65C34751-11	Stabilizer Trim Actuator	Boeing
65C34751-2	Stabilizer Trim Actuator	Boeing
65C34751-3	Stabilizer Trim Actuator	Boeing
65C34751-4	Stabilizer Trim Actuator	Boeing
65C34751-5	Stabilizer Trim Actuator	Boeing
65C34751-6	Stabilizer Trim Actuator	Boeing
65C34751-7	Stabilizer Trim Actuator	Boeing
65C34751-8	Stabilizer Trim Actuator	Boeing
65C34751-9	Stabilizer Trim Actuator	Boeing
65C34782-1	Outb.Flap Sequencing Carriage & Toggle	Boeing
65C34782-3	Outb.Flap Sequencing Carriage & Toggle	Boeing
65C34812-2	Flap Track assy	Boeing
65C34812-3	Flap Track assy	Boeing
65C34812-4	Flap Track assy	Boeing
65C34812-5	Flap Track assy	Boeing
65C34812-6	Flap Track assy	Boeing
65C34812-7	Flap Track assy	Boeing
65C35000-3	Emergency Hatch	Boeing
65C35000-4	Emergency Hatch	Boeing
65C35276-1	Flap Track assy	Boeing
65C35276-2	Flap Track assy	Boeing
65C35322-1	VHF Nav/Dme Control Panel Module	Boeing
65C35615-2	Flap Track assy	Boeing
65C35616-5	Flap Track assy	Boeing
65C35617-3	Flap Track assy	Boeing
65C35617-4	Flap Track assy	Boeing
65C35758-16	Lock Actuator	Boeing
65C35758-29	Lock Actuator	Boeing
65C36408-10	Leading Edge Slat Hyd. Actuator	Boeing
65C36408-11	Leading Edge Slat Hyd. Actuator	Boeing
65C36408-12	Leading Edge Slat Hyd. Actuator	Boeing
65C36408-5	Leading Edge Slat Hyd. Actuator	Boeing
65C36408-7	Leading Edge Slat Hyd. Actuator	Boeing
65C36408-8	Leading Edge Slat Hyd. Actuator	Boeing
65C36486-10	Stabilizer Trim Actuator	Boeing
65C36486-11	Stabilizer Trim Actuator	Boeing
65C36486-12	Stabilizer Trim Actuator	Boeing
65C36486-13	Stabilizer Trim Actuator	Boeing
65C36486-3	Stabilizer Trim Actuator	Boeing
65C36486-5	Stabilizer Trim Actuator	Boeing
65C36486-7	Stabilizer Trim Actuator	Boeing
65C36486-9	Stabilizer Trim Actuator	Boeing

Repair_Capability_List_Excel

65C37030-1	Aileron Control Transfer Mechanism	Boeing
65C37030-2	Aileron Control Transfer Mechanism	Boeing
65C37030-3	Aileron Control Transfer Mechanism	Boeing
65C37052-10	Rudder Power Control Unit	Boeing
65C37052-2	Rudder Power Control Unit	Boeing
65C37052-3	Rudder Power Control Unit	Boeing
65C37052-4	Rudder Power Control Unit	Boeing
65C37052-5	Rudder Power Control Unit	Boeing
65C37052-6	Rudder Power Control Unit	Boeing
65C37052-7	Rudder Power Control Unit	Boeing
65C37052-8	Rudder Power Control Unit	Boeing
65C37052-9	Rudder Power Control Unit	Boeing
65C37053-10	Rudder Power Control Unit	Boeing
65C37053-2	Rudder Power Control Unit	Boeing
65C37053-3	Rudder Power Control Unit	Boeing
65C37053-4	Rudder Power Control Unit	Boeing
65C37053-5	Rudder Power Control Unit	Boeing
65C37053-6	Rudder Power Control Unit	Boeing
65C37053-7	Rudder Power Control Unit	Boeing
65C37053-8	Rudder Power Control Unit	Boeing
65C37053-9	Rudder Power Control Unit	Boeing
65C37270-10	Auto Flight Ctrl Syst.Floodlight Ctrl Mod.	Boeing
65C37349-1	Control Stand Thrust Handle	Boeing
65C37349-2	Control Stand Thrust Handle	Boeing
65C37456-11	Transmission B/S assy	Boeing
65C37456-12	Transmission B/S assy	Boeing
65C37456-7	Transmission B/S assy	Boeing
65C37456-8	Transmission B/S assy	Boeing
65C37520-11	Transmission assy	Boeing
65C37520-12	Transmission assy	Boeing
65C37520-13	Transmission assy	Boeing
65C37520-14	Transmission assy	Boeing
65C37520-15	Transmission assy	Boeing
65C37520-16	Transmission assy	Boeing
65C37520-17	Transmission assy	Boeing
65C37520-18	Transmission assy	Boeing
65C37520-19	Transmission assy	Boeing
65C37520-20	Transmission assy	Boeing
65C37520-21	Transmission assy	Boeing
65C37520-22	Transmission assy	Boeing
65C37520-23	Transmission assy	Boeing
65C37520-24	Transmission assy	Boeing
65C37520-25	Transmission assy	Boeing
65C37520-26	Transmission assy	Boeing
65C37520-27	Transmission assy	Boeing
65C37520-28	Transmission assy	Boeing
65C37520-29	Transmission assy	Boeing
65C37520-30	Transmission assy	Boeing
65C37520-33	Transmission assy	Boeing
65C37520-34	Transmission assy	Boeing
65C37520-35	Transmission assy	Boeing
65C37520-36	Transmission assy	Boeing
65C37520-37	Transmission assy	Boeing
65C37520-38	Transmission assy	Boeing
65C37520-39	Transmission assy	Boeing
65C37520-40	Transmission assy	Boeing
65C37520-41	Transmission assy	Boeing
65C37520-42	Transmission assy	Boeing

Repair_Capability_List_Excel

65C37520-43	Transmission assy	Boeing
65C37520-44	Transmission assy	Boeing
65C37520-45	Transmission assy	Boeing
65C37520-46	Transmission assy	Boeing
65C37520-47	Transmission assy	Boeing
65C37520-48	Transmission assy	Boeing
65C37520-49	Transmission assy	Boeing
65C37520-50	Transmission assy	Boeing
65C37520-9	Transmission assy	Boeing
65C38058-10	Slat Actuator	Boeing
65C38058-11	Slat Actuator	Boeing
65C38058-12	Slat Actuator	Boeing
65C38058-22	Slat Actuator	Boeing
65C38058-23	Slat Actuator	Boeing
65C38058-24	Slat Actuator	Boeing
65C38058-5	Slat Actuator	Boeing
65C38058-7	Slat Actuator	Boeing
65C38058-8	Slat Actuator	Boeing
65C38059-10	Slat Actuator	Boeing
65C38059-11	Slat Actuator	Boeing
65C38059-12	Slat Actuator	Boeing
65C38059-13	Slat Actuator	Boeing
65C38059-14	Slat Actuator	Boeing
65C38059-15	Slat Actuator	Boeing
65C38059-5	Slat Actuator	Boeing
65C38059-7	Slat Actuator	Boeing
65C38059-8	Slat Actuator	Boeing
65C80739-1	Toggle assy	Boeing
65V10153-1	Desk Light Passenger Service Unit	Boeing
65V10153-7	Desk Light Passenger Service Unit	Boeing
65V10605-11	Oxygen Service Unit	Boeing
65V10605-12	Oxygen Service Unit	Boeing
65V10605-13	Oxygen Service Unit	Boeing
65V10605-3	Oxygen Service Unit	Boeing
65V10605-4	Oxygen Service Unit	Boeing
65V10605-9	Oxygen Service Unit	Boeing
65V10687-20	Oxygen Mask Container	Boeing
65V10687-21	Oxygen Mask Container	Boeing
65V10687-22	Oxygen Mask Container	Boeing
65V10687-23	Oxygen Mask Container	Boeing
65V10687-24	Oxygen Mask Container	Boeing
65V10687-25	Oxygen Mask Container	Boeing
65V10687-26	Oxygen Mask Container	Boeing
65V10687-30	Oxygen Mask Container	Boeing
65V10687-31	Oxygen Mask Container	Boeing
65V10687-32	Oxygen Mask Container	Boeing
65V10687-33	Oxygen Mask Container	Boeing
65V10687-50	Oxygen Mask Container	Boeing
65V10687-60	Oxygen Mask Container	Boeing
65V10687-61	Oxygen Mask Container	Boeing
65V10695-101	Desk Light Passenger Service Unit	Boeing
65V10794-1	Passenger Service Unit	Boeing
65V10794-10	Partial Sect. Passenger Service Unit	Boeing
65V10794-11	Partial Sect. Passenger Service Unit	Boeing
65V10794-13	Passenger Service Unit	Boeing
65V10794-14	Passenger Service Unit	Boeing
65V10794-15	Passenger Service Unit	Boeing
65V10794-16	Passenger Service Unit	Boeing

Repair_Capability_List_Excel

65V10794-17	Partial Sect. Passenger Service Unit	Boeing
65V10794-18	Partial Sect. Passenger Service Unit	Boeing
65V10794-19	Passenger Service Unit	Boeing
65V10794-2	Passenger Service Unit	Boeing
65V10794-20	Passenger Service Unit	Boeing
65V10794-21	Passenger Service Unit	Boeing
65V10794-22	Passenger Service Unit	Boeing
65V10794-23	Partial Sect. Passenger Service Unit	Boeing
65V10794-24	Partial Sect. Passenger Service Unit	Boeing
65V10794-25	Passenger Service Unit	Boeing
65V10794-26	Passenger Service Unit	Boeing
65V10794-27	Passenger Service Unit	Boeing
65V10794-28	Passenger Service Unit	Boeing
65V10794-29	Partial Sect. Passenger Service Unit	Boeing
65V10794-3	Passenger Service Unit	Boeing
65V10794-30	Partial Sect. Passenger Service Unit	Boeing
65V10794-301	Partial Sect. Passenger Service Unit	Boeing
65V10794-302	Partial Sect. Passenger Service Unit	Boeing
65V10794-31	Passenger Service Unit	Boeing
65V10794-32	Passenger Service Unit	Boeing
65V10794-33	Partial Sect. Passenger Service Unit	Boeing
65V10794-34	Partial Sect. Passenger Service Unit	Boeing
65V10794-38	Partial Sect. Passenger Service Unit	Boeing
65V10794-4	Passenger Service Unit	Boeing
65V10794-401	Partial Sect. Passenger Service Unit	Boeing
65V10794-41	Passenger Service Unit	Boeing
65V10794-42	Passenger Service Unit	Boeing
65V10794-43	Passenger Service Unit	Boeing
65V10794-44	Passenger Service Unit	Boeing
65V10794-45	Passenger Service Unit	Boeing
65V10794-5	Passenger Service Unit	Boeing
65V10794-6	Passenger Service Unit	Boeing
65V10794-7	Passenger Service Unit	Boeing
65V10794-8	Passenger Service Unit	Boeing
65V10794-9	Partial Sect. Passenger Service Unit	Boeing
65V11529-1	Oxygen Service Container	Boeing
65V11529-12	Oxygen Service Container	Boeing
65V11529-14	Oxygen Service Container	Boeing
65V11529-16	Oxygen Service Container	Boeing
65V11529-18	Oxygen Service Container	Boeing
65V11529-2	Oxygen Service Container	Boeing
65V11529-6	Oxygen Service Container	Boeing
65V11529-7	Oxygen Service Container	Boeing
65V11529-9	Oxygen Service Container	Boeing
65V18297-101	Autothrottle Clutch and Cam	Boeing
65V18297-104	Autothrottle Clutch and Cam	Boeing
65V18297-105	Autothrottle Clutch and Cam	Boeing
65V18297-106	Autothrottle Clutch and Cam	Boeing
65V18297-107	Autothrottle Clutch and Cam	Boeing
65V18297-108	Autothrottle Clutch and Cam	Boeing
65V18297-201	Autothrottle Clutch and Cam	Boeing
65V18297-202	Autothrottle Clutch and Cam	Boeing
65V18297-203	Autothrottle Clutch and Cam	Boeing
65V18297-204	Autothrottle Clutch and Cam	Boeing
65V18297-205	Autothrottle Clutch and Cam	Boeing
65V18297-206	Autothrottle Clutch and Cam	Boeing
65V18297-211	Autothrottle Clutch and Cam	Boeing
65V18297-212	Autothrottle Clutch and Cam	Boeing

Repair_Capability_List_Excel

65V18297-213	Autothrottle Clutch and Cam	Boeing
65V18297-214	Autothrottle Clutch and Cam	Boeing
65V18297-215	Autothrottle Clutch and Cam	Boeing
65V18297-216	Autothrottle Clutch and Cam	Boeing
66030-5	Valve	Essex Industries
66068-05	AC Motor Pump	Parker Hannifin
66068-06	AC Motor Pump	Parker Hannifin
66068-07	Package Pump-Motor	Abex
66068-08	AC Motor Pump	Parker Hannifin
6607-1-69	Pressure Switch	Consolidated Controls
6607-1-87	Pressure Switch	Consolidated Controls
6607-1-87A	Pressure Switch	Consolidated Controls
660720222	Slip Ring assy	Dowty Aerospace
6607-2-105	Pressure Switch	Consolidated Controls
6607-3-151	Pressure Switch	Consolidated Controls
6607-3-153	Pressure Switch	Consolidated Controls
6607A1-12	Pressure Switch	Consolidated Controls
6607A1-73	Pressure Switch	Consolidated Controls
6607A2-125	Pressure Switch	Consolidated Controls
6607A2-125A	Pressure Switch	Consolidated Controls
6607A2-67	Pressure Switch	Consolidated Controls
6607A3-172	Pressure Switch	Consolidated Controls
6607A9-99	Pressure Switch	Consolidated Controls
6607P8-20	Pressure Switch	Consolidated Controls
6607P8-20A	Pressure Switch	Consolidated Controls
6607P8-20B	Pressure Switch	Consolidated Controls
6607P9-24C	Pressure Switch	Consolidated Controls
6607P9-8C	Pressure Switch	Consolidated Controls
6607P9-8D	Pressure Switch	Consolidated Controls
66087	Hydraulic Pump	Abex
6608M37	Signal Conditioner	Honeywell
6608M43	Signal Conditioner	Honeywell
6610-15945	Rotary Actuator	Nord-Micro
6610-15946	Rotary Actuator	Nord-Micro
6610-15946-2	Rotary Actuator	Nord-Micro
6610-18168	Rotary Actuator	Nord-Micro
6610-18205-1	Rotary Actuator	Nord-Micro
6610-18205-3	Rotary Actuator	Nord-Micro
6610-18205-4	Rotary Actuator	Nord-Micro
6610-18520	Rotary Actuator	Nord-Micro
6610-19480	Rotary Actuator	Nord-Micro
6610-19878-1	Rotary Actuator	Nord-Micro
6610-19878-2	Rotary Actuator	Nord-Micro
6610-20560-01	Rotary Actuator	Nord-Micro
6610-20567-01	Rotary Actuator	Nord-Micro
66198-01	Hydraulic Pump	Parker Hannifin
6-63931	Control Stand Stabilizer Trim Jack	Boeing
66432	A/C Motor	Parker Hannifin
66432-01	A/C Motor	Parker Hannifin
66432-02	A/C Motor	Parker Hannifin
66432-03	A/C Motor	Parker Hannifin
664D100-5	Cargo Door Lift Latch Actuator	Eaton
664D100-7	Cargo Door Lift Latch Actuator	Eaton
666000143	Propeller Electronic Controller	Dowty Aerospace
66790-1	Control Valve	Sterer-Vickers
667C0000-02	Solenoid Valve	Liebherr Aerotechnik
668CA01	Three-Pole Contactor	ECE
66950	Shut-Off Valve	Eaton Aerospace

Repair_Capability_List_Excel

669926-1	Gyrosyn Compass Indicator	Honeywell
669926-6	Gyrosyn Compass Indicator	Honeywell
66D44	Air Press Regulator	Grimes Aerospace
6700-300-80-10	AC Power Monitor	Thales Avionics
67-0033	AC Actuator	Grimes Aerospace
6700-400-80-11	DC Power Monitor	Thales Avionics
67030	Solenoid Operated Selector Valve	Sterer
670E010000	Valve assy	Liebherr Aerotechnik
6713C010000	Regulating Valve HP	Liebherr Aerospace
6713D020000	Regulating Valve HP	Liebherr Aerospace
6713D040000	Regulating Valve HP	Liebherr Aerospace
6713D040000 Amdt A	Regulating Valve HP	Liebherr Aerospace
6713D050000	Regulating Valve HP	Liebherr Aerospace
6713D060000	Regulating Valve HP	Liebherr Aerospace
6713D070000	Regulating Valve HP	Liebherr Aerospace
6714C010000	Bleed Pressure Valve	Liebherr Aerospace
6714D010000	Bleed Pressure Valve	Liebherr Aerospace
6714D020000	Bleed Pressure Valve	Liebherr Aerospace
6714D040000	Bleed Pressure Valve	Liebherr Aerospace
6714D050000	Bleed Pressure Valve	Liebherr Aerospace
6714D060000	Bleed Pressure Valve	Liebherr Aerospace
6714D060000 Amdt A	Bleed Pressure Valve	Liebherr Aerospace
671SE01	Three Pole Base Contactor	ECE
672160-105	Regulator	Honeywell
67-2905-001	Valve assy	Grimes Aerospace
67-2906-002	Shut-Off Valve	Grimes Aerospace
67-2935-001	Shut-Off Valve	Grimes Aerospace
67-2985-001	Shut-Off Valve	Grimes Aerospace
67-2985-001M	Shut-Off Valve	Grimes Aerospace
67-2985-002	Shut-Off Valve	Grimes Aerospace
67-2985-003	Shut-Off Valve	Grimes Aerospace
672SE01	Three Pole Base Contactor	ECE
6730A02	Fan Air Valve	Liebherr Aerospace
6730B01	Fan Air Valve	Liebherr Aerospace
6730C010000	Fan Air Valve	Liebherr Aerospace
67-3139-002	Valve assy	Grimes Aerospace
67-3139-002M	Valve assy	Grimes Aerospace
67-3139-003	Valve assy	Grimes Aerospace
67-3139-004	Valve assy	Ross Aircraft
6732A010000	Fan Air Valve	Liebherr Aerospace
6733A020000	Fan Air Valve	Liebherr Aerospace
6733A030000	Fan Air Valve	Liebherr Aerospace
673447	Gyrosyn Compass Control Unit	Sperry
6740B03	Overpressure Valve	Liebherr Aerospace
6740B03 Amdt A	Overpressure Valve	Liebherr Aerospace
6740B04	Overpressure Valve	Liebherr Aerospace
6740B04 Amdt A	Overpressure Valve	Liebherr Aerospace
6740B050000	Overpressure Valve	Liebherr Aerospace
6740E010000	Overpressure Valve	Liebherr Aerospace
6740E010000 Amdt A	Overpressure Valve	Liebherr Aerospace
6742A020000	Overpressure Valve	Liebherr Aerospace
6742A030000	Overpressure Valve	Liebherr Aerospace
6742D010000	Overpressure Valve	Liebherr Aerospace
6743A010000	Overpressure Valve	Liebherr Aerospace
6746	Transformer	Oeco Corporation
6752-304-50	Circuit Breaker	Texas Instruments
675300-1	Right Angle Drive Gearbox	Eaton Aerospace
6753B010000	HP Bleed Valve	Liebherr Aerospace

Repair_Capability_List_Excel

6753B020000	HP Bleed Valve	Liebherr Aerospace
6753B030000	HP Bleed Valve	Liebherr Aerospace
6753D010000	HP Bleed Valve	Liebherr Aerospace
6754C010000	Bleed Pressure Valve	Liebherr Aerospace
6754C020000	Bleed Pressure Valve	Liebherr Aerospace
6754D010000	Bleed Pressure Valve	Liebherr Aerospace
676SE01	Three Pole Base Contactor	ECE
6773B020000	Regulating Valve HP	Liebherr Aerospace
6773E010000	Regulating Valve HP	Liebherr Aerospace
6773F010000	Regulating Valve HP	Liebherr Aerospace
6774B020000	Bleed Pressure Valve	Liebherr Aerospace
6774E010000	Bleed Pressure Valve	Liebherr Aerospace
677SE01	Three Pole Base Contactor	ECE
67940	Flow Limiter Valve	Sterer-Vickers
67940-2	Flow Limiter Valve	Sterer-Vickers
680.1360.100	Auto Transformer	Auxilec
680-0012-900	Transformer	Auxilec
680-0021-200	Overheat Detector	Auxilec
680-0021-210	Overheat Detector	Auxilec
680-0021-300	Regulator	Auxilec
680-0021-310	Regulator	Auxilec
680-0021-320	Regulator	Auxilec
680-0021-400	Wing De Ice Monitoring	Auxilec
680-0021-500	Overheat Detector	Auxilec
68000-5003	Elevator Control Package	Parker-Hannifin
68000-5005	Elevator Control Package	Parker-Hannifin
68000-5007	Elevator Control Package	Parker-Hannifin
6800-100-80-10	Battery Temperature Monitor	Thales Avionics
6801360100	Auto Transformer	Auxilec
680-1360-100	Auto Transformer	Auxilec
680203007A	Turbine Leg & Pump	Hamilton Sundstrand
680203019	Turbine Leg & Pump	Hamilton Sundstrand
680203020	Turbine Leg & Pump	Hamilton Sundstrand
680203021	Turbine Leg & Pump	Hamilton Sundstrand
680203027	Turbine Leg & Pump	Hamilton Sundstrand
680203037	Turbine Leg & Pump	Hamilton Sundstrand
682005002	Select Unit	Messier-Dowty
682005002A	Select Unit	Messier-Dowty
682007001	RAT Control Panel	Messier-Dowty
682007003	RAT Control Panel	Messier-Dowty
682007004	RAT Control Panel	Messier-Dowty
682MK1	Flap Control Unit	Goodrich Control Systems
682MK2	Flap Control Unit	Goodrich Control Systems
683478-1-1	Thermal Switch	Honeywell
683-6030-100	Fuel Box Heating	Thales Avionics
683GC01Y01	Battery Protection Unit	ECE
684-1024-005	Transformer Rectifier	Auxilec
684-1024-008	Transformer Rectifier	Auxilec
684-1024-010	Transformer Rectifier	Auxilec
684-1024-011	Transformer Rectifier	Auxilec
684-1024-013	Transformer Rectifier	Auxilec
684-1024-014	Transformer Rectifier	Auxilec
684-1024-015	Transformer Rectifier	Auxilec
684-1024-016	Transformer Rectifier	Auxilec
684-1024-017	Transformer Rectifier	Auxilec
684-1024-018	Transformer Rectifier	Auxilec
684-1024-019	Transformer Rectifier	Auxilec
684535	Compass Amplifier	Sperry

Repair_Capability_List_Excel

684D100-1	Speed Brake Linear Actuator	Eaton
684D100-11	Speed Brake Linear Actuator	Eaton
684D100-13	Speed Brake Linear Actuator	Eaton
684D100-15	Speed Brake Linear Actuator	Eaton
684D100-17	Linear Actuator	Eaton
684D100-3	Speed Brake Linear Actuator	Eaton
684D100-5	Speed Brake Linear Actuator	Eaton
684D100-7	Speed Brake Linear Actuator	Eaton
684D100-9	Speed Brake Linear Actuator	Eaton
685SE01	Three Pole Base Contactor	ECE
689460	Quick Attach-Detach Adapter Kit	Hamilton Sundstrand
689460A	Quick Attach-Detach Adapter Kit	Hamilton Sundstrand
689478C	Pressure Switch	Hamilton Standard
6903-765	Pressure Indicator	HTL Industries
6903-771	Pressure Indicator	HTL Industries
690500-04	Control Unit	Eaton Aerospace
690500-06	Control Unit	Eaton Aerospace
690500-08	Control Unit	Eaton Aerospace
690500-09	Control Unit	Eaton Aerospace
6905-779	Pressure Switch	Pacific Scientific
6905K0001-01	Control Unit	Eaton Aerospace
69-10314-10	Lock Actuator	Boeing
69-10314-11	Lock Actuator	Boeing
69-10314-12	Lock Actuator	Boeing
69-10314-4	Lock Actuator	Boeing
69-10314-5	Lock Actuator	Boeing
69-10314-8	Lock Actuator	Boeing
69-1410-3	Valve assy	Boeing
69-14106-1	Cylinder	Boeing
69-14106-2	Cylinder	Boeing
69-14106-3	Cylinder	Boeing
69-14106-4	Cylinder	Boeing
69-14106-5	Cylinder	Boeing
69-14106-6	Cylinder	Boeing
69-14106-7	Cylinder	Boeing
69-14217-1	Valve assy	Boeing
69-14217-2	Valve assy	Boeing
69-17380-1	Passenger Signs Module	Boeing
69-17380-11	Passenger Signs Module	Boeing
69-17380-12	Passenger Signs Module	Boeing
69-17380-14	Passenger Signs Module	Boeing
69-17380-15	Passenger Signs Module	Boeing
69-17380-16	Passenger Signs Module	Boeing
69-17380-18	Passenger Signs Module	Boeing
69-17380-20	Passenger Signs Module	Boeing
69-17380-21	Passenger Signs Module	Boeing
69-17380-22	Passenger Signs Module	Boeing
69-17380-23	Passenger Signs Module	Boeing
69-17380-25	Passenger Signs Module	Boeing
69-17380-34	Passenger Signs Module	Boeing
69-17380-36	Passenger Signs Module	Boeing
69-17380-4	Passenger Signs Module	Boeing
69-17380-6	Passenger Signs Module	Boeing
69-17380-8	Passenger Signs Module	Boeing
69-17380-9	Passenger Signs Module	Boeing
69-20321-2	Galley/Sevice Door Guide Arm	Boeing
69-20321-3	Galley/Sevice Door Guide Arm	Boeing
69-20321-4	Galley/Sevice Door Guide Arm	Boeing

Repair_Capability_List_Excel

692321-3	By-Pass Valve	Honeywell
69-23695-2	Light assy	Grimes Aerospace
692523-3-7	Thermostat	Honeywell
692525	Oil Pressure Switch	Honeywell
692525-7	Oil Pressure Switch	Honeywell
692525-9	Oil Pressure Switch	Honeywell
692545-1	Solenoid Shut-Off Valve	Honeywell
692545-10	Solenoid Shut-Off Valve	Honeywell
692545-11	Solenoid Shut-Off Valve	Honeywell
692545-12	Solenoid Shut-Off Valve	Honeywell
692545-13	Solenoid Shut-Off Valve	Honeywell
692545-14	Solenoid Shut-Off Valve	Honeywell
692545-15	Solenoid Shut-Off Valve	Honeywell
692545-16	Solenoid Shut-Off Valve	Honeywell
692545-17	Solenoid Shut-Off Valve	Honeywell
692545-2	Solenoid Shut-Off Valve	Honeywell
692545-3	Solenoid Shut-Off Valve	Honeywell
692545-4	Solenoid Shut-Off Valve	Honeywell
692545-400	Solenoid Shut-Off Valve	Honeywell
692545-5	Solenoid Shut-Off Valve	Honeywell
692545-500	Solenoid Shut-Off Valve	Honeywell
692545-6	Solenoid Shut-Off Valve	Honeywell
692545-7	Solenoid Shut-Off Valve	Honeywell
692545-8	Solenoid Shut-Off Valve	Honeywell
692545-9	Solenoid Shut-Off Valve	Honeywell
692546-1	Solenoid Valve	Honeywell
692546-2	Solenoid Valve	Honeywell
692547-1	Oil Tank assy	Honeywell
69-26245-2	Airstair Carriage	Boeing
69-26245-3	Airstair Carriage	Boeing
69-26245-4	Airstair Carriage	Boeing
69-26245-5	Airstair Carriage	Boeing
69-26245-6	Airstair Carriage	Boeing
69-27991-1	Gearbox assy	Boeing
69-27991-2	Gearbox assy	Boeing
69-29567-1	APU Fire Warning Horn	Boeing
69-29567-5	APU Fire Warning Horn	Boeing
69-29585-1	Ball Screw assy	Boeing
69-29585-4	Ball Screw assy	Boeing
692993	Solenoid Valve	Honeywell
692D100-11	Cargo Door Rotary Actuator	Eaton
692D100-13	Cargo Door Rotary Actuator	Eaton
692D100-2	Cargo Door Rotary Actuator	Eaton
692D100-3	Cargo Door Rotary Actuator	Eaton
692D100-5	Cargo Door Rotary Actuator	Eaton
692D100-9	Cargo Door Rotary Actuator	Eaton
693064	Oil Tank assy	Honeywell
693335	Hydraulic Pump	Vickers
693337	Hydraulic Pump	Vickers
69-34511-1	Rain Repellent System Visual Reservoir	Boeing
69-34511-2	Rain Repellent System Visual Reservoir	Boeing
69-35293-1	Palletized Cargo System AFT Stop	Boeing
69-35293-2	Palletized Cargo System AFT Stop	Boeing
69-35293-3	Palletized Cargo System AFT Stop	Boeing
69-35336-1	Toggle assy	Boeing
69-35336-2	Toggle assy	Boeing
69-35336-3	Toggle assy	Boeing
69-35500-3	Main Gear Lock Actuator	Boeing

Repair_Capability_List_Excel

69-35500-4	Main Gear Lock Actuator	Boeing
69-35500-5	Main Gear Lock Actuator	Boeing
69-35500-6	Main Gear Lock Actuator	Boeing
69-36129-1	Dummy Load Assy	Boeing
69-36129-12	Dummy Load Assy	Boeing
69-36129-13	Dummy Load Assy	Boeing
69-36129-17	Dummy Load Assy	Boeing
69-36129-18	Dummy Load Assy	Boeing
69-36129-19	Dummy Load Assy	Boeing
69-36129-2	Dummy Load Assy	Boeing
69-36129-20	Dummy Load Assy	Boeing
69-36129-22	Dummy Load Assy	Boeing
69-36129-26	Dummy Load Assy	Boeing
69-36129-3	Dummy Load Assy	Boeing
69-36129-30	Dummy Load Assy	Boeing
69-36129-32	Dummy Load Assy	Boeing
69-36129-35	Dummy Load Assy	Boeing
69-36129-37	Dummy Load Assy	Boeing
69-36129-4	Dummy Load Assy	Boeing
69-36129-7	Dummy Load Assy	Boeing
69-37290-10	Vernier Adjustment Control Rod	Boeing
69-37290-11	Vernier Adjustment Control Rod	Boeing
69-37290-12	Vernier Adjustment Control Rod	Boeing
69-37290-13	Vernier Adjustment Control Rod	Boeing
69-37290-6	Vernier Adjustment Control Rod	Boeing
69-37290-7	Vernier Adjustment Control Rod	Boeing
69-37290-8	Vernier Adjustment Control Rod	Boeing
69-73100	Flap Track assy	Boeing
697310004	Rotary Actuator	Dowty Aerospace
69-73371-2	Vernier Adjustment Control Rod	Boeing
69-73371-3	Vernier Adjustment Control Rod	Boeing
69-73371-4	Vernier Adjustment Control Rod	Boeing
69-73371-5	Vernier Adjustment Control Rod	Boeing
69-73371-6	Vernier Adjustment Control Rod	Boeing
69-73371-7	Vernier Adjustment Control Rod	Boeing
69-73677-1	Nose Minor Components	Boeing
69-73677-3	Nose Minor Components	Boeing
69-73677-5	Nose Minor Components	Boeing
69-73677-9	Nose Minor Components	Boeing
697501001	Right Angle Gearbox	Messier-Dowty
697502001	Kink Bevel Gearbox	Messier-Dowty
697503001	Downdrive Gearbox	Messier-Dowty
697504001	Downdrive Gearbox	Messier-Dowty
697505003	Input Gearbox	Messier-Dowty
697505004	Input Gearbox	Messier-Dowty
697505005	Input Gearbox	Messier-Dowty
697506003	Input Gearbox	Messier-Dowty
697506004	Input Gearbox	Messier-Dowty
697506005	Input Gearbox	Messier-Dowty
697507003	Input Gearbox	Messier-Dowty
697507004	Input Gearbox	Messier-Dowty
697507005	Input Gearbox	Messier-Dowty
697508002	Input Gearbox	Messier-Dowty
697508003	Input Gearbox	Messier-Dowty
697508004	Input Gearbox	Messier-Dowty
697509002	Input Gearbox	Messier-Dowty
697509003	Input Gearbox	Messier-Dowty
697509004	Input Gearbox	Messier-Dowty

Repair_Capability_List_Excel

697510003	Flap Actuator	Messier-Dowty
697510004	Flap Actuator	Messier-Dowty
697511004	Flap Actuator	Messier-Dowty
697511005	Flap Actuator	Messier-Dowty
697511006	Flap Actuator	Messier-Dowty
697511007	Flap Actuator	Messier-Dowty
697514001	Right Angle Gearbox	Messier-Dowty
697514002	Right Angle Gearbox	Messier-Dowty
697515001	Shaft Assembly	Goodrich Control Systems
697515002	Shaft Assembly	Messier-Dowty
697515003	Shaft Assembly	Messier-Dowty
697516001	Shaft Assembly	Messier-Dowty
697516002	Shaft Assembly	Messier-Dowty
697517001	Shaft Assembly	Messier-Dowty
697518001	Shaft Assembly	Messier-Dowty
697519001	Shaft Assembly	Messier-Dowty
697520001	Shaft Assembly	Messier-Dowty
697520002	Shaft Assembly	Messier-Dowty
697521001	Shaft Assembly	Messier-Dowty
697522002	Shaft Assembly	Messier-Dowty
697523001	Shaft Assembly	Messier-Dowty
697524002	Shaft Assembly	Messier-Dowty
697525001	Shaft Assembly	Messier-Dowty
697526001	Shaft Assembly	Messier-Dowty
697527001	Shaft Assembly	Messier-Dowty
697528001	Shaft Assembly	Messier-Dowty
697529001	Shaft Assembly	Messier-Dowty
697530001	Shaft Assembly	Messier-Dowty
697531001	Shaft Assembly	Messier-Dowty
697531003	Shaft Assembly	Messier-Dowty
697532001	Shaft Assembly	Messier-Dowty
697532002	Shaft Assembly	Messier-Dowty
697533001	Shaft Assembly	Messier-Dowty
697534001	Shaft Assembly	Messier-Dowty
697535001	Shaft Assembly	Messier-Dowty
697536001	Shaft Assembly	Messier-Dowty
697538001	Shaft Assembly	Messier-Dowty
697539001	Shaft Assembly	Messier-Dowty
697550001	Shaft Assembly	Messier-Dowty
69755001	Crass Shaft	Dowty Aerospace
697551001	Shaft Assembly	Messier-Dowty
697555001	Shaft-Cross assy	Messier-Dowty
697556001	Shaft-Cross assy	Messier-Dowty
697557001	Shaft-Cross assy	Messier-Dowty
697558001	Shaft-Cross assy	Messier-Dowty
697570001	Shaft-Cross assy	Messier-Dowty
697578001	Gearbox	Messier-Dowty
697579001	Input Gearbox	Messier-Dowty
697579002	Input Gearbox	Messier-Dowty
697579003	Input Gearbox	Messier-Dowty
697580001	Input Gearbox	Messier-Dowty
697580002	Input Gearbox	Messier-Dowty
697580003	Input Gearbox	Messier-Dowty
697581001	Input Gearbox	Messier-Dowty
697581002	Input Gearbox	Messier-Dowty
697581003	Input Gearbox	Messier-Dowty
697582001	Input Gearbox	Messier-Dowty
697582002	Input Gearbox	Messier-Dowty

Repair_Capability_List_Excel

697582003	Input Gearbox	Messier-Dowty
697583001	Input Gearbox	Messier-Dowty
697583002	Input Gearbox	Messier-Dowty
697583003	Input Gearbox	Messier-Dowty
697584001	Shaft Assembly	Messier-Dowty
697620001	Shaft Assembly	Messier-Dowty
697621001	Shaft Assembly	Messier-Dowty
697622001	Shaft Assembly	Messier-Dowty
697623001	Shaft Assembly	Messier-Dowty
697624001	Shaft Assembly	Messier-Dowty
697625001	Shaft Assembly	Messier-Dowty
697626001	Shaft Assembly	Messier-Dowty
697627001	Shaft Assembly	Messier-Dowty
697628001	Shaft Assembly	Messier-Dowty
697629001	Shaft Assembly	Messier-Dowty
697630001	Shaft Assembly	Messier-Dowty
697631001	Shaft Assembly	Messier-Dowty
697632001	Shaft Assembly	Messier-Dowty
697633001	Shaft Assembly	Messier-Dowty
697634001	Shaft Assembly	Messier-Dowty
697635001	Shaft Assembly	Messier-Dowty
697638001	Shaft Assembly	Messier-Dowty
697639001	Shaft Assembly	Messier-Dowty
697650001	Kink Bevel Gearbox	Dowty Aerospace
697651001	Right Angle Gearbox	Dowty Aerospace
697652001	Downdrive Gearbox	Dowty Aerospace
697653001	Downdrive Gearbox	Dowty Aerospace
697654001	Downdrive Gearbox	Dowty Aerospace
697655001	Input Gearbox	Dowty Aerospace
697656001	Input Gearbox	Dowty Aerospace
697657001	Input Gearbox	Dowty Aerospace
697658001	Input Gearbox	Dowty Aerospace
697659001	Input Gearbox	Dowty Aerospace
697660001	Input Gearbox	Dowty Aerospace
697661001	Input Gearbox	Dowty Aerospace
697662001	Input Gearbox	Dowty Aerospace
697663001	Input Gearbox	Dowty Aerospace
697664001	Input Gearbox	Dowty Aerospace
697666001	Shaft Assembly	Dowty Aerospace
697670001	Shaft Assembly	Dowty Aerospace
697672001	Shaft Assembly	Dowty Aerospace
69-77044-1	Main Gear Minor Components	Boeing
69-77045-1	Main Gear Minor Components	Boeing
69-77055-3	Door Warning Annunciator Module	Boeing
697707001	Shaft Assembly	Dowty Aerospace
697708001	Shaft Downdrive	Dowty Aerospace
697712001	Shaft Assembly	Dowty Aerospace
697718001	Shaft Downdrive	Dowty Aerospace
697728001	Shaft Assembly	Dowty Aerospace
697729C	Input Housing	Hamilton Sundstrand
697729D	Input Housing	Hamilton Sundstrand
697740001	Shaft Downdrive	Dowty Aerospace
69-77496-10	Actuator	Boeing
69-77496-11	Actuator	Boeing
69-77496-12	Actuator	Boeing
69-77496-13	Actuator	Boeing
69-77496-14	Actuator	Boeing
69-77496-17	Actuator	Boeing

Repair_Capability_List_Excel

69-77496-18	Actuator	Boeing
69-77496-19	Actuator	Boeing
69-77496-20	Actuator	Boeing
69-77496-21	Actuator	Boeing
69-77496-22	Actuator	Boeing
69-77496-23	Actuator	Boeing
69-77496-26	Actuator	Boeing
69-77496-27	Actuator	Boeing
69-77496-28	Actuator	Boeing
69-77496-29	Actuator	Boeing
69-77496-30	Actuator	Boeing
69-77496-5	Actuator	Boeing
69-77496-6	Actuator	Boeing
69-77496-7	Actuator	Boeing
69-77496-8	Actuator	Boeing
69-77496-9	Actuator	Boeing
69-78096-1	Airborne Data Loader Panel	Boeing
69-78096-4	Airborne Data Loader Panel	Boeing
69-78096-5	Airborne Data Loader Panel	Boeing
69-78547-1	Flight Rec.& Mach Airsp.Warn.Test Mod	Boeing
69-78547-2	Flight Rec.& Mach Airsp.Warn.Test Mod	Boeing
69-78581-2	Speaker/Amplifier	Boeing
69-78581-4	Speaker/Amplifier	Boeing
697902	Pressure Switch	Hamilton Sundstrand
697902A	Pressure Switch	Hamilton Sundstrand
697902B	Pressure Switch	Hamilton Sundstrand
697902C	Pressure Switch	Hamilton Sundstrand
697902D	Pressure Switch	Hamilton Sundstrand
697902E	Pressure Switch	Hamilton Sundstrand
698404-1	Oil Tank assy	Honeywell
698900AA000PC0A	L.P. Hydraulic Filter	Sofrance
698900AB000PC0A	L.P. Hydraulic Filter	Sofrance
698900AC000PC0A	L.P. Hydraulic Filter	Sofrance
699000AA000PC0A	Hydraulic Filter	Sofrance
699000AB000PC0A	Hydraulic Filter	Sofrance
699191	Output Housing	Hamilton Sundstrand
699394	External Module	Hamilton Sundstrand
699394A	External Module	Hamilton Sundstrand
699394B	External Module	Hamilton Sundstrand
699413	Differential	Hamilton Sundstrand
699512	Vent Valve	Hamilton Sundstrand
699739B	Block Cylinder	Hamilton Sundstrand
69B63779-1	Stop ay	Goodrich
69B63803-1	Caster Support ay	Goodrich
69B80358-1	Actuator	Boeing
69B80358-10	Actuator	Boeing
69B80358-11	Actuator	Boeing
69B80358-12	Actuator	Boeing
69B80358-13	Actuator	Boeing
69B80358-15	Actuator	Boeing
69B80358-16	Actuator	Boeing
69B80358-17	Actuator	Boeing
69B80358-18	Actuator	Boeing
69B80358-19	Actuator	Boeing
69B80358-2	Actuator	Boeing
69B80358-20	Actuator	Boeing
69B80358-21	Actuator	Boeing
69B80358-22	Actuator	Boeing

Repair_Capability_List_Excel

69B80358-23	Actuator	Boeing
69B80358-24	Actuator	Boeing
69B80358-25	Actuator	Boeing
69B80358-26	Actuator	Boeing
69B80358-27	Actuator	Boeing
69B80358-28	Actuator	Boeing
69B80358-29	Actuator	Boeing
69B80358-3	Actuator	Boeing
69B80358-30	Actuator	Boeing
69B80358-31	Actuator	Boeing
69B80358-32	Actuator	Boeing
69B80358-4	Actuator	Boeing
69B80358-5	Actuator	Boeing
69B80358-6	Actuator	Boeing
69B80358-7	Actuator	Boeing
69B80358-8	Actuator	Boeing
69B80358-9	Actuator	Boeing
69B80359-2	Actuator	Boeing
69B81070-1	Rudder Control Components	Boeing
69B81071-1	Rudder Control Components	Boeing
69B81723-1	Elevator Control Components	Boeing
69B82756-1	Speed Brake Lever Install.Components	Boeing
69B82756-3	Speed Brake Lever Install.Components	Boeing
69B82756-5	Speed Brake Lever Install.Components	Boeing
69B82839-1	Speed Brake Lever Install.Components	Boeing
69B82839-13	Speed Brake Lever Install.Components	Boeing
69B82839-15	Speed Brake Lever Install.Components	Boeing
69B82839-17	Speed Brake Lever Install.Components	Boeing
69B82839-19	Speed Brake Lever Install.Components	Boeing
6D187-6	Valve assy	Allen Aircraft
6D227	Valve	Allen Aircraft
700	Autotransformer	Auxilec
700000	Cable Tension Regulator	Sarma
70-0039-1	Strobe Light Flasher	Grimes Aerospace
70-0039-3	Strobe Light Flasher	Grimes Aerospace
7000469-913	Horizontal Situation Indicator	Sperry
7000836-909	Attitude Director Indicator	Sperry
7000836-922	Attitude Director Indicator	Sperry
7000836-923	Attitude Director Indicator	Sperry
700100	Cable Tension Regulator	Sarma
700-1114-001	Video Projector	Sony Trans Com
700-1117-001	Video Projector	Sony Trans Com
700-1117-003	Video Projector	Sony Trans Com
700-1117-004	Video Projector	Sony Trans Com
700-1117-005	Video Projector	Sony Trans Com
700-1117-006	Video Projector	Sony Trans Com
700-1117-007	Video Projector	Sony Trans Com
700-1117-008	Video Projector	Sony Trans Com
700-1117-009	Video Projector	Sony Trans Com
700-1117-010	Video Projector	Sony Trans Com
700-1117-011	Video Projector	Sony Trans Com
700-1117-012	Video Projector	Sony Trans Com
700196	Pump & Motor	Hamilton Sundstrand
700200-1	Control Cable Tension Regulator	Sarma
700200-2	Control Cable Tension Regulator	Sarma
700-2004-001	Monitor	Sony Trans Com
700-2004-002	Monitor	Sony Trans Com
700-2004-003	Monitor	Sony Trans Com

Repair_Capability_List_Excel

700-2004-004	Monitor	Sony Trans Com
7002260-722	AP Actuator	Honeywell
7002260-821	Servo Drive assy	Honeywell
7002260-822	Servo Drive assy	Honeywell
7002260-901	Servo Drive assy	Honeywell
7002260-902	Servo Drive assy	Honeywell
7002260-903	Servo Drive assy	Honeywell
7002260-911	Servo Drive assy	Honeywell
7002260-912	Servo Drive assy	Honeywell
7002260-913	Servo Drive assy	Honeywell
7002260-921	Servo Drive assy	Honeywell
7002260-922	Servo Drive assy	Honeywell
7002260-923	Servo Drive assy	Honeywell
7002260-931	Servo Drive assy	Honeywell
7002260-932	Servo Drive assy	Honeywell
7002260-933	Servo Drive assy	Honeywell
70-0240-1	Emergency Evacuation Panel	Grimes Aerospace
70-0240-2	Emergency Evacuation Panel	Grimes Aerospace
70-0240-3	Emergency Evacuation Panel	Grimes Aerospace
70-0240-5	Emergency Evacuation Panel	Grimes Aerospace
70-0240-6	Emergency Evacuation Panel	Grimes Aerospace
7002638-902	True Airspeed Temp Indicator	Sperry
7002638-906	True Airspeed Temp Indicator	Sperry
7002638-907	TAS/Temp Indicator	Honeywell
7002860-909	Airspeed Indicator	Honeywell
700300-1	Pitch Roll Control Cable Tension	Sarma
700300-2	Pitch Roll Control Cable Tension	Sarma
700328	Governor & Support	Hamilton Sundstrand
700400	Control Cable Tension Regulator	Sarma
700474	Governor & Support	Hamilton Sundstrand
700500-1	Control Cable Tension Regulator	Sarma
700500-2	Control Cable Tension Regulator	Sarma
700564B	Housing	Hamilton Sundstrand
7005973-912	Instrument Remote Controller	Honeywell
7005973-914	Instrument Remote Controller	Honeywell
700600-1	Control Cable Tension Regulator	Sarma
700600-2	Control Cable Tension Regulator	Sarma
7006921-302	Weather Radar Control Box	Honeywell
700800-1	Control Cable Tension Regulator	Sarma
700800-2	Control Cable Tension Regulator	Sarma
700842	Constant Speed Transmission	Hamilton Sundstrand
700901B	Hydraulic Control Unit	Hamilton Sundstrand
700B36894	Interphone Amplifier	Gables
700TS06Y10	Engine/APU Fire Panel	ECE
700TS06Y11	Engine/APU Fire Panel	ECE
700TS06Y111	Engine/APU Fire Panel	ECE
700TS06Y12	Engine/APU Fire Panel	ECE
7010133	Flux Valve	Honeywell
701034	Vent Valve	Hamilton Sundstrand
701100	Control Cable Tension Regulator	Sarma
7012-17971-3	Outflow Valve assy	Nord-Micro
7012-17971-4	Outflow Valve assy	Nord-Micro
7012-17975-1	Negative Relief Valve	Nord-Micro
7012-17975-2	Negative Relief Valve	Nord-Micro
7012-18088	Valve	Nord-Micro
701-2650000	Door Damper & Emerg.Cylinder ay	Ratier-Figeac
701-2650002	Door Damper & Emerg.Cylinder ay	Ratier-Figeac
701-3100	Valve assy	Intertechnique

Repair_Capability_List_Excel

701-3100001	Valve assy	Intertechnique
701-3320000	Valve assy	Intertechnique
701-3350000	Valve assy	Intertechnique
701-33501-3358	Brake Safety Valve	Aerospatiale
701-3358000	Brake Safety Valve	Airbus Industrie
701-3383000	Valve assy	Intertechnique
701-3385	Flow Limiting Non-return Valve	Airbus Industrie
701-3395000	Valve assy	Intertechnique
701-3420000	Limiter	Intertechnique
701-3495000	Valve assy	Intertechnique
701-3515	Hydraulic Operated Parking Brake Valve	Airbus Industrie
701363	Light & Power Supply	Symbolic Displays
701-3630001	Valve assy	Intertechnique
701364	Anti-Collision Strobe Light	Grimes Aerospace
701-3740000	Door Damper & Emerg.Cylinder ay	Ratier-Figeac
701-3740001	Door Damper & Emerg.Cylinder ay	Ratier-Figeac
701-3800000	Rod assy	Intertechnique
701-3830001	Valve assy	Intertechnique
701-3860000	Electro-Mechanical Spring Rod	Airbus Industrie
701-4200000	Timing Valve	Airbus Industrie
701-4200001	Timing Valve	Airbus Industrie
701-4540000	Check Valve	Airbus Industrie
701-5000000	Damper Actuating Cylinder	Ratier-Figeac
701-5000001	Damper Actuating Cylinder	Ratier-Figeac
701-5000002	Damper Actuating Cylinder	Ratier-Figeac
701-5000003	Damper Actuating Cylinder	Ratier-Figeac
701-5000004	Damper Actuating Cylinder	Ratier-Figeac
701-5000005	Damper Actuating Cylinder	Ratier-Figeac
701-5080000	Damper Actuating Cylinder	Ratier-Figeac
701-5080001	Damper Actuating Cylinder	Ratier-Figeac
701-5080002	Damper Actuating Cylinder	Ratier-Figeac
701-5090000	Damper Actuating Cylinder	Ratier-Figeac
701-5090001	Damper Actuating Cylinder	Ratier-Figeac
701-5090002	Damper Actuating Cylinder	Ratier-Figeac
701-5097000	Damper Actuating Cylinder	Ratier-Figeac
701-5097001	Damper Actuating Cylinder	Ratier-Figeac
701-5097002	Damper Actuating Cylinder	Ratier-Figeac
701-5097003	Damper Actuating Cylinder	Ratier-Figeac
701-5097003A	Damper Actuating Cylinder	Ratier-Figeac
701-5097003B	Damper Actuating Cylinder	Ratier-Figeac
701528	Input Shaft	Hamilton Sundstrand
701-5380-000	Pressure Valve	Airbus Industrie
701-5600000	Damper Actuating Cylinder	Ratier-Figeac
701-5600001	Damper Actuating Cylinder	Ratier-Figeac
701-5600002	Damper Actuating Cylinder	Ratier-Figeac
701-5610000	Damper Actuating Cylinder	Ratier-Figeac
701-5970000	Damper Actuating Cylinder	Ratier-Figeac
701-5970001	Damper Actuating Cylinder	Ratier-Figeac
701-5970002	Damper Actuating Cylinder	Ratier-Figeac
701-5970003	Damper Actuating Cylinder	Ratier-Figeac
701-5970003 Amdt A	Damper Actuating Cylinder	Ratier-Figeac
701-5970003 Amdt B	Damper Actuating Cylinder	Ratier-Figeac
701654	Anti-Collision Strobe Light	Grimes Aerospace
70170	Valve assy	Sterer
70171	Sequence Valve	Sterer
70172	Pressure Reducer Valve	Sterer
70172-1	Reducer Pressure	Sterer
70184	Brake Control Valve	Sterer

Repair_Capability_List_Excel

70184-1	Valve Brake Control	Sterer
70185	Sequence Valve	Sterer
70185-1	Sequence Valve	Sterer
701859A	Carrier Shaft assy	Hamilton Sundstrand
70200	Manual Bleed Valve	Westland-Sitec
70205	Valve assy	Eaton Aerospace
70205-1	Valve assy	Eaton Aerospace
70218	Shut-Off Valve	Sterer
702242	Light	Symbolic Displays
702242C	Light	Symbolic Displays
70237	Valve assy	Sterer
70237-1	Shut-Off Valve	Sterer
702422	Governor & Support	Hamilton Sundstrand
702504	Anti-Collision Strobe Light	Grimes Aerospace
70267	Valve assy	Eaton Aerospace
70268	Pressure Regulator & Relief Valve	Sterer
70268-1	Pressure Regulator & Relief Valve	Sterer
70379	Parking Brake Valve	Sterer
70385	Rudder Manifold Actuator	Sterer
70385-1	Rudder Manifold Actuator	Sterer
70385-10	Rudder Manifold Actuator	Sterer
70385-2	Rudder Manifold Actuator	Sterer
70385-3	Rudder Manifold Actuator	Sterer
70386	Rudder Manifold Stand-By	Sterer
70386-1	Rudder Manifold Stand-By	Sterer
70386-10	Rudder Manifold Actuator	Sterer
70386-2	Rudder Manifold Actuator	Sterer
70386-3	Rudder Manifold Actuator	Sterer
70400	Relief Valve	Westland-Sitec
70400-1	LEVEL SENSOR	MONOGRAM
70400-3	LEVEL SENSOR	MONOGRAM
70408-2	Shuttle Valve	Hydro-Aire
704181	Output Housing	Hamilton Sundstrand
704185	Load Controller	Hamilton Sundstrand
704185A	Load Controller	Hamilton Sundstrand
704185B	Load Controller	Hamilton Sundstrand
704185C	Load Controller	Hamilton Sundstrand
704185D	Load Controller	Hamilton Sundstrand
704-722-4	Sensor	Intertechnique
704-771-3	Tank Probe	Intertechnique
704-771-4	Tank Probe	Intertechnique
704-772-3	Tank Probe	Intertechnique
704-772-4	Tank Probe	Intertechnique
704-773-3	Tank Probe	Intertechnique
704-773-4	Tank Probe	Intertechnique
704-774-3	Tank Probe	Intertechnique
704-774-4	Tank Probe	Intertechnique
704-775-3	Tank Probe	Intertechnique
704-775-4	Tank Probe	Intertechnique
704-776-3	Tank Probe	Intertechnique
704-776-4	Tank Probe	Intertechnique
704-777-3	Tank Probe	Intertechnique
704-777-4	Tank Probe	Intertechnique
704-777-5	Tank Probe	Intertechnique
704-778-3	Tank Probe	Intertechnique
704-778-4	Tank Probe	Intertechnique
704-779-3	Tank Probe	Intertechnique
704-779-4	Tank Probe	Intertechnique

Repair_Capability_List_Excel

704-780-3	Tank Probe	Intertechnique
704-780-4	Tank Probe	Intertechnique
704-781-3	Tank Probe	Intertechnique
704-781-4	Tank Probe	Intertechnique
704-782-3	Tank Probe	Intertechnique
704-782-4	Tank Probe	Intertechnique
705-15V10	Gyroscopic Horizon	Thales Avionics
705-15V1M1	Gyroscopic Horizon	Thales Avionics
705-15V3	Gyroscopic Horizon	Thales Avionics
705-15V4	Gyroscopic Horizon	Thales Avionics
705-15V9	Gyroscopic Horizon	Thales Avionics
705-19	Gyroscopic Horizon Indicator	Thales
705-20	Gyroscopic Horizon Indicator	Thales
705-20M1	Gyroscopic Horizon Indicator	Thales
705-7V4	Gyroscopic Horizon Indicator	Thales
705-7V42M1	Gyroscopic Horizon Indicator	Thales
705-7V4M1	Gyroscopic Horizon Indicator	Thales
705-7V84	Gyroscopic Horizon Indicator	Thales
705-7V84M1	Gyroscopic Horizon Indicator	Thales
705-7V9	Stand-by Horizon Indicator	Thales Avionics
705-7V91M1	Stand-by Horizon Indicator	Thales Avionics
705-7V93	Gyroscopic Horizon Indicator	Thales
705-7V96	Gyroscopic Horizon Indicator	Thales
705-7V9M1	Stand-by Horizon Indicator	Thales Avionics
705CA01	Three-Pole Contactor	ECE
706348	Charge Pump	Hamilton Sundstrand
706400-2	Motor Fuel Drive Unit	Argo-Tech
706400-3	Motor Fuel Drive Unit	Argo-Tech
706400-4	Motor Fuel Drive Unit	Argo-Tech
706-491-1	Fuel Quantity Amplifier	Intertechnique
706-620	Fuel Quantity Amplifier	Intertechnique
706-620-1	Fuel Quantity Amplifier	Intertechnique
706-622	Fuel Quantity Amplifier	Intertechnique
706-622-1	Fuel Quantity Amplifier	Intertechnique
706-915	Amplifier	Intertechnique
706-915-1	Amplifier	Intertechnique
706-915-2	Amplifier	Intertechnique
70699	Shuttle Valve	Sterer
70699-1	Shuttle Valve	Sterer
70705	Shuttle Valve	Sterer
707175	Differential	Hamilton Sundstrand
70729-1	Brake Control Valve	Sterer
707305	Quick Disconnect	Hamilton Sundstrand
707334	Scavenge Pump	Hamilton Sundstrand
707337	Charge Pump	Hamilton Sundstrand
707372	Block Cylinder	Hamilton Sundstrand
707388	Transmission	Hamilton Sundstrand
707-398-1	Quantity Preselector	Intertechnique
70741-3	Inboard Flap Cylinder assy	Vickers
70741-5	Inboard Flap Cylinder assy	Vickers
7074-2	Motor Control Unit	Thales Avionics
7074-3	Motor Control Unit	Thales Avionics
7074-4	Motor Control Unit	Thales Avionics
70754	Torquemotor Servovalve	Parker Hannifin
707586	Load Controller	Hamilton Sundstrand
707588	Wiring Harness	Hamilton Sundstrand
707588A	Wiring Harness	Hamilton Sundstrand
707716	Scavenge Pump	Hamilton Sundstrand

Repair_Capability_List_Excel

707716A	Scavenge Pump	Hamilton Sundstrand
707731	Differential	Hamilton Sundstrand
707760-2	Static Inverter	Smiths Industries
707760-3	Static Inverter	Smiths Industries
707760-4	Static Inverter	Smiths Industries
70781-3	Trailing Edge Flap Actuator	Sterer
70781-5	Trailing Edge Flap Actuator	Sterer
70781-7	Trailing Edge Flap Actuator	Sterer
707820	Electrical Harness	Hamilton Sundstrand
707894	Governor & Support	Hamilton Sundstrand
707911	Pump & Motor	Hamilton Sundstrand
707921	Pump & Motor	Hamilton Sundstrand
707999	Output Housing	Hamilton Sundstrand
708-044-1	Amplifier	FR Hitemp
708-079-3	Contents Gauge Cable Harness	Intertechnique
708-079-4	Contents Gauge Cable Harness	Intertechnique
708-080-3	Contents Gauge Cable Harness	Intertechnique
708-080-4	Contents Gauge Cable Harness	Intertechnique
708-100	Load Limit Selector	Intertechnique
708-105-1	Electrical Center Tank Harness	Intertechnique
708200-2	Lamp Dimmer assy	Smiths Industries
708200-3	Lamp Dimmer assy	Smiths Industries
708-312	Load Limit Selector	Intertechnique
708-313	Amplifier	FR Hitemp
708-316	Load Limit Amplifier	Intertechnique
708510A	Housing	Hamilton Sundstrand
708520-2	DC Control	Smiths Aerospace
708524	Integrated Drive Generator	Hamilton Sundstrand
708585	Charge Filter Cap	Hamilton Sundstrand
708-595	Load Limit Selector	Intertechnique
708-600	Load Limit Selector	Intertechnique
708-614-2	Contents Gauge Cable Harness	Intertechnique
708-614-3	Contents Gauge Cable Harness	Intertechnique
708-615	Contents Gauge Cable Harness	Intertechnique
708-615-1	Contents Gauge Cable Harness	Intertechnique
708-616-1	Contents Gauge Cable Harness	Intertechnique
708-616-2	Contents Gauge Cable Harness	Intertechnique
708-616-3	Contents Gauge Cable Harness	Intertechnique
708863	End Housing	Hamilton Sundstrand
708863D	End Housing	Hamilton Sundstrand
708988	Filter By-Pass Valve	Hamilton Sundstrand
708CA28	Non-Return Valve	FR Hitemp
708CA28/1	Valve assy	FR Hitemp
708CA28-1	Non-Return Valve	FR Hitemp
708CA29	Valve assy	FR Hitemp
70900-1	Sensor	Rogerson Kratos
70902	Ground Service Manifold assy	Sterer
70902-3	Ground Service Manifold assy	Sterer
70902-4	Ground Service Manifold assy	Sterer
709038	Charge & Scavenge Pump	Hamilton Sundstrand
709051	Input Housing	Hamilton Sundstrand
70912	Valve assy	Eaton Aerospace
70912-1	Valve assy	Eaton Aerospace
709192	Quick Disconnect	Hamilton Sundstrand
7101-01	Fire and Overheat Detector	Meggitt
7101-02	Fire and Overheat Detector	Meggitt
7101-03	Fire and Overheat Detector	Meggitt
7101-04	Fire and Overheat Detector	Meggitt

Repair_Capability_List_Excel

7101-05	Fire and Overheat Detector	Meggitt
7101-06	Fire and Overheat Detector	Meggitt
7101-07	Fire and Overheat Detector	Meggitt
7101-08	Fire and Overheat Detector	Meggitt
7101-09	Fire and Overheat Detector	Meggitt
7101-10	Fire Detector	Whittaker
7101-11	Fire and Overheat Detector	Meggitt
7101-12	Fire Detector	Whittaker
7101-129	Fire and Overheat Detector	Meggitt
7101-13	Fire Detector	Whittaker
7101-135	Fire and Overheat Detector	Meggitt
7101-136	Fire and Overheat Detector	Meggitt
7101-137	Fire and Overheat Detector	Meggitt
7101-138	Fire and Overheat Detector	Meggitt
7101-14	Fire and Overheat Detector	Meggitt
7101-148	Fire and Overheat Detector	Meggitt
7101-149	Fire and Overheat Detector	Meggitt
7101-15	Fire and Overheat Detector	Meggitt
7101-155	Fire and Overheat Detector	Meggitt
7101-16	Fire and Overheat Detector	Meggitt
7101-17	Fire and Overheat Detector	Meggitt
7101-18	Fire and Overheat Detector	Meggitt
7101-19	Fire and Overheat Detector	Meggitt
7101-20	Fire and Overheat Detector	Meggitt
7101-21	Fire and Overheat Detector	Meggitt
7101-22	Fire and Overheat Detector	Meggitt
7101-23	Fire and Overheat Detector	Meggitt
7101-236	Fire and Overheat Detector	Meggitt
7101-237	Fire and Overheat Detector	Meggitt
7101-24	Fire and Overheat Detector	Meggitt
7101-25	Fire and Overheat Detector	Meggitt
7101-26	Fire and Overheat Detector	Meggitt
7101-265	Fire and Overheat Detector	Meggitt
7101-27	Fire and Overheat Detector	Meggitt
7101-28	Fire and Overheat Detector	Meggitt
7101-29	Fire and Overheat Detector	Meggitt
7101-30	Fire Detector	Whittaker
7101-31	Fire Detector	Whittaker
7101-32	Fire Detector	Whittaker
7101-33	Fire Detector	Whittaker
7101-34	Fire Detector	Whittaker
7101-35	Fire Detector	Whittaker
7101-36	Fire Detector	Whittaker
7101-37	Fire Detector	Whittaker
7101-38	Fire Detector	Whittaker
7101-39	Fire Detector	Whittaker
7101-40	Fire Detector	Whittaker
7101-41	Fire Detector	Whittaker
7101-42	Fire and Overheat Detector	Meggitt
7101-43	Fire and Overheat Detector	Meggitt
7101-44	Fire and Overheat Detector	Meggitt
7101-45	Fire and Overheat Detector	Meggitt
7101-46	Fire and Overheat Detector	Meggitt
7101-47	Fire and Overheat Detector	Meggitt
7101-48	Fire and Overheat Detector	Meggitt
7101-49	Fire and Overheat Detector	Meggitt
7101-50	Fire and Overheat Detector	Meggitt
7101-51	Fire and Overheat Detector	Meggitt

Repair_Capability_List_Excel

7101-52	Fire and Overheat Detector	Meggitt
7101-53	Fire and Overheat Detector	Meggitt
7101-54	Fire and Overheat Detector	Meggitt
7101-55	Fire and Overheat Detector	Meggitt
7101-56	Fire and Overheat Detector	Meggitt
7101-57	Fire and Overheat Detector	Meggitt
7101-58	Fire and Overheat Detector	Meggitt
7101-59	Fire and Overheat Detector	Meggitt
7101-60	Fire and Overheat Detector	Meggitt
7101-61	Fire and Overheat Detector	Meggitt
7101-62	Fire and Overheat Detector	Meggitt
7101-63	Fire and Overheat Detector	Meggitt
7101-64	Fire and Overheat Detector	Meggitt
7101-65	Fire and Overheat Detector	Meggitt
7101-66	Fire and Overheat Detector	Meggitt
7101-67	Fire and Overheat Detector	Meggitt
7101-68	Fire and Overheat Detector	Meggitt
7101-69	Fire and Overheat Detector	Meggitt
7101-70	Fire and Overheat Detector	Meggitt
7101-71	Fire and Overheat Detector	Meggitt
7101-72	Fire and Overheat Detector	Meggitt
7101-73	Fire and Overheat Detector	Meggitt
7101-77	Fire and Overheat Detector	Meggitt
7101-78	Fire and Overheat Detector	Meggitt
7101-80	Fire and Overheat Detector	Meggitt
7101-81	Fire and Overheat Detector	Meggitt
71035-3	Priority Valve	Sterer
710-469-1	Indicator	Intertechnique
710-470-2	Indicator	Intertechnique
710-509-3	Indicator	Intertechnique
710-510-3	Indicator	Intertechnique
710-511-1	Totalizer Indicator	Intertechnique
710544	Carrier Shaft assy	Hamilton Sundstrand
710586	Charge Pump	Hamilton Sundstrand
710599	Generator Scavenge Pump	Hamilton Sundstrand
710-912	Fuel Quantity Indicator	Intertechnique
710-913	Fuel Quantity Indicator	Intertechnique
710-914	Totalizer Indicator	Intertechnique
710CA28	Non-Return Check Valve	FR Hitemp
710CA28/1	Valve assy	FR Hitemp
710CA28-1	Non-Return Check Valve	FR Hitemp
710TS06Y01	Nose Wheel Steering Controller	ECE
710TS06Y02	Nose Wheel Steering Controller	ECE
710TS06Y03	Nose Wheel Steering Controller	ECE
710TS06Y06	Nose Wheel Steering Controller	ECE
710TS06Y11	Nose Wheel Steering Controller	ECE
710TS06Y12	Nose Wheel Steering Controller	ECE
710TS06Y13	Nose Wheel Steering Controller	ECE
71145-1	Solenoid Valve	Sterer
71178-1	Pitch Trimmer Manifold	Vickers
71178-2	Pitch Trimmer Manifold	Vickers
71179-1	Pitch Trimmer Manifold	Vickers
71179-2	Pitch Trimmer Manifold	Vickers
71190400010NC0A	Sampling Valve	Sofrance
71190400010NCOA	Sampling Valve	Sofrance
711916	Support Bearing	Hamilton Sundstrand
711TS06Y	Nose Wheel Steering Controller	ECE
711TS06Y01	Nose Wheel Steering Controller	ECE

Repair_Capability_List_Excel

712180	Charge Pump	Hamilton Sundstrand
712186	Scavenge Pump	Hamilton Sundstrand
7123-19973-01AA	Cabin Pressure Selector Panel	Hamilton Sundstrand
7123-19973-02AB	Cabin Pressure Selector Panel	Hamilton Sundstrand
7123-19973-03AB	Cabin Pressure Selector Panel	Hamilton Sundstrand
71234	Hand Hydraulic Pump	Hydro-Aire
712801	Scavenge Pump	Hamilton Sundstrand
712TS06Y	Nose Wheel Steering Controller	ECE
712TS06Y01	Nose Wheel Steering Controller	ECE
71300-5005	Valve	Parker-Hannifin
71300-5007	Valve	Parker-Hannifin
71300-5009	Valve	Parker-Hannifin
713185	Center Housing	Hamilton Sundstrand
713317	Input Housing	Hamilton Sundstrand
713442	Pressure Switch	Hamilton Sundstrand
71367	Hydraulic Flow Regulator	Sterer
713716	DC Actuator	Hamilton Sundstrand
713717	AC Actuator	Hamilton Sundstrand
71404	Dual Brake Metering Valve	Eaton
71404-1	Dual Brake Metering Valve	Eaton
714702	Motor Driven Variable Resistor	Hamilton Sundstrand
71476	Actuator	Eaton Aerospace
71476-1	Actuator	Eaton Aerospace
71476-4	Actuator	Eaton Aerospace
71522	Change-Over Valve	Sterer
71523	By-Pass Valve	Sterer
71538	Selector Valve	Hydro-Aire
71538-1	Selector Valve	Hydro-Aire
71538-2	Landing Gear Selector Valve	Hydro-Aire
71539	Control Valve	Crane
71539-1	NLG Door Selector Valve	Hydro-Aire
71540	Control Valve	Crane
71541	MLG Door Sequence Valve	Hydro-Aire
71541-1	MLG Door Sequence Valve	Hydro-Aire
715417	In Line Relief Valve	Vickers
715418	In Line Relief Valve	Vickers
71542	Shut-Off Valve	Crane
71543	Control Valve	Crane
715439	Relief Valve assy	Vickers
71544	Control Valve	Crane
71544-1	Control Valve	Crane
715445	Relief Valve assy	Vickers
71545	Control Valve	Crane
71545-1	Dump Valve	Hydro-Aire
71547	Control Brake	Weston Aerospace
71577-2	Brake Valve	Hydro-Aire
71577-3	Brake Valve	Hydro-Aire
71577-4	Brake Valve	Hydro-Aire
71577-5	Brake Valve	Hydro-Aire
715776	Hydraulic Pump	Vickers
71580-7	Valve	Crane
71580-8	Valve	Crane
715852	Differential assy	Hamilton Sundstrand
715874	Driven Generator Hydraulic Motor	Hamilton Sundstrand
715TS06Y11	Nose Wheel Steering Controller	ECE
715TS06Y12	Nose Wheel Steering Controller	ECE
715TS06Y13	Nose Wheel Steering Controller	ECE
716066B	Constant Speed Drive	Hamilton Sundstrand

Repair_Capability_List_Excel

716066C	Constant Speed Drive	Hamilton Sundstrand
716066D	Constant Speed Drive	Hamilton Sundstrand
716-067	Fuel Indicator	Intertechnique
716-068	Fuel Indicator	Intertechnique
716-069	Fuel Indicator	Intertechnique
716-070	Fuel Indicator	Intertechnique
716-071	Fuel Indicator	Intertechnique
716-363	Fuel Indicator	Intertechnique
716-662	Totalizer Indicator	Intertechnique
716-662-1	Totalizer Indicator	Intertechnique
716-663	Fuel Indicator	Intertechnique
716-663-1	Fuel Indicator	Intertechnique
716-664	Fuel Indicator	Intertechnique
716-664-1	Fuel Indicator	Intertechnique
716-667	Fuel Indicator	Intertechnique
716-667-1	Fuel Indicator	Intertechnique
716-668	Fuel Indicator	Intertechnique
716-668-1	Fuel Indicator	Intertechnique
716-669	Totalizer Indicator	Intertechnique
716-669-1	Totalizer Indicator	Intertechnique
716-714-1	Fuel Indicator	Intertechnique
716773	Center Housing	Hamilton Sundstrand
716-841	Totalizer Indicator	Intertechnique
716-841-1	Totalizer Indicator	Intertechnique
716BK-5-046	Rate of Climb	Kollsman
716BK-8-036	Rate of Climb	Kollsman
716BU8-036	Rate of Climb Indicator	Kollsman
716CU-X-041	Rate of Climb	Kollsman
716CU-X-055	Rate of Climb	Kollsman
716TS06Y	Nose Wheel Steering Controller	ECE
716U-03	Rate of Climb	Kollsman
717206	Input Housing	Hamilton Sundstrand
717-2500-1	Power Drive Unit	Goodrich Control Systems
717324	Charge Filter Cap	Hamilton Sundstrand
717324A	Charge Filter Cap	Hamilton Sundstrand
717327	Governor & Support	Hamilton Sundstrand
717345	Charge & Scavenge Pump	Hamilton Sundstrand
71742-2	Shuttle Valve	Hydro-Aire
717TS06Y01	Nose Wheel Steering Controller	ECE
717TS06Y12	Nose Wheel Steering Controller	ECE
717TS06Y13	Nose Wheel Steering Controller	ECE
718-053-2	Level Pack Switch	Intertechnique
718-054	Sensor	Intertechnique
718-054-1	Sensor	Intertechnique
718-055-1	Low Level Sensor	Intertechnique
718-171-1	Level Pack Switch	Intertechnique
718534	Charge & Scavenge Pump	Hamilton Sundstrand
718-541	Level Pack Switch	Intertechnique
718-557	Sensing Unit	Intertechnique
718-886	Sensor	Intertechnique
718-887	Level Pack Switch	Intertechnique
718972	Center Housing	Hamilton Sundstrand
718973	Input Housing	Hamilton Sundstrand
718-985	Level Switching Amplifier	Intertechnique
719004	Electrical Harness	Hamilton Sundstrand
719223-3	By-Pass Valve	Hamilton Standard
719223-4	By-Pass Valve	Hamilton Standard
719224-3	Valve assy	Hamilton Standard

Repair_Capability_List_Excel

719224-4	Valve assy	Hamilton Standard
71998	Valve assy	Hydro-Aire
720000-1	Bleed Valve Actuator	Hamilton Standard
720000-10	Bleed Valve Actuator	Hamilton Standard
720000-11	Bleed Valve Actuator	Hamilton Standard
720000-12	Bleed Valve Actuator	Hamilton Standard
720000-17	Bleed Valve Actuator	Hamilton Standard
720000-18	Bleed Valve Actuator	Hamilton Standard
720000-19	Bleed Valve Actuator	Hamilton Standard
720000-20	Bleed Valve Actuator	Hamilton Standard
720000-4	Bleed Valve Actuator	Hamilton Standard
720000-6	Bleed Valve Actuator	Hamilton Standard
720000-8	Bleed Valve Actuator	Hamilton Standard
720000-9	Bleed Valve Actuator	Hamilton Standard
7202-778-401	Audio Jack Box	Fokker Aircraft
7202-778-403	Audio Jack Box	Fokker Aircraft
7202-779-401	Intercom Selector Panel	Fokker Aircraft
7202-779-403	Intercom Selector Panel	Fokker Aircraft
7202-779-405	Intercom Selector Panel	Fokker Aircraft
7202-779-407	Intercom Selector Panel	Fokker Aircraft
720433-2	Zone Duct Temp. Sensor	Hamilton Sundstrand
720847	Current Transformer assy	Hamilton Sundstrand
7208A01	Non-Return Valve	Bronzavia-Air Equipement
7209055A1	Front Face Illuminated Indicating	SMS
721429	Stator Housing assy	Hamilton Sundstrand
721432	Rotor assy	Hamilton Sundstrand
7216A01	Non-Return Valve	Bronzavia-Air Equipement
7217-206-400	Nose Wheel Steering Follow-Up Mech.	Fokker Aircraft
7217-206-401	Nose Wheel Steering Follow-Up Mech.	Fokker Aircraft
7217-206-403	Nose Wheel Steering Follow-Up Mech.	Fokker Aircraft
7217-206-405	Nose Wheel Steering Follow-Up Mech.	Fokker Aircraft
7217-206-407	Nose Wheel Steering Follow-Up Mech.	Fokker Aircraft
7217-206-801	Nose Wheel Steering Follow-Up Mech.	Fokker Aircraft
7217-206-803	Nose Wheel Steering Follow-Up Mech.	Fokker Aircraft
7217-206-901	Nose Wheel Steering Follow-Up Mech.	Fokker Aircraft
72180300	Water Heater	B/E Aerospace
72180310	Water Heater	B/E Aerospace
72180320	Water Heater	B/E Aerospace
721863	Uplock	Hamilton Sundstrand
722-032	Level Sensor Harness	Intertechnique
722-100-2	Harness assy	Intertechnique
722-100-3	Harness assy	Intertechnique
722-100-4	Harness assy	Intertechnique
722-114	Level Sensor Harness	Intertechnique
722-115	Fuel Sensor Harness	Intertechnique
722-116-2	Fuel Sensor Harness	Intertechnique
722-139-1	Detector	Intertechnique
722-378	Level Sensor Control Unit	Intertechnique
722-404	Detector	Intertechnique
722-404-1	Detector	Intertechnique
722-404-2	Detector	Intertechnique
722450	Oil Level Signal Conditioner	Intertechnique
722-514	Level Sensor	Intertechnique
722-536-1	Oil Level Detector	Intertechnique
722-536-3	Oil Level Detector	Intertechnique
722610	High Level Sensor	Intertechnique
722613	Input Shaft	Hamilton Sundstrand
723001-4	Lube & Scavenge Pump	Argo-Tech

Repair_Capability_List_Excel

72340	Control Valve	Hydro-Aire
7235-1-20	Overload Sensor	B/E Aerospace
723765	Lube & Scavenge Pump	Hamilton Sundstrand
723D100-1	Sud Door Flight Lock Actuator	Eaton Aerospace
723D100-3	Sud Door Flight Lock Actuator	Eaton Aerospace
723D100-5	Sud Door Flight Lock Actuator	Eaton Aerospace
723D100-7	Sud Door Flight Lock Actuator	Eaton Aerospace
723D100-9	Sud Door Flight Lock Actuator	Eaton Aerospace
724	Tachymeter Indicator	Weston Aerospace
72407	Relief Valve	Weston Aerospace
72407-1	Relief Valve	Crane
72408	Relief Valve	Weston Aerospace
72408-1	Relief Valve	Crane
724234	DC Electric Motor	Hamilton Sundstrand
724234-2	DC Electric Motor	Hamilton Sundstrand
724234-3	DC Electric Motor	Hamilton Sundstrand
724249-2	Zone Temperature Sensor	Hamilton Sundstrand
724249-3	Zone Temperature Sensor	Hamilton Sundstrand
724249-4	Zone Temperature Sensor	Hamilton Sundstrand
724249-5	Zone Temperature Sensor	Hamilton Sundstrand
72427	Dual Hydraulic Power Brake	Crane
72427-1	Dual Hydraulic Power Brake	Crane
72427-3	Dual Hydraulic Power Brake	Crane
72428	Shut-Off Valve	Crane
72428-1	Hydraulic Shut-Off Valve	Hydro-Aire
724409	Zone Duct Temp.Sensor	Hamilton Sundstrand
724419	Zone Temp.Sensor	Hamilton Sundstrand
724423	Pack Temp.Sensor	Hamilton Sundstrand
724425-1	Compressor Overtemp Switch	Hamilton Sundstrand
724426-1	Pack Overtemp Switch	Hamilton Sundstrand
724430	Ram Air Actuator	Hamilton Sundstrand
724440	Inlet Temperature Sensor	Hamilton Sundstrand
724444	APU Signal Harness	Hamilton Sundstrand
724447	Temperature Selector	Hamilton Sundstrand
724789	Differential	Hamilton Sundstrand
724791	Center Housing	Hamilton Sundstrand
724801-4	Lube & Scavenge Pump	Argo-Tech
724912-10	Brake Servomotor	Hamilton Standard
724912-11	Brake Servomotor	Hamilton Standard
724912-12	Brake Servomotor	Hamilton Standard
724912-13	Brake Servomotor	Hamilton Standard
724912-14	Brake Servomotor	Hamilton Standard
724912-15	Brake Servomotor	Hamilton Standard
724912-17	Brake Servomotor	Hamilton Standard
724912-18	Brake Servomotor	Hamilton Standard
724912-19	Brake Servomotor	Hamilton Standard
724912-21	Brake Servomotor	MPC-Prod
724912-5	Brake Servomotor	Hamilton Standard
724912-6	Brake Servomotor	Hamilton Standard
724912-7	Brake Servomotor	Hamilton Standard
724912-8	Brake Servomotor	Hamilton Standard
724912-9	Brake Servomotor	Hamilton Standard
724D100-1	Alternate Landing Gear Actuator	Eaton Aerospace
724D100-3	Alternate Landing Gear Actuator	Eaton Aerospace
725770116B	Latch	Airbus Industrie
725820025-1	Control Panel	Air France
7258A01	Valve assy	Goodrich Control Systems
726473	Stator	Hamilton Sundstrand

Repair_Capability_List_Excel

726574-2	Pressure & Shut-Off Valve	Hamilton Standard
726574-3	Pressure & Shut-Off Valve	Hamilton Standard
726574-4	Pressure & Shut-Off Valve	Hamilton Standard
726574-5	Pressure & Shut-Off Valve	Hamilton Standard
726574-6	Pressure & Shut-Off Valve	Hamilton Standard
726574-7	Pressure & Shut-Off Valve	Hamilton Standard
7266A01	Valve assy	Goodrich Control Systems
726956A	Harness	Hamilton Sundstrand
727	Audio Selector Panel	Edo-Aire
727-1	Audio Selector Panel	Edo-Aire
727-1A	Audio Selector Panel	Edo-Aire
727-2	Audio Selector Panel	Edo-Aire
727-2A	Audio Selector Panel	Edo-Aire
727802	Current Transformer assy	Hamilton Sundstrand
727810	Auxiliary Generator	Hamilton Sundstrand
727810A	AC Auxiliary Generator	Hamilton Sundstrand
727810B	AC Auxiliary Generator	Hamilton Sundstrand
727810C	AC Auxiliary Generator	Hamilton Sundstrand
727A	Audio Selector Panel	Edo-Aire
728127	Generator and Strut	Hamilton Sundstrand
728316	Uplock Actuator assy	Hamilton Sundstrand
728403	APU Generator Adapter	Hamilton Sundstrand
728431	Ejector Jack	Hamilton Sundstrand
728514	Input Housing	Hamilton Sundstrand
728515	Center Housing	Hamilton Sundstrand
72854	By-Pass & Relief Valve	Hydro-Aire
728547	Center Housing	Hamilton Sundstrand
728716	Input Housing	Hamilton Sundstrand
728785	Charge Pump	Hamilton Sundstrand
728788	Scavenge Pump	Hamilton Sundstrand
728843	Rotor Balance assy	Hamilton Sundstrand
728901	Shaft Carrier	Hamilton Sundstrand
728905	A/C Stator	Hamilton Sundstrand
728BK-019	Pressure Manifold	Kollsman
728BK-02	Pressure Manifold	Kollsman
728BK-020	Pressure Manifold	Kollsman
728BK-04	Pressure Manifold	Kollsman
728BK-05	Pressure Manifold	Kollsman
728FU-10-04	Pressure Manifold	Kollsman
728FU-10-045	Pressure Manifold	Kollsman
728FU-10-05	Pressure Manifold	Kollsman
729	Audio Control Panel	Edo-Aire
729-1	Audio Control Panel	Edo-Aire
729-2	Audio Control Panel	Edo-Aire
729208	Electrical Harness	Hamilton Sundstrand
729208A	Electrical Harness	Hamilton Sundstrand
729208B	Electrical Harness	Hamilton Sundstrand
729209	Electrical Harness	Hamilton Sundstrand
729211	Input Housing assy	Hamilton Sundstrand
729212	Center Housing assy	Hamilton Sundstrand
729214	Pump & Motor	Hamilton Sundstrand
729215	Pump & Motor	Hamilton Sundstrand
729-3	Audio Control Panel	Edo-Aire
729302	Center Housing	Hamilton Sundstrand
729346	Stator Housing assy	Hamilton Sundstrand
729346A	Stator Housing assy	Hamilton Sundstrand
729346B	Stator Housing assy	Hamilton Sundstrand
729346C	Stator Housing assy	Hamilton Sundstrand

Repair_Capability_List_Excel

729346D	Stator Housing assy	Hamilton Sundstrand
729346E	Stator Housing assy	Hamilton Sundstrand
729346F	Stator Housing assy	Hamilton Sundstrand
729355	Rotor Balance assy	Hamilton Sundstrand
729-4	Audio Control Panel	Edo-Aire
729548D	RAT Hydraulic Pump	Hamilton Sundstrand
729548E	RAT Hydraulic Pump	Hamilton Sundstrand
729548F	RAT Hydraulic Pump	Hamilton Sundstrand
729548G	RAT Hydraulic Pump	Hamilton Sundstrand
729548H	RAT Hydraulic Pump	Hamilton Sundstrand
729548J	RAT Hydraulic Pump	Hamilton Sundstrand
729548K	RAT Hydraulic Pump	Hamilton Sundstrand
729548L	RAT Hydraulic Pump	Hamilton Sundstrand
729548M	RAT Hydraulic Pump	Hamilton Sundstrand
729638	Housing & Support-Matched Set	Hamilton Sundstrand
729641	Transmission	Hamilton Sundstrand
729699	Center Housing	Hamilton Sundstrand
72CF8944-00	Control	CBA
72CF8945-00	Control	CBA
730082	Center Housing	Hamilton Sundstrand
730-083-5	Control Box	Liebherr Aerospace
730-083-5A	Control Box	Liebherr Aerospace
730-083-5B	Control Box	Liebherr Aerospace
730-083-5C	Control Box	Liebherr Aerospace
73020	Flow Control Servovalve	Abex
7304-01-02	Fire Detection Unit - FDU	L'Hotellier
7304SE010100	HP Restrictor Valve	Bronzavia-Air Equipement
7304SE010200	HP Restrictor Valve	Bronzavia-Air Equipement
7306G01	Check Valve	Liebherr Aerospace
7306SD01	Non-Return Valve	Goodrich Control Systems
7306SE010100	HP Restrictor Valve	Bronzavia-Air Equipement
7306SE010200	HP Restrictor Valve	Bronzavia-Air Equipement
7306SF01	HP Hydraulic Non-Return Valve	Bronzavia-Air Equipement
730814	RAT Hydraulic Pump	Hamilton Sundstrand
730814B	RAT Hydraulic Pump	Hamilton Sundstrand
730814C	RAT Hydraulic Pump	Hamilton Sundstrand
730814D	RAT Hydraulic Pump	Hamilton Sundstrand
730814E	RAT Hydraulic Pump	Hamilton Sundstrand
730814F	RAT Hydraulic Pump	Hamilton Sundstrand
730814G	RAT Hydraulic Pump	Hamilton Sundstrand
730818	Ground Test Selector	Hamilton Sundstrand
730820	RAT Jack	Hamilton Sundstrand
730822A	RAT Uplock	Hamilton Sundstrand
730822B	RAT Uplock	Hamilton Sundstrand
730842	Quick Attach-Detach Kit	Hamilton Sundstrand
730844	Quick Attach-Detach Kit	Hamilton Sundstrand
730844A	Quick Attach-Detach Kit	Hamilton Sundstrand
730844B	Quick Attach-Detach Kit	Hamilton Sundstrand
7308H01	Non-Return Valve	Liebherr Aerospace
7308SD01	HP Hydraulic Non-Return Valve	Bronzavia-Air Equipement
7310SB01	HP Hydraulic Non-Return Valve	Bronzavia-Air Equipement
7310SD01	Non-Return Valve	Goodrich Control Systems
7310SE010200	HP Restrictor Valve	Bronzavia-Air Equipement
7310SE010300	HP Restrictor Valve	Bronzavia-Air Equipement
7310SE010400	HP Restrictor Valve	Bronzavia-Air Equipement
7310SE010500	HP Restrictor Valve	Bronzavia-Air Equipement
7310SE010600	HP Restrictor Valve	Bronzavia-Air Equipement
7310SE010700	HP Restrictor Valve	Bronzavia-Air Equipement

Repair_Capability_List_Excel

7310SE010800	HP Restrictor Valve	Bronzavia-Air Equipement
731111	Pressure Switch assy	Hamilton Sundstrand
7312SD01	HP Hydraulic Non-Return Valve	Bronzavia-Air Equipement
731376	Axial Flow Fan	Hamilton Sundstrand
731376A	Axial Flow Fan	Hamilton Sundstrand
731378	Axial Flow Fan	Hamilton Sundstrand
731378A	Axial Flow Fan	Hamilton Sundstrand
7-3141-1	MLG Door Actuator	Sangamoweston
7-3141-2	MLG Door Actuator	Sangamoweston
7-3141-3	MLG Door Actuator	Sangamoweston
7-3141-4	Main Gear Actuator	Sargent
731428	Hydraulic Motor Pump	Vickers
731430	Driven Motor Pump	Vickers
7316SD01	HP Hydraulic Non-Return Valve	Bronzavia-Air Equipement
7316SD02	HP Hydraulic Non-Return Valve	Bronzavia-Air Equipement
731840	Hydraulic Motorpump assy	Eaton
731879	Ejector Pump	Hamilton Sundstrand
73195	Aileron Servovalve	Abex
73196-02	Elevator Servovalve	Abex
73196-03	Elevator Servovalve	Abex
7319604	Elevator Servovalve	Abex
73196-04	Elevator Servovalve	Abex
7319605	Elevator Servovalve	Abex
73196-05	Elevator Servovalve	Abex
731966	Hydraulic Motor Pump	Vickers
732036	Stator	Vickers
732-11750-01	Isolation By-pass Check Valve	Shimadzu
732-11750-02	Isolation By-pass Check Valve	Shimadzu
732-11750-03	Isolation By-pass Check Valve	Shimadzu
732-13380-03	Valve	Shimadzu
732-13650-06	Cargo Door Power Drive Unit	Shimadzu Precision
732-13650-07	Cargo Door Power Drive Unit	Shimadzu Precision
732-13650-09	Cargo Door Power Drive Unit	Shimadzu Precision
732-13650-10	Cargo Door Power Drive Unit	Shimadzu Precision
732-13650-11	Cargo Door Power Drive Unit	Shimadzu Precision
732-13650-12	Cargo Door Power Drive Unit	Shimadzu Precision
732-13650-13	Cargo Door Power Drive Unit	Shimadzu Precision
732-13650-14	Cargo Door Power Drive Unit	Shimadzu Precision
732-13650-15	Cargo Door Power Drive Unit	Shimadzu Precision
732-13870-01	Actuator	Shimadzu Precision
732-13870-02	Actuator	Shimadzu Precision
732-13870-03	Actuator	Shimadzu Precision
732-13870-04	Actuator	Shimadzu Precision
732-13870-05	Actuator	Shimadzu Precision
732-13870-06	APU Door Actuator	Shimadzu
732-13870-07	Actuator	Shimadzu Precision
732-13870-09	Actuator	Shimadzu Precision
732-13870-10	PDU Door Actuator	Shimadzu
732-13870-11	Actuator	Shimadzu Precision
732-13870-12	Actuator	Shimadzu Precision
732-13870-13	Actuator	Shimadzu Precision
732-16810-01	Trim Actuator	Shimadzu Precision
732-16810-03	Trim Actuator	Shimadzu Precision
732-16810-05	Trim Actuator	Shimadzu Precision
732-16830-01	Actuator	Shimadzu Precision
732-16830-02	Actuator	Shimadzu Precision
732-16870-01	Door Actuator	Shimadzu
732-16870-02	Door Actuator	Shimadzu

Repair_Capability_List_Excel

732-18550-01	Control Valve	Shimadzu
732-18550-02	Control Valve	Shimadzu
732-18550-03	Control Valve	Shimadzu
732-18550-04	Control Valve	Shimadzu
732-18550-05	Control Valve	Shimadzu
732-18550-06	Control Valve	Shimadzu
732-18550-07	Control Valve	Shimadzu
732-18550-08	Control Valve	Shimadzu
732-18550-09	Control Valve	Shimadzu
732-18550-10	Control Valve	Shimadzu
732-18550-11	Control Valve	Shimadzu
732-18550-12	Control Valve	Shimadzu
732-18550-13	Control Valve	Shimadzu
732-18600-02	Motor Valve assy	Shimadzu
732654	Center Housing	Hamilton Sundstrand
732678	Governor and Support	Hamilton Sundstrand
733742	Stator Housing	Hamilton Sundstrand
733742A	Stator Housing	Hamilton Sundstrand
733742B	Stator Housing	Hamilton Sundstrand
733742C	Stator Housing	Hamilton Sundstrand
733742D	Stator Housing	Hamilton Sundstrand
733742E	Stator Housing	Hamilton Sundstrand
733756	Pump & Motor assy	Hamilton Sundstrand
733756A	Pump & Motor assy	Hamilton Sundstrand
733756B	Pump & Motor assy	Hamilton Sundstrand
733756C	Pump & Motor assy	Hamilton Sundstrand
733756D	Pump & Motor assy	Hamilton Sundstrand
733756E	Pump & Motor assy	Hamilton Sundstrand
733757	Pump & Motor assy	Hamilton Sundstrand
733757A	Pump & Motor assy	Hamilton Sundstrand
733757B	Pump & Motor assy	Hamilton Sundstrand
733757C	Pump & Motor assy	Hamilton Sundstrand
733757D	Pump & Motor assy	Hamilton Sundstrand
733914	Engine HP Bleed Valve	Hamilton Sundstrand
733915	Engine Isolation Valve	Hamilton Sundstrand
733926-10	Flow Control Valve	Hamilton Sundstrand
733926-11	Flow Control Valve	Hamilton Sundstrand
733926-12	Flow Control Valve	Hamilton Sundstrand
733926-13	Flow Control Valve	Hamilton Sundstrand
733926-14	Flow Control Valve	Hamilton Sundstrand
733926-15	Flow Control Valve	Hamilton Sundstrand
733926-4	Flow Control Valve	Hamilton Sundstrand
733926-7	Flow Control Valve	Hamilton Sundstrand
733926-9	Flow Control Valve	Hamilton Sundstrand
733927	Manifold Temp.Control Valve	Hamilton Sundstrand
733930	Water Separator	Hamilton Sundstrand
733946	Manifold Temp.Control Valve	Hamilton Sundstrand
733949	Dual Heat Exchanger	Hamilton Sundstrand
733A0000-01	Valve	Liebherr Aerotechnik
734-16100-01	Linear Actuator	Shimadzu
734-17360-02	MLG Truck Positioner Actuator	Shimadzu
734-17360-03	MLG Truck Positioner Actuator	Shimadzu
734177	Flap Power Drive Unit	Hamilton Sundstrand
734-17980-01	Valve	Shimadzu
734181	Flap Drive Actuator assy	Hamilton Sundstrand
734183	Flap Drive Transfer Gearbox assy	Hamilton Sundstrand
734185	Flap Drive Torque Sensor assy	Hamilton Sundstrand
734-18510-01	Sequence Valve	Shimadzu

Repair_Capability_List_Excel

734-18520-01	Sequence Valve	Shimadzu
734-18530-01	Sequence Valve	Shimadzu
734187	Flap Drive Torque Tube assy	Hamilton Sundstrand
734216	Flap Drive Actuator assy	Hamilton Sundstrand
734285	AC Externeal Power Control	Hamilton Sundstrand
734285A	AC Externeal Power Control	Hamilton Sundstrand
734285B	AC Externeal Power Control	Hamilton Sundstrand
734285C	AC Externeal Power Control	Hamilton Sundstrand
734285D	AC Externeal Power Control	Hamilton Sundstrand
734285E	AC Externeal Power Control	Hamilton Sundstrand
734350D	Turbine Leg	Sundstrand
734374	Flap Drive Actuator assy	Hamilton Sundstrand
734378	Flap Drive Torque Tube assy	Hamilton Sundstrand
734380	Flap Drive Torque Tube assy	Hamilton Sundstrand
734382	Flap Drive Torque Tube assy	Hamilton Sundstrand
734383	Flap Drive Torque Tube assy	Hamilton Sundstrand
734384	Flap Drive Torque Tube assy	Hamilton Sundstrand
734386	Flap Drive Torque Tube assy	Hamilton Sundstrand
734388	Flap Drive Torque Tube assy	Hamilton Sundstrand
734444	Remote Temperature Sensor	Hamilton Sundstrand
734933	Ground Checkout Module	Hamilton Sundstrand
735509	Ground Test Selector	Hamilton Sundstrand
735511	Comstant Speed Transmission	Hamilton Sundstrand
735615	Wiring Harness	Hamilton Sundstrand
735619	Flex Shaft Coupling assy	Hamilton Sundstrand
735-632-3	Hydraulic System Monitoring Unit	Intertechnique
735-632-4	Hydraulic System Monitoring Unit	Intertechnique
735-632-41	Hydraulic System Monitoring Unit	Intertechnique
735-632-42	Hydraulic System Monitoring Unit	Intertechnique
735-632-5	Hydraulic System Monitoring Unit	Intertechnique
735697	Input Housing	Hamilton Sundstrand
735961	Direct Current Motor assy	Hamilton Sundstrand
736-033	Fuel Quantity Amplifier	Intertechnique
736-153	Amplifier	Intertechnique
736-153-1	Amplifier	Intertechnique
736-153-2	Amplifier	Intertechnique
736692	Stator Housing	Hamilton Sundstrand
736692A	Stator Housing	Hamilton Sundstrand
736692B	Stator Housing	Hamilton Sundstrand
736692C	Stator Housing	Hamilton Sundstrand
736692D	Stator Housing	Hamilton Sundstrand
736692E	Stator Housing	Hamilton Sundstrand
737837	Pump & Motor	Hamilton Sundstrand
737856	Current Transformer	Hamilton Sundstrand
738057	APU Surge Valve	Hamilton Sundstrand
738058	Surge Valve Control	Hamilton Sundstrand
738062	Inlet Guide Vane assy	Hamilton Sundstrand
738066-1	Low Oil Pressure Switch	Hamilton Sundstrand
738066-2	Low Oil Pressure Switch	Hamilton Sundstrand
738067	APU Power Harness	Hamilton Sundstrand
738075	Clogged Fuel Filter Switch	Hamilton Sundstrand
738084	APU Starter Harness	Hamilton Sundstrand
738461	Inversion Pump	Hamilton Sundstrand
738461A	Inversion Pump	Hamilton Sundstrand
738461B	Inversion Pump	Hamilton Sundstrand
738719	Oil/Fuel Heater	Hamilton Sundstrand
738750	Load Hardware Gearbox	Hamilton Sundstrand
738833	Eklapsed Time Indicator	Hamilton Sundstrand

Repair_Capability_List_Excel

738850	APU Exhaust Muffler	Hamilton Sundstrand
739047-1	Pressure & Shut-Off Valve	Hamilton Standard
739047-2	Pressure & Shut-Off Valve	Hamilton Standard
739047-3	Pressure & Shut-Off Valve	Hamilton Standard
739047-4	Pressure & Shut-Off Valve	Hamilton Standard
739064	Bleed Air Mix Ejector	Hamilton Sundstrand
739069	Ram Cooling Header	Hamilton Sundstrand
739071	Pack Ice Sensor	Hamilton Sundstrand
739084	Engine HP Bleed Valve Control	Hamilton Sundstrand
739162	Bleed Air Temperature Sensor	Hamilton Sundstrand
739CK8-015	Airspeed Indicator	Kollsman
739CU4-030	Airspeed Indicator	Kollsman
739CU4-034	Airspeed Indicator	Kollsman
739CU5-015	Airspeed Indicator	Kollsman
739CX4-023	Airspeed Indicator	Kollsman
739CX4-028	Airspeed Indicator	Kollsman
739CX8-015	Airspeed Indicator	Kollsman
739DX10-057	Sensitive Airspeed Indicator	Kollsman
739DX4-056	Sensitive Airspeed Indicator	Kollsman
739DX4-057	Sensitive Airspeed Indicator	Kollsman
73E61-1	Discharge Downstream Valve	Aeroquip Vickers
74003	Servo Valve	Abex
740161	Water Aspirator	Hamilton Sundstrand
740179-10	Pneumatic Starter	Hamilton Standard
740179-11	Pneumatic Starter	Hamilton Standard
740179-12	Pneumatic Starter	Hamilton Standard
740179-13	Pneumatic Starter	Hamilton Standard
740179-3	Pneumatic Starter	Hamilton Standard
740179-4	Pneumatic Starter	Hamilton Standard
740179-5	Pneumatic Starter	Hamilton Standard
740179-6	Pneumatic Starter	Hamilton Standard
740179-7	Pneumatic Starter	Hamilton Standard
740179-8	Pneumatic Starter	Hamilton Standard
740179-9	Pneumatic Starter	Hamilton Standard
7404SB01	HP Hydraulic Non-Return Valve	Bronzavia-Air Equipement
7404SB02	HP Hydraulic Non-Return Valve	Bronzavia-Air Equipement
740516	Current Transformer	Hamilton Sundstrand
740520	APU Generator	Hamilton Sundstrand
7-40538-1	Control Cable	Triumph Controls
7406SB01	HP Hydraulic Non-Return Valve	Bronzavia-Air Equipement
740742	Diffuser Housing	Hamilton Sundstrand
740743	Inlet Shell	Hamilton Sundstrand
740817-10	Sensor	Hamilton Standard
7408SB01	Non-Return Valve	Bronzavia-Air Equipement
7410SB01	Non-Return Valve	Bronzavia-Air Equipement
7412SB01	HP Hydraulic Non-Return Valve	Bronzavia-Air Equipement
741426-125	Cable assy	Burndy Corporation
741609	IGV Feedback Transducer	Hamilton Sundstrand
741756	Stator Housing assy	Hamilton Sundstrand
741801	Zone Trim Overtemp.Switch	Hamilton Sundstrand
7-42114	TR Control System	Triumph Controls
7422001-1	Roller Tray ay	Goodrich
7422001-2	Roller Tray ay	Goodrich
7422002-1	Roller Tray ay	Goodrich
7422002-2	Roller Tray ay	Goodrich
7422012-1	Roller Tray ay	Goodrich
7422012-2	Roller Tray ay	Goodrich
7422022-1	Roller Tray ay	Goodrich

Repair_Capability_List_Excel

7422022-2	Roller Tray ay	Goodrich
7422023-1	Roller Tray ay	Goodrich
7422023-2	Roller Tray ay	Goodrich
7422030-2	Ladder ay	Goodrich
7422030-3	Ladder ay	Goodrich
7422030-4	Ladder ay	Goodrich
7422030-5	Ladder ay	Goodrich
7422030-8	Ladder ay	Goodrich
7422031-1	Ladder Tray ay	Goodrich
7422032-1	Ladder Tray ay	Goodrich
7422033-1	Roller Tray ay	Goodrich
7422401-1	Roller Tray ay	Goodrich
7422401-2	Roller Tray ay	Goodrich
7422411-1	Roller Tray ay	Goodrich
7422411-2	Roller Tray ay	Goodrich
7422421-1	Roller Tray ay	Goodrich
7422421-2	Roller Tray ay	Goodrich
7422431-1	Ladder Tray ay	Goodrich
7422960-1	Roller Panel ay	Goodrich
7422970-1	Roller Panel ay	Goodrich
7422980-1	Roller Panel ay	Goodrich
7422980-2	Roller Panel ay	Goodrich
7422990-1	Roller Panel ay	Goodrich
7422990-2	Roller Panel ay	Goodrich
7423101-1	Guide ay	Goodrich
7423101-2	Guide ay	Goodrich
7423102-1	Guide ay	Goodrich
7423102-2	Guide ay	Goodrich
7423103-1	Guide ay	Goodrich
7423103-2	Guide ay	Goodrich
7423104-1	Guide ay	Goodrich
7423105-1	Guide ay	Goodrich
7423106-1	Guide ay	Goodrich
7423107-1	Guide ay	Goodrich
7423107-2	Guide ay	Goodrich
7423107-3	Guide ay	Goodrich
7423108-1	Guide ay	Goodrich
7423108-2	Guide ay	Goodrich
7423108-3	Guide ay	Goodrich
7423109-1	Guide ay	Goodrich
7423109-2	Guide ay	Goodrich
7423110-1	Guide ay	Goodrich
7423110-2	Guide ay	Goodrich
7423111-1	Guide ay	Goodrich
7423112-1	Guide ay	Goodrich
7423112-2	Guide ay	Goodrich
7423113-1	Guide ay	Goodrich
7423113-2	Guide ay	Goodrich
7423114-1	Guide ay	Goodrich
7423115-1	Guide Roller ay	Goodrich
7423116-1	Guide Roller ay	Goodrich
7423117-1	Guide Roller ay	Goodrich
7423118-1	Guide Roller ay	Goodrich
7423118-2	Guide Roller ay	Goodrich
7423237-1	Guide ay	Goodrich
7423237-2	Guide ay	Goodrich
7423242-1	Guide ay	Goodrich
7423242-2	Guide ay	Goodrich

Repair_Capability_List_Excel

7423245-1	Guide ay	Goodrich
7423246-1	Guide ay	Goodrich
7423267-1	Guide ay	Goodrich
7425030-1	Guide ay	Goodrich
7425030-2	Guide ay	Goodrich
7425050-1	Pallet Lock ay	Goodrich
7425099-3	Stop ay	Goodrich
7425100-1	Restraint ay	Goodrich
7425100-2	Restraint ay	Goodrich
7425140-3	Ladder ay	Goodrich
7425150-1	Guide ay	Goodrich
7425180-3	Stop and Lock ay	Goodrich
7425180-4	Stop and Lock ay	Goodrich
7425220-2	Stop ay	Goodrich
7425230-1	Retractable Stop ay	Goodrich
7425230-2	Retractable Stop ay	Goodrich
7425281-1	Restraint ay	Goodrich
7425281-2	Restraint ay	Goodrich
7425285-1	Stop ay	Goodrich
7425300-1	Pallet Lock ay	Goodrich
7425300-2	Pallet Lock ay	Goodrich
7425300-3	Pallet Lock ay	Goodrich
7426000-1	Ball Panel ay	Goodrich
7426020-1	Ball Panel ay	Goodrich
7426040-1	Ball Panel ay	Goodrich
7426060-1	Ball Panel ay	Goodrich
7426080-1	Ball Panel ay	Goodrich
7426100-1	Ball Panel ay	Goodrich
7426120-1	Ball Panel ay	Goodrich
7426140-1	Ball Panel ay	Goodrich
7426160-1	Ball Panel ay	Goodrich
7426180-1	Ball Panel ay	Goodrich
7426200-1	Ball Panel ay	Goodrich
7426220-1	Ball Panel ay	Goodrich
7426240-1	Ball Panel ay	Goodrich
7426260-1	Ball Panel ay	Goodrich
7426280-1	Ball Panel ay	Goodrich
7426300-1	Ball Panel ay	Goodrich
7426320-1	Ball Panel ay	Goodrich
7426340-1	Ball Panel ay	Goodrich
7426360-1	Ball Panel ay	Goodrich
7426380-1	Ball Panel ay	Goodrich
7426405-1	Ball Channel ay	Goodrich
7426405-2	Ball Channel ay	Goodrich
7426410-1	Power Drive Unit Filler Panel ay	Goodrich
7426430-1	Ball Panel ay	Goodrich
7426440-1	Ball Panel ay	Goodrich
7426450-1	Ball Panel ay	Goodrich
7426470-1	Ball Panel ay	Goodrich
7426480-1	Ball Panel ay	Goodrich
742824-1	Turbine By-Pass Valve Actuator	Hamilton Sundstrand
742824-2	Turbine By-Pass Valve Actuator	Hamilton Sundstrand
742824-3	Turbine By-Pass Valve Actuator	Hamilton Sundstrand
742824-4	Turbine By-Pass Valve Actuator	Hamilton Sundstrand
742868-1	Ram Air Valve Actuator	Hamilton Sundstrand
742868-2	Ram Air Valve Actuator	Hamilton Sundstrand
742868-3	Ram Air Valve Actuator	Hamilton Sundstrand
742868-4	Ram Air Valve Actuator	Hamilton Sundstrand

Repair_Capability_List_Excel

742868-5	Ram Air Valve Actuator	Hamilton Sundstrand
742E000-1	Lower Lobe Control Panel ay	Goodrich
742E000-2	Lower Lobe Control Panel ay	Goodrich
743407	Flap Drive Drag Brake assy	Hamilton Sundstrand
745554	Flap Drive Torque Sensor assy	Hamilton Sundstrand
745581	Flexible Shaft assy	Hamilton Sundstrand
745583	Flexible Shaft assy	Hamilton Sundstrand
745593	Flexible Shaft assy	Hamilton Sundstrand
745608	Fuel Heater	Pratt & Whitney
745A0000-01	Valve assy	Goodrich Control Systems
745A0000-02	Valve assy	Goodrich Control Systems
746078	Cylinder assy	Messier-Bugatti
746078.102	Cylinder assy	Snecma Hispano-Suiza
746078-1	Cylinder assy	Messier-Bugatti
746078-101	Cylinder assy	Messier-Hispano
746078-102	Cylinder assy	Snecma Hispano-Suiza
746078-2	Cylinder assy	Messier-Bugatti
746161-1	Cylinder assy	Messier-Bugatti
746161-101	Cylinder assy	Messier-Bugatti
746277	Stator Housing	Hamilton Sundstrand
746277A	Stator Housing	Hamilton Sundstrand
746277B	Stator Housing	Hamilton Sundstrand
746277C	Stator Housing	Hamilton Sundstrand
746277D	Stator Housing	Hamilton Sundstrand
746A0000-04	Trim Air Pressure Valve	Liebherr Aerotechnik
746A0000-05	Trim Air Pressure Valve	Liebherr Aerotechnik
746A0000-06	Trim Air Pressure Valve	Liebherr Aerotechnik
747-5100-1-0A	Power Unit	Lucas Western
747-5100-1-0	Power Unit	Lucas Western
747-5100-2-0	Power Unit	Lucas Western
747-5100-2-0A	Power Unit	Lucas Western
747-5100-5-0	Power Unit	Lucas Western
747-5100-6-0	Power Unit	Lucas Western
747-5100-6-0A	Power Unit	Lucas Western
747-5700-1-0	Linear Actuator	Goodrich
747-5700-2-0	Linear Actuator	Goodrich
747-5700-3-0	Linear Actuator	Goodrich
747-5700-4-0	Linear Actuator	Goodrich
747-5700-5-0	Linear Actuator	Goodrich
747-5750-1-0	Brake	Goodrich
747-5826-1-0	Motor	Goodrich
747660	HP Overpressure Switch	Hamilton Sundstrand
747661	Overpressure Shut-off Valve	Hamilton Sundstrand
747740	Stator Housing	Hamilton Sundstrand
747740C	Stator Housing	Hamilton Sundstrand
747743	Pump & Motor assy	Hamilton Sundstrand
747743A	Pump & Motor assy	Hamilton Sundstrand
747744	Pump & Motor assy	Hamilton Sundstrand
747744A	Pump & Motor assy	Hamilton Sundstrand
747744B	Pump & Motor assy	Hamilton Sundstrand
747749	Pump assy	Hamilton Sundstrand
747750	Pump assy	Hamilton Sundstrand
747753	Shaft Carrier	Hamilton Sundstrand
747753A	Shaft Carrier	Hamilton Sundstrand
747763	Pressure Switch	Hamilton Sundstrand
747765	Harness	Hamilton Sundstrand
747767	Support	Hamilton Sundstrand
747768	Rotor Balance assy	Hamilton Sundstrand

Repair_Capability_List_Excel

747768A	Rotor Balance assy	Hamilton Sundstrand
747768B	Rotor Balance assy	Hamilton Sundstrand
747-8000-1	Cart Lift ay	Goodrich
747-8000-2	Cart Lift ay	Goodrich
747-8000-3	Cart Lift ay	Goodrich
747-8000-4	Cart Lift ay	Goodrich
747-8000-5	Cart Lift ay	Goodrich
747-8002-1	Lift Car ay	Goodrich
747-8002-2	Lift Car ay	Goodrich
747-8002-7	Lift Car ay	Goodrich
747-8002-8	Lift Car ay	Goodrich
747892-1	Actuating Cylinder	Messier-Bugatti
747892-103	Actuating Cylinder	Messier-Bugatti
747892-104	Actuating Cylinder	Messier-Bugatti
747892-1-1	Actuating Cylinder	Messier-Bugatti
747892-1-2	Actuating Cylinder	Messier-Bugatti
747892-3	Actuating Cylinder	Messier-Bugatti
747892-301	Actuating Cylinder	Messier-Bugatti
747892-302	Actuating Cylinder	Messier-Bugatti
747892-401	Actuating Cylinder	Messier-Bugatti
747892-402	Actuating Cylinder	Messier-Bugatti
747-9000-1	Cart Lift ay	Goodrich
747-9000-2	Cart Lift ay	Goodrich
747-9000-3	Cart Lift ay	Goodrich
747-9000-4	Cart Lift ay	Goodrich
747-9002-1	Lift Car ay	Goodrich
747-9002-2	Lift Car ay	Goodrich
747-9002-3	Lift Car ay	Goodrich
747-9100-1	Cart Lift ay	Goodrich
747-9100-2	Cart Lift ay	Goodrich
747-9100-3	Cart Lift ay	Goodrich
747-9100-4	Cart Lift ay	Goodrich
747-9100-5	Cart Lift ay	Goodrich
747-9102-1	Lift Car ay	Goodrich
747-9102-5	Lift Car ay	Goodrich
747-9102-6	Lift Car ay	Goodrich
747-9102-7	Lift Car ay	Goodrich
747-9200-1	Cart Lift ay	Goodrich
747-9200-10	Cart Lift ay	Goodrich
747-9200-11	Cart Lift ay	Goodrich
747-9200-12	Cart Lift ay	Goodrich
747-9200-13	Cart Lift ay	Goodrich
747-9200-2	Cart Lift ay	Goodrich
747-9200-3	Cart Lift ay	Goodrich
747-9200-4	Cart Lift ay	Goodrich
747-9200-5	Cart Lift ay	Goodrich
747-9200-6	Cart Lift ay	Goodrich
747-9200-7	Cart Lift ay	Goodrich
747-9200-8	Cart Lift ay	Goodrich
747-9200-9	Cart Lift ay	Goodrich
747-9202-1	Lift Car ay	Goodrich
747-9202-10	Lift Car ay	Goodrich
747-9202-14	Lift Car ay	Goodrich
747-9202-15	Lift Car ay	Goodrich
747-9202-4	Lift Car ay	Goodrich
747-9202-5	Lift Car ay	Goodrich
747-9202-6	Lift Car ay	Goodrich
747-9202-7	Lift Car ay	Goodrich

Repair_Capability_List_Excel

747-9202-8	Lift Car ay	Goodrich
747-9202-9	Lift Car ay	Goodrich
747A0000-02	Water Extractor	Liebherr Aerotechnik
747A0000-03	Water Extractor	Liebherr Aerotechnik
748-099	Fuel Quantity Indicator	Intertechnique
748443	Output Housing	Hamilton Sundstrand
748-465-4	Fuel Quantity Indicator	Intertechnique
748-465-5	Fuel Quantity Indicator	Intertechnique
748-522-1	Fuel Quantity Indicator	Intertechnique
748-522-2	Fuel Quantity Indicator	Intertechnique
748-681-1	Fuel Quantity Indicator	Intertechnique
748-681-2	Fuel Quantity Indicator	Intertechnique
748-682-1	Fuel Quantity Indicator	Intertechnique
748-682-2	Fuel Quantity Indicator	Intertechnique
748-722	Repeater Indicator	Intertechnique
748-724	Repeater Indicator	Intertechnique
748A0000-04	Anti-Ice Valve	Goodrich Control Systems
748A0000-05	Anti-Ice Valve	Goodrich Control Systems
748A0000-07	Anti-Ice Valve	Goodrich Control Systems
748A0000-08	Anti-Ice Valve	Goodrich Control Systems
748B0000-01	Anti-Ice Valve	Goodrich Control Systems
749058	Bleed Temperature Sequence Switch	Hamilton Sundstrand
749-158	Fuel Quantity Indicator	Intertechnique
749-159	Fuel Quantity Indicator	Intertechnique
749-160	Fuel Quantity Indicator	Intertechnique
749-161	Fuel Quantity Indicator	Intertechnique
749188	Triple Pressure Indicator	Intertechnique
749-188	Triple Pressure Indicator	Intertechnique
749198-1	Hydraulic Reservoir	Messier-Bugatti
749198-2	Hydraulic Reservoir	Messier-Bugatti
749382	Hydromechanical Spoiler Selector	Messier-Bugatti
749-757	Fuel Quantity Indicator	Intertechnique
749-758	Fuel Quantity Indicator	Intertechnique
749-759	Fuel Quantity Indicator	Intertechnique
749-760	Fuel Quantity Indicator	Intertechnique
749965	Oil Cooler	Pratt & Whitney
749A0000-02	Air Plenum Chamber	Liebherr Aerotechnik
75-0130-1	Annunciator Indicator Light	Grimes Aerospace
75-0148-1	Annunciator Panel	Grimes Aerospace
75-0148-11	Annunciator Panel	Grimes Aerospace
75-0148-13	Annunciator Panel	Grimes Aerospace
75-0148-15	Annunciator Panel	Grimes Aerospace
75-0148-17	Annunciator Panel	Grimes Aerospace
75-0148-19	Annunciator Panel	Grimes Aerospace
75-0148-21	Annunciator Panel	Grimes Aerospace
75-0148-23	Annunciator Panel	Grimes Aerospace
75-0148-25	Annunciator Panel	Grimes Aerospace
75-0148-27	Annunciator Panel	Grimes Aerospace
75-0148-29	Annunciator Panel	Grimes Aerospace
75-0148-3	Annunciator Panel	Grimes Aerospace
75-0148-31	Annunciator Panel	Grimes Aerospace
75-0148-33	Annunciator Panel	Grimes Aerospace
75-0148-35	Annunciator Panel	Grimes Aerospace
75-0148-5	Annunciator Panel	Grimes Aerospace
75-0148-7	Annunciator Panel	Grimes Aerospace
75-0148-9	Annunciator Panel	Grimes Aerospace
75-0149-1	Light	Grimes Aerospace
75-0149-10	Light	Grimes Aerospace

Repair_Capability_List_Excel

75-0149-11	Light	Grimes Aerospace
75-0149-12	Light	Grimes Aerospace
75-0149-13	Light	Grimes Aerospace
75-0149-14	Light	Grimes Aerospace
75-0149-15	Light	Grimes Aerospace
75-0149-16	Light	Grimes Aerospace
75-0149-17	Light	Grimes Aerospace
75-0149-18	Light	Grimes Aerospace
75-0149-19	Light	Grimes Aerospace
75-0149-2	Light	Grimes Aerospace
75-0149-20	Light	Grimes Aerospace
75-0149-21	Light	Grimes Aerospace
75-0149-25	Light	Grimes Aerospace
75-0149-26	Light	Grimes Aerospace
75-0149-27	Light	Grimes Aerospace
75-0149-28	Light	Grimes Aerospace
75-0149-29	Light	Grimes Aerospace
75-0149-3	Light	Grimes Aerospace
75-0149-30	Light	Grimes Aerospace
75-0149-31	Light	Grimes Aerospace
75-0149-32	Light	Grimes Aerospace
75-0149-33	Light	Grimes Aerospace
75-0149-34	Light	Grimes Aerospace
75-0149-35	Light	Grimes Aerospace
75-0149-36	Light	Grimes Aerospace
75-0149-37	Light	Grimes Aerospace
75-0149-38	Light	Grimes Aerospace
75-0149-4	Light	Grimes Aerospace
75-0149-40	Light	Grimes Aerospace
75-0149-41	Light	Grimes Aerospace
75-0149-42	Light	Grimes Aerospace
75-0149-43	Light	Grimes Aerospace
75-0149-44	Light	Grimes Aerospace
75-0149-45	Light	Grimes Aerospace
75-0149-46	Light	Grimes Aerospace
75-0149-47	Light	Grimes Aerospace
75-0149-48	Light	Grimes Aerospace
75-0149-49	Light	Grimes Aerospace
75-0149-5	Light	Grimes Aerospace
75-0149-50	Light	Grimes Aerospace
75-0149-51	Light	Grimes Aerospace
75-0149-52	Light	Grimes Aerospace
75-0149-53	Light	Grimes Aerospace
75-0149-54	Light	Grimes Aerospace
75-0149-55	Light	Grimes Aerospace
75-0149-56	Light	Grimes Aerospace
75-0149-57	Light	Grimes Aerospace
75-0149-58	Light	Grimes Aerospace
75-0149-59	Light	Grimes Aerospace
75-0149-6	Light	Grimes Aerospace
75-0149-60.61	Light	Grimes Aerospace
75-0149-62	Light	Grimes Aerospace
75-0149-63	Light	Grimes Aerospace
75-0149-64	Light	Grimes Aerospace
75-0149-65	Light	Grimes Aerospace
75-0149-66	Light	Grimes Aerospace
75-0149-67	Light	Grimes Aerospace
75-0149-68	Light	Grimes Aerospace

Repair_Capability_List_Excel

75-0149-69	Light	Grimes Aerospace
75-0149-7	Light	Grimes Aerospace
75-0149-70	Light	Grimes Aerospace
75-0149-71	Light	Grimes Aerospace
75-0149-73	Light	Grimes Aerospace
75-0149-75	Light	Grimes Aerospace
75-0149-77	Light	Grimes Aerospace
75-0149-79	Light	Grimes Aerospace
75-0149-8	Light	Grimes Aerospace
75-0149-9	Light	Grimes Aerospace
75-0169-1	Light	Grimes Aerospace
75-0169-3	Light	Grimes Aerospace
75-0169-5	Generator System Annunciator Panel	Grimes Aerospace
7502-15-A8-1	Pressure Transmitter	Pioneer
75-0434-1	Caution & Advisory Annunciator Panel	Grimes Aerospace
75-0434-3	Caution & Advisory Annunciator Panel	Grimes Aerospace
75-0434-5	Caution & Advisory Annunciator Panel	Grimes Aerospace
75-0434-7	Caution & Advisory Annunciator Panel	Grimes Aerospace
750503	Zone Trim Pressure Regulator	Hamilton Sundstrand
750659-1	Overtemperature Switch	Hamilton Sundstrand
750659-10	Overtemperature Switch	Hamilton Sundstrand
750659-11	Overtemperature Switch	Hamilton Sundstrand
750659-12	Overtemperature Switch	Hamilton Sundstrand
750659-13	Overtemperature Switch	Hamilton Sundstrand
750659-14	Overtemperature Switch	Hamilton Sundstrand
750659-15	Overtemperature Switch	Hamilton Sundstrand
750659-16	Overtemperature Switch	Hamilton Sundstrand
750659-17	Overtemperature Switch	Hamilton Sundstrand
750659-3	Overtemperature Switch	Hamilton Sundstrand
750659-4	Overtemperature Switch	Hamilton Sundstrand
750659-5	Overtemperature Switch	Hamilton Sundstrand
750659-6	Overtemperature Switch	Hamilton Sundstrand
750659-7	Overtemperature Switch	Hamilton Sundstrand
750659-8	Overtemperature Switch	Hamilton Sundstrand
750659-9	Overtemperature Switch	Hamilton Sundstrand
750662-1	Water Separator	Hamilton Sundstrand
750662-2	Water Separator	Hamilton Sundstrand
750662-8	Water Separator	Hamilton Sundstrand
750665-1	Overtemperature Switch	Hamilton Sundstrand
750665-2	Overtemperature Switch	Hamilton Sundstrand
750665-3	Overtemperature Switch	Hamilton Sundstrand
750665-4	Overtemperature Switch	Hamilton Sundstrand
750665-5	Overtemperature Switch	Hamilton Sundstrand
750665-6	Overtemperature Switch	Hamilton Sundstrand
750665-7	Overtemperature Switch	Hamilton Sundstrand
750665-8	Overtemperature Switch	Hamilton Sundstrand
750665-9	Overtemperature Switch	Hamilton Sundstrand
750886-1	Brake Accumulator	Messier-Bugatti
750886-101	Brake Accumulator	Messier-Bugatti
750886-102	Brake Accumulator	Messier-Bugatti
750A0000-02	Trim Air Valve	Liebherr Aerotechnik
750A0000-02 Amdt A	Trim Air Valve	Liebherr Aerotechnik
750A0000-02 Amdt A & B	Trim Air Valve	Liebherr Aerotechnik
750A0000-02 Amdt B	Trim Air Valve	Liebherr Aerotechnik
750A0000-02 Amdt C	Trim Air Valve	Liebherr Aerotechnik
750A0000-02 Amdt D	Trim Air Valve	Liebherr Aerotechnik
750B0000-01	Trim Air Valve	Liebherr Aerotechnik
75130	Flow Control Servovalve	Abex

Repair_Capability_List_Excel

751909	APU Surge Valve	Hamilton Sundstrand
751A0000-03	Flow Control Valve	Liebherr Aerospace
751A0000-04	Flow Control Valve	Liebherr Aerospace
751A0000-05	Flow Control Valve	Liebherr Aerospace
751A0000-06	Flow Control Valve	Liebherr Aerospace
751A0000-07	Flow Control Valve	Liebherr Aerospace
751B0000-01	Flow Control Valve	Goodrich Control Systems
751B0000-02	Flow Control Valve	Goodrich Control Systems
751BK-02	Tachymeter	Kollsman
751CK-02	Tachymeter	Kollsman
751K-02	Tachymeter	Kollsman
752	AC Tachymeter Indicator	Weston Aerospace
752161A	Attach/Detach Quick Adapter Kit	Sundstrand
7530333	Valve assy	Bavaria A.T.
7530334	Temperature Selector	Bavaria A.T.
753302	Differential Pressure Switch	Hamilton Sundstrand
753355-4	Heat Exchanger	Hamilton Sundstrand
753355-8	Heat Exchanger	Hamilton Sundstrand
753355-9	Heat Exchanger	Hamilton Sundstrand
753490A	Stator & PMG Housing assy	Hamilton Sundstrand
753490B	Stator & PMG Housing assy	Hamilton Sundstrand
753490C	Stator & PMG Housing assy	Hamilton Sundstrand
753493A	Supply and Scavenge Pump	Hamilton Sundstrand
753493B	Supply and Scavenge Pump	Hamilton Sundstrand
753493C	Supply and Scavenge Pump	Hamilton Sundstrand
753503	End Housing assy	Hamilton Sundstrand
753503A	End Housing assy	Hamilton Sundstrand
753531	Shaft Assembly	Hamilton Sundstrand
753533	Charge and Scavenge Pump	Hamilton Sundstrand
753582	Starter Shut-off Valve	Hamilton Sundstrand
753582-1	Shut-off Valve	Hamilton Standard
753582-2	Shut-off Valve	Hamilton Standard
753A0000-03	Primary Heat Exchanger	Liebherr Aerotechnik
754028A	Pump & Motor assy	Hamilton Sundstrand
754028B	Pump & Motor assy	Hamilton Sundstrand
754028C	Pump & Motor assy	Hamilton Sundstrand
754028D	Pump & Motor assy	Hamilton Sundstrand
754028E	Pump & Motor assy	Hamilton Sundstrand
754028F	Pump & Motor assy	Hamilton Sundstrand
754029A	Pump & Motor assy	Hamilton Sundstrand
754029B	Pump & Motor assy	Hamilton Sundstrand
754029C	Pump & Motor assy	Hamilton Sundstrand
754317	Compressor Bleed Valve	Pratt & Whitney
754681	Cabin/Duct Temperature Sensor	Hamilton Sundstrand
754681-1	Cabin/Duct Temperature Sensor	Hamilton Sundstrand
754691	Cabin/Duct Temperature Sensor	Hamilton Sundstrand
754691-1	Cabin/Duct Temperature Sensor	Hamilton Sundstrand
754691-2	Cabin/Duct Temperature Sensor	Hamilton Sundstrand
754691-3	Cabin/Duct Temperature Sensor	Hamilton Sundstrand
754691-5	Cabin/Duct Temperature Sensor	Hamilton Sundstrand
754822-1	Temperature Selector	Hamilton Sundstrand
754822-2	Temperature Selector	Hamilton Sundstrand
754822-3	Temperature Selector	Hamilton Sundstrand
754822-4	Temperature Selector	Hamilton Sundstrand
754890-1	Temperature Controller	Hamilton Sundstrand
754890-2	Temperature Controller	Hamilton Sundstrand
754890-3	Temperature Controller	Hamilton Sundstrand
754890-4	Temperature Controller	Hamilton Sundstrand

Repair_Capability_List_Excel

754900-10	Rotary Actuator	Hamilton Sundstrand
754900-11	Rotary Actuator	Hamilton Sundstrand
754900-12	Rotary Actuator	Hamilton Sundstrand
754900-13	Rotary Actuator	Hamilton Sundstrand
754900-2	Rotary Actuator	Hamilton Sundstrand
754900-3	Rotary Actuator	Hamilton Sundstrand
754900-4	Rotary Actuator	Hamilton Sundstrand
754900-5	Rotary Actuator	Hamilton Sundstrand
754900-6	Rotary Actuator	Hamilton Sundstrand
754900-7	Rotary Actuator	Hamilton Sundstrand
754900-8	Rotary Actuator	Hamilton Sundstrand
754900-9	Rotary Actuator	Hamilton Sundstrand
754932	Turbine Leg assy	Hamilton Sundstrand
754A0000-03	Main Heat Exchanger	Liebherr Aerotechnik
754B0000-01	Main Heat Exchanger	Liebherr Aerotechnik
755150	Remote Temperature Sensor	Hamilton Sundstrand
755299	Geared Rotary Actuator	Hamilton Sundstrand
755299A	Geared Rotary Actuator	Hamilton Sundstrand
755299B	Geared Rotary Actuator	Hamilton Sundstrand
755299C	Geared Rotary Actuator	Hamilton Sundstrand
755299D	Geared Rotary Actuator	Hamilton Sundstrand
755300	Geared Rotary Actuator	Hamilton Sundstrand
755300A	Geared Rotary Actuator	Hamilton Sundstrand
755300B	Geared Rotary Actuator	Hamilton Sundstrand
755300C	Geared Rotary Actuator	Hamilton Sundstrand
755300D	Geared Rotary Actuator	Hamilton Sundstrand
7555456	Hydraulic Pressure System	Purolator
7556256	Filter assy	Purolator
755691	Electrical Harness	Hamilton Sundstrand
755704	Pump and Motor	Hamilton Sundstrand
755A0000-03	Reheater	Liebherr Aerotechnik
755A0000-04	Reheater	Liebherr Aerospace
755A0000-04 Amdt A	Reheater	Liebherr Aerotechnik
755B0000-02	Reheater	Liebherr Aerospace
755B0000-02 Amdt A	Reheater	Liebherr Aerotechnik
755C0000-01	Reheater	Liebherr Aerospace
755CA02F	Three-Pole Contactor	ECE
756158	Flap Drive Torque Sensor assy	Hamilton Sundstrand
756605A	Housing & Support-Matched Set	Hamilton Sundstrand
756692	Rotor Balance assy	Hamilton Sundstrand
756722	Solenoid Valve assy	Hamilton Sundstrand
756829	Stator Housing	Hamilton Sundstrand
756829A	Stator Housing	Hamilton Sundstrand
756829B	Stator Housing	Hamilton Sundstrand
756865	Center Housing	Hamilton Sundstrand
756953	Quick Attach-Detach Kit	Hamilton Sundstrand
756955	Quick Attach-Detach Kit	Hamilton Sundstrand
756A0000-04	Condenser	Liebherr Aerotechnik
756A0000-05	Condenser	Liebherr Aerotechnik
757179	Housing & Support-Matched Set	Hamilton Sundstrand
757739	Ram Air Turbine	Hamilton Sundstrand
757811	Electrical Harness	Hamilton Sundstrand
7578724	Case assy	PTI Technologies
7578944	Filter assy	PTI Technologies
7581418	CSD Line Filter	PTI Technologies
758303	Quick Attach-Detach Kit	Hamilton Sundstrand
7586592	Filter Module	Purolator
7588587-101	Drain Filter Module	Purolator

Repair_Capability_List_Excel

7588587-102	Drain Filter Module	Purolator
7588587-103	Drain Filter Module	Purolator
7588587-104	Drain Filter Module	Purolator
758A0000-02	Valve assy	Goodrich Control Systems
7590590-101	Pressure Module	PTI Technologies
759123	Ram Air Turbine Module	Sundstrand Aviation
759137	RAT Actuator	Liebherr Aerotechnik
759467	Stator Housing	Hamilton Sundstrand
759467A	Stator Housing	Hamilton Sundstrand
759467B	Stator Housing	Hamilton Sundstrand
759998	Ram Air Turbine	Hamilton Sundstrand
75B1-5182	Valve	Airbus Industrie
75B64-1	Pressure Switch	CC Switches
75D64-1	Pressure Switch	Custom Control Sensors
7612100-1	Roller Tray ay	Goodrich
7612101-1	Roller Tray ay	Goodrich
7612102-1	Roller Tray ay	Goodrich
7612103-1	Roller Tray ay	Goodrich
7612105-1	Roller Tray ay	Goodrich
7612106-1	Roller Tray ay	Goodrich
7612107-1	Roller Tray ay	Goodrich
7612108-1	Roller Tray ay	Goodrich
7612109-1	Roller Tray ay	Goodrich
7612110-1	Roller Tray ay	Goodrich
7612111-1	Roller Tray ay	Goodrich
7612112-1	Roller Tray ay	Goodrich
7612113-1	Roller Tray ay	Goodrich
7612114-1	Roller Tray ay	Goodrich
7612115-1	Roller Tray ay	Goodrich
7612116-1	Roller Tray ay	Goodrich
7612117-1	Roller Tray ay	Goodrich
7612118-1	Roller Tray ay	Goodrich
7612119-1	Roller Tray ay	Goodrich
7612120-1	Roller Tray ay	Goodrich
7612122-1	Roller Tray ay	Goodrich
7612123-1	Roller Tray ay	Goodrich
7612124-1	Roller Tray ay	Goodrich
7612125-1	Roller Tray ay	Goodrich
7612126-1	Roller Tray ay	Goodrich
7612127-1	Roller Tray ay	Goodrich
7612128-1	Roller Tray ay	Goodrich
7612129-1	Roller Tray ay	Goodrich
7612130-1	Roller Tray ay	Goodrich
7612131-1	Roller Tray ay	Goodrich
7612132-1	Roller Tray ay	Goodrich
7612155-1	Roller Tray ay	Goodrich
7612160-1	Roller Tray ay	Goodrich
7612161-1	Roller Tray ay	Goodrich
7612162-1	Roller Tray ay	Goodrich
7612163-1	Roller Tray ay	Goodrich
7612164-1	Roller Tray ay	Goodrich
7612165-1	Roller Tray ay	Goodrich
7612166-1	Roller Tray ay	Goodrich
7612167-1	Roller Tray ay	Goodrich
7612168-1	Roller Tray ay	Goodrich
7612169-1	Roller Tray ay	Goodrich
7612170-1	Roller Tray ay	Goodrich
7612171-1	Roller Tray ay	Goodrich

Repair_Capability_List_Excel

7612172-1	Roller Tray ay	Goodrich
7612173-1	Roller Tray ay	Goodrich
7612174-1	Roller Tray ay	Goodrich
7612175-1	Roller Tray ay	Goodrich
7612176-1	Roller Tray ay	Goodrich
7612177-1	Roller Tray ay	Goodrich
7612178-1	Roller Tray ay	Goodrich
7612179-1	Roller Tray ay	Goodrich
7612180-1	Roller Tray ay	Goodrich
7612181-1	Roller Tray ay	Goodrich
7612182-1	Roller Tray ay	Goodrich
7612183-1	Roller Tray ay	Goodrich
7612184-1	Roller Tray ay	Goodrich
7612185-1	Roller Tray ay	Goodrich
7612186-1	Roller Tray ay	Goodrich
7612187-1	Roller Tray ay	Goodrich
7612901-1	Lock Tray ay	Goodrich
7612902-1	Lock Tray ay	Goodrich
7612903-1	Lock Tray ay	Goodrich
7612904-1	Lock Tray ay	Goodrich
7612905-1	Lock Tray ay	Goodrich
7612906-1	Lock Tray ay	Goodrich
7612907-1	Lock Tray ay	Goodrich
7612908-1	Lock Tray ay	Goodrich
7612909-1	Lock Tray ay	Goodrich
7612945-1	Latch ay	Goodrich
7612975-1	Latch ay	Goodrich
761343	ADG Ejection jack	Hamilton Sundstrand
761345	ADG Uplock assy	Hamilton Sundstrand
761516	Pressure Switch Harness	Hamilton Sundstrand
7616H0-1	Ball Panel ay	Goodrich
7616J0-1	Ball Panel ay	Goodrich
7616K0-1	Ball Panel ay	Goodrich
761844	Inversion Pump	Hamilton Sundstrand
761851	Charge & Scavenge Pump	Hamilton Sundstrand
761859A	Carrier Shaft assy	Hamilton Sundstrand
761864	Pump & Motor assy	Hamilton Sundstrand
761A0000-02	Inlet Actuator	Liebherr Aerotechnik
761A0000-03	Inlet Actuator	Liebherr Aerotechnik
761A0000-04	Inlet Actuator	Liebherr Aerotechnik
761B0000-01	Inlet Actuator	Liebherr Aerotechnik
762067	Stator Housing assy	Hamilton Sundstrand
762073A	Exciter Stator Housing assy	Hamilton Sundstrand
762073B	Exciter Stator Housing assy	Hamilton Sundstrand
762073C	Exciter Stator Housing assy	Hamilton Sundstrand
762080	Safety Valve	Messier-Bugatti
762080003	Safety Valve	Messier-Bugatti
762080-1	Safety Valve	Messier-Bugatti
762080-2	Safety Valve	Messier-Bugatti
762187	Bus Power Control Unit	Hamilton Sundstrand
762246	Quick Attach-Detach Adapter Kit	Hamilton Sundstrand
762359	Rotor Balance assy	Hamilton Sundstrand
762359A	Rotor Balance assy	Hamilton Sundstrand
762359B	Rotor Balance assy	Hamilton Sundstrand
762359C	Rotor Balance assy	Hamilton Sundstrand
762359D	Rotor Balance assy	Hamilton Sundstrand
762359E	Rotor Balance assy	Hamilton Sundstrand
762359F	Rotor Balance assy	Hamilton Sundstrand

Repair_Capability_List_Excel

762610-1	Stop and Lock ay	Goodrich
762620-1	Stop and Lock ay	Goodrich
762630-1	Pallet Lock/Stop Latch ay	Goodrich
762947A	Gearbox assy	Hamilton Sundstrand
762947B	Gearbox assy	Hamilton Sundstrand
762947C	Gearbox assy	Hamilton Sundstrand
762969	Leg assy	Hamilton Sundstrand
762969A	Leg assy	Hamilton Sundstrand
762A0000-02	Outlet Actuator	Liebherr Aerotechnik
762A0000-03	Outlet Actuator	Liebherr Aerotechnik
762A0000-04	Outlet Actuator	Liebherr Aerotechnik
76-300	Temperature Indicator	.
763051	Support Bearing	Hamilton Sundstrand
763222	Power Relay	Hamilton Sundstrand
763569	Pneumatic Starter	Hamilton Sundstrand
763569-2	Pneumatic Starter	Hamilton Standard
763569-3	Pneumatic Starter	Hamilton Standard
763569-4	Pneumatic Starter	Hamilton Standard
763569-5	Pneumatic Starter	Hamilton Standard
763569-6	Pneumatic Starter	Hamilton Standard
763569A2	Pneumatic Starter	Hamilton Standard
763569A3	Pneumatic Starter	Hamilton Standard
763569A4	Pneumatic Starter	Hamilton Standard
763569A5	Pneumatic Starter	Hamilton Standard
763569A6	Pneumatic Starter	Hamilton Standard
763775	Electrical Harness	Hamilton Sundstrand
763775A	Electrical Harness	Hamilton Sundstrand
763775B	Electrical Harness	Hamilton Sundstrand
763775C	Electrical Harness	Hamilton Sundstrand
763A0000-02	Temperature Sensor	Liebherr Aerotechnik
763A0000-03	Temperature Sensor	Liebherr Aerotechnik
764097	LH/RH Housing Unit assy	Hamilton Sundstrand
764097A	LH/RH Housing Unit assy	Hamilton Sundstrand
764098	LH/RH Housing Unit assy	Hamilton Sundstrand
764098A	LH/RH Housing Unit assy	Hamilton Sundstrand
764099	LH/RH Pump assy	Hamilton Sundstrand
764100	LH/RH Pump assy	Hamilton Sundstrand
764224	Lubrication & Scavenge Oil Pump	Hamilton Sundstrand
764537	ADG Strut/Generator assy	Hamilton Sundstrand
7645-37A5-1	Hydraulic Pressure Transmitter	Allied Signal
764633	Pressure Transducer	Hamilton Sundstrand
764711	RAT Actuator	Liebherr Aerotechnik
764711A	RAT Actuator	Liebherr Aerotechnik
764713-1	Tank Probe	Intertechnique
764A0000-02	Temperature Sensor	Liebherr Aerotechnik
764A0000-03	Temperature Sensor	Liebherr Aerotechnik
764B0000-01	Temperature Sensor	Liebherr Aerotechnik
765480	Variable Frequency AC Motor	Hamilton Sundstrand
765581	Charge & Scavenge Pump	Hamilton Sundstrand
765590	Inlet Guide Vane assy	Hamilton Sundstrand
76602	Fuel Deicing Valve	Colt Industries
766-046-2	Tank Probe	Intertechnique
766-047-2	Tank Probe	Intertechnique
766-048-2	Tank Probe	Intertechnique
766-078-1	Tank Probe	Intertechnique
766079	Scavenge Pump	Hamilton Sundstrand
766238	Motor assy	Hamilton Sundstrand
766239	Motor assy	Hamilton Sundstrand

Repair_Capability_List_Excel

766261	Pump & Motor assy	Hamilton Sundstrand
766262	Pump & Motor assy	Hamilton Sundstrand
766282A	AC Generator	Hamilton Sundstrand
766288	Generator assy	Hamilton Sundstrand
766-323-1	Fuel Quantity Probe	Intertechnique
766-325-1	Fuel Quantity Probe	Intertechnique
766-326-1	Fuel Quantity Probe	Intertechnique
766-327-2	Fuel Quantity Probe	Intertechnique
766-328-1	Fuel Quantity Probe	Intertechnique
766-329-1	Fuel Quantity Probe	Intertechnique
766-330-1	Fuel Quantity Probe	Intertechnique
766-331-1	Fuel Quantity Probe	Intertechnique
766351	Ram Air Turbine	Hamilton Sundstrand
766352	Ram Air Turbine	Hamilton Sundstrand
766359	Flap & Slat Power Drive Unit	Hamilton Sundstrand
766361	Inboard Flap Actuator assy	Hamilton Sundstrand
766363	Midboard RH Flap Actuator assy	Hamilton Sundstrand
766365	Midboard LH Flap Actuator assy	Hamilton Sundstrand
766367	Outboard RH Flap Actuator assy	Hamilton Sundstrand
766369	Outboard LH Flap Actuator assy	Hamilton Sundstrand
766377	Flap & Slat Angle Gearbox	Hamilton Sundstrand
766379	Flap & Slat Angle Gearbox	Hamilton Sundstrand
766381	Flap & Slat Angle Gearbox	Hamilton Sundstrand
766383	Inboard Slat Actuator assy	Hamilton Sundstrand
766385	Outboard Slat Actuator assy	Hamilton Sundstrand
766512	Differential	Hamilton Sundstrand
766-531	Fuel Probe	Intertechnique
766-532	Fuel Probe	Intertechnique
766-643	Tank Probe	Intertechnique
766-791-1	Fuel Quantity Probe	Intertechnique
766-792-1	Fuel Quantity Probe	Intertechnique
766-793-1	Tank Probe	Intertechnique
766-795-2	Tank Probe	Intertechnique
766-796-2	Tank Probe	Intertechnique
766-797-2	Tank Probe	Intertechnique
766-801-1	Tank Probe	Intertechnique
766-831-2	Tank Probe	Intertechnique
766-983-1	Tank Probe	Intertechnique
766A0000-01	Temperature Sensor	Liebherr Aerospace
766B0000-01	Temperature Sensor	Liebherr Aerospace
767110	Rotor Balance assy	Hamilton Sundstrand
767115	Dual Heat Exchanger	Hamilton Sundstrand
767176A	Stator Housing assy	Hamilton Sundstrand
767176B	Stator Housing assy	Hamilton Sundstrand
767176C	Stator Housing assy	Hamilton Sundstrand
767178A	Exciter Stator Housing assy	Hamilton Sundstrand
767179	Stator Housing assy	Hamilton Sundstrand
767199	Differential assy	Hamilton Sundstrand
767226	Pump and Motor assy	Hamilton Sundstrand
767264	Inversion Pump assy	Hamilton Sundstrand
767273A	Charge & Scavenge Pump	Hamilton Sundstrand
767281	Governor assy	Hamilton Sundstrand
767469	Bleed Air Mixing Ejector	Hamilton Sundstrand
767497	Pump & Motor assy	Hamilton Sundstrand
767520	Pump & Motor assy	Hamilton Sundstrand
767669B	Attach/Detach Quick Adapter Kit	Hamilton Sundstrand
767879A	Pump & Motor assy	Hamilton Sundstrand
767891C	Inversion Pump	Hamilton Sundstrand

Repair_Capability_List_Excel

767898C	Charge & Scavenge Pump	Hamilton Sundstrand
767916	Stator Housing	Hamilton Sundstrand
767920B	Exciter Stator Housing assy	Hamilton Sundstrand
767925	Pump & Motor assy	Hamilton Sundstrand
767A0000-03	Temperature Sensor	Liebherr Aerospace
767A0000-04	Temperature Sensor	Liebherr Aerospace
767B0000-02	Temperature Sensor	Liebherr Aerospace
768-055	Tank Probe	Intertechnique
768-100	Tank Probe	Intertechnique
768342	Rotor Balance assy	Hamilton Sundstrand
768363	Differential Pressure Switch	Pratt & Whitney
768-380	Fuel Quantity Probe	Intertechnique
768389A	Charge Pump assy	Hamilton Sundstrand
768614	Flap & Slat Angle Gearbox	Hamilton Sundstrand
768616	Midboard Slat Actuator assy	Hamilton Sundstrand
768645B	Charge & Scavenge Pump	Hamilton Sundstrand
768919B	Inversion Pump	Hamilton Sundstrand
768959-1	Tank Probe	Intertechnique
768959-2	Tank Probe	Intertechnique
768960-1	Tank Probe	Intertechnique
768960-2	Tank Probe	Intertechnique
768961-1	Tank Probe	Intertechnique
768962-1	Tank Probe	Intertechnique
768962-2	Tank Probe	Intertechnique
768963-1	Tank Probe	Intertechnique
768963-2	Tank Probe	Intertechnique
768964-1	Tank Probe	Intertechnique
768965-1	Tank Probe	Intertechnique
768965-2	Tank Probe	Intertechnique
768966-1	Tank Probe	Intertechnique
768967-1	Tank Probe	Intertechnique
768967-2	Tank Probe	Intertechnique
768968-1	Tank Probe	Intertechnique
768969-1	Tank Probe	Intertechnique
768A0000-02	Pressure Sensor	Liebherr Aerotechnik
768A0000-03	Pressure Sensor	Liebherr Aerotechnik
769104	Airborne Ground Check Module	Messier-Dowty
769105	Airborne Ground Check Module	Messier-Dowty
769106	Airborne Ground Check Module	Messier-Dowty
769220	Compressor Bleed Valve	Pratt & Whitney
769A0000-01	Check Valve	Liebherr Aerotechnik
769A0000-02	Check Valve	Liebherr Aerotechnik
769B0000-01	Check Valve	Liebherr Aerotechnik
7700198	Actuator assy	Envirovac
770376	Center Housing assy	Hamilton Sundstrand
770385	Scavenge & Gen. Scavenge Pump	Hamilton Sundstrand
770665-1	Overtemperature Switch	Hamilton Sundstrand
770665-2	Overtemperature Switch	Hamilton Sundstrand
770665-3	Overtemperature Switch	Hamilton Sundstrand
770665-4	Overtemperature Switch	Hamilton Sundstrand
770665-5	Overtemperature Switch	Hamilton Sundstrand
770665-6	Overtemperature Switch	Hamilton Sundstrand
770665-7	Overtemperature Switch	Hamilton Sundstrand
770665-8	Overtemperature Switch	Hamilton Sundstrand
770665-9	Overtemperature Switch	Hamilton Sundstrand
770796	Variable Disp.Hydraulic Motorpump	Eaton
770895	Servo Motor	Hamilton Sundstrand
7709-55B8-1	Blower Pressure Transmitter	Bendix

Repair_Capability_List_Excel

7709-72B8-1	Fuel Pressure Transmitter	Bendix
77-1	Transformer	Auxilec
771020-1	Bi-Directional Load Stop ay	Goodrich
771050-1	Pallet Lock ay	Goodrich
771051	Generator assy	Hamilton Sundstrand
771060-1	Pallet Lock ay	Goodrich
771070-1	Pallet Lock ay	Goodrich
77-109-10	Oil Quantity Transmitter	Meggitt Avionics
77-109-11	Oil Quantity Transmitter	Meggitt Avionics
77-109-12	Oil Quantity Transmitter	Meggitt Avionics
77-109-13	Oil Quantity Transmitter	Meggitt Avionics
77-109-14	Oil Quantity Transmitter	Meggitt Avionics
77-109-15	Oil Quantity Transmitter	Meggitt Avionics
77-109-5	Oil Quantity Transmitter	Meggitt Avionics
77-109-8	Oil Quantity Transmitter	Meggitt Avionics
77-109-9	Oil Quantity Transmitter	Meggitt Avionics
7711120-1	Stop ay	Goodrich
7711130-1	Stop ay	Goodrich
7711140-2	Pallet Lock ay	Goodrich
7711150-1	Stop ay	Goodrich
7711160	Stop ay	Goodrich
7711170	Stop and Lock ay	Goodrich
7711180-1	Stop and Lock ay	Goodrich
7712100-1	Roller Tray ay	Goodrich
7712101-1	Roller Tray ay	Goodrich
7712102-1	Roller Tray ay	Goodrich
7712103-1	Roller Tray ay	Goodrich
7712104-1	Roller Tray ay	Goodrich
7712105-1	Roller Tray ay	Goodrich
7712106-1	Roller Tray ay	Goodrich
7712107-1	Roller Tray ay	Goodrich
7712108-1	Roller Tray ay	Goodrich
7712109-1	Roller Tray ay	Goodrich
7712110-1	Roller Tray ay	Goodrich
7712111-1	Roller Tray ay	Goodrich
7712112-1	Roller Tray ay	Goodrich
7712113-1	Roller Tray ay	Goodrich
7712114-1	Roller Tray ay	Goodrich
7712115-1	Roller Tray ay	Goodrich
7712116-1	Roller Tray ay	Goodrich
7712116-2	Roller Tray ay	Goodrich
7712117-1	Roller Tray ay	Goodrich
7712118-1	Roller Tray ay	Goodrich
7712118-2	Roller Tray ay	Goodrich
7712119-1	Roller Tray ay	Goodrich
7712120-1	Roller Tray ay	Goodrich
7712121-1	Roller Tray ay	Goodrich
7712121-2	Roller Tray ay	Goodrich
7712122-1	Roller Tray ay	Goodrich
7712123-1	Roller Tray ay	Goodrich
7712124-1	Roller Tray ay	Goodrich
7712125-1	Roller Tray ay	Goodrich
7712126-1	Roller Tray ay	Goodrich
7712127-1	Roller Tray ay	Goodrich
7712128-1	Roller Tray ay	Goodrich
7712129-1	Roller Tray ay	Goodrich
7712130-1	Roller Tray ay	Goodrich
7712131-1	Roller Tray ay	Goodrich

Repair_Capability_List_Excel

7712132-1	Roller Tray ay	Goodrich
7712133-1	Roller Tray ay	Goodrich
7712134-1	Roller Tray ay	Goodrich
7712135-1	Roller Tray ay	Goodrich
7712136-1	Roller Tray ay	Goodrich
7712137-1	Roller Tray ay	Goodrich
7712138-1	Roller Tray ay	Goodrich
7712139-1	Roller Tray ay	Goodrich
7712140-1	Roller Tray ay	Goodrich
7712141-1	Roller Tray ay	Goodrich
7712142-1	Roller Tray ay	Goodrich
7712142-2	Roller Tray ay	Goodrich
7712143-1	Roller Tray ay	Goodrich
7712144-1	Roller Tray ay	Goodrich
7712145-1	Roller Tray ay	Goodrich
7712145-2	Roller Tray ay	Goodrich
7712146-1	Roller Tray ay	Goodrich
7712147-1	Roller Tray ay	Goodrich
7712148-1	Roller Tray ay	Goodrich
7712150-1	Roller Tray ay	Goodrich
7712151-1	Roller Tray ay	Goodrich
7712152-1	Roller Tray ay	Goodrich
7712153-1	Roller Tray ay	Goodrich
7712154-1	Roller Tray ay	Goodrich
7712155-1	Roller Tray ay	Goodrich
7712156-1	Roller Tray ay	Goodrich
7712157-1	Roller Tray ay	Goodrich
7712158-1	Roller Tray ay	Goodrich
7712159-1	Roller Tray ay	Goodrich
7712160-1	Roller Tray ay	Goodrich
7712161-1	Roller Tray ay	Goodrich
7712162-1	Roller Tray ay	Goodrich
7712163-1	Roller Tray ay	Goodrich
7712164-1	Roller Tray ay	Goodrich
7712165-1	Roller Tray ay	Goodrich
7712166-1	Roller Tray ay	Goodrich
7712167-1	Roller Tray ay	Goodrich
7712168-1	Roller Tray ay	Goodrich
7712169-1	Roller Tray ay	Goodrich
7712170-1	Roller Tray ay	Goodrich
7712171-1	Roller Tray ay	Goodrich
7712172-1	Roller Tray ay	Goodrich
7712173-1	Roller Tray ay	Goodrich
7712174-1	Roller Tray ay	Goodrich
7712175-1	Roller Tray ay	Goodrich
7712175-2	Roller Tray ay	Goodrich
7712176-1	Roller Tray ay	Goodrich
7712177-1	Roller Tray ay	Goodrich
7712178-1	Roller Tray ay	Goodrich
7712179-1	Roller Tray ay	Goodrich
7712180-1	Roller Tray ay	Goodrich
7712181-1	Roller Tray ay	Goodrich
7712182-1	Roller Tray ay	Goodrich
7712183-1	Roller Tray ay	Goodrich
7712183-2	Roller Tray ay	Goodrich
7712184-1	Roller Tray ay	Goodrich
7712185-1	Roller Tray ay	Goodrich
7712186-1	Roller Tray ay	Goodrich

Repair_Capability_List_Excel

7712187-1	Roller Tray ay	Goodrich
7712188-1	Roller Tray ay	Goodrich
7712188-2	Roller Tray ay	Goodrich
7712189-1	Roller Tray ay	Goodrich
7712190-1	Roller Tray ay	Goodrich
7712191-1	Roller Tray ay	Goodrich
7712192-1	Roller Tray ay	Goodrich
7712193-1	Roller Tray ay	Goodrich
7712193-2	Roller Tray ay	Goodrich
7712194-1	Roller Tray ay	Goodrich
7712194-2	Roller Tray ay	Goodrich
7712195-1	Roller Tray ay	Goodrich
7712196-1	Roller Tray ay	Goodrich
7712196-2	Roller Tray ay	Goodrich
7712197-1	Roller Tray ay	Goodrich
7712197-2	Roller Tray ay	Goodrich
7712198-1	Roller Tray ay	Goodrich
7712199-1	Roller Tray ay	Goodrich
7712200-1	Roller Tray ay	Goodrich
7712201-1	Roller Tray ay	Goodrich
7712202-1	Roller Tray ay	Goodrich
7712203-1	Roller Tray ay	Goodrich
7712204-1	Roller Tray ay	Goodrich
7712205-1	Roller Tray ay	Goodrich
7712206-1	Roller Tray ay	Goodrich
7712207-1	Roller Tray ay	Goodrich
7712208-1	Roller Tray ay	Goodrich
7712209-1	Roller Tray ay	Goodrich
7712210-1	Roller Tray ay	Goodrich
7712211-1	Roller Tray ay	Goodrich
7712212-1	Roller Tray ay	Goodrich
771409	LH & RH Slat Disconnect Sensors	Hamilton Sundstrand
771410	LH & RH Slat Disconnect Sensors	Hamilton Sundstrand
7715200-1	Guide ay	Goodrich
7715200-2	Guide ay	Goodrich
7715201-1	Guide ay	Goodrich
7715201-2	Guide ay	Goodrich
7715250-1	Stop ay	Goodrich
7716200-1	Ball Panel ay	Goodrich
7716250-1	Ball Panel ay	Goodrich
7716300-1	Ball Panel ay	Goodrich
7716300-2	Ball Panel ay	Goodrich
7716350-1	Ball Panel ay	Goodrich
7716350-2	Ball Panel ay	Goodrich
7716350-3	Ball Panel ay	Goodrich
7716350-4	Ball Panel ay	Goodrich
7716400-1	Ball Panel ay	Goodrich
7716400-2	Ball Panel ay	Goodrich
7716450-1	Ball Panel ay	Goodrich
7716450-2	Ball Panel ay	Goodrich
7716500-1	Ball Panel ay	Goodrich
771A010001	Compressor	Liebherr Aerotechnik
771K-4-025	Tachymeter Indicator	Kollsman
772170	Input Housing assy	Hamilton Sundstrand
772183	Stator Housing	Hamilton Sundstrand
772460	Bleed Air Temperature Sensor	Hamilton Sundstrand
772499-1	Vane & Bleed Control	Hamilton Sundstrand
772-5005-004	Course Indicator	Rockwell Collins

Repair_Capability_List_Excel

772-5005-005	Course Indicator	Rockwell Collins
772-5005-006	Course Indicator	Rockwell Collins
772-5005-011	Course Indicator	Rockwell Collins
772-5126-001	Flight Director Control Panel	Rockwell Collins
772-5271-001	HF Communication Control Panel	Rockwell Collins
772-5271-002	HF Communication Control Panel	Rockwell Collins
772-5272-001	HF Communication Control Panel	Rockwell Collins
772-5370-001	Course Indicator	Rockwell Collins
772-5370-002	Course Indicator	Rockwell Collins
772-5370-003	Course Indicator	Rockwell Collins
772-5370-005	Course Indicator	Rockwell Collins
772A0000-01	Duct Overheat Sensor	Liebherr Aerotechnik
772A0000-02	Duct Overheat Sensor	Liebherr Aerotechnik
773284-3	Fan Air Temperature Sensor	Hamilton Sundstrand
773284-4	Fan Air Temperature Sensor	Hamilton Sundstrand
773284-5	Fan Air Temperature Sensor	Hamilton Sundstrand
773284-6	Fan Air Temperature Sensor	Hamilton Sundstrand
773284-7	Fan Air Temperature Sensor	Hamilton Sundstrand
773287-3	Air Supply Precooler	Hamilton Sundstrand
773287-5	Air Supply Precooler	Hamilton Sundstrand
773288-10	Pressure Regulating & Shut-off Valve	Hamilton Sundstrand
773288-6	Pressure Regulating & Shut-off Valve	Hamilton Sundstrand
773288-7	Pressure Regulating & Shut-off Valve	Hamilton Sundstrand
773288-8	Pressure Regulating & Shut-off Valve	Hamilton Sundstrand
773288-9	Pressure Regulating & Shut-off Valve	Hamilton Sundstrand
773289-10	High Pressure Controller	Hamilton Sundstrand
773289-11	High Pressure Controller	Hamilton Sundstrand
773289-12	High Pressure Controller	Hamilton Sundstrand
773289-13	High Pressure Controller	Hamilton Sundstrand
773289-14	High Pressure Controller	Hamilton Sundstrand
773289-15	High Pressure Controller	Hamilton Sundstrand
773289-16	High Pressure Controller	Hamilton Sundstrand
773289-17	High Pressure Controller	Hamilton Sundstrand
773289-18	High Pressure Controller	Hamilton Sundstrand
773289-3	High Pressure Controller	Hamilton Sundstrand
773289-4	High Pressure Controller	Hamilton Sundstrand
773289-5	High Pressure Controller	Hamilton Sundstrand
773289-6	High Pressure Controller	Hamilton Sundstrand
773289-7	High Pressure Controller	Hamilton Sundstrand
773289-8	High Pressure Controller	Hamilton Sundstrand
773289-9	High Pressure Controller	Hamilton Sundstrand
773461	Air Supply Module	Hamilton Sundstrand
773-467-00	Stewart Station Keyboard	Diehl
773-468-00	Stewart Station Keyboard	Diehl
773855-3	Fan Air Modulating Valve	Hamilton Sundstrand
773855-4	Fan Air Modulating Valve	Hamilton Sundstrand
773855-5	Fan Air Modulating Valve	Hamilton Sundstrand
773855-6	Fan Air Modulating Valve	Hamilton Sundstrand
773855-7	Fan Air Modulating Valve	Hamilton Sundstrand
773855-8	Fan Air Modulating Valve	Hamilton Sundstrand
773856	Intermediate Pressure Check Valve	Hamilton Sundstrand
773856-10	Intermediate Pressure Check Valve	Hamilton Sundstrand
773856-11	Intermediate Pressure Check Valve	Hamilton Sundstrand
773856-12	Intermediate Pressure Check Valve	Hamilton Sundstrand
773856-13	Intermediate Pressure Check Valve	Hamilton Sundstrand
773856-14	Intermediate Pressure Check Valve	Hamilton Sundstrand
773856-15	Intermediate Pressure Check Valve	Hamilton Sundstrand
773856-16	Intermediate Pressure Check Valve	Hamilton Sundstrand

Repair_Capability_List_Excel

773856-17	Intermediate Pressure Check Valve	Hamilton Sundstrand
773856-18	Intermediate Pressure Check Valve	Hamilton Sundstrand
773856-19	Intermediate Pressure Check Valve	Hamilton Sundstrand
773856-3	Intermediate Pressure Check Valve	Hamilton Sundstrand
773856-4	Intermediate Pressure Check Valve	Hamilton Sundstrand
773856-5	Intermediate Pressure Check Valve	Hamilton Sundstrand
773856-6	Intermediate Pressure Check Valve	Hamilton Sundstrand
773856-8	Intermediate Pressure Check Valve	Hamilton Sundstrand
773857-10	High Pressure Shut-off Valve	Hamilton Sundstrand
773857-11	High Pressure Shut-off Valve	Hamilton Sundstrand
773857-12	High Pressure Shut-off Valve	Hamilton Sundstrand
773857-13	High Pressure Shut-off Valve	Hamilton Sundstrand
773857-14	High Pressure Shut-off Valve	Hamilton Sundstrand
773857-15	High Pressure Shut-off Valve	Hamilton Sundstrand
773857-16	High Pressure Shut-off Valve	Hamilton Sundstrand
773857-17	High Pressure Shut-off Valve	Hamilton Sundstrand
773857-18	High Pressure Shut-off Valve	Hamilton Sundstrand
773857-19	High Pressure Shut-off Valve	Hamilton Sundstrand
773857-20	High Pressure Shut-off Valve	Hamilton Sundstrand
773857-21	High Pressure Shut-off Valve	Hamilton Sundstrand
773857-6	High Pressure Shut-off Valve	Hamilton Sundstrand
773857-7	High Pressure Shut-off Valve	Hamilton Sundstrand
773857-8	High Pressure Shut-off Valve	Hamilton Sundstrand
773857-9	High Pressure Shut-off Valve	Hamilton Sundstrand
77-389	Motor	Crane
77-395	Transducer Motor assy	Crane
773A0000-01	Temperature Sensor	Liebherr Aerotechnik
774383	Zone Trim Actuator assy	Hamilton Sundstrand
774384	Turbine Bypass Actuator assy	Hamilton Sundstrand
774455	Zone Trim Valve	Hamilton Sundstrand
774460	Turbine Bypass Valve	Hamilton Sundstrand
774469-1	Air Bearing ACM	Hamilton Sundstrand
774469-11	Air Bearing ACM	Hamilton Sundstrand
774469-2	Air Bearing ACM	Hamilton Sundstrand
774469-3	Air Bearing ACM	Hamilton Sundstrand
774469-4	Air Bearing ACM	Hamilton Sundstrand
774500	Remote Temperature Sensor	Hamilton Sundstrand
774555-1	Vane & Bleed Control	Hamilton Sundstrand
774987-1	Shut-Off Valve	Hamilton Sundstrand
774A0000-02	Water Injector	Liebherr Aerotechnik
775516	Air Supply Precooler	Hamilton Sundstrand
775538-1	Starter Control Valve	Hamilton Sundstrand
775538-10	Starter Control Valve	Hamilton Standard
775538-11	Starter Control Valve	Hamilton Standard
775538-12	Starter Control Valve	Hamilton Standard
775538-13	Starter Control Valve	Hamilton Standard
775538-15	Starter Control Valve	Hamilton Standard
775538-16	Starter Control Valve	Hamilton Standard
775538-3	Starter Control Valve	Hamilton Standard
775538-6	Starter Control Valve	Hamilton Sundstrand
775538-7	Starter Control Valve	Hamilton Sundstrand
775538-9	Starter Control Valve	Hamilton Standard
776655	Hydraulic Motorpump	Vickers
776876	Relief Valve assy	Vickers
776902	Dual Temperature Control Valve	Hamilton Sundstrand
776916	Condenser & Mixer	Hamilton Sundstrand
777-1029-001	HF Communication Control Panel	Rockwell Collins
777-1029-002	HF Communication Control Panel	Rockwell Collins

Repair_Capability_List_Excel

777-1029-003	HF Communication Control Panel	Rockwell Collins
777-1029-004	HF Communication Control Panel	Rockwell Collins
777-1029-005	HF Communication Control Panel	Rockwell Collins
777-1029-006	HF Communication Control Panel	Rockwell Collins
777-1029-007	HF Communication Control Panel	Rockwell Collins
777-1128-001	Flight Director Control Panel	Rockwell Collins
777-1129-001	Flight Director Control Panel	Rockwell Collins
777-1225-001	HF Communication Control Panel	Rockwell Collins
777-1225-002	HF Communication Control Panel	Rockwell Collins
777-1225-003	HF Communication Control Panel	Rockwell Collins
777-1397-004	Course Indicator	Rockwell Collins
777-1397-008	Course Indicator	Rockwell Collins
777-1397-010	Course Indicator	Rockwell Collins
777-1480-001	VOR/ILS Receiver	Rockwell-Collins
777-1492-001	ADF Receiver	Rockwell-Collins
777-1492-002	ADF Receiver	Rockwell-Collins
777-1492-003	ADF Receiver	Rockwell-Collins
777-1492-004	ADF Receiver	Rockwell-Collins
777-1492-005	ADF Receiver	Rockwell-Collins
777-1492-006	ADF Receiver	Rockwell-Collins
777-1493-001	ADF Control Unit	Rockwell Collins
777-1493-002	ADF Control Unit	Rockwell Collins
777-1493-003	ADF Control Unit	Rockwell Collins
777-1493-004	ADF Control Unit	Rockwell Collins
777-1493-005	ADF Control Unit	Rockwell Collins
777-1493-006	ADF Control Unit	Rockwell Collins
777-1493-007	ADF Control Unit	Rockwell Collins
777-1493-008	ADF Control Unit	Rockwell Collins
777-1493-009	ADF Control Unit	Rockwell Collins
777-1493-010	ADF Control Unit	Rockwell Collins
777A0000-01	Temperature Selector	Liebherr Aerotechnik
778683	Dual Heat Exchanger	Hamilton Sundstrand
778683-2	Dual Heat Exchanger	Hamilton Sundstrand
778683-3	Dual Heat Exchanger	Hamilton Sundstrand
778683-4	Dual Heat Exchanger	Hamilton Sundstrand
778683-5	Dual Heat Exchanger	Hamilton Sundstrand
778684-3	Condenser and Mixer	Hamilton Sundstrand
778684-4	Condenser and Mixer	Hamilton Sundstrand
778684-5	Condenser and Mixer	Hamilton Sundstrand
778684-6	Condenser and Mixer	Hamilton Sundstrand
778684-7	Condenser and Mixer	Hamilton Sundstrand
778684-8	Condenser and Mixer	Hamilton Sundstrand
778684-9	Condenser and Mixer	Hamilton Sundstrand
778686-3	High Pressure Shut-Off Valve	Hamilton Sundstrand
778686-4	High Pressure Shut-Off Valve	Hamilton Sundstrand
778695-1	Pressure Reg. & Shut-Off Valve	Hamilton Sundstrand
778696	Wing Isolation Check Valve	Hamilton Sundstrand
778697	Trim Zone Temp. Valve	Hamilton Sundstrand
778697-1	Trim Zone Temp. Valve	Hamilton Sundstrand
778701	APU Surge Control	Hamilton Sundstrand
778720	Load Hardware Gearbox	Hamilton Sundstrand
778727-1	Pack Temperature Control Valve	Hamilton Sundstrand
778727-10	Pack Temperature Control Valve	Hamilton Sundstrand
778727-2	Pack Temperature Control Valve	Hamilton Sundstrand
778727-4	Pack Temperature Control Valve	Hamilton Sundstrand
778727-5	Pack Temperature Control Valve	Hamilton Sundstrand
778727-6	Pack Temperature Control Valve	Hamilton Sundstrand
778727-7	Pack Temperature Control Valve	Hamilton Sundstrand

Repair_Capability_List_Excel

778727-8	Pack Temperature Control Valve	Hamilton Sundstrand
778727-9	Pack Temperature Control Valve	Hamilton Sundstrand
778728	Recirculation Fan	Hamilton Sundstrand
778728-4	Recirculation Fan	Hamilton Sundstrand
778728-6	Recirculation Fan	Hamilton Sundstrand
778820	Rate Sensor	Hamilton Sundstrand
778A0200-02	Pipe assy	Liebherr Aerotechnik
778A0200-03	Pipe assy	Liebherr Aerotechnik
778A0500-02	Pipe assy	Liebherr Aerotechnik
778A0500-03	Pipe assy	Liebherr Aerotechnik
778A0600-03	Pipe assy	Liebherr Aerotechnik
778A0600-04	Pipe assy	Liebherr Aerotechnik
778A0600-05	Pipe assy	Liebherr Aerotechnik
778A4100-01	Pipe assy	Liebherr Aerotechnik
779215	Dual Heat Exchanger	Hamilton Sundstrand
779970	Temperature Sensor	Hamilton Sundstrand
7800000-005	Valve assy	Envirovac
7800000-006	Valve assy	Envirovac
7800000-007	Valve assy	Envirovac
7800000-008	Valve assy	Envirovac
7800000-009	Valve assy	Envirovac
7800000-010	Valve assy	Envirovac
7800000-011	Valve assy	Envirovac
7800001-008	Water Valve assy	Envirovac
7800028-006	Valve assy	Envirovac
7800084-001	Flush Control Unit	Envirovac
7800084-002	Flush Control Unit	Envirovac
7800084-003	Flush Control Unit	Envirovac
7800084-004	Flush Control Unit	Envirovac
78-006-01	Fuel Flow Rate Indicator	Marconi
78-007-01	Fuel Flow Rate Indicator	Marconi
7802-57000	Fuel Consumed Indicator	Elliott
78035-01100	Tachometer Indicator	Aerosonic Corp
78068	Servo Valve	Abex
780876	DC Rotary Actuator	Hamilton Sundstrand
78090	Servo Valve	Abex
780960	APU Surge Valve assy	Hamilton Sundstrand
780A0000-01	Command Sensor Unit	Liebherr Aerotechnik
780A0000-02	Command Sensor Unit	Liebherr Aerotechnik
780B0000-01	Command Sensor Unit	Liebherr Aerotechnik
78-10066BP	Cycle De-Icing Switch	Northern Aero Ind.
78-10066BPC	Cycle De-Icing Switch	Northern Aero Ind.
78142	Servo Valve	Abex
78169-01	Control Module	Parker Hannifin
78169-02	Control Module	Parker Hannifin
78169-03	Control Module	Parker Hannifin
78169-04	Control Module	Parker Hannifin
7820700	Ball Screw assy	Sabinaw
7820921	Ball Screw assy	Sabinaw
7820922	Ball Screw assy	Sabinaw
7820923	Ball Screw assy	Sabinaw
7820924	Ball Screw assy	Sabinaw
782100	HP Bleed Pressure Switch	Hamilton Sundstrand
782100-1	HP Bleed Pressure Switch	Hamilton Sundstrand
782100-10	HP Bleed Pressure Switch	Hamilton Sundstrand
782100-11	HP Bleed Pressure Switch	Hamilton Sundstrand
782100-2	HP Bleed Pressure Switch	Hamilton Sundstrand
782100-3	HP Bleed Pressure Switch	Hamilton Sundstrand

Repair_Capability_List_Excel

782100-4	HP Bleed Pressure Switch	Hamilton Sundstrand
782100-5	HP Bleed Pressure Switch	Hamilton Sundstrand
782100-6	HP Bleed Pressure Switch	Hamilton Sundstrand
782100-7	HP Bleed Pressure Switch	Hamilton Sundstrand
782100-8	HP Bleed Pressure Switch	Hamilton Sundstrand
782100-9	HP Bleed Pressure Switch	Hamilton Sundstrand
7821341	Ball Screw assy	Sabinaw
7821342	Ball Screw assy	Sabinaw
7821343	Ball Screw assy	Sabinaw
7821344	Ball Screw assy	Sabinaw
7822105	Ball Screw assy	Sabinaw
7822106	Ball Screw assy	Sabinaw
7822107	Ball Screw assy	Sabinaw
7822108	Ball Screw assy	Sabinaw
7822471	Ball Screw assy	Saginaw
7822472	Ball Screw assy	Saginaw
7822473	Ball Screw assy	Saginaw
7822474	Ball Screw assy	Saginaw
7822475	Ball Screw assy	Saginaw
7822477	Ball Screw assy	Saginaw
782396-1	Housing	Airbus Industrie
7824-1	Emergency Lighting Power Supply	Luminescent Systems
7824300	Ballscrew assy	Linearmotion LLC
7824300-3	Ballscrew assy	Linearmotion LLC
7824300-4	Ballscrew assy	Linearmotion LLC
782449	Recirculation Fan	Hamilton Sundstrand
782467-1	Fuel Pump	Hamilton Sundstrand
782467-2	Fuel Pump	Hamilton Sundstrand
782475-1	Adapter and Clamp	Hamilton Sundstrand
782475-2	Adapter and Clamp	Hamilton Sundstrand
7824791	Ball Screw assy	Linearmotion LLC
7824792	Ball Screw assy	Linearmotion LLC
7825221	Ball Screw assy	Linearmotion LLC
7825222	Ball Screw assy	Linearmotion LLC
7825223	Ball Screw assy	Linearmotion LLC
7825224	Ball Screw assy	Linearmotion LLC
7826837	Ball Screw assy	Sabinaw
782689	Brush Block assy	Hamilton Sundstrand
782689-1	Brush Block assy	Hamilton Sundstrand
782689-2	Brush Block assy	Hamilton Sundstrand
782689-3	Brush Block assy	Hamilton Sundstrand
782689-4	Brush Block assy	Hamilton Sundstrand
782689-5	Brush Block assy	Hamilton Sundstrand
782689-6	Brush Block assy	Hamilton Sundstrand
782779-1	Precooler Heat Exchanger	Hamilton Sundstrand
782860	Dual Temperature Control Valve	Hamilton Sundstrand
782-889-2	Air Flow Detector	Intertechnique
782-889-3	Air Flow Detector	Intertechnique
782-889-4	Air Flow Detector	Intertechnique
782-890-2	Air Flow Detector	Intertechnique
7829995	Ball Screw assy	Sabinaw
7829996	Ball Screw assy	Sabinaw
7829997	Ball Screw assy	Sabinaw
7829998	Ball Screw assy	Sabinaw
784623	Pressure Reg & Shut-Off Valve	Hamilton Sundstrand
784624-2	Bleed Shut-Off Valve	Hamilton Sundstrand
784629	Condenser and Mixer	Hamilton Sundstrand
784660	Dual Heat Exchanger & Spray Nozzle	Hamilton Sundstrand

Repair_Capability_List_Excel

784-717-2	Thermal Switch	Intertechnique
784-718	Amplifier	Intertechnique
784750A2	Engine Pneumatic Starter	Hamilton Standard
784750A3	Engine Pneumatic Starter	Hamilton Standard
784750A4	Engine Pneumatic Starter	Hamilton Standard
784750A6	Engine Pneumatic Starter	Hamilton Standard
784-793	Air Flow Detector	Intertechnique
785-113-1	Detection Box	Intertechnique
785-259-1	Thermal Switch	Intertechnique
785-403	Thermal Switch	Intertechnique
785680	Pressure Relief Valve	Hamilton Sundstrand
785712	Condenser and Mixer	Hamilton Sundstrand
785719	High Pressure Bleed Valve	Hamilton Sundstrand
785791	Pressure Reg & Shut-Off Valve	Hamilton Sundstrand
785791-1	Pressure Reg & Shut-Off Valve	Hamilton Sundstrand
785791-2	Pressure Reg & Shut-Off Valve	Hamilton Sundstrand
785791-3	Pressure Reg & Shut-Off Valve	Hamilton Sundstrand
785791-4	Pressure Reg & Shut-Off Valve	Hamilton Sundstrand
785791-5	Pressure Reg & Shut-Off Valve	Hamilton Sundstrand
785802-1	Pressure Reg & Shut-Off Valve	Hamilton Sundstrand
785802-2	Pressure Reg & Shut-Off Valve	Hamilton Sundstrand
785802-3	Pressure Reg & Shut-Off Valve	Hamilton Sundstrand
785802-4	Pressure Reg & Shut-Off Valve	Hamilton Sundstrand
785802-5	Pressure Reg & Shut-Off Valve	Hamilton Sundstrand
785804-1	High Pressure Bleed Valve	Hamilton Sundstrand
785804-2	High Pressure Bleed Valve	Hamilton Sundstrand
785804-3	High Pressure Bleed Valve	Hamilton Sundstrand
785806-3	Air Data Sensor Heater Controller	Intertechnique
786-0040	Compressor	Liebherr Aerospace
786-010-1	Fuel Vent Protectors	Intertechnique
786-010-2	Fuel Vent Protectors	Intertechnique
786-010-3	Fuel Vent Protectors	Intertechnique
786-010-4	Fuel Vent Protectors	Intertechnique
786-010-5	Fuel Vent Protectors	Intertechnique
786-010-6	Fuel Vent Protectors	Intertechnique
786-032-1	Fuel Vent Protectors	Intertechnique
786-052	Fuel Vent Protectors	Intertechnique
786-058	Fuel Vent Protectors	Intertechnique
786333	Remote Temperature Sensor	Hamilton Sundstrand
786A0000-03	Slat Control Unit	Goodrich Control Systems
786A0000-04	Slat Control Unit	Goodrich Control Systems
786A0000-05	Slat Control Unit	Goodrich Control Systems
786A0000-06	Slat Control Unit	Goodrich Control Systems
786A0000-07	Slat Control Unit	Goodrich Control Systems
786A0000-08	Slat Control Unit	Goodrich Control Systems
786A0000-09	Slat Control Unit	Goodrich Control Systems
786A0000-10	Slat Control Unit	Goodrich Control Systems
786A0000-11	Slat Control Unit	Goodrich Control Systems
786A0000-12	Slat Control Unit	Goodrich Control Systems
786A0100-01	Pressure-Off Brake	Liebherr Aerotechnik
786A0100-02	Pressure-Off Brake	Liebherr Aerotechnik
786A1900-01	Pressure-Off Brake	Liebherr Aerotechnik
786A2000-01	Pressure-Off Brake	Liebherr Aerotechnik
787	VHF NAV/DME Control Panel	Primex
787-1	VHF NAV/DME Control Panel	Primex
787145	Fuel Pump	Hamilton Sundstrand
787-6211-001	ATC Transponder	Rockwell-Collins
787-6211-002	ATC Transponder	Rockwell-Collins

Repair_Capability_List_Excel

787-6211-003	ATC Transponder	Rockwell-Collins
787-6302-001	HF Communication Control Panel	Rockwell Collins
787-6302-002	HF Communication Control Panel	Rockwell Collins
787-6366-001	ADF Control Panel	Rockwell Collins
787-6366-002	ADF Control Panel	Rockwell Collins
787-6366-003	ADF Control Panel	Rockwell Collins
787-6366-004	ADF Control Panel	Rockwell Collins
787-6366-006	ADF Control Panel	Rockwell Collins
787-6366-007	ADF Control Panel	Rockwell Collins
787-6366-008	ADF Control Panel	Rockwell Collins
787-6366-009	ADF Control Panel	Rockwell Collins
787-6366-010	ADF Control Panel	Rockwell Collins
787-6366-011	ADF Control Panel	Rockwell Collins
787-6366-012	ADF Control Panel	Rockwell Collins
787-6366-013	ADF Control Panel	Rockwell Collins
787-6366-014	ADF Control Panel	Rockwell Collins
787-6366-015	ADF Control Panel	Rockwell Collins
787-6366-016	ADF Control Panel	Rockwell Collins
787-6366-017	ADF Control Panel	Rockwell Collins
787-6366-018	ADF Control Panel	Rockwell Collins
787A	VHF NAV/DME Control Panel	Sigma-Tek
787A0000-02	Block Valve	Liebherr Aerotechnik
787A0000-03	Block Valve	Liebherr Aerotechnik
787A0000-04	Block Valve	Liebherr Aerotechnik
787A0000-06	Block Valve	Liebherr Aerotechnik
787A0000-07	Block Valve	Liebherr Aerotechnik
787A1	VHF NAV/DME Control Panel	Sigma-Tek
787A2	VHF NAV/DME Control Panel	Sigma-Tek
787B	VHF NAV/DME Control Panel	Sigma-Tek
7881	Detector assy	Meggitt Avionics
7881-01	Detector assy	Meggitt Avionics
7882	Detector assy	Meggitt Avionics
788217	Precooler assy	Hamilton Sundstrand
7883	Detector assy	Meggitt Avionics
788366	Fuel Distribution Valve	Hamilton Sundstrand
788399	Air/Oil Heat Exchanger Valve	Hamilton Sundstrand
788399-1	Air/Oil Heat Exchanger Valve	Hamilton Sundstrand
788399-3	Air/Oil Heat Exchanger Valve	Hamilton Sundstrand
788399-4	Air/Oil Heat Exchanger Valve	Hamilton Sundstrand
788399-5	Air/Oil Heat Exchanger Valve	Hamilton Sundstrand
788399-6	Air/Oil Heat Exchanger Valve	Hamilton Sundstrand
788A0000-01	Gearbox Right Angle	Goodrich Control Systems
788A0000-02	Gearbox Right Angle	Goodrich Control Systems
788K-02	Pressure Manifold	Kollsman
788K-020	Pressure Manifold	Kollsman
789642	Compressor Bleed Valve	Pratt & Whitney
789643	Compressor Bleed Valve	Pratt & Whitney
789803	Compressor Bleed Valve	Pratt & Whitney
789A0000-01	Gearbox Line	Goodrich Control Systems
789A0000-02	Gearbox Line	Goodrich Control Systems
78RV	Engine Speed Indicator	Vibrometer
78RV-SB	Engine Speed Indicator	Vibrometer
7900063	Toilet assy	Envirovac
7900063-1	Toilet assy	Envirovac
7900063A	Toilet assy	Envirovac
7900063B	Toilet assy	Envirovac
7900063C	Toilet assy	Envirovac
7900063D	Toilet assy	Envirovac

Repair_Capability_List_Excel

7900063E	Toilet assy	Envirovac
7900064	Toilet assy	Envirovac
7900064-1	Toilet assy	Envirovac
7900064A	Toilet assy	Envirovac
7900064B	Toilet assy	Envirovac
7900064C	Toilet assy	Envirovac
7900064D	Toilet assy	Envirovac
7900064E	Toilet assy	Envirovac
7900065	Toilet assy	Envirovac
7900065A	Toilet assy	Envirovac
7900065B	Toilet assy	Envirovac
7900065C	Toilet assy	Envirovac
7900065D	Toilet assy	Envirovac
7900065E	Toilet assy	Envirovac
7900066	Toilet assy	Envirovac
7900066A	Toilet assy	Envirovac
7900066B	Toilet assy	Envirovac
7900066C	Toilet assy	Envirovac
7900066D	Toilet assy	Envirovac
7900066E	Toilet assy	Envirovac
7900067	Ball Screw assy	Sabinaw
7900072	Ball Screw assy	Sabinaw
7900103	Toilet assy	Envirovac
7900104	Toilet assy	Envirovac
7900105	Toilet assy	Envirovac
7900106	Toilet assy	Envirovac
790144	Air/Oil Heat Exchanger Valve	Hamilton Sundstrand
790-209	Tank Probe	Intertechnique
790-209-1	Tank Probe	Intertechnique
790210	Bleed Actuator	Hamilton Sundstrand
790-210	Tank Probe	Intertechnique
790210-1	Bleed Actuator	Hamilton Sundstrand
790-210-1	Tank Probe	Intertechnique
790-211	Tank Probe	Intertechnique
790-211-1	Tank Probe	Intertechnique
790270-1	High Pressure Shut-off Valve	Hamilton Sundstrand
790270-10	High Pressure Shut-off Valve	Hamilton Sundstrand
790270-11	High Pressure Shut-off Valve	Hamilton Sundstrand
790270-12	High Pressure Shut-off Valve	Hamilton Sundstrand
790270-13	High Pressure Shut-off Valve	Hamilton Sundstrand
790270-14	High Pressure Shut-off Valve	Hamilton Sundstrand
790270-15	High Pressure Shut-off Valve	Hamilton Sundstrand
790270-2	High Pressure Shut-off Valve	Hamilton Sundstrand
790270-3	High Pressure Shut-off Valve	Hamilton Sundstrand
790270-4	High Pressure Shut-off Valve	Hamilton Sundstrand
790270-5	High Pressure Shut-off Valve	Hamilton Sundstrand
790270-6	High Pressure Shut-off Valve	Hamilton Sundstrand
790270-7	High Pressure Shut-off Valve	Hamilton Sundstrand
790270-8	High Pressure Shut-off Valve	Hamilton Sundstrand
790270-9	High Pressure Shut-off Valve	Hamilton Sundstrand
7903042M	Spherical Plug Valve	FR Hitemp
7903043F	Spherical Plug Valve	FR Hitemp
790312-1	Check Valve	Pratt & Whitney
790313-1	Check Valve	Hamilton Sundstrand
790370	Pack Temperature Control Valve	Hamilton Sundstrand
790420-1	Bleed Shut-Off Valve	Hamilton Sundstrand
790420-2	Bleed Shut-Off Valve	Hamilton Sundstrand
790420-3	Bleed Shut-Off Valve	Hamilton Sundstrand

Repair_Capability_List_Excel

790A0000-01	Gearbox 19 Degree	Goodrich Control Systems
790A0000-02	Gearbox 19 Degree	Goodrich Control Systems
791A0000-02	Flap Actuator	Goodrich Control Systems
791A0000-03	Flap Actuator	Goodrich Control Systems
791A0000-04	Flap Actuator	Goodrich Control Systems
791A0000-05	Flap Actuator	Goodrich Control Systems
791A0000-06	Flap Actuator	Goodrich Control Systems
791C0000-01	Flap Actuator	Goodrich Control Systems
792000	Variable Pitch AC Propeller	Hamilton Sundstrand
792000-3	Variable Pitch AC Propeller	Hamilton Sundstrand
792000-4	Variable Pitch AC Propeller	Hamilton Sundstrand
7923061M	Non-Return Valve	FR Hitemp
7923261M	Non-Return Valve	FR Hitemp
7923267J	Valve	FR Hitemp
7923268L	Overflow Valve	FR Hitemp
792-6091-001	Course Indicator	Rockwell Collins
792-6091-009	Course Indicator	Rockwell Collins
792-6091-011	Course Indicator	Rockwell Collins
792-6091-012	Course Indicator	Rockwell Collins
792-6091-016	Course Indicator	Rockwell Collins
792-6140-001	Antenna Coupler	Rockwell-Collins
792-6355-004	Flight Director Indicator	Rockwell Collins
792778-1	Cabin Temperature Sensor	Hamilton Sundstrand
792778-3	Cabin Temperature Sensor	Hamilton Sundstrand
792778-4	Cabin Temperature Sensor	Hamilton Sundstrand
792917	Compressor Bleed Valve	Pratt & Whitney
792919	Compressor Bleed Valve	Pratt & Whitney
792930	Air Supply Precooler	Hamilton Sundstrand
792930-3	Air Supply Precooler	Hamilton Sundstrand
792930-4	Air Supply Precooler	Hamilton Sundstrand
792930-5	Air Supply Precooler	Hamilton Sundstrand
792940-3	Air Supply Precooler	Hamilton Sundstrand
792940-4	Air Supply Precooler	Hamilton Sundstrand
792940-5	Air Supply Precooler	Hamilton Sundstrand
792A0000-03	Flap Actuator	Goodrich Control Systems
792A0000-04	Flap Actuator	Goodrich Control Systems
792A0000-05	Flap Actuator	Goodrich Control Systems
792A0000-06	Flap Actuator	Goodrich Control Systems
792A0000-07	Flap Actuator	Goodrich Control Systems
792C0000-01	Flap Actuator	Goodrich Control Systems
792D0000-01	Flap Actuator	Goodrich Control Systems
7930-358-401	Lamp Test & Flight Phase Adapter Box	Fokker Aircraft
793042	Dual Heat Exchanger & Spray Nozzle	Hamilton Sundstrand
7933141J	Spherical Plug Valve	FR Hitemp
7933156J	Spherical Plug Valve	FR Hitemp
793322	Probe assy	Pratt & Whitney
793323	Compressor Outlet Temp. Sensor	Hamilton Sundstrand
793323-1	Compressor Outlet Temp. Sensor	Hamilton Sundstrand
793999	Air/Oil Heat Exchanger Valve	Hamilton Sundstrand
793999-1	Air/Oil Heat Exchanger Valve	Hamilton Sundstrand
793999-2	Air/Oil Heat Exchanger Valve	Hamilton Sundstrand
793999-3	Air/Oil Heat Exchanger Valve	Hamilton Sundstrand
793A0000-03	Flap Actuator	Goodrich Control Systems
793A0000-04	Flap Actuator	Goodrich Control Systems
793A0000-05	Flap Actuator	Goodrich Control Systems
793A0000-06	Flap Actuator	Goodrich Control Systems
793A0000-07	Flap Actuator	Goodrich Control Systems
793C0000-01	Flap Actuator	Goodrich Control Systems

Repair_Capability_List_Excel

793T100-1	Drive Unit	Telair International
793T100-3	Drive Unit	Telair International
793T100-5	Drive Unit	Telair International
793T100-7	Actuator	Telair International
7940007H	Valve assy	FR Hitemp
7940052D	Valve assy	FR Hitemp
7940061D	Valve assy	FR Hitemp
794-357	Tank Probe	Intertechnique
794-357-1	Tank Probe	Intertechnique
794-358	Tank Probe	Intertechnique
794-358-1	Tank Probe	Intertechnique
794-359	Tank Probe	Intertechnique
794-359-1	Tank Probe	Intertechnique
794-360	Tank Probe	Intertechnique
794-360-1	Tank Probe	Intertechnique
794-361	Tank Probe	Intertechnique
794-361-1	Tank Probe	Intertechnique
794-362	Tank Probe	Intertechnique
794-362-1	Tank Probe	Intertechnique
7945007/H	Shut-Off Valve	FR Hitemp
7945008/F	Valve assy	FR Hitemp
7945009/F	Valve assy	FR Hitemp
7945010/D	Valve assy	FR Hitemp
7945011/H	Valve assy	FR Hitemp
7945012/H	Valve assy	FR Hitemp
7945013/H	Valve assy	FR Hitemp
7945016/H	Valve assy	FR Hitemp
7945017/F	Valve assy	FR Hitemp
7945201/H	Valve assy	FR Hitemp
7945202/H	Valve assy	FR Hitemp
7945217/F	Valve assy	FR Hitemp
794-531-2	Probe	Intertechnique
794-532-1	Probe	Intertechnique
794-533-1	Probe	Intertechnique
794-534-1	Probe	Intertechnique
794-535-1	Probe	Intertechnique
794-536-1	Probe	Intertechnique
794-536-2	Fuel Quantity Probe	Intertechnique
794-537-2	Probe	Intertechnique
794-538-1	Probe	Intertechnique
794-540-1	Probe	Intertechnique
794-541-2	Probe	Intertechnique
794-542-1	Probe	Intertechnique
794-543-1	Probe	Intertechnique
794-544-1	Probe	Intertechnique
794-777	Tank Probe	Intertechnique
794-777-1	Tank Probe	Intertechnique
794-818	Probe	Intertechnique
794-819	Probe	Intertechnique
794-936	Tank Probe	Intertechnique
794-937	Tank Probe	Intertechnique
794-938	Tank Probe	Intertechnique
794-992	Tank Probe	Intertechnique
794A0000-02	Flap Actuator	Goodrich Control Systems
794A0000-03	Flap Actuator	Goodrich Control Systems
794A0000-04	Flap Actuator	Goodrich Control Systems
794A0000-05	Flap Actuator	Goodrich Control Systems
794A0000-06	Flap Actuator	Goodrich Control Systems

Repair_Capability_List_Excel

794C0000-01	Flap Actuator	Goodrich Control Systems
794PG	Pressure Transmitter	Vibrometer
794PG-M	Pressure Transmitter	Vibrometer
7957132-5501	Pressure Transmitter	Ametek
796050-1-000	Fuel Flow Divider Valve	Hamilton Sundstrand
796257	Compressor Bleed Valve	Pratt & Whitney
796258	Compressor Bleed Valve	Pratt & Whitney
796-295	Selector	Intertechnique
796-296-1	Amplifier	FR Hitemp
796-297	Selector	Intertechnique
796-298	Selector	Intertechnique
796-354-1	Attitude Sensor	Intertechnique
796-364	Selector	Intertechnique
796-371-2	Preselector	Intertechnique
796-391	Contents Gauge Cable Harness	Intertechnique
796-391-1	Contents Gauge Cable Harness	Intertechnique
796-488-1	Fuel Tank Harness	Intertechnique
796-624-1	Preselector	Intertechnique
796-697-1	Harness assy	Intertechnique
796-697-2	Harness assy	Intertechnique
796-697-3	Harness assy	Intertechnique
796-698-1	Harness assy	Intertechnique
796-698-2	Harness assy	Intertechnique
796-698-3	Harness assy	Intertechnique
796-699-1	Harness assy	Intertechnique
796-699-2	Harness assy	Intertechnique
796-699-3	Harness assy	Intertechnique
796-700-1	Harness assy	Intertechnique
796-778-1	Adapter Harness	Intertechnique
796-779-1	Adapter Harness	Intertechnique
796-806	Preselector	Intertechnique
796-814	Preselector	Intertechnique
796-871-1	Harness assy	Intertechnique
796-871-2	Harness assy	Intertechnique
796-871-3	Harness assy	Intertechnique
796882-1-001	Cabin Temp. Selector Panel	Hamilton Sundstrand
796882-2-001	Cabin Temp. Selector Panel	Hamilton Sundstrand
796882-3-001	Cabin Temp. Selector Panel	Hamilton Sundstrand
796-947-1	Harness assy	Intertechnique
796-947-2	Harness assy	Intertechnique
796-947-3	Harness assy	Intertechnique
796-948-1	Harness assy	Intertechnique
796-948-2	Harness assy	Intertechnique
796-948-3	Harness assy	Intertechnique
796-949-1	Harness assy	Intertechnique
796-949-2	Harness assy	Intertechnique
796-949-3	Harness assy	Intertechnique
796-950-1	Junction Box	Intertechnique
796-965	Harness assy	Intertechnique
796-966	Preselector	Intertechnique
796-967	Preselector	Intertechnique
796-976	Harness assy	Intertechnique
796-977	Harness assy	Intertechnique
796-977-1	Harness assy	Intertechnique
796-977-2	Harness assy	Intertechnique
796-978	Harness assy	Intertechnique
796-979	Preselector	Intertechnique
796-984	Preselector	Intertechnique

Repair_Capability_List_Excel

796A0000-01	Gearbox	Goodrich Control Systems
796A0000-02	Gearbox	Goodrich Control Systems
7977-03-01	Torque Differential	Precilec
797800	Pressure Reg. Valve Shutdown Ctrl	Hamilton Sundstrand
797A0000-01	Gearbox	Goodrich Control Systems
797A0000-02	Gearbox	Goodrich Control Systems
798-017	Harness assy	Intertechnique
798-017-1	Harness assy	Intertechnique
798-017-2	Harness assy	Intertechnique
798-038	Tank Probe	Intertechnique
798-078	Harness assy	Intertechnique
798-078-1	Harness assy	Intertechnique
798-078-2	Harness assy	Intertechnique
798113-3	Refuel Defuel Panel	Intertechnique
798113-4	Refuel Defuel Panel	Intertechnique
798113-5	Refuel Defuel Panel	Intertechnique
798113-6	Refuel Defuel Panel	Intertechnique
798114-3	Refuel Defuel Panel	Intertechnique
798114-4	Refuel Defuel Panel	Intertechnique
798114-5	Refuel Defuel Panel	Intertechnique
798114-6	Refuel Defuel Panel	Intertechnique
798457	Flight Deck Temp. Selector	Hamilton Sundstrand
798750	Air/Oil Heat Exchanger Valve	Hamilton Sundstrand
798750-1	Air/Oil Heat Exchanger Valve	Hamilton Sundstrand
798840-1-0	Fuel Temperature Sensor	Intertechnique
798850	Air/Oil Heat Exchanger Valve	Hamilton Sundstrand
798850-1	Air/Oil Heat Exchanger Valve	Hamilton Sundstrand
798850-2	Air/Oil Heat Exchanger Valve	Hamilton Sundstrand
798882-1-1	Refuel Defuel Panel	Intertechnique
798883-1-1	Refuel Defuel Panel	Intertechnique
798A0000-01	Gearbox	Goodrich Control Systems
798A0000-02	Gearbox	Goodrich Control Systems
799700-1	Starter Control Valve	Hamilton Sundstrand
799700-2	Starter Control Valve	Hamilton Sundstrand
799710	Pack Temperature Control Valve	Hamilton Sundstrand
799746-1	Overtemperature Switch	Hamilton Sundstrand
799746-2	Overtemperature Switch	Hamilton Sundstrand
799801	Pressure Regulating & Shut-off Valve	Hamilton Sundstrand
799801-1	Pressure Regulating & Shut-off Valve	Hamilton Sundstrand
799801-2	Pressure Regulating & Shut-off Valve	Hamilton Sundstrand
799801-3	Pressure Regulating & Shut-off Valve	Hamilton Sundstrand
799801-4	Pressure Regulating & Shut-off Valve	Hamilton Sundstrand
799A0000-01	Actuator	Goodrich Control Systems
79RV	Engine Speed Indicator	Vibrometer
79RV-SB	Engine Speed Indicator	Vibrometer
7ET1-T	Switch	Micro Switch
7G1018	Switch	Custom Control Sensors
7G110-3	Low Pressure Switch	Custom Control Sensors
7G110-5	Low Pressure Switch	Custom Control Sensors
7G110-6	Low Pressure Switch	Custom Control Sensors
7G74	Pressure Switch	Custom Control Sensors
7G754	Switch	Custom Control Sensors
7G754-2	Switch	Custom Control Sensors
7G811	Pressure Switch	Custom Control Sensors
7G813	Pressure Switch	Custom Control Sensors
7G839	Low Pressure Switch	Custom Control Sensors
7G840	High Pressure Switch	Custom Control Sensors
7G844	Low Pressure Switch	Custom Control Sensors

Repair_Capability_List_Excel

7G845	High Pressure Switch	Custom Control Sensors
7GB309	Pressure Switch	Custom Control Sensors
7GR159	Switch	Custom Control Sensors
7M1330-1	Rail ay	Goodrich
7M1330-2	Rail ay	Goodrich
7M1330-3	Rail ay	Goodrich
7M1330-4	Rail ay	Goodrich
7M1340-1	Rail ay	Goodrich
7M1340-2	Rail ay	Goodrich
7M1344-1	Rail Support Fitting ay	Goodrich
7M1345-1	Rail Support Fitting ay	Goodrich
7M1346-1	Rail Support Fitting ay	Goodrich
7M1346-2	Rail Support Fitting ay	Goodrich
7M1359-1	Rail Support Fitting ay	Goodrich
7M1360-1	Rail ay	Goodrich
7M1360-2	Rail ay	Goodrich
7M1361-1	Rail ay	Goodrich
7M1361-2	Rail ay	Goodrich
7M1361-3	Rail ay	Goodrich
7M1361-4	Rail ay	Goodrich
7M1362-1	Rail ay	Goodrich
7M1363-1	Rail ay	Goodrich
7M1364-1	Rail ay	Goodrich
7M1365-1	Rail ay	Goodrich
7M1365-3	Rail ay	Goodrich
7M1366-1	Rail ay	Goodrich
7M1367-1	Rail ay	Goodrich
7M1367-2	Rail ay	Goodrich
7M1368-1	Rail ay	Goodrich
7M1369-1	Rail ay	Goodrich
7M1370-1	Rail ay	Goodrich
7M1370-3	Rail ay	Goodrich
7M1371-1	Rail ay	Goodrich
7M1372-1	Rail ay	Goodrich
7M1372-2	Rail ay	Goodrich
7M1373-1	Rail ay	Goodrich
7M1374-1	Rail ay	Goodrich
7M1374-2	Rail ay	Goodrich
7M1375-1	Rail ay	Goodrich
7M1375-2	Rail ay	Goodrich
7M1376-1	Rail ay	Goodrich
7M1377-1	Rail ay	Goodrich
7M1398-1	Rail Support Fitting ay	Goodrich
7M14001-1	Stop ay	Goodrich
7M14001-2	Stop ay	Goodrich
7M1650-1	Caster Panel ay	Goodrich
7M1651-1	Caster Panel ay	Goodrich
7M1652-1	Caster Panel ay	Goodrich
7M1653-1	Caster Panel ay	Goodrich
7M1654-1	Caster Panel ay	Goodrich
7M1655-1	Caster Panel ay	Goodrich
7M1656-1	Caster Panel ay	Goodrich
7M1657-1	Caster Panel ay	Goodrich
7M1658-1	Caster Panel ay	Goodrich
7M1659-1	Caster Panel ay	Goodrich
7M1680-1	Caster ay	Goodrich
7M1680-2	Caster ay	Goodrich
7M1680-3	Caster ay	Goodrich

Repair_Capability_List_Excel

7M1680-4	Caster ay	Goodrich
7M1860-1	Caster ay	Goodrich
7M1860-2	Caster ay	Goodrich
7M1E100-1	Local Panel ay	Goodrich
7M1E100-2	Local Panel ay	Goodrich
7M1E100-3	Local Panel ay	Goodrich
7M1E100-4	Local Panel ay	Goodrich
7M1E100-5	Local Panel ay	Goodrich
7M1E100-6	Local Panel ay	Goodrich
7M1E110-1	Local Panel ay	Goodrich
7M1E110-2	Local Panel ay	Goodrich
7M1E110-3	Local Panel ay	Goodrich
7M1E110-4	Local Panel ay	Goodrich
7M1E120-1	Door Panel ay	Goodrich
7M1E120-2	Door Panel ay	Goodrich
7M1E130-1	Cargo Control Panel	Goodrich
7M1E140-1	Remote Control Panel ay	Goodrich
7M1E170-1	Nose Door Control Panel	Goodrich
7M1E180-1	Auxiliary Control Panel ay	Goodrich
7M1E190-1	PDU Disengage Control Panel ay	Goodrich
7M1E190-2	PDU Disengage Control Panel ay	Goodrich
7M2370-1	Guide Rail ay	Goodrich
7M2397-1	Guide and Restraint ay	Goodrich
7M2404-1	Guide Rail Support ay	Goodrich
7M2404-2	Guide Rail Support ay	Goodrich
7M30000-18	Lock Tray ay	Goodrich
7M30000-19	Lock Tray ay	Goodrich
7M30000-20	Lock Tray ay	Goodrich
7M30000-21	Lock Tray ay	Goodrich
7M30000-22	Lock Tray ay	Goodrich
7M30005-1	Lock Tray ay	Goodrich
7M30006-1	Lock Tray ay	Goodrich
7M30007-1	Lock Tray ay	Goodrich
7M30008-1	Lock Tray ay	Goodrich
7M30009-1	Lock Tray ay	Goodrich
7M30010-1	Lock Tray ay	Goodrich
7M30010-2	Lock Tray ay	Goodrich
7M30010-3	Lock Tray ay	Goodrich
7M30014-1	Lock ay	Goodrich
7M30015-7	Lock Tray ay	Goodrich
7M30016-1	Stop ay	Goodrich
7M30017-1	Lock Tray ay	Goodrich
7M30018-1	Lock Tray ay	Goodrich
7M30019-2	Lock Tray ay	Goodrich
7M30023-1	Stop ay	Goodrich
7M30024-5	Stop ay	Goodrich
7M30026-4	Retractable End Stop ay	Goodrich
7M30026-5	Retractable End Stop ay	Goodrich
7M30040-1	Pallet Lock ay	Goodrich
7M30040-2	Pallet Lock ay	Goodrich
7M30040-3	Pallet Lock ay	Goodrich
7M30047-1	Stop ay	Goodrich
7M30162-6	Stop ay	Goodrich
7M30300-1	Stop ay	Goodrich
7M30300-2	Stop ay	Goodrich
7M31030-1	Bumper ay	Goodrich
7M31040-1	Directional Guide Panel ay	Goodrich
7M32500-1	Unicaster ay	Goodrich

Repair_Capability_List_Excel

7M32500-2	Unicaster ay	Goodrich
7M32502-1	Unicaster ay	Goodrich
7M32502-2	Unicaster ay	Goodrich
7M32502-3	Unicaster ay	Goodrich
7M32504-1	Tray ay	Goodrich
7M32504-2	Tray ay	Goodrich
7M32507-1	Restraint Tray ay	Goodrich
7M32507-2	Restraint Tray ay	Goodrich
7M32508-1	Restraint Tray ay	Goodrich
7M32508-2	Restraint Tray ay	Goodrich
7M32509-1	Restraint Tray ay	Goodrich
7M32509-2	Restraint Tray ay	Goodrich
7M32510-1	Restraint Tray ay	Goodrich
7M32510-2	Restraint Tray ay	Goodrich
7M32511-1	Restraint Tray ay	Goodrich
7M32511-2	Restraint Tray ay	Goodrich
7M32512-1	Restraint Tray ay	Goodrich
7M32512-2	Restraint Tray ay	Goodrich
7M32513-1	Restraint Tray ay	Goodrich
7M32513-2	Restraint Tray ay	Goodrich
7M32514-1	Restraint Tray ay	Goodrich
7M32514-2	Restraint Tray ay	Goodrich
7M32515-1	Restraint Tray ay	Goodrich
7M32515-2	Restraint Tray ay	Goodrich
7M32516-1	Restraint Tray ay	Goodrich
7M32516-2	Restraint Tray ay	Goodrich
7M32517-1	Tray ay	Goodrich
7M32517-2	Tray ay	Goodrich
7M32518-1	Tray ay	Goodrich
7M32518-2	Tray ay	Goodrich
7M32519-1	Tray ay	Goodrich
7M32519-2	Tray ay	Goodrich
7M32520-1	Tray ay	Goodrich
7M32520-2	Tray ay	Goodrich
7M32521-1	Tray ay	Goodrich
7M32521-2	Tray ay	Goodrich
7M32522-1	Tray ay	Goodrich
7M32522-2	Tray ay	Goodrich
7M32523-1	Tray ay	Goodrich
7M32523-2	Tray ay	Goodrich
7M32524-1	Tray ay	Goodrich
7M32524-2	Tray ay	Goodrich
7M32525-1	Tray ay	Goodrich
7M32525-2	Tray ay	Goodrich
7M32526-1	Tray ay	Goodrich
7M32526-2	Tray ay	Goodrich
7M32527-1	Tray ay	Goodrich
7M32527-2	Tray ay	Goodrich
7M32528-1	Tray ay	Goodrich
7M32528-2	Tray ay	Goodrich
7M32529-1	Tray ay	Goodrich
7M32529-2	Tray ay	Goodrich
7M32530-1	Tray ay	Goodrich
7M32530-2	Tray ay	Goodrich
7M32531-1	Tray ay	Goodrich
7M32531-2	Tray ay	Goodrich
7M32532-1	Tray ay	Goodrich
7M32532-2	Tray ay	Goodrich

Repair_Capability_List_Excel

7M32533-1	Tray ay	Goodrich
7M32533-2	Tray ay	Goodrich
7M32534-1	Tray ay	Goodrich
7M32534-2	Tray ay	Goodrich
7M32535-1	Tray ay	Goodrich
7M32535-2	Tray ay	Goodrich
7M32536-1	Tray ay	Goodrich
7M32536-2	Tray ay	Goodrich
7M32537-1	Tray ay	Goodrich
7M32537-2	Tray ay	Goodrich
7M32538-1	Tray ay	Goodrich
7M32538-2	Tray ay	Goodrich
7M32539-1	Tray ay	Goodrich
7M32539-2	Tray ay	Goodrich
7M32540-1	Tray ay	Goodrich
7M32540-2	Tray ay	Goodrich
7M32541-1	Tray ay	Goodrich
7M32541-2	Tray ay	Goodrich
7M32542-1	Tray ay	Goodrich
7M32542-2	Tray ay	Goodrich
7M32543-1	Tray ay	Goodrich
7M32543-2	Tray ay	Goodrich
7M32544-1	Tray ay	Goodrich
7M32545-1	Tray ay	Goodrich
7M32545-2	Tray ay	Goodrich
7M32546-1	Tray ay	Goodrich
7M32546-2	Tray ay	Goodrich
7M32547-1	Tray ay	Goodrich
7M32547-2	Tray ay	Goodrich
7M32610-1	Tray ay	Goodrich
7M32612-1	Tray ay	Goodrich
7M32621-1	Tray ay	Goodrich
7M32622-1	Tray ay	Goodrich
7M32625-1	Tray ay	Goodrich
7M32627-1	Restraint and Caster ay	Goodrich
7M33001-7	Retractable Guide Rail ay	Goodrich
7M33001-8	Retractable Guide Rail ay	Goodrich
7M33002-24	Guide and Restraint ay	Goodrich
7M33003-1	Park Rail ay	Goodrich
7M33004-4	Guide Rail ay	Goodrich
7M33005-2	Guide Rail ay	Goodrich
7M33006-2	Guide Rail ay	Goodrich
7M33007-2	Guide Rail ay	Goodrich
7M33008-1	Guide Support ay	Goodrich
7M33010-7	Guide Rail ay	Goodrich
7M33012-2	Rail Support ay	Goodrich
7M33025-1	Restraint ay	Goodrich
7M33107-1	Caster ay	Goodrich
7M33107-2	Caster ay	Goodrich
7M33107-3	Caster ay	Goodrich
7M33107-4	Caster ay	Goodrich
7M33341-7	Park Rail ay	Goodrich
7M34000-1	Retractable Stop ay	Goodrich
7M3M001-135	Caster Tray ay	Goodrich
7M3M005-53	Restraint and Caster ay	Goodrich
7M3M009-1	Lock Tray ay	Goodrich
7M3M009-2	Lock Tray ay	Goodrich
7M3M010-1	Lock Tray ay	Goodrich

Repair_Capability_List_Excel

7M3M010-2	Lock Tray ay	Goodrich
7M3M011-1	Lock Tray ay	Goodrich
7M3M011-2	Lock Tray ay	Goodrich
7M3M012-1	Lock Tray ay	Goodrich
7M3M012-2	Lock Tray ay	Goodrich
7M3M013-1	Lock Tray ay	Goodrich
7M3M013-2	Lock Tray ay	Goodrich
7M3M014-1	Lock Tray ay	Goodrich
7M3M014-2	Lock Tray ay	Goodrich
7M3M015-1	Lock Tray ay	Goodrich
7M3M015-2	Lock Tray ay	Goodrich
7M3M016-1	Lock Tray ay	Goodrich
7M3M016-2	Lock Tray ay	Goodrich
7M3M017-1	Lock Tray ay	Goodrich
7M3M017-2	Lock Tray ay	Goodrich
7M3M018-1	Lock Roller Tray ay	Goodrich
7M3M018-2	Lock Roller Tray ay	Goodrich
7M3M020-1	Lock Tray ay	Goodrich
7M3M021-1	Lock Tray ay	Goodrich
7M3N000-16	Roller Tray ay	Goodrich
7M3N000-17	Roller Tray ay	Goodrich
7M3N000-18	Roller Tray ay	Goodrich
7M3N000-19	Roller Tray ay	Goodrich
7M3N100-1	Power Drive Unit ay	Goodrich
7M3N100-2	Power Drive Unit ay	Goodrich
7M3N100-3	Power Drive Unit ay	Goodrich
7M3N100-4	Power Drive Unit ay	Goodrich
7M3N100-5	Power Drive Unit ay	Goodrich
7M3N140-1	Power Drive Unit Drain Pan ay	Goodrich
7M3N140-2	Power Drive Unit Drain Pan ay	Goodrich
7M3N140-3	Power Drive Unit Drain Pan ay	Goodrich
7M3N140-4	Power Drive Unit Drain Pan ay	Goodrich
7M3T000-1	Sill ay	Goodrich
7M3T000-2	Sill ay	Goodrich
7M3T050-2	Roller Frame ay	Goodrich
7M3V070-1	Restraint ay	Goodrich
7M3V071-1	Restraint ay	Goodrich
7M3V072-1	Restraint ay	Goodrich
7M3V180-1	Restraint ay	Goodrich
7M3W025-1	Unicaster ay	Goodrich
7M3W030-1	Unicaster Panel ay	Goodrich
7M3W031-1	Unicaster Panel ay	Goodrich
7M3W032-1	Unicaster Panel ay	Goodrich
7M3W033-1	Unicaster Panel ay	Goodrich
7M3W034-1	Unicaster Panel ay	Goodrich
7M3W035-1	Unicaster Panel ay	Goodrich
7M3W036-1	Unicaster Panel ay	Goodrich
7M3W037-1	Unicaster Panel ay	Goodrich
7M3W038-1	Unicaster Panel ay	Goodrich
7M3W039-1	Unicaster Panel ay	Goodrich
7N12010-1	Ball Tube ay	Goodrich
7N12020-1	Ball Tube ay	Goodrich
7N12030-1	Ball Tube ay	Goodrich
7N12040-1	Ball Tube ay	Goodrich
7N12100-1	Tray ay	Goodrich
7N12101-1	Tray ay	Goodrich
7N12102-1	Tray ay	Goodrich
7N12103-1	Tray ay	Goodrich

Repair_Capability_List_Excel

7N12104-1	Tray ay	Goodrich
7N12105-1	Tray ay	Goodrich
7N12106-1	Tray ay	Goodrich
7N12107-1	Tray ay	Goodrich
7N12108-1	Tray ay	Goodrich
7N12150-1	BTU Rail ay	Goodrich
7N12151-1	Rail ay	Goodrich
7N12152-1	Rail ay	Goodrich
7N12153-1	Rail ay	Goodrich
7N12154-1	Rail ay	Goodrich
7N12155-1	Rail ay	Goodrich
7N12156-1	Rail ay	Goodrich
7N12157-1	Rail ay	Goodrich
7N12158-1	Rail ay	Goodrich
7N12159-1	Rail ay	Goodrich
7N12170-1	Guide ay	Goodrich
7N15010-1	Auxiliary Side Guide	Goodrich
7N15010-10	Auxiliary Side Guide	Goodrich
7N15010-2	Auxiliary Side Guide	Goodrich
7N15010-3	Auxiliary Side Guide	Goodrich
7N15010-4	Auxiliary Side Guide	Goodrich
7N15010-5	Auxiliary Side Guide	Goodrich
7N15010-6	Auxiliary Side Guide	Goodrich
7N15010-7	Auxiliary Side Guide	Goodrich
7N15010-8	Auxiliary Side Guide	Goodrich
7N15010-9	Auxiliary Side Guide	Goodrich
7N15040-1	Rail support ay	Goodrich
7N15060-1	Restraint Rail ay	Goodrich
7N16000-1	Ball Panel ay	Goodrich
7N16050-1	Ball Panel ay	Goodrich
7N16100-1	Ball Panel ay	Goodrich
7N16200-1	Ball Panel ay	Goodrich
7N16300-1	Ball Panel ay	Goodrich
7N16350-1	Ball Panel ay	Goodrich
7N16400-1	Ball Panel ay	Goodrich
7N16450-1	Ball Panel ay	Goodrich
7N16500-1	Ball Panel ay	Goodrich
7N16550-1	Ball Panel ay	Goodrich
7N16600-1	Ball Panel ay	Goodrich
80-0120-1	Central Warning Panel	Grimes Aerospace
80-0120-11	Central Warning Panel	Grimes Aerospace
80-0120-13	Central Warning Panel	Grimes Aerospace
80-0120-15	Central Warning Panel	Grimes Aerospace
80-0120-17	Central Warning Panel	Grimes Aerospace
80-0120-19	Central Warning Panel	Grimes Aerospace
80-0120-21	Central Warning Panel	Grimes Aerospace
80-0120-23	Central Warning Panel	Grimes Aerospace
80-0120-27	Central Warning Panel	Grimes Aerospace
80-0120-29	Central Warning Panel	Grimes Aerospace
80-0120-3	Central Warning Panel	Grimes Aerospace
80-0120-31	Central Warning Panel	Grimes Aerospace
80-0120-33	Central Warning Panel	Grimes Aerospace
80-0120-35	Central Warning Panel	Grimes Aerospace
80-0120-37	Central Warning Panel	Grimes Aerospace
80-0120-39	Central Warning Panel	Grimes Aerospace
80-0120-41	Central Warning Panel	Grimes Aerospace
80-0120-43	Central Warning Panel	Grimes Aerospace
80-0120-45	Central Warning Panel	Grimes Aerospace

Repair_Capability_List_Excel

80-0120-47	Central Warning Panel	Grimes Aerospace
80-0120-49	Central Warning Panel	Grimes Aerospace
80-0120-5	Central Warning Panel	Grimes Aerospace
80-0120-51	Central Warning Panel	Grimes Aerospace
80-0120-53	Central Warning Panel	Grimes Aerospace
80-0120-55	Central Warning Panel	Grimes Aerospace
80-0120-57	Central Warning Panel	Grimes Aerospace
80-0120-7	Central Warning Panel	Grimes Aerospace
80-0120-9	Central Warning Panel	Grimes Aerospace
80-0122-1	Warning Panel	Grimes Aerospace
80-0122-11	Warning Panel	Grimes Aerospace
80-0122-13	Warning Panel	Grimes Aerospace
80-0122-15	Warning Panel	Grimes Aerospace
80-0122-17	Warning Panel	Grimes Aerospace
80-0122-19	Warning Panel	Grimes Aerospace
80-0122-3	Warning Panel	Grimes Aerospace
80-0122-5	Warning Panel	Grimes Aerospace
80-0122-7	Warning Panel	Grimes Aerospace
80-0122-9	Warning Panel	Grimes Aerospace
80-0535-1	Caution & Advisory Annunciator Panel	Grimes Aerospace
80-0535-11	Caution & Advisory Annunciator Panel	Grimes Aerospace
80-0535-13	Caution & Advisory Annunciator Panel	Grimes Aerospace
80-0535-15	Caution & Advisory Annunciator Panel	Grimes Aerospace
80-0535-17	Caution & Advisory Annunciator Panel	Grimes Aerospace
80-0535-19	Caution & Advisory Annunciator Panel	Grimes Aerospace
80-0535-21	Caution & Advisory Annunciator Panel	Grimes Aerospace
80-0535-23	Caution & Advisory Annunciator Panel	Grimes Aerospace
80-0535-25	Caution & Advisory Annunciator Panel	Grimes Aerospace
80-0535-27	Caution & Advisory Annunciator Panel	Grimes Aerospace
80-0535-29	Caution & Advisory Annunciator Panel	Grimes Aerospace
80-0535-3	Caution & Advisory Annunciator Panel	Grimes Aerospace
80-0535-31	Caution & Advisory Annunciator Panel	Grimes Aerospace
80-0535-33	Caution & Advisory Annunciator Panel	Grimes Aerospace
80-0535-35	Caution & Advisory Annunciator Panel	Grimes Aerospace
80-0535-37	Caution & Advisory Annunciator Panel	Grimes Aerospace
80-0535-39	Caution & Advisory Annunciator Panel	Grimes Aerospace
80-0535-5	Caution & Advisory Annunciator Panel	Grimes Aerospace
80-0535-7	Caution & Advisory Annunciator Panel	Grimes Aerospace
80-0535-9	Caution & Advisory Annunciator Panel	Grimes Aerospace
80-0557-11	Aural Warning Unit	Grimes Aerospace
80-0590-2-2	Integrated Alerting Unit	Grimes Aerospace
80-0590-2-3	Integrated Alerting Unit	Grimes Aerospace
80-0590-2-4	Integrated Alerting Unit	Grimes Aerospace
80-0590-3-5	Integrated Alerting Unit	Grimes Aerospace
80-0590-3-6	Integrated Alerting Unit	Grimes Aerospace
80-0590-3-7	Integrated Alerting Unit	Grimes Aerospace
80-0590-3-8	Integrated Alerting Unit	Grimes Aerospace
80-0591-11	Central Annunciator Panel	Grimes Aerospace
80-0591-13	Central Annunciator Panel	Grimes Aerospace
80-0591-15	Central Annunciator Panel	Grimes Aerospace
80-0591-17	Central Annunciator Panel	Grimes Aerospace
80-0591-19	Central Annunciator Panel	Grimes Aerospace
80-0591-21	Central Annunciator Panel	Grimes Aerospace
80-0591-23	Central Annunciator Panel	Grimes Aerospace
80-0591-3	Central Annunciator Panel	Grimes Aerospace
80-0591-5	Central Annunciator Panel	Grimes Aerospace
80-0591-7	Central Annunciator Panel	Grimes Aerospace
80-0591-9	Central Annunciator Panel	Grimes Aerospace

Repair_Capability_List_Excel

80-0611-3	Standby Annunciator Panel	Grimes Aerospace
80-0611-5	Standby Annunciator Panel	Grimes Aerospace
80-0611-7	Standby Annunciator Panel	Grimes Aerospace
80-0611-9	Standby Annunciator Panel	Grimes Aerospace
80-0622-1	Indicator Light Warning Control Unit	Grimes Aerospace
80-0622-3	Indicator Light Warning Control Unit	Grimes Aerospace
800700	Control Cable Tension Regulator	Sarma
800700-B	Regulator	Sarma
800900	Control Cable Tension Regulator	Sarma
800953-1	IGV Actuator	Hamilton Sundstrand
800ZN01	Two Poles Sensitive Relay	ECE
801-1202	Drive Shaft assy	Goodrich Control Systems
801-1501	Drive Shaft assy	Goodrich Control Systems
801240-1	Vaneaxial Fan	Honeywell
801240-2	Vaneaxial Fan	Honeywell
801240-3	Vaneaxial Fan	Honeywell
801240-4	Vaneaxial Fan	Honeywell
801673	Compressor Bleed Valve	Pratt & Whitney
801677	Compressor Bleed Valve	Pratt & Whitney
801A0200-01	Shaft Assembly	Goodrich Control Systems
801A0300-01	Shaft Assembly	Goodrich Control Systems
801A0800-01	Shaft Assembly	Goodrich Control Systems
801A1500-01	Shaft ay Flap Drive	Goodrich Control Systems
801A2200-01	Shaft Assembly	Goodrich Control Systems
801A2400-01	Shaft Assembly	Goodrich Control Systems
801A3000-01	Shaft Assembly	Goodrich Control Systems
801A3100-01	Universal Joint	Goodrich Control Systems
801A3300-01	Universal Joint	Goodrich Control Systems
801A3400-01	Universal Joint	Goodrich Control Systems
801A3500-01	Plunging Joint	Goodrich Control Systems
801A3600-01	Shaft Assembly	Goodrich Control Systems
801A4000-01	Torsion Shaft assy	Goodrich Control Systems
801A4500-01	Universal Joint	Liebherr Aerotechnik
801B0400-01	Shaft Assembly	Goodrich Control Systems
801B0500-01	Shaft ay Flap Drive	Goodrich Control Systems
801B0600-01	Shaft Assembly	Goodrich Control Systems
801B0700-01	Shaft Assembly	Liebherr Aerotechnik
801B1200-01	Shaft Assembly	Goodrich Control Systems
801B1300-01	Shaft Assembly	Goodrich Control Systems
801B1400-01	Shaft Assembly	Goodrich Control Systems
801B1600-01	Shaft Assembly	Goodrich Control Systems
801B1700-01	Steady Bearing	Goodrich Control Systems
801B1900-01	Steady Bearing	Goodrich Control Systems
801B2100-01	Shaft Assembly	Goodrich Control Systems
801B2300-01	Shaft Assembly	Goodrich Control Systems
801B2700-01	Shaft Assembly	Goodrich Control Systems
801B2800-01	Shaft Assembly	Goodrich Control Systems
801B2900-01	Shaft Assembly	Goodrich Control Systems
801B3400-01	Shaft Assembly	Goodrich Control Systems
801B4200-02	Shaft Assembly	Goodrich Control Systems
801B4300-01	Shaft Assembly	Goodrich Control Systems
801B4400-01	Shaft Assembly	Goodrich Control Systems
801B4500-01	Universal Joint	Goodrich Control Systems
801B4600-01	Shaft ay Flap Drive	Goodrich Control Systems
801B4600-02	Shaft ay Flap Drive	Goodrich Control Systems
801B4700-01	Shaft Assembly	Goodrich Control Systems
801B4800-01	Shaft Assembly	Goodrich Control Systems
801B4900-01	Shaft Assembly	Goodrich Control Systems

Repair_Capability_List_Excel

801B5000-01	Shaft Assembly	Goodrich Control Systems
801B5100-01	Shaft Assembly	Goodrich Control Systems
801C1700-01	Steady Bearing	Goodrich Control Systems
801C1700-02	Steady Bearing	Goodrich Control Systems
801C1900-01	Steady Bearing	Goodrich Control Systems
801C1900-02	Steady Bearing	Goodrich Control Systems
802148	High Stage Bleed Valve	Hamilton Sundstrand
802157	High Pressure Shut-off Valve	Hamilton Sundstrand
802170	High Pressure Shut-off Valve	Hamilton Sundstrand
802170-1	High Pressure Shut-off Valve	Hamilton Sundstrand
802170-10	High Pressure Shut-off Valve	Hamilton Sundstrand
802170-11	High Pressure Shut-off Valve	Hamilton Sundstrand
802170-12	High Pressure Shut-off Valve	Hamilton Sundstrand
802170-2	High Pressure Shut-off Valve	Hamilton Sundstrand
802170-3	High Pressure Shut-off Valve	Hamilton Sundstrand
802170-4	High Pressure Shut-off Valve	Hamilton Sundstrand
802170-5	High Pressure Shut-off Valve	Hamilton Sundstrand
802170-6	High Pressure Shut-off Valve	Hamilton Sundstrand
802170-7	High Pressure Shut-off Valve	Hamilton Sundstrand
802170-8	High Pressure Shut-off Valve	Hamilton Sundstrand
802170-9	High Pressure Shut-off Valve	Hamilton Sundstrand
802837	Temperature Controller	Hamilton Sundstrand
804401	Air Supply Module	Hamilton Sundstrand
804401-2-005	Air Supply Module	Hamilton Sundstrand
804D100-3	Cargo Door Power Drive Unit	Eaton Aerospace
806170	Differential Pressure Switch	Hamilton Sundstrand
806177	Dual Heat Exchanger	Hamilton Sundstrand
806180-3	Condenser/Mixer Heat Exchanger	Hamilton Sundstrand
806180-4	Condenser/Mixer Heat Exchanger	Hamilton Sundstrand
806181	Bleed Shut-Off Valve	Hamilton Sundstrand
806181-1	Bleed Shut-Off Valve	Hamilton Sundstrand
806224-1	Fan Housing	Hamilton Sundstrand
806309	Bleed Crossover Valve	Hamilton Sundstrand
806346	Bleed Shut-Off Valve	Hamilton Sundstrand
806346-1	Bleed Shut-Off Valve	Hamilton Sundstrand
806349-5	Water Collector	Hamilton Sundstrand
806349-6	Water Collector	Hamilton Sundstrand
806373	Water Collector	Hamilton Sundstrand
806808	Stator Vane Actuator	Hamilton Sundstrand
806808-1	Stator Vane Actuator	Hamilton Sundstrand
806808-2	Stator Vane Actuator	Hamilton Sundstrand
806808-3	Stator Vane Actuator	Hamilton Sundstrand
806D100-1	Cargo Door Power Drive Unit	Eaton Aerospace
807962-401	Airstair Actuator	Monogram Systems
807962-403	Airstair Actuator	Monogram Systems
808000-601	Airstair assy	Monogram Systems
808000-602	Airstair assy	Monogram Systems
808000-603	Airstair assy	Monogram Systems
808000-604	Airstair assy	Monogram Systems
808000-605	Airstair assy	Monogram Systems
808000-606	Airstair assy	Monogram Systems
808000-607	Airstair assy	Monogram Systems
808000-608	Airstair assy	Monogram Systems
808000-609	Airstair assy	Monogram Systems
808000-610	Airstair assy	Monogram Systems
808000-611	Airstair assy	Monogram Systems
8084010F	Water Valve	FR Hitemp
8084012D	Water Valve	FR Hitemp

Repair_Capability_List_Excel

8084013F	Water Valve	FR Hitemp
8084015F	Water Valve	FR Hitemp
8084017C	Water Valve	FR Hitemp
8084018D	Water Valve	FR Hitemp
8084019D	Water Valve	FR Hitemp
8084020C	Water Valve	FR Hitemp
8084020D	Shut-Off Valve	FR Hitemp
8084021C	Water Valve	FR Hitemp
8084022C	Water Valve	FR Hitemp
8084023D	Water Valve	FR Hitemp
8084024D	Water Valve	FR Hitemp
8084032C	Water Valve	FR Hitemp
8084036H	Water Valve	FR Hitemp
8084037F	Water Valve	FR Hitemp
8084038F	Water Valve	FR Hitemp
8084040H	Water Valve	FR Hitemp
8084044H	Water Valve	FR Hitemp
8084240H	Water Valve	FR Hitemp
8084245H	Water Valve	FR Hitemp
8084246H	Water Valve	FR Hitemp
808440	Dual By-Pass Valve	Hamilton Sundstrand
808445-1	Overtemperature Switch	Hamilton Sundstrand
808550	Flow Regulator	Hamilton Sundstrand
808556	Intermediate Pressure Check Valve	Hamilton Sundstrand
808556-1	Intermediate Pressure Check Valve	Hamilton Sundstrand
808726	Bleed Actuator	Hamilton Sundstrand
808726-1	Bleed Actuator	Hamilton Sundstrand
808726-2	Bleed Actuator	Hamilton Sundstrand
808990	Restrictor By-pass Valve	Goodrich Control Systems
8095259-4017	VHF Comm Control Panel	Chelton
8095261-4209	TPR Control Panel	Chelton
8095261-4210	TPR Control Display	Chelton
8095262-4317	ADF Control Panel	Chelton
8095263-4401	DME Control Panel	Chelton
8095263-4402	DME Control Panel	Chelton
8095263-4403	DME Control Panel	Chelton
8095263-4404	DME Control Panel	Chelton
8095263-4405	DME Control Panel	Chelton
8095444-4101	VHF Navigation Control Panel	Chelton
8095477-1001	EFIS Control Panel	Chelton
8095477-1002	EFIS Control Panel	Chelton
8095477-1003	EFIS Control Panel	Chelton
8095477-1004	EFIS Control Panel	Chelton
809581-1	Zone Trim Actuator	Hamilton Sundstrand
809581-2	Zone Trim Actuator	Hamilton Sundstrand
809581-3	Zone Trim Actuator	Hamilton Sundstrand
809581-4	Zone Trim Actuator	Hamilton Sundstrand
809984-2	Signal Data Trans	Honeywell
81000-39	Brake Temp. Transmitter	Lewis Engineering
81000-40	Brake Temp. Transmitter	Lewis Engineering
81001A020100	Regulation & Safety Valve	Liebherr Aerospace
8101-01-4000-1	Oven Control assy	Sell Aviation Division
8101-22-000B	Oven Control assy	Sell Aviation Division
810164	Indicating Unit	Gravure Mecanique
810211	THMS Temperature Sensor	Hamilton Sundstrand
810211-2	THMS Temperature Sensor	Hamilton Sundstrand
810218	THMS Temperature Sensor	Hamilton Sundstrand
810218-2	THMS Temperature Sensor	Hamilton Sundstrand

Repair_Capability_List_Excel

810220	THMS Temperature Sensor	Hamilton Sundstrand
810220-2	THMS Temperature Sensor	Hamilton Sundstrand
810221	Zone Trim Valve	Hamilton Sundstrand
810221-1	Zone Trim Valve	Hamilton Sundstrand
810221-2	Zone Trim Valve	Hamilton Sundstrand
810223	THMS Temperature Sensor	Hamilton Sundstrand
810223-2	THMS Temperature Sensor	Hamilton Sundstrand
810223-3	THMS Temperature Sensor	Hamilton Sundstrand
810234	Temperature Sensor	Hamilton Sundstrand
810234-1	Temperature Sensor	Hamilton Sundstrand
810234-2	Temperature Sensor	Hamilton Sundstrand
810234-3	Temperature Sensor	Hamilton Sundstrand
8107-110-00-10	Oil Pressure Transmitter	Thales Avionics
810A0000-03	Rudder Servocontrol	Liebherr Aerotechnik
810A0000-03 Amdt. A	Rudder Servocontrol	Liebherr Aerotechnik
810A0000-03 Amdt. B	Rudder Servocontrol	Liebherr Aerotechnik
810A0000-04	Rudder Servocontrol	Liebherr Aerotechnik
810A0000-04 Amdt. A	Rudder Servocontrol	Liebherr Aerotechnik
810A0000-05	Rudder Servocontrol	Liebherr Aerotechnik
810ZN01	Overheat Detection Unit	ECE
811369-1616A	Pilot & Copilot Seats	EADS Sogerma
811369-1616B	Pilot & Copilot Seats	EADS Sogerma
811370-1612A	Pilot & Copilot Seats	EADS Sogerma
811370-1612B	Pilot & Copilot Seats	EADS Sogerma
811390-1	Engine Starter Valve	Hamilton Sundstrand
811390-2	Engine Starter Valve	Hamilton Sundstrand
811390-3	Engine Starter Valve	Hamilton Sundstrand
811CA01	Contactora	ECE
813500-401	Actuator	Monogram Systems
813500-409	Actuator	Monogram Systems
813500-411	Actuator	Monogram Systems
813500-413	Actuator	Monogram Systems
813500-415	Actuator	Monogram Systems
813500-417	Actuator	Monogram Systems
813520-1	FMU By-pass Valve	Hamilton Sundstrand
8136	Vaneaxial Fan assy	Hamilton Sundstrand
8136-1	Vaneaxial Fan assy	Hamilton Sundstrand
8136-2	Vaneaxial Fan assy	Hamilton Sundstrand
8136-3	Vaneaxial Fan assy	Hamilton Sundstrand
8136-4	Vaneaxial Fan assy	Hamilton Sundstrand
814890	Bleed Actuator	Hamilton Sundstrand
814890-1	Bleed Actuator	Hamilton Sundstrand
814890-2	Bleed Actuator	Hamilton Sundstrand
815136-401	Switch	Weber Aircraft
815163	Condenser/Mixer Heat Exchanger	Hamilton Sundstrand
815289	Temperature Sensor	Hamilton Sundstrand
815291	Temperature Switch	Hamilton Sundstrand
815950	Air Supply Precooler	Hamilton Sundstrand
816086	Flight Deck Humidifier	Hamilton Sundstrand
816086-1	Flight Deck Humidifier	Hamilton Sundstrand
816086-2	Flight Deck Humidifier	Hamilton Sundstrand
816086-3	Flight Deck Humidifier	Hamilton Sundstrand
816101-2	Temperature Controller	Hamilton Sundstrand
816101-4	Temperature Controller	Hamilton Sundstrand
816172	Compressor Outlet Temp. Sensor	Hamilton Sundstrand
816172-1	Compressor Outlet Temp. Sensor	Hamilton Sundstrand
816601	High Stage Bleed Valve	Hamilton Sundstrand
816601-1	High Stage Bleed Valve	Hamilton Sundstrand

Repair_Capability_List_Excel

816603-1	Engine Bleed & APU Check Valve	Hamilton Sundstrand
816603-2	Engine Bleed & APU Check Valve	Hamilton Sundstrand
816603-3	Engine Bleed & APU Check Valve	Hamilton Sundstrand
816604-1	Pressure Reg. & Shut-Off Valve	Hamilton Sundstrand
816604-2	Pressure Reg. & Shut-Off Valve	Hamilton Sundstrand
816604-3	Pressure Reg. & Shut-Off Valve	Hamilton Sundstrand
816605-1	Ground Check Valve	Hamilton Sundstrand
816605-2	Ground Check Valve	Hamilton Sundstrand
816606	Bleed Crossover Valve	Hamilton Sundstrand
816606-1	Bleed Cross-Over Valve	Hamilton Sundstrand
816607	Bleed Shut-Off Valve	Hamilton Sundstrand
816607-1	Bleed Shut-Off Valve	Hamilton Sundstrand
816610-1	Precooler Fan Air Valve	Hamilton Sundstrand
816610-2	Precooler Fan Air Valve	Hamilton Sundstrand
816624	Precooler Sensor	Hamilton Sundstrand
816624-1	Precooler Sensor	Hamilton Sundstrand
816624-10	Precooler Sensor	Hamilton Sundstrand
816624-2	Precooler Sensor	Hamilton Sundstrand
816624-3	Precooler Sensor	Hamilton Sundstrand
816624-4	Precooler Sensor	Hamilton Sundstrand
816624-5	Precooler Sensor	Hamilton Sundstrand
816624-6	Precooler Sensor	Hamilton Sundstrand
816624-7	Precooler Sensor	Hamilton Sundstrand
816624-8	Precooler Sensor	Hamilton Sundstrand
816624-9	Precooler Sensor	Hamilton Sundstrand
816630	Dual Heat Exchanger	Hamilton Sundstrand
816630-1	Dual Heat Exchanger	Hamilton Sundstrand
816630-2	Dual Heat Exchanger	Hamilton Sundstrand
816650	Condenser and Mixer	Hamilton Sundstrand
816656	Temperature Mix Sensor	Hamilton Sundstrand
816656-3	Temperature Mix Sensor	Hamilton Sundstrand
8168	Actuator	Aviac
8168-1	Actuator	Aviac
818476	Permanent Magnet Alternator	Hamilton Sundstrand
818490	Fuel Distribution Valve	Hamilton Sundstrand
818818-1	Water Separator	Hamilton Sundstrand
818818-2	Water Separator	Hamilton Sundstrand
8191	Detector assy	Meggitt Avionics
8191-01	Detector assy	Meggitt Avionics
8193	Detector assy	Meggitt Avionics
8193-01	Detector assy	Meggitt Avionics
8194	Detector assy	Meggitt Avionics
819802	Stator Vane Actuator	Hamilton Sundstrand
819802-1	Stator Vane Actuator	Hamilton Sundstrand
819802-2	AOA SENSOR	TELEDYNE
820902	Flow Control & Shut-Off Valve	Hamilton Sundstrand
820902-2	Flow Control & Shut-Off Valve	Hamilton Sundstrand
820902-3	Flow Control & Shut-Off Valve	Hamilton Sundstrand
820905	Heat Exchanger	Hamilton Sundstrand
820905-1	Heat Exchanger	Hamilton Sundstrand
820907	Overtemperature Switch	Hamilton Sundstrand
820907-1	Overtemperature Switch	Hamilton Sundstrand
820907-2	Overtemperature Switch	Hamilton Sundstrand
820907-3	Overtemperature Switch	Hamilton Sundstrand
820907-4	Overtemperature Switch	Hamilton Sundstrand
820907-5	Overtemperature Switch	Hamilton Sundstrand
820908-2	Overtemperature Switch	Hamilton Sundstrand
820909	Fan Inlet Diffuser Housing	Hamilton Sundstrand

Repair_Capability_List_Excel

820909-1	Fan Inlet Diffuser Housing	Hamilton Sundstrand
820912	Condensing Heat Exchanger	Hamilton Sundstrand
820912-3	Condensing Heat Exchanger	Hamilton Sundstrand
820914	Pack By-Pass Valve	Hamilton Sundstrand
820914-2	Pack By-Pass Valve	Hamilton Sundstrand
820914-3	Pack By-Pass Valve	Hamilton Sundstrand
820925	Turbine Shut-Off Valve	Hamilton Sundstrand
820925-1	Turbine Shut-Off Valve	Hamilton Sundstrand
820926-2	Check Valve	Hamilton Sundstrand
820927-2	Check Valve	Hamilton Sundstrand
820934-2	Check Valve	Hamilton Sundstrand
820939-1	Distribution Damper Valve	Hamilton Sundstrand
820939-2	Distribution Damper Valve	Hamilton Sundstrand
820948-2	Check Valve	Hamilton Sundstrand
820950	Water Collector	Hamilton Sundstrand
820950-2	Water Collector	Hamilton Sundstrand
820960	Temperature Sensor	Hamilton Sundstrand
820960-1	Temperature Sensor	Hamilton Sundstrand
820961-1	Temperature Sensor	Hamilton Sundstrand
820962	Dual Thermistor Temp. Sensor	Hamilton Sundstrand
820964	Pressure Sensor	Hamilton Sundstrand
820964-1	Pressure Sensor	Hamilton Sundstrand
820965	Differential Pressure Sensor	Hamilton Sundstrand
820965-1	Differential Pressure Sensor	Hamilton Sundstrand
820965-5	Differential Pressure Sensor	Hamilton Sundstrand
820966-1	Solenoid Shut-Off Valve	Hamilton Sundstrand
820966-2	Solenoid Shut-Off Valve	Hamilton Sundstrand
820966-3	Solenoid Shut-Off Valve	Hamilton Sundstrand
820967	Check Valve	Hamilton Sundstrand
820967-1	Check Valve	Hamilton Sundstrand
820971	Regulating & Shut-Off Valve	Hamilton Sundstrand
820971-2	Regulating & Shut-Off Valve	Hamilton Sundstrand
820972	Precooler Heat Exchanger	Hamilton Sundstrand
820972-2	Precooler Heat Exchanger	Hamilton Sundstrand
820973	Pressure Switch	Hamilton Sundstrand
820973-1	Pressure Switch	Hamilton Sundstrand
820973-2	Pressure Switch	Hamilton Sundstrand
820983	Shut-Off Valve	Hamilton Sundstrand
820983-1	Shut-Off Valve	Hamilton Sundstrand
820CE02Y00	Contactors	ECE
820CE02Y01	Contactors	ECE
821097-2	Actuator	Hamilton Sundstrand
821097-3	Actuator	Hamilton Sundstrand
821097-4	Actuator	Hamilton Sundstrand
821195	Torque Motor Servo Valve	Hamilton Sundstrand
821195-1	Torque Motor Servo Valve	Hamilton Sundstrand
821195-2	Torque Motor Servo Valve	Hamilton Sundstrand
821195-3	Torque Motor Servo Valve	Hamilton Sundstrand
821195-4	Torque Motor Servo Valve	Hamilton Sundstrand
821195-5	Torque Motor Servo Valve	Hamilton Sundstrand
821195-6	Torque Motor Servo Valve	Hamilton Sundstrand
821195-7	Torque Motor Servo Valve	Hamilton Sundstrand
821195-8	Torque Motor Servo Valve	Hamilton Sundstrand
821195-9	Torque Motor Servo Valve	Hamilton Sundstrand
821252	Dump Valve	Hamilton Sundstrand
821253	Pressure Sensor	Hamilton Sundstrand
821253-1	Pressure Sensor	Hamilton Sundstrand
821254	Control Valve	Hamilton Sundstrand

Repair_Capability_List_Excel

821255	Check Relief Valve	Hamilton Sundstrand
821337-1	Check Valve	Hamilton Sundstrand
822-0052-001	Altimeter Select Panel	Rockwell Collins
82200A0101	Landing Altitude Selector	Liebherr Aerospace
822-0282-002	ILS Receiver	Rockwell Collins
822-0282-102	ILS Receiver	Rockwell-Collins
822-0282-120	ILS Receiver	Rockwell-Collins
822-0693-001	VHF Comm Transceiver	Rockwell Collins
822-0693-002	VHF Comm Transceiver	Rockwell Collins
822-0693-003	VHF Comm Transceiver	Rockwell Collins
822-0693-004	VHF Communications Transceiver	Rockwell-Collins
822-0693-005	VHF Communications Transceiver	Rockwell-Collins
822-0693-120	VHF Communications Transceiver	Rockwell-Collins
822-0726-002	VOR / MB Navigation Receiver	Rockwell-Collins
822-0726-020	VOR / MB Navigation Receiver	Rockwell-Collins
822-0726-103	VOR / MB Navigation Receiver	Rockwell-Collins
822-0726-120	VOR / MB Navigation Receiver	Rockwell-Collins
822-0731-001	VHF Comm Transceiver	Rockwell Collins
822-0731-002	VHF Comm Transceiver	Rockwell Collins
822-0731-003	VHF Comm Transceiver	Rockwell Collins
822-0731-004	VHF Comm Transceiver	Rockwell Collins
822-0731-005	VHF Comm Transceiver	Rockwell Collins
822-0731-006	VHF Comm Transceiver	Rockwell Collins
822-0731-008	VHF Comm Transceiver	Rockwell Collins
822-0731-009	VHF Comm Transceiver	Rockwell Collins
822-0731-010	VHF Comm Transceiver	Rockwell Collins
822-0731-011	VHF Comm Transceiver	Rockwell Collins
822-0732-001	VHF Comm Transceiver	Rockwell Collins
822-0732-002	VHF Comm Transceiver	Rockwell Collins
822-0732-003	VHF Comm Transceiver	Rockwell Collins
822-0732-010	VHF Comm Transceiver	Rockwell Collins
822-0732-011	VHF Comm Transceiver	Rockwell Collins
822-0732-101	VHF Comm Transceiver	Rockwell Collins
822-0732-102	VHF Comm Transceiver	Rockwell Collins
822-0732-103	VHF Comm Transceiver	Rockwell Collins
822-0732-110	VHF Comm Transceiver	Rockwell Collins
822-0732-111	VHF Comm Transceiver	Rockwell Collins
822-0732-203	VHF Comm Transceiver	Rockwell Collins
822-0732-205	VHF Comm Transceiver	Rockwell Collins
822-0732-206	VHF Comm Transceiver	Rockwell Collins
822-0732-208	VHF Comm Transceiver	Rockwell Collins
822-0732-209	VHF Comm Transceiver	Rockwell Collins
822-0732-210	VHF Comm Transceiver	Rockwell Collins
822-0760-001	VHF Navigation Receiver	Rockwell Collins
822-0760-002	VHF Navigation Receiver	Rockwell Collins
822-0760-003	VHF Navigation Receiver	Rockwell Collins
822-0760-004	VHF Navigation Receiver	Rockwell Collins
822-0760-005	VHF Navigation Receiver	Rockwell Collins
822-0760-006	VHF Navigation Receiver	Rockwell Collins
822-0760-007	VHF Navigation Receiver	Rockwell Collins
822-0760-008	VHF Navigation Receiver	Rockwell Collins
822-0760-009	VHF Navigation Receiver	Rockwell Collins
822-0761-001	VOR/ILS Receiver	Rockwell
822-0761-002	VHF Navigation Receiver	Rockwell Collins
822-0761-003	VHF Navigation Receiver	Rockwell Collins
822-0761-004	VHF Navigation Receiver	Rockwell Collins
822-0761-005	VHF Navigation Receiver	Rockwell Collins
822-0761-006	VHF Navigation Receiver	Rockwell Collins

Repair_Capability_List_Excel

822-0761-007	VHF Navigation Receiver	Rockwell Collins
822-0761-008	VHF Navigation Receiver	Rockwell Collins
822-0761-009	VHF Navigation Receiver	Rockwell Collins
822-0761-010	VHF Navigation Receiver	Rockwell Collins
822-0761-011	VHF Navigation Receiver	Rockwell Collins
822-0761-012	VHF Navigation Receiver	Rockwell Collins
822-0761-013	VHF Navigation Receiver	Rockwell Collins
822-0762-001	VHF Navigation Receiver	Rockwell Collins
822-0762-002	VHF Navigation Receiver	Rockwell Collins
822-0762-003	VHF Navigation Receiver	Rockwell Collins
822-0762-004	VHF Navigation Receiver	Rockwell Collins
822-0762-005	VHF Navigation Receiver	Rockwell Collins
822-1044-003	VHF Comm Transceiver	Rockwell Collins
822-1044-004	VHF Communications Transceiver	Rockwell-Collins
822-1044-005	VHF Comm Transceiver	Rockwell Collins
822-1044-120	VHF Communications Transceiver	Rockwell-Collins
822-1045-001	VHF Comm Transceiver	Rockwell Collins
822-1045-003	VHF Comm Transceiver	Rockwell Collins
822-1045-004	VHF Comm Transceiver	Rockwell Collins
822-1045-005	VHF Comm Transceiver	Rockwell Collins
822-1045-006	VHF Comm Transceiver	Rockwell Collins
822-1045-008	VHF Comm Transceiver	Rockwell Collins
822-1045-009	VHF Comm Transceiver	Rockwell Collins
822-1045-301	VHF Comm Transceiver	Rockwell Collins
822-1045-303	VHF Comm Transceiver	Rockwell Collins
822-1045-311	VHF Comm Transceiver	Rockwell Collins
822-1045-401	VHF Comm Transceiver	Rockwell Collins
822-1045-403	VHF Comm Transceiver	Rockwell Collins
822-1045-411	VHF Comm Transceiver	Rockwell Collins
822-1045-503	VHF Comm Transceiver	Rockwell Collins
822-1045-505	VHF Comm Transceiver	Rockwell Collins
822-1045-506	VHF Comm Transceiver	Rockwell Collins
822-1045-508	VHF Comm Transceiver	Rockwell Collins
822-1045-509	VHF Comm Transceiver	Rockwell Collins
822-1046-001	VHF Comm Transceiver	Rockwell Collins
822-1046-003	VHF Comm Transceiver	Rockwell Collins
822-1046-011	VHF Comm Transceiver	Rockwell Collins
822-1046-101	VHF Comm Transceiver	Rockwell Collins
822-1046-103	VHF Comm Transceiver	Rockwell Collins
822-1046-111	VHF Comm Transceiver	Rockwell Collins
822-1046-203	VHF Comm Transceiver	Rockwell Collins
822-1046-205	VHF Comm Transceiver	Rockwell Collins
822-1046-206	VHF Comm Transceiver	Rockwell Collins
822-1046-208	VHF Comm Transceiver	Rockwell Collins
822-1046-209	VHF Comm Transceiver	Rockwell Collins
822-1047-002	VHF Communications Transceiver	Rockwell-Collins
822-1047-003	VHF Communications Transceiver	Rockwell-Collins
822-1047-010	VHF Communications Transceiver	Rockwell-Collins
822-1047-020	VHF Communications Transceiver	Rockwell-Collins
822-1047-030	VHF Communications Transceiver	Rockwell-Collins
822-1047-220	VHF Communications Transceiver	Rockwell-Collins
822500-15	Motor	Vickers
8225C0001-01	Motor	Vickers
8225C0001-03	Motor	Vickers
8236-3	Trim Actuator	Aviac
823742	Bleed Actuator	Hamilton Sundstrand
823742-1	Bleed Actuator	Hamilton Sundstrand
8243	Detector assy	Meggitt Avionics

Repair_Capability_List_Excel

8244	Detector assy	Meggitt Avionics
825204	Flow Control & Shut-off Valve	Hamilton Sundstrand
825204-1	Flow Control & Shut-Off Valve	Hamilton Sundstrand
825207	Fan Inlet Diffuser Housing	Hamilton Sundstrand
825207-1	Fan Inlet Diffuser Housing	Hamilton Sundstrand
825208	Dual Heat Exchanger	Hamilton Sundstrand
825208-1	Dual Heat Exchanger	Hamilton Sundstrand
825210	Condenser/ReHeater Heat Exchanger	Hamilton Sundstrand
825212	Water Collector	Hamilton Sundstrand
825212-1	Water Collector	Hamilton Sundstrand
825212-2	Water Collector	Hamilton Sundstrand
825214	Turbine By-pass Valve	Hamilton Sundstrand
825214-1	Turbine By-Pass Valve	Hamilton Sundstrand
825215	Economy Cooling Valve	Hamilton Sundstrand
825228	Trim Air Pressure Sensor	Hamilton Sundstrand
825230	Flow Sensing Venturi	Hamilton Sundstrand
825230-1	Flow Sensing Venturi	Hamilton Sundstrand
825235	Temperature Sensor	Hamilton Sundstrand
825301	High Pressure Shut-off Valve	Hamilton Sundstrand
825301-1	High Pressure Shut-off Valve	Hamilton Sundstrand
825303	Pressure Regulating & Shut-off Valve	Hamilton Sundstrand
825305	Fan Air Modulating Valve	Hamilton Sundstrand
825305-1	Fan Air Modulating Valve	Hamilton Sundstrand
825305-2	Fan Air Modulating Valve	Hamilton Sundstrand
825307	Air Supply Control & Test Unit	Hamilton Sundstrand
825307-1-001	Air Supply Control & Test Unit	Hamilton Sundstrand
825308	Temperature Sensor	Hamilton Sundstrand
825310	PRV Controller	Hamilton Sundstrand
825312	Pressure Sensor	Hamilton Sundstrand
825314	Controller Air Cooler	Hamilton Sundstrand
825501-10	Engine Main Fuel Pump	Argo-Tech
825501-11	Engine Main Fuel Pump	Argo-Tech
825501-12	Engine Main Fuel Pump	Argo-Tech
825501-8	Engine Main Fuel Pump	Argo-Tech
825501-9	Engine Main Fuel Pump	Argo-Tech
825CE02Y00	External Power Monitor	ECE
825CE02Y01	External Power Monitor	ECE
827	Meters	Weston Aerospace
8276M1	AC Motor	CEF Industries
827A0000-01	Tee Gearbox	Goodrich Control Systems
827A0000-02	Tee Gearbox	Goodrich Control Systems
828A0000-01	Bevel Gearbox	Goodrich Control Systems
828A0000-02	Bevel Gearbox	Goodrich Control Systems
8294	Electrical Linear Actuator	Aviac
8294-1	Electrical Linear Actuator	Aviac
829A0000-01	Actuator Rotary Slat	Liebherr Aerotechnik
829A0000-02	Actuator Rotary Slat	Liebherr Aerotechnik
829A0000-03	Actuator Rotary Slat	Liebherr Aerotechnik
829B0000-01	Actuator Rotary Slat	Liebherr Aerotechnik
83001B0100	Position Indicator	Liebherr Aerospace
83001B0100-01	Position Indicator	Liebherr Aerospace
83001B0100-02	Position Indicator	Liebherr Aerospace
83002B0101	Safety Valve Position Indicator	Liebherr Aerospace
83002C0102	Valve Position Indicator	Liebherr Aerospace
830901-1	Lube & Scavenge Pump	Argo-Tech
830A0000-01	Actuator Rotary Slat	Liebherr Aerotechnik
830A0000-02	Actuator Rotary Slat	Liebherr Aerotechnik
830A0000-03	Actuator Rotary Slat	Liebherr Aerotechnik

Repair_Capability_List_Excel

830A0000-04	Actuator Rotary Slat	Liebherr Aerotechnik
830CE02Y00	LH DC Power Center	ECE
830CE02Y01	LH DC Power Center	ECE
831	Volt/Amperemeter	Weston
8312-120-00-10	Temperature Sensor	Thales Avionics
8314-102-00-00	Temperature Sensor	Thales Avionics
8316-103-00-10	Fuel Temperature Transmitter	Thales Avionics
831-63-270	Self Sealing Coupling	Bronzavia-Air Equipement
831-6Y1	Volt/Amperemeter	Weston
831A0000-01	Brake Wing Tip	Liebherr Aerotechnik
831A0000-02	Brake Wing Tip	Liebherr Aerotechnik
831A0000-03	Brake Wing Tip	Liebherr Aerotechnik
831A0000-04	Brake Wing Tip	Liebherr Aerotechnik
831A0000-05	Brake Wing Tip	Liebherr Aerotechnik
831B0000-01	Brake Wing Tip	Liebherr Aerotechnik
833	Volt/Amp Meter	Weston Aerospace
833-0101	Drive Shaft assy	Goodrich Control Systems
833-0402	Drive Shaft assy	Goodrich Control Systems
833-13Y1	Voltmeter	Weston
833-2102	Drive Shaft assy	Goodrich Control Systems
833A0500-01	Shaft Assembly	Goodrich Control Systems
833A0600-01	Shaft Assembly	Goodrich Control Systems
833A0700-01	Shaft ay Slat Drive	Goodrich Control Systems
833A1400-01	Shaft Assembly	Goodrich Control Systems
833A1500-01	Shaft Assembly	Goodrich Control Systems
833A1600-01	Shaft ay Slat Drive	Goodrich Control Systems
833A1700-01	Shaft ay Slat Drive	Goodrich Control Systems
833A1800-01	Shaft ay Slat Drive	Goodrich Control Systems
833A1900-01	Shaft ay Slat Drive	Goodrich Control Systems
833A2000-01	Shaft ay Slat Drive	Goodrich Control Systems
833A2100-01	Shaft ay Slat Drive	Liebherr Aerotechnik
833A2200-01	Shaft Assembly	Goodrich Control Systems
833A2400-01	Shaft assy APPU	Goodrich Control Systems
833A2400-02	Shaft assy APPU	Liebherr Aerotechnik
833A2700-01	Shaft Assembly	Goodrich Control Systems
833A2800-01	Shaft Assembly	Goodrich Control Systems
833A3300-01	Shaft Assembly	Goodrich Control Systems
833A3400-01	Shaft Assembly	Goodrich Control Systems
833A3500-01	Shaft Assembly	Goodrich Control Systems
833A4200-01	Shaft Assembly	Goodrich Control Systems
833A4300-01	Shaft Assembly	Goodrich Control Systems
833A4400-01	Shaft Assembly	Goodrich Control Systems
833A4500-01	Shaft Assembly	Goodrich Control Systems
833A4600-01	Shaft Assembly	Goodrich Control Systems
833A4700-01	Shaft Assembly	Goodrich Control Systems
833A4800-01	Shaft Assembly	Goodrich Control Systems
833A5000-01	Shaft Assembly	Goodrich Control Systems
833A5100-01	Shaft Assembly	Goodrich Control Systems
833B0100-01	Shaft ay Slat Drive	Goodrich Control Systems
833B0200-01	Shaft ay Slat Drive	Goodrich Control Systems
833B0300-01	Shaft ay Slat Drive	Goodrich Control Systems
833B0400-01	Shaft Assembly	Goodrich Control Systems
833B0500-01	Shaft Assembly	Goodrich Control Systems
833B0800-01	Shaft Assembly	Goodrich Control Systems
833B0900-01	Shaft Assembly	Goodrich Control Systems
833B1000-01	Shaft Assembly	Goodrich Control Systems
833B1100-01	Shaft Assembly	Goodrich Control Systems
833B1200-01	Shaft Assembly	Goodrich Control Systems

Repair_Capability_List_Excel

833B1300-01	Shaft Assembly	Goodrich Control Systems
833B2200-01	Slat Drive Shaft	Goodrich Control Systems
833B2300-01	Steady Bearing	Goodrich Control Systems
833B3800-01	Shaft Assembly	Goodrich Control Systems
833B3900-01	Shaft Assembly	Goodrich Control Systems
833B4000-01	Shaft Assembly	Goodrich Control Systems
833B4100-01	Shaft Assembly	Goodrich Control Systems
833B5200-01	Steady Bearing	Goodrich Control Systems
833B5300-01	Shaft Assembly	Goodrich Control Systems
833B5400-01	Shaft Assembly	Goodrich Control Systems
833B5600-01	Shaft Assembly	Goodrich Control Systems
833B5700-01	Shaft Assembly	Goodrich Control Systems
833C0900-01	Shaft ay Slat Drive	Goodrich Control Systems
833C1200-01	Slat Drive Shaft	Goodrich Control Systems
833C1300-01	Slat Drive Shaft	Goodrich Control Systems
833C2300-01	Steady Bearing	Goodrich Control Systems
833C2300-02	Steady Bearing	Goodrich Control Systems
833C5200-01	Steady Bearing	Goodrich Control Systems
833C5200-02	Steady Bearing	Goodrich Control Systems
833T20Y1	Volt/Amperemeter	Weston
8-341-01	Pressure Sensor	Crane
8-344-02	Pressure Sensor	Crane
8-344-03	Pressure Sensor	Crane
8-345-01	Pressure Sensor	Crane
8-345-02	Pressure Sensor	Crane
8-345-03	Pressure Sensor	Crane
8-348-01	Pressure Sensor	Crane
8-348-02	Pressure Sensor	Crane
835CE02Y00	RH DC Power Center	ECE
835CE02Y01	RH DC Power Center	ECE
836SD6-20	Quantity Measuring Fuse	Waterman
8-371-01	Detector Proximity Box	Eldec Corp.
8-371-01A	Detector Proximity Box	Eldec Corp.
8-371-02	Detector Proximity Box	Eldec Corp.
8-372-01	Proximity Sensor	Eldec Corp.
8-372-02	Proximity Sensor	Eldec Corp.
837-7037-010	Switch	Rockwell-Collins
838-67	Prop Hub	Hartzell
838K-X-011	Pressure Manifold	Kollsman
838K-X-022	Pressure Manifold	Kollsman
840	Meters	Weston Aerospace
8400-025-00-11	Current Transformer	Thales Avionics
840780-01	Check Valve	Walter Kidde
840892-3000	Pneumatic Relief Valve	Walter Kidde
841	Meters	Weston Aerospace
84100A01	Manual Pressurization Relief Valve	Liebherr Aerospace
8410MK1	Fuel Pump	FR Hitemp
8410MK2	Fuel Pump	FR Hitemp
8411/1 MK 1	Canister	GEC-Marconi
8411/1 MK 2	Canister	GEC-Marconi
8411/2 MK 1	Canister	GEC-Marconi
8411/2 MK 2	Canister	GEC-Marconi
8420-018-003	Swing Check Valve	Fokker Aircraft
8420-018-005	Swing Check Valve	Fokker Aircraft
8420-034-801	Waste Drain Valve	Fokker Aircraft
8420-034-901	Waste Drain Valve	Fokker Aircraft
84354235	Remote Control Circuit Breaker	Thales Avionics
84354250	Remote Control Circuit Breaker	Thales Avionics

Repair_Capability_List_Excel

84354335	Remote Control Circuit Breaker	Thales Avionics
84354350	Remote Control Circuit Breaker	Thales Avionics
846D100-3	Horizontal Stabilizer Drive Unit	Eaton Aerospace
846D100-7	Horizontal Stabilizer Drive Unit	Eaton Aerospace
848137	Motor Pump assy	Vickers
848354	Hydraulic Pump	Vickers
8-484-01	Proximity Sensor	Eldec Corp.
848847	Variable Displacement Hyd. Motorpump	Vickers
8489-713-1	Horiz.Stab.Trim Actuator Motor	Thales Avionics
849377	Motor Pump assy	Vickers
849557	Hydraulic Motorpump assy	Eaton
849589	Variable Displacement Hyd. Pump	Vickers
8-497-02	Proximity Switch	Eldec Corp.
8-497-04	Proximity Switch	Crane
8500-341-403	Cable Tension Regulator	Teleflex
85-0446-1	Cargo Dome Light	Grimes Aerospace
85-0446-3	Cargo Dome Light	Grimes Aerospace
85-0446-7	Cargo Dome Light	Grimes Aerospace
85-0446-9	Cargo Dome Light	Grimes Aerospace
851CA01	Contactora	ECE
852D100-10	Inboard/Outboard Flap Actuator	Eaton Aerospace
852D100-11	Inboard/Outboard Flap Actuator	Eaton Aerospace
852D100-19	Inboard/Outboard Flap Actuator	Eaton Aerospace
852D100-9	Inboard/Outboard Flap Actuator	Eaton Aerospace
8535C000	Condenser and Mixer	Honeywell
853BR	Pitot Head	Rosemount
853D100-11	Inboard/Outboard Flap Actuator	Eaton Aerospace
853D100-12	Inboard/Outboard Flap Actuator	Eaton Aerospace
853D100-13	Inboard/Outboard Flap Actuator	Eaton Aerospace
853D100-14	Inboard/Outboard Flap Actuator	Eaton Aerospace
853D100-17	Inboard/Outboard Flap Actuator	Eaton Aerospace
853D100-19	Inboard/Outboard Flap Actuator	Eaton Aerospace
853D100-20	Inboard/Outboard Flap Actuator	Eaton Aerospace
853JB	Pitot Head	Rosemount
853KK	Pitot Head	Rosemount
85464-2	AC Generator	Pacific Scientific
85465-1	AC Generator	Pacific Scientific
85465-2	AC Generator	Pacific Scientific
854D100-11	Inboard/Outboard Flap Actuator	Eaton Aerospace
854D100-12	Inboard/Outboard Flap Actuator	Eaton Aerospace
854D100-19	Inboard/Outboard Flap Actuator	Eaton Aerospace
854D100-20	Inboard/Outboard Flap Actuator	Eaton Aerospace
8552C000	Fuel/Oil Heat Exchanger	Honeywell
85569-1	AC Generator	Pacific Scientific
85569-2	AC Generator	Pacific Scientific
85570-1	AC Generator	Pacific Scientific
855D100-11	Brake Position Sensor Unit	Eaton Aerospace
855D100-7	Brake Position Sensor Unit	Eaton Aerospace
855D100-9	Brake Position Sensor Unit	Eaton Aerospace
8560C000	Fuel/Oil Heat Exchanger	Honeywell
8571C000	Dual Heat Exchanger	Honeywell
8-582-01	Proximity Switching Unit	Eldec
8-582-02	Proximity Switching Unit	Eldec
86001A010101	Switch	Liebherr Aerospace
86001A010102	Switch	Liebherr Aerospace
861555	Hydraulic Pump	Vickers
861561	Stator	Vickers
861686	AC Driven Motorpump assy	Vickers

Repair_Capability_List_Excel

861CA01	Contactora	ECE
861CAE	AOA Sensor	Rosemount Aerospace
861CAE1	AOA Sensor	Rosemount Aerospace
861CAE1-0001	AOA Sensor	Rosemount Aerospace
861CAE1-0001A	AOA Sensor	Rosemount Aerospace
861CAH	AOA Sensor	Rosemount Aerospace
861CAS3	AOA Sensor	Rosemount Aerospace
862536	Variable Disp.Hydraulic Motorpump	Eaton
864-001	Icing Visual Indicator Lighthead	Madelec Aero
86500-109	Water Valve	LGG
865D100-7	Wing Flap System Power Drive	Eaton Aerospace
866157-1	TC Fixed Res Assy	Honeywell
866157-10	TC Fixed Res Assy	Honeywell
866157-11	TC Fixed Res Assy	Honeywell
866157-13	TC Fixed Res Assy	Honeywell
866157-14	TC Fixed Res Assy	Honeywell
866157-15	TC Fixed Res Assy	Honeywell
866157-3	TC Fixed Res Assy	Honeywell
866157-4	TC Fixed Res Assy	Honeywell
866157-5	TC Fixed Res Assy	Honeywell
866157-6	TC Fixed Res Assy	Honeywell
866157-7	TC Fixed Res Assy	Honeywell
866157-8	TC Fixed Res Assy	Honeywell
866157-9	TC Fixed Res Assy	Honeywell
8680-020	Air Pressure Reducer Valve	Parker Hannifin
8680-045-401	Sniffle Valve	Parker Hannifin
8680-045-403	Sniffle Valve	Parker Hannifin
86815-1	AC Generator	Pacific Scientific
8-689-01	Proximity Sensor	Messier-Bugatti
8-689-02	Proximity Sensor	Messier-Bugatti
8-695-01	Proximity Sensor	Eldec Corp.
8700	Pump	Micropump
87000-1105	Mechanical Aircraft Clock	Aerosonic
87000-1106	Mechanical Aircraft Clock	Aerosonic
87000-1116	Mechanical Aircraft Clock	Aerosonic
87000-1117	Mechanical Aircraft Clock	Aerosonic
87000-1120	Mechanical Aircraft Clock	Aerosonic
87006-1	AC Generator	Pacific Scientific
87006-2	AC Generator	Pacific Scientific
87006-3	AC Generator	Pacific Scientific
87006-4	AC Generator	Pacific Scientific
87006-5	AC Generator	Pacific Scientific
87006-9	AC Generator	Pacific Scientific
871DF1-1	Ice Detector	Rosemount
87232323V00	Duct Temperature Sensor	Thales Avionics
87232323V01	Duct Temperature Sensor	Thales Avionics
87232324V00	Skin Temperature Sensor	Thales Avionics
87500-1130	Mechanical Aircraft Clock	Aerosonic
87500-1132	Mechanical Aircraft Clock	Aerosonic
87500-1133	Mechanical Aircraft Clock	Aerosonic
87500-1134	Mechanical Aircraft Clock	Aerosonic
87500-1135	Mechanical Aircraft Clock	Aerosonic
87500-1136	Mechanical Aircraft Clock	Aerosonic
87500-1137	Mechanical Aircraft Clock	Aerosonic
87500-1138	Mechanical Aircraft Clock	Aerosonic
87500-1139	Mechanical Aircraft Clock	Aerosonic
87500-1140	Mechanical Aircraft Clock	Aerosonic
87500-1141	Mechanical Aircraft Clock	Aerosonic

Repair_Capability_List_Excel

87500-1142	Mechanical Aircraft Clock	Aerosonic
87500-1143	Mechanical Aircraft Clock	Aerosonic
87500-1144	Mechanical Aircraft Clock	Aerosonic
87500-1145	Mechanical Aircraft Clock	Aerosonic
87500-1146	Mechanical Aircraft Clock	Aerosonic
87500-2131	Mechanical Aircraft Clock	Aerosonic
879-2525-006	ATC Control Unit	Thales Avionics
879-2525-007	ATC Control Unit	Thales Avionics
879-2525-010	ATC Control Unit	Thales Avionics
879-2525-012	ATC Control Unit	Thales Avionics
879-2525-013	ATC Control Unit	Thales Avionics
879-2525-014	ATC Control Unit	Thales Avionics
879-2525-015	ATC Control Unit	Thales Avionics
879-2525-016	ATC Control Unit	Thales Avionics
879-2535-002	ATC Control Unit	Thales Avionics
88000-4102	Clock	Aerosonic
88000-4116	Clock	Aerosonic
88001B01	Safety Valve	Liebherr Aerospace
88002A02	Safety Valve	Liebherr Aerospace
88002B01	Safety Valve	Liebherr Aerospace
88002C01	Safety Valve	Liebherr Aerospace
88003A0101	Ground Venting Valve	Liebherr Aerospace
88003A0201	Ground Venting Valve	Liebherr Aerospace
88003B0101	Ground Venting Valve	Liebherr Aerospace
88003B0201	Ground Venting Valve	Liebherr Aerospace
88005A0101	Ground Venting Valve	Liebherr Aerospace
88005A0101 Index A	Ground Venting Valve	Liebherr Aerospace
88005A0101 Index B	Ground Venting Valve	Liebherr Aerospace
88005B0203	Pressure Valve	Liebherr Aerospace
88005B0204	Pressure Valve	Liebherr Aerospace
88005B0205	Pressure Valve	Liebherr Aerospace
88005B0206	Pressure Valve	Liebherr Aerospace
88005B0304	Pressure Valve	Liebherr Aerospace
88005B0305	Pressure Valve	Liebherr Aerospace
88005B0306	Pressure Valve	Liebherr Aerospace
881CA01	Contactora	ECE
8-852-01	Proximity Switch Unit	Crane
887030	Hydraulic Motorpump assy	Eaton
887031	Variable Disp.Hydraulic Motorpump	Eaton
887055	Variable Displacement Hyd. Pump	Vickers
887087	Constant Displacement Hydraulic Motor	Vickers
887111	Hydraulic Pump	Vickers
887173	Variable Disp.Electric Motorpump	Eaton
887476	Hydraulic Pump	Vickers
887477	AC Driven Motor Pump	Vickers
887479	AC Driven Motor Pump	Vickers
887480	AC Driven Motorpump	Vickers
887673	Hydraulic Pump	Vickers
889-2223-004	ILS Control Unit	Thales Avionics
889-2223-006	ILS Control Unit	Thales Avionics
889-2223-008	ILS Control Unit	Thales Avionics
889-2323-004	ILS Control Unit	Thales Avionics
889-2323-006	ILS Control Unit	Thales Avionics
889-2323-007	ILS Control Unit	Thales Avionics
889-2625-001	ADF Control Unit	Thales Avionics
889-2625-004	ADF Control Unit	Thales Avionics
8900207	Control Box	Nord-Micro
89-01-07000	Cockpit Handset	Holmberg

Repair_Capability_List_Excel

89-01-07072	Handset	Holmberg
8901-314	COMP SENSOR	GENERAL ELECTRIC
8903000-5	Non-Return Valve	FR Hitemp
890405-0030-01	Pressure Reducer Valve	Walter Kidde
890405-0030-02	Pressure Reducer Valve	Walter Kidde
890405-0030-03	Pressure Reducer Valve	Walter Kidde
890405-0035-01	Pressure Reducer Valve	Walter Kidde
890405-0035-02	Pressure Reducer Valve	Walter Kidde
890405-0035-03	Pressure Reducer Valve	Walter Kidde
890405-0070-01	Pressure Reducer Valve	Walter Kidde
890405-0070-02	Pressure Reducer Valve	Walter Kidde
890405-0070-03	Pressure Reducer Valve	Walter Kidde
890405-01	Pressure Reducer Valve	Walter Kidde
890405-0100	Pressure Reducer Valve	Walter Kidde
890405-0100-01	Pressure Reducer Valve	Walter Kidde
890405-0100-02	Pressure Reducer Valve	Walter Kidde
890405-0100-03	Pressure Reducer Valve	Walter Kidde
890405-02	Pressure Reducer Valve	Walter Kidde
890405-03	Pressure Reducer Valve	Walter Kidde
890406-0090	Pressure Reducer Valve	Walter Kidde
890406-0090-01	Pressure Reducer Valve	Walter Kidde
890406-0090-02	Pressure Reducer Valve	Walter Kidde
890406-0090-03	Pressure Reducer Valve	Walter Kidde
890406-01	Pressure Reducer Valve	Walter Kidde
890406-0100	Pressure Reducer Valve	Walter Kidde
890406-0100-01	Pressure Reducer Valve	Walter Kidde
890406-0100-02	Pressure Reducer Valve	Walter Kidde
890406-0100-03	Pressure Reducer Valve	Walter Kidde
890406-02	Pressure Reducer Valve	Walter Kidde
890406-03	Pressure Reducer Valve	Walter Kidde
890409	Pressure Reducing Valve	Walter Kidde
890409-1000	Pneumatic Pressure Reducing Valve	Walter Kidde
890409-1100	Pressure Reducing Valve	Walter Kidde
890411	Solenoid Valve	Walter Kidde
890411-01	Solenoid Valve	Walter Kidde
890411-02	Solenoid Valve	Walter Kidde
890412	Solenoid Valve	Walter Kidde
89056	Braking Roller	Goodrich Control Systems
891794	Valve assy	Valcor
8921270G2	Drain Mast assy	General Electric
892291-1	Oil Tank assy	Honeywell
8-930-03	Battery Charger	Crane
893364	Nose Wheel Steering Unit	Valcor
893410-0450	Fire Detection Control Unit	Kidde Technologies
893442	Motor Air	Valcor
893456	Control Dual Valve	Kidde Technologies
893627	High Pressure Relief Valve	Walter Kidde
893713	Fire Detection Unit	Kidde Technologies
893726	Control Dual Valve	Kidde Technologies
893726-01	Control Dual Valve	Kidde Technologies
893954	Steering Unit	Valcor
893966-01	Gearbox	Valcor
894481	Element Sensing	Kidde Aerospace
895866-2	Shut-Off Check Valve	Honeywell
898108-6-1	Shut-Off Valve	Honeywell
898108-7-1	Shut-Off Valve	Honeywell
898126-2-1	Pressure Regulator	Honeywell
898172-10-1	Pressure Regulator Valve	Honeywell

Repair_Capability_List_Excel

898172-1-1	Pressure Regulator Valve	Honeywell
898172-11-1	Pressure Regulator Valve	Honeywell
898172-12-1	Pressure Regulator Valve	Honeywell
898172-16-1	Pressure Regulator Valve	Honeywell
898172-17-1	Pressure Regulator Valve	Honeywell
898172-18-1	Pressure Regulator Valve	Honeywell
898172-19-1	Pressure Regulator Valve	Honeywell
898172-2-1	Pressure Regulator Valve	Honeywell
898172-3-1	Pressure Regulator Valve	Honeywell
898172-7-1	Pressure Regulator Valve	Honeywell
898172-8-1	Pressure Regulator Valve	Honeywell
898172-9-1	Pressure Regulator Valve	Honeywell
898230-1	Valve assy	Honeywell
898296-1	Overpressure Valve	Honeywell
898296-2	Overpressure Valve	Honeywell
898296-3	Overpressure Valve	Honeywell
898396-2	Regulating Valve	Honeywell
898396-3	Regulating Valve	Honeywell
898566-2	Regulating Valve	Honeywell
898566-3	Regulating Valve	Honeywell
898626-3	Pressure Valve	Honeywell
898626-4	Pressure Valve	Honeywell
898737	Fire Detector assy	Kidde Aerospace
898737-1	Fire Detector assy	Kidde Aerospace
898738	Fire Detector assy	Kidde Aerospace
898738-1	Fire Detector assy	Kidde Aerospace
898760	Regulating Valve	Honeywell
898760-1	Regulating Valve	Honeywell
898806-1	Valve assy	Honeywell
898980	Regulating Valve	Honeywell
898980-1	Regulating Valve	Honeywell
898980-2	Regulating Valve	Honeywell
898980-3	Regulating Valve	Honeywell
899052-01	CONTROL UNIT	WALTER KIDD
899-156-612	Waste Tank Sensor	Ametek
899185	Fire Detector assy	Kidde Aerospace
899186	Fire Detector assy	Kidde Aerospace
899-2125-003	VHF/Comm Control Unit	Thales Avionics
899-2125-004	VHF/Comm Control Unit	Thales Avionics
899-2223-004	VOR/DME Control Unit	Thales Avionics
899-2223-006	VOR/DME Control Unit	Thales Avionics
899-2223-008	VOR/DME Control Unit	Thales Avionics
899-2725-007	HF Control Unit	Thales Avionics
899320-1	Oil Tank assy	Honeywell
899323-3	Combustion Chamber Cap	Honeywell
899344	Fire Detector assy	Kidde Aerospace
899545-1	Transducer	Honeywell
899580-1	Ignition Exciter	Honeywell
899580-2	Ignition Exciter	Honeywell
899580-3	Ignition Exciter	Honeywell
899580-4	IGNITION EXCITER	UNISON
899580-5	IGNITION EXCITER	UNISON
899580-6	IGNITION EXCITER	UNISON
899978	Fire Detector assy	Kidde Aerospace
8DJ148WAC2	Tach Indicator	Ametek
8DJ148WAD2	Tach Indicator	Ametek
8DJ170LWA1	Fuel Flow Indicator	Ametek
8DJ170LWG1	Fuel Flow Indicator	Ametek

Repair_Capability_List_Excel

8DJ170LWL1	Fuel Flow Rate Indicator	Ametek
8DJ170LWN1	Fuel Flow Rate Indicator	Ametek
8DJ170LWP1	Fuel Flow Indicator	Ametek
8DJ170LWR1	Fuel Flow Indicator	Ametek
8DJ171LWA2	Fuel Used Indicator	Ametek
8DJ171LWA3	Fuel Used Indicator	Ametek
8DJ171LWD2	Fuel Used Indicator	Ametek
8DJ171LWD3	Fuel Used Indicator	Ametek
8DJ172LWA1	Oil Quantity Indicator	Ametek
8DJ172LWD1	Oil Quantity Indicator	Ametek
8DJ172LWE1	Oil Quantity Indicator	Ametek
8DJ172LWK1	Oil Quantity Indicator	Ametek
8DJ172LWL1	Oil Quantity Indicator	Ametek
8DJ172LWP1	Oil Quantity Indicator	Ametek
8DJ172LWR1	Oil Quantity Indicator	Ametek
8DJ172LWY1	Oil Quantity Indicator	Ametek
8DJ173LWA1	Oil Quantity Indicator	Ametek
8DJ173LWC1	Oil Quantity Indicator	Ametek
8DJ173LWD1	Oil Quantity Indicator	Ametek
8DJ173LWE1	Oil Quantity Indicator	Ametek
8DJ174LWA1	EPR Indicator	Ametek
8DJ174LWM1	EPR Indicator	Ametek
8DJ174LWP1	EPR Indicator	Ametek
8DJ175LWK2	EGT Indicator	Ametek
8DJ175LWK2-T	EGT Indicator	Ametek
8DJ175LWL1	EGT Indicator	Ametek
8DJ175LWM2	EGT Indicator	Ametek
8DJ175LWR1	EGT Indicator	Ametek
8DJ175LWS2	EGT Indicator	Ametek
8DJ175LWT2	EGT Indicator	Ametek
8DJ175LWX1	EGT Indicator	Ametek
8DJ175LXA1	EGT Indicator	Ametek
8DJ175LXB2	EGT Indicator	Ametek
8DJ175LXC2	EGT Indicator	Ametek
8DJ175LXF2	EGT Indicator	Ametek
8DJ175LXH1	EGT Indicator	Ametek
8DJ175LXK1	EGT Indicator	Ametek
8DJ175LXR2	EGT Indicator	Ametek
8DJ175LXT1	EGT Indicator	Ametek
8DJ175LXV1	EGT Indicator	Ametek
8DJ176LWG2	N2 Indicator	Ametek
8DJ176LWS2	Speed Indicator	Ametek
8DJ176LWT2	Speed Indicator	Ametek
8DJ176LWV2	N2 Indicator	Ametek
8DJ176LWX1	Speed Indicator	Ametek
8DJ176LWY1	Speed Indicator	Ametek
8DJ176LWZ2	N1 Indicator	Ametek
8DJ176LXA1	N2 Indicator	Ametek
8DJ176LXE1	N2 Indicator	Ametek
8DJ176LXEY1	N2 Indicator	Ametek
8DJ176LXG1	N2 Indicator	Ametek
8DJ176LXH1	N2 Indicator	Ametek
8DJ176LXK1	N2 Indicator	Ametek
8DJ176LXL1	N2 Indicator	Ametek
8DJ176LXN1	N2 Indicator	Ametek
8DJ176LXS1	N2 Indicator	Ametek
8DJ176LXT1	N2 Indicator	Ametek
8DJ176LXV1	N2 Indicator	Ametek

Repair_Capability_List_Excel

8DJ176LXW1	N2 Indicator	Ametek
8DJ176LXZ1	N2 Indicator	Ametek
8DJ176LZA3	N2 Indicator	Ametek
8DJ176LZB1	Speed Indicator	Ametek
8DJ176LZC1	Speed Indicator	Ametek
8DJ176LZD2	Speed Indicator	Ametek
8DJ176LZF2	N2 Indicator	Ametek
8DJ176LZK2	Speed Indicator	Ametek
8DJ176LZN2	Speed Indicator	Ametek
8DJ176LZP1	Speed Indicator	Ametek
8DJ176LZR1	Speed Indicator	Ametek
8DJ176LZS2	N2 Indicator	Ametek
8DJ176LZT2	N1 Indicator	Ametek
8DJ176LZV3	N2 Indicator	Ametek
8DJ176LZY1	Speed Indicator	Ametek
8DJ176LZZ1	Speed Indicator	Ametek
8DJ176WAD1	Speed Indicator	Ametek
8DJ176WAE1	Speed Indicator	Ametek
8DJ176WAH3	N2 Indicator	Ametek
8DJ176WAK3	N2 Indicator	Ametek
8DJ176WAP2	Speed Indicator	Ametek
8DJ176WAR2	N2 Indicator	Ametek
8DJ176WAV1	Speed Indicator	Ametek
8DJ176WAZ2	N1 Indicator	Ametek
8DJ176WBF1	N2 Indicator	Ametek
8DJ176WBG1	Speed Indicator	Ametek
8DJ176WBH1	Speed Indicator	Ametek
8DJ176WBN1	Speed Indicator	Ametek
8DJ176WBP1	Speed Indicator	Ametek
8DJ176WBR1	N2 Indicator	Ametek
8DJ177LWN1	Temperature Indicator	Ametek
8DJ177LWP1	Temperature Indicator	Ametek
8DJ177LWR1	Temperature Indicator	Ametek
8DJ177LWS1	Temperature Indicator	Ametek
8DJ177LWV1	Temperature Indicator	Ametek
8DJ177LWW1	Temperature Indicator	Ametek
8DJ177LWX1	Temperature Indicator	Ametek
8DJ184LWA1	EPR Indicator	Ametek
8DJ184LWA2	EPR Indicator	Ametek
8DJ184LWN2	EPR Indicator	Ametek
8DJ184LWT2	EPR Indicator	Ametek
8DJ185LWE1	TGT Indicator	Ametek
8DJ185LWEY1	TGT Indicator	Ametek
8DJ185LWF1	TGT Indicator	Ametek
8DJ185LWF1Y1	TGT Indicator	Ametek
8DJ185LWG1	TGT Indicator	Ametek
8DJ185LWH1	TGT Indicator	Ametek
8DJ185LWL1	TGT Indicator	Ametek
8DJ185LWN1	TGT Indicator	Ametek
8DJ185LWP1	TGT Indicator	Ametek
8DJ185LWT1	TGT Indicator	Ametek
8DJ185LWV1	TGT Indicator	Ametek
8DJ186LWD1	Speed Indicator	Ametek
8DJ186LWF1	Speed Indicator	Ametek
8DJ186LWG1	Speed Indicator	Ametek
8DJ186LWH1	Speed Indicator	Ametek
8DJ186LWK1	Speed Indicator	Ametek
8DJ186LWL1	Speed Indicator	Ametek

Repair_Capability_List_Excel

8DJ186LWM1	Speed Indicator	Ametek
8DJ186LWN1	Speed Indicator	Ametek
8DJ186LWS1	Speed Indicator	Ametek
8DJ186LWT1	Speed Indicator	Ametek
8DJ186LWW1	Speed Indicator	Ametek
8DJ186LWZ1	Speed Indicator	Ametek
8DJ186LXA1	Speed Indicator	Ametek
8DJ186LXB1	Speed Indicator	Ametek
8DJ186LXC1	Speed Indicator	Ametek
8DJ186LXD1	Speed Indicator	Ametek
8DJ339WAD1	Stand-By Engine Indicator	Ametek
8DJ339WAF1	Stand-By Engine Indicator	Ametek
8DJ339WAG1	Stand-By Engine Indicator	Ametek
8DJ339WAH1	Stand-By Engine Indicator	Ametek
8DJ81AAA1	TACHOMETER INDICATOR	AMETEK
8DJ81AAB1	TACHOMETER INDICATOR	AMETEK
8DJ81AAC1	TACHOMETER INDICATOR	AMETEK
8DJ81ACB2	TACHOMETER INDICATOR	AMETEK
8DJ81ACL1	TACHOMETER INDICATOR	AMETEK
8DJ81BAA1	TACHOMETER INDICATOR	AMETEK
8DJ81CAA1	TACHOMETER INDICATOR	AMETEK
8DJ81CAA2	TACHOMETER INDICATOR	AMETEK
8DJ81CAC1	TACHOMETER INDICATOR	AMETEK
8DJ81CAC2	TACHOMETER INDICATOR	AMETEK
8DJ81CAE1	TACHOMETER INDICATOR	AMETEK
8DJ81CAE2	TACHOMETER INDICATOR	AMETEK
8DJ81CAF1	TACHOMETER INDICATOR	AMETEK
8DJ81CAF2	TACHOMETER INDICATOR	AMETEK
8DJ81CAH1	TACHOMETER INDICATOR	AMETEK
8DJ81CAH2	TACHOMETER INDICATOR	AMETEK
8DJ81CAK1	TACHOMETER INDICATOR	AMETEK
8DJ81CAK2	TACHOMETER INDICATOR	AMETEK
8DJ81CAL2	TACHOMETER INDICATOR	AMETEK
8DJ81CAM1	TACHOMETER INDICATOR	AMETEK
8DJ81CAM2	TACHOMETER INDICATOR	AMETEK
8DJ81CAN1	TACHOMETER INDICATOR	AMETEK
8DJ81CAN2	TACHOMETER INDICATOR	AMETEK
8DJ81CAS2	TACHOMETER INDICATOR	AMETEK
8DJ81CAX2	TACHOMETER INDICATOR	AMETEK
8DJ81CAY2	TACHOMETER INDICATOR	AMETEK
8DJ81CAZ2	TACHOMETER INDICATOR	AMETEK
8DJ81CBA2	TACHOMETER INDICATOR	AMETEK
8DJ81CBB2	TACHOMETER INDICATOR	AMETEK
8DJ81CBK2	TACHOMETER INDICATOR	AMETEK
8DJ81CBX2	TACHOMETER INDICATOR	AMETEK
8DJ81CCK2	TACHOMETER INDICATOR	AMETEK
8DJ81CCL2	TACHOMETER INDICATOR	AMETEK
8DJ81CCM2	TACHOMETER INDICATOR	AMETEK
8DJ81CDC2	TACHOMETER INDICATOR	AMETEK
8DJ81CDE2	TACHOMETER INDICATOR	AMETEK
8DJ81CDH2	TACHOMETER INDICATOR	AMETEK
8DJ81CDY2	TACHOMETER INDICATOR	AMETEK
8DJ81FAA1	TACHOMETER INDICATOR	AMETEK
8DJ81FAA2	TACHOMETER INDICATOR	AMETEK
8DJ81LAA1	TACHOMETER INDICATOR	AMETEK
8DJ81LAA2	TACHOMETER INDICATOR	AMETEK
8DJ81LAB2	TACHOMETER INDICATOR	AMETEK
8DJ81LAC1	TACHOMETER INDICATOR	AMETEK

Repair_Capability_List_Excel

8DJ81LAC2	TACHOMETER INDICATOR	AMETEK
8DJ81LAD1	TACHOMETER INDICATOR	AMETEK
8DJ81LAD2	TACHOMETER INDICATOR	AMETEK
8DJ81LAE1	TACHOMETER INDICATOR	AMETEK
8DJ81LAE2	TACHOMETER INDICATOR	AMETEK
8DJ81LAK1	TACHOMETER INDICATOR	AMETEK
8DJ81LAK2	TACHOMETER INDICATOR	AMETEK
8DJ81LAN2	TACHOMETER INDICATOR	AMETEK
8DJ81LAT1	TACHOMETER INDICATOR	AMETEK
8DJ81LAT2	TACHOMETER INDICATOR	AMETEK
8DJ81LAV2	TACHOMETER INDICATOR	AMETEK
8DJ81LAW1	TACHOMETER INDICATOR	AMETEK
8DJ81LAW2	TACHOMETER INDICATOR	AMETEK
8DJ81LAX2	TACHOMETER INDICATOR	AMETEK
8DJ81LAY2	TACHOMETER INDICATOR	AMETEK
8DJ81LAZ2	TACHOMETER INDICATOR	AMETEK
8DJ81LBC2	TACHOMETER INDICATOR	AMETEK
8DJ81LBD2	TACHOMETER INDICATOR	AMETEK
8DJ81LBE2	TACHOMETER INDICATOR	AMETEK
8DJ81LBF2	TACHOMETER INDICATOR	AMETEK
8DJ81LBH2	TACHOMETER INDICATOR	AMETEK
8DJ81LBK2	TACHOMETER INDICATOR	AMETEK
8DJ81LBL2	TACHOMETER INDICATOR	AMETEK
8DJ81LBS2	TACHOMETER INDICATOR	AMETEK
8DJ81LBT2	TACHOMETER INDICATOR	AMETEK
8DJ81LBX2	TACHOMETER INDICATOR	AMETEK
8DJ81LCB2	TACHOMETER INDICATOR	AMETEK
8DJ81LCD2	TACHOMETER INDICATOR	AMETEK
8DJ81LCF2	TACHOMETER INDICATOR	AMETEK
8DJ81LCK2	TACHOMETER INDICATOR	AMETEK
8DJ81LWA1	TACHOMETER INDICATOR	AMETEK
8DJ81LWA2	TACHOMETER INDICATOR	AMETEK
8DJ81LWB2	TACHOMETER INDICATOR	AMETEK
8DJ81LWC2	TACHOMETER INDICATOR	AMETEK
8DJ81LWH2	TACHOMETER INDICATOR	AMETEK
8DJ81LWM2	TACHOMETER INDICATOR	AMETEK
8DJ81LWN2	TACHOMETER INDICATOR	AMETEK
8DJ81LWR2	TACHOMETER INDICATOR	AMETEK
8DJ81LWS2	TACHOMETER INDICATOR	AMETEK
8DJ81LWT2	TACHOMETER INDICATOR	AMETEK
8DJ81LWV2	TACHOMETER INDICATOR	AMETEK
8DJ81LWY2	TACHOMETER INDICATOR	AMETEK
8DJ81LWZ2	TACHOMETER INDICATOR	AMETEK
8DJ81LXC2	TACHOMETER INDICATOR	AMETEK
8DJ81LXD2	TACHOMETER INDICATOR	AMETEK
8DJ81LXE2	TACHOMETER INDICATOR	AMETEK
8DJ81LXF2	TACHOMETER INDICATOR	AMETEK
8DJ81LXG2	TACHOMETER INDICATOR	AMETEK
8DJ81LXH2	TACHOMETER INDICATOR	AMETEK
8DJ81LXK2	TACHOMETER INDICATOR	AMETEK
8DJ81LXL2	TACHOMETER INDICATOR	AMETEK
8DJ81LXM2	TACHOMETER INDICATOR	AMETEK
8DJ81LXN2	TACHOMETER INDICATOR	AMETEK
8DJ81LXP2	TACHOMETER INDICATOR	AMETEK
8DJ81LXT2	TACHOMETER INDICATOR	AMETEK
8DJ81LXV2	TACHOMETER INDICATOR	AMETEK
8DJ81LXW2	TACHOMETER INDICATOR	AMETEK
8DJ81LXY2	TACHOMETER INDICATOR	AMETEK

Repair_Capability_List_Excel

8DJ81LXZ2	TACHOMETER INDICATOR	AMETEK
8DJ81LYA2	TACHOMETER INDICATOR	AMETEK
8DJ81LYB2	TACHOMETER INDICATOR	AMETEK
8DJ81LYC2	TACHOMETER INDICATOR	AMETEK
8DJ81LYP2	TACHOMETER INDICATOR	AMETEK
8DJ81LYT2	Tachymeter Indicator	Ametek
8DJ81LYT4	Tachymeter Indicator	Ametek
8DJ81LYV2	Tachymeter Indicator	Ametek
8DJ81LYV4	Tachymeter Indicator	Ametek
8DJ81LYW2	TACHOMETER INDICATOR	AMETEK
8DJ81LYX2	TACHOMETER INDICATOR	AMETEK
8DJ81LZB2	TACHOMETER INDICATOR	AMETEK
8DJ81LZC2	TACHOMETER INDICATOR	AMETEK
8DJ81LZE2	TACHOMETER INDICATOR	AMETEK
8DJ81LZF2	TACHOMETER INDICATOR	AMETEK
8DJ81WAG2	TACHOMETER INDICATOR	AMETEK
8DL-OC6A	Standby Engine Indicator	Ametek
8DW84LVZ1	DC A/V Meter	Ametek
8ES002769-03	Power Supply	Hella
8ES003761-00	Energy Box	Hella
8ES003974-00	Energy Box	Hella
8ES004631-00	Power Unit	Hella
8ES004632-00	Power Unit	Hella
8ES004751-00	Strobe assy	Hella
8ES004752-00	Strobe assy	Hella
8ES004753-00	Strobe assy	Hella
8ES005045-00	Strobe assy	Hella
8ES005236-03	Strobe assy	Hella
8ES005236-13	Strobe assy	Hella
8ES005237-03	Strobe assy	Hella
8ES005237-13	Strobe assy	Hella
8ES005238-03	Strobe assy	Hella
8ES005238-13	Strobe assy	Hella
8ES005304-00	Strobe assy	Hella
8ES005309-00	Strobe assy	Hella
8ES403701-02	Rear Navigation Light Transformer	Hella
8ES403703-02	Rear Navigation Light Transformer	Hella
8ES403703-02A	Rear Navigation Light Transformer	Hella
8G703-1	Pressure Gage Switch	Custom Control Sensors
8G804-1A	Pressure Switch	Custom Control Sensors
8G804-2	Pressure Switch	Custom Control Sensors
8KA402040-00	Wire Harness	Hella
8KA402040-01	Wire Harness	Hella
8P13-01-01	Artificial Feel Solenoid	Mecalectro
8TC34ABH2	Thermocouple Probe	Ametek
8TC34ABH8	Thermocouple Probe	Ametek
8TE34AAM1	Thermocouple Harness	Ametek
8TE34AAN1	Thermocouple Harness	Ametek
8TE34AAP1	Thermocouple Harness	Ametek
8TE34AAR1	Thermocouple Harness	Ametek
8TE34AAV1	Thermocouple Harness	Ametek
8TE34ABV1	Thermocouple Harness	Ametek
8TE34ACE1	Thermocouple Harness	Ametek
8TE34ACE2	Thermocouple Harness	Ametek
8TE34ACE3	Thermocouple Harness	Ametek
8TE34ACF1	Thermocouple Harness	Ametek
8TE34ACF2	Thermocouple Harness	Ametek
8TE34ACF3	Thermocouple Harness	Ametek

Repair_Capability_List_Excel

8TE34ACH1	Thermocouple Harness	Ametek
8TE34ACH2	Thermocouple Harness	Ametek
8TE34ACH3	Thermocouple Harness	Ametek
8TE34ACJ1	Thermocouple Harness	General Electric
8TE34ACJ2	Thermocouple Harness	General Electric
8TE34ACJ3	Thermocouple Harness	General Electric
8TE34ACK1	Thermocouple Harness	Ametek
8TE34ACK2	Thermocouple Harness	Ametek
8TE34ACU11	Thermocouple Indicating System	Ametek
8TE34ACU6	Thermocouple Indicating System	Ametek
8TE34ACU8	Thermocouple Indicating System	Ametek
8TJ100GAD6	Fuel Flow Transmitter	Ametek
8TJ100GAD7	Fuel Flow Transmitter	Ametek
8TJ100GBD7	Fuel Flow Transmitter	Ametek
8TJ124ERC1	Fuel Flow Transmitter	Ametek
8TJ124ERE1	Fuel Flow Transmitter	Ametek
8TJ124ERF1	Fuel Flow Transmitter	Ametek
8TJ124ERG1	Fuel Flow Transmitter	Ametek
8TJ124GGD1	Fuel Flow Transmitter	Ametek
8TJ124GGD3	Fuel Flow Transmitter	Ametek
8TJ124GGN1	Fuel Flow Transmitter	Ametek
8TJ124GGN2	Fuel Flow Transmitter	Ametek
8TJ124GGN3	Fuel Flow Transmitter	Ametek
8TJ124GGR1	Fuel Flow Transmitter	Ametek
8TJ124GGT1	Fuel Flow Transmitter	Ametek
8TJ126GAT2	Flow Meter	Ametek
8TJ138AAA3	Fan Speed Sensor	Ametek
8TJ138AAA4	Fan Speed Sensor	Ametek
8TJ138AAA5	Fan Speed Sensor	Ametek
8TJ138AAF2	Fan Speed Sensor	Ametek
8TJ146AAA1	Oil Level Sensor	Ametek
8TJ146CFA1	Oil Level Sensor	Ametek
8TJ146CFB1	Oil Level Sensor	Ametek
8TJ160AAB1	Dual Oil Level Transmitter	Ametek
8TJ160AAE1	Oil Level Sensor	Ametek
8TJ162AAB1	Core Speed Sensor	Ametek
8TJ162AAC1	Core Speed Sensor	Ametek
8TJ163AAB1	N1 Speed Sensor	Ametek
8TJ163AAC1	N1 Speed Sensor	Ametek
8TJ50GBZ3	Fuel Flow Transmitter	Ametek
8TJ50GCA3	Fuel Flow Transmitter	Ametek
8TJ85GAZ1	Fuel Flow Transmitter	Ametek
8TJ85GAZ2	Fuel Flow Transmitter	Ametek
8TJ85GCG2	Fuel Flow Transmitter	Ametek
8TJ88GAN1	Fule Flow Power Supply	Ametek
8TJ88GAN3	Fule Flow Power Supply	Ametek
8TJ88GAN4	Fule Flow Transmitter Power Supply	Ametek
8TJ95GAB	Power Supply	Ametek
8TJ95GAB3	Fuel Flow Power Supply	Ametek
8TJ95GAB4	Fuel Flow Power Supply	Ametek
8TJ99GAF1	Liquid Level Transmitter	Ametek
8TJ99GAF2	Liquid Level Transmitter	Ametek
8TJ99GAT1	Liquid Level Transmitter	Ametek
8TJ99GAT2	Liquid Level Transmitter	Ametek
8TJ99GAV3	Liquid Level Transmitter	Ametek
8TJ99GAV4	Liquid Level Transmitter	Ametek
8TJ99GAV5	Liquid Level Transmitter	Ametek
8TJ99GAV6	Liquid Level Transmitter	Ametek

Repair_Capability_List_Excel

8TJ99GBC2	Liquid Level Transmitter	Ametek
8TJ99GBH1	Liquid Level Transmitter	Ametek
8TJ99GGB3	Liquid Level Transmitter	Ametek
8TJ99GGE1	APU Oil Qty Transmitter	Ametek
8TJ99GGG3	Liquid Level Transmitter	Ametek
8TK34ABB1	Thermocouple Indicating System	Ametek
8TK34ABC1	Thermocouple Indicating System	Ametek
8TK34ABP2	Thermocouple Indicating System	Ametek
8TK34ABR1	Thermocouple Indicating System	Ametek
8TK34ABR2	Thermocouple Indicating System	Ametek
8TK34ABS1	Thermocouple Indicating System	Ametek
8TK34ABV1	Thermocouple Indicating System	Ametek
8TK34ABW1	Thermocouple Indicating System	Ametek
8TK34ABW2	Thermocouple Indicating System	Ametek
9000003-1	Linear Accelerometer	Honeywell
9000003-3	Linear Accelerometer	Honeywell
9000-01	Volt-Loadmeter	Aero Tech
9000910-1	Slat Skew Switch	Honeywell
9000910-2	Slat Skew Switch	Honeywell
90-0215-1	Windshield Wiper Gearcase	Grimes Aerospace
90-0215-2	Windshield Wiper Gearcase	Grimes Aerospace
90-0215-3	Windshield Wiper Gearcase	Grimes Aerospace
90-0215-4	Windshield Wiper Gearcase	Grimes Aerospace
90-0215-5	Windshield Wiper Gearcase	Grimes Aerospace
90-0215-6	Windshield Wiper Gearcase	Grimes Aerospace
90-0215-7	Windshield Wiper Gearcase	Grimes Aerospace
90-0215-8	Windshield Wiper Gearcase	Grimes Aerospace
9005-42	Battery Power Supply	Intertechnique
9008-3	Battery Power Supply	Intertechnique
9008-4	Battery Power Supply	Intertechnique
9008-5	Battery Power Supply	Intertechnique
9008D07-1	Electric Motor	Westinghouse
9008D09-1	Power Relay	Hamilton Sundstrand
9008D09-2	Power Relay	Hamilton Sundstrand
9008D09-3	Power Relay	Hamilton Sundstrand
9008D15-2	Alternating Current Motor	Hamilton Sundstrand
90-10072	Entry Door Snubber	Boeing
90-10072-1	Entry Door Snubber	Boeing
90-10072-2	Entry Door Snubber	Boeing
901905	Detector assy	Meggitt
901906	Detector assy	Meggitt
901907	Detector assy	Meggitt
901908	Detector assy	Meggitt
9023-15703-4	Outflow Valve	Nord-Micro
9023-15703-41	Outflow Valve	Nord-Micro
9023-15703-6	Outflow Valve	Nord-Micro
9023-15703-7	Outflow Valve	Nord-Micro
9023-15703-71	Outflow Valve	Nord-Micro
9023-15703-8	Outflow Valve	Nord-Micro
9023-15703-81	Outflow Valve	Nord-Micro
9023A0003-01	Switch	Liebherr Aerotechnik
9023A0004-01	Switch	Liebherr Aerotechnik
9023A0005-01	Pressure Switch	Liebherr Aerospace
9023A0005-02	Pressure Switch	Liebherr Aerospace
9024-15704-2	Safety Valve	Nord-Micro
9024-15704-2 Amdt A	Safety Valve	Nord-Micro
9026A0001-01	Filter	Liebherr Aerotechnik
9026A0003-01	Filter	Liebherr Aerotechnik

Repair_Capability_List_Excel

9026A0010-01	Filter	Liebherr Aerotechnik
9026A0019-01	Filter	Liebherr Aerotechnik
9027-16120	LDG Field Selector	Nord-Micro
9027-20010	LDG Field Selector	Nord-Micro
9027-20157	LDG Field Selector	Nord-Micro
9028A0001-01	Position Pickoff Unit	Liebherr Aerotechnik
9028A0002-01	Position Pickoff Unit	Liebherr Aerotechnik
9028A0004-01	Position Pickoff Unit	Liebherr Aerotechnik
9028A0005-01	Position Pickoff Unit	Liebherr Aerotechnik
9031A0001-01	Intermediate Gearbox	Liebherr Aerotechnik
9031A0001-02	Intermediate Gearbox	Liebherr Aerotechnik
9031A0002-01	Intermediate Gearbox	Liebherr Aerotechnik
9031A0002-02	Intermediate Gearbox	Liebherr Aerotechnik
9031A0003-01	Intermediate Gearbox	Liebherr Aerotechnik
9031A0003-02	Intermediate Gearbox	Liebherr Aerotechnik
9032-2-1	Valve assy	Transdigm Inc
9032-2-4	Valve assy	Transdigm Inc
9032-3-1	Valve assy	Transdigm Inc
9032-3-2	Valve assy	Transdigm Inc
9032-4-1	Valve assy	Transdigm Inc
9032-4-2	Valve assy	Transdigm Inc
9032-4-3	Valve assy	Transdigm Inc
903A0000-01	Solenoid Valve	Liebherr Aerotechnik
9040M62P01	Displacement Transmitter	General Electric
9040M62P02	Displacement Transmitter	General Electric
9040M62P03	Displacement Transmitter	General Electric
9040M62P04	Displacement Transmitter	General Electric
9040M62P05	Displacement Transmitter	General Electric
9040M62P06	Displacement Transmitter	General Electric
9040M62P07	Displacement Transmitter	General Electric
9042M12P03	By-Pass Valve Actuator	General Electric
9042M12P04	By-Pass Valve Actuator	General Electric
9043105-3	Ignition Lead assy	Unison Industries
9043105-4	Ignition Lead assy	Unison Industries
9043105-5	Ignition Lead assy	Unison Industries
9043105-6	Ignition Lead assy	Unison Industries
9043105-7	Ignition Lead assy	Unison Industries
9043170-2	Ignition Lead	Unison
9043170-3	Ignition Lead	Unison
9043171-1	Ignition Lead	Unison
9043185-14	Ignition Lead assy	Unison
9055M73G01	Thermocouple	General Electric
9055M73G02	Thermocouple	General Electric
9055M74G01	Thermocouple	General Electric
9055M74G02	Thermocouple	General Electric
9055M74G03	Thermocouple	General Electric
9055M74G04	Thermocouple	General Electric
9055M75G01	Thermocouple	General Electric
9055M75G02	Thermocouple	General Electric
9055M89P01	Thermocouple	General Electric
9055M89P02	Thermocouple	General Electric
9055M89P03	Thermocouple	General Electric
9055M90P01	Thermocouple	General Electric
9055M90P02	Thermocouple	General Electric
9055M90P03	Thermocouple	General Electric
9055M90P04	Thermocouple harness	General Electric
9055M90P05	Thermocouple harness	General Electric
9055M90P06	Thermocouple	General Electric

Repair_Capability_List_Excel

9055M91P01	Thermocouple	General Electric
9055M91P02	Thermocouple harness	Ametek
9055M91P03	Thermocouple	General Electric
9066M97P02	Pressure Valve	General Electric
9066M97P03	Pressure Valve	General Electric
9066M97P05	Pressure Valve	General Electric
9066M97P06	Pressure Valve	General Electric
9067M65P02	Feedback Cable Actuator	Parker Hannifin
9067M65P04	Feedback Cable Actuator	Parker Hannifin
9067M65P05	Feedback Cable Actuator	General Electric
9067M65P06	Feedback Cable Actuator	General Electric
9067M65P08	Feedback Cable Actuator	General Electric
9067M65P10	Feedback Cable Actuator	General Electric
9067M77P01	By-Pass Feedback Valve Cable	General Electric
9067M77P02	By-Pass Feedback Valve Cable	General Electric
9067M77P03	By-Pass Feedback Valve Cable	General Electric
9069A1001-02	Electro Mechanical Actuator	Liebherr Aerotechnik
9069A1002-01	Electro Mechanical Actuator	Liebherr Aerotechnik
9069A1003-01	Electro Mechanical Actuator	Liebherr Aerotechnik
9069A1015-01	Electro Mechanical Actuator	Liebherr Aerotechnik
9069A1018-01	Electro Mechanical Actuator	Liebherr Aerotechnik
9069B1002-01	Electro Mechanical Actuator	Liebherr Aerotechnik
9070-13	Meter	Thales Avionics
907D547-1	Stator Exciter	Hamilton Sundstrand
909C453-2	Transformer	Hamilton Sundstrand
90G118-2	Pressure Switch	Custom Control Sensors
90G183	Pressure Switch	Custom Control Sensors
90G191	Switch	Custom Control Sensors
90G222	Pressure Switch	Custom Control Sensors
90G37	Pressure Switch	Custom Control Sensors
90G62-3	Switch	Custom Control Sensors
9100M30G08	OIL TANK	GENERAL ELECTRIC
9100M30G10	OIL TANK	GENERAL ELECTRIC
9100M30G11	OIL TANK	GENERAL ELECTRIC
9100M30G12	OIL TANK	GENERAL ELECTRIC
9100M30G13	OIL TANK	GENERAL ELECTRIC
9101M52P12	Ignition Exciter	General Electric
9101M52P13	Ignition Exciter	General Electric
9101M52P16	Ignition Exciter	General Electric
9101M52P17	Ignition Exciter	General Electric
9101M52P20	Ignition Exciter	General Electric
9104A0002-01	Pressure Sensor	Liebherr Aerotechnik
9104A0003-01	Pressure Sensor	Liebherr Aerotechnik
9104A0005-01	Pressure Sensor	Liebherr Aerotechnik
9104A0007-01	Pressure Sensor	Liebherr Aerotechnik
9106A0001-01	Pressure Sensor	Liebherr Aerotechnik
9106A0003-01	Pressure Sensor	Liebherr Aerotechnik
9106A0005-01	Pressure Sensor	Liebherr Aerotechnik
9-112-05	TRANSMITTER	ELDEC CORP
9-114-04	TRANSMITTER	ELDEC CORP
9124-8062	Relay	Leach
9124-8063	Relay	Leach
9124-9283	Relay	Leach
9124M14P01	Thermocouple	General Electric
9124M14P02	Thermocouple	General Electric
9124M28P02	Harness	General Electric
9124M29P02	Harness	General Electric
912D0401	Manual Controller	Liebherr Aerospace

Repair_Capability_List_Excel

9131-8505	Relay	Leach
9131-8506	Relay	Leach
9133-54-A1	Fuel Flow Transmitter	Bendix/King
9136-5-A1	Fuel Flow Transmitter	Bendix/King
914F565-4	Control Panel	Hamilton Sundstrand
914F565-5	Control Panel	Hamilton Sundstrand
914F567-3	Power Relay	Hamilton Sundstrand
914F567-4	Power Relay	Hamilton Sundstrand
914F582-3	Power Control External	Hamilton Sundstrand
9153M75P01	Displacement Transmitter	General Electric
9153M75P02	Displacement Transmitter	General Electric
9153M75P03	Displacement Transmitter	General Electric
9153M75P04	Displacement Transmitter	General Electric
9153M75P05	Displacement Transmitter	General Electric
9153M75P06	Displacement Transmitter	General Electric
9153M75P07	Displacement Transmitter	General Electric
915F197-1	Rotor	Hamilton Sundstrand
915F199-1	Semi-Conductor	Hamilton Sundstrand
915F466-1	Stator	Hamilton Sundstrand
915F466-2	Stator	Hamilton Sundstrand
915F499-1	Stator	Hamilton Sundstrand
915F500-1	Exciter Stator	Hamilton Sundstrand
915F517-1	Rotor Armature	Hamilton Sundstrand
915F716-2	Semi-Conductor	Hamilton Sundstrand
915F718-1	Rotor	Hamilton Sundstrand
915F718-2	Rotor	Hamilton Sundstrand
915F718-3	Rotor	Hamilton Sundstrand
9162	Coffee Pump	Micropump
9168	Coffee Pump	Micropump
918A0000-04	Slat Control Unit	Liebherr Aerotechnik
918A0000-05	Slat Control Unit	Liebherr Aerotechnik
918A0100-01	Brake Valve	Liebherr Aerotechnik
918A0100-02	Brake Valve	Liebherr Aerotechnik
918B0000-01	Slat Control Unit	Liebherr Aerotechnik
91943	Thermometer	Weston Aerospace
91945	Thermometer	Weston Aerospace
92003-3790076-105	Actuator	Parker Hannifin
9201000-244	Quantity Transmitter	FR Hitemp
9201000-78	Contents Transmitter	FR Hitemp
9201000-79	Transmitter	FR Hitemp
9201A01	Actuator	Liebherr Aerospace
920449	Hydraulic Motor assy	Vickers
920635	Relief Valve	Vickers
9207-8339	Realy assy	Leach Corp
920A0000-01	Block Valve	Liebherr Aerotechnik
920A0000-02	Block Valve	Liebherr Aerotechnik
920A0000-03	Block Valve	Liebherr Aerotechnik
920A0000-04	Block Valve	Liebherr Aerotechnik
920A0000-05	Block Valve	Liebherr Aerotechnik
921A0000-01	Tee Gearbox	Liebherr Aerotechnik
921B0000-01	Tee Gearbox	Goodrich Control Systems
921C0000-01	Tee Gearbox	Goodrich Control Systems
9229M10P01	Feedback Cable Actuator	General Electric
9229M10P03	Feedback Cable Actuator	General Electric
9231-3	Servo Motor	Aviac
9231-4	Servo Motor	Aviac
9231-4-600	Electronic Module	Aviac
9231-5	Servo Motor	Aviac

Repair_Capability_List_Excel

9231-5-760	Motor assy	Aviac
9238M66P05	Ignition Exciter	Unison
9238M66P07	Ignition Exciter	Unison
9238M66P08	Ignition Exciter	Unison
924A0000-01	Bevel Gearbox	Liebherr Aerotechnik
924B0000-01	Bevel Gearbox	Goodrich Control Systems
924D100-1	Auto Ground Speed Brake Actuator	Eaton Aerospace
925-91713-000-A0	Fan assy	Airbus Industrie
926A0000-01	Slat Actuator	Liebherr Aerotechnik
926A0000-02	Slat Actuator	Liebherr Aerotechnik
926A0000-03	Slat Actuator	Liebherr Aerotechnik
926B0000-01	Slat Actuator	Liebherr Aerotechnik
926C0000-01	Slat Actuator	Liebherr Aerotechnik
927002-1	Thermal Switch	Custom Control Sensors
927078-1	Water Injector Nozzle	Honeywell
927214-1	Discharge Thermal Switch	Honeywell
927308-1	Temperature Indicator Sensor	Honeywell
927519-1	Sensor	LRE
9300141	Spherical Plug Valve	FR Hitemp
9300143	Spherical Plug Valve	FR Hitemp
9300213	Fire Shut-Off Valve	FR Hitemp
9300216	Shut-Off Valve	FR Hitemp
9300341	Shut-Off Valve	FR Hitemp
931D100-1	Large Cargo Door Power Drive	Eaton Aerospace
931D100-3	Large Cargo Door Power Drive	Eaton Aerospace
9324-8213	Relay	Leach
933249	Pump	Vickers
933252	Pump	Vickers
933D100-1	Flight Lock Actuator	Eaton Aerospace
9350022	Drain Valve	FR Hitemp
9350127	Drain Valve	FR Hitemp
93600-5005	Control Elevator	Parker Hannifin
93600-5007	Control Elevator	Parker Hannifin
93600-5009	Control Elevator	Parker Hannifin
93600-5011	Control Elevator	Parker Hannifin
93600-5013	Control Elevator	Parker Hannifin
93600-5015	Control Elevator	Parker Hannifin
93600-5017	Control Elevator	Parker Hannifin
93600-5019	Control Elevator	Parker Hannifin
93600-5021	Control Elevator	Parker Hannifin
93600-5023	Control Elevator	Parker Hannifin
93600-5025	Control Elevator	Parker Hannifin
93600-5027	Control Elevator	Parker Hannifin
93600-5029	Control Elevator	Parker Hannifin
93600-5031	Control Elevator	Parker Hannifin
93600-5033	Control Elevator	Parker Hannifin
93600-5035	Control Elevator	Parker Hannifin
93600-5037	Control Elevator	Parker Hannifin
93600-5039	Control Elevator	Parker Hannifin
93600-5041	Control Elevator	Parker Hannifin
93600-5043	Control Elevator	Parker Hannifin
93600-5045	Control Elevator	Parker Hannifin
93600-5047	Control Elevator	Parker Hannifin
93600-5049	Control Elevator	Parker Hannifin
93600-5051	Control Elevator	Parker Hannifin
93600-5053	Control Elevator	Parker Hannifin
93600-9005	Control Elevator	Parker Hannifin
93600-9007	Control Elevator	Parker Hannifin

Repair_Capability_List_Excel

93600-9009	Control Elevator	Parker Hannifin
93600-9011	Control Elevator	Parker Hannifin
93600-9013	Control Elevator	Parker Hannifin
93600-9015	Control Elevator	Parker Hannifin
93600-9017	Control Elevator	Parker Hannifin
93600-9019	Control Elevator	Parker Hannifin
93600-9021	Control Elevator	Parker Hannifin
93600-9023	Control Elevator	Parker Hannifin
93600-9025	Control Elevator	Parker Hannifin
93600-9027	Control Elevator	Parker Hannifin
93600-9029	Control Elevator	Parker Hannifin
93600-9031	Control Elevator	Parker Hannifin
93600-9033	Control Elevator	Parker Hannifin
93600-9035	Control Elevator	Parker Hannifin
93600-9037	Control Elevator	Parker Hannifin
93600-9041	Control Elevator	Parker Hannifin
93600-9043	Control Elevator	Parker Hannifin
93600-9045	Control Elevator	Parker Hannifin
93600-9047	Control Elevator	Parker Hannifin
93600-9049	Control Elevator	Parker Hannifin
93600-9051	Control Elevator	Parker Hannifin
93700-5005	Control Elevator	Parker Hannifin
93700-5009	Control Elevator	Parker Hannifin
93700RW1-1001	Control Elevator	Parker Hannifin
93700RW1-1003	Control Elevator	Parker Hannifin
93700RW1-1005	Control Elevator	Parker Hannifin
93700RW1-1007	Control Elevator	Parker Hannifin
9377M60P02-01	Switch	General Electric
9377M60P02-03	Switch	General Electric
9377M60P02-04	Switch	General Electric
9377M60P02-05	Switch	General Electric
9377M60P02-06	Switch	General Electric
93787	Thermometer	Weston Aerospace
937A0100-01	Steady Bearing	Goodrich Control Systems
937A0200-01	Steady Bearing	Goodrich Control Systems
937A0300-01	Steady Bearing	Goodrich Control Systems
937A1000-01	Shaft Torque assy	Goodrich Control Systems
937A1100-01	Shaft Torque assy	Goodrich Control Systems
937A1200-02	Shaft Torque assy	Goodrich Control Systems
937A1300-01	Shaft Torque assy	Goodrich Control Systems
937A1400-01	Shaft Torque assy	Goodrich Control Systems
937A1500-01	Shaft Torque assy	Goodrich Control Systems
937A1700-01	Shaft Assembly	Liebherr Aerotechnik
937A1800-01	Shaft Assembly	Liebherr Aerotechnik
937A1900-01	Shaft Assembly	Liebherr Aerotechnik
937A2000-01	Shaft Assembly	Goodrich Control Systems
937A2100-01	Shaft Assembly	Goodrich Control Systems
937A2100-02	Shaft Assembly	Liebherr Aerotechnik
937A2200-01	Shaft Assembly	Goodrich Control Systems
937A2200-02	Shaft Assembly	Liebherr Aerotechnik
937A2300-01	Shaft Assembly	Liebherr Aerotechnik
937A2400-01	Shaft Assembly	Liebherr Aerotechnik
937A2500-01	Shaft Assembly	Liebherr Aerotechnik
937A2600-01	Shaft Assembly	Liebherr Aerotechnik
937A2700-01	Shaft Assembly	Liebherr Aerotechnik
937A2800-01	Shaft Assembly	Liebherr Aerotechnik
937A2900-01	Shaft Assembly	Liebherr Aerotechnik
937A3000-01	Shaft Assembly	Goodrich Control Systems

Repair_Capability_List_Excel

937A3100-01	Shaft Assembly	Goodrich Control Systems
937A3100-02	Shaft Assembly	Goodrich Control Systems
937A3200-01	Shaft Assembly	Goodrich Control Systems
937A3300-01	Shaft Assembly	Liebherr Aerotechnik
937A3400-01	Shaft Assembly	Liebherr Aerotechnik
937A3500-01	Shaft Assembly	Liebherr Aerotechnik
937A3600-01	Shaft Assembly	Liebherr Aerotechnik
937A3700-01	Compliant Shaft assy	Liebherr Aerotechnik
937A3800-01	Shaft Assembly	Liebherr Aerotechnik
937A6000-01	Steady Bearing	Liebherr Aerotechnik
937A6100-01	Steady Bearing	Liebherr Aerotechnik
937A6200-01	Steady Bearing	Liebherr Aerotechnik
937B1000-01	Shaft Torque assy	Liebherr Aerotechnik
937B1100-01	Shaft Torque assy	Liebherr Aerotechnik
937B1200-01	Shaft Torque assy	Liebherr Aerotechnik
937B1300-01	Shaft Torque assy	Liebherr Aerotechnik
937B1400-01	Shaft Torque assy	Liebherr Aerotechnik
937B1500-01	Shaft Torque assy	Liebherr Aerotechnik
937B2000-01	Shaft Assembly	Liebherr Aerotechnik
937C1200-01	Shaft Torque assy	Goodrich Control Systems
937C1500-01	Shaft Torque assy	Goodrich Control Systems
937C1700-01	Shaft Assembly	Goodrich Control Systems
937C1800-01	Shaft Assembly	Goodrich Control Systems
937C1900-01	Shaft Assembly	Goodrich Control Systems
937C2000-01	Shaft Assembly	Goodrich Control Systems
937C2100-01	Shaft Assembly	Goodrich Control Systems
937C2200-01	Shaft Assembly	Goodrich Control Systems
937C2400-01	Shaft Assembly	Goodrich Control Systems
937C2500-01	Shaft Assembly	Goodrich Control Systems
937C2600-01	Shaft Assembly	Goodrich Control Systems
937C2700-01	Shaft Assembly	Goodrich Control Systems
937C2800-01	Shaft Assembly	Goodrich Control Systems
937C2900-01	Shaft Assembly	Goodrich Control Systems
937C3000-01	Shaft Assembly	Goodrich Control Systems
937C3100-01	Shaft Assembly	Goodrich Control Systems
937C3300-01	Shaft Assembly	Goodrich Control Systems
937C3400-01	Shaft Assembly	Goodrich Control Systems
937C3500-01	Shaft Assembly	Goodrich Control Systems
937C3600-01	Shaft Assembly	Goodrich Control Systems
937C3700-01	Shaft Assembly	Goodrich Control Systems
937C3800-01	Shaft Assembly	Goodrich Control Systems
937D1500-01	Shaft Torque assy	Goodrich Control Systems
937D1700-01	Shaft Assembly	Goodrich Control Systems
937D1800-01	Shaft Assembly	Goodrich Control Systems
937D1900-01	Shaft Assembly	Goodrich Control Systems
937D2000-01	Shaft Assembly	Goodrich Control Systems
937D2100-01	Shaft Assembly	Goodrich Control Systems
937D2100-02	Shaft Assembly	Goodrich Control Systems
937D2400-01	Shaft Assembly	Goodrich Control Systems
937D2500-01	Shaft Assembly	Goodrich Control Systems
937D2500-02	Shaft Assembly	Goodrich Control Systems
937D2600-01	Shaft Assembly	Goodrich Control Systems
937D2700-01	Shaft Assembly	Goodrich Control Systems
937D2800-01	Shaft Assembly	Goodrich Control Systems
937D2900-01	Shaft Assembly	Goodrich Control Systems
937D3000-01	Shaft Assembly	Goodrich Control Systems
937D3300-01	Shaft Assembly	Goodrich Control Systems
937D3400-01	Shaft Assembly	Goodrich Control Systems

Repair_Capability_List_Excel

937D3500-01	Shaft Assembly	Goodrich Control Systems
937D3600-01	Shaft Assembly	Goodrich Control Systems
937D3700-01	Shaft Assembly	Goodrich Control Systems
937D3800-01	Shaft Assembly	Goodrich Control Systems
93925	Thermometer	Weston Aerospace
939D128-3	AC Motor	Hamilton Sundstrand
939D128-4	AC Motor	Hamilton Sundstrand
939D150-2	Voltage Regulator	Hamilton Sundstrand
939D217-1	Voltage Regulator	Hamilton Sundstrand
939D228-2	AC Motor	Hamilton Sundstrand
939D228-4	AC Motor	Hamilton Sundstrand
939D259-3	AC Motor	Hamilton Sundstrand
939D259-5	AC Motor	Hamilton Sundstrand
940	External Power Protection Unit	Auxilec
940-1	External Power Protection Unit	Auxilec
9401037	Lightweight Motor Unit	FR Hitemp
9402006	Actuator	FR Hitemp
9404003	Motor assy	FR Hitemp
94-0500-00-00X	Water Tank	MAN Technologie
94-0501-00-000	Water Tank	MAN Technologie
94-0502-00-000	Water Tank	MAN Technologie
9406012	Actuator	FR Hitemp
9406021	Actuator	FR Hitemp
9406038	Actuator	FR Hitemp
9406054	Actuator	FR Hitemp
9406057	Actuator	FR Hitemp
9407001	Motor assy	FR Hitemp
940732	Hydraulic Motor Pump	Vickers
9409122	Flat Actuator	FR Hitemp
940A	External Power Protection Unit	Auxilec
940B	External Power Protection Unit	Auxilec
940D046-1	Exciter Stator	Hamilton Sundstrand
94-1-1100-01	Ram Air Actuator	Elektro Metall Exp.
941D335-2	Circuit Breaker	Hamilton Sundstrand
941D335-4	Circuit Breaker	Hamilton Sundstrand
941D339-1	Transformer	Hamilton Sundstrand
941D340-1	Transformer	Hamilton Sundstrand
941D342-2	AC Motor	Hamilton Sundstrand
941D347-2	Circuit Breaker	Hamilton Sundstrand
941D586-1	Exciter Armature	Hamilton Sundstrand
9-4-3100-3	Joystick	Elektro Metall Exp.
943D206-3	Power Relay	Hamilton Sundstrand
943D206-4	Power Relay	Hamilton Sundstrand
943D206-5	Power Relay	Hamilton Sundstrand
946B084-1	Adapter	Hamilton Sundstrand
946F177-1	Semi-Conductor	Hamilton Sundstrand
946F339-1	Exciter Stator	Hamilton Sundstrand
946F481-1	PMG Stator	Hamilton Sundstrand
946F489-1	Exciter Stator	Hamilton Sundstrand
946F960-1	Rotor	Hamilton Sundstrand
946F979-1	PM Stator	Hamilton Sundstrand
947	Audio Amplifier	Auxilec
94796-02	Lateral Shockmount	Barry Controls
94796-03	Lateral Shockmount	Barry Controls
94796-04	Lateral Shockmount	Barry Controls
94796-06	Torque Bar assy	Barry Controls
94796-07	Lateral Shockmount	Barry Controls
94796-10	Upper Shockmount	Barry Controls

Repair_Capability_List_Excel

947F006-1	Semi-Conductor	Hamilton Sundstrand
948A0100-01	Pressure Off Brake	Liebherr
949F283-1	Diode Stack	Hamilton Sundstrand
949F309-1	Rotor	Hamilton Sundstrand
9505000	Float Drain Valve	FR Hitemp
9505110	Drain Valve	FR Hitemp
9505265	Float Vent Valve	FR Hitemp
9505285	Float Drain Valve	FR Hitemp
9507080	Valve assy	FR Hitemp
9507305	Float Vent Valve	FR Hitemp
9507445	Float Vent Valve	FR Hitemp
9508170	Valve assy	FR Hitemp
9508175	Float Vent Valve	FR Hitemp
95150-01	Fire Control Unit	Liebherr Aerospace
95150-04	Fire Control Unit	Liebherr Aerospace
95280000106829A	Back-Up Ring	Sofrance
952800AA000PC0A	HP Hydraulic Filter	Sofrance
952800AB000PC0A	HP Hydraulic Filter	Sofrance
952801AA000PC0A	HP Hydraulic Filter	Sofrance
952801AB000PC0A	HP Hydraulic Filter	Sofrance
952A0100-01	Shaft Assembly	Liebherr Aerotechnik
952A0200-01	Shaft Assembly	Liebherr Aerotechnik
952C0100-01	Shaft Assembly	Goodrich Control Systems
952C0200-01	Shaft Assembly	Goodrich Control Systems
952D0100-01	Shaft Assembly	Goodrich Control Systems
952D0100-02	Shaft Assembly	Goodrich Control Systems
952D0200-01	Shaft Assembly	Goodrich Control Systems
9535251	Shuttle Valve	ABS
953A0000-01	Flap Control Unit	Liebherr Aerotechnik
953A0000-02	Flap Control Unit	Liebherr Aerotechnik
953A0000-04	Flap Control Unit	Liebherr Aerotechnik
953A0000-05	Flap Control Unit	Liebherr Aerotechnik
953A0000-06	Flap Control Unit	Liebherr Aerotechnik
953B0000-01	Flap Control Unit	Liebherr Aerotechnik
953B0000-02	Flap Control Unit	Liebherr Aerotechnik
9542717	Skid Control Box	Goodyear International Corp
9542718	Skid Control Valve	ABS
9542719	Wheel Driven Unit	ABS
9542719-1	Wheel Driven Unit	ABS
9542719-2	Wheel Driven Unit	ABS
9542719-3	Wheel Driven Unit	ABS
9543206	Valve assy	Goodyear International Corp
9544258	Lift Dumper Control Box	ABS
9544258-1	Lift Dumper Control Box	ABS
954A0000-01	Slat Actuator	Liebherr Aerotechnik
954A0000-02	Slat Actuator	Goodrich Control Systems
9550166730	Ignition Exciter	Hamilton Sundstrand
9550169260	Anti-Surge Valve	Hamilton Sundstrand
9550170900	Starter Motor	Hamilton Sundstrand
9560159730	Servo-Actuator assy	Moog Gmbh
9560160690	Oil Cooler	Hamilton Sundstrand
9560160700	Oil Cooler (Limco)	Hamilton Sundstrand
9560164910	Fuel Pump	Hamilton Sundstrand
9560169730	Servo-Actuator assy	Moog Gmbh
957A0000-02	Temperature Control Valve	Liebherr Aerotechnik
957A0000-02 Amdt A	Temperature Control Valve	Liebherr Aerotechnik
957B0000-01	Temperature Control Valve	Liebherr Aerotechnik
9589	Rain Repellent Filling Gage	Adams Rite

Repair_Capability_List_Excel

958A0000-02	By-Pass Valve	Liebherr Aerotechnik
958A0000-03	By-Pass Valve	Liebherr Aerotechnik
9590-1	Motor Brake	Hamilton Sundstrand
9590-5	Motor Brake	Hamilton Sundstrand
9590-6	Motor Brake	Hamilton Sundstrand
959A0000-01	Water Injector	Liebherr Aerotechnik
960500AA000PC0A	HP Filter assy	Sofrance
960503AA000PC0C	Filter	Sofrance
961-5023-001	Temperature Controller	Honeywell
961-5046-003	Controller	Honeywell
961-5046-004	Controller	Honeywell
961-5059-002	Controller	Hamilton Sundstrand
961596	Hydraulic Pump/Motor	Vickers
961627	Hydraulic Motor Pump	Vickers
961-7017-003	Temperature Controller	Hamilton Sundstrand
963A0000-02	Trim Air Valve	Liebherr Aerotechnik
963B0000-01	Trim Air Valve	Liebherr Aerotechnik
964-0076-004	Comparator	Hamilton Sundstrand
964A0000-03	Flow Control Valve	Liebherr Aerotechnik
964A0000-04	Flow Control Valve	Liebherr Aerotechnik
964A0000-05	Flow Control Valve	Liebherr Aerotechnik
964D100-1	Cargo Door Lift Latch Actuator	Eaton Aerospace
965-4020-003	AOA Sensor	Sundstrand
965-4020-006	AOA Sensor	Hamilton Sundstrand
965-4020-007	AOA Sensor	Hamilton Sundstrand
965A0000-02	Air Cycle Machine	Liebherr Aerospace
968034-1	Ignition Unit	Honeywell
968390-1	Swing Check Valve	Honeywell
968390-2	Swing Check Valve	Honeywell
968390-3	Swing Check Valve	Honeywell
968390-4	Swing Check Valve	Honeywell
9688-1-3	Faucet	Adams Rite
9688-3-3	Faucet	Adams Rite
969158-1	Oil Tank assy	Honeywell
969373-1	Ignition Unit	Honeywell
969-6019-001	Ice Detector Controller	Sundstrand
969822-11	Pump assy	Honeywell
96AT3F	Temperature Indicator	Honeywell
971-4193-001	Accelerometer	Honeywell
971-4193-002	Accelerometer	Honeywell
971533	Variable Disp.Electric Motorpump	Eaton
971600	Motor Pump assy	Eaton
971808	Variable Disp.Hydraulic Motorpump	Eaton
971844	Hydraulic Pump	Vickers
9719-1	Faucet assy	Adams Rite
971910	RAT Hydraulic Pump	Vickers
972424	Variable Displacement Hyd. Pump	Vickers
972630	Hydraulic Pump	Vickers
972A6-1	Check Valve	Intertechnique
972A8-2	Tank Vapor Relief Valve	Intertechnique
972C10-1	Shuttle Valve	Intertechnique
972C10-2	Shuttle Valve	Intertechnique
973122	Hydraulic Motorpump	Vickers
973600	Hydraulic Motor	Vickers
973930	RAT Hydraulic Pump	Vickers
973A4-1	Thermal Expansion Valve	Intertechnique
974014	Motor Pump assy	Eaton
974641	Reservoir Level Switch assy	Eaton

Repair_Capability_List_Excel

974848	Position Transmitter	Honeywell
974848-2	Position Transmitter	Honeywell
974947	Hydraulic Motor Pump	Vickers
974976	Hydraulic Pump	Vickers
974A0000-04	Air Plenum Chamber	Liebherr Aerotechnik
974A0000-05	Air Plenum Chamber	Liebherr Aerotechnik
974A0000-06	Air Plenum Chamber	Liebherr Aerotechnik
974B0000-01	Air Plenum Chamber	Liebherr Aerotechnik
974F582-4	External Power Control	Hamilton Sundstrand
975-0145-001	Compt Temperature Thermal Switch	Honeywell
975-0145-002	Compt Temperature Thermal Switch	Honeywell
975-0145-004	Compt Temperature Thermal Switch	Honeywell
975-0145-005	Compt Temperature Thermal Switch	Honeywell
975-0145-006	Compt Temperature Thermal Switch	Honeywell
975-0145-007	Compt Temperature Thermal Switch	Honeywell
975-0172-001	Thermal Switch	Honeywell
975-0172-003	Thermal Switch	Honeywell
975-0172-004	Thermal Switch	Honeywell
975-0172-005	Thermal Switch	Honeywell
975-0172-006	Thermal Switch	Honeywell
975-0172-007	Thermal Switch	Honeywell
975-0172-008	Thermal Switch	Honeywell
975-0172-009	Thermal Switch	Honeywell
975-0172-010	Thermal Switch	Honeywell
9756	Water Faucet assy	Adams Rite
9756-11	Water Faucet assy	Adams Rite
9756-1-1	Water Faucet assy	Adams Rite
9756-11-1	Water Faucet assy	Adams Rite
9756-11-3	Water Faucet assy	Adams Rite
9756-1-3	Water Faucet assy	Adams Rite
9756-15-1	Water Faucet assy	Adams Rite
9756-15-3	Water Faucet assy	Adams Rite
9756-17-1	Water Faucet assy	Adams Rite
9756-17-3	Water Faucet assy	Adams Rite
9756-19-1	Water Faucet assy	Adams Rite
9756-19-3	Water Faucet assy	Adams Rite
9756-21	Water Faucet assy	Adams Rite
9756-25	Water Faucet assy	Adams Rite
9756-25F	Water Faucet assy	Adams Rite
9756-27	Water Faucet assy	Adams Rite
9756-29	Water Faucet assy	Adams Rite
9756-3	Water Faucet assy	Adams Rite
9756-31	Water Faucet assy	Adams Rite
9756-3-1	Water Faucet assy	Adams Rite
9756-3-3	Water Faucet assy	Adams Rite
9756-7	Water Faucet assy	Adams Rite
9756-7-1	Water Faucet assy	Adams Rite
9756-7-3	Water Faucet assy	Adams Rite
9756-9	Water Faucet assy	Adams Rite
9756-9-1	Water Faucet assy	Adams Rite
9756-9-3	Water Faucet assy	Adams Rite
976087-1	Solenoid Valve	Honeywell
976087-1E	Solenoid Valve	Honeywell
976087-2	Solenoid Valve	Honeywell
976150-1	Centrigugal Multi-Switch ay	Honeywell
976150-1-1	Centrigugal Multi-Switch ay	Honeywell
976150-2	Centrigugal Multi-Switch ay	Honeywell
976150-2-1	Centrigugal Multi-Switch ay	Honeywell

Repair_Capability_List_Excel

976150-3	Centrigugal Multi-Switch ay	Honeywell
976150-4	Centrigugal Multi-Switch ay	Honeywell
976150-5	Centrigugal Multi-Switch ay	Honeywell
976372-1	Oil Tank assy	Honeywell
976372-2	Oil Tank assy	Honeywell
976560-2-1	Temperature Control Valve	Airesearch
976A0000-02	Ram Air Actuator	Liebherr Aerotechnik
976J118-11	AC Generator	Hamilton Sundstrand
976J118-8	AC Generator	Hamilton Sundstrand
976J119-11	AC Generator	Hamilton Sundstrand
976J119-12	AC Generator	Hamilton Sundstrand
976J119-8	AC Generator	Hamilton Sundstrand
976J186-3	Generator AC	Hamilton Sundstrand
976J186-4	Generator AC	Hamilton Sundstrand
976J252-3	AC Generator	Hamilton Sundstrand
976J252-6	AC Generator	Hamilton Sundstrand
976J252-7	AC Generator	Hamilton Sundstrand
976J252-8	AC Generator	Hamilton Sundstrand
976J254-4	Control Panel	Hamilton Sundstrand
976J255-4	AC Generator	Hamilton Sundstrand
976J366-2	AC Generator	Hamilton Sundstrand
976J449-1	AC Generator	Hamilton Sundstrand
976J497-1	AC Generator	Hamilton Sundstrand
976J498-1	AC Generator	Hamilton Sundstrand
976J498-1R	AC Generator	Hamilton Sundstrand
976J498-2	AC Generator	Hamilton Sundstrand
976J597-1	AC Generator	Hamilton Sundstrand
976J598-1	AC Generator	Hamilton Sundstrand
976J862-10	Panel Bus Control	Hamilton Sundstrand
976J862-12	Panel Bus Control	Hamilton Sundstrand
976J862-9	Panel Bus Control	Hamilton Sundstrand
976J863-10	AC Generator	Hamilton Sundstrand
976J863-7	AC Generator	Hamilton Sundstrand
976J889-3	Panel Bus Control	Hamilton Sundstrand
976J976-3	Stator	Hamilton Sundstrand
977166-1	Meter Totalizing	Honeywell
977550-002	Jack Electro Hydraulic	Goodrich Control Systems
977550-003	Jack Electro Hydraulic	Goodrich Control Systems
977550-004	Jack Electro Hydraulic	Goodrich Control Systems
977550-022	Jack Electro Hydraulic	Goodrich Control Systems
977550-023	Jack Electro Hydraulic	Goodrich Control Systems
977550-024	Jack Electro Hydraulic	Goodrich Control Systems
977759-24-1	Engine Starter	Honeywell
977759-6	Engine Starter	Honeywell
977759-9	Engine Starter	Honeywell
977961-2	Liquid Qty Transmitter	Honeywell
977J150-1	AC Generator	Hamilton Sundstrand
977J150-2	AC Generator	Hamilton Sundstrand
977J150-3	AC Generator	Hamilton Sundstrand
977J150-4	AC Generator	Hamilton Sundstrand
977J413-2	Stator	Hamilton Sundstrand
978514-10	Bleed Control Valve	Honeywell
978514-11	Bleed Control Valve	Honeywell
978514-12	Bleed Control Valve	Honeywell
978514-9	Bleed Control Valve	Honeywell
978558-1-1	Shut-Off Valve	Honeywell
978558-2-1	Shut-Off Valve	Honeywell
978560-2	Water Separator Temp.Cont.Valve	Honeywell

Repair_Capability_List_Excel

978560-2-1	Turbine By-Pass Control Valve	Honeywell
978560-5	Water Separator Temp.Cont.Valve	Honeywell
978560-5-1	Turbine By-Pass Control Valve	Honeywell
978560-6	Water Separator Temp.Cont.Valve	Honeywell
978620-5	Fan Air Valve	Honeywell
978620-6	Fan Air Valve	Honeywell
97862400-01	Power Supply	Liebherr Aerotechnik
978668-1	Shut-Off Valve	Honeywell
978668-1-1	Shut-Off Valve	Honeywell
978668-1-2	Shut-Off Valve	Honeywell
978668-1-3	Shut-Off Valve	Honeywell
978668-2	Shut-Off Valve	Honeywell
978668-3	Shut-Off Valve	Honeywell
978690-11	Bleed Control Valve	Honeywell
978692-1	Pneumatic Valve	Honeywell
978692-2	Overpressure Valve	Honeywell
978692-2-1	Overpressure Valve	Honeywell
978710-5	Fan Reverser Overpress. Shut-Off Valve	Honeywell
978710-6	Fan Reverser Overpress. Shut-Off Valve	Honeywell
978734-1	Valve assy	Honeywell
978734-2	Valve assy	Honeywell
978734-3	Valve assy	Honeywell
978734-4	Valve assy	Honeywell
978734-5	Valve assy	Honeywell
978820-2	Anti-Ice Valve	Honeywell
978820-3	Anti-Ice Valve	Honeywell
978820-4	Anti-Ice Valve	Honeywell
978820-5	Anti-Ice Valve	Honeywell
978820-6	Anti-Ice Valve	Honeywell
978840-3	Anti-Ice Valve	Honeywell
978840-4	Anti-Ice Valve	Honeywell
978842-1	Valve assy	Honeywell
978842-2	Valve assy	Honeywell
978842-3	Valve assy	Honeywell
978842-4	Valve assy	Honeywell
978844-4	ANTI ICE VALVE	HONEYWELL
978852-2	Fan Reverser Overpress. Shut-Off Valve	Honeywell
978852-3	Fan Reverser Overpress. Shut-Off Valve	Honeywell
978892-2	Bleed Control Valve	Honeywell
978892-3	Bleed Control Valve	Honeywell
978892-4	Bleed Control Valve	Honeywell
978892-5	Bleed Control Valve	Honeywell
978892-6	Bleed Control Valve	Honeywell
978A0000-07	Controller	Liebherr Aerospace
979070-10-1	Starter Shut-Off Valve	Honeywell
979070-1-1	Starter Shut-Off Valve	Honeywell
979070-11-1	Starter Shut-Off Valve	Honeywell
979070-12-1	Starter Shut-Off Valve	Honeywell
979070-2-1	Starter Shut-Off Valve	Honeywell
979070-3-1	Starter Shut-Off Valve	Honeywell
979070-4-1	Starter Shut-Off Valve	Honeywell
979070-5-1	Starter Shut-Off Valve	Honeywell
979070-6-1	Starter Shut-Off Valve	Honeywell
979070-7-1	Starter Shut-Off Valve	Honeywell
979070-8-1	Starter Shut-Off Valve	Honeywell
979070-9-1	Starter Shut-Off Valve	Honeywell
979078-1	Starter Shut-Off Valve	Honeywell
979078-10	Starter Shut-Off Valve	Honeywell

Repair_Capability_List_Excel

979078-10-1	Shut-Off Valve	Honeywell
979078-11	Starter Shut-Off Valve	Honeywell
979078-1-1	Shut-Off Valve	Honeywell
979078-11-1	Shut-Off Valve	Honeywell
979078-2	Starter Shut-Off Valve	Honeywell
979078-2-1	Shut-Off Valve	Honeywell
979078-3	Starter Shut-Off Valve	Honeywell
979078-3-1	Shut-Off Valve	Honeywell
979078-4	Starter Shut-Off Valve	Honeywell
979078-4-1	Shut-Off Valve	Honeywell
979078-5	Starter Shut-Off Valve	Honeywell
979078-6	Starter Shut-Off Valve	Honeywell
979078-7	Starter Shut-Off Valve	Honeywell
979078-8	Starter Shut-Off Valve	Honeywell
979078-8-1	Shut-Off Valve	Honeywell
979078-9	Starter Shut-Off Valve	Honeywell
979078-9-1	Shut-Off Valve	Honeywell
979102-1-1	Starter Shut-Off Valve	Honeywell
979102-2-1	Starter Shut-Off Valve	Honeywell
979102-3-1	Starter Shut-Off Valve	Honeywell
979102-4-1	Starter Shut-Off Valve	Honeywell
979102-5-1	Starter Shut-Off Valve	Honeywell
979102-6-1	Starter Shut-Off Valve	Honeywell
979102-7-1	Starter Shut-Off Valve	Honeywell
979102-8-1	Starter Shut-Off Valve	Honeywell
979114-1-1	Shut-Off Valve	Honeywell
979114-2-1	Shut-Off Valve	Honeywell
979142-6-1	Turbofan Shut-Off Valve	Honeywell
979146-1	Valve assy	Honeywell
979146-3	Valve assy	Honeywell
979146-4	Valve assy	Honeywell
979186-1	Fan Reverser Overpress. Shut-Off Valve	Honeywell
979188-1	Fan Reverser Overpress. Shut-Off Valve	Honeywell
979254-1-1	Shut-Off Valve	Honeywell
979254-2-1	Shut-Off Valve	Honeywell
979254-3-1	Shut-Off Valve	Honeywell
979254-4-1	Shut-Off Valve	Honeywell
979254-6-1	Shut-Off Valve	Honeywell
979254-8-1	Shut-Off Valve	Honeywell
979410-1-1	Shut-Off Valve	Honeywell
979410-2-1	Shut-Off Valve	Honeywell
979410-3-1	Shut-Off Valve	Honeywell
979410-4	Shut-Off Valve	Honeywell
979410-5	Shut-Off Valve	Honeywell
979410-6	Shut-Off Valve	Honeywell
979626-2	Shut-Off Valve	Honeywell
979626-2-1	Shut-Off Valve	Honeywell
979626-3	Shut-Off Valve	Honeywell
979626-3-1	Shut-Off Valve	Honeywell
979626-4	Shut-Off Valve	Honeywell
979626-4-1	Shut-Off Valve	Honeywell
979680-1-1	Temp. Control Valve	Honeywell
979786-1	4 1/2" Shut-off Valve	Honeywell
979786-2	4 1/2" Shut-off Valve	Honeywell
979788-1	Modulating Valve	Honeywell
979806-10	Surge Control Valve	Honeywell
979806-11	Surge Control Valve	Honeywell
979806-12	Surge Control Valve	Honeywell

Repair_Capability_List_Excel

979806-3-1	Surge Control Valve	Honeywell
979806-4-1	Surge Control Valve	Honeywell
979806-5-1	Surge Control Valve	Honeywell
979806-6-1	Surge Control Valve	Honeywell
979806-7	Surge Control Valve	Honeywell
979806-8	Surge Control Valve	Honeywell
979806-9	Surge Control Valve	Honeywell
979826-1	Pneumatic Butterfly Valve	Honeywell
979826-10	Pneumatic Butterfly Valve	Honeywell
979826-2	Pneumatic Butterfly Valve	Honeywell
979826-3	Pneumatic Butterfly Valve	Honeywell
979826-4	Pneumatic Butterfly Valve	Honeywell
979826-8	Pneumatic Butterfly Valve	Honeywell
979826-9	Pneumatic Butterfly Valve	Honeywell
979858-1	Starter Valve	Honeywell
979858-2	Starter Valve	Honeywell
979858-3	Starter Valve	Honeywell
979858-5	Valve assy	Honeywell
979990-1	Temperature Control Valve	Honeywell
97AT4B	Temperature Indicator	Honeywell
980-6109-001	Microphone Monitor	Honeywell
980-6109-002	Microphone Monitor	Honeywell
980-6109-003	Microphone Monitor	Honeywell
980-6109-004	Microphone Monitor	Honeywell
980-6109-005	Microphone Monitor	Honeywell
980-6109-006	Microphone Monitor	Honeywell
980-6109-007	Microphone Monitor	Honeywell
980-6109-008	Microphone Monitor	Honeywell
980-6109-009	Microphone Monitor	Honeywell
980-6109-010	Microphone Monitor	Honeywell
980-6109-011	Microphone Monitor	Honeywell
980-6109-012	Microphone Monitor	Honeywell
980-6109-013	Microphone Monitor	Honeywell
980-6109-014	Microphone Monitor	Honeywell
980-6109-015	Microphone Monitor	Honeywell
980-6109-016	Microphone Monitor	Honeywell
980-6109-017	Microphone Monitor	Honeywell
980-6109-018	Microphone Monitor	Honeywell
980-6109-019	Microphone Monitor	Honeywell
980-6109-020	Microphone Monitor	Honeywell
980-6109-021	Microphone Monitor	Honeywell
980-6109-022	Microphone Monitor	Honeywell
980-6109-023	Microphone Monitor	Honeywell
980-6109-024	Microphone Monitor	Honeywell
980-6109-025	Microphone Monitor	Honeywell
980-6109-026	Microphone Monitor	Honeywell
980-6109-027	Microphone Monitor	Honeywell
980-6109-028	Microphone Monitor	Honeywell
980-6109-029	Microphone Monitor	Honeywell
980-6109-030	Microphone Monitor	Honeywell
980-6109-031	Microphone Monitor	Honeywell
980-6109-032	Microphone Monitor	Honeywell
980A0000-01	Downstream Check Valve	Liebherr Aerotechnik
980B0000-02	Downstream Check Valve	Liebherr Aerotechnik
98111025	Check Valve	FR Hitemp
9811-11	Trim Air Valve Position Indicator	Litton Systems
9811-12	Flow Air Conditioning Pack Indicator	Litton Systems
9811760	Non-Return Valve	FR Hitemp

Repair_Capability_List_Excel

9811795	Check Valve	FR Hitemp
9811820	Check Valve	FR Hitemp
9811825	Non-Return Valve	FR Hitemp
9811827	Non-Return Valve	FR Hitemp
9811839	Non-Return Valve	FR Hitemp
9811950	Check Valve	FR Hitemp
9813200	Shuttle Valve	FR Hitemp
9813215	Shuttle Valve	FR Hitemp
9813395	Air Release Valve	FR Hitemp
9813445	Air Release Valve	FR Hitemp
9815715	Pressure Relief Valve	FR Hitemp
9815900	Vent Valve	FR Hitemp
982A0000-01	Trim Air Check Valve	Liebherr Aerotechnik
9840044	Non-Return Valve	FR Hitemp
9840044H	Non-Return Valve	FR Hitemp
9840098H	Non-Return Valve	FR Hitemp
9843144M	Check Valve	FR Hitemp
986A14-4	Ventilation Valve	Intertechnique
986F12-1	Check Valve	Intertechnique
989-10-01	Compass	Kollsman
9902-1	Electrical Motor	AVIAC
9958293-1	Light assy	Farwest
995CA01Y00	Power Relay	ECE
995CA01Y01	Power Relay	ECE
997305	Rudder Isolation Valve	Eaton
997635	Hydraulic Motorpump	Vickers
99C51330-1	Sequence Valve	Shimadzu
99C51330-3	Sequence Valve	Shimadzu
99C51330-5	Sequence Valve	Shimadzu
99C51330-7	Sequence Valve	Shimadzu
9BG400958-00	Housing	Hella
9BG408324-00	Chart Holder Control Unit	Hella
9EL404080-00	Lens Glass	Hella
9EL404081-00	Lens Glass	Hella
A0041017200000	Secondary Transmission	Airbus Industrie
A0041018000095	Throttle Control Microswitch Unit	Airbus Industrie
A0041018000195	Throttle Control Microswitch Unit	Airbus Industrie
A0041057500000	Reduction Gearbox	Airbus Industrie
A0041057500100	Reduction Gearbox	Airbus Industrie
A05000	Actuator	Westland-Sitec
A05A00	Actuator	Westland-Sitec
A05B00	Actuator	Westland-Sitec
A06000	Actuator	Westland-Sitec
A-0643-089A	Pump & Motor	Vickers
A-0643-089C	Pump & Motor	Vickers
A-0643-089D	Pump & Motor	Vickers
A-0643-089E	Pump & Motor	Vickers
A06A00	Actuator	Westland-Sitec
A06C00	Actuator	Westland-Sitec
A06D00	Actuator	Westland-Sitec
A06L00	Actuator	Westland-Sitec
A08000	Actuator	Westland-Sitec
A08900	Adapter assy	Westland-Sitec
A1077DD	Relay	CII Technologies
A1153-1A	Fwd Rod assy	NORCO
A1153-1B	Fwd Rod assy	NORCO
A1153-4	Aft Rod assy	NORCO
A1153-4A	Aft Rod assy	NORCO

Repair_Capability_List_Excel

A15406	Universal Joint	Mollart
A15407	Universal Joint	Mollart
A15460	Universal Joint	Mollart
A15460-4	Universal Joint	Mollart
A15460-5	Universal Joint	Mollart
A15461	Universal Joint	Mollart
A15461-3	Universal Joint	Mollart
A15461-4	Universal Joint	Mollart
A15463	Universal Joint	Mollart
A15532-P4	Clock	Philips Electronics
A155560	Universal Joint	Mollart
A155561	Universal Joint	Mollart
A15660-403	Spindle assy	Fokker
A15801	Clock	Philips Electronics
A-21	Thermometer	Edison
A2104001020000	Ventilation Valve	Airbus Industrie
A2104001020200	Spring Strut	Airbus Industrie
A2104001025000	Ventilation Valve	Airbus Industrie
A2104001025200	Spring Strut	Airbus Industrie
A2104001025400	Ventilation Valve	Airbus Industrie
A2113311500700	Door assy Access	Airbus Industrie
A21638	Brake Pedal Transmitter	Messier-Bugatti
A-23	Thermometer	Edison
A23312-1	Selector Valve	Messier-Bugatti
A23313-1	Selector Valve	Messier-Bugatti
A23313-101	Selector Valve	Messier-Bugatti
A2350-0048	Actuator	Circle Seal Controls
A-24	Thermometer	Edison
A-25	Thermometer	Edison
A25176090	Restrictor	Messier-Bugatti
A25199-0-2	Valve assy	Messier-Bugatti
A25199-0-3	Valve assy	Messier-Bugatti
A252400003	Selector	Messier-Bugatti
A25240003	Selector	Messier-Bugatti
A25240-1	Emergency Selector	Messier-Bugatti
A25240-2	Emergency Selector	Messier-Bugatti
A25270-0-2	Ground Door Control Valve	Messier-Bugatti
A25270-0-3	Ground Door Control Valve	Messier-Bugatti
A25270-4	Ground Door Control Valve	Messier-Bugatti
A25270-4C	Ground Door Control Valve	Messier-Bugatti
A25271	Sequence Valve	Messier - Bugatti
A25271-1	Sequence Valve	Messier-Bugatti
A25271-1-1	Sequence Valve	Messier-Bugatti
A25277-0-2	Air Vent Valve	Messier-Bugatti
A25279-1	Sequence Valve	Messier-Bugatti
A25280-1	Sequence Valve	Messier-Bugatti
A25285	Air Vent Valve	Messier-Bugatti
A25287005	Valve assy	Messier-Bugatti
A25287-2	Valve assy	Messier-Bugatti
A25287-3	Valve assy	Messier-Bugatti
A25287-3-1	Valve assy	Messier-Bugatti
A25287-3-2	Valve assy	Messier-Bugatti
A25287-4-1	Valve assy	Messier-Bugatti
A25287-4-2	Selector Valve	Messier-Bugatti
A25312	Throttle Valve	Messier-Bugatti
A25312-1	Throttle Valve	Messier-Bugatti
A25313	Brake Selector Valve	Messier-Bugatti
A25313002	Brake Selector Valve	Messier-Bugatti

Repair_Capability_List_Excel

A25313002-1	Brake Selector Valve	Messier-Bugatti
A25313003	Brake Selector Valve	Messier-Bugatti
A25313-1	Brake Selector Valve	Messier-Bugatti
A25313-101	Brake Selector Valve	Messier-Bugatti
A25314	Hydraulically Operated Brake Valve	Messier-Bugatti
A25314-1	Hydraulically Operated Brake Valve	Messier-Bugatti
A25315	Parking Brake Valve	Messier-Bugatti
A25315020	Parking Brake Valve	Messier-Bugatti
A25315020-1	Parking Brake Valve	Messier-Bugatti
A25315-1	Parking Brake Valve	Messier-Bugatti
A25316	Shuttle Valve	Messier-Bugatti
A25316020	Dual Shuttle Valve	Messier-Bugatti
A25316-1	Shuttle Valve	Messier-Bugatti
A25316-101	Shuttle Valve	Messier-Bugatti
A25317	Safety Valve	Messier-Bugatti
A25317-1	Safety Valve	Messier-Bugatti
A25319-1	Swivel Fitting	Messier-Bugatti
A25323002	Dual Swivel Fitting	Messier-Dowty
A25323-1	Dual Swivel Fitting	Messier-Dowty
A25375004	Coupling Unit	Messier-Bugatti
A25375004-1	Coupling Unit	Messier-Bugatti
A25375011	Coupler	Messier-Bugatti
A25375014	Coupling Unit	Messier-Bugatti
A25375-1	Coupling Unit	Messier-Bugatti
A25375-101	Coupling Unit	Messier-Bugatti
A25375-2	Coupling Unit	Messier-Bugatti
A25375-201	Coupling Unit	Messier-Bugatti
A25421001	Uplock assy	Messier-Bugatti
A25421001-1	Uplock assy	Messier-Bugatti
A25421001-2	Uplock assy	Messier-Bugatti
A25421-0-1	Uplock assy	Messier-Bugatti
A25421-0-2	Uplock assy	Messier-Bugatti
A25421-0-3	Uplock assy	Messier-Bugatti
A25421-4	Uplock assy	Messier-Bugatti
A25421-5	Uplock assy	Messier-Bugatti
A25431-0	Uplock assy	Messier-Bugatti
A25431001	Uplock assy	Messier-Bugatti
A25431001-1	Uplock assy	Messier-Bugatti
A25431001-2	Uplock assy	Messier-Bugatti
A25431-0-1	Uplock assy	Messier-Bugatti
A25431-0-2	Uplock assy	Messier-Bugatti
A25431-3	Uplock assy	Messier-Bugatti
A25431-4	Uplock assy	Messier-Bugatti
A25434005-1	Valve assy	Messier-Bugatti
A25434005-2	Valve assy	Messier-Bugatti
A25434005-3	Valve assy	Messier-Bugatti
A25434005-4	Valve assy	Messier-Bugatti
A25434006	Valve assy	Messier-Bugatti
A25434006-1	Valve assy	Messier-Bugatti
A25434006-2	Valve assy	Messier-Bugatti
A25434006-2A	Valve assy	Messier-Bugatti
A25434006-3	Valve assy	Messier-Bugatti
A25434020	Brake Valve	Messier-Bugatti
A25434021	Brake Valve	Messier-Bugatti
A25434021-001	Brake Valve	Messier-Bugatti
A25434021-1	Brake Valve	Messier-Bugatti
A25434021-2	Brake Valve	Messier-Bugatti
A25434-202	Distribution Valve	Messier-Bugatti

Repair_Capability_List_Excel

A25434-203	Distribution Valve	Messier-Bugatti
A25434-204	Distribution Valve	Messier-Bugatti
A25434-205	Distribution Valve	Messier-Bugatti
A25434-2-1	Distribution Valve	Messier-Bugatti
A25434-2-100	Distribution Valve	Messier-Bugatti
A25434-2-200	Distribution Valve	Messier-Bugatti
A25434-2-300	Distribution Valve	Messier-Bugatti
A25434-2-400	Distribution Valve	Messier-Bugatti
A25434-2-500	Distribution Valve	Messier-Bugatti
A25434-3	Distribution Valve	Messier-Bugatti
A25434-3-001	Distribution Valve	Messier-Bugatti
A25434-301	Distribution Valve	Messier-Bugatti
A25434-302	Distribution Valve	Messier-Bugatti
A25434-3-100	Distribution Valve	Messier-Bugatti
A25434-3-200	Distribution Valve	Messier-Bugatti
A25434-4	Distribution Valve	Messier-Bugatti
A25434-4-001	Distribution Valve	Messier-Bugatti
A25434-401	Distribution Valve	Messier-Bugatti
A25434-402	Distribution Valve	Messier-Bugatti
A25434-403	Distribution Valve	Messier-Bugatti
A25434-404	Distribution Valve	Messier-Bugatti
A25434-4-100	Distribution Valve	Messier-Bugatti
A25434-4-200	Distribution Valve	Messier-Bugatti
A25434-4-300	Distribution Valve	Messier-Bugatti
A25434-4-400	Distribution Valve	Messier-Bugatti
A25441	MLG Door Uplock assy	Messier-Bugatti
A25441-0	MLG Door Uplock assy	Messier-Bugatti
A25441001	MLG Uplock assy	Messier-Bugatti
A25441001-1	MLG Uplock assy	Messier-Bugatti
A25441001-2	MLG Uplock assy	Messier-Bugatti
A25441-0-1	MLG Door Uplock assy	Messier-Bugatti
A25441-0-2	MLG Door Uplock assy	Messier-Bugatti
A25441-3	MLG Door Uplock assy	Messier-Bugatti
A25441-4	MLG Door Uplock assy	Messier-Bugatti
A25441-5	MLG Door Uplock assy	Messier-Bugatti
A25451001	MLG Uplock assy	Messier-Bugatti
A25451001-1	MLG Uplock assy	Messier-Bugatti
A25451001-2	MLG Uplock assy	Messier-Bugatti
A25451001-3	MLG Uplock assy	Messier-Bugatti
A25451002-1	MLG Uplock assy	Messier-Bugatti
A25451002-2	MLG Uplock assy	Messier-Bugatti
A25451002-3	MLG Uplock assy	Messier-Bugatti
A25451-0-1	MLG Uplock assy	Messier-Bugatti
A25451-0-3	MLG Uplock assy	Messier-Bugatti
A25451-0-4	MLG Uplock assy	Messier-Bugatti
A25451-5	MLG Uplock assy	Messier-Bugatti
A25451-6	MLG Uplock assy	Messier-Bugatti
A25451-7	MLG Uplock assy	Messier-Bugatti
A25452001	MLG Uplock assy	Messier-Bugatti
A25452001-1	MLG Uplock assy	Messier-Bugatti
A25452001-2	MLG Uplock assy	Messier-Bugatti
A25452001-3	MLG Uplock assy	Messier-Bugatti
A25452002-1	MLG Uplock assy	Messier-Bugatti
A25452002-2	MLG Uplock assy	Messier-Bugatti
A25452002-3	MLG Uplock assy	Messier-Bugatti
A25452-0-1	MLG Uplock assy	Messier-Bugatti
A25452-0-3	MLG Uplock assy	Messier-Bugatti
A25452-0-4	MLG Uplock assy	Messier-Bugatti

Repair_Capability_List_Excel

A25452-5	MLG Uplock assy	Messier-Bugatti
A25452-6	MLG Uplock assy	Messier-Bugatti
A25452-7	MLG Uplock assy	Messier-Bugatti
A25453001	MLG Uplock assy	Messier-Bugatti
A25453001-1	MLG Uplock assy	Messier-Bugatti
A25453001-2	MLG Uplock assy	Messier-Bugatti
A25453-0-3	MLG Uplock assy	Messier-Bugatti
A25453-0-4	MLG Uplock assy	Messier-Bugatti
A25453-5	MLG Uplock assy	Messier-Bugatti
A25453-6	MLG Uplock assy	Messier-Bugatti
A25453-7	MLG Uplock assy	Messier-Bugatti
A25454001	MLG Uplock assy	Messier-Bugatti
A25454001-1	MLG Uplock assy	Messier-Bugatti
A25454001-2	MLG Uplock assy	Messier-Bugatti
A25454-0-3	MLG Uplock assy	Messier-Bugatti
A25454-0-4	MLG Uplock assy	Messier-Bugatti
A25454-5	MLG Uplock assy	Messier-Bugatti
A25454-6	MLG Uplock assy	Messier-Bugatti
A25454-7	MLG Uplock assy	Messier-Bugatti
A25460-2	Automatic Selector	Messier-Bugatti
A25461020-1	Automatic Selector	Messier-Bugatti
A25461020-2	Automatic Selector	Messier-Bugatti
A25461-1	Automatic Selector	Messier-Bugatti
A25461-102	Automatic Selector	Messier-Bugatti
A25461-103	Automatic Selector	Messier-Bugatti
A25461-103A	Automatic Selector	Messier-Bugatti
A25461-104	Automatic Selector	Messier-Bugatti
A25461-1-1	Automatic Selector	Messier-Bugatti
A25474	Restrictor	Messier-Bugatti
A2557052000000	Valve	Airbus Industrie
A2577020000800	X-Latch Automatic	Airbus Industrie
A2577020001200	X-Latch Automatic	Airbus Industrie
A2577020001600	X-Latch Automatic	Airbus Industrie
A2577020002400	X-Latch Automatic	Airbus Industrie
A2577020002800	X-Latch Automatic	Airbus Industrie
A2577040500600	YZ-Latch Automatic	Airbus Industrie
A2577040500800	YZ-Latch Automatic	Airbus Industrie
A2577040501200	YZ-Latch Automatic	Airbus Industrie
A2577040501400	YZ-Latch Automatic	Airbus Industrie
A2577040501600	YZ-Latch Automatic	Airbus Industrie
A2577040501800	YZ-Latch Automatic	Airbus Industrie
A2577050500400	Y-Guide Retractable	Airbus Industrie
A2577050500600	Y-Guide Retractable	Airbus Industrie
A2577050500800	Y-Guide Retractable	Airbus Industrie
A2577050501000	Y-Guide Retractable	Airbus Industrie
A2577050501200	Y-Guide Retractable	Airbus Industrie
A2577050501400	Y-Guide Retractable	Airbus Industrie
A2577050501600	Y-Guide Retractable	Airbus Industrie
A2577050501800	Y-Guide Retractable	Airbus Industrie
A2577050502000	Y-Guide Retractable	Airbus Industrie
A2577050502200	Y-Guide Retractable	Airbus Industrie
A2577050502400	Y-Guide Retractable	Airbus Industrie
A2577050502800	Y-Guide Retractable	Airbus Industrie
A2577050503000	Y-Guide Retractable	Airbus Industrie
A2577050503200	Y-Guide Retractable	Airbus Industrie
A2577050503400	Y-Guide Retractable	Airbus Industrie
A2577050503600	Y-Guide Retractable	Airbus Industrie
A2577055500200	Automatic Door Sill Latch	Airbus Industrie

Repair_Capability_List_Excel

A2577055500400	Automatic Door Sill Latch	Airbus Industrie
A2577055500800	Automatic Door Sill Latch	Airbus Industrie
A2577055501000	Automatic Door Sill Latch	Airbus Industrie
A2577056900000	Door Sill Latch Servo Mechanism	Airbus Industrie
A2577056900200	Door Sill Latch Servo Mechanism	Airbus Industrie
A2577056900400	Door Sill Latch Servo Mechanism	Airbus Industrie
A2577060600600	Y-Guide Movable	Airbus Industrie
A2577061600000	Track assy Guide	Airbus Industrie
A2577061600200	Track assy Guide	Airbus Industrie
A2577061600400	Track assy Guide	Airbus Industrie
A2577064000000	Retractable Door Sill Guide	Airbus Industrie
A2577064000200	Retractable Door Sill Guide	Airbus Industrie
A2577064000400	Retractable Door Sill Guide	Airbus Industrie
A2577064000651	Retractable Door Sill Guide	Airbus Industrie
A2577064000652	Retractable Door Sill Guide	Airbus Industrie
A2577064000800	Retractable Door Sill Guide	Airbus Industrie
A2577064001000	Retractable Door Sill Guide	Airbus Industrie
A2577064001200	Retractable Door Sill Guide	Airbus Industrie
A2577064001400	Retractable Door Sill Guide	Airbus Industrie
A2577070600400	YZ-Latch Retractable	Airbus Industrie
A2577070600600	YZ-Latch Retractable	Airbus Industrie
A2577070600800	YZ-Latch Retractable	Airbus Industrie
A2577070601000	YZ-Latch Retractable	Airbus Industrie
A2577074100000	XY Guide assy	Airbus Industrie
A2577074100001	XY Guide assy	Airbus Industrie
A2577074100200	XY Guide assy	Airbus Industrie
A2577074100400	XY Guide assy	Airbus Industrie
A2577074100600	XY Guide assy	Airbus Industrie
A2577074100800	XY Guide assy	Airbus Industrie
A2577075200200	Y-Guide Movable	Airbus Industrie
A2577075200400	Y-Guide Movable	Airbus Industrie
A2577075200600	Y-Guide Movable	Airbus Industrie
A2577075200800	Y-Guide Movable	Airbus Industrie
A2577075201000	Y-Guide Movable	Airbus Industrie
A2577075201200	Y-Guide Movable	Airbus Industrie
A2577080601800	YZ-Latch Fixed	Airbus Industrie
A2577080700000	YZ-Latch Fixed	Airbus Industrie
A2577080700200	YZ-Latch Fixed	Airbus Industrie
A2577083600400	Guide Inlet	Airbus Industrie
A2577083600600	Guide assy XY Inlet	Airbus Industrie
A2577083600800	Guide assy XY Inlet	Airbus Industrie
A2577083601000	Guide assy XY Inlet	Airbus Industrie
A2577083601200	Guide assy XY Inlet	Airbus Industrie
A2577083601600	Guide assy XY Inlet	Airbus Industrie
A2577092500000	Pallet Stop assy	Airbus Industrie
A2577092500200	Pallet Stop assy	Airbus Industrie
A2577092500400	Pallet Stop assy	Airbus Industrie
A2577110200000	Latch Door Sill	Airbus Industrie
A2577110200200	Latch Door Sill	Airbus Industrie
A2577110200400	Latch Door Sill	Airbus Industrie
A2577110200600	Latch Door Sill	Airbus Industrie
A2577110200800	Door Sill Latch	Airbus Industrie
A2577110201000	Latch Door Sill	Airbus Industrie
A2577110201200	Latch Door Sill	Airbus Industrie
A2577110201400	Latch Door Sill	Airbus Industrie
A2577110201600	Latch Door Sill	Airbus Industrie
A2577110201800	Door Sill Latch	Airbus Industrie
A2577110202000	Latch Door Sill	Airbus Industrie

Repair_Capability_List_Excel

A2577110202200	Latch Door Sill	Airbus Industrie
A2577110202400	Door Sill Latch	Airbus Industrie
A2577110202600	Latch Door Sill	Airbus Industrie
A2577110202800	Latch Door Sill	Airbus Industrie
A2577110203000	Latch Door Sill	Airbus Industrie
A2577110203200	Latch Door Sill	Airbus Industrie
A2577110203400	Door Sill Latch	Airbus Industrie
A2577110203455	Door Sill Latch	Airbus Industrie
A2577110203456	Door Sill Latch	Airbus Industrie
A2577110203457	Door Sill Latch	Airbus Industrie
A2577110203458	Door Sill Latch	Airbus Industrie
A2577110203459	Door Sill Latch	Airbus Industrie
A2577110203600	Latch Door Sill	Airbus Industrie
A2577110203800	Latch Door Sill	Airbus Industrie
A2577110204000	Latch Door Sill	Airbus Industrie
A2577110301000	Door Sill Latch	Airbus Industrie
A2577110302000	Door Sill Latch	Airbus Industrie
A2577110302054	Door Sill Latch	Airbus Industrie
A2577110302055	Door Sill Latch	Airbus Industrie
A2577110302056	Door Sill Latch	Airbus Industrie
A2577110302057	Door Sill Latch	Airbus Industrie
A2577110302058	Door Sill Latch	Airbus Industrie
A2577110302800	Door Sill Latch	Airbus Industrie
A2577110304000	Door Sill Latch	Airbus Industrie
A2577110305400	Door Sill Latch	Airbus Industrie
A2577110306000	Door Sill Roller assy	Airbus Industrie
A2577110306200	Door Sill Roller assy	Airbus Industrie
A2577110400400	Automatic Door Sill Latch	Airbus Industrie
A2577110400600	Automatic Door Sill Latch	Airbus Industrie
A2577148300000	Overrideable YZ Latch	Airbus Industrie
A2577148300200	Overrideable YZ Latch	Airbus Industrie
A2577148300400	Overrideable YZ Latch	Airbus Industrie
A2577148300600	Overrideable YZ Latch	Airbus Industrie
A2577148300800	Overrideable YZ Latch	Airbus Industrie
A2577156100000	Door Sill Latch Servo Mechanism	Airbus Industrie
A2577156100200	Door Sill Latch Servo Mechanism	Airbus Industrie
A2577253800600	Guide	Airbus Industrie
A2577253801000	Guide	Airbus Industrie
A2577253801200	Guide	Airbus Industrie
A2577253801400	XY Guide assy	Airbus Industrie
A2577254000400	Roller Sill	Airbus Industrie
A2577254900000	Pulley Deflection assy	Airbus Industrie
A2577254900200	Pulley Deflection assy	Airbus Industrie
A2577254900400	Pulley Deflection assy	Airbus Industrie
A2577255400200	Automatic Door Sill Latch	Airbus Industrie
A2577256000452	Actuator Unit	Airbus Industrie
A2577256000651	Actuator Unit	Airbus Industrie
A2577276500000	Actuator Unit	Airbus Industrie
A2577276500200	Actuator Unit	Airbus Industrie
A2577285000600	Y-Guide	Airbus Industrie
A2577300500000	Door Sill Protection	Airbus Industrie
A2577300500200	Door Sill Protection	Airbus Industrie
A2577300500600	Door Sill Protection	Airbus Industrie
A2577300500800	Door Sill Protection	Airbus Industrie
A2577300501000	Door Sill Protection	Airbus Industrie
A2577300501200	Door Sill Protection	Airbus Industrie
A2577333400000	Ball Mats	Airbus Industrie
A2577333400400	Ball Mats	Airbus Industrie

Repair_Capability_List_Excel

A2577333400800	Ball Mats	Airbus Industrie
A2577333500000	Ball Mats	Airbus Industrie
A2577333500400	Ball Mats	Airbus Industrie
A2577333500800	Ball Mats	Airbus Industrie
A2577333600000	Ball Mats	Airbus Industrie
A2577333700000	Ball Mats	Airbus Industrie
A2577333700200	Ball Mats	Airbus Industrie
A2577333700600	Ball Mats	Airbus Industrie
A2577333701800	Ball Mats	Airbus Industrie
A2577333702000	Ball Mats	Airbus Industrie
A2577333702200	Ball Mats	Airbus Industrie
A2577333703200	Ball Mats	Airbus Industrie
A2577333703400	Ball Mats	Airbus Industrie
A2577333703600	Ball Mats	Airbus Industrie
A2577333703800	Ball Mats	Airbus Industrie
A2577333704400	Ball Mats	Airbus Industrie
A2577333704600	Ball Mats	Airbus Industrie
A2577333800000	Ball Mats	Airbus Industrie
A2577333800400	Ball Mats	Airbus Industrie
A2577333800800	Ball Mats	Airbus Industrie
A2577333900000	Ball Mats	Airbus Industrie
A2577333900400	Ball Mats	Airbus Industrie
A2577333900800	Ball Mats	Airbus Industrie
A2577335100400	Swivel Roller Mat assy	Airbus Industrie
A2577335100600	Swivel Roller Mat assy	Airbus Industrie
A2577335100800	Swivel Roller Mat assy	Airbus Industrie
A2577335101000	Swivel Roller Mat assy	Airbus Industrie
A2577335101200	Swivel Roller Mat assy	Airbus Industrie
A2577335102000	Swivel Roller Mat assy	Airbus Industrie
A2577335102400	Swivel Roller Mat assy	Airbus Industrie
A2577335102600	Swivel Roller Mat assy	Airbus Industrie
A2577337100000	Latch YZ	Airbus Industrie
A2577337100400	Latch YZ	Airbus Industrie
A2577339000000	Loading Bridge	Airbus Industrie
A2577339000200	Loading Bridge	Airbus Industrie
A2577339000800	Loading Bridge	Airbus Industrie
A2577339001000	Loading Bridge	Airbus Industrie
A2577339001200	Loading Bridge	Airbus Industrie
A2577339001400	Loading Bridge	Airbus Industrie
A2577339001600	Loading Bridge	Airbus Industrie
A2577339001800	Loading Bridge	Airbus Industrie
A2577339002000	Loading Bridge	Airbus Industrie
A2577339002200	Loading Bridge	Airbus Industrie
A2577339002400	Loading Bridge	Airbus Industrie
A2577339002600	Loading Bridge	Airbus Industrie
A2577346500000	Splitter assy	Airbus Industrie
A2577346500100	Splitter assy	Airbus Industrie
A2577346500200	Splitter assy	Airbus Industrie
A2577346500400	Splitter assy	Airbus Industrie
A2577346500600	Splitter assy	Airbus Industrie
A2577346502000	Splitter assy	Airbus Industrie
A2577346502200	Splitter assy	Airbus Industrie
A2577346502600	Splitter assy	Airbus Industrie
A2577346503200	Splitter assy	Airbus Industrie
A2577349000200	Ball Mats	Airbus Industrie
A2577349000600	Ball Mats	Airbus Industrie
A2577349001000	Ball Mats	Airbus Industrie
A2577350000000	Door Frame Protection assy	Airbus Industrie

Repair_Capability_List_Excel

A2587005	Selector Valve	Messier-Bugatti
A2701022500001	Bellcrank assy	Airbus Industrie
A2701029000100	Adjusting Actuator assy	Airbus Industrie
A2701029000151	Pedal Position Adjuster	Airbus Industrie
A2701029000551	Pedal Position Adjuster	Airbus Industrie
A27010300000C01	Pedal assy	Airbus Industrie
A27010300001C01	Pedal assy	Airbus Industrie
A27010300002E01	Pedal assy	Airbus Industrie
A27010300003E01	Pedal assy	Airbus Industrie
A2711030000000	Spring Rod	Airbus Industrie
A2711-1	Cowl Hold Open Rod	Norco
A2711-10	Cowl Hold Open Rod	Norco
A2711-11	Cowl Hold Open Rod	Norco
A2711-15	Cowl Hold Open Rod	Norco
A2711-16	Cowl Hold Open Rod	Norco
A2711-17	Cowl Hold Open Rod	Norco
A2711-2	Cowl Hold Open Rod	Norco
A2711208800001	Adjustable Crank assy	Airbus Industrie
A2711208800101	Adjustable Crank assy	Airbus Industrie
A2711-3	Cowl Hold Open Rod	Norco
A2711-4	Cowl Hold Open Rod	Norco
A2711-5	Cowl Hold Open Rod	Norco
A2711-6	Cowl Hold Open Rod	Norco
A2711-7	Cowl Hold Open Rod	Norco
A2711-8	Cowl Hold Open Rod	Norco
A2711-9	Cowl Hold Open Rod	Norco
A2714007800000	Aileron Gearbox assy	Airbus Industrie
A2714007800200	Aileron Trim Gearbox	Airbus Industrie
A2714011402800	Lockout ay Low Speed Aileron	Airbus Industrie
A2714011402900	Lockout ay Low Speed Aileron	Airbus Industrie
A2714011403000	Lockout ay Low Speed Aileron	Airbus Industrie
A2714011403100	Lockout ay Low Speed Aileron	Airbus Industrie
A2714015600000	Aileron Trim Jack	Airbus Industrie
A2714028009000	Differential Droop & Mechanism ay	Airbus Industrie
A2714028009100	Differential Droop & Mechanism ay	Airbus Industrie
A2714038600200	Load Limiting Spoiler Strut assy	Airbus Industrie
A2714038610000	Load Limiting Spoiler Strut assy	Airbus Industrie
A2714043600200	Load Limit Aileron Trim Strut assy	Airbus Industrie
A2714070000200	Non-Linear Gearing Unit	Airbus Industrie
A2714070000300	Non-Linear Gearing Unit	Airbus Industrie
A2714073801200	Detent assy	Airbus Industrie
A2714073801260	Detent assembly	Airbus Industrie
A2714073801300	Detent assy	Airbus Industrie
A2714073801500	Detent assy	Airbus Industrie
A2714073801600	Detent assy	Airbus Industrie
A2714073801700	Detent assy	Airbus Industrie
A2714073801800	Detent assy	Airbus Industrie
A2714073801900	Detent assy	Airbus Industrie
A2714073802000	Detent assy	Airbus Industrie
A2714073802100	Detent assy	Airbus Industrie
A2714074502400	Spoiler Drive Cam	Airbus Industrie
A2714074502500	Spoiler Drive Cam	Airbus Industrie
A2714074502600	Spoiler Drive Cam	Airbus Industrie
A2714074502700	Spoiler Drive Cam	Airbus Industrie
A2714074502800	Spoiler Drive Cam	Airbus Industrie
A2714074502900	Spoiler Drive Cam	Airbus Industrie
A2714074505000	Spoiler Drive Cam	Airbus Industrie
A2714074505100	Spoiler Drive Cam	Airbus Industrie

Repair_Capability_List_Excel

A2714078105000	Strut assy Spring	Airbus Industrie
A2714090600400	Spring Strut assy	Airbus Industrie
A2714090610000	Spring Strut assy	Airbus Industrie
A2714092300600	Aileron Autopilot Detent ay	Airbus Industrie
A2714092301000	Aileron Autopilot Detent ay	Airbus Industrie
A2714092301200	Aileron Autopilot Detent ay	Airbus Industrie
A2714092310000	Aileron Autopilot Detent ay	Airbus Industrie
A2714092310200	Aileron Autopilot Detent ay	Airbus Industrie
A2714097000000	Strut Spring	Airbus Industrie
A2714098100000	Strut assy Spring	Airbus Industrie
A2714103000000	Differential Droop & Mechanism ay	Airbus Industrie
A2714103000100	Differential Droop & Mechanism ay	Airbus Industrie
A2714103000200	Differential Droop & Mechanism ay	Airbus Industrie
A2714103000300	Differential Droop & Mechanism ay	Airbus Industrie
A2714103000400	Differential Droop & Mechanism ay	Airbus Industrie
A2714103000500	Differential Droop & Mechanism ay	Airbus Industrie
A2714103000600	Differential Droop & Mechanism ay	Airbus Industrie
A2714103000700	Differential Droop & Mechanism ay	Airbus Industrie
A2714103000800	Differential Droop & Mechanism ay	Airbus Industrie
A2714103000900	Differential Droop & Mechanism ay	Airbus Industrie
A2714103001000	Differential Droop & Mechanism ay	Airbus Industrie
A2714103001100	Differential Droop & Mechanism ay	Airbus Industrie
A2714103001200	Differential Droop & Mechanism ay	Airbus Industrie
A2714103001300	Differential Droop & Mechanism ay	Airbus Industrie
A2714103001400	Differential Droop & Mechanism ay	Airbus Industrie
A2714103001500	Differential Droop & Mechanism ay	Airbus Industrie
A2714103001600	Differential Droop & Mechanism ay	Airbus Industrie
A2714103001700	Differential Droop & Mechanism ay	Airbus Industrie
A2714103010000	Differential Droop & Mechanism ay	Airbus Industrie
A2714103010100	Differential Droop & Mechanism ay	Airbus Industrie
A2717034000000	Differential and Droop Unit	Airbus Industrie
A2717034000100	Differential and Droop Unit	Airbus Industrie
A2717034000400	Differential and Droop Unit	Airbus Industrie
A2717040500000	Artificial Feel Unit	Airbus Industrie
A2717045000000	Spring Rod	Airbus Industrie
A2717062000000	Layshaft assy	Airbus Industrie
A2717062000100	Layshaft assy	Airbus Industrie
A2717062000200	Layshaft assy	Airbus Industrie
A2717062000300	Layshaft assy	Airbus Industrie
A2717067000000	Bellcrank Lever assy	Airbus Industrie
A2717067000100	Bellcrank Lever assy	Airbus Industrie
A2717067000200	Bellcrank Lever assy	Airbus Industrie
A2717067000300	Bellcrank Lever assy	Airbus Industrie
A2717068000000	Adjustement Lever assy	Airbus Industrie
A2717068000100	Adjustement Lever assy	Airbus Industrie
A2717068000200	Adjustement Lever assy	Airbus Industrie
A2717068000300	Adjustement Lever assy	Airbus Industrie
A2717070200000	ASA Trim Gear assy	Airbus Industrie
A2717070200100	ASA Trim Gear assy	Airbus Industrie
A2717070200200	ASA Trim Gear assy	Airbus Industrie
A2717070200300	ASA Trim Gear assy	Airbus Industrie
A2717082000000	Autopilot Detent Unit	Airbus Industrie
A2717082000200	Autopilot Detent Unit	Airbus Industrie
A2717094500600	ASA Pulley Bracket	Airbus Industrie
A2717094500700	ASA Pulley Bracket	Airbus Industrie
A2717106000000	Differential and Droop Unit	Airbus Industrie
A2717106000100	Differential and Droop Unit	Airbus Industrie
A2717106000200	Differential and Droop Unit	Airbus Industrie

Repair_Capability_List_Excel

A2717106000300	Differential and Droop Unit	Airbus Industrie
A2717112000200	Artificial Feel Unit	Airbus Industrie
A2717117500000	Artificial Feel Unit	Airbus Industrie
A2717122000200	Support and Lever assy	Airbus Industrie
A2717122000300	Support and Lever assy	Airbus Industrie
A2717125000051	Bellcrank assy	Airbus Industrie
A2717125000151	Bellcrank assy	Airbus Industrie
A2717127000000	Lever assy	Airbus Industrie
A2717127000100	Lever assy	Airbus Industrie
A2717127000200	Lever assy	Airbus Industrie
A2717127000300	Lever assy	Airbus Industrie
A2717131500000	Autopilot Detent Unit	Airbus Industrie
A2717140500600	Droop Lever assy	Airbus Industrie
A2717140500700	Droop Lever assy	Airbus Industrie
A271A010101	Manometric Switch	Liebherr Aerotechnik
A27210000000B01	Set of Pedals	Airbus Industrie
A27210000000B02	Set of Pedals	Airbus Industrie
A27210000000C01	Set of Pedals	Airbus Industrie
A27210000000C02	Set of Pedals	Airbus Industrie
A27210000000C04	Set of Pedals	Airbus Industrie
A27210000000Z01	Set of Pedals	Airbus Industrie
A27210000000Z02	Set of Pedals	Airbus Industrie
A27210000002C01	Set of Pedals	Airbus Industrie
A27210000002C04	Set of Pedals	Airbus Industrie
A2721007000100	Pedal Position Adjuster	Airbus Industrie
A2727022604800	Rod-assy	Airbus Industrie
A2727029000000	Torque Shaft	Airbus Industrie
A2727032500251	Rudder Control Frame assy	Airbus Industrie
A2727032500451	Rudder Control Frame assy	Airbus Industrie
A2727032500651	Rudder Control Frame assy	Airbus Industrie
A2727032500851	Rudder Control Frame assy	Airbus Industrie
A2727032501051	Rudder Control Frame assy	Airbus Industrie
A2727032501251	Rudder Control Frame assy	Airbus Industrie
A2727032501270	Rudder Control Frame assy	Airbus Industrie
A2727032501451	Rudder Control Frame assy	Airbus Industrie
A2727032501651	Rudder Control Frame assy	Airbus Industrie
A2727050000200	Artificial Feel & Trim Unit	Airbus Industrie
A2727050000400	Artificial Feel & Trim Unit	Airbus Industrie
A2727065100000	Angle Drive Gearbox	Airbus Industrie
A2727067500000	Torque Shaft	Airbus Industrie
A2727083500000	Shaft Assembly	Airbus Industrie
A2727083500200	Shaft Assembly	Airbus Industrie
A2727085100000	Shaft	Airbus Industrie
A2727085100200	Shaft	Airbus Industrie
A2727086500200	Spring Rod	Airbus Industrie
A2727086500400	Spring Rod	Airbus Industrie
A2727086500600	Spring Rod	Airbus Industrie
A2727087600000	Shaft	Airbus Industrie
A2727090000000	Load Limiting Spring Rod	Airbus Industrie
A2727090000200	Load Limiting Spring Rod	Airbus Industrie
A2727092500000	Angle Drive Gearbox	Airbus Industrie
A2727092500200	Angle Drive Gearbox	Airbus Industrie
A2727114000051	Rudder Control Frame assy	Airbus Industrie
A2727114000251	Rudder Control Frame assy	Airbus Industrie
A2727114000651	Rudder Control Frame assy	Airbus Industrie
A2727114000851	Rudder Control Frame assy	Airbus Industrie
A2727114900000	Spring Rod	Airbus Industrie
A2727123500051	Rudder Control Frame assy	Airbus Industrie

Repair_Capability_List_Excel

A2727123500251	Rudder Control Frame assy	Airbus Industrie
A2727124000051	Variable Stop Unit	Airbus Industrie
A2727124000251	Variable Stop Unit	Airbus Industrie
A2727124000451	Variable Stop Unit	Airbus Industrie
A2727124000651	Variable Stop Unit	Airbus Industrie
A2727124000851	Variable Stop Unit	Airbus Industrie
A2727132500000	Artificial Feel & Trim Unit	Airbus Industrie
A2727132500200	Artificial Feel & Trim Unit	Airbus Industrie
A2731001000000	Captain Elev. Mech. Ctrl Bellcrank ay	Airbus Industrie
A27310010000100	Captain Elev. Mech. Ctrl Bellcrank ay	Airbus Industrie
A27310010000140	Captain Elev. Mech. Ctrl Bellcrank ay	Airbus Industrie
A2731014000000	Captain Elev. Mech. Ctrl Bellcrank ay	Airbus Industrie
A2731014000001	Captain Elev. Mech. Ctrl Bellcrank ay	Airbus Industrie
A2737029000200	Spring Rod	Airbus Industrie
A2737029000400	Spring Rod	Airbus Industrie
A2737029000600	Spring Rod	Airbus Industrie
A2737029000800	Spring Rod	Airbus Industrie
A2737032500251	Artificial Feel Frame assy	Airbus Industrie
A2737032500451	Artificial Feel Frame assy	Airbus Industrie
A2737051000051	Artificial Feel Frame assy	Airbus Industrie
A2737051000251	Artificial Feel Frame assy	Airbus Industrie
A2737051000651	Artificial Feel Frame assy	Airbus Industrie
A2737051000851	Artificial Feel Frame assy	Airbus Industrie
A2737087000251	Artificial Feel Frame assy	Airbus Industrie
A2737087000451	Artificial Feel Frame assy	Airbus Industrie
A2737087000651	Artificial Feel Frame assy	Airbus Industrie
A2737087000652	Artificial Feel Frame assy	Airbus Industrie
A2737087000851	Artificial Feel Frame assy	Airbus Industrie
A2737087000852	Artificial Feel Frame assy	Airbus Industrie
A2737087000853	Artificial Feel Frame assy	Airbus Industrie
A2737087000854	Artificial Feel Frame assy	Airbus Industrie
A2737087000855	Artificial Feel Frame assy	Airbus Industrie
A2737087000856	Artificial Feel Frame assy	Airbus Industrie
A2737087000857	Artificial Feel Frame assy	Airbus Industrie
A2737087000858	Artificial Feel Frame assy	Airbus Industrie
A2737087001051	Artificial Feel Frame assy	Airbus Industrie
A2737087001251	Artificial Feel Frame assy	Airbus Industrie
A2737112500052	Artificial Feel Frame assy	Airbus Industrie
A2737122000000	Spring Rod	Airbus Industrie
A2737122000200	Spring Rod	Airbus Industrie
A2737310000200	Elevator Drive Shaft	Airbus Industrie
A2737315000200	Elevator Drive Shaft	Airbus Industrie
A2737317000000	Elevator Drive Shaft	Airbus Industrie
A2737318000000	Elevator Drive Shaft	Airbus Industrie
A2737319000000	Elevator Drive Shaft	Airbus Industrie
A2737319500000	Elevator Drive Shaft	Airbus Industrie
A2737371100000	Pitch Uncoupling Unit Locking Mech.	Airbus Industrie
A2737460000200	Spring Rod assy	Airbus Industrie
A2737460000400	Spring Rod assy	Airbus Industrie
A2737465000400	Aft.Detent Bellcrank	Airbus Industrie
A2737465000600	Aft.Detent Bellcrank	Airbus Industrie
A2737465000800	Aft Detent Bellcrank	Airbus Industrie
A2737465001000	Aft.Detent Bellcrank	Airbus Industrie
A2737465001200	Aft Detent Bellcrank	Airbus Industrie
A2737470000060	Rod assy	Airbus Industrie
A2737470000260	Rod assy	Airbus Industrie
A2737470000261	Rod assy	Airbus Industrie
A2737470001600	Rod assy	Airbus Industrie

Repair_Capability_List_Excel

A2737470002800	Rod assy	Airbus Industrie
A2737470003300	Rod assy	Airbus Industrie
A2737470003400	Rod assy	Airbus Industrie
A2737470500000	Pitch Uncoupling Unit Locking Mech.	Airbus Industrie
A2737470500200	Pitch Uncoupling Unit Locking Mech.	Airbus Industrie
A2737470500400	Pitch Uncoupling Unit Locking Mech.	Airbus Industrie
A2741204600000	Pitch Trim Ctrl Stop Wash.& Gearset	Airbus Industrie
A2741205100060Z	Pitch Trim Ctrl Stop Wash.& Gearset	Airbus Industrie
A27427032500051	Rudder Contro Frame assy	Airbus Industrie
A27510156000C01	Flap & Slat Control Handle assy	Airbus Industrie
A27510156001C01	Flap & Slat Control Handle assy	Airbus Industrie
A27510156002E01	Flap & Slat Control Handle assy	Airbus Industrie
A27510156003C01	Flap & Slat Control Handle assy	Airbus Industrie
A2753227000000	Flap Control Microswitch Unit	Airbus Industrie
A2753261100001	Flap Control Cam Box	Airbus Industrie
A2753261100201	Flap Control Cam Box	Airbus Industrie
A2754003600000	Lever ay Reversing	Airbus Industrie
A2754003700000	Lever ay Reversing	Airbus Industrie
A2754003800000	Lever	Airbus Industrie
A2754005300000	Rod assy Tab Drive	Airbus Industrie
A2754005300200	Rod assy Tab Drive	Airbus Industrie
A2754007300100	Lever Stepped	Airbus Industrie
A2754007400000	Lever ay Stepped LH	Airbus Industrie
A2754007400100	Lever ay Stepped RH	Airbus Industrie
A2754007500000	Lever LH	Airbus Industrie
A2754007500100	Lever RH	Airbus Industrie
A2754007600000	Lever LH	Airbus Industrie
A2754007600100	Lever RH	Airbus Industrie
A2754012105000	Rod-control	Airbus Industrie
A2754012105200	Rod-control	Airbus Industrie
A2764009600200	Detent assy	Airbus Industrie
A2764009600300	Detent assy	Airbus Industrie
A2764009600400	Detent assy	Airbus Industrie
A2764009600500	Detent assy	Airbus Industrie
A2764009600600	Detent assy	Airbus Industrie
A2764009600700	Detent assy	Airbus Industrie
A2764009600800	Detent assy	Airbus Industrie
A2764009600900	Detent assy	Airbus Industrie
A2764009601000	Detent assy	Airbus Industrie
A2764009601100	Detent assy	Airbus Industrie
A2764009601200	Detent assy	Airbus Industrie
A2764009601300	Detent assy	Airbus Industrie
A2764009601400	Detent assy	Airbus Industrie
A2764009601500	Detent assy	Airbus Industrie
A2764009601600	Detent assy	Airbus Industrie
A2764009601700	Detent assy	Airbus Industrie
A2764009601800	Detent assy	Airbus Industrie
A2764009601900	Detent assy	Airbus Industrie
A2764012100000	Lever Assy LH	Airbus Industrie
A2764012100100	Lever Assy RH	Airbus Industrie
A2764012100200	Lever Assy LH	Airbus Industrie
A2764012100300	Lever Assy RH	Airbus Industrie
A2764018600400	Lever assy-inner LH	Airbus Industrie
A2764018600700	Lever assy-inner RH	Airbus Industrie
A2764018600800	Lever assy-inner LH	Airbus Industrie
A2764018601100	Lever Ay -inner RH	Airbus Industrie
A2764026500200	Inner Airbrake Detent ay	Airbus Industrie
A2764026500300	Inner Airbrake Detent ay	Airbus Industrie

Repair_Capability_List_Excel

A2764026500400	Inner Airbrake Detent ay	Airbus Industrie
A2764026500500	Inner Airbrake Detent ay	Airbus Industrie
A2764026505000	Inner Airbrake Detent ay	Airbus Industrie
A2764026505100	Inner Airbrake Detent ay	Airbus Industrie
A2764027200400	Detent assy Inner Airbrake	Airbus Industrie
A2764027200500	Detent assy Inner Airbrake	Airbus Industrie
A2764027200600	Detent assy Inner Airbrake	Airbus Industrie
A2764027200700	Detent assy Inner Airbrake	Airbus Industrie
A2764027200800	Detent assy Inner Airbrake	Airbus Industrie
A2764027200900	Detent assy Inner Airbrake	Airbus Industrie
A2764027201000	Detent assy Inner Airbrake	Airbus Industrie
A2764027201100	Detent assy Inner Airbrake	Airbus Industrie
A2764027205000	Detent assy Inner Airbrake	Airbus Industrie
A2764027205100	Detent assy Inner Airbrake	Airbus Industrie
A2764028400000	Rod assy	Airbus Industrie
A2764-1	Core Cowl Hold Open Rod	Norco
A2764-16	Core Cowl Hold Open Rod	Norco
A2764-17	Core Cowl Hold Open Rod	Norco
A2764-3	Core Cowl Hold Open Rod	Norco
A2783261000001	Slat Control Cam Box	Airbus Industrie
A2783261000101	Slat Control Cam Box	Airbus Industrie
A2783261000201	Slat Control Cam Box	Airbus Industrie
A2783261000301	Slat Control Cam Box	Airbus Industrie
A2783261100001	Slat Control Cam Box	Airbus Industrie
A2783261100101	Slat Control Cam Box	Airbus Industrie
A2783261100201	Slat Control Cam Box	Airbus Industrie
A2785-12	Fan Cowl Hold Open Rod	Norco
A2785-14	Fan Cowl Hold Open Rod	Norco
A2785-15	Fan Cowl Hold Open Rod	Norco
A2785-16	Fan Cowl Hold Open Rod	Norco
A2791150400001	Pitch Control Bellcrank assy	Airbus Industrie
A2791150500001	Pitch Control Bellcrank assy	Airbus Industrie
A2791219000001	Lower Trim Control Trasm. Gearbox	Airbus Industrie
A2791219000002	Lower Trim Control Trasm. Gearbox	Airbus Industrie
A2791242600000	Pitch Trim Ctrl Stop Wash.& Gearset	Airbus Industrie
A2791242600200	Pitch Trim Ctrl Stop Wash.& Gearset	Airbus Industrie
A2791242600240	Pitch Trim Ctrl Stop Wash.& Gearset	Airbus Industrie
A2791242600400	Pitch Trim Ctrl Stop Wash.& Gearset	Airbus Industrie
A2791258000001	Spring Rod	Airbus Industrie
A27912610000B01	Flap & Slat Control Handle assy	Airbus Industrie
A27912610002C01	Flap & Slat Control Handle assy	Airbus Industrie
A27912610002C02	Flap & Slat Control Handle assy	Airbus Industrie
A27912610002Z01	Flap & Slat Control Handle assy	Airbus Industrie
A2791262600001	Pitch Control Bellcrank assy	Airbus Industrie
A2791262600101	Pitch Control Bellcrank assy	Airbus Industrie
A2791262600201	Pitch Control Bellcrank assy	Airbus Industrie
A2791262600202	Pitch Control Bellcrank assy	Airbus Industrie
A2791262600301	Pitch Control Bellcrank assy	Airbus Industrie
A2791262600302	Pitch Control Bellcrank assy	Airbus Industrie
A2791272900051	LDG Emerg. Extension Ctrl Mech. ay	Airbus Industrie
A2791290000000	Spring Rod	Airbus Industrie
A2794204000400	Flap Carriage Track 1	Airbus Industrie
A2794204000600	Flap Carriage Track 1	Airbus Industrie
A2794251200260	Flap Carriage Track 2	Airbus Industrie
A2794251200261	Flap Carriage Track 2	Airbus Industrie
A2794251200264	Flap Carriage Track 2	Airbus Industrie
A2794251200266	Flap Carriage Track 2	Airbus Industrie
A2794251200360	Flap Carriage Track 2	Airbus Industrie

Repair_Capability_List_Excel

A2794251200361	Flap Carriage Track 2	Airbus Industrie
A2794251200364	Flap Carriage Track 2	Airbus Industrie
A2794251200366	Flap Carriage Track 2	Airbus Industrie
A2797312500000	Lever Assy-Pulley	Airbus Industrie
A2797312500100	Lever Assy-Pulley	Airbus Industrie
A2797312500200	Lever Assy-Pulley	Airbus Industrie
A2797312500300	Lever Assy-Pulley	Airbus Industrie
A2797312500400	Lever Assy-Pulley	Airbus Industrie
A2797312500500	Lever Assy-Pulley	Airbus Industrie
A2797312500600	Lever Assy-Pulley	Airbus Industrie
A2797312500700	Lever Assy-Pulley	Airbus Industrie
A2797312700000	Lever Assy-Pulley	Airbus Industrie
A2797312700100	Lever Assy-Pulley	Airbus Industrie
A2797312700200	Lever Assy-Pulley	Airbus Industrie
A2797312700300	Lever Assy-Pulley	Airbus Industrie
A2797312700400	Lever Assy-Pulley	Airbus Industrie
A2797312700500	Lever Assy-Pulley	Airbus Industrie
A2797312700600	Lever Assy-Pulley	Airbus Industrie
A2797312700700	Lever Assy-Pulley	Airbus Industrie
A2797314100000	Lever Assy-Pulley	Airbus Industrie
A2797314100100	Lever Assy-Pulley	Airbus Industrie
A2797314100200	Lever Assy-Pulley	Airbus Industrie
A2797314100300	Lever Assy-Pulley	Airbus Industrie
A2797314100400	Lever Assy-Pulley	Airbus Industrie
A2797314100500	Lever Assy-Pulley	Airbus Industrie
A2797314300000	Lever Assy-Pulley	Airbus Industrie
A2797314300100	Lever Assy-Pulley	Airbus Industrie
A2797314300200	Lever Assy-Pulley	Airbus Industrie
A2797314300300	Lever Assy-Pulley	Airbus Industrie
A2797314300400	Lever Assy-Pulley	Airbus Industrie
A2797314300500	Lever Assy-Pulley	Airbus Industrie
A2797315100000	Lever Assy-Pulley	Airbus Industrie
A2797315100100	Lever Assy-Pulley	Airbus Industrie
A2797315100200	Lever Assy-Pulley	Airbus Industrie
A2797315100300	Lever Assy-Pulley	Airbus Industrie
A2797315100400	Lever Assy-Pulley	Airbus Industrie
A2797315100500	Lever Assy-Pulley	Airbus Industrie
A2797315300000	Lever Assy-Pulley	Airbus Industrie
A2797315300100	Lever Assy-Pulley	Airbus Industrie
A2797315300200	Lever Assy-Pulley	Airbus Industrie
A2797315300300	Lever Assy-Pulley	Airbus Industrie
A2797315300400	Lever Assy-Pulley	Airbus Industrie
A2797315300500	Lever Assy-Pulley	Airbus Industrie
A28071-11-302	Tachymeter Generator	Kollsman
A2814006600200	Jet Pump	Airbus Industrie
A2814006600300	Jet Pump	Airbus Industrie
A2815007200000	Jet Pump	Airbus Industrie
A2815007200100	Jet Pump	Airbus Industrie
A2815013500000	Jet Pump	Airbus Industrie
A2815013500100	Jet Pump	Airbus Industrie
A2824004900000	Sequence Valve	Airbus Industrie
A2824004900200	Sequence Valve	Airbus Industrie
A2824017900200	Drain Valve	Airbus Industrie
A2824017900400	Drain Valve	Airbus Industrie
A2824017900600	Drain Valve	Airbus Industrie
A2824017900800	Drain Valve	Airbus Industrie
A2827090600600	Selector Valve & Fuel Tube ay	Airbus Industrie
A2827090600800	Selector Valve & Fuel Tube ay	Airbus Industrie

Repair_Capability_List_Excel

A28320-1	Servo Actuator	Moog
A28320-10	Servo Actuator	Moog
A28320-11	Servo Actuator	Moog
A28320-12	Servo Actuator	Moog
A28320-13	Servo Actuator	Moog
A28320-14	Servo Actuator	Moog
A28320-15	Servo Actuator	Moog
A28320-2	Servo Actuator	Moog
A28320-3	Servo Actuator	Moog
A28320-4	Servo Actuator	Moog
A28320-5	Servo Actuator	Moog
A28320-6	Servo Actuator	Moog
A28320-7	Servo Actuator	Moog
A28320-8	Servo Actuator	Moog
A28320-9	Servo Actuator	Moog
A28321-10	Servo Actuator	Moog
A28321-11	Servo Actuator	Moog
A28321-12	Servo Actuator	Moog
A28321-13	Servo Actuator	Moog
A28321-14	Servo Actuator	Moog
A28321-15	Servo Actuator	Moog
A28321-16	Servo Actuator	Moog
A28321-17	Servo Actuator	Moog
A28321-18	Servo Actuator	Moog
A28321-2	Servo Actuator	Moog
A28321-3	Servo Actuator	Moog
A28321-4	Servo Actuator	Moog
A28321-5	Servo Actuator	Moog
A28321-6	Servo Actuator	Moog
A28321-7	Servo Actuator	Moog
A28321-8	Servo Actuator	Moog
A28321-9	Servo Actuator	Moog
A2841300600101	Door assy	Airbus Industrie
A2841300990100	Door Service	Airbus Industrie
A2844000800000	Sealing Valve	Airbus Industrie
A285-000-00	Engine Vibration Indicator	Vibrometer
A28640-10	Lateral Central Ctrl Actuator	Moog
A28640-11	Lateral Central Ctrl Actuator	Moog
A28640-12	Lateral Central Ctrl Actuator	Moog
A28640-2	Lateral Central Ctrl Actuator	Moog
A28640-3	Lateral Central Ctrl Actuator	Moog
A28640-4	Lateral Central Ctrl Actuator	Moog
A28640-5	Lateral Central Ctrl Actuator	Moog
A28640-6	Lateral Central Ctrl Actuator	Moog
A28640-7	Lateral Central Ctrl Actuator	Moog
A28640-8	Lateral Central Ctrl Actuator	Moog
A28640-9	Lateral Central Ctrl Actuator	Moog
A2877074100400	XY GUIDE ASSY	AIRBUS INDUSTRIE
A2880-1	Fan Cowl Hold Open Rod	Norco
A2882-2	Fan Cowl Hold Open Rod	Norco
A2913207620000	Manifold	Airbus Industrie
A2913265500062	Manifold	Airbus Industrie
A2913350000167	Manifold	Airbus Industrie
A2913367920009	Manifold	Airbus Industrie
A2956-4	Thrust Reverser Hold Open Rod	Norco
A2956-5	Thrust Reverser Hold Open Rod	Norco
A2956-5A	Thrust Reverser Hold Open Rod	Norco
A2956-6	Thrust Reverser Hold Open Rod	Norco

Repair_Capability_List_Excel

A2974-1	Cowl Hold Open Rod	Norco
A2979-1	Cowl Hold Open Rod	Norco
A2979-3	Cowl Hold Open Rod	Norco
A-3	Position Indicator	Weston Aerospace
A3000954590	Bleed Duct	Arrowhead Prod.
A300B09606027B	Rotary Selector Switch	IEC Electronique
A300B09606031B	Rotary Selector Switch	IEC Electronique
A300B0961066A	Rotary Selector Switch	IEC Electronique
A3014500100000	Duct assy Telescopic	Airbus Industrie
A3014500100200	Duct assy Telescopic	Airbus Industrie
A3014500400000	Duct	Airbus Industrie
A3014502600400	Duct	Airbus Industrie
A3014503000100	Duct	Airbus Industrie
A3017022000400	Duct	Airbus Industrie
A3017308000000	Duct	Airbus Industrie
A3231102300001	Rod-Spring	Airbus Industrie
A3231102300101	Rod-Spring	Airbus Industrie
A3231200000000	Bellcrank-control	Airbus Industrie
A3241000700000	Bellcrank assy	Airbus Industrie
A3241000700001	Bellcrank assy	Airbus Industrie
A3241000700100	Bellcrank assy	Airbus Industrie
A3241000700101	Bellcrank assy	Airbus Industrie
A3241200200001	Bellcrank assy	Airbus Industrie
A3241200200101	Bellcrank assy	Airbus Industrie
A3241200200201	Bellcrank assy	Airbus Industrie
A3241200200202	Bellcrank assy	Airbus Industrie
A3241200200301	Bellcrank assy	Airbus Industrie
A3241200200302	Bellcrank assy	Airbus Industrie
A3251007100001	Reduction Gearbox	Airbus Industrie
A3251007100102	Reduction Gearbox	Airbus Industrie
A3251007100200	Reduction Gearbox	Airbus Industrie
A3251007100300	Reduction Gearbox	Airbus Industrie
A3251204000000	Reduction Gearbox	Airbus Industrie
A3251208500500	Spring Rod	Airbus Industrie
A3251213000001	Reduction Gearbox	Airbus Industrie
A3251213000002	Reduction Gearbox	Airbus Industrie
A3251213000101	Reduction Gearbox	Airbus Industrie
A3251213000102	Reduction Gearbox	Airbus Industrie
A3251213400000	Spring Rod	Airbus Industrie
A3251220600000	Reduction Gearbox	Airbus Industrie
A3251226000000	Spring Rod	Airbus Industrie
A3277020900400	Strut assy Shock	Airbus Industrie
A3295-1	Fan Cowl Hold Open Rod	Norco
A3295-2	Fan Cowl Hold Open Rod	Norco
A3417022000000	Drainer	Airbus Industrie
A3482-1	Fan Cowl Hold Open Rod	Norco
A3482-2	Fan Cowl Hold Open Rod	Norco
A3482-4	Fan Cowl Hold Open Rod	Norco
A3615710067	Standby Airspeed Indicator	Kollsman
A3615710070	Standby Airspeed Indicator	Kollsman
A3615710071	Standby Airspeed Indicator	Kollsman
A3615710072	Standby Airspeed Indicator	Kollsman
A3615710073	Standby Airspeed Indicator	Kollsman
A3615710167	Standby Airspeed Indicator	Kollsman
A36HNP6955	HP Hydraulic Filter	Sofrance
A36HNP6955A	HP Hydraulic Filter	Sofrance
A36HRP6952	HP Hydraulic Filter	Sofrance
A38103-1	Spoiler Servovalve	Moog

Repair_Capability_List_Excel

A38103-2	Spoiler Servovalve	Moog
A38103-3	Spoiler Servovalve	Moog
A38103-4	Spoiler Servovalve	Moog
A38729-10-004	Altimeter	Kollsman
A39469-10012	Mach Airspeed Indicator	Kollsman
A-4	Position Indicator	Liquidometer Corp
A400100-1	XZ-Single Latch	Goodrich
A400120-1	XZ-Single Latch	Goodrich
A400140-1	YZ-Single Latch	Goodrich
A408200-1	Braking Roller	Goodrich
A41869-10-016	Servo Altimeter	Kollsman
A4927021120000	Duct	Airbus Industrie
A-5	Volt/Amp Meter	Hickok Electrical Inst
A-510-12	Switch	Gerdas
A5211022600000	Handle Ay Ext Ctl LH	Airbus Industrie
A5211022600100	Handle Ay Ext Ctl RH	Airbus Industrie
A5211022600200	Handle Ay Extern LH	Airbus Industrie
A5211022600300	Handle Ay Extern RH	Airbus Industrie
A5211022600400	Handle Ay Ext Ctl LH	Airbus Industrie
A5211022600500	Handle Ay Ext Ctl RH	Airbus Industrie
A5211022601200	Handle Ay Ext Ctl LH	Airbus Industrie
A5211022601300	Handle Ay Ext Ctl RH	Airbus Industrie
A5211051700001	Rod Spring	Airbus Industrie
A5211051700101	Rod Spring	Airbus Industrie
A5211051700201	Rod Spring	Airbus Industrie
A5211053400000	Rod upper	Airbus Industrie
A5211053400001	Rod Upper	Airbus Industrie
A5211053400100	Rod upper	Airbus Industrie
A5211053600100	Link Lower	Airbus Industrie
A5211060500000	Slider assy	Airbus Industrie
A5211060500060	Slider assy	Airbus Industrie
A5211060500061	Slider assy	Airbus Industrie
A5211060500200	Slider assy	Airbus Industrie
A5211060500260	Slider assy	Airbus Industrie
A5211060500261	Slider assy	Airbus Industrie
A5211060500400	Slider assy	Airbus Industrie
A5211060500460	Slider assy	Airbus Industrie
A5211060500461	Slider assy	Airbus Industrie
A5211060500462	Slider assy	Airbus Industrie
A5211060500463	Slider assy	Airbus Industrie
A5211060500600	Slider assy	Airbus Industrie
A5211063400000	Locking LH	Airbus Industrie
A5211063400100	Locking RH	Airbus Industrie
A5211071200000	Rod Spring	Airbus Industrie
A5211081800000	Locking LH	Airbus Industrie
A5211081800100	Locking RH	Airbus Industrie
A5211101000000	Rod assy-upper	Airbus Industrie
A5211122900001	Avionics Compartment Access Door	Airbus Industrie
A5211122900301	Avionics Compartment Access Door	Airbus Industrie
A5211122900501	Avionics Compartment Access Door	Airbus Industrie
A5211127000101	Avionics Compartment Access Door	Airbus Industrie
A5217213300200	Arm assy Guide	Airbus Industrie
A5217213300400	Arm assy Guide	Airbus Industrie
A5217213300600	Arm assy Guide	Airbus Industrie
A5217213300800	Arm assy Guide	Airbus Industrie
A5217213420200	Arm assy Guide	Airbus Industrie
A5217213420400	Arm Guide	Airbus Industrie
A5217240820000	Arm Guide	Airbus Industrie

Repair_Capability_List_Excel

A5227033500000	Shaft ay-door Lift LH	Airbus Industrie
A5227033500100	Shaft ay-door Lift RH	Airbus Industrie
A5227033500200	Shaft ay-door Lift LH	Airbus Industrie
A5227033500251	Shaft ay-door Lift LH	Airbus Industrie
A5227033500252	Shaft ay-door Lift LH	Airbus Industrie
A5227033500300	Shaft ay-door Lift RH	Airbus Industrie
A5227033500351	Shaft ay-door Lift RH	Airbus Industrie
A5227033500352	Shaft ay-door Lift RH	Airbus Industrie
A5241001200000	Rod assy Spring	Airbus Industrie
A5241001200200	Rod assy Spring	Airbus Industrie
A5241002400001	Door Service	Airbus Industrie
A5243002900000	Rod-assy	Airbus Industrie
A5247201500000	Strut-assy	Airbus Industrie
A5247201500100	Strut-assy	Airbus Industrie
A5247201500200	Strut-assy	Airbus Industrie
A5247201500251	Strut-assy	Airbus Industrie
A5247201500300	Strut-assy	Airbus Industrie
A5247201500351	Strut-assy	Airbus Industrie
A5247300000000	Equipment Compartment Access Door	Airbus Industrie
A5247300000200	Equipment Compartment Access Door	Airbus Industrie
A5247300000600	Equipment Compartment Access Door	Airbus Industrie
A5281005220100	Fitting Hinge	Airbus Industrie
A5283402700000	Hinge assy	Airbus Industrie
A5283402700100	Hinge assy	Airbus Industrie
A5283402700200	Hinge assy	Airbus Industrie
A5283402700300	Hinge assy	Airbus Industrie
A5283402700400	Hinge assy	Airbus Industrie
A5283402700500	Hinge assy	Airbus Industrie
A5286994500000	Hinge Aft	Airbus Industrie
A5286994500200	Hinge Aft	Airbus Industrie
A5286996400000	Hinge Forward	Airbus Industrie
A5351021320001	Inboard & Outboard Link	Airbus Industrie
A5351021320101	Inboard & Outboard Link	Airbus Industrie
A5351021320201	Inboard & Outboard Link	Airbus Industrie
A5351021320301	Inboard & Outboard Link	Airbus Industrie
A5351021320401	Inboard & Outboard Link	Airbus Industrie
A5351021320402	Inboard & Outboard Link	Airbus Industrie
A5351021320403	Inboard & Outboard Link	Airbus Industrie
A5351021320501	Inboard & Outboard Link	Airbus Industrie
A5351021320502	Inboard & Outboard Link	Airbus Industrie
A5351021320503	Inboard & Outboard Link	Airbus Industrie
A5351021420001	Inboard & Outboard Link	Airbus Industrie
A5351021420201	Inboard & Outboard Link	Airbus Industrie
A5351021420401	Inboard & Outboard Link	Airbus Industrie
A5351021420402	Inboard & Outboard Link	Airbus Industrie
A5351021420403	Inboard & Outboard Link	Airbus Industrie
A5351027600000	Spring Rod	Airbus Industrie
A5351027600100	Spring Rod	Airbus Industrie
A5361140400000	Panel assy	Airbus Industrie
A5398033000000	Rod assy	Airbus Industrie
A5398033000100	Rod assy	Airbus Industrie
A5398033000600	Rod assy LH	Airbus Industrie
A5398033000700	Rod assy RH	Airbus Industrie
A5398033001200	Rod assy	Airbus Industrie
A5517209000200	Arm Hinge N°1	Airbus Industrie
A5517221000000	Arm Hinge N°2, 3	Airbus Industrie
A5517221000200	Arm N°2, 3	Airbus Industrie
A5517221200200	Arm N°4	Airbus Industrie

Repair_Capability_List_Excel

A5517241000000	Rudder Support N°5	Airbus Industrie
A5517253000000	Arm Hinge N°6	Airbus Industrie
A5517265000200	Arm Hinge N°7	Airbus Industrie
A5517506200000	Panel	Airbus Industrie
A5537009700200	Arm Hinge N° 4	Airbus Industrie
A5537010000600	Arm Hinge N° 1	Airbus Industrie
A5537010600000	Arm Hinge N° 2	Airbus Industrie
A5537010600200	Arm Hinge N° 2	Airbus Industrie
A5537010600400	Arm Hinge N° 2	Airbus Industrie
A5537010600600	Arm Hinge N° 2	Airbus Industrie
A5537011100000	Arm Hinge N° 3	Airbus Industrie
A5537011100200	Arm Hinge N° 3	Airbus Industrie
A5537011100400	Arm Hinge N° 3	Airbus Industrie
A5537011100600	Arm Hinge N° 3	Airbus Industrie
A5537012000400	Arm Hinge N° 5	Airbus Industrie
A5537012500400	Arm Hinge N° 6	Airbus Industrie
A5537013000000	Arm Hinge N° 7	Airbus Industrie
A5724025000000	Cantilever Outer	Airbus Industrie
A5724025100000	Cantilever Centre	Airbus Industrie
A5724033300000	Lever assy deflector	Airbus Industrie
A5724033300200	Lever assy deflector	Airbus Industrie
A5724033300400	Lever assy deflector	Airbus Industrie
A5724119400000	Spring Strut	Airbus Industrie
A5724123000000	Spring Strut	Airbus Industrie
A5724238700000	Spring Strut	Airbus Industrie
A5724242600000	Spring Box	Airbus Industrie
A5724459800000	Spring Box	Airbus Industrie
A5724459800200	Spring Box	Airbus Industrie
A5724459800400	Spring Box	Airbus Industrie
A5724477500000	Spring Strut	Airbus Industrie
A5724477500200	Spring Strut	Airbus Industrie
A5724477500400	Spring Strut	Airbus Industrie
A5734002200200	Panel Type 3	Airbus Industrie
A5734002600000	Panel Type 4A	Airbus Industrie
A5734002600200	Panel Type 4A	Airbus Industrie
A5734002800200	Panel Type 5	Airbus Industrie
A5734003000200	Panel Type 1	Airbus Industrie
A5734003000400	Panel Type 1	Airbus Industrie
A5734003400400	Panel Type 1A	Airbus Industrie
A5734003800439	Panel Type 2	Airbus Industrie
A5734003900200	Panel Type 4	Airbus Industrie
A5734004000400	Panel Type 2A	Airbus Industrie
A5734004600439	Panel Type 2B	Airbus Industrie
A5734006720000	Panel Type 2B	Airbus Industrie
A5784009500000	Spring Strut	Airbus Industrie
A5784029000000	Foldaway Slat Spring Strut	Airbus Industrie
A5784029000100	Foldaway Slat Spring Strut	Airbus Industrie
A5786350000200	Track assy N° 1	Airbus Industrie
A5786350200200	Track assy N°3	Airbus Industrie
A5786350900000	Track assy N°2	Airbus Industrie
A5786450000200	Knuckle assy	Airbus Industrie
A5786450200200	Track assy N°4	Airbus Industrie
A5786450500200	Track assy N° 6	Airbus Industrie
A5786450600200	Track assy N° 7	Airbus Industrie
A5786450800000	Link assy	Airbus Industrie
A5786550000200	Knuckle	Airbus Industrie
A5786550200000	Knuckle assy	Airbus Industrie
A5786550400000	Link assy	Airbus Industrie

Repair_Capability_List_Excel

A5786550600200	Track assy N° 8	Airbus Industrie
A5786550700200	Track assy N° 9	Airbus Industrie
A5786550800200	Track assy N° 10	Airbus Industrie
A5786550900200	Track assy N° 11	Airbus Industrie
A5794015000000	Strut Operating Flap Track	Airbus Industrie
A5794015000200	Strut Operating Flap Track	Airbus Industrie
A5794015000400	Strut Operating Flap Track	Airbus Industrie
A5794015000600	Strut Operating Flap Track	Airbus Industrie
A5794015005000	Strut Operating Flap Track	Airbus Industrie
A5794015005200	Strut Operating Flap Track	Airbus Industrie
A5794015400860	Flap Carriage Track 3, 4, 5 & 6	Airbus Industrie
A5794015400862	Flap Carriage Track 3, 4, 5 & 6	Airbus Industrie
A5794015400960	Flap Carriage Track 3, 4, 5 & 6	Airbus Industrie
A5794015400962	Flap Carriage Track 3, 4, 5 & 6	Airbus Industrie
A5794015401060	Flap Carriage Track 3, 4, 5 & 6	Airbus Industrie
A5794015401062	Flap Carriage Track 3, 4, 5 & 6	Airbus Industrie
A5794015401160	Flap Carriage Track 3, 4, 5 & 6	Airbus Industrie
A5794015401162	Flap Carriage Track 3, 4, 5 & 6	Airbus Industrie
A5794015401260	Flap Carriage Track 3, 4, 5 & 6	Airbus Industrie
A5794015401262	Flap Carriage Track 3, 4, 5 & 6	Airbus Industrie
A5794015401360	Flap Carriage Track 3, 4, 5 & 6	Airbus Industrie
A5794015401362	Flap Carriage Track 3, 4, 5 & 6	Airbus Industrie
A5794015401460	Flap Carriage Track 3, 4, 5 & 6	Airbus Industrie
A5794015401462	Flap Carriage Track 3, 4, 5 & 6	Airbus Industrie
A5794015401560	Flap Carriage Track 3, 4, 5 & 6	Airbus Industrie
A5794015401562	Flap Carriage Track 3, 4, 5 & 6	Airbus Industrie
A5794028300000	Yoke-ay Flap Track 2	Airbus Industrie
A5794028305000	Yoke-ay Flap Track 2	Airbus Industrie
A5794029000000	Lever assy-bellcrank	Airbus Industrie
A5794029001000	Lever assy-bellcrank	Airbus Industrie
A5794041300000	Strut assy Flap Track	Airbus Industrie
A5794041300200	Strut assy Flap Track	Airbus Industrie
A5794041300400	Strut assy Flap Track	Airbus Industrie
A5794041300600	Strut assy Flap Track	Airbus Industrie
A5794041400000	Strut assy Flap Track	Airbus Industrie
A5794200000000	Strut assy Flap Track	Airbus Industrie
A5794253800061	Carriages Track 3, 4, 5 & 6	Airbus Industrie
A5794253800161	Carriages Track 3, 4, 5 & 6	Airbus Industrie
A5794253800261	Carriages Track 3, 4, 5 & 6	Airbus Industrie
A5794253800361	Carriages Track 3, 4, 5 & 6	Airbus Industrie
A5794253800461	Carriages Track 3, 4, 5 & 6	Airbus Industrie
A5794253800561	Carriages Track 3, 4, 5 & 6	Airbus Industrie
A5794253800661	Carriages Track 3, 4, 5 & 6	Airbus Industrie
A5794253800761	Carriages Track 3, 4, 5 & 6	Airbus Industrie
A5796716600000	Link assy Track 3	Airbus Industrie
A5796716600200	Link assy Track 4	Airbus Industrie
A5796745700200	Lever assy	Airbus Industrie
A5796816600000	Link assy Track 5	Airbus Industrie
A5796816600200	Link assy Track 6	Airbus Industrie
A5796845700000	Lever assy	Airbus Industrie
A5797253300000	Damper assy	Airbus Industrie
A5797253300200	Damper assy	Airbus Industrie
A5797404200000	Operating Rod 2 assy	Airbus Industrie
A5797404300000	Actuating Rod 3 & 5 assy	Airbus Industrie
A5797404300200	Actuating Rod 3 & 5 assy	Airbus Industrie
A5797404400001	Actuating Rod 4 assy	Airbus Industrie
A5797404400101	Actuating Rod 4 assy	Airbus Industrie
A5797405500000	Side Load Stay assy	Airbus Industrie

Repair_Capability_List_Excel

A5797405500100	Side Load Stay assy	Airbus Industrie
A5797405500200	Side Load Stay assy	Airbus Industrie
A5797405500300	Side Load Stay assy	Airbus Industrie
A5797405600000	Side Load Stay assy	Airbus Industrie
A5797405600100	Side Load Stay assy	Airbus Industrie
A5797405600200	Side Load Stay assy	Airbus Industrie
A5797405600300	Side Load Stay assy	Airbus Industrie
A60087-CD6	Valve assy	Hydro-Aire
A-60203-5001	Drain Valve	Crane
A-60203-5501	Drain Valve	Crane
A-60203-5503	Drain Valve	Crane
A-60203-5505	Drain Valve	Crane
A-60203-5507	Drain Valve	Crane
A-60203-5509	Drain Valve	Crane
A61142-001	Servo Valve assy	Moog Gmbh
A61144-001	Servo Valve assy	Moog Gmbh
A61144-002	Servo Valve assy	Moog Gmbh
A61144-004	Servo Valve assy	Moog Gmbh
A61400-001A	Servo Valve Spoiler	Moog Gmbh
A61446-1	NLG Valve	Hydro-Aire
A61446-2	NLG Valve	Hydro-Aire
A61446-3	NLG Valve	Hydro-Aire
A61446-4	NLG Valve	Hydro-Aire
A61457-001B	Elevator Servo Valve	Moog GMBH
A61457-1	Servo Valve	Moog Inc
A61498	Relief Valve	Hydro-Aire
A-61498	Relief Valve	Hydro-Aire
A61545	Servo Valve assy	Moog Gmbh
A61545-001	Servo Valve assy	Moog Gmbh
A6201-2	Core Cowl Hold Open Rod	Norco
A6201-3	Core Cowl Hold Open Rod	Norco
A6201-32	Core Cowl Hold Open Rod	Norco
A63359-1	Valve assy	Crane
A63359-2	Valve assy	Crane
A63361	Relief Valve	Crane
A63363	Relief Valve	Crane
A64605-1	Servo Actuator	Moog
A64605-2	Servo Actuator	Moog
A64605-3	Servo Actuator	Moog
A64847-006	Servo Actuator	Moog
A64847-1	Servo Actuator	Moog
A64847-2	Servo Actuator	Moog
A64847-3	Servo Actuator	Moog
A64847-4	Servo Actuator	Moog
A64847-5	Servo Actuator	Moog
A64982-1	Servo-Actuator assy	Moog Inc
A64982-2	Servo-Actuator assy	Moog Inc
A64982-3	Servo-Actuator assy	Moog Inc
A68793	Servo Valve assy	Moog Gmbh
A68799	Servo Valve assy	Moog Gmbh
A68982	Servo Valve assy	Moog Gmbh
A703CD	Relay	CII Technologies
A71298-401	Restrictor Valve assy	Fokker Aircraft
A71298-403	Restrictor Valve assy	Fokker Aircraft
A71298-405	Restrictor Valve assy	Fokker Aircraft
A71298-407	Restrictor Valve assy	Fokker Aircraft
A71312-401	Check Valve Restrictor	Fokker Aircraft
A71312-403	Check Valve Restrictor	Fokker Aircraft

Repair_Capability_List_Excel

A71384-401	Selector Valve	Fokker Aircraft
A71720-1	Elevator Autopilot Servo	Moog
A71720-2	Elevator Autopilot Servo	Moog
A71720-3	Elevator Autopilot Servo	Moog
A71720-4	Elevator Autopilot Servo	Moog
A71720-5	Elevator Autopilot Servo	Moog
A71720-6	Elevator Autopilot Servo	Moog
A71874-1	Spoiler Servovalve	Moog
A71874-2	Spoiler Servovalve	Moog
A71874-3	Spoiler Servovalve	Moog
A71874-4	Spoiler Servovalve	Moog
A71882-1	Deflector Jet Servovalve	Moog
A71882-2	Deflector Jet Servovalve	Moog
A72012-401	Hydraulic Reservoir	Fokker Aircraft
A72012-403	Hydraulic Reservoir	Fokker Aircraft
A72012-405	Hydraulic Reservoir	Fokker Aircraft
A72012-407	Hydraulic Reservoir	Fokker Aircraft
A72012-409	Hydraulic Reservoir	Fokker Aircraft
A72012-411	Hydraulic Reservoir	Fokker Aircraft
A72012-413	Hydraulic Reservoir	Fokker Aircraft
A72012-415	Hydraulic Reservoir	Fokker Aircraft
A72012-417	Hydraulic Reservoir	Fokker Aircraft
A72012-419	Hydraulic Reservoir	Fokker Aircraft
A72012-421	Hydraulic Reservoir	Fokker Aircraft
A72012-423	Hydraulic Reservoir	Fokker Aircraft
A72012-425	Hydraulic Reservoir	Fokker Aircraft
A72012-427	Hydraulic Reservoir	Fokker Aircraft
A72012-429	Hydraulic Reservoir	Fokker Aircraft
A72012-431	Hydraulic Reservoir	Fokker Aircraft
A72012-433	Hydraulic Reservoir	Fokker Aircraft
A72012-435	Hydraulic Reservoir	Fokker Aircraft
A72012-437	Hydraulic Reservoir	Fokker Aircraft
A72012-439	Hydraulic Reservoir	Fokker Aircraft
A72012-441	Hydraulic Reservoir	Fokker Aircraft
A72035-403	Manifold assy	Fokker Aircraft
A72035-405	Manifold assy	Fokker Aircraft
A72035-407	Manifold assy	Fokker Aircraft
A72035-409	Manifold assy	Fokker Aircraft
A72035-411	Manifold assy	Fokker Aircraft
A72036-401	Hydraulic Reservoir	Fokker Aircraft
A72036-403	Hydraulic Reservoir	Fokker Aircraft
A72036-405	Hydraulic Reservoir	Fokker Aircraft
A72036-407	Hydraulic Reservoir	Fokker Aircraft
A72036-409	Hydraulic Reservoir	Fokker Aircraft
A72036-411	Hydraulic Reservoir	Fokker Aircraft
A72036-413	Hydraulic Reservoir	Fokker Aircraft
A72036-415	Hydraulic Reservoir	Fokker Aircraft
A72036-417	Hydraulic Reservoir	Fokker Aircraft
A72036-419	Hydraulic Reservoir	Fokker Aircraft
A72036-421	Hydraulic Reservoir	Fokker Aircraft
A72036-423	Hydraulic Reservoir	Fokker Aircraft
A72036-425	Hydraulic Reservoir	Fokker Aircraft
A72036-427	Hydraulic Reservoir	Fokker Aircraft
A72036-429	Hydraulic Reservoir	Fokker Aircraft
A72036-431	Hydraulic Reservoir	Fokker Aircraft
A72036-433	Hydraulic Reservoir	Fokker Aircraft
A72036-435	Hydraulic Reservoir	Fokker Aircraft
A72036-437	Hydraulic Reservoir	Fokker Aircraft

Repair_Capability_List_Excel

A72036-439	Hydraulic Reservoir	Fokker Aircraft
A72080-401	Liquid Level Gauge	Fokker Aircraft
A72080-403	Liquid Level Gauge	Fokker Aircraft
A72080-405	Liquid Level Gauge	Fokker Aircraft
A72080-407	Liquid Level Gauge	Fokker Aircraft
A72080-409	Liquid Level Gauge	Fokker Aircraft
A72080-411	Liquid Level Gauge	Fokker Aircraft
A72080-413	Liquid Level Gauge	Fokker Aircraft
A74208-401	Sensing Selector Valve	Fokker Aircraft
A74208-403	Sensing Selector Valve	Fokker Aircraft
A75900-409	Aileron & Rudder Trim Knobs	Fokker Aircraft
A75900-411	Aileron & Rudder Trim Knobs	Fokker Aircraft
A75900-413	Aileron & Rudder Trim Knobs	Fokker Aircraft
A75900-415	Aileron & Rudder Trim Knobs	Fokker Aircraft
A7611000700001	Secondary Transmission	Airbus Industrie
A7611005200000	Spring Link	Airbus Industrie
A7611005200100	Spring Link	Airbus Industrie
A7611007800100	Primary Transmission	Airbus Industrie
A7611007800200	Primary Transmission	Airbus Industrie
A7611007800400	Primary Transmission	Airbus Industrie
A7611007800600	Primary Transmission	Airbus Industrie
A7611017300001	Secondary Transmission	Airbus Industrie
A7611017300102	Secondary Transmission	Airbus Industrie
A7611017300301	Secondary Transmission	Airbus Industrie
A7611017300460	Secondary Transmission	Airbus Industrie
A7611500200000	Secondary Transmission	Airbus Industrie
A7611500200100	Secondary Transmission	Airbus Industrie
A7611500200200	Secondary Transmission	Airbus Industrie
A7611500200240	Secondary Transmission	Airbus Industrie
A7611500200300	Secondary Transmission	Airbus Industrie
A7611500200340	Secondary Transmission	Airbus Industrie
A7611507805100	Primary Transmission	Airbus Industrie
A7611507805200	Primary Transmission	Airbus Industrie
A7611511300200	Primary Transmission	Airbus Industrie
A7611511300300	Primary Transmission	Airbus Industrie
A7611511400200	Primary Transmission	Airbus Industrie
A7611511400300	Primary Transmission	Airbus Industrie
A7611518300200	Primary Transmission	Airbus Industrie
A7611518300300	Primary Transmission	Airbus Industrie
A76602	Fuel De-icing Valve	Colt Industries
A76602C	Fuel De-icing Valve	Colt Industries
A76602D	Fuel De-icing Valve	Colt Industries
A76602E	Fuel De-icing Valve	Colt Industries
A76602F	Fuel De-icing Valve	Colt Industries
A76602G	Fuel De-icing Valve	Colt Industries
A76602H	Fuel De-icing Valve	Colt Industries
A76602J	Fuel De-icing Valve	Colt Industries
A76602K	Fuel De-icing Valve	Colt Industries
A76602L	Fuel De-icing Valve	Colt Industries
A76602M	Fuel De-icing Valve	Colt Industries
A76602N	Fuel De-icing Valve	Colt Industries
A76602P	Fuel De-icing Valve	Colt Industries
A76602S	Fuel De-icing Valve	Colt Industries
A76602T	Fuel De-icing Valve	Colt Industries
A76602U	Fuel De-icing Valve	Colt Industries
A76825-401	Aieron Feel Trim Spring Unit	Fokker Aircraft
A76825-403	Aieron Feel Trim Spring Unit	Fokker Aircraft
A78160-401	Cable Tension Regulator	Fokker Aircraft

Repair_Capability_List_Excel

A78160-402	Cable Tension Regulator	Fokker Aircraft
A78160-403	Cable Tension Regulator	Fokker Aircraft
A78160-404	Cable Tension Regulator	Fokker Aircraft
A78160-405	Cable Tension Regulator	Fokker Aircraft
A78160-406	Cable Tension Regulator	Fokker Aircraft
A78160-407	Cable Tension Regulator	Fokker Aircraft
A78160-408	Cable Tension Regulator	Fokker Aircraft
A78160-409	Cable Tension Regulator	Fokker Aircraft
A78160-410	Cable Tension Regulator	Fokker Aircraft
A78160-411	Cable Tension Regulator	Fokker Aircraft
A78160-701	Cable Tension Regulator	Fokker Aircraft
A78300-401	Elevator Gustlock assy	Fokker Aircraft
A78300-403	Elevator Gustlock assy	Fokker Aircraft
A78300-405	Elevator Gustlock assy	Fokker Aircraft
A78300-407	Elevator Gustlock assy	Fokker Aircraft
A78300-703	Elevator Gustlock assy	Fokker Aircraft
A78710-401	MLG Door Uplock	Fokker Aircraft
A78710-402	MLG Door Uplock	Fokker Aircraft
A78710-403	MLG Door Uplock	Fokker Aircraft
A78710-404	MLG Door Uplock	Fokker Aircraft
A78710-405	MLG Door Uplock	Fokker Aircraft
A78710-406	MLG Door Uplock	Fokker Aircraft
A78710-407	MLG Door Uplock	Fokker Aircraft
A78710-408	MLG Door Uplock	Fokker Aircraft
A78710-409	MLG Door Uplock	Fokker Aircraft
A78710-410	MLG Door Uplock	Fokker Aircraft
A78710-411	MLG Door Uplock	Fokker Aircraft
A78710-412	MLG Door Uplock	Fokker Aircraft
A78710-413	MLG Door Uplock	Fokker Aircraft
A78710-414	MLG Door Uplock	Fokker Aircraft
A78710-415	MLG Door Uplock	Fokker Aircraft
A78710-416	MLG Door Uplock	Fokker Aircraft
A78710-417	MLG Door Uplock	Fokker Aircraft
A78710-418	MLG Door Uplock	Fokker Aircraft
A78710-419	MLG Door Uplock	Fokker Aircraft
A78710-420	MLG Door Uplock	Fokker Aircraft
A78710-421	MLG Door Uplock	Fokker Aircraft
A78710-422	MLG Door Uplock	Fokker Aircraft
A78730-402	MLG Door Uplock	Fokker Aircraft
A78730-404	MLG Door Uplock	Fokker Aircraft
A78730-405	MLG Door Uplock	Fokker Aircraft
A78730-406	MLG Door Uplock	Fokker Aircraft
A78730-407	MLG Door Uplock	Fokker Aircraft
A78730-409	MLG Door Uplock	Fokker Aircraft
A78730-411	MLG Door Uplock	Fokker Aircraft
A78730-413	MLG Door Uplock	Fokker Aircraft
A78730-415	MLG Door Uplock	Fokker Aircraft
A78730-417	MLG Door Uplock	Fokker Aircraft
A78730-419	MLG Door Uplock	Fokker Aircraft
A78730-421	MLG Door Uplock	Fokker Aircraft
A78730-423	MLG Door Uplock	Fokker Aircraft
A78730-427	MLG Door Uplock	Fokker Aircraft
A78730-429	MLG Door Uplock	Fokker Aircraft
A78730-431	MLG Door Uplock	Fokker Aircraft
A78730-433	MLG Door Uplock	Fokker Aircraft
A78730-435	MLG Door Uplock	Fokker Aircraft
A78730-437	MLG Door Uplock	Fokker Aircraft
A78730-439	MLG Door Uplock	Fokker Aircraft

Repair_Capability_List_Excel

A79550-403	Winch assy	Fokker Aircraft
A79550-405	Winch assy	Fokker Aircraft
A79550-407	Winch assy	Fokker Aircraft
A79550-409	Winch assy	Fokker Aircraft
A79550-411	Winch assy	Fokker Aircraft
A79550-413	Winch assy	Fokker Aircraft
A79761-407	Spring Box	Fokker Aircraft
A79761-409	Spring Box	Fokker Aircraft
A79761-411	Spring Box	Fokker Aircraft
A79761-413	Spring Box	Fokker Aircraft
A82903-405	Wiper Hatch assy	Fokker Aircraft
A82903-407	Wiper Hatch assy	Fokker Aircraft
A82903-409	Wiper Hatch assy	Fokker Aircraft
A82903-411	Wiper Hatch assy	Fokker Aircraft
A82903-413	Wiper Hatch assy	Fokker Aircraft
A82903-415	Wiper Hatch assy	Fokker Aircraft
A82903-417	Wiper Hatch assy	Fokker Aircraft
A82904-405	Wiper Hatch assy	Fokker Aircraft
A82904-407	Wiper Hatch assy	Fokker Aircraft
A82904-409	Wiper Hatch assy	Fokker Aircraft
A82904-411	Wiper Hatch assy	Fokker Aircraft
A82904-413	Wiper Hatch assy	Fokker Aircraft
A82904-415	Wiper Hatch assy	Fokker Aircraft
A82904-417	Wiper Hatch assy	Fokker Aircraft
A83070-419	Flap Instrumentation Switch Unit	Fokker Aircraft
A83070-427	Flap Instrumentation Switch Unit	Fokker Aircraft
A83070-431	Flap Instrumentation Switch Unit	Fokker Aircraft
A83070-433	Flap Instrumentation Switch Unit	Fokker Aircraft
A83070-435	Flap Instrumentation Switch Unit	Fokker Aircraft
A83210-401	Flap assy	Fokker
A83210-403	Flap Asymmetry Unit	Fokker Aircraft
A83210-405	Flap Asymmetry Unit	Fokker Aircraft
A83210-407	Flap Asymmetry Unit	Fokker Aircraft
A83210-409	Flap Asymmetry Unit	Fokker Aircraft
A83235	Flap Asymmetry Unit	Fokker Aircraft
A83235-401	Flap Asymmetry Unit	Fokker Aircraft
A83235-403	Flap Asymmetry Unit	Fokker Aircraft
A83235-405	Flap Asymmetry Unit	Fokker Aircraft
A83235-407	Flap Asymmetry Unit	Fokker Aircraft
A83235-409	Flap Asymmetry Unit	Fokker Aircraft
A83235-411	Flap Asymmetry Unit	Fokker Aircraft
A83235-413	Flap Asymmetry Unit	Fokker Aircraft
A83235-415	Flap Asymmetry Unit	Fokker Aircraft
A83235-417	Flap Asymmetry Unit	Fokker Aircraft
A83235-419	Flap Asymmetry Unit	Fokker Aircraft
A83235-425	Flap Asymmetry Unit	Fokker Aircraft
A843-0029	Transformer Rectifier Unit	Euroatlas
A88004	Servo Valve assy	Moog Gmbh
A88004-003	Servo Valve assy	Moog Gmbh
A88004-2	Servo Valve assy	Moog Gmbh
A88008	Servo Valve assy	Moog Gmbh
A88008-002	Servo Valve assy	Moog Gmbh
A9259119600000	Automatic Door Sill Latch	Airbus Industrie
A9259119600200	Automatic Door Sill Latch	Airbus Industrie
A9259119600400	Automatic Door Sill Latch	Airbus Industrie
A9259119600600	Automatic Door Sill Latch	Airbus Industrie
A9259147203800	Panel Ceiling	Airbus Industrie
A9259147304200	Panel Ceiling	Airbus Industrie

Repair_Capability_List_Excel

A9259162000200	Automatic XY Guide	Airbus Industrie
A9259162000400	Automatic XY Guide	Airbus Industrie
A9259162000800	Automatic XY Guide	Airbus Industrie
A9313205020005	Manifold	Airbus Industrie
A9313205620005	Manifold	Airbus Industrie
A95500047101B00	Fire Control Handle & Microswitch Unit	Airbus Industrie
A95500047101C00	Fire Control Handle & Microswitch Unit	Airbus Industrie
A95500047142C00	Fire Control Handle & Microswitch Unit	Airbus Industrie
A95500047142C40	Fire Control Handle & Microswitch Unit	Airbus Industrie
A95500047179C00	Fire Control Handle & Microswitch Unit	Airbus Industrie
A95500047308C00	Fire Control Handle & Microswitch Unit	Airbus Industrie
A95500048101B00	Fire Control Handle & Microswitch Unit	Airbus Industrie
A95500048101C00	Fire Control Handle & Microswitch Unit	Airbus Industrie
A95500048142C00	Fire Control Handle & Microswitch Unit	Airbus Industrie
A95500048142C40	Fire Control Handle & Microswitch Unit	Airbus Industrie
A95500048179C00	Fire Control Handle & Microswitch Unit	Airbus Industrie
A95500048308C00	Fire Control Handle & Microswitch Unit	Airbus Industrie
A9550011210101	Throttle Control Microswitch Unit	Airbus Industrie
A9550011211401	Throttle Control Microswitch Unit	Airbus Industrie
A9550011220901	Throttle Control Microswitch Unit	Airbus Industrie
A9550011220902	Throttle Control Microswitch Unit	Airbus Industrie
A9550011225901	Throttle Control Microswitch Unit	Airbus Industrie
A9550011225902	Throttle Control Microswitch Unit	Airbus Industrie
A9550011310101	Throttle Control Microswitch Unit	Airbus Industrie
A9550011311401	Throttle Control Microswitch Unit	Airbus Industrie
A9550011320901	Throttle Control Microswitch Unit	Airbus Industrie
A9550011320902	Throttle Control Microswitch Unit	Airbus Industrie
A9550011325901	Throttle Control Microswitch Unit	Airbus Industrie
A9550011325902	Throttle Control Microswitch Unit	Airbus Industrie
A9550011410200	Flap Control Microswitch Unit	Airbus Industrie
A9550011410240	Flap Control Microswitch Unit	Airbus Industrie
A955B011226201	Throttle Control Microswitch Unit	Airbus Industrie
A955B011229101	Throttle Control Microswitch Unit	Airbus Industrie
A955B011247801	Throttle Control Microswitch Unit	Airbus Industrie
A955B011282601	Throttle Control Microswitch Unit	Airbus Industrie
A955B011283201	Throttle Control Microswitch Unit	Airbus Industrie
A955B011326201	Throttle Control Microswitch Unit	Airbus Industrie
A955B011329101	Throttle Control Microswitch Unit	Airbus Industrie
A955B011347801	Throttle Control Microswitch Unit	Airbus Industrie
A955B011382601	Throttle Control Microswitch Unit	Airbus Industrie
A955B011383201	Throttle Control Microswitch Unit	Airbus Industrie
A95608001100B00	Nose Wheel Steering Ctrl Handwheel	Airbus Industrie
A95608001129B02	Nose Wheel Steering Ctrl Handwheel	Airbus Industrie
A95608001129C01	Nose Wheel Steering Ctrl Handwheel	Airbus Industrie
A95608001129Z01	Nose Wheel Steering Ctrl Handwheel	Airbus Industrie
A95608001262C01	Nose Wheel Steering Ctrl Handwheel	Airbus Industrie
A95608001468C02	Nose Wheel Steering Ctrl Handwheel	Airbus Industrie
A95608002100B00	Nose Wheel Steering Ctrl Handwheel	Airbus Industrie
A95608002129B02	Nose Wheel Steering Ctrl Handwheel	Airbus Industrie
A95608002129C01	Nose Wheel Steering Ctrl Handwheel	Airbus Industrie
A95608002129Z01	Nose Wheel Steering Ctrl Handwheel	Airbus Industrie
A95608002262C01	Nose Wheel Steering Ctrl Handwheel	Airbus Industrie
A95608002468C02	Nose Wheel Steering Ctrl Handwheel	Airbus Industrie
A95608503101B01	Control Pedestal Aileron & Rudder Trim	Airbus Industrie
A95608503121C01	Control Pedestal Aileron & Rudder Trim	Airbus Industrie
A95608503121Z01	Control Pedestal Aileron & Rudder Trim	Airbus Industrie
A95608503127C01	Control Pedestal Aileron & Rudder Trim	Airbus Industrie
A95608503127C40	Control Pedestal Aileron & Rudder Trim	Airbus Industrie

Repair_Capability_List_Excel

A95608503259C01	Control Pedestal Aileron & Rudder Trim	Airbus Industrie
A95609210100B01	Flight Compartment Throttle Control	Airbus Industrie
A95609210121C01	Flight Compartment Throttle Control	Airbus Industrie
A95609210121C02	Flight Compartment Throttle Control	Airbus Industrie
A95609210121Z01	Flight Compartment Throttle Control	Airbus Industrie
A95609210227C01	Flight Compartment Throttle Control	Airbus Industrie
A95609210259C01	Flight Compartment Throttle Control	Airbus Industrie
A95609210262C01	Flight Compartment Throttle Control	Airbus Industrie
A956B9210291C01	Flight Compartment Throttle Control	Airbus Industrie
A956B9210317C01	Flight Compartment Throttle Control	Airbus Industrie
A956B9210441C02	Flight Compartment Throttle Control	Airbus Industrie
A956B9210449C02	Flight Compartment Throttle Control	Airbus Industrie
A956B9210554C02	Flight Compartment Throttle Control	Airbus Industrie
A956F9210468C01	Flight Compartment Throttle Control	Airbus Industrie
A956F9210478C01	Flight Compartment Throttle Control	Airbus Industrie
A956F9210478C02	Flight Compartment Throttle Control	Airbus Industrie
A956F9210533C01	Flight Compartment Throttle Control	Airbus Industrie
A956F9210724C02	Flight Compartment Throttle Control	Airbus Industrie
ABA7677-1	Drive Unit	Douglas
ABM7091-1	Valve assy	Douglas
ABM7091-503	Valve assy	Douglas
ABM7091-505	Valve assy	Douglas
AC01223	Restrictor assy	Dunlop
AC027610	Pressure Switch	Dunlop
AC032268	Non-Return Valve	Dunlop
AC032270	Non-Return Valve	Dunlop
AC044341	Shuttle Valve	Dunlop
AC11184	NLG Uplock Ram	Dunlop
AC11654	Brake Control Valve	Dunlop
AC12562	Selector Valve	Dunlop
AC13228	Brake Selector Valve	Dunlop
AC13328	NLG Actuator	Dunlop
AC13336	Steering Motor	Dunlop
AC13340	NLG Uplock Ram	Dunlop
AC13342	MLG Uplock Ram	Dunlop
AC13346	Converter assy	Dunlop
AC14444	Follow-Up Control Valve	Dunlop
AC14446	Pneumatic Valve	Dunlop
AC2A	Servo Motor	CDA
AC30-0003-3	Rotary Switch	Janco
AC30-0003-4	Rotary Switch	Janco
AC30-0004	Rotary Switch	Janco
AC30-0004-1	Rotary Switch	Janco
AC30-0004-2	Rotary Switch	Janco
AC40-0184310	Divider Net	Bridport Gundry
AC40-0184320	Separation Net	Bridport Gundry
AC40-0184410	Lateral Net	Bridport Gundry
AC40-0184420	Lateral Net	Bridport Gundry
AC40-0184430	Lateral Net	Bridport Gundry
AC40-0184510	Longitudinal Net	Bridport Gundry
AC40-0184520	Longitudinal Net	Bridport Gundry
AC40-0184530	Longitudinal Net	Bridport Gundry
AC40-0184610	Door Net	Bridport Gundry
AC40-0184620	Door Net	Bridport Gundry
AC40-0184630	Door Net	Bridport Gundry
AC40-0184710	Crew Baggage Net	Bridport Gundry
AC40-0209500	Divider Net	Bridport Gundry
AC40-0209900	Divider Net	Bridport Gundry

Repair_Capability_List_Excel

AC40-0209910	Net-Divider Type C	Bridport Aviation Products
AC40-0210100	Divider Net	Bridport Gundry
AC40-0210200	Divider Net	Bridport Gundry
AC40-0217000	Door Net	Bridport Gundry
AC40-0217010	Net-Door	Bridport Aviation Products
AC40-0217100	Door Net	Bridport Gundry
AC40-0217110	Net-Door	Bridport Aviation Products
AC40-0217200	Door Net	Bridport Gundry
AC40-0217210	Net-Door	Bridport Aviation Products
AC40-0217300	Door Net	Bridport Gundry
AC40-0217400	Door Net	Bridport Gundry
AC40-0217500	Divider Net	Bridport Gundry
AC40-0219000	Net	Bridport Gundry
AC40-0219100	Net	Bridport Gundry
AC40-0219200	Net	Bridport Gundry
AC40-0219300	Net	Bridport Gundry
AC40-0227210	Door Net	Bridport Gundry
AC40-0227220	Door Net	Bridport Gundry
AC40-0227230	Door Net	Bridport Gundry
AC40-0227240	Corner Net	Bridport Gundry
AC40-0227250	Divider Net	Bridport Gundry
AC40-0241204	Door Net	Bridport Gundry
AC40-0241205	Net-Door	Bridport Aviation Products
AC60150	NLG Actuator	Dunlop
AC60160	NLG Actuator	Dunlop
AC60194	NLG Actuator	Dunlop
AC61078	Selector Valve	Dunlop
AC61348	Brake Control Valve	Dunlop
AC61422	Steering Motor	Dunlop
AC61552	Compressor Air	Dunlop
AC61906	Follow-Up Control Valve	Dunlop
AC62136	Maxaret Unit	Dunlop
AC62142	Maxaret Unit	Dunlop
AC62276	Follow-Up Control Valve	Dunlop
AC62602	Brake Control Valve	Dunlop
AC62838	NLG Actuator	Dunlop
AC62840	NLG Actuator	Dunlop
AC62856	Pneumatic Spring Return Ram	Dunlop
AC62898	MLG Uplock Ram	Dunlop
AC63538	Maxaret Unit	Dunlop
AC63544	Maxaret Unit	Dunlop
AC63546	Steering Motor	Dunlop
AC63552	Steering Motor	Dunlop
AC63880	Brake Control Valve	Dunlop
AC64130	NLG Uplock Ram	Dunlop
AC64208	Selector Valve	Dunlop
AC64240	Brake Control Valve	Dunlop
AC66150	Steering Motor	Dunlop
AC66414	NLG Actuator	Dunlop
AC66994	Air Compressor	Dunlop
AC67002	NLG Actuator	Dunlop
AC67004	NLG Actuator	Dunlop
AC67006	NLG Actuator	Dunlop
AC67008	MLG Uplock Ram	Dunlop
AC67010	MLG Uplock Ram	Dunlop
AC67132	MLG Actuator	Dunlop
AC67134	MLG Actuator	Dunlop
AC67846	NLG Actuator	Dunlop

Repair_Capability_List_Excel

AC67848	MLG Uplock Ram	Dunlop
AC67850	MLG Uplock Ram	Dunlop
AC69118	Auto Drain & Watertrap	Dunlop
AC69262	Solenoid Valve	Dunlop
AC69572	Solenoid Valve	Dunlop
ACG7098-5503	NLG Retract Cylinder assy	Douglas
ACG7130-5503	Steering Control Valve	Douglas
ACG7130-5505	Steering Control Valve	Douglas
ACG7130-5507	Steering Control Valve	Douglas
ACG7144-5503	NLG Steering Cylinder	Douglas
ACG7144-5505	NLG Steering Cylinder	Douglas
ACG7144-5509	NLG Steering Cylinder	Douglas
ACG7144-5511	NLG Steering Cylinder	Douglas
ACG7144-5513	NLG Steering Cylinder	Douglas
ACG7149-5001	Steering Cylinder Gland assy	Douglas
ACG7149-5003	Steering Cylinder Gland assy	Douglas
ACG7149-5005	Steering Cylinder Gland assy	Douglas
ACG7149-5007	Steering Cylinder Gland assy	Douglas
ACG7164-5001	Steering By-Pas Valve ay	Douglas
ACG7170-5001	Steering Manifold ay	Douglas
ACG7170-5501	Steering Manifold ay	Douglas
ACG7170-5503	Steering Manifold ay	Douglas
ACG7170-5505	Steering Manifold ay	Douglas
ACG7247-5501	Snubber	Douglas
ACG7258-5001	Upper Cargo Door Latch Cylinder ay	Douglas
ACG7286-5001	Upper Cargo Door Control Valve ay	Douglas
ACG7299-5501	Upper Cargo Door Cylinder	Douglas
ACG7301-5501	Upper Cargo Door Cylinder	Douglas
ACG7301-5503	Upper Cargo Door Cylinder	Douglas
ACG7301-5505	Upper Cargo Door Cylinder	Douglas
ACG7330-5001	NLG Unlock Cylinder	Douglas
ACG7330-5501	NLG Unlock Cylinder	Douglas
ACG7401-5001	NLG Retract Cylinder	Douglas
ACG7402-5001	NLG Steering Cylinder	Douglas
ACG7402-5501	NLG Steering Cylinder	Douglas
ACG7402-5503	NLG Steering Cylinder	Douglas
ACG7402-5505	NLG Steering Cylinder	Douglas
ACG7402-5507	NLG Steering Cylinder	Douglas
ACG7439-5501	NLG Steering Cylinder	Douglas
ACG7439-5503	NLG Steering Cylinder	Douglas
ACG7439-5505	NLG Steering Cylinder	Douglas
ACG7440-5501	NLG Steering Cylinder	Douglas
ACG7440-5503	NLG Steering Cylinder	Douglas
ACG7440-5505	NLG Steering Cylinder	Douglas
ACG7440-5507	NLG Steering Cylinder	Douglas
ACM16936	High Pressure Relief Valve	Dunlop
ACM17036	Air Filter	Dunlop
ACM17708	Pressure Regulator	Dunlop
ACM17892	Isolating Valve	Dunlop
ACM18048	Oil & Water Trap	Dunlop
ACM18304	Porous Metal Filter	Dunlop
ACM18540	Non-Return Valve	Dunlop
ACM18802	Rapid Exhaust Valve	Dunlop
ACM18982	Exhaust Valve	Dunlop
ACM20570	Damper Valve	Dunlop
ACM20818	Pressure Switch	Dunlop
ACM22070	Pressure Regulator	Dunlop
ACM22090	Dehydrator	Dunlop

Repair_Capability_List_Excel

ACM22234	Pressure Switch	Dunlop
ACM22426	Relief Valve	Dunlop
ACM23042	Dehydrator	Dunlop
ACM23442	Valve assy	Dunlop
ACM26214	Isolating Valve	Dunlop
ACM26230	Isolating Valve	Dunlop
ACM28268	Non-Return Valve	Dunlop
ACM28296	Reducer Valve	Dunlop
ACM28298	Rotary Valve	Dunlop
ACM28766	Pressure Reducer Valve	Dunlop
ACM28786	Air Filter	Dunlop
ACM28788	Pressure Regulator	Dunlop
ACM28978	Pressure Regulator	Dunlop
ACM28980	High Pressure Regulator	Dunlop
ACM28982	High Pressure Regulator	Dunlop
ACM29950	Pressure Relief Valve	Dunlop
ACM30056	Dehydrator	Dunlop
ACM30102	Dehydrator	Dunlop
ACM30152	Non-Return Valve	Dunlop
ACM30342	Non-Return Valve	Dunlop
ACP2531AC02	Audio Control Panel	Thales Avionics
ACP2788AA02	Audio Control Panel	TEAM
ACP2788AB04	Audio Control Panel	TEAM
ACP2788AB05	Audio Control Panel	TEAM
AD8650501	Actuator	Artus
AD8650502	Actuator	Artus
AD8650503	Actuator	Artus
AD8650601	Actuator	Artus
AD8650602	Actuator	Artus
AD8650603	Actuator	Artus
AD-9227-1640	FUEL FILTER	PALL
AD-9227-1780	FUEL FILTER	PALL
AD-9227-2080	FUEL FILTER	PALL
AD-9227-2480	FUEL FILTER	PALL
AD-9227-2780	FUEL FILTER	PALL
AD9380-2024	Scavenge Oil Filter	Pall
AD9380-4010	Scavenge Oil Filter	Pall
AD9380-4011	Scavenge Oil Filter	Pall
AD9380-5010	Scavenge Oil Filter	Pall
AD9380-5011	Scavenge Oil Filter	Pall
AD9380-6010	Scavenge Oil Filter	Pall
AD9380-6011	Scavenge Oil Filter	Pall
ADG7010-1	Hydraulic Counterbalance Actuator	Douglas
ADG7010-501	Hydraulic Counterbalance Actuator	Douglas
ADG7010-503	Hydraulic Counterbalance Actuator	Douglas
ADG7010-505	Hydraulic Counterbalance Actuator	Douglas
ADG7010-507	Hydraulic Counterbalance Actuator	Douglas
AE1007313	Teflon Hose assy	Aeroquip
AE1007868	Teflon Hose assy	Aeroquip
AE1008713G	Teflon Hose assy	Aeroquip
AE1008990N	Teflon Hose assy	Aeroquip
AE1009014N	Teflon Hose assy	Aeroquip
AE1009060	Teflon Hose assy	Aeroquip
AE1009061	Teflon Hose assy	Aeroquip
AE1009062	Teflon Hose assy	Aeroquip
AE1012B00	Recirculation Fan	Technofan
AE1502U01	Brake Fan Motor assy	Technofan
AE3663	Teflon Hose assy	Aeroquip

Repair_Capability_List_Excel

AE3668	Teflon Hose assy	Aeroquip
AE3669	Teflon Hose assy	Aeroquip
AE4123MK1	Actuator	Goodrich Control Systems
AE5751MK1	Auto Transformer	Goodrich Control Systems
AE5901MK1	Auto Transformer	Goodrich Control Systems
AE5902MK1	Power Transformer	Goodrich Control Systems
AE5942MK1	Power Transformer	Goodrich Control Systems
AE5982MK1	Power Transformer	Goodrich Control Systems
AE704322-1	Teflon Hose assy	Aeroquip
AE704323-1	Teflon Hose assy	Aeroquip
AE704324-1	Teflon Hose assy	Aeroquip
AE705925-31	Teflon Hose assy	Aeroquip
AE705926-17	Teflon Hose assy	Aeroquip
AE705926-21	Teflon Hose assy	Aeroquip
AE705926-23	Teflon Hose assy	Aeroquip
AE707418-1	Teflon Hose assy	Aeroquip
AE707419-1	Teflon Hose assy	Aeroquip
AE707419-3	Teflon Hose assy	Aeroquip
AE707420-2	Teflon Hose assy	Aeroquip
AE708818-1	Teflon Hose Assy	Aero Equipment
AE7088-18-1	Hose assy	Aeroquip
AE708819	Teflon Hose Assy	Aero Equipment
AE708820-1	Hose assy	Aeroquip
AE708821-1	Hose assy	Aeroquip
AE708821-2	Hose assy	Aeroquip
AE708822-3	Hose assy	Aeroquip
AE709215-2	Teflon Hose assy	Aeroquip
AE709216-2	Teflon Hose assy	Aeroquip
AE709217-1	Teflon Hose assy	Aeroquip
AE709218-3	Teflon Hose assy	Aeroquip
AE709224-2	Teflon Hose assy	Aeroquip
AE709225-3	Teflon Hose assy	Aeroquip
AE709240-2	Teflon Hose assy	Aeroquip
AE80531K	Quick Disconnect Coupling	Aeroquip
AE80532N	Quick Disconnect Coupling	Aeroquip
AE81266P	Self-sealing Coupling	Aeroquip
AE8434N	Self-sealing Adapter	Aeroquip
AE84760Z	Swivel Joint assy	Aeroquip
AE86195G	Valve assy	Aeroquip
AE86773K	Coupling	Aeroquip
AE87671P	Quick Disconnect Coupling	Aeroquip
AE95394M	Self-sealing Coupling	Aeroquip
AE95396P	Self-sealing Coupling	Aeroquip
AE95473P	Couplings Self Sealing	Aeroquip
AE95614G	Self-sealing Coupling	Aeroquip
AE95683N	Self-sealing Coupling	Aeroquip
AE95683P	Self-sealing Coupling	Aeroquip
AE95685G	Self-sealing Coupling	Aeroquip
AE95686G	Self-sealing Coupling	Aeroquip
AE95687G	Couplings Self Sealing	Aeroquip
AE95733P	Self-sealing Coupling	Aeroquip
AE95798K	Self-sealing Coupling	Aeroquip
AE95826N	Self-sealing Adapter	Aeroquip
AE95997P	Self-sealing Coupling	Aeroquip
AE96211M	Self-sealing Adapter	Aeroquip
AE96212K	Self-sealing Adapter	Aeroquip
AE96213M	Self-sealing Adapter	Aeroquip
AE96214K	Self-sealing Adapter	Aeroquip

Repair_Capability_List_Excel

AE96412N	Self-sealing Adapter	Aeroquip
AE96692N	Self-sealing Adapter	Aeroquip
AE96787N	Self-sealing Adapter	Aeroquip
AE96824N	Couplings Self Sealing	Aeroquip
AE96824P	Couplings Self Sealing	Aeroquip
AE96825G	Couplings Self Sealing	Aeroquip
AE96927E	Swivel Joint	Aeroquip
AE96928E	Swivel Joint	Aeroquip
AE96993E	Self-sealing Coupling	Aeroquip
AE96994E	Couplings Self Sealing	Aeroquip
AE96995P	Self Seal Couplings	Aeroquip
AE96996P	Self Seal Couplings	Aeroquip
AE96997P	Self Seal Couplings	Aeroquip
AE970031	Couplings Self Sealing	Aeroquip
AE97004J	Couplings Self Sealing	Aeroquip
AE97048P	Half Coupling	Aeroquip
AE97908N	Self-sealing Adapter	Aeroquip
AE98033N	Self-sealing Adapter	Aeroquip
AE98434N	Self-sealing Adapter	Aeroquip
AE99118J	Quick Disconnect Coupling	Aeroquip
AE99118K	Quick Disconnect Coupling	Aeroquip
AE99119J	Quick Disconnect Coupling	Aeroquip
AE99119K	Quick Disconnect Coupling	Aeroquip
AF25-195-1	Inclinometer	Blanchet
AF-25-195-1	Inclinometer	Blanchet
AGCM7VG	Ground Test Selector	Messier-Dowty
AH2542AB02	Attendant Handset Base	Team
AH2542AB03	Attendant Handset Base	Team
AH2542AD02	Handset	Team
AH2542AD03	Handset	Team
AH2542AE01	Cabin Attendant Handset	TEAM
AH2542AE02	Cabin Attendant Handset	TEAM
AH2542AT03	Attendant Handset	Thales Avionics
AH2542B	Attendant Handset Base	Team
AH2542BA01	Cabin Attendant Handset	TEAM
AH2542BA02	Cabin Attendant Handset	TEAM
AH2542C	Base Handset Support	Team
AH2542D	Handset	Team
AH3345AA01	Attendant Handset Base	Team
AH52805	Hydraulic Plate Brake	Dunlop
AH52894	Hydraulic Plate Brake	Dunlop
AHA2311	Nose Wheel Axle Sleeve	Dunlop
AHA2312	Hub Cap assy	Dunlop
AHA2312-2	Hub Cap assy	Dunlop
AHA2312-3	Hub Cap assy	Dunlop
AHV5-221	Altitude Indicator	Thales Avionics
AI30-10	Smoke Detection Indicator	Cerberus Guinard
AIR91728-1	Accumulator	APPH
AIR91730	Accumulator	APPH
AIR91740-0	Accumulator	APPH
AIR91740-1	Accumulator	APPH
AIR91754	Accumulator	APPH
AIR91756	Accumulator	APPH
AIR91756-0	Accumulator	APPH
AIR985	Air Bleed Temperature Sensor	Atexis
AJG7005-5001	Horizontal Stabilizer Brake ay	Douglas
AJG7005-5501	Horizontal Stabilizer Brake ay	Douglas
AJG7011-5005	Horizontal Stabilizer Brake ay	Douglas

Repair_Capability_List_Excel

AJG7011-5501	Horizontal Stabilizer Brake ay	Douglas
AJG7011-5507	Hydraulic System Manifold ay	Douglas
AJG7011-5509	Hydraulic System Manifold ay	Douglas
AJG7011-5511	Hydraulic System Manifold ay	Douglas
AJG7011-5513	Hydraulic System Manifold ay	Douglas
AJG7011-5515	Hydraulic System Manifold ay	Douglas
AJG7011-5517	Hydraulic System Manifold ay	Douglas
AJG7011-5519	Hydraulic System Manifold ay	Douglas
AJG7011-5521	Hydraulic System Manifold ay	Douglas
AJG7011-5523	Hydraulic System Manifold ay	Douglas
AJG7011-5525	Hydraulic System Manifold ay	Douglas
AJG7011-5527	Hydraulic System Manifold ay	Douglas
AJG7041-5507	Primary Trim Valve assy	Douglas
AJG7041-5513	Primary Trim Valve assy	Douglas
AJG7041-5515	Primary Trim Valve assy	Douglas
AJG7041-5517	Primary Trim Valve assy	Douglas
AJG7041-5523	Primary Trim Valve assy	Douglas
AJG7041-5525	Primary Trim Valve assy	Douglas
AJG7041-5527	Primary Trim Valve assy	Douglas
AJG7041-5531	Primary Trim Valve assy	Douglas
AJG7041-5533	Primary Trim Valve assy	Douglas
AJG7041-5535	Primary Trim Valve assy	Douglas
AJG7041-5537	Primary Trim Valve assy	Douglas
AJG7041-5539	Primary Trim Valve assy	Douglas
AJG7041-5541	Primary Trim Valve assy	Douglas
AJG7043-5505	LSSAS Control Valve ay	Douglas
AJH7150-501	Screw Actuator assy	Douglas
AJH7150-503	Screw Actuator assy	Douglas
AJH7150-505	Screw Actuator assy	Douglas
AJH7150-507	Screw Actuator assy	Douglas
AJH7150-509	Screw Actuator assy	Douglas
AJH7150-511	Screw Actuator assy	Douglas
AL00601	Actuator	Goodrich Control Systems
AL271EAP	Engage & Trim Indicator	Smiths Industries
AL95RVSB	Engine Speed Indicator	Smiths Industries
ALG7022-5001	Damper Valve assy	Douglas
ALG7022-5503	Damper Elevator Valve	Douglas
ALG7024-5001	Elevator Buzz Damper ay	Douglas
ALG7024-5501	Elevator Buzz Damper ay	Douglas
ALG7024-5505	Elevator Buzz Damper ay	Douglas
ALG7024-5507	Elevator Buzz Damper ay	Douglas
ALG7051-5001	Elevator Damper assy	Douglas
ALG7051-5501	Elevator Damper assy	Douglas
ALG7051-5505	Elevator Damper assy	Douglas
ALG7051-5507	Elevator Damper assy	Douglas
ALG7052-5001	Damper Valve assy	Douglas
ALG7052-5501	Damper Valve assy	Douglas
ALG7052-5503	Damper Valve assy	Douglas
ALG7080-5001	Elevator Damper assy	Douglas
ALG7080-5003	Elevator Damper assy	Douglas
ALG7080-5501	Elevator Damper assy	Douglas
AM1C-032-01	Hydraulic Motor	Parker Hannifin
AM1C-032-02	Hydraulic Motor	Parker Hannifin
AM1C-032-03	Hydraulic Motor	Parker Hannifin
AN5525-1	Resistance Bulb	Edison
AN5525-2	Resistance Bulb	Edison
AN5536-2A	Thermocouple Indicator	Weston Aerospace
AN5536T2A	Thermocouple Indicator	Weston Aerospace

Repair_Capability_List_Excel

AN5770-1	Pressure Manifold	Ametek
AN5770-1A	Pressure Manifold	Ametek
AN5770-2	Pressure Indicator	M,M&M
AN5771-1	Pressure Gage	Autolite Prod.Philco
AN5771-2A	Pressure Gage	Ametek
AN5771-4B	Pressure Gage	Ametek
AN5771-6	Pressure Gage	Ametek
AN5771-7A	Pressure Gage	Ametek
AN5771T-4B	Pressure Gage	Ametek
AN5771T7A	Pressure Gage	Ametek
AN5772-1	Pressure Indicator	Ametek
AN5772-2	Pressure Gage	Autolite Prod.Philco
AN5780-1	Position Indicator	Weston Aerospace
AN5780-2	Position Indicator	Weston Aerospace
AN5785-1	Position Transmitter	Weston Aerospace
AN5790-6	Thermometer	Autolite Prod.Philco
AN5790T6A	Thermometer	Autolite Prod.Philco
AN5795-6	Thermometer	Autolite Prod.Philco
AN5795T6A	Thermometer	Autolite Prod.Philco
AN5839-1	Position Indicator	Keystone
AP10V-58A	VARIABLE HYP PUMP	PARKER
AP10V-58A-01	VARIABLE HYP PUMP	PARKER
AP10V-58A-04	VARIABLE HYP PUMP	PARKER
AP10V-58A-05	VARIABLE HYP PUMP	PARKER
AP10V-58A-06	VARIABLE HYP PUMP	PARKER
AP10V-58A-07	VARIABLE HYP PUMP	PARKER
AP10V-58A-08	VARIABLE HYP PUMP	PARKER
AP10V-68A	VARIABLE HYP PUMP	PARKER
AP10V-68A-01	VARIABLE HYP PUMP	PARKER
AP10V-68A-02	VARIABLE HYP PUMP	PARKER
AP10V-68A-03	VARIABLE HYP PUMP	PARKER
AP10V-68A-04	VARIABLE HYP PUMP	PARKER
AP10V-68A-05	VARIABLE HYP PUMP	PARKER
AP10V-68A-06	VARIABLE HYP PUMP	PARKER
AP10V-7A	VARIABLE HYP PUMP	PARKER
AP10V-7A-02	VARIABLE HYP PUMP	PARKER
AP10V-7A-03	VARIABLE HYP PUMP	PARKER
AP-655	DUAL SKID CTL VALVE	ABSC
APE2650	Clock	Air Precision
APE2652	Clock	Air Precision
APE909-0051	GMT Clock	Air Precision
APE962	Time Display Unit	Air Precision
APE962-01	Time Display Unit	Air Precision
APG7000-5501	Slat Control Valve	Douglas
APG7000-5503	Slat Control Valve	Douglas
APG7000-5505	Slat Control Valve	Douglas
APG7000-5509	Slat Control Valve	Douglas
APG7000-5511	Slat Control Valve	Douglas
APG7002-5503	Two-Speed Slat Valve assy	Douglas
APG7002-5505	Two-Speed Slat Valve assy	Douglas
APS1-1000-40D	Oil Pressure Switch	Kulite
APS1-1000-40DW	Oil Pressure Switch	Kulite
APS30-1	Anti-Collision Light Power Supply Unit	Logic Spa
APS32-1	Anti-Collision Light Power Supply Unit	Logic Spa
APS5-1500	Pressure Switch	Kulite
APS6-1000	Pressure Switch	Kulite
APS-6-1000	Pressure Switch	Kulite
APS7-1000	Pressure Switch	Kulite

Repair_Capability_List_Excel

APS-7-1000	Pressure Switch	Kulite
APS8-1000	Pressure Switch	Kulite
APS-8-1000	Pressure Switch	Kulite
APT4-1000-4KW	Pressure Transducer	Kulite
APT7-1000-4000A	Oil Pressure Transducer	Kulite
APT7-1000-4000AW	Oil Pressure Transducer	Kulite
APT8-1000-100DW	Oil Pressure Transducer	Kulite
APT9-1000-50GW	Oil Pressure Transducer	Kulite
AR02402	Landing Gear Free Fall Actuator	Goodrich Control Systems
AR02403	Landing Gear Free Fall Actuator	Goodrich Control Systems
AR02404	Landing Gear Free Fall Actuator	Goodrich Control Systems
AR02405	Landing Gear Free Fall Actuator	Goodrich Control Systems
AR2510-1S12	Lavatory Latch assy	Adams Rite
AR2510-2S12	Lavatory Latch assy	Adams Rite
AR2510-3S12	Lavatory Latch assy	Adams Rite
AR2510-4S12	Lavatory Latch assy	Adams Rite
AR2510-5S12	Lavatory Latch assy	Adams Rite
AR2510-6S12	Lavatory Latch assy	Adams Rite
AR2529-1	Lock assy	Adams Rite
AR2529-3	Lock assy	Adams Rite
AR2529B-1	Lock assy	Adams Rite
AR2529B-3	Lock assy	Adams Rite
AR2962	Lock assy	Adams Rite
AR4701-1	Double Roller Electric Strike assy	Adams Rite
AR4701-11	Double Roller Electric Strike assy	Adams Rite
AR4701-13	Double Roller Electric Strike assy	Adams Rite
AR4701-17	Double Roller Electric Strike assy	Adams Rite
AR4701-19	Double Roller Electric Strike assy	Adams Rite
AR4701-21	Double Roller Electric Strike assy	Adams Rite
AR4701-23	Double Roller Electric Strike assy	Adams Rite
AR4701-3	Double Roller Electric Strike assy	Adams Rite
AR4701-5	Double Roller Electric Strike assy	Adams Rite
AR4701-7	Double Roller Electric Strike assy	Adams Rite
AR4701-9	Double Roller Electric Strike assy	Adams Rite
AR4704-1	Double Roller Electric Strike assy	Adams Rite
AR4704-2	Double Roller Electric Strike assy	Adams Rite
AR4704-3	Double Roller Electric Strike assy	Adams Rite
AR4704-4	Double Roller Electric Strike assy	Adams Rite
AR4704-5	Double Roller Electric Strike assy	Adams Rite
AR4704-6	Double Roller Electric Strike assy	Adams Rite
AR4704-7	Double Roller Electric Strike assy	Adams Rite
AR4704-8	Double Roller Electric Strike assy	Adams Rite
AR4708-1	Double Roller Electric Strike assy	Adams Rite
AR4708-3	Double Roller Electric Strike assy	Adams Rite
AR4708-5	Double Roller Electric Strike assy	Adams Rite
AR4708-7	Double Roller Electric Strike assy	Adams Rite
AR4709-1	Cockpit System Control	Adams Rite
AR4709-201	Cockpit System Controller	Adams Rite
AR4709-203	Cockpit System Controller	Adams Rite
AR4709-3	Cockpit System Control	Adams Rite
AR4709-5	Cockpit System Control	Adams Rite
AR4714-1	Electrically Operated Strike assy	Adams Rite
AR4714-3	Strike Cockpit Door	Adams Rite
AR4714-5	Electrically Operated Strike assy	Adams Rite
AR4726-1	Double Roller Electric Strike assy	Adams Rite
AR4726-5	Double Roller Electric Strike assy	Adams Rite
AR7077M1MOD1	Stabilizer Trim Ctrl Actuator	Goodrich Aerospace
AR7077M1MOD2	Stabilizer Trim Ctrl Actuator	Goodrich Aerospace

Repair_Capability_List_Excel

AR7077M1MOD3	Stabilizer Trim Ctrl Actuator	Goodrich Aerospace
AR7077M2MOD1	Stabilizer Trim Ctrl Actuator	Goodrich Aerospace
AR7077M2MOD2	Stabilizer Trim Ctrl Actuator	Goodrich Aerospace
AR7077M2MOD3	Stabilizer Trim Ctrl Actuator	Goodrich Aerospace
AR7077M2MOD4	Stabilizer Trim Ctrl Actuator	Goodrich Aerospace
AR7077M2MOD5	Stabilizer Trim Ctrl Actuator	Goodrich Aerospace
AR7077M2MOD6	Stabilizer Trim Ctrl Actuator	Goodrich Aerospace
AR7077M2MOD7	Stabilizer Trim Ctrl Actuator	Goodrich Aerospace
AR7077M2MOD8	Stabilizer Trim Ctrl Actuator	Goodrich Aerospace
AR7077M3	Stabilizer Trim Ctrl Actuator	Goodrich Aerospace
AR7077M3MOD1	Stabilizer Trim Ctrl Actuator	Goodrich Aerospace
AR9592-7	Waste Drain Valve	Adams Rite
ARG7025-5003	MLG Retract Swivel assy	Douglas
ARG7025-5007	MLG Retract Swivel assy	Douglas
ARG7025-5503	MLG Retract Cylinder assy	Douglas
ARG7025-5505	MLG Retract Cylinder assy	Douglas
ARG7025-5507	MLG Retract Cylinder assy	Douglas
ARG7025-5509	MLG Retract Cylinder assy	Douglas
ARG7025-5511	MLG Retract Cylinder assy	Douglas
ARG7025-5513	MLG Retract Cylinder assy	Douglas
ARG7025-5515	MLG Retract Cylinder assy	Douglas
ARG7025-5517	MLG Retract Cylinder assy	Douglas
ARG7025-5519	MLG Retract Cylinder assy	Douglas
ARG7025-5521	MLG Retract Cylinder assy	Douglas
ARG7025-5523	MLG Retract Cylinder assy	Douglas
ARG7025-5525	MLG Retract Cylinder assy	Douglas
ARG7025-5527	MLG Retract Cylinder assy	Douglas
ARG7025-5529	MLG Retract Cylinder assy	Douglas
ARG7076-5505	MLG Retract Cylinder assy	Douglas
ARG7076-5507	MLG Retract Cylinder assy	Douglas
ARG7076-5509	MLG Retract Cylinder assy	Douglas
ARG7076-5511	MLG Retract Cylinder assy	Douglas
ARG7173-5001	Tail Cone Hydraulic Cylinder	Douglas
ARG7220-5505	Trim Cylinder Relief Valve	Douglas
ARG7228-5001	Damper Valve assy	Douglas
ARG7228-5501	Damper Valve assy	Douglas
ARG7231-5001	Outboard Aileron Buzz Damper	Douglas
ARG7231-5501	Outboard Aileron Buzz Damper	Douglas
ARG7231-5505	Outboard Aileron Buzz Damper	Douglas
ARG7231-5507	Outboard Aileron Buzz Damper	Douglas
ARG7231-5509	Outboard Aileron Buzz Damper	Douglas
ARG7246-5501	MLG Latch Cylinder assy	Douglas
ARG7246-5503	MLG Latch Cylinder assy	Douglas
ARG7246-5505	MLG Latch Cylinder assy	Douglas
ARG7246-5507	MLG Latch Cylinder assy	Douglas
ARG7263-5001	MLG Downlock & Brake Gland ay	Douglas
ARG7266-5001	Trim Cylinder Gland assy	Douglas
ARG7376-5001	MLG Retract Cylinder assy	Douglas
ARG7376-5501	MLG Retract Cylinder assy	Douglas
ARG7376-5503	MLG Retract Cylinder assy	Douglas
ARG7376-5505	MLG Retract Cylinder assy	Douglas
ARG7376-5507	MLG Retract Cylinder assy	Douglas
ARG7376-5509	MLG Retract Cylinder assy	Douglas
ARG7376-5511	MLG Retract Cylinder assy	Douglas
ARG7376-5513	MLG Retract Cylinder assy	Douglas
ARG7376-5515	MLG Retract Cylinder assy	Douglas
ARG7376-5517	MLG Retract Cylinder assy	Douglas
ARG7432-5001	MLG Hydraulic Cylinder assy	Douglas

Repair_Capability_List_Excel

ARG7470-5001	Trim Cylinder Gland assy	Douglas
ARG7471-5001	MLG Downlock & Brake Gland ay	Douglas
ARH0052-501	Outboard Slat Drive Mechanism	Douglas
ARH0052-502	Outboard Slat Drive Mechanism	Douglas
ARH0052-503	Outboard Slat Drive Mechanism	Douglas
ARH0052-504	Outboard Slat Drive Mechanism	Douglas
ARH0052-505	Outboard Slat Drive Mechanism	Douglas
ARH0052-506	Outboard Slat Drive Mechanism	Douglas
ARH0052-507	Outboard Slat Drive Mechanism	Douglas
ARH0052-508	Outboard Slat Drive Mechanism	Douglas
ARH0052-509	Outboard Slat Drive Mechanism	Douglas
ARH0052-510	Outboard Slat Drive Mechanism	Douglas
ARH0052-511	Outboard Slat Drive Mechanism	Douglas
ARH0052-512	Outboard Slat Drive Mechanism	Douglas
ARH0052-513	Outboard Slat Drive Mechanism	Douglas
ARH0052-514	Outboard Slat Drive Mechanism	Douglas
ARH0052-515	Outboard Slat Drive Mechanism	Douglas
ARH0052-516	Outboard Slat Drive Mechanism	Douglas
ARH0052-517	Outboard Slat Drive Mechanism	Douglas
ARH0052-518	Outboard Slat Drive Mechanism	Douglas
ARH0052-519	Outboard Slat Drive Mechanism	Douglas
ARH0052-520	Outboard Slat Drive Mechanism	Douglas
ARH0052-521	Outboard Slat Drive Mechanism	Douglas
ARH0052-522	Outboard Slat Drive Mechanism	Douglas
ARH0052-523	Outboard Slat Drive Mechanism	Douglas
ARH0052-524	Outboard Slat Drive Mechanism	Douglas
ARH0052-525	Outboard Slat Drive Mechanism	Douglas
ARH0052-526	Outboard Slat Drive Mechanism	Douglas
ARH0052-529	Outboard Slat Drive Mechanism	Douglas
ARH0052-530	Outboard Slat Drive Mechanism	Douglas
ARH0052-531	Outboard Slat Drive Mechanism	Douglas
ARH0052-532	Outboard Slat Drive Mechanism	Douglas
ARH0500-501	Inboard Slat Drive Mechanism	Douglas
ARH0500-503	Inboard Slat Drive Mechanism	Douglas
ARH0500-505	Inboard Slat Drive Mechanism	Douglas
ARH0500-507	Inboard Slat Drive Mechanism	Douglas
ARH0670-2	Drooped LE Drive Mechanism ay	Douglas
ARH0670-501	Drooped LE Drive Mechanism ay	Douglas
ARH0670-502	Drooped LE Drive Mechanism ay	Douglas
ARH0670-503	Drooped LE Drive Mechanism ay	Douglas
ARH0670-504	Drooped LE Drive Mechanism ay	Douglas
ARH0670-505	Drooped LE Drive Mechanism ay	Douglas
ARH0670-506	Drooped LE Drive Mechanism ay	Douglas
ARH0670-507	Drooped LE Drive Mechanism ay	Douglas
ARH0670-508	Drooped LE Drive Mechanism ay	Douglas
ARH0670-509	Drooped LE Drive Mechanism ay	Douglas
ARH0670-510	Drooped LE Drive Mechanism ay	Douglas
ARH0670-511	Drooped LE Drive Mechanism ay	Douglas
ARH0670-512	Drooped LE Drive Mechanism ay	Douglas
ARH1210-501	Inboard Flap Vane Cartridge ay	Douglas
ARH1210-503	Inboard Flap Vane Cartridge ay	Douglas
ARH1210-505	Inboard Flap Vane Cartridge ay	Douglas
ARH1210-507	Inboard Flap Vane Cartridge ay	Douglas
ARH1410-501	Outboard Flap Vane Cartridge ay	Douglas
ARH1410-503	Outboard Flap Vane Cartridge ay	Douglas
ARH1410-507	Outboard Flap Vane Cartridge ay	Douglas
ARH1410-509	Outboard Flap Vane Cartridge ay	Douglas
AS-19570	Hydraulic Motor Pump	Vickers

Repair_Capability_List_Excel

AS-19570-B	Hydraulic Motor Pump	Vickers
AS-19570-B-GB1	Hydraulic Motor Pump	Vickers
AS-19570-C	Hydraulic Motor Pump	Vickers
AS-19570-C-GB1	Hydraulic Motor Pump	Vickers
AS-19593	Hydraulic Motor Pump	Vickers
AS-19593-A	Hydraulic Motor Pump	Vickers
AS-19593-B	Hydraulic Motor Pump	Vickers
AS-19593-C	Hydraulic Motor Pump	Vickers
AS66411-L-S666	Hydraulic Pump	Vickers
AS-66411-L-S666	Hydraulic Pump	Vickers
AS-66651-L8A	Hydraulic Pump	Vickers
AS-66691-L8A	Hydraulic Pump	Vickers
AS-66698-L8A	Hydraulic Pump	Vickers
ASG0014-5505	Manifold assy	Douglas
ASG0014-5507	Manifold assy	Douglas
ASG0014-5509	Manifold assy	Douglas
ASG0014-5511	Manifold assy	Douglas
ASG0014-5513	Manifold assy	Douglas
ASG0014-5517	Manifold assy	Douglas
ASG0014-5519	Manifold assy	Douglas
ASG0014-5521	Manifold assy	Douglas
ASG0014-5523	Manifold assy	Douglas
ASG0014-5525	Manifold assy	Douglas
ASG0014-5527	Manifold assy	Douglas
ASL0043-507	Rod assy	Airbus Industrie
AT0516AA1	Turbofan	Technofan
AT0518A00	Ground Cooling Fan	Technofan
AT0518A01	Ground Cooling Fan	Technofan
ATE960023	Door By-Pass Valve	FR Hitemp
AV11A1138	ELECTRO VALVE	ITT
AV11A1143	ELECTRO VALVE	ITT
AV11A1147	ELECTRO VALVE	ITT
AV11A1341	ELECTRO VALVE	ITT
AV11A1345	ELECTRO VALVE	ITT
AV13J5100	Motor Operated Valve assy	ITT Aerospace
AV13J5101	Motor Operated Valve assy	ITT Aerospace
AV13J5105	Motor Operated Valve assy	ITT Aerospace
AV13J5144	Motor Operated Valve assy	ITT Aerospace
AV13J5145	Motor Operated Valve assy	ITT Aerospace
AV13J5147	Motor Operated Valve assy	ITT Aerospace
AV13J5158	Motor Operated Valve assy	ITT Aerospace
AV14H5171	Brake Valve	ITT Aerospace Ctrlrs
AV14H5178	Brake Valve	ITT Aerospace Ctrlrs
AV14H5194	Brake Valve	ITT Aerospace Ctrlrs
AV16B1736D	Valve assy	ITT Aerospace Ctrlrs
AV16E3261C	Shut-Off Valve	ITT Aerospace
AV24E3134	2 Way Motor Valve	ITT Industries
AV24E3134-1	2 Way Motor Valve	ITT Industries
AV31	Fuel Valve Actuator	Mitsubishi
AV31-1	Fuel Valve Actuator	Mitsubishi
AVX-1818	Coupling	Lockheed
AW-1 7/8-15	Pressure Gage	Ametek
AW-1 7/8-15-AN	Pressure Gage	Ametek
AW-1 7/8-15-BP	Pressure Gage	Ametek
AW-1 7/8-15-CFF4	Pressure Gage	Ametek
AW-1 7/8-15-CIF4	Pressure Gage	Ametek
AW-1 7/8-15-K	Pressure Gage	Ametek
AW-1 7/8-17-AL	Pressure Gage	Ametek

Repair_Capability_List_Excel

AW-1 7/8-17-BP	Pressure Gage	Ametek
AW-1 7/8-17-CN13	Pressure Gage	Ametek
AW-1 7/8-17-CN15	Pressure Gage	Ametek
AW-1 7/8-17-CZ2	Pressure Gage	Ametek
AW-1 7/8-17-CZ4	Pressure Gage	Ametek
AW-1 7/8-17-CZ6	Pressure Gage	Ametek
AW-1 7/8-17-DAF4	Pressure Gage	Ametek
AW-1 7/8-17-DI	Pressure Gage	Ametek
AW-1 7/8-17-DR	Pressure Gage	Ametek
AW-1 7/8-17-GF2	Pressure Gage	Ametek
AW-1 7/8-17-GF4	Pressure Gage	Ametek
AW-1 7/8-17-JF5	Pressure Gage	Ametek
AW1530AD01	Pressure Gage	Ametek
AW17/8-17CN8	Pressure Gage	Ametek
AW-2 3/4-14-E	Pressure Gage	Ametek
AW-2 3/4-14-G	Pressure Gage	Ametek
AW-2 3/4-14-L	Pressure Gage	Ametek
AW-2 3/4-25-H	Pressure Gage	Ametek
AW-2 3/4-25-H3	Pressure Gage	Ametek
AW-2 3/4-25-L	Pressure Gage	Ametek
AW-2 3/4-40-B	Pressure Gage	Ametek
AW-2 3/4-40-B2	Pressure Gage	Ametek
AW2044AB01	Nitrogen Press Gage	Ametek
AW2044AB02	Nitrogen Press Gage	Ametek
AW2-21	Pressure Gage	Ametek
AW2-21A	Pressure Gage	Ametek
AW2-21B	Pressure Gage	Ametek
AW2-36	Pressure Gage	Ametek
AW2-36A	Pressure Gage	Ametek
AW2-36B	Pressure Gage	Ametek
AW2-36C	Pressure Gage	Ametek
AW2835AE01	Cabin Altimeter	Ametek
AW2835AE02	Cabin Altimeter Diff. Press. Indicator	Ametek
AW2835AF01	Cabin Differentgial Press Indicator	Ametek
AYG7027-5007	Reservoir assy	Douglas
AYG7027-5017	Reservoir assy	Douglas
AYG7027-5019	Reservoir assy	Douglas
AYG7027-5023	Reservoir assy	Douglas
AYG7027-5501	Reservoir assy	Douglas
AYG7027-5503	Reservoir assy	Douglas
AYG7027-5505	Reservoir assy	Douglas
AYG7027-5513	Reservoir assy	Douglas
AYG7027-5515	Reservoir assy	Douglas
AYG7027-5517	Reservoir assy	Douglas
AYG7027-5519	Reservoir assy	Douglas
AYG7027-5521	Reservoir assy	Douglas
AYG7027-5523	Reservoir assy	Douglas
AYG7027-5525	Reservoir assy	Douglas
AYG7027-5527	Reservoir assy	Douglas
AYG7027-5529	Reservoir assy	Douglas
AYG7027-5531	Reservoir assy	Douglas
AYG7027-5533	Reservoir assy	Douglas
AYG7027-5535	Reservoir assy	Douglas
AYG7027-5537	Reservoir assy	Douglas
AYG7027-5539	Reservoir assy	Douglas
AYG7027-5541	Reservoir assy	Douglas
AYG7027-5543	Reservoir assy	Douglas
AYG7027-5545	Reservoir assy	Douglas

Repair_Capability_List_Excel

AYG7027-5547	Reservoir assy	Douglas
AYG7027-5549	Reservoir assy	Douglas
AYG7027-5551	Reservoir assy	Douglas
AYG7027-5553	Reservoir assy	Douglas
AYG7027-5555	Reservoir assy	Douglas
AYG7030-5503	Flap Control Valve	Douglas
AYG7030-5505	Flap Control Valve	Douglas
AYG7030-5507	Flap Control Valve	Douglas
AYG7030-5509	Flap Control Valve	Douglas
AYG7030-5511	Flap Control Valve	Douglas
AYG7030-5513	Flap Control Valve	Douglas
AYG7030-5515	Flap Control Valve	Douglas
AYG7030-5517	Flap Control Valve	Douglas
AYG7050-5501	Landing Gear Selector Valve ay	Douglas
AYG7050-5503	Landing Gear Selector Valve ay	Douglas
AYG7050-5505	Landing Gear Selector Valve ay	Douglas
AYG7050-5507	Landing Gear Selector Valve ay	Douglas
AYG7055-5501	Manifold assy	Douglas
AYG7055-5505	Manifold assy	Douglas
AYG7055-5507	Manifold assy	Douglas
AYG7055-5509	Manifold assy	Douglas
AYG7055-5511	Manifold assy	Douglas
AYG7055-5513	Manifold assy	Douglas
AYG7055-5517	Manifold assy	Douglas
AYG7055-5519	Manifold assy	Douglas
AYG7091-5503	Spoiler Drive Servo Actuator	Douglas
AYG7091-5505	Spoiler Drive Servo Actuator	Douglas
AYG7091-5509	Spoiler Drive Servo Actuator	Douglas
AYG7095-5501	Auxiliary Pump Manifold assy	Douglas
AYG7095-5505	Auxiliary Pump Manifold assy	Douglas
AYG7095-5507	Auxiliary Pump Manifold assy	Douglas
AYG7130-5001	Reversible Pump Manifold assy	Douglas
AYG7219-5001	CLG Downlock Cylinder assy	Douglas
AYG7224-5501	CLG Retract Cylinder assy	Douglas
AYG7272-1	Link assy	Douglas
AYG7272-501	Link assy	Douglas
AYG7272-503	Link assy	Douglas
AYG7323-5001	Flap Lock Valve assy	Douglas
AYG7323-5501	Flap Lock Valve assy	Douglas
AYG7323-5503	Flap Lock Valve assy	Douglas
AYG7323-5505	Flap Lock Valve assy	Douglas
AYG7323-5507	Flap Lock Valve assy	Douglas
AYG7323-5509	Flap Lock Valve assy	Douglas
AYG7415-5001	Cylinder	Douglas
AYG7422-5001	Valve Actuator	Douglas
AYLF9714	Temperature Sensor	Smiths Industries
AYLF9714-1	Temperature Sensor	Smiths Industries
B03AA1040	Dual Distributor De-Icing Valve	Liebherr Aerospace
B03AA1060	Dual Distributor De-Icing Valve	Liebherr Aerospace
B05JB1040	Check Valve	Goodrich Control Systems
B05JB1041	Check Valve	Goodrich Control Systems
B06CA0303	Valve assy	Goodrich Control Systems
B0706-10003	Sensor assy	Lear Siegler Inc
B07EF2000	Wing Water Drain	Liebherr Aerospace
B083723190	Gas Throttle Position Detector	Artus
B083723290	Gas Throttle Position Detector	Artus
B-1	Volt/Amp Meter	Hickok Electrical Inst
B10046	Wing Flap Screw	Beaver

Repair_Capability_List_Excel

B10046B	Wing Flap Screw	Beaver
B10046C	Wing Flap Screw	Beaver
B10046D	Wing Flap Screw	Beaver
B10047	Wing Flap Screw	Beaver
B10047B	Wing Flap Screw	Beaver
B10047C	Wing Flap Screw	Beaver
B10047D	Wing Flap Screw	Beaver
B-11	Thermocouple Indicator	Weston Aerospace
B11174-1	OXY FILL VALVE	CARLETON
B-11299	Ball Screw assy	Beaver
B13500-1	OXY FILL VALVE	CARLETON
B13-941-22-05-1A	Clock	Revue Thommen
B13-944-22-05-1F	Clock	Revue Thommen
B13-944-42-05	Clock	Revue Thommen
B13-944-42-05-1F	Clock	Revue Thommen
B1425-5	Fuel Load Selector	Simmonds Precision
B14GF1502	Pressure Reg. & Shut-Off Valve	Liebherr Aerospace
B14GF1503	Pressure Reg. & Shut-Off Valve	Liebherr Aerospace
B1540	Motor assy	Auxilec
B156A0204	Pressure Reducing Valve	Goodrich Control Systems
B1584	Stick Shaker	AUEC
B1590	Stick Shaker	AUEC
B15GA0204	Valve assy	Lucas Aerospace
B15GA0204A	Valve assy	Lucas Aerospace
B-16	Compass	Kollsman
B1763H1	Filter	Fairey Hydraulics
B1795H1	Filter	Fairey Hydraulics
B17CA1041	Regulating Valve	Liebherr Aerospace
B17CA1042	Regulating Valve	Liebherr Aerospace
B-1801D	Wing Flap Screw	Beaver
B18834	Actuator assy	Beaver Aerospace
B18834B	Actuator assy	Beaver Aerospace
B18D18	Air/Oil Heat Exchanger	Honeywell
B18DA1000	Pressure Reducing Valve	Goodrich Control Systems
B18DA1001	Pressure Reducing Valve	Goodrich Control Systems
B-2	Thermocouple Indicator	Weston Aerospace
B-20	Oil Pressure Indicator	Kollsman
B20745	Wing Flap Screw	Beaver
B20745C	Wing Flap Screw	Beaver
B20745D	Wing Flap Screw	Beaver
B227	Relay	Hartman
B254ADM1	Inverter Processor	Thales
B2CM0	Yaw Damper	Thales Avionics
B30839-10-006	Barometric Altimeter	Kollsman
B33025-1	Inboard Aileron Servo Valve	Moog
B33025-2	Inboard Aileron Servo Valve	Moog
B33025-3	Inboard Aileron Servo Valve	Moog
B33026-001B	Servo valve	Moog
B33026-004	Servo valve	Moog
B33026-1	Outboard Aileron Servo Valve	Moog
B33026-2	Outboard Aileron Servo Valve	Moog
B33026-3	Outboard Aileron Servo Valve	Moog
B36689-10-004	Cabin Altim & Differential Press Indicator	Kollsman
B36689-10-013	Cabin Altim & Differential Press Indicator	Kollsman
B38LC1504	Shut-Off Valve	Goodrich Control Systems
B38LC1505	Shut-Off Valve	Goodrich Control Systems
B38LC1506	Shut-Off Valve	Goodrich Control Systems
B38LC1507	Shut-Off Valve	Goodrich Control Systems

Repair_Capability_List_Excel

B38QA6505 Amdt A	Shut-Off Valve	Goodrich Control Systems
B38QA6505 Amdt B	Shut-Off Valve	Goodrich Control Systems
B38QA6505-001	Shut-Off Valve	Goodrich Control Systems
B38QA6505-018	Shut-Off Valve	Goodrich Control Systems
B38QA6505A	Shut-Off Valve	Goodrich Control Systems
B38QA6505B	Shut-Off Valve	Goodrich Control Systems
B-403-11394-103	Starter Control Valve	Elliott
B40CD0401	Fan assy	Goodrich Control Systems
B40CF0401	Fan assy	Goodrich Control Systems
B40NA1500	Smoke Detection Fan	Goodrich Control Systems
B4150B	Taxi Light	Grimes Aerospace
B4150B-1	Taxi Light	Grimes Aerospace
B4150B-2	Taxi Light	Grimes Aerospace
B4150B-24	Taxi Light	Grimes Aerospace
B4150B-2-4587	Taxi Light	Grimes Aerospace
B4150B-2-4596	Taxi Light	Grimes Aerospace
B4150B-3-4594	Taxi Light	Grimes Aerospace
B4150B-3-4626	Taxi Light	Grimes Aerospace
B4150B-4	Taxi Light	Grimes Aerospace
B4150B-4-4587	Taxi Light	Grimes Aerospace
B4150B-4-4596	Taxi Light	Grimes Aerospace
B4150B-4501	Taxi Light	Grimes Aerospace
B4150B-4509	Taxi Light	Grimes Aerospace
B4150B-4587	Taxi Light	Grimes Aerospace
B4150B-4589	Taxi Light	Grimes Aerospace
B4150B-4593	Taxi Light	Grimes Aerospace
B4150B-4594	Taxi Light	Grimes Aerospace
B4150B-4595	Taxi Light	Grimes Aerospace
B4150B-4596	Taxi Light	Grimes Aerospace
B4150B-4626	Taxi Light	Grimes Aerospace
B4150B-5-4594	Taxi Light	Grimes Aerospace
B4150B-5-4595	Taxi Light	Grimes Aerospace
B4150B-6-4587	Taxi Light	Grimes Aerospace
B4150B-7-4587	Taxi Light	Grimes Aerospace
B4150B-7-4596	Taxi Light	Grimes Aerospace
B4150B-7-4626	Taxi Light	Grimes Aerospace
B42AA1021	Valve assy	Goodrich Control Systems
B42AC8201	Valve assy	Goodrich Control Systems
B42CA1000	Valve assy	Goodrich Control Systems
B42CA1010	Valve assy	Goodrich Control Systems
B42CA2000	Non-Return Valve	Goodrich Control Systems
B42CA2001	Non-Return Valve	Goodrich Control Systems
B42CA2002	Non-Return Valve	Goodrich Control Systems
B42CA2003	Non-Return Valve	Goodrich Control Systems
B430-1	Circuit Breaker Unit	CII Technologies
B430Z	Circuit Breaker Unit	CII Technologies
B48AB1000	Safety Valve	Goodrich Control Systems
B6245	Dome Light	Grimes Aerospace
B6245-303	Dome Light	Grimes Aerospace
B6245-305	Dome Light	Grimes Aerospace
B6245R	Dome Light	Grimes Aerospace
B63D89	CSD Oil Heat Exchanger	Grimes Aerospace
B66182	Fan	Airscrew Howden
B7020	Temp Sensor	Scientific Instruments
B7040-2	Anticipator Temp Sensor	Scientific Instruments
B7050	Anticipator Temp Sensor	Scientific Instruments
B7080	Anticipator Temp Sensor	Scientific Instruments
B7090	Anticipator Temp Sensor	Scientific Instruments

Repair_Capability_List_Excel

B7100	Anticipator Temp Sensor	Scientific Instruments
B711-1	Hydraulic Qty Indicator	Goodrich
B711-3	Hydraulic Qty Indicator	Goodrich
B711-4	Hydraulic Qty Indicator	Goodrich
B711-5	Hydraulic Qty Indicator	Goodrich
B711-6	Hydraulic Qty Indicator	Goodrich
B711-7	Hydraulic Qty Indicator	Goodrich
B712-1	Hydraulic Qty Indicator	Goodrich
B712-2	Hydraulic Qty Indicator	Goodrich
B712-4	Hydraulic Qty Indicator	Goodrich
B7150	Probe	Scientific Instruments
B71505-001	Spoiler Servo Valve	Moog
B7160	Sensor	Scientific Instruments
B7170	Sensor	Scientific Instruments
B7180	Sensor	Scientific Instruments
B7250	Temp Sensor	Scientific Instruments
B7260	Compressor Outlet Temp. Sensor	Scientific Instruments
B7270	Mixer Temp Sensor	Scientific Instruments
B7280	Temperature Sensor	Scientific Instruments
B7290	Temperature Sensor	Scientific Instruments
B7300	Temperature Sensor	Scientific Instruments
B7310	Duct Overheat Sensor	Scientific Instruments
B7320	Temperature Sensor	Scientific Instruments
B74012-1	Servo Actuator	Moog
B-9	Thermometer	Weston Aerospace
B97-13-603	APU Shut-Off Valve	Intertechnique
B97-13-653	APU Shut-Off Valve	Intertechnique
B97-13-654	APU Shut-Off Valve	Intertechnique
B97-13-656	APU Shut-Off Valve	Intertechnique
B97-19-452	Hydraulic Shut-Off Valve	Intertechnique
B97-19-453	Hydraulic Shut-Off Valve	Intertechnique
B97-19-454	Hydraulic Shut-Off Valve	Intertechnique
B97-31-653	Fuel Shut-Off Valve	Intertechnique
B97-31-655	Fuel Shut-Off Valve	Intertechnique
B97-31-656	Fuel Shut-Off Valve	Intertechnique
B97-31-657	Fuel Shut-Off Valve	Intertechnique
B97-38-602	Engine Shut-Off Valve	Intertechnique
B97-38-663	Crossflow Shut-Off Valve	Intertechnique
B97-38-665	Crossflow Shut-Off Valve	Intertechnique
B97-38-666	Crossflow Shut-Off Valve	Intertechnique
B97-38-668	Crossflow Shut-Off Valve	Intertechnique
B97-51-601	Fuel Valve	Intertechnique
B97-51-603	Crossflow Shut-Off Valve	Intertechnique
B97CA1090	Shut-Off Anti-Icing Valve	Liebherr Aerospace
B97E51-604	Low Pressure Valve	Intertechnique
B97E51-604A	Low Pressure Valve	Intertechnique
B97E51-655	Low Pressure Valve	Intertechnique
B97E541-655	Low Pressure Valve	Intertechnique
B97H19-601	Valve assy	Intertechnique
B97H19-601A	Open/Shut Fuel Valve	Intertechnique
B97H19-601B	Valve assy	Intertechnique
B97H19-602	Valve assy	Intertechnique
B97H38-602	1 1/2" Valve assy	Intertechnique
B97H38-603	1 1/2" Valve assy	Intertechnique
B97H38-604	1 1/2" Valve assy	Intertechnique
B97H51-601	Valve assy	Intertechnique
B97H51-601A	Valve assy	Intertechnique
B97H51-601B	Valve assy	Intertechnique

Repair_Capability_List_Excel

B97H51-604	2" Valve assy	Intertechnique
B97H51-605	2" Valve assy	Intertechnique
B97H51-606	2" Valve assy	Intertechnique
B97H51-607	2" Valve assy	Intertechnique
B97H63-601	Fuel Valve	Intertechnique
B97H63-602	Fuel Valve	Intertechnique
B97H63-604	Fuel Valve	Intertechnique
B97N19-201	Fresh Vent Valve	Intertechnique
B97P38-601	Transfer Valve	Intertechnique
B97P38-602	Transfer Valve	Intertechnique
B97W99-115A	Actuator	Intertechnique
B97W99-115B	Actuator	Intertechnique
B97W99-116B	Actuator	Intertechnique
BED00101	Proximity Detector Module Unit	Crane-Eldec
BED00101A	Proximity Detector Module Unit	Crane-Eldec
BED00101B	Proximity Detector Module Unit	Crane-Eldec
BED00101B01	Proximity Detector Module Unit	Crane-Eldec
BED00101C	Proximity Detector Module Unit	Crane-Eldec
BED00101D	Proximity Detector Module Unit	Crane-Eldec
BED201	Proximity System Electronics Unit	Crane-Eldec
BED201-1	Proximity System Electronics Unit	Crane-Eldec
BHC1000	Hydraulic Control Unit	SAMM
BHC1000-1	Flap Block Valve	Goodrich Actuation Syst
BHC1000-2	Flap Block Valve	Goodrich Actuation Syst
BHC1000-3	Flap Block Valve	Goodrich Actuation Syst
BHC1020-1	Hydraulic Control Unit	SAMM
BHC1021	Spoiler Block Valve	Goodrich Actuation Syst
BHC1060-03	Priority Valve	Goodrich Control Systems
BHC1060-04	Hydraulic Control Unit	Goodrich Control Systems
BPS7-2	Emergency Exit Lighting Supply	Radiant
BPS7-3	Emergency Exit Lighting Supply	Radiant
BR1660A	Jack Panel	TEAM
BR1660AP01	Jack Panel	TEAM
BR1660B	Jack Panel	TEAM
BR1660C	Jack Panel	TEAM
BR1660D	Jack Panel	TEAM
BR1660F	Jack Panel	TEAM
BR1660H	Jack Panel	TEAM
BR1660J	Jack Panel	TEAM
BR1660K	Jack Panel	TEAM
BWJ7007-511	Drive Unit	Douglas
BYG7004-5511	Brake Control Valve assy	Douglas
BYG7004-5515	Brake Control Valve assy	Douglas
BYLB50142	Valve & Actuator	Barber-Colman
C-00276-1	Cabin Fan Controller	Lamar
C07202-2	Control Shaker assy	Safe Flight
C-07202-2	Shaker Control	Coaxial
C07202-2MODA	Control Shaker assy	Safe Flight
C07202-3	Control Shaker assy	Safe Flight
C07202-3MODA	Control Shaker assy	Safe Flight
C07202-5	Control Shaker assy	Safe Flight
C07202-5MODA	Control Shaker assy	Safe Flight
C-10	Pressure Gage	Ametek
C-11	Thermometer	Edison
C11VQ0030	Fuel Electric Pump	Goodrich Control Systems
C1220Y	Stepped Drum Switch	Dowty Aerospace
C1224Y	Undercarriage Position Indicator	Dowty Aerospace
C1224YMK10	Undercarriage Position Indicator	Dowty Aerospace

Repair_Capability_List_Excel

C12CB0010	Fuel Pump	Lucas Aerospace
C12CB0011	Fuel Pump	Lucas Aerospace
C12CB0012	Fuel Pump	Lucas Aerospace
C-13	Pressure Gage	Ametek
C137/M1	Valve assy	FR Hitemp
C137/M11	Valve assy	FR Hitemp
C137949	Srewjack	ECE
C-13A	Thermometer	Weston Aerospace
C-13B	Thermometer	Weston Aerospace
C14129BA	Altimeter	Thales Avionics
C14130AA	Altimeter	Thales Avionics
C14135AB	RH Air Data Probe	Thales Avionics
C14135BB	LH Air Data Probe	Thales Avionics
C143123-2	Torque Motor Dual Valve	Hamilton Sundstrand
C143123-4	Torque Motor Dual Valve	Hamilton Sundstrand
C146440-1	Propeller Module Valve	Hamilton Sundstrand
C146440-2	Propeller Module Valve	Hamilton Sundstrand
C-16	Pressure Indicator	Kollsman
C16177AC	AOA Sensor	Thales Avionics
C16193AC	Standby Air Data Probe	Thales Avionics
C16197AA	Standby Altimeter	Thales Avionics
C16222AA01	Torque Indicator	Thales Avionics
C16235AA	Brake Pressure Indicator	Thales Avionics
C16258AA	AOA Sensor	Thales Avionics
C16268AB	Rudder Trim Position Indicator	Thales Avionics
C16269AB	Aileron Trim Position Indicator	Thales Avionics
C16291AA	AOA Sensor	Thales
C16363AA	AOA Sensor	Thales
C17061AB	Prime Power Supply Module	Thales Avionics
C17LR0020	Feeder Tank Jet Pump	Goodrich Control Systems
C17MQ0020	Jet Pump	Goodrich Control Systems
C19AA0121	Blue Hydraulic Reservoir	Goodrich Control Systems
C19AA0122	Blue Hydraulic Reservoir	Goodrich Control Systems
C19AA0123	Blue Hydraulic Reservoir	Goodrich Control Systems
C19AA0124	Blue Hydraulic Reservoir	Goodrich Control Systems
C19AA0125	Blue Hydraulic Reservoir	Goodrich Control Systems
C19AA0131	Blue Hydraulic Reservoir	Goodrich Control Systems
C19AA0132	Blue Hydraulic Reservoir	Goodrich Control Systems
C19AA0133	Blue Hydraulic Reservoir	Goodrich Control Systems
C19AA0134	Blue Hydraulic Reservoir	Goodrich Control Systems
C19AA0181	Blue Hydraulic Reservoir	Goodrich Control Systems
C19AA0182	Blue Hydraulic Reservoir	Goodrich Control Systems
C19AA0191	Blue Hydraulic Reservoir	Goodrich Control Systems
C19AA0192	Blue Hydraulic Reservoir	Goodrich Control Systems
C19AA0222	Yellow Reservoir assy	Goodrich Control Systems
C19AA0223	Yellow Reservoir assy	Goodrich Control Systems
C19AA0224	Yellow Reservoir assy	Goodrich Control Systems
C19AA0225	Yellow Reservoir assy	Goodrich Control Systems
C19AA0231	Yellow Reservoir assy	Goodrich Control Systems
C19AA0232	Yellow Reservoir assy	Goodrich Control Systems
C19AA0233	Yellow Reservoir assy	Goodrich Control Systems
C19AA0234	Yellow Reservoir assy	Goodrich Control Systems
C19AA0281	Yellow Reservoir assy	Goodrich Control Systems
C19AA0291	Yellow Reservoir assy	Goodrich Control Systems
C19AA0321	Green Hydraulic Reservoir	Goodrich Control Systems
C19AA0322	Green Hydraulic Reservoir	Goodrich Control Systems
C19AA0323	Green Hydraulic Reservoir	Goodrich Control Systems
C19AA0324	Green Hydraulic Reservoir	Goodrich Control Systems

Repair_Capability_List_Excel

C19AA0325	Green Hydraulic Reservoir	Goodrich Control Systems
C19AA0331	Green Hydraulic Reservoir	Goodrich Control Systems
C19AA0332	Green Hydraulic Reservoir	Goodrich Control Systems
C19AA0333	Green Hydraulic Reservoir	Goodrich Control Systems
C19AA0334	Green Hydraulic Reservoir	Goodrich Control Systems
C19AA0341	Green Hydraulic Reservoir	Goodrich Control Systems
C19AA0351	Green Hydraulic Reservoir	Goodrich Control Systems
C19AA0361	Green Hydraulic Reservoir	Goodrich Control Systems
C19AA0371	Green Hydraulic Reservoir	Goodrich Control Systems
C19AA0381	Green Hydraulic Reservoir	Goodrich Control Systems
C19AA0391	Green Hydraulic Reservoir	Goodrich Control Systems
C19BQ0011	Blue Hydraulic Reservoir	Goodrich Control Systems
C19BQ0012	Blue Hydraulic Reservoir	Goodrich Control Systems
C19BQ0013	Blue Hydraulic Reservoir	Goodrich Control Systems
C19BQ0014	Blue Hydraulic Reservoir	Goodrich Control Systems
C19DS0011	Yellow Hydraulic Reservoir	Goodrich Control Systems
C19DS0012	Yellow Hydraulic Reservoir	Goodrich Control Systems
C19DS0013	Yellow Hydraulic Reservoir	Goodrich Control Systems
C19DS0014	Yellow Hydraulic Reservoir	Goodrich Control Systems
C19DS0021	Green Hydraulic Reservoir	Goodrich Control Systems
C19DS0022	Green Hydraulic Reservoir	Goodrich Control Systems
C19DS0023	Green Hydraulic Reservoir	Goodrich Control Systems
C19DS0024	Green Hydraulic Reservoir	Goodrich Control Systems
C19DS0030	Blue Reservoir assy	Goodrich Control Systems
C19DS0040	Blue Reservoir assy	Goodrich Control Systems
C19ES0010	Yellow Reservoir assy	Goodrich Control Systems
C19ES0020	Yellow Reservoir assy	Goodrich Control Systems
C19ES0112	Yellow Reservoir assy	Goodrich Control Systems
C19ES0113	Yellow Reservoir assy	Goodrich Control Systems
C19FS0010	Green Hydraulic Reservoir	Goodrich Control Systems
C19FS0012	Green Hydraulic Reservoir	Goodrich Control Systems
C19FS0020	Green Hydraulic Reservoir	Goodrich Control Systems
C19FS0022	Green Hydraulic Reservoir	Goodrich Control Systems
C19FS0030	Green Hydraulic Reservoir	Goodrich Control Systems
C19FS0032	Green Hydraulic Reservoir	Goodrich Control Systems
C19FS0040	Green Hydraulic Reservoir	Goodrich Control Systems
C19FS0042	Green Hydraulic Reservoir	Goodrich Control Systems
C19GS0012	Blue Reservoir assy	Goodrich Control Systems
C19GS0013	Blue Reservoir assy	Goodrich Control Systems
C19JS0012	Green Hydraulic Reservoir	Goodrich Control Systems
C19JS0013	Green Hydraulic Reservoir	Goodrich Control Systems
C2001-1	Pressure Switch	Bristol Babcock
C20025	Union assy	Messier-Bugatti
C20030015	Brake System Control Box	Messier-Bugatti
C20030016	Brake System Control Box	Messier-Bugatti
C20030017	Brake System Control Box	Messier-Bugatti
C20030020	Brake System Control Box	Messier-Bugatti
C20030021	Brake System Control Box	Messier-Bugatti
C20030-12	Brake System Control Box	Messier-Bugatti
C20030-14	Brake System Control Box	Messier-Bugatti
C20030-2	Brake System Control Box	Messier-Bugatti
C20040	Coupling assy	Messier-Bugatti
C2005-1	Pressure Switch	Bristol Babcock
C20086000	NLG Drive Tachometer Mechanism	Messier-Bugatti
C20086100	NLG Drive Tachometer Mechanism	Messier-Bugatti
C20087000	Tachometer Fitting	Messier-Bugatti
C20087001	Tachometer Fitting	Messier-Bugatti
C20102000	Pressure Transducer	Messier-Bugatti

Repair_Capability_List_Excel

C20103100	Servo Valve	Messier-Bugatti
C20103100-1	Servo Valve	Messier-Bugatti
C20103500	Servo Valve	Messier-Bugatti
C20103520	Servo Valve	Messier-Bugatti
C20104000	Master Valve	Messier-Bugatti
C20105000	Tachometer	Messier-Bugatti
C20105000-1	Tachometer	Messier-Bugatti
C20105000A	DC Tachometer Generator	Messier-Bugatti
C20105100	Tachometer	Messier-Bugatti
C201-1500-1	Solenoid Valve	Aro Corporation
C201-1600-1	Solenoid Valve	Aro Corporation
C20118000	Brake Pedal Transmitter	Messier-Bugatti
C201-1800-1	Solenoid Valve	Aro Corporation
C201-1800-5	Solenoid Valve	Aro Corporation
C201-1811-05	Rain Repellent System	Crane
C20119000	Brake Cooling Fan	Technofan
C201-1900-1	Solenoid Valve	Aro Corporation
C20119100	Fan & Tachometer Drive assy	Messier-Bugatti
C201-2500-1	Rain Repellent System	Crane
C201-2500-20	Solenoid Valve	Aro Corporation
C201-2500-40	Solenoid Valve	Aro Corporation
C201-2600-17	Solenoid Valve	Aro Corporation
C201-2600-40	Solenoid Valve	Aro Corporation
C20129000	Thermocouple	Messier-Bugatti
C20196000	Drive Cap	Messier-Bugatti
C20198000	Drive Cap	Messier-Bugatti
C20204000	Thermocouple	Messier-Bugatti
C20207000	Drive Cap	Messier-Bugatti
C20215000	Brake Pedal Transmitter	Messier-Bugatti
C20215000A	Brake Pedal Transmitter	Messier-Bugatti
C2021622C2427	Braking & Steering Control Unit	Messier-Bugatti
C20229000	Thermocouple	Messier-Bugatti
C20244000	Drive Cap	Messier-Bugatti
C20250000	Tachometer Fitting	Messier-Bugatti
C20288000-1	Brake Accumulator	Messier-Bugatti
C20288000-2	Brake Accumulator	Messier-Bugatti
C20290000	Tachometer Drive	Messier-Bugatti
C2029333B3B3B	BRAKE/STEER UNIT	MESSIER BUGATT
C2029333C3C3C	BRAKE/STEER UNIT	MESSIER BUGATT
C2029334B4B4B	Braking & Stearing Control Unit	Messier - Bugatti
C20312	Complete Fan	Messier-Bugatti
C20312-0-1	Complete Fan	Messier-Bugatti
C20312-0-2	Complete Fan	Messier-Bugatti
C20312100	Complete Fan	Messier-Bugatti
C20312-3	Complete Fan	Messier-Bugatti
C20327000	Servo Valve	Messier-Bugatti
C20328000	Tachometer Drive	Messier-Bugatti
C20374000-1	Brake Selector Valve	Messier-Bugatti
C20374000-2	Brake Selector Valve	Messier-Bugatti
C20467000	Drive Shaft Tachometer	Technofan
C22089	Electrical Loom	Messier-Bugatti
C22147000-2	Actuating Cylinder	Messier-Bugatti
C22147000-3	Actuating Cylinder	Messier-Bugatti
C22147000-4	Actuating Cylinder	Messier-Bugatti
C22147000-5	Actuating Cylinder	Messier-Bugatti
C22147300	Actuating Cylinder	Messier-Bugatti
C22147300-1	Actuating Cylinder	Messier-Bugatti
C22147300-2	Actuating Cylinder	Messier-Bugatti

Repair_Capability_List_Excel

C22740	Steering Control Unit	Messier-Bugatti
C22740005	Steering Control Unit	Messier-Bugatti
C22740005-1	Steering Control Unit	Messier-Bugatti
C22740005-2	Steering Control Unit	Messier-Bugatti
C22740-2	Steering Control Unit	Messier-Bugatti
C22740-3	Steering Control Unit	Messier-Bugatti
C22740-303	Steering Control Unit	Messier-Bugatti
C22740-304	Steering Control Unit	Messier-Bugatti
C22740-305	Steering Control Unit	Messier-Bugatti
C22740-3-1	Steering Control Unit	Messier-Bugatti
C22740-3-2	Steering Control Unit	Messier-Bugatti
C22740-405	Steering Control Unit	Messier-Bugatti
C22740-4-1	Steering Control Unit	Messier-Bugatti
C22740-4-2	Steering Control Unit	Messier-Bugatti
C22753	Visual Indicator	Messier-Bugatti
C22797-1	Dual Connecting Block	Messier-Bugatti
C22797-5	Dual Connecting Block	Messier-Bugatti
C22798-1	Dual Connecting Block	Messier-Bugatti
C22798-5	Dual Connecting Block	Messier-Bugatti
C22839	Spring Assy	Messier-Bugatti
C22839-0-1	Spring Assy	Messier-Bugatti
C22839-0-2	Spring Assy	Messier-Bugatti
C22839-3	Spring Assy	Messier-Bugatti
C22888-2	Electrical Loom	Messier-Bugatti
C22893-1	Electrical Loom	Messier-Bugatti
C22894-1	Electrical Loom	Messier-Bugatti
C22895-2	Electrical Loom	Messier-Bugatti
C22896-2	Electrical Loom	Messier-Bugatti
C22897-1	Dual Connecting Block	Messier-Bugatti
C22897-2	Dual Connecting Block	Messier-Bugatti
C22897-4	Dual Connecting Block	Messier-Bugatti
C22897-5	Dual Connecting Block	Messier-Bugatti
C22898-1	Dual Connecting Block	Messier-Bugatti
C22898-2	Dual Connecting Block	Messier-Bugatti
C22898-4	Dual Connecting Block	Messier-Bugatti
C22898-5	Dual Connecting Block	Messier-Bugatti
C22964	Valve Block	Messier-Bugatti
C22964-2	Valve Block	Messier-Bugatti
C22965	Valve Block	Messier-Bugatti
C22965-1	Valve Block	Messier-Bugatti
C22997-1811	Main Landing Gear LH	Messier-Bugatti
C22997-1812	Main Landing Gear LH	Messier-Bugatti
C22997-1813	Main Landing Gear LH	Messier-Bugatti
C22997-1814	Main Landing Gear LH	Messier-Bugatti
C22997-1815	Main Landing Gear LH	Messier-Bugatti
C22997-1816	Main Landing Gear LH	Messier-Bugatti
C22997-1817	Main Landing Gear LH	Messier-Bugatti
C22997-2	Main Landing Gear LH	Messier-Bugatti
C22997-2-11	Main Landing Gear LH	Messier-Bugatti
C22997-2-13	Main Landing Gear LH	Messier-Bugatti
C22997-2-14	Main Landing Gear LH	Messier-Bugatti
C22997-2-15	Main Landing Gear LH	Messier-Bugatti
C22997-2-16	Main Landing Gear LH	Messier-Bugatti
C22997-2-17	Main Landing Gear LH	Messier-Bugatti
C22997-2-18	Main Landing Gear LH	Messier-Bugatti
C22997-2-19	Main Landing Gear LH	Messier-Bugatti
C22997-2-20	Main Landing Gear LH	Messier-Bugatti
C22997-2-21	Main Landing Gear LH	Messier-Bugatti

Repair_Capability_List_Excel

C22998-614	Main Landing Gear RH	Messier-Bugatti
C22998-6-2	Main Landing Gear RH	Messier-Bugatti
C22998-6-3	Main Landing Gear RH	Messier-Bugatti
C22998-6-4	Main Landing Gear RH	Messier-Bugatti
C22998-7	Main Landing Gear RH	Messier-Bugatti
C22998-7-1	Main Landing Gear RH	Messier-Bugatti
C22998-710	Main Landing Gear RH	Messier-Bugatti
C22998-711	Main Landing Gear RH	Messier-Bugatti
C22998-712	Main Landing Gear RH	Messier-Bugatti
C22998-713	Main Landing Gear RH	Messier-Bugatti
C22998-714	Main Landing Gear RH	Messier-Bugatti
C22998-715	Main Landing Gear RH	Messier-Bugatti
C22998-716	Main Landing Gear RH	Messier-Bugatti
C22998-717	Main Landing Gear RH	Messier-Bugatti
C22998-718	Main Landing Gear RH	Messier-Bugatti
C22998-719	Main Landing Gear RH	Messier-Bugatti
C22998-7-2	Main Landing Gear RH	Messier-Bugatti
C22998-720	Main Landing Gear RH	Messier-Bugatti
C22998-721	Main Landing Gear RH	Messier-Bugatti
C22998-7-3	Main Landing Gear RH	Messier-Bugatti
C22998-7-4	Main Landing Gear RH	Messier-Bugatti
C22998-7-5	Main Landing Gear RH	Messier-Bugatti
C22998-7-6	Main Landing Gear RH	Messier-Bugatti
C22998-7-7	Main Landing Gear RH	Messier-Bugatti
C229987-8	Main Landing Gear RH	Messier-Bugatti
C22998-7-8	Main Landing Gear RH	Messier-Bugatti
C229987-807	Main Landing Gear RH	Messier-Bugatti
C229987-808	Main Landing Gear RH	Messier-Bugatti
C229987-809	Main Landing Gear RH	Messier-Bugatti
C229987-8-1	Main Landing Gear RH	Messier-Bugatti
C229987-810	Main Landing Gear RH	Messier-Bugatti
C229987-811	Main Landing Gear RH	Messier-Bugatti
C229987-812	Main Landing Gear RH	Messier-Bugatti
C229987-813	Main Landing Gear RH	Messier-Bugatti
C229987-814	Main Landing Gear RH	Messier-Bugatti
C229987-815	Main Landing Gear RH	Messier-Bugatti
C229987-816	Main Landing Gear RH	Messier-Bugatti
C229987-817	Main Landing Gear RH	Messier-Bugatti
C229987-8-2	Main Landing Gear RH	Messier-Bugatti
C229987-8-3	Main Landing Gear RH	Messier-Bugatti
C229987-8-4	Main Landing Gear RH	Messier-Bugatti
C229987-8-5	Main Landing Gear RH	Messier-Bugatti
C229987-8-6	Main Landing Gear RH	Messier-Bugatti
C22998-7-9	Main Landing Gear RH	Messier-Bugatti
C22AA0021	Valve assy	Goodrich Control Systems
C22AA5021	Valve assy	Goodrich Control Systems
C22AN0010	Relief Valve	Goodrich Control Systems
C23005-5	Pitch Damper	Messier-Dowty
C23005-6	Pitch Damper	Messier-Dowty
C23032-1	Normal Actuating Cylinder	Messier-Bugatti
C23032-1-1	Normal Actuating Cylinder	Messier-Bugatti
C23032-1-3	Normal Actuating Cylinder	Messier-Bugatti
C23032-1-4	Normal Actuating Cylinder	Messier-Bugatti
C23032-1-5	Normal Actuating Cylinder	Messier-Bugatti
C23032-1-6	Normal Actuating Cylinder	Messier-Bugatti
C23032-1-7	Normal Actuating Cylinder	Messier-Bugatti
C23032-1-8	Normal Actuating Cylinder	Messier-Bugatti
C23032-2-1	Normal Actuating Cylinder	Messier-Bugatti

Repair_Capability_List_Excel

C23032-2-3	Normal Actuating Cylinder	Messier-Bugatti
C23032-2-4	Normal Actuating Cylinder	Messier-Bugatti
C23032-2-5	Normal Actuating Cylinder	Messier-Bugatti
C23032-2-6	Normal Actuating Cylinder	Messier-Bugatti
C23032-2-7	Normal Actuating Cylinder	Messier-Bugatti
C23032-2-8	Normal Actuating Cylinder	Messier-Bugatti
C23033-1	Emergency Actuating Cylinder	Messier-Bugatti
C23035	Actuating Cylinder	Messier-Bugatti
C23035-1-1	Actuating Cylinder	Messier-Bugatti
C23035-1-10	Actuating Cylinder	Messier-Bugatti
C23035-1-11	Actuating Cylinder	Messier-Bugatti
C23035-1-12	Actuating Cylinder	Messier-Bugatti
C23035-1-3	Actuating Cylinder	Messier-Bugatti
C23035-1-4	Actuating Cylinder	Messier-Bugatti
C23035-1-5	Actuating Cylinder	Messier-Bugatti
C23035-1-6	Actuating Cylinder	Messier-Bugatti
C23035-1-7	Actuating Cylinder	Messier-Bugatti
C23035-1-8	Actuating Cylinder	Messier-Bugatti
C23035-2-10	Actuating Cylinder	Messier-Bugatti
C23035-2-11	Actuating Cylinder	Messier-Bugatti
C23035-212	Actuating Cylinder	Messier-Bugatti
C23035-213	Actuating Cylinder	Messier-Bugatti
C23035-2-2	Actuating Cylinder	Messier-Bugatti
C23035-2-4	Actuating Cylinder	Messier-Bugatti
C23035-2-5	Actuating Cylinder	Messier-Bugatti
C23035-2-6	Actuating Cylinder	Messier-Bugatti
C23035-2-7	Actuating Cylinder	Messier-Bugatti
C23035-2-8	Actuating Cylinder	Messier-Bugatti
C23035-4	Actuating Cylinder	Messier-Bugatti
C23035-409	Actuating Cylinder	Messier-Bugatti
C23035-4-1	Actuating Cylinder	Messier-Bugatti
C23035-410	Actuating Cylinder	Messier-Bugatti
C23035-411	Actuating Cylinder	Messier-Bugatti
C23035-412	Actuating Cylinder	Messier-Bugatti
C23035-413	Actuating Cylinder	Messier-Bugatti
C23035-414	Actuating Cylinder	Messier-Bugatti
C23035-4-2	Actuating Cylinder	Messier-Bugatti
C23035-4-3	Actuating Cylinder	Messier-Bugatti
C23035-4-4	Actuating Cylinder	Messier-Bugatti
C23035-4-5	Actuating Cylinder	Messier-Bugatti
C23035-4-6	Actuating Cylinder	Messier-Bugatti
C23035-4-7	Actuating Cylinder	Messier-Bugatti
C23035-4-8	Actuating Cylinder	Messier-Bugatti
C23036-1307	Telescopic Strut	Messier-Bugatti
C230361402	Telescopic Strut	Messier-Bugatti
C23036-2	Telescopic Strut	Messier-Bugatti
C23036-205	Telescopic Strut	Messier-Bugatti
C23036-206	Telescopic Strut	Messier-Bugatti
C23036-2-1	Telescopic Strut	Messier-Bugatti
C23036-2-2	Telescopic Strut	Messier-Bugatti
C23036-2-3	Telescopic Strut	Messier-Bugatti
C23036-2-4	Telescopic Strut	Messier-Bugatti
C23036-3	Telescopic Strut	Messier-Bugatti
C23036-305	Telescopic Strut	Messier-Bugatti
C23036-306	Telescopic Strut	Messier-Bugatti
C23036-307	Telescopic Strut	Messier-Bugatti
C23036-3-1	Telescopic Strut	Messier-Bugatti
C23036-3-2	Telescopic Strut	Messier-Bugatti

Repair_Capability_List_Excel

C23036-3-3	Telescopic Strut	Messier-Bugatti
C23036-3-4	Telescopic Strut	Messier-Bugatti
C23036-4	Telescopic Strut	Messier-Bugatti
C23036-401	Telescopic Strut	Messier-Bugatti
C23036-402	Telescopic Strut	Messier-Bugatti
C23037-1207	Telescopic Strut assy	Messier-Bugatti
C23037-1307	Telescopic Strut assy	Messier-Bugatti
C23037-1402	Telescopic Strut assy	Messier-Bugatti
C23037-2	Telescopic Strut assy	Messier-Bugatti
C23037-206	Telescopic Strut assy	Messier-Bugatti
C23037-207	Telescopic Strut assy	Messier-Bugatti
C23037-2-1	Telescopic Strut assy	Messier-Bugatti
C23037-2-2	Telescopic Strut assy	Messier-Bugatti
C23037-2-3	Telescopic Strut assy	Messier-Bugatti
C23037-2-4	Telescopic Strut assy	Messier-Bugatti
C23037-2-5	Telescopic Strut assy	Messier-Bugatti
C23037-3	Telescopic Strut assy	Messier-Bugatti
C23037-305	Telescopic Strut assy	Messier-Bugatti
C23037-307	Telescopic Strut assy	Messier-Bugatti
C23037-3-1	Telescopic Strut assy	Messier-Bugatti
C23037-3-2	Telescopic Strut assy	Messier-Bugatti
C23037-3-3	Telescopic Strut assy	Messier-Bugatti
C23037-3-4	Telescopic Strut assy	Messier-Bugatti
C23037-4	Telescopic Strut assy	Messier-Bugatti
C23037-401	Telescopic Strut assy	Messier-Bugatti
C23037-402	Telescopic Strut assy	Messier-Bugatti
C23038-2	Actuating Cylinder	Goodrich Control Systems
C23038-2-1	Actuating Cylinder	Goodrich Control Systems
C23038-4	Actuating Cylinder	Goodrich Control Systems
C23038-403	Actuating Cylinder	Goodrich Control Systems
C23038-404	Actuating Cylinder	Goodrich Control Systems
C23038-4-1	Actuating Cylinder	Goodrich Control Systems
C23038-4-2	Actuating Cylinder	Goodrich Control Systems
C23042-2	Nose Landing Gear	Messier-Bugatti
C23042-2-1	Nose Landing Gear	Messier-Bugatti
C23042-2-10	Nose Landing Gear	Messier-Bugatti
C23042-2-12	Nose Landing Gear	Messier-Bugatti
C23042-2-13	Nose Landing Gear	Messier-Bugatti
C23042-2-14	Nose Landing Gear	Messier-Bugatti
C23042-215	Nose Landing Gear	Messier-Bugatti
C23042-216	Nose Landing Gear	Messier-Bugatti
C23042-217	Nose Landing Gear	Messier-Bugatti
C23042-218	Nose Landing Gear	Messier-Bugatti
C23042-219	Nose Landing Gear	Messier-Bugatti
C23042-2-2	Nose Landing Gear	Messier-Bugatti
C23042-220	Nose Landing Gear	Messier-Bugatti
C23042-2-3	Nose Landing Gear	Messier-Bugatti
C23042-2-4	Nose Landing Gear	Messier-Bugatti
C23042-2-5	Nose Landing Gear	Messier-Bugatti
C23042-2-6	Nose Landing Gear	Messier-Bugatti
C23042-2-7	Nose Landing Gear	Messier-Bugatti
C23042-2-8	Nose Landing Gear	Messier-Bugatti
C23042-2-9	Nose Landing Gear	Messier-Bugatti
C23042-3	Nose Landing Gear	Messier-Bugatti
C23042-3-1	Nose Landing Gear	Messier-Bugatti
C23042-3-10	Nose Landing Gear	Messier-Bugatti
C23042-311	Nose Landing Gear	Messier-Bugatti
C23042-312	Nose Landing Gear	Messier-Bugatti

Repair_Capability_List_Excel

C23042-313	Nose Landing Gear	Messier-Bugatti
C23042-314	Nose Landing Gear	Messier-Bugatti
C23042-315	Nose Landing Gear	Messier-Bugatti
C23042-316	Nose Landing Gear	Messier-Bugatti
C23042-317	Nose Landing Gear	Messier-Bugatti
C23042-318	Nose Landing Gear	Messier-Bugatti
C23042-319	Nose Landing Gear	Messier-Bugatti
C23042-3-2	Nose Landing Gear	Messier-Bugatti
C23042-3-3	Nose Landing Gear	Messier-Bugatti
C23042-3-4	Nose Landing Gear	Messier-Bugatti
C23042-3-5	Nose Landing Gear	Messier-Bugatti
C23042-3-6	Nose Landing Gear	Messier-Bugatti
C23042-3-7	Nose Landing Gear	Messier-Bugatti
C23042-3-8	Nose Landing Gear	Messier-Bugatti
C23042-3-9	Nose Landing Gear	Messier-Bugatti
C23049	Swivel Bearing	Messier-Bugatti
C23049-1	Swivel Bearing	Messier-Bugatti
C23049-101	Swivel Bearing	Messier-Bugatti
C23051	Connecting Block	Messier-Bugatti
C23052	Connecting Block	Messier-Bugatti
C23053	Connecting Block	Messier-Bugatti
C23054	Connecting Block	Messier-Bugatti
C23055	Connecting Block	Messier-Bugatti
C23056	Connecting Block	Messier-Bugatti
C23089	Interphone Box	Messier-Bugatti
C23089-0	Interphone Box	Messier-Bugatti
C23089-0-1	Interphone Box	Messier-Bugatti
C23089010	Interphone Box	Messier-Bugatti
C23089010-1	Interphone Box	Messier-Bugatti
C23089-0-2	Interphone Box	Messier-Bugatti
C23089-10	Interphone Box	Messier-Bugatti
C23089-1001	Interphone Box	Messier-Bugatti
C23093-1	Main Landing Gear LH	Messier-Bugatti
C23093-10	Main Landing Gear LH	Messier-Bugatti
C23093-1002	Main Landing Gear LH	Messier-Bugatti
C23093-1003	Main Landing Gear LH	Messier-Bugatti
C23093-1004	Main Landing Gear LH	Messier-Bugatti
C23093-1005	Main Landing Gear LH	Messier-Bugatti
C23093-1006	Main Landing Gear LH	Messier-Bugatti
C23093-1007	Main Landing Gear LH	Messier-Bugatti
C23093-1008	Main Landing Gear LH	Messier-Bugatti
C23093-10-1	Main Landing Gear LH	Messier-Bugatti
C23093-11	Main Landing Gear LH	Messier-Bugatti
C23093-1-10	Main Landing Gear LH	Messier-Bugatti
C23093-1102	Main Landing Gear LH	Messier-Bugatti
C23093-1103	Main Landing Gear LH	Messier-Bugatti
C23093-1104	Main Landing Gear LH	Messier-Bugatti
C23093-1105	Main Landing Gear LH	Messier-Bugatti
C23093-1106	Main Landing Gear LH	Messier-Bugatti
C23093-1107	Main Landing Gear LH	Messier-Bugatti
C23093-1108	Main Landing Gear LH	Messier-Bugatti
C23093-1109	Main Landing Gear LH	Messier-Bugatti
C23093-1-11	Main Landing Gear LH	Messier-Bugatti
C23093-11-1	Main Landing Gear LH	Messier-Bugatti
C23093-1110	Main Landing Gear LH	Messier-Bugatti
C23093-1111	Main Landing Gear LH	Messier-Bugatti
C23093-1112	Main Landing Gear LH	Messier-Bugatti
C23093-1113	Main Landing Gear LH	Messier-Bugatti

Repair_Capability_List_Excel

C23094-5-4	Main Landing Gear RH	Messier-Bugatti
C23094-5-5	Main Landing Gear RH	Messier-Bugatti
C23094-5-6	Main Landing Gear RH	Messier-Bugatti
C23094-5-7	Main Landing Gear RH	Messier-Bugatti
C23094-8	Main Landing Gear RH	Messier-Bugatti
C23094-803	Main Landing Gear RH	Messier-Bugatti
C23094-804	Main Landing Gear RH	Messier-Bugatti
C23094-805	Main Landing Gear RH	Messier-Bugatti
C23094-806	Main Landing Gear RH	Messier-Bugatti
C23094-807	Main Landing Gear RH	Messier-Bugatti
C23094-808	Main Landing Gear RH	Messier-Bugatti
C23094-809	Main Landing Gear RH	Messier-Bugatti
C23094-8-1	Main Landing Gear RH	Messier-Bugatti
C23094-810	Main Landing Gear RH	Messier-Bugatti
C23094-811	Main Landing Gear RH	Messier-Bugatti
C23094-812	Main Landing Gear RH	Messier-Bugatti
C23094-8-2	Main Landing Gear RH	Messier-Bugatti
C23094-9	Main Landing Gear RH	Messier-Bugatti
C23094-903	Main Landing Gear RH	Messier-Bugatti
C23094-904	Main Landing Gear RH	Messier-Bugatti
C23094-905	Main Landing Gear RH	Messier-Bugatti
C23094-906	Main Landing Gear RH	Messier-Bugatti
C23094-907	Main Landing Gear RH	Messier-Bugatti
C23094-908	Main Landing Gear RH	Messier-Bugatti
C23094-909	Main Landing Gear RH	Messier-Bugatti
C23094-9-1	Main Landing Gear RH	Messier-Bugatti
C23094-910	Main Landing Gear RH	Messier-Bugatti
C23094-911	Main Landing Gear RH	Messier-Bugatti
C23094-912	Main Landing Gear RH	Messier-Bugatti
C23094-913	Main Landing Gear RH	Messier-Bugatti
C23094-914	Main Landing Gear RH	Messier-Bugatti
C23094-915	Main Landing Gear RH	Messier-Bugatti
C23094-916	Main Landing Gear RH	Messier-Bugatti
C23094-917	Main Landing Gear RH	Messier-Bugatti
C23094-918	Main Landing Gear RH	Messier-Bugatti
C23094-919	Main Landing Gear RH	Messier-Bugatti
C23094-9-2	Main Landing Gear RH	Messier-Bugatti
C23103	Coupling	Messier-Bugatti
C23104	Coupling	Messier-Bugatti
C23105	Coupling	Messier-Bugatti
C23107	Pipes & Coupling	Messier-Bugatti
C23107-0-1	Pipes & Coupling	Messier-Bugatti
C23107-0-2	Pipes & Coupling	Messier-Bugatti
C23108	Pipes & Coupling	Messier-Bugatti
C23108-0-1	Pipes & Coupling	Messier-Bugatti
C23108-0-2	Pipes & Coupling	Messier-Bugatti
C23109	Strut assy Telescopic	Messier-Bugatti
C23109-0-1	Strut assy Telescopic	Messier-Bugatti
C23109-0-2	Strut assy Telescopic	Messier-Bugatti
C23109-0-3	Strut assy Telescopic	Messier-Bugatti
C23109-0-4	Strut assy Telescopic	Messier-Bugatti
C23109-1	Strut assy Telescopic	Messier-Bugatti
C23109-105	Strut assy Telescopic	Messier-Bugatti
C23109-106	Strut assy Telescopic	Messier-Bugatti
C23109-107	Strut assy Telescopic	Messier-Bugatti
C23109-108	Strut assy Telescopic	Messier-Bugatti
C23109-109	Strut assy Telescopic	Messier-Bugatti
C23109-1-1	Strut assy Telescopic	Messier-Bugatti

Repair_Capability_List_Excel

C23109-1109	Strut assy Telescopic	Messier-Bugatti
C23109-1-2	Strut assy Telescopic	Messier-Bugatti
C23109-1204	Strut assy Telescopic	Messier-Bugatti
C23109-1-3	Strut assy Telescopic	Messier-Bugatti
C23109-1-4	Strut assy Telescopic	Messier-Bugatti
C23109-2	Strut assy Telescopic	Messier-Bugatti
C23109-201	Strut assy Telescopic	Messier-Bugatti
C23109-202	Strut assy Telescopic	Messier-Bugatti
C23109-203	Strut assy Telescopic	Messier-Bugatti
C23109-204	Strut assy Telescopic	Messier-Bugatti
C23110-0-1	Telescopic Strut	Messier-Bugatti
C23110-0-2	Telescopic Strut	Messier-Bugatti
C23110-0-3	Telescopic Strut	Messier-Bugatti
C23110-0-4	Telescopic Strut	Messier-Bugatti
C23110-1	Telescopic Strut	Messier-Bugatti
C23110-105	Telescopic Strut	Messier-Bugatti
C23110-106	Telescopic Strut	Messier-Bugatti
C23110-107	Telescopic Strut	Messier-Bugatti
C23110-108	Telescopic Strut	Messier-Bugatti
C23110-1-1	Telescopic Strut	Messier-Bugatti
C23110-1107	Telescopic Strut	Messier-Bugatti
C23110-1108	Telescopic Strut	Messier-Bugatti
C23110-1-2	Telescopic Strut	Messier-Bugatti
C23110-1-3	Telescopic Strut	Messier-Bugatti
C23110-1-4	Telescopic Strut	Messier-Bugatti
C23118	Normal Cylinder assy	Messier-Bugatti
C23118-0-1	Normal Cylinder assy	Messier-Bugatti
C23118-0-2	Normal Cylinder assy	Messier-Bugatti
C23118-0-4	Normal Cylinder assy	Messier-Bugatti
C23118-0-5	Normal Cylinder assy	Messier-Bugatti
C23118-0-6	Normal Cylinder assy	Messier-Bugatti
C23118-0-7	Normal Cylinder assy	Messier-Bugatti
C23118-0-8	Normal Cylinder assy	Messier-Bugatti
C23118-0-9	Normal Cylinder assy	Messier-Bugatti
C23118-1-1	Normal Cylinder assy	Messier-Bugatti
C23118-1-2	Normal Cylinder assy	Messier-Bugatti
C23118-1-4	Normal Cylinder assy	Messier-Bugatti
C23118-1-5	Normal Cylinder assy	Messier-Bugatti
C23118-1-6	Normal Cylinder assy	Messier-Bugatti
C23118-1-7	Normal Cylinder assy	Messier-Bugatti
C23118-1-8	Normal Cylinder assy	Messier-Bugatti
C23118-1-9	Normal Cylinder assy	Messier-Bugatti
C23119	Cylinder assy	Messier-Bugatti
C23119-0-6	Cylinder assy	Messier-Bugatti
C23119-0-7	Cylinder assy	Messier-Bugatti
C23119-0-8	Cylinder assy	Messier-Bugatti
C23119-0-9	Cylinder assy	Messier-Bugatti
C23119-1-6	Cylinder assy	Messier-Bugatti
C23119-1-7	Cylinder assy	Messier-Bugatti
C23119-1-8	Cylinder assy	Messier-Bugatti
C23119-1-9	Cylinder assy	Messier-Bugatti
C23119500	Electrical Box	Messier- Dowty
C23120	Cylinder assy	Messier-Bugatti
C23129	Cylinder Actuator	Messier-Bugatti
C23129004	Cylinder Actuator	Messier-Bugatti
C23129004-1	Cylinder Actuator	Messier-Bugatti
C23129004-2	Cylinder Actuator	Messier-Bugatti
C23129004-3	Cylinder Actuator	Messier-Bugatti

Repair_Capability_List_Excel

C23129004-4	Cylinder Actuator	Messier-Bugatti
C23129-0-2	Cylinder Actuator	Messier-Bugatti
C23129-0-3	Cylinder Actuator	Messier-Bugatti
C23129-0-5	Cylinder Actuator	Messier-Bugatti
C23129-0-6	Cylinder Actuator	Messier-Bugatti
C23129-1	Cylinder Actuator	Messier-Bugatti
C23129-1-11	Cylinder Actuator	Messier-Bugatti
C23129-1-12	Cylinder Actuator	Messier-Bugatti
C23129-1-2	Cylinder Actuator	Messier-Bugatti
C23129-1-3	Cylinder Actuator	Messier-Bugatti
C23129-1-5	Cylinder Actuator	Messier-Bugatti
C23129-1-6	Cylinder Actuator	Messier-Bugatti
C23129-1-7	Cylinder Actuator	Messier-Bugatti
C23129-1-8	Cylinder Actuator	Messier-Bugatti
C23129-1-9	Cylinder Actuator	Messier-Bugatti
C23129-2	Cylinder Actuator	Messier-Bugatti
C23129-2-11	Cylinder Actuator	Messier-Bugatti
C23129-2-12	Cylinder Actuator	Messier-Bugatti
C23129-213	Cylinder Actuator	Messier-Bugatti
C23129-214	Cylinder Actuator	Messier-Bugatti
C23129-2-2	Cylinder Actuator	Messier-Bugatti
C23129-2-3	Cylinder Actuator	Messier-Bugatti
C23129-2-4	Cylinder Actuator	Messier-Bugatti
C23129-2-6	Cylinder Actuator	Messier-Bugatti
C23129-2-7	Cylinder Actuator	Messier-Bugatti
C23129-2-8	Cylinder Actuator	Messier-Bugatti
C23129-2-9	Cylinder Actuator	Messier-Bugatti
C23129-3	Cylinder Actuator	Messier-Bugatti
C23129-308	Cylinder Actuator	Messier-Bugatti
C23129-309	Cylinder Actuator	Messier-Bugatti
C23129-3-1	Cylinder Actuator	Messier-Bugatti
C23129-310	Cylinder Actuator	Messier-Bugatti
C23129-311	Cylinder Actuator	Messier-Bugatti
C23129-312	Cylinder Actuator	Messier-Bugatti
C23129-313	Cylinder Actuator	Messier-Bugatti
C23129-3-2	Cylinder Actuator	Messier-Bugatti
C23129-3-3	Cylinder Actuator	Messier-Bugatti
C23129-3-4	Cylinder Actuator	Messier-Bugatti
C23129-3-5	Cylinder Actuator	Messier-Bugatti
C23129-3-6	Cylinder Actuator	Messier-Bugatti
C23129-3-7	Cylinder Actuator	Messier-Bugatti
C23129-4	Cylinder Actuator	Messier-Bugatti
C23129-4-1	Cylinder Actuator	Messier-Bugatti
C23129-4-2	Cylinder Actuator	Messier-Bugatti
C23129-4-3	Cylinder Actuator	Messier-Bugatti
C23129-4-4	Cylinder Actuator	Messier-Bugatti
C23130004	Cylinder Actuator	Messier-Bugatti
C23130004-1	Cylinder Actuator	Messier-Bugatti
C23130004-2	Cylinder Actuator	Messier-Bugatti
C23130004-3	Cylinder Actuator	Messier-Bugatti
C23130-1-11	Cylinder Actuator	Messier-Bugatti
C23130-1-12	Cylinder Actuator	Messier-Bugatti
C23130-1-13	Cylinder Actuator	Messier-Bugatti
C23130-1-8	Cylinder Actuator	Messier-Bugatti
C23130-2-11	Cylinder Actuator	Messier-Bugatti
C23130-2-12	Cylinder Actuator	Messier-Bugatti
C23130-213	Cylinder Actuator	Messier-Bugatti
C23130-214	Cylinder Actuator	Messier-Bugatti

Repair_Capability_List_Excel

C23130-2-8	Cylinder Actuator	Messier-Bugatti
C23130-308	Cylinder Actuator	Messier-Bugatti
C23130-309	Cylinder Actuator	Messier-Bugatti
C23130-310	Cylinder Actuator	Messier-Bugatti
C23130-311	Cylinder Actuator	Messier-Bugatti
C23130-312C	Cylinder Actuator	Messier-Bugatti
C23130-3-7	Cylinder Actuator	Messier-Bugatti
C23132-1	Door Actuator	Messier-Bugatti
C23132-103	Door Actuator	Messier-Bugatti
C23132-104	Door Actuator	Messier-Bugatti
C23132-1-1	Door Actuator	Messier-Bugatti
C23132-1-2	Door Actuator	Messier-Bugatti
C23132-2	Door Actuator	Messier-Bugatti
C23137002	Nose Landing Gear	Messier-Bugatti
C23137002-1	Nose Landing Gear	Messier-Bugatti
C23137002-10	Nose Landing Gear	Messier-Bugatti
C23137002-11	Nose Landing Gear	Messier-Bugatti
C23137002-2	Nose Landing Gear	Messier-Bugatti
C23137002-3	Nose Landing Gear	Messier-Bugatti
C23137002-4	Nose Landing Gear	Messier-Bugatti
C23137002-5	Nose Landing Gear	Messier-Bugatti
C23137002-6	Nose Landing Gear	Messier-Bugatti
C23137002-7	Nose Landing Gear	Messier-Bugatti
C23137002-8	Nose Landing Gear	Messier-Bugatti
C23137002-9	Nose Landing Gear	Messier-Bugatti
C23137003	Nose Landing Gear	Messier-Bugatti
C23137003-1	Nose Landing Gear	Messier-Bugatti
C23137003-2	Nose Landing Gear	Messier-Bugatti
C23137003-3	Nose Landing Gear	Messier-Bugatti
C23137003-4	Nose Landing Gear	Messier-Bugatti
C23137003-5	Nose Landing Gear	Messier-Bugatti
C23137003-6	Nose Landing Gear	Messier-Bugatti
C23137003-7	Nose Landing Gear	Messier-Bugatti
C23137003-8	Nose Landing Gear	Messier-Bugatti
C23137003-9	Nose Landing Gear	Messier-Bugatti
C23137-1	Nose Landing Gear	Messier-Bugatti
C23137102-10	Nose Landing Gear	Messier-Bugatti
C23137102-11	Nose Landing Gear	Messier-Bugatti
C23137-1-1	Nose Landing Gear	Messier-Bugatti
C23137-1-10	Nose Landing Gear	Messier-Bugatti
C23137-1-11	Nose Landing Gear	Messier-Bugatti
C23137-112	Nose Landing Gear	Messier-Bugatti
C23137-113	Nose Landing Gear	Messier-Bugatti
C23137-114	Nose Landing Gear	Messier-Bugatti
C23137-115	Nose Landing Gear	Messier-Bugatti
C23137-116	Nose Landing Gear	Messier-Bugatti
C23137-117	Nose Landing Gear	Messier-Bugatti
C23137-118	Nose Landing Gear	Messier-Bugatti
C23137-119	Nose Landing Gear	Messier-Bugatti
C23137-1-2	Nose Landing Gear	Messier-Bugatti
C23137-1-3	Nose Landing Gear	Messier-Bugatti
C23137-1-4	Nose Landing Gear	Messier-Bugatti
C23137-1-5	Nose Landing Gear	Messier-Bugatti
C23137-1-6	Nose Landing Gear	Messier-Bugatti
C23137-1-7	Nose Landing Gear	Messier-Bugatti
C23137-1-9	Nose Landing Gear	Messier-Bugatti
C23138-1-6-114	Barrel	Messier-Bugatti
C23139-3-4	Shock Absorber	Messier-Bugatti

Repair_Capability_List_Excel

C23145	Electrical Loom	Messier-Bugatti
C23199-1	Door Actuator	Messier-Bugatti
C23199-101	Door Actuator	Messier-Bugatti
C23199-102	Door Actuator	Messier-Bugatti
C23199-103	Door Actuator	Messier-Bugatti
C23199-104	Door Actuator	Messier-Bugatti
C23265-1	Dual Manifold	Messier-Bugatti
C23265-1-1	Dual Manifold	Messier-Bugatti
C23265-3	Dual Manifold	Messier-Bugatti
C23266-1	Dual Manifold	Messier-Bugatti
C23266-1-1	Dual Manifold	Messier-Bugatti
C23266-3	Dual Manifold	Messier-Bugatti
C23267	Brake System Connecting Block	Messier-Bugatti
C23267001	Brake System Connecting Block	Messier-Bugatti
C23267001-1	Brake System Connecting Block	Messier-Bugatti
C23267-1	Brake System Connecting Block	Messier-Bugatti
C23273-1	Aft Manifold assy	Messier-Bugatti
C23274-1	Aft Manifold assy	Messier-Bugatti
C23279	Electrical Loom	Messier-Bugatti
C23280	Electrical Loom	Messier-Bugatti
C23285	Electrical Loom	Messier-Bugatti
C23286	Electrical Loom	Messier-Bugatti
C23309	Pipes & Coupling	Messier-Bugatti
C23309-0-1	Pipes & Coupling	Messier-Bugatti
C23310	Pipes & Coupling	Messier-Bugatti
C23310-0-1	Pipes & Coupling	Messier-Bugatti
C23406	Coupling	Messier-Bugatti
C23455	Mechanical Indicator	Messier-Bugatti
C23455-1	Mechanical Indicator	Messier-Bugatti
C23468	Electrical Loom	Messier-Bugatti
C23AC0102	Check Valve	Messier-Bugatti
C23AE0102	Check Valve	Goodrich Control Systems
C23AE0103	Check Valve	Goodrich Control Systems
C23WM5021	Non Return Valve	Goodrich Control Systems
C23WM5041	Non Return Valve	Goodrich Control Systems
C24111-1	Hand Pump	Messier-Bugatti
C24264004	Pressure Limiter	Messier-Bugatti
C24264-2	Pressure Limiter	Messier-Bugatti
C24264-202	Pressure Limiter	Messier-Bugatti
C24264-2-1	Pressure Limiter	Messier-Bugatti
C24264-3	Pressure Limiter	Messier-Bugatti
C24264-302	Pressure Limiter	Messier-Bugatti
C24264-3-1	Pressure Limiter	Messier-Bugatti
C24273	Variable Restrictor assy	Messier-Bugatti
C24273-0-1	Variable Restrictor assy	Messier-Bugatti
C24273-1	Variable Restrictor assy	Messier-Bugatti
C24273-1-1	Variable Restrictor assy	Messier-Bugatti
C24274	Variable Restrictor assy	Messier-Bugatti
C24274-0-1	Variable Restrictor assy	Messier-Bugatti
C24274-1	Variable Restrictor assy	Messier-Bugatti
C24274-1-1	Variable Restrictor assy	Messier-Bugatti
C24295350	Three Way Solenoid Valve	Messier-Bugatti
C24343-1	Valve assy	Messier-Bugatti
C24443000	Swivel Fitting	Messier-Bugatti
C24443002	Swivel Fitting	Messier-Bugatti
C24466000	Thrust Reverser Hydraulic Control Unit	Messier-Bugatti
C24466000-102	Thrust Reverser Hydraulic Control Unit	Messier-Bugatti
C24466000-103	Thrust Reverser Hydraulic Control Unit	Messier-Bugatti

Repair_Capability_List_Excel

C24466000-104	Thrust Reverser Hydraulic Control Unit	Messier-Bugatti
C24466000-3	Thrust Reverser Hydraulic Control Unit	Messier-Bugatti
C24466000-4	Thrust Reverser Hydraulic Control Unit	Messier-Bugatti
C24466001-102	Thrust Reverser Hydraulic Control Unit	Messier-Bugatti
C24466001-103	Thrust Reverser Hydraulic Control Unit	Messier-Bugatti
C24466001-2	Thrust Reverser Hydraulic Control Unit	Messier-Bugatti
C24466001-3	Thrust Reverser Hydraulic Control Unit	Messier-Bugatti
C24466900	Thrust Reverser Hydraulic Control Unit	Messier-Bugatti
C24483010	NLG Swivel Selector Valve	Messier-Bugatti
C24489000-1	Master Valve Manifold	Messier-Bugatti
C24489001	Master Valve Manifold	Messier-Bugatti
C24489001-1	Master Valve Manifold	Messier-Bugatti
C24491000	Master Valve Manifold	Messier-Bugatti
C24491000-1	Master Valve Manifold	Messier-Bugatti
C24491000-2	Master Valve Manifold	Messier-Bugatti
C24491001	Master Valve Manifold	Messier-Bugatti
C24513000	Manifold Accumulator	Messier-Bugatti
C24568000-1	Differential Control Sel. Valve	Messier-Bugatti
C24568000-2	Differential Control Sel. Valve	Messier-Bugatti
C24568000-3	Differential Control Sel. Valve	Messier-Bugatti
C24568000-4	Differential Control Sel. Valve	Messier-Bugatti
C24568000-5	Differential Control Sel. Valve	Messier-Bugatti
C24589000	Uplock Box	Messier-Bugatti
C24589000-1	Uplock Box	Messier-Dowty
C24589000-2	Uplock Box	Messier-Dowty
C24592000	Master Cylinder	Messier-Bugatti
C24592000-1	Master Cylinder	Messier-Bugatti
C24592020	Master Cylinder	Messier-Bugatti
C24603000	MLG LH Lever assy	Messier-Bugatti
C24604000	MLG RH Lever assy	Messier-Bugatti
C24607000	NLG Lever assy	Messier-Bugatti
C24703001	Parking Pressure Limiter	Messier-Bugatti
C24703001-1	Parking Pressure Limiter	Messier-Bugatti
C24703001-2	Parking Pressure Limiter	Messier-Bugatti
C24703001-3	Parking Pressure Limiter	Messier-Bugatti
C24703001-4	Parking Pressure Limiter	Messier-Bugatti
C24703002	Parking Valve	Messier-Bugatti
C24703002-1	Parking Valve	Messier-Bugatti
C24703003	Pressure Limiter	Messier-Bugatti
C24721001	Hydraulic Fuse	Messier-Bugatti
C24730000-2	NLG Door Uplock assy	Messier-Bugatti
C24730000-3	NLG Door Uplock assy	Messier-Bugatti
C24730000-4	NLG Door Uplock assy	Messier-Bugatti
C24730000-5	NLG Door Uplock assy	Messier-Bugatti
C24730001-2	NLG Uplock assy	Messier-Bugatti
C24730001-3	NLG Uplock assy	Messier-Bugatti
C24730001-4	NLG Uplock assy	Messier-Bugatti
C24730001-5	NLG Uplock assy	Messier-Bugatti
C24730001-6	NLG Uplock assy	Messier-Bugatti
C24730100	NLG Door Uplock assy	Messier-Bugatti
C24736000	Servo Control	Messier-Bugatti
C24736001	Servo Control	Messier-Bugatti
C24736001-0-1	Servo Control	Messier-Bugatti
C24736001-1	Servo Control	Messier-Bugatti
C24736001-2	Servo Control	Messier-Bugatti
C24739010	Manifold LH	Messier-Bugatti
C24740010	Manifold RH	Messier-Bugatti
C24742000-1	Latch	Goodrich Control Systems

Repair_Capability_List_Excel

C24742000-2	Latch	Goodrich Control Systems
C24742000-3	Latch	Goodrich Control Systems
C2474-3-1	Valve assy	Messier-Bugatti
C24747000	Selector Valve	Messier-Bugatti
C24747000-1	Selector Valve	Messier-Bugatti
C24750000-1	Hydraulic Control Unit	Goodrich Control Systems
C24750000-2	Hydraulic Control Unit	Goodrich Control Systems
C24750000-3	Hydraulic Control Unit	Goodrich Control Systems
C24750000-4	Hydraulic Control Unit	Goodrich Control Systems
C24750000-5	Hydraulic Control Unit	Goodrich Control Systems
C24750000-512	Hydraulic Control Unit	Goodrich Control Systems
C24750000-521	Hydraulic Control Unit	Goodrich Control Systems
C24750000-522	Hydraulic Control Unit	Goodrich Control Systems
C24750000-7	Hydraulic Control Unit	Goodrich Control Systems
C24750000-712	Hydraulic Control Unit	Goodrich Control Systems
C24750000-721	Hydraulic Control Unit	Goodrich Control Systems
C24750000-722	Hydraulic Control Unit	Goodrich Control Systems
C24752000-1	Pressure Switch	Goodrich Control Systems
C24752000-102	Pressure Switch	Goodrich Control Systems
C24757000	Safety Valve	Messier-Bugatti
C24757020	Safety Valve	Messier-Bugatti
C24763000	Sensor Box	Messier-Bugatti
C24764000	Gearbox	Messier-Bugatti
C24767200	LPTACC Valve	Messier-Bugatti
C24769000	LH Lever assy	Messier-Bugatti
C24770000	RH Lever assy	Messier-Bugatti
C24777020-1	Normal Brake Manifold assy	Messier-Bugatti
C24777020-2	Normal Brake Manifold assy	Messier-Bugatti
C24777020-3	Normal Brake Manifold assy	Messier-Bugatti
C24782000	Solenoid Valve	Messier-Bugatti
C24782000-1	Solenoid Valve	Messier-Bugatti
C24782000-2	Solenoid Valve	Messier-Bugatti
C24784000	LPTACC Valve	Messier-Bugatti
C24792000	LPTACC Valve	Messier-Bugatti
C24792000-1	LPTACC Valve	Messier-Bugatti
C24792000-2	LPTACC Valve	Messier-Bugatti
C24797001-1	Manifold	Messier-Bugatti
C24819000	Brake Manifold	Messier - Bugatti
C24819000-1	Parking Brake Manifold assy	Messier-Bugatti
C24828000	Pressure Switch	Goodrich Control Systems
C24830000	Door Uplock	Messier-Bugatti
C24830000-1	Door Uplock	Messier-Bugatti
C24830000-2	Door Uplock	Messier-Bugatti
C24831100-3	Main Landing Gear Uplock	Messier-Bugatti
C24831100-4	Main Landing Gear Uplock	Messier-Bugatti
C24833100-2	Door Uplock	Messier-Bugatti
C24834000-3	Nose Landing Gear Uplock	Messier-Bugatti
C24834000-4	Nose Landing Gear Uplock	Messier-Bugatti
C24834000-5	Nose Landing Gear Uplock	Messier-Bugatti
C24837101	Brake Manifold assy	Messier-Bugatti
C24837101-1	Brake Manifold assy	Messier-Bugatti
C24837101-2	Brake Manifold assy	Messier-Bugatti
C24837101-3	Brake Manifold assy	Messier-Bugatti
C24839010	Manifold	Messier-Bugatti
C24840010	Manifold	Messier-Bugatti
C24856000-3	Electro - Hydraulic Block	Messier - Bugatti
C24857000	Swivel Selector Valve	Messier-Bugatti
C24857000-1	Swivel Selector Valve	Messier-Bugatti

Repair_Capability_List_Excel

C24858000	Feedback Sensor	Messier-Bugatti
C24859000	Nose Wheel Steering Gearbox	Messier-Bugatti
C24876000-1	Centerline Landing Gear Uplock	Messier-Bugatti
C24876000-2	Centerline Landing Gear Uplock	Messier-Bugatti
C24879020-2	Emergency Brake Manifold assy	Messier-Bugatti
C24879020-3	Emergency Brake Manifold assy	Messier-Bugatti
C24880020-2	Emergency Brake Manifold assy	Messier-Bugatti
C24880020-3	Emergency Brake Manifold assy	Messier-Bugatti
C24891020	Reservoir Hydraulic	Messier-Bugatti
C24960000	Safety Valve	Messier-Bugatti
C24960000-1	Safety Valve	Messier-Bugatti
C24966000	Safety Valve	Messier-Bugatti
C24984000	Solenoid Shut-Off Valve	Messier-Bugatti
C25149000	LPTACC Valve	Messier-Bugatti
C25149000-1	LPTACC Valve	Messier-Bugatti
C25175000	LPTACC Valve	Messier-Bugatti
C25175000-1	LPTACC Valve	Messier-Bugatti
C25243002	Safety Valve	Messier-Bugatti
C25243002-1	Safety Valve	Messier-Bugatti
C25243002-2	Safety Valve	Messier-Bugatti
C25FA0102	Float Valve	Goodrich Control Systems
C25FA0103	Float Valve	Goodrich Control Systems
C25FA0104	Float Valve	Goodrich Control Systems
C25FA0105	Float Valve	Goodrich Control Systems
C25FA0106	Float Valve	Goodrich Control Systems
C25FA0107	Float Valve	Goodrich Control Systems
C25FA0108	Float Valve	Goodrich Control Systems
C25FA0109	Float Valve	Goodrich Control Systems
C25FA0110	Float Valve	Goodrich Control Systems
C25FA0111	Float Valve	Goodrich Control Systems
C25FA0112	Float Valve	Goodrich Control Systems
C29054-001	Pressure Transmitter	Penny and Giles
C29055-011	Selector Valve	Moog Inc
C29066-01	Selector Valve	SAMM
C-30	Pressure Indicator	Kollsman
C301002-0104	Flap Motor	American Bosch
C30202	Control Shaker	Safe Flight
C3495100010	Overspeed Warning Switch	Kollsman
C3495100026	Overspeed Warning Switch	Kollsman
C3495100045	Overspeed Warning Switch	Kollsman
C49AA0211	Electric Pump Canister	Goodrich Control Systems
C49AA0221	Canister	Goodrich Control Systems
C49AA0222	Canister	Goodrich Control Systems
C4E	Compass	Ametek
C-5	Pressure Gage	Ametek
C51LM0011	Selector Manual	Bronzavia-Air Equipement
C51LM0012	Selector Manual	Bronzavia-Air Equipement
C51LM0013	Selector Manual	Bronzavia-Air Equipement
C51LM0014	Selector Manual	Bronzavia-Air Equipement
C51LM0020	Valve 4 way	Goodrich Control Systems
C51LM0030	Selector Valve	Goodrich Control Systems
C5C	Compass	Ametek
C5H	Compass	Ametek
C5K	Stand-by Compass	Ametek
C5L	Compass	Ametek
C5M	Compass	Ametek
C-6	Thermometer	Edison
C60AA0051	Low Level Switch	Goodrich Control Systems

Repair_Capability_List_Excel

C60AA0052	Low Level Switch	Goodrich Control Systems
C60AA0061	Low Level Switch	Goodrich Control Systems
C60AA0062	Low Level Switch	Goodrich Control Systems
C60AA0071	Low Level Switch	Goodrich Control Systems
C60AA0072	Low Level Switch	Goodrich Control Systems
C60AA0081	Low Level Switch	Goodrich Control Systems
C60AA0082	Low Level Switch	Goodrich Control Systems
C611005-0103	Control Unit	Textron
C61LA0010	Manual Magnetic Indicator	Goodrich Control Systems
C61LA0020	Manual Magnetic Indicator	Goodrich Control Systems
C6351AAM04	EXTENSION CAM	SEXTANT AVIOMIQUE
C662005-0101	Fuel Gauge	AID
C66502-3	Sensor assy	Airbus Industrie
C72922	Screw Jack Unit	Teleflex
C-75802	Stick Shaker	Thales Avionics
C-8	Pressure Gage	Ametek
C81661-1	Cable assy	Aero Controlex
C81661-2	Cable assy	Aero Controlex
C81661-3	Cable assy	Aero Controlex
C81662-2	Cable assy	Aerocontrolex
C81662-3	Cable assy	Aerocontrolex
C81662-4	Cable assy	Aerocontrolex
C81694-1	Cable assy	Transdigm Inc
C81694-2	Cable assy	Transdigm Inc
C81694-3	Cable assy	Transdigm Inc
C81694-4	Cable assy	Transdigm Inc
C81694-5	Cable assy	Transdigm Inc
C82LL0010	Drain Valve	Goodrich Control Systems
C90ST0002	Gauge Transmitter	Goodrich Control Systems
C90ST0003	Gauge Transmitter	Goodrich Control Systems
C93L13-601	Shut-Off Valve Body	Intertechnique
C93R13-601	Canister	Intertechnique
C93R25-601	Canister	Intertechnique
C93R38-601	Canister	Intertechnique
C93R38-606	Canister	Intertechnique
C93R38-608	Crossflow Pump Canister	Intertechnique
C99-26-001	Crossflow Inlet Screen	Intertechnique
CA9303	Motor assy	Menasco Aerospace
CACED1625-02	Automatic Low Speed Aileron	Bronzavia-Air Equipement
CACED1625-03	Automatic Low Speed Aileron	Bronzavia-Air Equipement
CACED1625-04	Automatic Low Speed Aileron	Bronzavia-Air Equipement
CACED1625-05	Automatic Low Speed Aileron	Bronzavia-Air Equipement
CACED1625-06	Automatic Low Speed Aileron	Bronzavia-Air Equipement
CACED1625-07	Automatic Low Speed Aileron	Bronzavia-Air Equipement
CACED1625-08	Automatic Low Speed Aileron	Bronzavia-Air Equipement
CACED1625-09	Automatic Low Speed Aileron	Bronzavia-Air Equipement
CACED1625-10	Automatic Low Speed Aileron	Bronzavia-Air Equipement
CAR070	Check Valve	Goodrich Control Systems
CAR100	Check Valve	Goodrich Control Systems
CAR101	Check Valve	Goodrich Control Systems
CAR105	Check Valve	Goodrich Control Systems
CAR170	Check Valve	Goodrich Control Systems
CAR175-1	Check Valve	Goodrich Control Systems
CAR200	Check Valve	Goodrich Control Systems
CAR201	Check Valve	Goodrich Control Systems
CAR205	Check Valve	Goodrich Control Systems
CAR210	Check Valve	Goodrich Control Systems
CAR300	Check Valve	Goodrich Control Systems

Repair_Capability_List_Excel

CAR301	Check Valve	Goodrich Control Systems
CAR305	Check Valve	Goodrich Control Systems
CAR370-1	Check Valve	Goodrich Control Systems
CAR375-1	Check Valve	Goodrich Control Systems
CAR400	Check Valve	SAMM
CAR70	Check Valve	Goodrich Control Systems
CAR75	Check Valve	Goodrich Control Systems
CART33	Check Valve	Goodrich Control Systems
CE1716AA0	Ground Cooling Fan	Technofan
CE1909AA1	Fan	Technofan
CE1909AA1 AMDTA	Fan	Technofan
CG0440503658N00	Restrictor Air Filter	Sofrance
CG12527F	Switch	Westport International
CG7G	Detector	Cerberus Guinard
CG7G0	Smoke Detector	Cerberus Guinard
CG7G0-10	Smoke Detector	Cerberus Guinard
CG7G0-11	Smoke Detector	Cerberus Guinard
CG7G0-S	Smoke Detector	Cerberus Guinard
CG7GD1	Smoke Detector	Cerberus Guinard
CG7GE	Smoke Detector	Cerberus Guinard
CG7GF	Smoke Detector	Cerberus Guinard
CG7GF10	Smoke Detector	Cerberus Guinard
CG7GFSG	Smoke Detector	Cerberus Guinard
CG7GT10	Smoke Detector	Cerberus Guinard
CG7GT10AMDTA	Smoke Detector	Cerberus Guinard
CG7P	Detector	Cerberus Guinard
CG7P0	Smoke Detector	Cerberus Guinard
CG7PD1	Smoke Detector	Cerberus Guinard
CG7PE	Smoke Detector	Cerberus Guinard
CG7PF	Smoke Detector	Cerberus Guinard
CG7PF10	Smoke Detector	Cerberus Guinard
CGDU2200-00	Smoke Detector	Cerberus Guinard
CH0118101331C00	Filter Element	Sofrance
CH0184101331C00	Filter Element	Sofrance
CH0305101331C02	Filter Element	Sofrance
CH0310101391C01	Filter Element	Sofrance
CH0509101331C00	Filter Element	Sofrance
CH0512101331C00	Filter Element	Sofrance
CH1329A0008	Box Coupling	Goodrich Control Systems
CH1329A0026	Shaft Assembly	Goodrich Control Systems
CH1329A0044	Shaft Assembly	Goodrich Control Systems
CH1329A008	Torque Limiter	Goodrich Control Systems
CH1330A0100	Shaft Assembly	Goodrich Control Systems
CH1330A0105	Shaft Assembly	Goodrich Control Systems
CH1330A0110	Universal Joint	Goodrich Control Systems
CH1330A0115	Steady Bearing	Goodrich Control Systems
CH1330A0118	Steady Bearing	Goodrich Control Systems
CH1330A0120	Shaft Assembly	Goodrich Control Systems
CH1330A0125	Shaft Assembly	Goodrich Control Systems
CH1330A0130	Shaft Assembly	Goodrich Control Systems
CH1330A0135	Shaft Assembly	Goodrich Control Systems
CH1330P0136	Universal Joint assy	Goodrich Control Systems
CH1543-0001-01	Flexible Drive Shaft	Goodrich
CH1543-0001-03	Flexible Drive Shaft	Goodrich
CH1543-0011	Guide Tube assy	Goodrich
CH1543-0028	Flexible Guide Tube	Goodrich
CH1543-029	Tee Piece Connection assy	Goodrich
CH1806T02	Thrust Reverser Transmission	Goodrich

Repair_Capability_List_Excel

CH7744101481C00	Filter Element	Sofrance
CHA1001-002	Stepback Gearbox	Goodrich Control Systems
CHA1001-002L	Stepback Gearbox	Goodrich Control Systems
CHA1001-002R	Stepback Gearbox	Goodrich Control Systems
CHA1001-004A	Stepback Gearbox	Goodrich Control Systems
CHA1001-004AR	Stepback Gearbox	Goodrich Control Systems
CHA1001-005A	Stepback Gearbox	Goodrich Control Systems
CHA1001-006A	Stepback Gearbox	Goodrich Control Systems
CHA1001-007A	Stepback Gearbox	Goodrich Control Systems
CHA1001-007B	Stepback Gearbox	Goodrich Control Systems
CHA1001-008A	Stepback Gearbox	Goodrich Control Systems
CHA1001-008B	Stepback Gearbox	Goodrich Control Systems
CHA1001-008C	Stepback Gearbox	Goodrich Control Systems
CHA1006-003	Flap Downdrive Gearbox	Goodrich Control Systems
CHA1006-003B	Flap Downdrive Gearbox	Goodrich Control Systems
CHA1006-003BL	Flap Downdrive Gearbox	Goodrich Control Systems
CHA1006-003BR	Flap Downdrive Gearbox	Goodrich Control Systems
CHA1006-003L	Flap Downdrive Gearbox	Goodrich Control Systems
CHA1006-003R	Flap Downdrive Gearbox	Goodrich Control Systems
CHA1006-005A	Flap Downdrive Gearbox	Goodrich Control Systems
CHA1006-006A	Flap Downdrive Gearbox	Goodrich Control Systems
CHA1006-007A	Flap Downdrive Gearbox	Goodrich Control Systems
CHA1012-002A	Instrumentation Unit	Goodrich Control Systems
CHA1012-002B	Instrumentation Unit	Goodrich Control Systems
CHA1012-003A	Instrumentation Unit	Goodrich Control Systems
CHA1012-003B	Instrumentation Unit	Goodrich Control Systems
CHA1012-004A	Instrumentation Unit	Goodrich Control Systems
CHA1012-004B	Instrumentation Unit	Goodrich Control Systems
CHA1012-004D	Instrumentation Unit	Goodrich Control Systems
CHA1012-004E	Instrumentation Unit	Goodrich Control Systems
CHA1012-006A	Instrumentation Unit	Goodrich Control Systems
CHA1012-009A	Instrumentation Unit	Goodrich Control Systems
CHA1012-010A	Instrumentation Unit	Goodrich Control Systems
CHA1012-011A	Instrumentation Unit	Goodrich Control Systems
CHA1018-001A	Slat Instrumentation Unit	Goodrich Control Systems
CHA1018-001B	Slat Instrumentation Unit	Goodrich Control Systems
CHA1018-002A	Slat Instrumentation Unit	Goodrich Control Systems
CHA1018-002B	Slat Instrumentation Unit	Goodrich Control Systems
CHA1055-002	Flap Screwjack N°1	Goodrich Control Systems
CHA1055-003A	Flap Screwjack N°1	Goodrich Control Systems
CHA1055-004A	Flap Screwjack N°1	Goodrich Control Systems
CHA1055-005A	Flap Screwjack N°1	Goodrich Control Systems
CHA1055-006A	Flap Screwjack N°1	Goodrich Control Systems
CHA1055-006B	Flap Screwjack N°1	Goodrich Control Systems
CHA1055-007A	Flap Screwjack N°1	Goodrich Control Systems
CHA1055-007B	Flap Screwjack N°1	Goodrich Control Systems
CHA1055-007C	Flap Screwjack N°1	Goodrich Control Systems
CHA1055-007D	Flap Screwjack N°1	Goodrich Control Systems
CHA1055-007E	Flap Screwjack N°1	Goodrich Control Systems
CHA1055-007F	Flap Screwjack N°1	Goodrich Control Systems
CHA1055-007G	Flap Screwjack N°1	Goodrich Control Systems
CHA1055-007H	Flap Screwjack N°1	Goodrich Control Systems
CHA1056-004B	Flap Screwjack N2	Goodrich Control Systems
CHA1056-004C	Flap Screwjack N2	Goodrich Control Systems
CHA1056-005C	Flap Screwjack N2	Goodrich Control Systems
CHA1056-005D	Flap Screwjack N2	Goodrich Control Systems
CHA1056-005E	Flap Screwjack N2	Goodrich Control Systems
CHA1056-006A	Flap Screwjack N2	Goodrich Control Systems

Repair_Capability_List_Excel

CHA1060-004A	Flap Screwjack N6	Goodrich Control Systems
CHA1060-005A	Flap Screwjack N6	Goodrich Control Systems
CHA1060-005B	Flap Screwjack N6	Goodrich Control Systems
CHA1060-005C	Flap Screwjack N6	Goodrich Control Systems
CHA1060-007A	Flap Screwjack N6	Goodrich Control Systems
CHA1060-007C	Flap Screwjack N6	Goodrich Control Systems
CHA1060-008A	Flap Screwjack N6	Goodrich Control Systems
CHA1060-008B	Flap Screwjack N6	Goodrich Control Systems
CHA1060-008C	Flap Screwjack N6	Goodrich Control Systems
CHA1060-008D	Flap Screwjack N6	Goodrich Control Systems
CHA1060-008E	Flap Screwjack N6	Goodrich Control Systems
CHA1060-008F	Flap Screwjack N6	Goodrich Control Systems
CHA1060-008G	Flap Screwjack N6	Goodrich Control Systems
CHA1060-008H	Flap Screwjack N6	Goodrich Control Systems
CHA1060-008J	Flap Screwjack N6	Goodrich Control Systems
CHA1061-001	Slat Screwjack	Goodrich Control Systems
CHA1061-001A	Slat Screwjack	Goodrich Control Systems
CHA1061-002A	Slat Screwjack	Goodrich Control Systems
CHA1061-003	Slat Screwjack	Goodrich Control Systems
CHA1061-003B	Slat Screwjack	Goodrich Control Systems
CHA1061-004A	Slat Screwjack	Goodrich Control Systems
CHA1061-005A	Slat Screwjack	Goodrich Control Systems
CHA1061-005B	Slat Screwjack	Goodrich Control Systems
CHA1062-001	Slat Friction Brakes	Goodrich Control Systems
CHA1062-002A	Slat Friction Brakes	Goodrich Control Systems
CHA1062-002B	Slat Friction Brakes	Goodrich Control Systems
CHA1062-005A	Slat Friction Brakes	Goodrich Control Systems
CHA1062-006A	Slat Friction Brakes	Goodrich Control Systems
CHA1062-006B	Slat Friction Brakes	Goodrich Control Systems
CHA1062-007A	Slat Friction Brakes	Goodrich Control Systems
CHA1062-007B	Slat Friction Brakes	Goodrich Control Systems
CHA1063-001	Slat Friction Brakes	Goodrich Control Systems
CHA1063-002A	Slat Friction Brakes	Goodrich Control Systems
CHA1063-002B	Slat Friction Brakes	Goodrich Control Systems
CHA1063-005A	Slat Friction Brakes	Goodrich Control Systems
CHA1063-006A	Slat Friction Brakes	Goodrich Control Systems
CHA1063-006B	Slat Friction Brakes	Goodrich Control Systems
CHA1063-007A	Slat Friction Brakes	Goodrich Control Systems
CHA1063-007B	Slat Friction Brakes	Goodrich Control Systems
CHA1067-001A	Slat Instrumentation Unit	Goodrich Control Systems
CHA1067-001B	Slat Instrumentation Unit	Goodrich Control Systems
CHA1067-002A	Slat Instrumentation Unit	Goodrich Control Systems
CHA1067-002B	Slat Instrumentation Unit	Goodrich Control Systems
CHA1071-001	Slat Instrumentation Unit	Goodrich Control Systems
CHA1071-002A	Slat Instrumentation Unit	Goodrich Control Systems
CHA1071-003A	Slat Instrumentation Unit	Goodrich Control Systems
CHA1071-003B	Slat Instrumentation Unit	Goodrich Control Systems
CHA1071-004A	Slat Instrumentation Unit	Goodrich Control Systems
CHA1095-002A	Aileron Droop Signal Unit	Goodrich Control Systems
CHA1095-002B	Aileron Droop Signal Unit	Goodrich Control Systems
CHA1095-003A	Aileron Droop Signal Unit	Goodrich Control Systems
CHA1095-004A	Aileron Droop Signal Unit	Goodrich Control Systems
CHA1096-002A	Aileron Droop Signal Unit	Goodrich Control Systems
CHA1096-002B	Aileron Droop Signal Unit	Goodrich Control Systems
CHA1096-003A	Aileron Droop Signal Unit	Goodrich Control Systems
CHA1096-004A	Aileron Droop Signal Unit	Goodrich Control Systems
CHA1154-001A	Simplex Bevel Gearbox	Goodrich Control Systems
CHA1154-001AL	Simplex Bevel Gearbox	Goodrich Control Systems

Repair_Capability_List_Excel

CHA1484-002S	Flap Screwjack N5	Goodrich Control Systems
CHA1484-002T	Flap Screwjack N5	Goodrich Control Systems
CHA1485-001A	Flap Screwjack N6	Goodrich Control Systems
CHA1485-001B	Flap Screwjack N6	Goodrich Control Systems
CHA1485-001C	Flap Screwjack N6	Goodrich Control Systems
CHA1485-002A	Flap Screwjack N6	Goodrich Control Systems
CHA1485-003A	Flap Screwjack N6	Goodrich Control Systems
CHA1485-003B	Flap Screwjack N6	Goodrich Control Systems
CHA1485-003C	Flap Screwjack N6	Goodrich Control Systems
CHA1485-003D	Flap Screwjack N6	Goodrich Control Systems
CHA1485-003E	Flap Screwjack N6	Goodrich Control Systems
CHA1485-003F	Flap Screwjack N6	Goodrich Control Systems
CHA1485-003G	Flap Screwjack N6	Goodrich Control Systems
CHA1485-003H	Flap Screwjack N6	Goodrich Control Systems
CHA1485-003J	Flap Screwjack N6	Goodrich Control Systems
CHA1485-003K	Flap Screwjack N6	Goodrich Control Systems
CHA1485-003L	Flap Screwjack N6	Goodrich Control Systems
CHA1485-003M	Flap Screwjack N6	Goodrich Control Systems
CHA1485-003N	Flap Screwjack N6	Goodrich Control Systems
CHA1485-003P	Flap Screwjack N6	Goodrich Control Systems
CHA1485-003Q	Flap Screwjack N6	Goodrich Control Systems
CHA1485-003R	Flap Screwjack N6	Goodrich Control Systems
CHA1485-003S	Flap Screwjack N6	Goodrich Control Systems
CHA1485-003T	Flap Screwjack N6	Goodrich Control Systems
CHA1485-004A	Flap Screwjack N6	Goodrich Control Systems
CHA1485-004B	Flap Screwjack N6	Goodrich Control Systems
CHA1485-004C	Flap Screwjack N6	Goodrich Control Systems
CHA1485-004D	Flap Screwjack N6	Goodrich Control Systems
CHA1485-004E	Flap Screwjack N6	Goodrich Control Systems
CHA1485-004F	Flap Screwjack N6	Goodrich Control Systems
CHA1485-004G	Flap Screwjack N6	Goodrich Control Systems
CHA1485-004H	Flap Screwjack N6	Goodrich Control Systems
CHA1485-004J	Flap Screwjack N6	Goodrich Control Systems
CHA1684A01	Flap Control Unit	Goodrich
CHA436-101	Fuel Booster Pump	Goodrich Control Systems
CHA436-141	Fuel Booster Pump	Goodrich Control Systems
CHA484-001-1	Fuel Canister	Goodrich Control Systems
CHA493-1000	Shaft Assembly	Goodrich Control Systems
CHA493-1002	Shaft Assembly	Goodrich Control Systems
CHA493-1003	Shaft Assembly	Goodrich Control Systems
CHA493-1004	Shaft Assembly	Goodrich Control Systems
CHA493-1029	Gearbox	Goodrich Control Systems
CHA493-1125	Gearbox	Goodrich Control Systems
CHA493-1126	Gearbox	Goodrich Control Systems
CHA493-1133	Shaft Assembly	Goodrich Control Systems
CHA493-1134	Shaft Assembly	Goodrich Control Systems
CHA493-1137	Shaft Assembly	Goodrich Control Systems
CHA493-1138	Shaft Assembly	Goodrich Control Systems
CHA493-1139	Shaft Assembly	Goodrich Control Systems
CHA493-1140	Shaft Assembly	Goodrich Control Systems
CHA493-1172	Gearbox	Goodrich Control Systems
CHA493-1173	Gearbox	Goodrich Control Systems
CHA493-1236	Gearbox	Goodrich Control Systems
CHA493-1237	Gearbox	Goodrich Control Systems
CHA493-1337	Shaft Assembly	Goodrich Control Systems
CHA493-1338	Shaft Assembly	Goodrich Control Systems
CHA493-1339	Shaft Assembly	Goodrich Control Systems
CHA493-1340	Shaft Assembly	Goodrich Control Systems

Repair_Capability_List_Excel

CHA493-1368	Bearing	Goodrich Control Systems
CHA493-1370	Bearing	Goodrich Control Systems
CHA493-1777	Bearing	Goodrich Control Systems
CHA493-1801	Bearing	Goodrich Control Systems
CHA493-1802	Bearing	Goodrich Control Systems
CHA493-1803	Bearing	Goodrich Control Systems
CHA493-1812	Shaft Assembly	Goodrich Control Systems
CHA493-1816	Shaft Assembly	Goodrich Control Systems
CHA493-1817	Shaft Assembly	Goodrich Control Systems
CHA493-1818	Shaft Assembly	Goodrich Control Systems
CHA493-1903	Shaft Assembly	Goodrich Control Systems
CHA493-1904	Shaft Assembly	Goodrich Control Systems
CHA493-1961	Gearbox	Goodrich Control Systems
CHA493-1962	Gearbox	Goodrich Control Systems
CHA493-1963	Gearbox	Goodrich Control Systems
CHA493-1964	Gearbox	Goodrich Control Systems
CHA493-631/4	Flap Control Unit	Goodrich Control Systems
CHA493-631/5	Flap Control Unit	Goodrich Control Systems
CHA493-631/6	Flap Control Unit	Goodrich Control Systems
CHA493-631/7	Flap Control Unit	Goodrich Control Systems
CHA493-631/8	Flap Control Unit	Goodrich Control Systems
CHA493-631/9	Flap Control Unit	Goodrich Control Systems
CHA493-892	Shaft Assembly	Goodrich Control Systems
CHA493-893	Shaft Assembly	Goodrich Control Systems
CHA493-894	Shaft Assembly	Goodrich Control Systems
CHA493-895	Shaft Assembly	Goodrich Control Systems
CHA493-896	Shaft Assembly	Goodrich Control Systems
CHA493-897	Shaft Assembly	Goodrich Control Systems
CHA493-898	Shaft Assembly	Goodrich Control Systems
CHA493-899	Shaft Assembly	Goodrich Control Systems
CHA493-910	Transmission Flap	Goodrich Control Systems
CHA493-911	Transmission Flap	Goodrich Control Systems
CHA493-912	Transmission Flap	Goodrich Control Systems
CHA493-913	Transmission Flap	Goodrich Control Systems
CHA493-980	Gearbox	Goodrich Control Systems
CHA493-981	Gearbox	Goodrich Control Systems
CHA493-988	Bearing	Goodrich Control Systems
CHA493-989	Bearing	Goodrich Control Systems
CHA493-993	Shaft Assembly	Goodrich Control Systems
CHA493-995	Shaft Assembly	Goodrich Control Systems
CHA493-997	Shaft Assembly	Goodrich Control Systems
CHA493-998	Shaft Assembly	Goodrich Control Systems
CHA493-999	Shaft Assembly	Goodrich Control Systems
CHA494-141-3	Screwjack	Goodrich Control Systems
CHA494-141-4	Screwjack	Goodrich Control Systems
CHA495-401/8	Tail Trim Actuator	Goodrich Control Systems
CHA501-051-3	Screwjack	Goodrich Control Systems
CHA502-011-3	Screwjack	Goodrich Control Systems
CHA502-011-4	Screwjack	Goodrich Control Systems
CHA503-031-3	Screwjack	Goodrich Control Systems
CHA504-301-5	Rudder Feel Simulator	Goodrich Control Systems
CHA504-301-6	Rudder Feel Simulator	Goodrich Control Systems
CHA504-301-7	Rudder Feel Simulator	Goodrich Control Systems
CHA505-141-5	Elevator Feel Simulator	Goodrich Control Systems
CHA516-011-5	Screwjack	Goodrich Control Systems
CHA516-011-6	Screwjack	Goodrich Control Systems
CHA517-011-6	Screwjack	Goodrich Control Systems
CHA517-011-7	Screwjack	Goodrich Control Systems

Repair_Capability_List_Excel

CHA517-011-8	Screwjack	Goodrich Control Systems
CHA517-011-9	Screwjack	Goodrich Control Systems
CHA547-001-3	Screwjack	Goodrich Control Systems
CHA547-001-4	Screwjack	Goodrich Control Systems
CHA561-024	Shaft assy Bearing	Goodrich Control Systems
CHA561-025	Shaft Assembly	Goodrich Control Systems
CHA561-026	Shaft Assembly	Goodrich Control Systems
CHA561-028	Bearing	Goodrich Control Systems
CHA561-029	Shaft assy Bearing	Goodrich Control Systems
CHA561-048	Transmission Flap	Goodrich Control Systems
CHA561-049	Transmission Flap	Goodrich Control Systems
CHA561-050	Transmission Flap	Goodrich Control Systems
CHA561-051	Transmission Flap	Goodrich Control Systems
CHA561-067	Shaft assy Bearing	Goodrich Control Systems
CHA561-068	Bearing	Goodrich Control Systems
CHA561-069	Bearing	Goodrich Control Systems
CHA561-070	Shaft Assembly	Goodrich Control Systems
CHA561-071	Shaft Assembly	Goodrich Control Systems
CHA561-073	Shaft Assembly	Goodrich Control Systems
CHA561-074	Shaft Assembly	Goodrich Control Systems
CHA561-075	Shaft assy Bearing	Goodrich Control Systems
CHA561-076	Bearing	Goodrich Control Systems
CHA561-077	Shaft Assembly	Goodrich Control Systems
CHA561-078	Shaft Assembly	Goodrich Control Systems
CHA561-079	Shaft Assembly	Goodrich Control Systems
CHA561-082	Bearing	Goodrich Control Systems
CHA561-084	Bearing	Goodrich Control Systems
CHA561-085	Bearing	Goodrich Control Systems
CHA561-086	Bearing	Goodrich Control Systems
CHA561-087	Bearing	Goodrich Control Systems
CHA561-088	Shaft Assembly	Goodrich Control Systems
CHA561-089	Shaft Assembly	Goodrich Control Systems
CHA561-090	Bearing	Goodrich Control Systems
CHA561-093	Gearbox	Goodrich Control Systems
CHA561-095	Gearbox	Goodrich Control Systems
CHA561-098	Gearbox	Goodrich Control Systems
CHA561-099	Gearbox	Goodrich Control Systems
CHA561-100	Bearing	Goodrich Control Systems
CHA561-101	Bearing	Goodrich Control Systems
CHA561-108	Gearbox	Goodrich Control Systems
CHA561-109	Gearbox	Goodrich Control Systems
CHA561-1113	Gearbox	Goodrich Control Systems
CHA561-1115	Gearbox	Goodrich Control Systems
CHA561-112	Bearing	Goodrich Control Systems
CHA561-114	Bearing	Goodrich Control Systems
CHA561-115	Bearing	Goodrich Control Systems
CHA561-116	Bearing	Goodrich Control Systems
CHA561-120	Shaft Assembly	Goodrich Control Systems
CHA561-126	Shaft Assembly	Goodrich Control Systems
CHA561-127	Shaft assy Bearing	Goodrich Control Systems
CHA561-128	Shaft assy Bearing	Goodrich Control Systems
CHA561-129	Bearing	Goodrich Control Systems
CHA561-130	Bearing	Goodrich Control Systems
CHA561-131	Bearing	Goodrich Control Systems
CHA561-132	Bearing	Goodrich Control Systems
CHA561-133	Bearing	Goodrich Control Systems
CHA561-134	Bearing	Goodrich Control Systems
CHA561-135	Bearing	Goodrich Control Systems

Repair_Capability_List_Excel

CHA561-136	Bearing	Goodrich Control Systems
CHA561-137	Bearing	Goodrich Control Systems
CHA561-1372	Gearbox	Goodrich Control Systems
CHA561-1375	Gearbox	Goodrich Control Systems
CHA561-196	Gearbox	Goodrich Control Systems
CHA561-197	Bearing	Goodrich Control Systems
CHA561-199	Gearbox	Goodrich Control Systems
CHA561-200	Bearing	Goodrich Control Systems
CHA561-203	Bearing	Goodrich Control Systems
CHA561-204	Bearing	Goodrich Control Systems
CHA561-205	Bearing	Goodrich Control Systems
CHA561-206	Bearing	Goodrich Control Systems
CHA561-207	Gearbox	Goodrich Control Systems
CHA561-208	Bearing	Goodrich Control Systems
CHA561-209	Bearing	Goodrich Control Systems
CHA561-210	Bearing	Goodrich Control Systems
CHA561-211	Bearing	Goodrich Control Systems
CHA561-212	Bearing	Goodrich Control Systems
CHA561-214	Bearing	Goodrich Control Systems
CHA561-215	Bearing	Goodrich Control Systems
CHA561-216	Bearing	Goodrich Control Systems
CHA561-217	Gearbox	Goodrich Control Systems
CHA561-218	Bearing	Goodrich Control Systems
CHA561-220	Shaft assy Bearing	Goodrich Control Systems
CHA561-221	Shaft assy Bearing	Goodrich Control Systems
CHA561-227	Shaft assy Bearing	Goodrich Control Systems
CHA561-228	Shaft assy Bearing	Goodrich Control Systems
CHA561-229	Shaft assy Bearing	Goodrich Control Systems
CHA561-230	Shaft assy Bearing	Goodrich Control Systems
CHA561-231	Bearing	Goodrich Control Systems
CHA561-232	Bearing	Goodrich Control Systems
CHA561-233	Bearing	Goodrich Control Systems
CHA561-234	Bearing	Goodrich Control Systems
CHA561-235	Bearing	Goodrich Control Systems
CHA561-236	Bearing	Goodrich Control Systems
CHA561-237	Bearing	Goodrich Control Systems
CHA561-238	Bearing	Goodrich Control Systems
CHA561-239	Bearing	Goodrich Control Systems
CHA561-240	Bearing	Goodrich Control Systems
CHA561-241	Bearing	Goodrich Control Systems
CHA561-242	Bearing	Goodrich Control Systems
CHA561-243	Bearing	Goodrich Control Systems
CHA561-244	Bearing	Goodrich Control Systems
CHA561-245	Bearing	Goodrich Control Systems
CHA561-246	Bearing	Goodrich Control Systems
CHA561-247	Bearing	Goodrich Control Systems
CHA561-248	Bearing	Goodrich Control Systems
CHA561-253	Shaft Assembly	Goodrich Control Systems
CHA561-254	Shaft Assembly	Goodrich Control Systems
CHA561-268	Shaft assy Bearing	Goodrich Control Systems
CHA561-270	Shaft assy Bearing	Goodrich Control Systems
CHA561-272	Bearing	Goodrich Control Systems
CHA561-273	Bearing	Goodrich Control Systems
CHA561-274	Bearing	Goodrich Control Systems
CHA561-275	Bearing	Goodrich Control Systems
CHA561-276	Bearing	Goodrich Control Systems
CHA561-277	Bearing	Goodrich Control Systems
CHA561-278	Bearing	Goodrich Control Systems

Repair_Capability_List_Excel

CHA561-279	Bearing	Goodrich Control Systems
CHA561-280	Bearing	Goodrich Control Systems
CHA561-288	Gearbox	Goodrich Control Systems
CHA561-289	Gearbox	Goodrich Control Systems
CHA561-290	Gearbox	Goodrich Control Systems
CHA561-291	Gearbox	Goodrich Control Systems
CHA561-294	Gearbox	Goodrich Control Systems
CHA561-295	Gearbox	Goodrich Control Systems
CHA561-296	Gearbox	Goodrich Control Systems
CHA561-297	Gearbox	Goodrich Control Systems
CHA561-299	Transmission Flap	Goodrich Control Systems
CHA561-300	Transmission Flap	Goodrich Control Systems
CHA561-301	Shaft Assembly	Goodrich Control Systems
CHA561-302	Shaft Assembly	Goodrich Control Systems
CHA561-311	Bearing	Goodrich Control Systems
CHA561-312	Bearing	Goodrich Control Systems
CHA561-313	Bearing	Goodrich Control Systems
CHA561-314	Bearing	Goodrich Control Systems
CHA561-315	Bearing	Goodrich Control Systems
CHA561-319	Bearing	Goodrich Control Systems
CHA561-322	Bearing	Goodrich Control Systems
CHA561-325	Bearing	Goodrich Control Systems
CHA561-331	Bearing	Goodrich Control Systems
CHA561-333	Bearing	Goodrich Control Systems
CHA561-334	Bearing	Goodrich Control Systems
CHA561-335	Bearing	Goodrich Control Systems
CHA561-336	Bearing	Goodrich Control Systems
CHA561-360	Shaft Assembly	Goodrich Control Systems
CHA561-366	Shaft Assembly	Goodrich Control Systems
CHA561-367	Bearing	Goodrich Control Systems
CHA561-369	Shaft Assembly	Goodrich Control Systems
CHA561-370	Shaft Assembly	Goodrich Control Systems
CHA561-371	Shaft Assembly	Goodrich Control Systems
CHA561-372	Shaft Assembly	Goodrich Control Systems
CHA561-373	Shaft Assembly	Goodrich Control Systems
CHA561-374	Shaft Assembly	Goodrich Control Systems
CHA561-375	Shaft Assembly	Goodrich Control Systems
CHA561-376	Shaft Assembly	Goodrich Control Systems
CHA561-380	Shaft assy Bearing	Goodrich Control Systems
CHA561-381	Shaft assy Bearing	Goodrich Control Systems
CHA561-982	Gearbox	Goodrich Control Systems
CHA561-983	Gearbox	Goodrich Control Systems
CHA562-001-1	Screwjack	Goodrich Control Systems
CHA562-001-2	Screwjack	Goodrich Control Systems
CHA563-001-2	Screwjack	Goodrich Control Systems
CHA563-001-3	Screwjack	Goodrich Control Systems
CHA564-001-2	Screwjack	Goodrich Control Systems
CHA566-001-2	Screwjack	Goodrich Control Systems
CHA566-001-3	Screwjack	Goodrich Control Systems
CHA566-001-4	Screwjack	Goodrich Control Systems
CHA566-001-5	Screwjack	Goodrich Control Systems
CHA567-001-1	Screwjack	Goodrich Control Systems
CHA567-001-2	Screwjack	Goodrich Control Systems
CHA571-001-2	Screwjack	Goodrich Control Systems
CHA571-001-3	Screwjack	Goodrich Control Systems
CHA572-001-2	Screwjack	Goodrich Control Systems
CHA572-001-3	Screwjack	Goodrich Control Systems
CHA577-001-1	Screwjack	Goodrich Control Systems

Repair_Capability_List_Excel

CHA598-001-1	Elevator Feel Simulator	Goodrich Control Systems
CHA599-001-1	Flap Control Unit	Goodrich Control Systems
CHA599-001-2	Flap Control Unit	Goodrich Control Systems
CHA599-001-4	Flap Control Unit	Goodrich Control Systems
CHA599-001-5	Flap Control Unit	Goodrich Control Systems
CHA600-001-1	Screwjack	Goodrich Control Systems
CHA601-001-1	Screwjack	Goodrich Control Systems
CHA602-001-1	Flap Control Unit	Goodrich Control Systems
CHA602-001-2	Flap Control Unit	Goodrich Control Systems
CHA602-001-3	Flap Control Unit	Goodrich Control Systems
CHA602-001-4	Flap Control Unit	Goodrich Control Systems
CHA602-001-5	Flap Control Unit	Goodrich Control Systems
CHA603-001-1	Screwjack	Goodrich Control Systems
CHA604-001-1	Screwjack	Goodrich Control Systems
CHA614-001-1	Flap Control Unit	Goodrich
CHA614-001-2	Flap Control Unit	Goodrich
CHA617-001-1	Position Receiver	Goodrich
CHA624-001-1	Screwjack	Goodrich Control Systems
CHA629-001-3	Flap Control Unit	Goodrich Control Systems
CHA629-001-4	Flap Control Unit	Goodrich Control Systems
CHA630-001-2	Tail Trim Actuator	Goodrich Control Systems
CHA630-001-3	Tail Trim Actuator	Goodrich Control Systems
CHA653-001-1	Rudder Feel Simulator	Goodrich Control Systems
CHA653-001-2	Rudder Feel Simulator	Goodrich Control Systems
CHA653-001-3	Rudder Feel Simulator	Goodrich Control Systems
CHA682-001-1	Flap Control Unit	Goodrich Control Systems
CHA682-001-2	Flap Control Unit	Goodrich Control Systems
CHA696-007	Slat Control Unit	Goodrich Control Systems
CHA696-008	Slat Control Unit	Goodrich Control Systems
CHA696-009	Slat Control Unit	Goodrich Control Systems
CHA696-010A	Slat Control Unit	Goodrich Control Systems
CHA696-011A	Slat Control Unit	Goodrich Control Systems
CHA696-012A	Slat Control Unit	Goodrich Control Systems
CHA696-013A	Slat Control Unit	Goodrich Control Systems
CHA696-014A	Slat Control Unit	Goodrich Control Systems
CHA696-015A	Slat Control Unit	Goodrich Control Systems
CHA696-015D	Slat Control Unit	Goodrich Control Systems
CHA696-016A	Slat Control Unit	Goodrich Control Systems
CHA696-016D	Slat Control Unit	Goodrich Control Systems
CHA696-016H	Slat Control Unit	Goodrich Control Systems
CHA696-016J	Slat Control Unit	Goodrich Control Systems
CHA696-017D	Slat Control Unit	Goodrich Control Systems
CHA696-018A	Slat Control Unit	Goodrich Control Systems
CHA696-018D	Slat Control Unit	Goodrich Control Systems
CHA696-019A	Slat Control Unit	Goodrich Control Systems
CHA696-019C	Slat Control Unit	Goodrich Control Systems
CHA696-019D	Slat Control Unit	Goodrich Control Systems
CHA698-005	Torque Limiter	Goodrich Control Systems
CHA698-006A	Torque Limiter	Goodrich Control Systems
CHA698-007A	Torque Limiter	Goodrich Control Systems
CHA701-002	Bevel Gearbox	Goodrich Control Systems
CHA701-002L	Bevel Gearbox	Goodrich Control Systems
CHA701-002R	Bevel Gearbox	Goodrich Control Systems
CHA701-003A	Bevel Gearbox	Goodrich Control Systems
CHA701-004A	Bevel Gearbox	Goodrich Control Systems
CHA701-005A	Bevel Gearbox	Goodrich Control Systems
CHA701-006A	Bevel Gearbox	Goodrich Control Systems
CHA702-002	Gearbox Stepback	Goodrich Control Systems

Repair_Capability_List_Excel

CHA702-003A	Gearbox	Goodrich Control Systems
CHA702-004A	Gearbox	Goodrich Control Systems
CHA702-004B	Gearbox	Goodrich Control Systems
CHA704-168	Universal joint	Goodrich Control Systems
CHA704-168L	Universal Joint	Goodrich Control Systems
CHA704-214	Box Coupling	Goodrich Control Systems
CHA704-214L	Box Coupling	Goodrich Control Systems
CHA704-215	Steady Bearing	Goodrich Control Systems
CHA704-215L	Steady Bearing	Goodrich Control Systems
CHA704-216	Steady Bearing	Goodrich Control Systems
CHA704-216L	Steady Bearing	Goodrich Control Systems
CHA704-217	Steady Bearing	Goodrich Control Systems
CHA704-217L	Steady Bearing	Goodrich Control Systems
CHA704-218	Shaft Assembly	Goodrich Control Systems
CHA704-219	Shaft Assembly	Goodrich Control Systems
CHA704-220	Shaft Assembly	Goodrich Control Systems
CHA704-220L	Shaft Assembly	Goodrich Control Systems
CHA704-221	Shaft Assembly	Goodrich Control Systems
CHA704-221L	Shaft Assembly	Goodrich Control Systems
CHA704-222	Shaft Assembly	Goodrich Control Systems
CHA704-222L	Shaft Assembly	Goodrich Control Systems
CHA704-223	Shaft Assembly	Goodrich Control Systems
CHA704-223L	Shaft Assembly	Goodrich Control Systems
CHA704-224	Shaft Assembly	Goodrich Control Systems
CHA704-224L	Shaft Assembly	Goodrich Control Systems
CHA704-225	Shaft Assembly	Goodrich Control Systems
CHA704-225L	Shaft Assembly	Goodrich Control Systems
CHA704-226	Shaft Assembly	Goodrich Control Systems
CHA704-226L	Shaft Assembly	Goodrich Control Systems
CHA704-227	Shaft Assembly	Goodrich Control Systems
CHA704-227L	Shaft Assembly	Goodrich Control Systems
CHA704-228	Shaft Assembly	Goodrich Control Systems
CHA704-228L	Shaft Assembly	Goodrich Control Systems
CHA704-229	Shaft Assembly	Goodrich Control Systems
CHA704-229L	Shaft Assembly	Goodrich Control Systems
CHA704-230	Shaft Assembly	Goodrich Control Systems
CHA704-231	Shaft Assembly	Goodrich Control Systems
CHA704-231L	Shaft Assembly	Goodrich Control Systems
CHA704-232	Shaft Assembly	Goodrich Control Systems
CHA704-232L	Shaft Assembly	Goodrich Control Systems
CHA704-233	Shaft Assembly	Goodrich Control Systems
CHA704-234	Shaft Assembly	Goodrich Control Systems
CHA704-235	Shaft Assembly	Goodrich Control Systems
CHA704-235L	Shaft Assembly	Goodrich Control Systems
CHA704-236	Shaft Assembly	Goodrich Control Systems
CHA704-236L	Shaft Assembly	Goodrich Control Systems
CHA704-237	Shaft Assembly	Goodrich Control Systems
CHA704-238	Shaft Assembly	Goodrich Control Systems
CHA704-239	Shaft Assembly	Goodrich Control Systems
CHA704-239L	Shaft Assembly	Goodrich Control Systems
CHA704-240	Shaft Assembly	Goodrich Control Systems
CHA704-241	Shaft Assembly	Goodrich Control Systems
CHA704-242	Shaft Assembly	Goodrich Control Systems
CHA704-242L	Shaft Assembly	Goodrich Control Systems
CHA704-243	Shaft Assembly	Goodrich Control Systems
CHA704-243L	Shaft Assembly	Goodrich Control Systems
CHA704-244	Shaft Assembly	Goodrich Control Systems
CHA704-336	Shaft Assembly	Goodrich Control Systems

Repair_Capability_List_Excel

CHA704-354	Shaft Assembly	Goodrich Control Systems
CHA704-354L	Shaft Assembly	Goodrich Control Systems
CHA704-356	Shaft Assembly	Goodrich Control Systems
CHA704-357	Shaft Assembly	Goodrich Control Systems
CHA704-357L	Shaft Assembly	Goodrich Control Systems
CHA704-369	Shaft Assembly	Goodrich Control Systems
CHA704-369L	Shaft Assembly	Goodrich Control Systems
CHA704-370	Universal Joint	Goodrich Control Systems
CHA704-390	Shaft Assembly	Goodrich Control Systems
CHA704-413	Steady Bearing	Goodrich Control Systems
CHA704-416	Shaft Assembly	Goodrich Control Systems
CHA704-419	Shaft Assembly	Goodrich Control Systems
CHA704-420	Shaft Assembly	Goodrich Control Systems
CHA704-424	Box Coupling	Goodrich Control Systems
CHA704-425	Shaft Assembly	Goodrich Control Systems
CHA704-427	Shaft Assembly	Goodrich Control Systems
CHA704-428	Shaft Assembly	Goodrich Control Systems
CHA704-429	Shaft Assembly	Goodrich Control Systems
CHA704-430	Shaft Assembly	Goodrich Control Systems
CHA704-431	Shaft Assembly	Goodrich Control Systems
CHA704-433	Shaft Assembly	Goodrich Control Systems
CHA704-434	Shaft Assembly	Goodrich Control Systems
CHA704-435	Shaft Assembly	Goodrich Control Systems
CHA704-436	Shaft Assembly	Goodrich Control Systems
CHA704-437	Shaft Assembly	Goodrich Control Systems
CHA704-438	Shaft Assembly	Goodrich Control Systems
CHA704-439	Shaft Assembly	Goodrich Control Systems
CHA704-441	Steady Bearing	Goodrich Control Systems
CHA704-443	Shaft Assembly	Goodrich Control Systems
CHA704-444	Shaft Assembly	Goodrich Control Systems
CHA704-449	Steady Bearing	Goodrich Control Systems
CHA704-450	Shaft Assembly	Goodrich Control Systems
CHA704-453	Shaft Assembly	Goodrich Control Systems
CHA704-695	Universal joint	Goodrich Control Systems
CHA704-696	Steady Bearing	Goodrich Control Systems
CHA704-697	Shaft Assembly	Goodrich Control Systems
CHA704-698	Shaft Assembly	Goodrich Control Systems
CHA704-700	Shaft Assembly	Goodrich Control Systems
CHA704-702	Shaft Assembly	Goodrich Control Systems
CHA704-703	Box Coupling	Goodrich Control Systems
CHA704-704	Shaft Assembly	Goodrich Control Systems
CHA704-705	Shaft Assembly	Goodrich Control Systems
CHA704-706	Shaft Assembly	Goodrich Control Systems
CHA704-707	Shaft Assembly	Goodrich Control Systems
CHA704-708	Shaft Assembly	Goodrich Control Systems
CHA704-710	Steady Bearing	Goodrich Control Systems
CHA704-711	Shaft Assembly	Goodrich Control Systems
CHA704-713	Universal Joint	Goodrich Control Systems
CHA704-714	Shaft Assembly	Goodrich Control Systems
CHA704-716	Shaft Assembly	Goodrich Control Systems
CHA704-717	Shaft Assembly	Goodrich Control Systems
CHA704-718	Shaft Assembly	Goodrich Control Systems
CHA704-719	Steady Bearing	Goodrich Control Systems
CHA704-720	Shaft Assembly	Goodrich Control Systems
CHA704-721	Shaft Assembly	Goodrich Control Systems
CHA704-722	Shaft Assembly	Goodrich Control Systems
CHA704-723	Shaft Assembly	Goodrich Control Systems
CHA704-724	Shaft Assembly	Goodrich Control Systems

Repair_Capability_List_Excel

CHA704-725	Universal Joint	Goodrich Control Systems
CHA704-726	Shaft Assembly	Goodrich Control Systems
CHA704-727	Steady Bearing	Goodrich Control Systems
CHA704-728	Box Coupling	Goodrich Control Systems
CHA704-729	Shaft Assembly	Goodrich Control Systems
CHA704-730	Shaft Assembly	Goodrich Control Systems
CHA704-731	Shaft Assembly	Goodrich Control Systems
CHA704-732	Shaft Assembly	Goodrich Control Systems
CHA704-736	Universal joint	Goodrich Control Systems
CHA704-737	Shaft Assembly	Goodrich Control Systems
CHA704-738	Shaft Assembly	Goodrich Control Systems
CHA704-740	Shaft Assembly	Goodrich Control Systems
CHA704-742	Shaft Assembly	Goodrich Control Systems
CHA704-743	Shaft Assembly	Goodrich Control Systems
CHA704-744	Shaft Assembly	Goodrich Control Systems
CHA704-746	Steady Bearing	Goodrich Control Systems
CHA704-747	Shaft Assembly	Goodrich Control Systems
CHA704-749	Universal Joint	Goodrich Control Systems
CHA704-750	Shaft Assembly	Goodrich Control Systems
CHA704-752	Shaft Assembly	Goodrich Control Systems
CHA704-753	Shaft Assembly	Goodrich Control Systems
CHA704-754	Steady Bearing	Goodrich Control Systems
CHA704-755	Shaft Assembly	Goodrich Control Systems
CHA704-756	Shaft Assembly	Goodrich Control Systems
CHA704-757	Shaft Assembly	Goodrich Control Systems
CHA704-758	Shaft Assembly	Goodrich Control Systems
CHA704-759	Shaft Assembly	Goodrich Control Systems
CHA704-760	Shaft Assembly	Goodrich Control Systems
CHA704-761	Universal Joint	Goodrich Control Systems
CHA704-783	Shaft Assembly	Goodrich Control Systems
CHA704-785	Coupling Box	Goodrich Control Systems
CHA704-786	Shaft Assembly	Goodrich Control Systems
CHA704-787	Shaft Assembly	Goodrich Control Systems
CHA704-788	Shaft Assembly	Goodrich Control Systems
CHA704-789	Shaft Assembly	Goodrich Control Systems
CHA704-810	Universal Joint	Goodrich Control Systems
CHA704-820	Steady Bearing	Goodrich Control Systems
CHA705-007	Flap Control Unit	Goodrich Control Systems
CHA705-008	Flap Control Unit	Goodrich Control Systems
CHA705-009	Flap Control Unit	Goodrich Control Systems
CHA705-010A	Flap Control Unit	Goodrich Control Systems
CHA705-011A	Flap Control Unit	Goodrich Control Systems
CHA705-012A	Flap Control Unit	Goodrich Control Systems
CHA705-013A	Flap Control Unit	Goodrich Control Systems
CHA705-013B	Flap Control Unit	Goodrich Control Systems
CHA705-013C	Flap Control Unit	Goodrich Control Systems
CHA705-014A	Flap Control Unit	Goodrich Control Systems
CHA705-014B	Flap Control Unit	Goodrich Control Systems
CHA705-014F	Flap Control Unit	Goodrich Control Systems
CHA705-014G	Flap Control Unit	Goodrich Control Systems
CHA705-015A	Flap Control Unit	Goodrich Control Systems
CHA705-015B	Flap Control Unit	Goodrich Control Systems
CHA705-015C	Flap Control Unit	Goodrich Control Systems
CHA705-015D	Flap Control Unit	Goodrich Control Systems
CHA705-016B	Flap Control Unit	Goodrich Control Systems
CHA705-016D	Flap Control Unit	Goodrich Control Systems
CHA705-017B	Flap Control Unit	Goodrich Control Systems
CHA705-017D	Flap Control Unit	Goodrich Control Systems

Repair_Capability_List_Excel

CHA705-018D	Flap Control Unit	Goodrich Control Systems
CHA705-019A	Flap Control Unit	Goodrich Control Systems
CHA705-3020B	Flap Control Unit	Goodrich Control Systems
CHA705-3020C	Flap Control Unit	Goodrich Control Systems
CHA705-3020D	Flap Control Unit	Goodrich Control Systems
CHA705-3020E	Flap Control Unit	Goodrich Control Systems
CHA706-005	Torque Limiter	Goodrich Control Systems
CHA706-006A	Torque Limiter	Goodrich Control Systems
CHA706-007A	Torque Limiter	Goodrich Control Systems
CHA707-002	Tee Gearbox	Goodrich Control Systems
CHA707-002L	Tee Gearbox	Goodrich Control Systems
CHA707-002R	Tee Gearbox	Goodrich Control Systems
CHA707-003A	Tee Gearbox	Goodrich Control Systems
CHA707-003AR	Tee Gearbox	Goodrich Control Systems
CHA707-004A	Tee Gearbox	Goodrich Control Systems
CHA707-005A	Tee Gearbox	Goodrich Control Systems
CHA707-005B	Tee Gearbox	Goodrich Control Systems
CHA707-005C	Tee Gearbox	Goodrich Control Systems
CHA709-003	Bevel Gearbox	Goodrich Control Systems
CHA709-003L	Bevel Gearbox	Goodrich Control Systems
CHA709-003R	Bevel Gearbox	Goodrich Control Systems
CHA709-004A	Bevel Gearbox	Goodrich Control Systems
CHA709-004AR	Bevel Gearbox	Goodrich Control Systems
CHA709-005A	Bevel Gearbox	Goodrich Control Systems
CHA709-006A	Bevel Gearbox	Goodrich Control Systems
CHA710-001	Duplex Bevel Gearbox	Goodrich Control Systems
CHA710-002A	Duplex Bevel Gearbox	Goodrich Control Systems
CHA710-003A	Duplex Bevel Gearbox	Goodrich Control Systems
CHA710-003B	Duplex Bevel Gearbox	Goodrich Control Systems
CHA717-002	Aileron Droop Signal Unit	Goodrich Control Systems
CHA717-004	Aileron Droop Signal Unit	Goodrich Control Systems
CHA717-005	Aileron Droop Signal Unit	Goodrich Control Systems
CHA717-006A	Aileron Droop Signal Unit	Goodrich Control Systems
CHA717-007A	Aileron Droop Signal Unit	Goodrich Control Systems
CHA717-008A	Aileron Droop Signal Unit	Goodrich Control Systems
CHA719-002	Gearbox Downdrive	Goodrich Control Systems
CHA719-002L	Gearbox Downdrive	Goodrich Control Systems
CHA719-002R	Gearbox Downdrive	Goodrich Control Systems
CHA719-003A	Gearbox Downdrive	Goodrich Control Systems
CHA719-004A	Gearbox Downdrive	Goodrich Control Systems
CHA719-005A	Gearbox Downdrive	Goodrich Control Systems
CHA719-005B	Gearbox Downdrive	Goodrich Control Systems
CHA720-002	Gearbox Downdrive	Goodrich Control Systems
CHA720-002L	Gearbox Downdrive	Goodrich Control Systems
CHA720-002R	Gearbox Downdrive	Goodrich Control Systems
CHA720-003A	Gearbox Downdrive	Goodrich Control Systems
CHA720-004A	Gearbox Downdrive	Goodrich Control Systems
CHA720-005A	Gearbox Downdrive	Goodrich Control Systems
CHA720-005B	Gearbox Downdrive	Goodrich Control Systems
CHA722-146	Shaft Assembly	Goodrich Control Systems
CHA722-146L	Shaft Assembly	Goodrich Control Systems
CHA722-147	Shaft Assembly	Goodrich Control Systems
CHA722-147L	Shaft Assembly	Goodrich Control Systems
CHA722-155	Shaft Assembly	Goodrich Control Systems
CHA722-155L	Shaft Assembly	Goodrich Control Systems
CHA722-156	Shaft Assembly	Goodrich Control Systems
CHA722-156L	Shaft Assembly	Goodrich Control Systems
CHA722-157	Shaft Assembly	Goodrich Control Systems

Repair_Capability_List_Excel

CHA722-158	Shaft Assembly	Goodrich Control Systems
CHA722-158L	Shaft Assembly	Goodrich Control Systems
CHA722-159	Shaft Assembly	Goodrich Control Systems
CHA722-159L	Shaft Assembly	Goodrich Control Systems
CHA722-160	Shaft Assembly	Goodrich Control Systems
CHA722-161	Shaft Assembly	Goodrich Control Systems
CHA722-161L	Shaft Assembly	Goodrich Control Systems
CHA722-162	Shaft Assembly	Goodrich Control Systems
CHA722-162L	Shaft Assembly	Goodrich Control Systems
CHA722-163	Shaft Assembly	Goodrich Control Systems
CHA722-170	Shaft Assembly	Goodrich Control Systems
CHA722-170L	Shaft Assembly	Goodrich Control Systems
CHA722-184	Shaft assy Downdrive	Goodrich Control Systems
CHA722-185	Shaft assy Downdrive	Goodrich Control Systems
CHA722-186	Shaft assy Downdrive	Goodrich Control Systems
CHA722-187	Shaft assy Downdrive	Goodrich Control Systems
CHA722-188	Box Coupling	Goodrich Control Systems
CHA722-188L	Box Coupling	Goodrich Control Systems
CHA722-189	Steady Bearing	Goodrich Control Systems
CHA722-189L	Steady Bearing	Goodrich Control Systems
CHA722-190	Shaft Assembly	Goodrich Control Systems
CHA722-191	Shaft Assembly	Goodrich Control Systems
CHA722-191L	Shaft Assembly	Goodrich Control Systems
CHA722-192	Shaft Assembly	Goodrich Control Systems
CHA722-192L	Shaft Assembly	Goodrich Control Systems
CHA722-219	Shaft Sub -assy	Goodrich Control Systems
CHA722-300	Steady Bearing	Goodrich Control Systems
CHA722-302	Shaft Assembly	Goodrich Control Systems
CHA722-303	Shaft Assembly	Goodrich Control Systems
CHA722-304	Shaft Assembly	Goodrich Control Systems
CHA722-305	Shaft Assembly	Goodrich Control Systems
CHA722-307	Shaft Assembly	Goodrich Control Systems
CHA722-308	Shaft Assembly	Goodrich Control Systems
CHA722-309	Shaft Assembly	Goodrich Control Systems
CHA722-310	Shaft Assembly	Goodrich Control Systems
CHA722-311	Shaft Assembly	Goodrich Control Systems
CHA722-313	Shaft Assembly	Goodrich Control Systems
CHA722-318	Shaft Assembly	Goodrich Control Systems
CHA722-321	Shaft assy Downdrive	Goodrich Control Systems
CHA722-322	Shaft assy Downdrive	Goodrich Control Systems
CHA722-323	Shaft assy Downdrive	Goodrich Control Systems
CHA722-324	Shaft assy Downdrive	Goodrich Control Systems
CHA722-336	Box Coupling	Goodrich Control Systems
CHA722-367	Shaft assy Downdrive	Goodrich Control Systems
CHA722-368	Shaft assy Downdrive	Goodrich Control Systems
CHA722-369	Shaft assy Downdrive	Goodrich Control Systems
CHA722-374	Shaft assy Downdrive	Goodrich Control Systems
CHA722-375	Shaft assy Downdrive	Goodrich Control Systems
CHA722-376	Shaft assy Downdrive	Goodrich Control Systems
CHA722-388	Shaft Assembly	Goodrich Control Systems
CHA722-389	Shaft Assembly	Goodrich Control Systems
CHA722-390	Universal Joint	Goodrich Control Systems
CHA722-391	Shaft Assembly	Goodrich Control Systems
CHA722-392	Steady Bearing	Goodrich Control Systems
CHA722-393	Shaft Assembly	Goodrich Control Systems
CHA722-394	Shaft Assembly	Goodrich Control Systems
CHA722-396	Shaft Assembly	Goodrich Control Systems
CHA722-397	Box Coupling	Goodrich Control Systems

Repair_Capability_List_Excel

CHA722-398	Shaft Assembly	Goodrich Control Systems
CHA722-399	Shaft Assembly	Goodrich Control Systems
CHA722-400	Shaft Assembly	Goodrich Control Systems
CHA722-402	Shaft Assembly	Goodrich Control Systems
CHA722-403	Shaft Assembly	Goodrich Control Systems
CHA722-404	Shaft Assembly	Goodrich Control Systems
CHA722-410	Shaft Assembly	Goodrich Control Systems
CHA722-411	Shaft Assembly	Goodrich Control Systems
CHA722-412	Universal Joint	Goodrich Control Systems
CHA722-416	Box Coupling	Goodrich Control Systems
CHA722-419	Steady Bearing	Goodrich Control Systems
CHA722-420	Joint Assy	Goodrich Control Systems
CHA722-421	Coupling Box	Goodrich Control Systems
CHA722-422	Shaft Assembly	Goodrich Control Systems
CHA722-423	Steady Bearing	Goodrich Control Systems
CHA722-424	Shaft Assembly	Goodrich Control Systems
CHA722-435	Shaft Assembly	Goodrich Control Systems
CHA722-436	Shaft Assembly	Goodrich Control Systems
CHA722-437	Shaft Assembly	Goodrich Control Systems
CHA722-438	Shaft Assembly	Goodrich Control Systems
CHA722-439	Shaft Assembly	Goodrich Control Systems
CHA722-440	Shaft Assembly	Goodrich Control Systems
CHA722-441	Steady Bearing	Goodrich Control Systems
CHA722-442	Shaft Assembly	Goodrich Control Systems
CHA722-443	Shaft Assembly	Goodrich Control Systems
CHA722-444	Torque Tube assy	Goodrich Control Systems
CHA722-449	Steady Bearing	Goodrich Control Systems
CHA722-501	Steady Bearing	Goodrich Control Systems
CHA722-502	Steady Bearing	Goodrich Control Systems
CHA722-503	Shaft assy Downdrive	Goodrich Control Systems
CHA722-504	Shaft assy Downdrive	Goodrich Control Systems
CHA722-505	Shaft assy Downdrive	Goodrich Control Systems
CHA722-506	Shaft assy Downdrive	Goodrich Control Systems
CHA722-528	Shaft assy Downdrive	Goodrich Control Systems
CHA722-529	Shaft assy Downdrive	Goodrich Control Systems
CHA722-530	Shaft assy Downdrive	Goodrich Control Systems
CHA722-531	Shaft assy Downdrive	Goodrich Control Systems
CHA722-754	Steady Bearing	Goodrich Control Systems
CHA722-820	Steady Bearing	Goodrich Control Systems
CHA723-010	Tailplane Trim Actuator	Goodrich Control Systems
CHA723-011	Tailplane Trim Actuator	Goodrich Control Systems
CHA723-012	Tailplane Trim Actuator	Goodrich Control Systems
CHA723-014A	Tailplane Trim Actuator	Goodrich Control Systems
CHA723-014C	Tailplane Trim Actuator	Goodrich Control Systems
CHA723-014D	Tailplane Trim Actuator	Goodrich Control Systems
CHA723-014F	Tailplane Trim Actuator	Goodrich Control Systems
CHA723-015A	Tailplane Trim Actuator	Goodrich Control Systems
CHA723-016A	Tailplane Trim Actuator	Goodrich Control Systems
CHA723-016B	Tailplane Trim Actuator	Goodrich Control Systems
CHA723-016C	Tailplane Trim Actuator	Goodrich Control Systems
CHA723-016E	Tailplane Trim Actuator	Goodrich Control Systems
CHA723-017B	Tailplane Trim Actuator	Goodrich Control Systems
CHA723-018B	Tailplane Trim Actuator	Goodrich Control Systems
CHA723-018C	Tailplane Trim Actuator	Goodrich Control Systems
CHA723-018E	Tailplane Trim Actuator	Goodrich Control Systems
CHA723-018F	Tailplane Trim Actuator	Goodrich Control Systems
CHA723-018G	Tailplane Trim Actuator	Goodrich Control Systems
CHA723-018H	Tailplane Trim Actuator	Goodrich Control Systems

Repair_Capability_List_Excel

CHA743-008A	Aileron Droop Signal Unit	Goodrich Control Systems
CHA757-002A	Slat Instrumentation Unit	Goodrich Control Systems
CHA757-003A	Slat Instrumentation Unit	Goodrich Control Systems
CHA757-004A	Slat Instrumentation Unit	Goodrich Control Systems
CHA757-004B	Slat Instrumentation Unit	Goodrich Control Systems
CHA757-005A	Slat Instrumentation Unit	Goodrich Control Systems
CHA758-001	Bevel Gearbox	Goodrich Control Systems
CHA758-002A	Bevel Gearbox	Goodrich Control Systems
CM-2664-1	Voltmeter	Textron
CM412A	Pressure Switch	Goodrich Control Systems
CM412C130	Pressure Switch	Goodrich Control Systems
CM4412C130	Pressure Switch	SAMM
CMK80-01	Pressure Switch	Intertechnique
CMK80-1	Pressure Switch	Eros
CN110	Control Valve	Goodrich Control Systems
CN110-1	Control Valve	Goodrich Control Systems
CN120	Control Valve	Goodrich Control Systems
CP1600A	Audio Control Panel	TEAM
CP1600AA	Audio Control Panel	TEAM
CP1600B	Audio Control Panel	TEAM
CP1600BA	Audio Control Panel	TEAM
CP1600C	Audio Control Panel	TEAM
CP1600D	Audio Control Panel	TEAM
CP1600E	Audio Control Panel	TEAM
CP1600EA	Audio Control Panel	TEAM
CP1600G	Audio Control Panel	TEAM
CP1600H	Audio Control Panel	TEAM
CP1600HA	Audio Control Panel	TEAM
CP1600JA	Audio Control Panel	TEAM
CRB65	Overboard Discharge Indicator	Intertechnique
CS4003-02	Cargo Interlock Switch	Telair International
CT141	Check Valve	Technofan
CT141-1	Check Valve	Technofan
CT180	Non-Return Valve	Technofan
CT191B	Check Valve	Technofan
CT191B	Check Valve	Technofan
CUF5395	Panel	Thales Avionics
CV40-1	Check Valve	Circle Seal Controls
CZ90MGA	Pressure Transducer	Schlumberger
CZ9284E	Pressure Transducer	Sagem
CZ92A4-2	Pressure Transducer	Enertec-Schlumberger
CZ9DM6A	Pressure Transducer	Sagem
D01000	Drain assy	Westland-Sitec
D01A00	Drain assy	Westland-Sitec
D01B00	Drain assy	Westland-Sitec
D01C00	Drain assy	Westland-Sitec
D01H00	Drain assy	Westland-Sitec
D01K00	Drain assy	Westland-Sitec
D026-001	Servo valve	Moog
D026-002	Servo valve	Moog
D02A00	Drain assy	Westland-Sitec
D030VM306C	Magnetic Indicator	Framatome Connectors
D05000	Drain Fill Valve	Westland-Sitec
D05A00	Drain Fill Valve	Westland-Sitec
D06A00	Fill & Drain Valve	Westland-Sitec
D1522-4	Rotary Actuator	Eaton Aerospace
D1522-5	Rotary Actuator	Eaton Aerospace
D-17	Pressure Gage	Ametek

Repair_Capability_List_Excel

D1775	A/C Motor	Vickers
D1775-1	A/C Motor	Vickers
D1775-3	A/C Motor	Vickers
D17996	Evacuation System	Air Cruiser
D-18	Pressure Gage	Ametek
D18309	Reservoir	Aircruiser
D19207-701	Hydraulic Test Panel	Fokker Aircraft
D19207-801	Hydraulic Test Panel	Fokker Aircraft
D19220-801	MLG Door Uplock	Fokker Aircraft
D19220-802	MLG Door Uplock	Fokker Aircraft
D19220-803	MLG Door Uplock	Fokker Aircraft
D19220-804	MLG Door Uplock	Fokker Aircraft
D201094	Static Probe	Vulcanic
D2063	Rotary Actuator	Vickers
D2063-1	Rotary Actuator	Vickers
D2063-11	Rotary Actuator	Vickers
D2063-12	Rotary Actuator	Vickers
D2063-6	Rotary Actuator	Eaton Aerospace
D2063-7	Rotary Actuator	Vickers
D2063-9	Rotary Actuator	Vickers
D2063MD1-2	Rotary Actuator	Vickers
D2063MD-2	Rotary Actuator	Vickers
D2063MD6-1	Rotary Actuator	Eaton Aerospace
D2063MD7-2	Rotary Actuator	Vickers
D2067-3	Rotary Actuator	Vickers
D2067-4	Rotary Actuator	Vickers
D2067-5	Rotary Actuator	Vickers
D2067-6	Rotary Actuator	Vickers
D2067-8	Rotary Actuator	Vickers
D2067-9	Rotary Actuator	Vickers
D2070	Rotary Actuator	Eaton
D2070-1	Rotary Actuator	Eaton
D2070-11	Rotary Actuator	Eaton
D2070-2	Rotary Actuator	Eaton
D2070-3	Rotary Actuator	Eaton
D2070-9	Rotary Actuator	Eaton
D21310-401	NLG Door assy	Fokker Aircraft
D21310-403	NLG Door assy	Fokker Aircraft
D21310-405	NLG Door assy	Fokker Aircraft
D21310-407	NLG Door assy	Fokker Aircraft
D21310-409	NLG Door assy	Fokker Aircraft
D21310-411	NLG Door assy	Fokker Aircraft
D21310-413	NLG Door assy	Fokker Aircraft
D21310-415	NLG Door assy	Fokker Aircraft
D2157103000000	Ram Air Outlet Flap	Airbus Industrie
D2157103000200	Ram Air Outlet Flap	Airbus Industrie
D2157103000400	Ram Air Outlet Flap	Airbus Industrie
D2157103000600	Ram Air Outlet Flap	Airbus Industrie
D2173-2	Wing Flap Actuation System	Eaton Aerospace
D2173-3	Wing Flap Actuation System	Eaton Aerospace
D2173-5	Wing Flap Actuation System	Eaton Aerospace
D2173-7	Wing Flap Actuation System	Eaton Aerospace
D22085	Electrical Loom	Messier-Bugatti
D22086	Electrical Loom	Messier-Bugatti
D22090	Electrical Loom	Messier-Bugatti
D22237000	Manifold	Messier-Bugatti
D22237000-1	Manifold	Messier-Bugatti
D22237001	Standby Brakes Manifold	Messier-Bugatti

Repair_Capability_List_Excel

D22237002	Manifold	Messier-Bugatti
D22238000	Manifold	Messier-Bugatti
D22238000-1	Manifold	Messier-Bugatti
D22238001	Standby Brakes Manifold	Messier-Bugatti
D22238002	Manifold	Messier-Bugatti
D22261000	Electrical Loom	Messier-Bugatti
D22262000	Electrical Loom	Messier-Bugatti
D22263000	Electrical Loom	Messier-Bugatti
D22263000-1	Electrical Loom	Messier-Bugatti
D22264000	Electrical Loom	Messier-Bugatti
D22264000-1	Electrical Loom	Messier-Bugatti
D22265000	Electrical Loom	Messier-Bugatti
D22266000	Electrical Loom	Messier-Bugatti
D22267000	Electrical Loom	Messier-Bugatti
D22268000	Electrical Loom	Messier-Bugatti
D22269000	Electrical Loom	Messier-Bugatti
D22269000-1	Electrical Loom	Messier-Bugatti
D22270000	Electrical Loom	Messier-Bugatti
D22270000-1	Electrical Loom	Messier-Bugatti
D22271000	Electrical Loom	Messier-Bugatti
D22272000	Electrical Loom	Messier-Bugatti
D22273000	Electrical Loom	Messier-Bugatti
D22274000	Electrical Loom	Messier-Bugatti
D22275000	Electrical Loom	Messier-Bugatti
D22276000	Electrical Loom	Messier-Bugatti
D22296000	Electrical Loom	Messier-Bugatti
D22296010	Electrical Loom	Messier-Bugatti
D22297000	Electrical Loom	Messier-Bugatti
D22297000-1	Electrical Loom	Messier-Bugatti
D22297010-1	Electrical Loom	Messier-Bugatti
D22297020	Electrical Loom	Messier-Bugatti
D22298000	Electrical Loom	Messier-Bugatti
D22298010	Electrical Loom	Messier-Bugatti
D22322000	Electrical Loom	Messier-Bugatti
D22322000-1	Electrical Loom	Messier-Bugatti
D22365000	Electrical Loom	Messier-Bugatti
D22365020	Electrical Loom	Messier-Bugatti
D22366000	Electrical Loom	Messier-Bugatti
D22366020	Electrical Loom	Messier-Bugatti
D22367000	Electrical Loom	Messier-Bugatti
D22367020	Electrical Loom	Messier-Bugatti
D22368000	Electrical Loom	Messier-Bugatti
D22368020	Electrical Loom	Messier-Bugatti
D22369000	Electrical Loom	Messier-Bugatti
D22369020	Electrical Loom	Messier-Bugatti
D22370000	Electrical Loom	Messier-Bugatti
D22370020	Electrical Loom	Messier-Bugatti
D22371000	Electrical Loom	Messier-Bugatti
D22371020	Electrical Loom	Messier-Bugatti
D22372000	Electrical Loom	Messier-Bugatti
D22372020	Electrical Loom	Messier-Bugatti
D22373000	Electrical Loom	Messier-Bugatti
D22373020	Electrical Loom	Messier-Bugatti
D22374000	Electrical Loom	Messier-Bugatti
D22374020	Electrical Loom	Messier-Bugatti
D22375000	Electrical Loom	Messier-Bugatti
D22375020	Electrical Loom	Messier-Bugatti
D22376000	Electrical Loom	Messier-Bugatti

Repair_Capability_List_Excel

D22376020	Electrical Loom	Messier-Bugatti
D2246-3	Linear Mechanical Actuator	Eaton Aerospace
D2246-4	Linear Mechanical Actuator	Eaton Aerospace
D2246-5	Linear Mechanical Actuator	Eaton Aerospace
D2246-6	Linear Mechanical Actuator	Eaton Aerospace
D22471000	Towing Adapter assy	Messier-Bugatti
D22474000	Block Valve Adaptor assy	Messier-Bugatti
D22647000	Towing Adapter assy	Messier-Bugatti
D22650000	Electrical Loom	Messier-Bugatti
D22709500	NLG Actuator	Messier-Dowty
D22715500	MLG Unlocking Actuator	Messier-Dowty
D2287800-1	Adapter	Messier-Bugatti
D22897500	MLG Actuator	Messier-Dowty
D22898500	MLG Actuator	Messier-Dowty
D22AA1022	Fuel Return Valve	Goodrich Control Systems
D22AA1023	Fuel Return Valve	Goodrich
D22AA1031	Fuel Return Valve	Goodrich
D22AA1032	Fuel Return Valve	Goodrich
D22AA1034	Fuel Return Valve	Goodrich
D22AA1035	Fuel Return Valve	Goodrich
D22AA1036	Fuel Return Valve	Goodrich
D22AA1042	Fuel Return Valve	Goodrich Control Systems
D22AA1043	Fuel Return Valve	Goodrich Control Systems
D23071000	Actuating Cylinder	Messier-Bugatti
D23071000-1	Actuating Cylinder	Messier-Bugatti
D23071001	Actuating Cylinder	Messier-Bugatti
D23071001A	Actuating Cylinder	Messier-Bugatti
D23076000	Unlocking Actuator	Messier-Bugatti
D23076000-1	Unlocking Actuator	Messier-Bugatti
D23076000-2	Unlocking Actuator	Messier-Bugatti
D23076000-3	Unlocking Actuator	Messier-Bugatti
D23081000	Bearing Spherical	Messier-Bugatti
D23083000	Swivel Bearing	Messier-Dowty
D23090000-2	Thrust Reverser Actuator	Goodrich Control Systems
D23090000-3	Thrust Reverser Actuator	Goodrich Control Systems
D23090000-4	Thrust Reverser Actuator	Goodrich Control Systems
D23090000-5	Thrust Reverser Actuator	Goodrich Control Systems
D23090000-6	Thrust Reverser Actuator	Goodrich Control Systems
D23090000-6 Amdt B	Thrust Reverser Actuator	Goodrich Control Systems
D23116000	Anti-Shimmy Valve	Messier-Bugatti
D23119550	Electrical Box	Messier- Dowty
D23120000	Upper Electrical Harness	Messier-Bugatti
D23120000-1	Upper Electrical Harness	Messier-Bugatti
D23120001	Upper Electrical Harness	Messier-Bugatti
D23121000-1	Electrical Harness	Messier-Bugatti
D23121111	Upper Electrical Harness	Messier-Bugatti
D23123000	NLG Towing Attachment	Messier-Bugatti
D23150000	Lower Electrical Harness	Messier-Bugatti
D23150000-1	Lower Electrical Harness	Messier-Bugatti
D23150001	Lower Electrical Harness	Messier-Bugatti
D23154000	Intermediate Electrical Harness	Messier-Bugatti
D23154000-1	Intermediate Electrical Harness	Messier-Bugatti
D23154001	Intermediate Electrical Harness	Messier-Bugatti
D23159000	Electrical Harness	Messier-Bugatti
D23159000-1	Electrical Harness	Messier-Bugatti
D23159001	Electrical Harness	Messier-Bugatti
D23160000	Electrical Harness	Messier-Bugatti
D23160000-1	Electrical Harness	Messier-Bugatti

Repair_Capability_List_Excel

D23160000-2	Electrical Harness	Messier-Bugatti
D23160001	Electrical Harness	Messier-Bugatti
D2328000-2	LEG FITTING	MESSIER DOWTY
D23285001-6	NOSE LANDING GEAR	MESSIER DOWTY
D23285051-4	LANDING GEAR LEG	MESSIER DOWTY
D23285200	LANDING GEAR LEG	MESSIER DOWTY
D23286001-1	MAIN SHOCK	MESSIER DOWTY
D23286001-11	Main Shock Absorder Structure	Messier- Dowty
D23287000	Steering Actuator	Messier-Bugatti
D23289050	Upper Loom	Messier-Bugatti
D23289050-1	Upper Loom	Messier-Bugatti
D23289050-2	Upper Loom	Messier-Bugatti
D23289100	Upper Loom	Messier-Bugatti
D23289100-1	Upper Loom	Messier-Bugatti
D23289100-2	Upper Loom	Messier-Bugatti
D23290000	Upper Electrical Unit	Messier- Dowty
D23290050	Upper Loom	Messier-Bugatti
D23290050-1	Upper Loom	Messier-Bugatti
D23290100	Upper Loom	Messier-Bugatti
D23290100-1	Upper Loom	Messier-Bugatti
D23291000	Lower Loom	Messier-Bugatti
D23291050	Lower Loom	Messier-Bugatti
D23292000	Towing Fitting assy	Messier-Dowty
D23292000-1	Towing Fitting assy	Messier-Dowty
D23292000-2	Towing Fitting assy	Messier-Dowty
D23293000-1	Change Over Valve	Messier-Bugatti
D23298000	Lockstay Actuator	Messier - Bugatti
D23299000	Downlock Spring	Messier - Bugatti
D23303000-3	DRAG STAY	MESSIER DOWTY
D233520000-1	NLG Retraction Actuator	Messier-Bugatti
D23355000	Sleeve Axle	Messier-Bugatti
D23408000-1	Towing Fitting assy	Messier-Bugatti
D23408000-2	Towing Fitting assy	Messier-Bugatti
D23408000-3	Towing Fitting assy	Messier-Bugatti
D23443100	Leg Fitting	Messier-Dowty
D23443100-1	Leg Fitting	Messier-Dowty
D23443100-2	Leg Fitting	Messier-Dowty
D23444000	Drag Stay Upper Arm	Messier-Dowty
D23445000	Towing Fitting assy	Messier-Dowty
D23446100	Upper Loom	Messier-Dowty
D23446150	Upper Loom	Messier-Dowty
D23447000	Upper Loom	Messier-Dowty
D23447050	Am Upper Electrical Loom	Messier- Dowty
D23448000	Lower Loom	Messier-Dowty
D23448050	Lower Loom	Messier-Dowty
D23449000	Steering Actuator	Messier-Bugatti
D23450000	Change Over Valve	Messier-Bugatti
D23544000	Towing Fitting assy	Messier-Dowty
D23581100-1	LANDING GEAR LEG	MESSIER DOWTY
D23581150-1	LANDING GEAR LEG	MESSIER DOWTY
D23582100-1	Main Shock Absorder Structure	Messier- Dowty
D23585000	Box & Electrical Harness	Messier- Dowty
D23592000	Shock Absorber	Messier-Dowty
D23596000	NLG Strut assy	Messier-Dowty
D23599000	Forestay	Messier-Dowty
D23607000	Fitting Leg	Messier-Dowty
D23611000	Lock Spring	Messier-Dowty
D23612000	Lock Link	Messier-Dowty

Repair_Capability_List_Excel

D23613000	NLG Actuating Cylinder	Messier-Dowty
D23627000	Electrical Harness	Messier-Dowty
D23628000	Electrical Harness	Messier-Dowty
D23629000	Electrical Harness	Messier-Dowty
D23630000	Electrical Harness	Messier-Dowty
D2399-2	Nose Cargo Door Drive Unit	Eaton Aerospace
D2399-3	Nose Cargo Door Drive Unit	Eaton Aerospace
D2401-10	Linear Latch Actuator	Eaton Aerospace
D2401-11	Linear Latch Actuator	Eaton Aerospace
D2401-12	Linear Latch Actuator	Eaton Aerospace
D2401-13	Linear Latch Actuator	Eaton Aerospace
D2401-14	Linear Latch Actuator	Eaton Aerospace
D2401-15	Linear Latch Actuator	Eaton Aerospace
D2401-16	Linear Latch Actuator	Eaton Aerospace
D2401-7	Linear Latch Actuator	Eaton Aerospace
D2401-8	Linear Latch Actuator	Eaton Aerospace
D2401-9	Linear Latch Actuator	Eaton Aerospace
D2405-3	Push-Pull Linear Actuator	Eaton Aerospace
D2405-4	Push-Pull Linear Actuator	Eaton Aerospace
D2405-5	Push-Pull Linear Actuator	Eaton Aerospace
D2424018000000	Cable Quadrant	Airbus Industrie
D2511041300000	Arm assy	Airbus Industrie
D2557215800400	Mat-Ball assy	Airbus Industrie
D2557215901000	Mat-Ball assy	Airbus Industrie
D2557216800000	Mat-Ball assy	Airbus Industrie
D2557216900000	Mat-Ball assy	Airbus Industrie
D2557217000000	Mat-Ball assy	Airbus Industrie
D2557231000000	Door Sill Latch	Airbus Industrie
D2557231000200	Door Sill Latch	Airbus Industrie
D2557231000400	Door Sill Latch	Airbus Industrie
D2557231000600	Door Sill Latch	Airbus Industrie
D2557238500800	Guide assy	Airbus Industrie
D2557240101600	Guide assy	Airbus Industrie
D25AB1111	Flap Block Valve Restrictor	Lucas Aerospace
D25AB2430	Relief Valve	Goodrich Control Systems
D25AB2431	Relief Valve	Bronzavia-Air Equipement
D-25BA	Sidestable Contactor	Hartman
D25BD	Relay	CII Technologies
D-25BD	CONTACTOR	HARTMAN
D2611016000000	Duct assy	Airbus Industrie
D26AB1040	Cut-Out Valve	Lucas Air Equipement
D26AB1041	Cut-Out Valve	Lucas Air Equipement
D26AB1042	Cut-Out Valve	Lucas Air Equipement
D26AB1060	Free Fall Vent Valve	Lucas Air Equipement
D26AB1061	Free Fall Vent Valve	Lucas Air Equipement
D26AB1082	Cut-Out Valve	Goodrich Control Systems
D2711004000000	Roll Damper	Airbus Industrie
D2711004000100	Roll Damper	Airbus Industrie
D2721004000100	Pedal Position Adjuster ay	Airbus Industrie
D2727000100651	Rudder Control Frame	Airbus Industrie
D2727000100851	Rudder Control Frame	Airbus Industrie
D2727000101051	Rudder Control Frame	Airbus Industrie
D2727000101251	Rudder Control Frame	Airbus Industrie
D2727000101451	Rudder Control Frame	Airbus Industrie
D2727000101651	Rudder Control Frame	Airbus Industrie
D2727000101851	Rudder Control Frame	Airbus Industrie
D2727000102051	Rudder Control Frame	Airbus Industrie
D2727000102251	Rudder Control Frame	Airbus Industrie

Repair_Capability_List_Excel

D2727000700200	Spring Rod	Airbus Industrie
D2727000800200	Spring Rod	Airbus Industrie
D2727018000000	Quadrant Cable	Airbus Industrie
D2727025000400	Spring Rod	Airbus Industrie
D2727040000600	Artificial Feel and Trim Unit	Airbus Industrie
D2727040000651	Artif. Feel & Trim Unit without Solenoid	Airbus Industrie
D2727040000695	Artif. Feel & Trim Unit without Solenoid	Airbus Industrie
D2727040000696	Artificial Feel and Trim Unit	Airbus Industrie
D2727040000698	Artificial Feel and Trim Unit	Airbus Industrie
D2727040000800	Artificial Feel and Trim Unit	Airbus Industrie
D2727040000851	Artificial Feel and Trim Unit	Airbus Industrie
D2727040000896	Artificial Feel and Trim Unit	Airbus Industrie
D2727040001000	Artificial Feel and Trim Unit	Airbus Industrie
D2727040001051	Artificial Feel and Trim Unit	Airbus Industrie
D2727040001096	Artificial Feel and Trim Unit	Airbus Industrie
D2727040001200	Artificial Feel and Trim Unit	Airbus Industrie
D2731002000000	Spring Rod	Airbus Industrie
D2731002000100	Spring Rod	Airbus Industrie
D2731010000000	Pitch Damper	Airbus Industrie
D2731010000100	Pitch Damper	Airbus Industrie
D2731010000200	Pitch Damper	Airbus Industrie
D2731010000300	Pitch Damper	Airbus Industrie
D2731013000000	Spring Rod	Airbus Industrie
D2747008600000	Cable Tension Regulator	Airbus Industrie
D2751004300000	Flap Control	Airbus Industrie
D2751004300001	Flap and Slat Control Unit	Airbus Industrie
D27510043000AC	Flap and Slat Control Unit	Airbus Industrie
D2754002400200	Flap Actuator Levers N°2, 3 & 4	Airbus Industrie
D2754002400300	Flap Actuator Levers N°2, 3 & 4	Airbus Industrie
D2754002400600	Flap Actuator Levers N°2, 3 & 4	Airbus Industrie
D2754002400700	Flap Actuator Levers N°2, 3 & 4	Airbus Industrie
D2754002500200	Flap Actuator Levers N°2, 3 & 4	Airbus Industrie
D2754002500300	Flap Actuator Levers N°2, 3 & 4	Airbus Industrie
D2754002500800	Flap Actuator Levers N°2, 3 & 4	Airbus Industrie
D2754002500900	Flap Actuator Levers N°2, 3 & 4	Airbus Industrie
D2754002600200	Flap Actuator Levers N°2, 3 & 4	Airbus Industrie
D2754002600300	Flap Actuator Levers N°2, 3 & 4	Airbus Industrie
D2754002600600	Flap Actuator Levers N°2, 3 & 4	Airbus Industrie
D2754002600700	Flap Actuator Levers N°2, 3 & 4	Airbus Industrie
D2755001000200	Flap Actuator Levers N°2, 3 & 4	Airbus Industrie
D2755001000300	Flap Actuator Levers N°2, 3 & 4	Airbus Industrie
D2755001000600	Flap Actuator Levers N°2, 3 & 4	Airbus Industrie
D2755001000700	Flap Actuator Levers N°2, 3 & 4	Airbus Industrie
D2755001100200	Flap Actuator Levers N°2, 3 & 4	Airbus Industrie
D2755001100300	Flap Actuator Levers N°2, 3 & 4	Airbus Industrie
D2755001100600	Flap Actuator Levers N°2, 3 & 4	Airbus Industrie
D2755001100700	Flap Actuator Levers N°2, 3 & 4	Airbus Industrie
D2755001200200	Flap Actuator Levers N°2, 3 & 4	Airbus Industrie
D2755001200300	Flap Actuator Levers N°2, 3 & 4	Airbus Industrie
D2755001200600	Flap Actuator Levers N°2, 3 & 4	Airbus Industrie
D2755001200700	Flap Actuator Levers N°2, 3 & 4	Airbus Industrie
D2755304100000	Flap Track Carriages N°2, 3 & 4	Airbus Industrie
D2755304100200	Flap Track Carriages N°2, 3 & 4	Airbus Industrie
D2755304200000	Flap Track Carriages N°2, 3 & 4	Airbus Industrie
D2755304200200	Flap Track Carriages N°2, 3 & 4	Airbus Industrie
D2755305200400	Flap Track Carriages N°2, 3 & 4	Airbus Industrie
D2755305200600	Flap Track Carriages N°2, 3 & 4	Airbus Industrie
D2755305400400	Flap Track Carriages N°2, 3 & 4	Airbus Industrie

Repair_Capability_List_Excel

D2755305400600	Flap Track Carriages N°2, 3 & 4	Airbus Industrie
D2755600000651	Flap Track Carriages N°2, 3 & 4	Airbus Industrie
D2755600000851	Flap Track Carriages N°2, 3 & 4	Airbus Industrie
D2755605000251	Flap Track Carriages N°2, 3 & 4	Airbus Industrie
D2755605000651	Flap Track Carriages N°2, 3 & 4	Airbus Industrie
D2755605001051	Flap Track Carriages N°2, 3 & 4	Airbus Industrie
D2755605001251	Flap Track Carriages N°2, 3 & 4	Airbus Industrie
D2755605500651	Flap Track Carriages N°2, 3 & 4	Airbus Industrie
D2755605500751	Flap Track Carriages N°2, 3 & 4	Airbus Industrie
D2755605500851	Flap Track Carriages N°2, 3 & 4	Airbus Industrie
D2755605500951	Flap Track Carriages N°2, 3 & 4	Airbus Industrie
D2755611500000	Flap Actuator Levers N°2, 3 & 4	Airbus Industrie
D2755611500100	Flap Actuator Levers N°2, 3 & 4	Airbus Industrie
D2755611600800	Flap Actuator Levers N°2, 3 & 4	Airbus Industrie
D2755611600900	Flap Actuator Levers N°2, 3 & 4	Airbus Industrie
D2755611700000	Flap Actuator Levers N°2, 3 & 4	Airbus Industrie
D2755611700100	Flap Actuator Levers N°2, 3 & 4	Airbus Industrie
D2755875000051	Flap Track Carriages N°2, 3 & 4	Airbus Industrie
D2755875000251	Flap Track Carriages N°2, 3 & 4	Airbus Industrie
D2755875600051	Flap Track Carriages N°2, 3 & 4	Airbus Industrie
D2755875700051	Flap Track Carriages N°2, 3 & 4	Airbus Industrie
D2785004100000	Pinion assy Slat Tracks	Airbus Industrie
D2785004400000	Pinion assy Slat Tracks	Airbus Industrie
D2785012500000	Pinion assy Slat Tracks	Airbus Industrie
D2785012500200	Pinion assy Slat Tracks	Airbus Industrie
D2785012600000	Pinion assy Slat Tracks	Airbus Industrie
D2785012600200	Pinion assy Slat Tracks	Airbus Industrie
D2785012600400	Pinion assy Slat Tracks	Airbus Industrie
D2785012600600	Pinion assy Slat Tracks	Airbus Industrie
D2825006400200	Valve assy	Airbus Industrie
D2825013000000	Valve assy	Airbus Industrie
D2930A	Transformer	BIP
D3015000400000	Telescopic Duct	Airbus Industrie
D3015000400200	Telescopic Duct	Airbus Industrie
D31AB4411	MLG Selector Valve Manifold assy	Goodrich Control Systems
D31AB4411-2	MLG Selector Valve Manifold assy	Goodrich Control Systems
D31AB4412	MLG Selector Valve Manifold assy	Goodrich Control Systems
D31AB4430	MLG Safety Valve	Goodrich Control Systems
D31AB4431	MLG Safety Valve	Goodrich Control Systems
D31AB4510-1	LDG Selector Valve & Manifold assy	Goodrich Control Systems
D31AB4511	LDG Selector Valve & Manifold assy	Goodrich Control Systems
D31AB4530-1	LDG Selector Valve & Manifold assy	Goodrich Control Systems
D31AB4531	LDG Selector Valve & Manifold assy	Goodrich Control Systems
D31AB4551	Selector Valve	Goodrich Control Systems
D3214020300000	Strut-assy	Airbus Industrie
D3214020300200	Strut-assy	Airbus Industrie
D3215303000000	Pin	Airbus Industrie
D3215303000200	Pin	Airbus Industrie
D3231007000000	Reduction Gear Box	Airbus Industrie
D3231007000100	Reduction Gear Box	Airbus Industrie
D33375-401	Hydraulic Test Panel	Fokker Aircraft
D33375-405	Hydraulic Test Panel	Fokker Aircraft
D37080	Reservoir	Aircruiser
D41428	Pressure Reducer	Drager
D41552	Pressure Reducer	Drager
D455-01-001	Engine Fire Shut-Off Switch	Page Aerospace
D455-02-001	Engine Fire Shut-Off Switch	Page Aerospace
D455-03-001	Engine Fire Shut-Off Switch	Page Aerospace

Repair_Capability_List_Excel

D455-04-001	Engine Fire Shut-Off Switch	Page Aerospace
D455-05-001	Engine Fire Shut-Off Switch	Page Aerospace
D455-06-001	Engine Fire Shut-Off Switch	Page Aerospace
D455-07-001	Engine Fire Shut-Off Switch	Page Aerospace
D455-08-001	Engine Fire Shut-Off Switch	Page Aerospace
D455-15-001	Engine Fire Shut-Off Switch	Page Aerospace
D455-16-001	Engine Fire Shut-Off Switch	Page Aerospace
D455-17-001	Engine Fire Shut-Off Switch	Page Aerospace
D455-18-001	Engine Fire Shut-Off Switch	Page Aerospace
D455-19-001	Engine Fire Shut-Off Switch	Page Aerospace
D455-20-001	Engine Fire Shut-Off Switch	Page Aerospace
D455-21-001	Engine Fire Shut-Off Switch	Page Aerospace
D455-22-001	Engine Fire Shut-Off Switch	Page Aerospace
D455-23-001	Engine Fire Shut-Off Switch	Page Aerospace
D455-24-001	Engine Fire Shut-Off Switch	Page Aerospace
D455-25-001	Engine Fire Shut-Off Switch	Page Aerospace
D455-26-001	Engine Fire Shut-Off Switch	Page Aerospace
D455-51-001	Engine Fire Shut-Off Switch	Page
D455-52-001	Engine Fire Shut-Off Switch	Page
D455-55-001	Engine Fire Shut-Off Switch	Page
D455-56-001	Engine Fire Shut-Off Switch	Page
D4801-1	Contactora	Goodrich
D4802-1	Contactora	Goodrich
D4803	Contactora	Goodrich
D4804	Contactora	Goodrich
D494-07-001	Landing Gear Control Unit	Page
D494-13-001	Landing Gear Control Unit	Page
D494-14-001	Landing Gear Control Unit	Page
D5237210600000	Spring Unit	Airbus Industrie
D5241012500100	Avionics Compartment Access Door	Airbus Industrie
D5241012500300	Avionics Compartment Access Door	Airbus Industrie
D5241012500500	Avionics Compartment Access Door	Airbus Industrie
D5241012500700	Avionics Compartment Access Door	Airbus Industrie
D5241012500900	Avionics Compartment Access Door	Airbus Industrie
D5241014800100	Avionics Compartment Access Door	Airbus Industrie
D5241014800300	Avionics Compartment Access Door	Airbus Industrie
D5241018000100	Avionics Compartment Access Door	Airbus Industrie
D5241018000300	Avionics Compartment Access Door	Airbus Industrie
D5241020700100	Avionics Compartment Access Door	Airbus Industrie
D5241020700300	Avionics Compartment Access Door	Airbus Industrie
D5241025600000	Door assy	Airbus Industrie
D5241025600040	Door assy	Airbus Industrie
D5241025600042	Door assy	Airbus Industrie
D5241025600100	Door assy	Airbus Industrie
D5241025600200	Door assy	Airbus Industrie
D5241025600240	Door assy	Airbus Industrie
D5241026600040	Door assy	Airbus Industrie
D5261000300100	Entrance Stairs Doors	Airbus Industrie
D5281007500060	Rotary Connecting Rod	Airbus Industrie
D5281007500200	Rotary Connecting Rod	Airbus Industrie
D5311245600000	Fitting assy	Airbus Industrie
D5367304800000	Floor Panel	Airbus Industrie
D5367305400000	Floor Panel	Airbus Industrie
D5367305500000	Floor Panel	Airbus Industrie
D5367305900000	Floor Panel	Airbus Industrie
D5367306000000	Floor Panel	Airbus Industrie
D5367313400000	Floor Panel	Airbus Industrie
D5367313500000	Floor Panel	Airbus Industrie

Repair_Capability_List_Excel

D5367314100000	Floor Panel	Airbus Industrie
D5367314200000	Floor Panel	Airbus Industrie
D5367314300000	Floor Panel	Airbus Industrie
D5367324500000	Floor Panel	Airbus Industrie
D5367324600000	Floor Panel	Airbus Industrie
D5367324700200	Floor Panel	Airbus Industrie
D5367324700300	Floor Panel	Airbus Industrie
D5367324800000	Floor Panel	Airbus Industrie
D5367324900000	Floor Panel	Airbus Industrie
D5391078000100	Hinge assy	Airbus Industrie
D5754020000000	Support ay-frame H.1	Airbus Industrie
D5754020100000	Support ay-frame H.2	Airbus Industrie
D5754020200000	Support ay-frame H.3	Airbus Industrie
D5754169000000	Support ay-frame H.1	Airbus Industrie
D5754169000200	Support ay-frame H.1	Airbus Industrie
D5754169100000	Support ay-frame H.2	Airbus Industrie
D5754169100200	Support ay-frame H.2	Airbus Industrie
D5754169200000	Support ay-frame H.3	Airbus Industrie
D5754169200200	Support ay-frame H.3	Airbus Industrie
D5755600900000	Flap Track Carriage N°1	Airbus Industrie
D5757030500000	Connecting Strut	Airbus Industrie
D5757030500200	Connecting Strut	Airbus Industrie
D5757030500600	Connecting Strut	Airbus Industrie
D5757030500800	Connecting Strut	Airbus Industrie
D5757030501000	Connecting Strut	Airbus Industrie
D5757030501200	Connecting Strut	Airbus Industrie
D5757032200000	Connecting Strut	Airbus Industrie
D5757220000200	Flap Carriage Track N°1	Airbus Industrie
D5757220000300	Flap Carriage Track N°1	Airbus Industrie
D6490-1	Taxi Light	Grimes Aerospace
D6490-10	Taxi Light	Grimes Aerospace
D6490-11	Taxi Light	Grimes Aerospace
D6490-12	Taxi Light	Grimes Aerospace
D6490-13	Taxi Light	Grimes Aerospace
D6490-14	Taxi Light	Grimes Aerospace
D6490-15	Taxi Light	Grimes Aerospace
D6490-16	Taxi Light	Grimes Aerospace
D6490-17	Taxi Light	Grimes Aerospace
D6490-18	Taxi Light	Grimes Aerospace
D6490-2	Taxi Light	Grimes Aerospace
D6490-3	Taxi Light	Grimes Aerospace
D6490-4	Taxi Light	Grimes Aerospace
D6490-5	Taxi Light	Grimes Aerospace
D6490-6	Taxi Light	Grimes Aerospace
D6490-7	Taxi Light	Grimes Aerospace
D6490-8	Taxi Light	Grimes Aerospace
D6490-9	Taxi Light	Grimes Aerospace
D71120-401	By-Pass Valve	Fokker Aircraft
D71319-403	Hydraulic Priority Valve	Fokker Aircraft
D71320-401	Park Brake Valve assy	Fokker Aircraft
D71320-403	Park Brake Valve assy	Fokker Aircraft
D71322-401	Selector Valve	Fokker Aircraft
D71322-403	Selector Valve	Fokker Aircraft
D71421-401	Lift Dumper Manifold assy	Fokker Aircraft
D71421-403	Lift Dumper Manifold assy	Fokker Aircraft
D71422-401	Hydraulic Fuse assy	Fokker Aircraft
D71422-403	Hydraulic Fuse assy	Fokker Aircraft
D71423-401	Dual Skid Control Valve assy	Fokker Aircraft

Repair_Capability_List_Excel

D71423-403	Dual Skid Control Valve assy	Fokker Aircraft
D71423-407	Dual Skid Control Valve assy	Fokker Aircraft
D72181-401	Rudder Manifold assy	Fokker Aircraft
D72182-401	Rudder Manifold assy	Fokker Aircraft
D7235-1-20	Overload Sensor	Fokker Aircraft
D72548-401	Filter Manifold assy	Fokker Aircraft
D72549-401	Filter Manifold assy	Fokker Aircraft
D73203-401	Air Check Valve	Fokker Aircraft
D-7330-1	Motor & Mounting	Grimes Aerospace
D7611004000000	Unit Artificial Feel	Airbus Industrie
D7611012000000	Unit Artificial Feel	Airbus Industrie
D7611012000200	Unit Artificial Feel	Airbus Industrie
D76665-403	Aileron Tension Control assy	Fokker Aircraft
D76665-405	Aileron Tension Control assy	Fokker Aircraft
D76665-407	Aileron Tension Control assy	Fokker Aircraft
D78168-405	Sensor Housing assy	Fokker Aircraft
D78168-407	Sensor Housing assy	Fokker Aircraft
D78179-405	Cable Tension Regulator	Fokker Aircraft
D78179-407	Cable Tension Regulator	Fokker Aircraft
D78179-409	Cable Tension Regulator	Fokker Aircraft
D78179-411	Cable Tension Regulator	Fokker Aircraft
D78179-413	Cable Tension Regulator	Fokker Aircraft
D78179-703	Cable Tension Regulator	Fokker Aircraft
D78705-401	MLG Door Uplock	Fokker Aircraft
D78705-403	MLG Door Uplock	Fokker Aircraft
D78705-405	MLG Door Uplock	Fokker Aircraft
D78705-407	MLG Door Uplock	Fokker Aircraft
D78705-409	MLG Door Uplock	Fokker Aircraft
D78705-411	MLG Door Uplock	Fokker Aircraft
D78705-413	MLG Door Uplock	Fokker Aircraft
D78705-415	MLG Door Uplock	Fokker Aircraft
D78710-401	MLG Door Uplock	Fokker Aircraft
D78710-402	MLG Door Uplock	Fokker Aircraft
D78710-403	MLG Door Uplock	Fokker Aircraft
D78710-404	MLG Door Uplock	Fokker Aircraft
D78710-405	MLG Door Uplock	Fokker Aircraft
D78710-406	MLG Door Uplock	Fokker Aircraft
D78710-407	MLG Door Uplock	Fokker Aircraft
D78710-408	MLG Door Uplock	Fokker Aircraft
D826	Single Hand Faucet	Adams Rite
D82903-401	Windshield Wiper assy	Fokker Aircraft
D82903-403	Windshield Wiper assy	Fokker Aircraft
D82904-401	Windshield Wiper assy	Fokker Aircraft
D82904-403	Windshield Wiper assy	Fokker Aircraft
D83526-401	Nose Wheel Steering Mechanism Unit	Fokker Aircraft
D83526-403	Nose Wheel Steering Mechanism Unit	Fokker Aircraft
D83526-405	Nose Wheel Steering Mechanism Unit	Fokker Aircraft
D83526-407	Nose Wheel Steering Mechanism Unit	Fokker Aircraft
D83526-409	Nose Wheel Steering Mechanism Unit	Fokker Aircraft
D83526-411	Nose Wheel Steering Mechanism Unit	Fokker Aircraft
D83561-407	Nose Wheel Steering Mechanism	Fokker Aircraft
D83561-409	Nose Wheel Steering Mechanism	Fokker Aircraft
D83561-411	Nose Wheel Steering Mechanism	Fokker Aircraft
D83561-413	Nose Wheel Steering Mechanism	Fokker Aircraft
D83561-415	Nose Wheel Steering Mechanism	Fokker Aircraft
D83561-417	Nose Wheel Steering Mechanism	Fokker Aircraft
D83561-419	Nose Wheel Steering Mechanism	Fokker Aircraft
D83561-421	Nose Wheel Steering Mechanism	Fokker Aircraft

Repair_Capability_List_Excel

D83561-423	Nose Wheel Steering Mechanism	Fokker Aircraft
D836-4-20	Hydraulic Fuse assy	Allied Signal
D88557-403	Manifold assy	Fokker Aircraft
D88557-405	Manifold assy	Fokker Aircraft
D90ST2001-000	Gauge Transmitter	Goodrich Control Systems
D90ST2002-000	Gauge Transmitter	Goodrich Control Systems
D90ST2003-000	Low Level Switch	Goodrich Control Systems
D90ST2004-000	Low Level Switch	Goodrich Control Systems
D9550001800200	Side Stick Controller	Airbus Industrie
D9550001800300	Side Stick Controller	Airbus Industrie
D9550001800400	Side Stick Controller	Airbus Industrie
D9550001800500	Side Stick Controller	Airbus Industrie
D9550001800600	Side Stick Controller	Airbus Industrie
D95500018006AA	Side Stick Controller	Airbus Industrie
D95500018006AB	Side Stick Controller	Airbus Industrie
D95500018006AC	Side Stick Controller	Airbus Industrie
D95500018006AD	Side Stick Controller	Airbus Industrie
D95500018006AE	Side Stick Controller	Airbus Industrie
D95500018006AF	Side Stick Controller	Airbus Industrie
D95500018006AG	Side Stick Controller	Airbus Industrie
D9550001800700	Side Stick Controller	Airbus Industrie
D95500018007AA	Side Stick Controller	Airbus Industrie
D95500018007AB	Side Stick Controller	Airbus Industrie
D95500018007AC	Side Stick Controller	Airbus Industrie
D95500018007AD	Side Stick Controller	Airbus Industrie
D95500018007AE	Side Stick Controller	Airbus Industrie
D95500018007AF	Side Stick Controller	Airbus Industrie
D95500018007AG	Side Stick Controller	Airbus Industrie
D9550001800800	Side Stick Controller	Airbus Industrie
D95500018008AA	Side Stick Controller	Airbus Industrie
D95500018008AB	Side Stick Controller	Airbus Industrie
D95500018008AC	Side Stick Controller	Airbus Industrie
D95500018008AD	Side Stick Controller	Airbus Industrie
D95500018008AE	Side Stick Controller	Airbus Industrie
D95500018008AF	Side Stick Controller	Airbus Industrie
D95500018008AG	Side Stick Controller	Airbus Industrie
D9550001800900	Side Stick Controller	Airbus Industrie
D95500018009AA	Side Stick Controller	Airbus Industrie
D95500018009AB	Side Stick Controller	Airbus Industrie
D95500018009AC	Side Stick Controller	Airbus Industrie
D95500018009AD	Side Stick Controller	Airbus Industrie
D95500018009AE	Side Stick Controller	Airbus Industrie
D95500018009AF	Side Stick Controller	Airbus Industrie
D95500018009AG	Side Stick Controller	Airbus Industrie
D9550001801100	Side Stick Controller	Airbus Industrie
D95500018011AA	Side Stick Controller	Airbus Industrie
D95500018011AB	Side Stick Controller	Airbus Industrie
D95500018011AC	Side Stick Controller	Airbus Industrie
D95500018011AD	Side Stick Controller	Airbus Industrie
D95500018011AE	Side Stick Controller	Airbus Industrie
D95500018011AF	Side Stick Controller	Airbus Industrie
D95500018011AG	Side Stick Controller	Airbus Industrie
D9550001801300	Side Stick Controller	Airbus Industrie
D9550001801400	Side Stick Controller	Airbus Industrie
D9550001801700	Side Stick Controller	Airbus Industrie
D9550001801800	Side Stick Controller	Airbus Industrie
D9550001900200	Side Stick Controller	Airbus Industrie
D9550001900300	Side Stick Controller	Airbus Industrie

Repair_Capability_List_Excel

D9550001900400	Side Stick Controller	Airbus Industrie
D9550001900500	Side Stick Controller	Airbus Industrie
D9550001900600	Side Stick Controller	Airbus Industrie
D95500019006AA	Side Stick Controller	Airbus Industrie
D95500019006AB	Side Stick Controller	Airbus Industrie
D95500019006AC	Side Stick Controller	Airbus Industrie
D95500019006AD	Side Stick Controller	Airbus Industrie
D95500019006AE	Side Stick Controller	Airbus Industrie
D95500019006AF	Side Stick Controller	Airbus Industrie
D95500019006AG	Side Stick Controller	Airbus Industrie
D9550001900700	Side Stick Controller	Airbus Industrie
D95500019007AA	Side Stick Controller	Airbus Industrie
D95500019007AB	Side Stick Controller	Airbus Industrie
D95500019007AC	Side Stick Controller	Airbus Industrie
D95500019007AD	Side Stick Controller	Airbus Industrie
D95500019007AE	Side Stick Controller	Airbus Industrie
D95500019007AF	Side Stick Controller	Airbus Industrie
D95500019007AG	Side Stick Controller	Airbus Industrie
D9550001900800	Side Stick Controller	Airbus Industrie
D95500019008AA	Side Stick Controller	Airbus Industrie
D95500019008AB	Side Stick Controller	Airbus Industrie
D95500019008AC	Side Stick Controller	Airbus Industrie
D95500019008AD	Side Stick Controller	Airbus Industrie
D95500019008AE	Side Stick Controller	Airbus Industrie
D95500019008AF	Side Stick Controller	Airbus Industrie
D95500019008AG	Side Stick Controller	Airbus Industrie
D9550001900900	Side Stick Controller	Airbus Industrie
D95500019009AA	Side Stick Controller	Airbus Industrie
D95500019009AB	Side Stick Controller	Airbus Industrie
D95500019009AC	Side Stick Controller	Airbus Industrie
D95500019009AD	Side Stick Controller	Airbus Industrie
D95500019009AE	Side Stick Controller	Airbus Industrie
D95500019009AF	Side Stick Controller	Airbus Industrie
D95500019009AG	Side Stick Controller	Airbus Industrie
D9550001901100	Side Stick Controller	Airbus Industrie
D95500019011AA	Side Stick Controller	Airbus Industrie
D95500019011AB	Side Stick Controller	Airbus Industrie
D95500019011AC	Side Stick Controller	Airbus Industrie
D95500019011AD	Side Stick Controller	Airbus Industrie
D95500019011AE	Side Stick Controller	Airbus Industrie
D95500019011AF	Side Stick Controller	Airbus Industrie
D95500019011AG	Side Stick Controller	Airbus Industrie
D9550001901300	Side Stick Controller	Airbus Industrie
D9550001901400	Side Stick Controller	Airbus Industrie
D9550001901700	Side Stick Controller	Airbus Industrie
D9550001901800	Side Stick Controller	Airbus Industrie
D9550001906AA	SIDESTICK CONTROLER	AIRBUS INDUSTRIE
D9550001906AB	SIDESTICK CONTROLER	AIRBUS INDUSTRIE
D9550001906AC	SIDESTICK CONTROLER	AIRBUS INDUSTRIE
D9550001906AD	SIDESTICK CONTROLER	AIRBUS INDUSTRIE
D9550001906AE	SIDESTICK CONTROLER	AIRBUS INDUSTRIE
D9550001906AF	SIDESTICK CONTROLER	AIRBUS INDUSTRIE
D9550001906AG	SIDESTICK CONTROLER	AIRBUS INDUSTRIE
D9550011400300	Flap and Slat Control Unit	Airbus Industrie
D97B00-001	Actuator	Intertechnique
D97B00-502	Actuator	Intertechnique
D97B00-602	Actuator	Intertechnique
D97C00-501	Actuator	Intertechnique

Repair_Capability_List_Excel

D97C00-503	Actuator	Intertechnique
D97C00-603	Actuator	Intertechnique
D97C00-604	Electrical Actuator	Intertechnique
D97C00-605	Electrical Actuator	Intertechnique
D97C00-609	Actuator	Intertechnique
D97C00-610	Electrical Actuator	Intertechnique
D97C00-612	Electrical Actuator	Intertechnique
D97C00-613	Electrical Actuator	Intertechnique
D97C00-614	Electrical Actuator	Intertechnique
D97C00-615	Electrical Actuator	Intertechnique
D97D00-501	Actuator	Intertechnique
D97D00-502	Actuator	Intertechnique
D97D00-601	Actuator	Intertechnique
D97D00-602	Actuator	Intertechnique
D97D00-604	Actuator	Intertechnique
D97F00-601	Gearbox	Intertechnique
D97G00-202	Hand Pump	Intertechnique
D98A07-601	Pressure Sensor	Intertechnique
D98C07-605	Pressure Sensor	Intertechnique
D98C07-606	Pressure Sensor	Intertechnique
D98C07-607	Pressure Sensor	Intertechnique
D98C07-608	Pressure Sensor	Intertechnique
D98C08-606	Pressure Sensor	Intertechnique
D98C08-607	Pressure Sensor	Intertechnique
D98C09-602	Pressure Sensor	Intertechnique
D98C09-603	Pressure Sensor	Intertechnique
DHE1148	Proximity Switch	Eldec Corp.
DIP120	Pressure Transmitter	SAMM
DK033	Transmitter	VDO
DK033-3	Transmitter	VDO
DK063	Pressure Transmitter	VDO
DK100	Underwater Locating Device	Dukane
DK118-2	Pressure Switch	VDO
DK120	Underwater Locating Device	Dukane
DK453	Air Pressure Indicator	VDO
DK481	Pressure Indicator	VDO
DKR141	Oxygen System Fill Port	Intertechnique
DL1326M119	Lockout Actuator	Simmonds Precision
DL1326M119-2	Lockout Actuator	Simmonds Precision
DL2033M2	Actuator	Simmonds Precision
DL2033M2-2	Actuator	Simmonds Precision
DL2033M4	Linear Actuator	Simmonds Precision
DL2033M4-1	Linear Actuator	Simmonds Precision
DL2033M4-2	Linear Actuator	Simmonds Precision
DL2033M4-3	Linear Actuator	Simmonds Precision
DN21SYB31S10006	Cabin Attendant Seat	Sicma Aero Seat
DN26SYB3YS00006	Cabin Attendant Seat	Sicma Aero Seat
DR1374	Attitude Monitor	Avimo
DR13740000GA	Attitude Monitor	Avimo
DR1402C00	Brake Fan assy	Technofan
DR1502C00	Brake Fan assy	Technofan
DR3174	Attitude Monitor	Avimo
DR4	Water Heater	Inventum
DR80CS1056	Headset	TEAM
DSB1102	Sensor	Crane-Eldec
DSF00201	Sensor	Crane-Eldec
DSF00201-1	Proximity Sensor	Crane-Eldec
DSI421-106	Pneumatic Pressure Indicator	KDG

Repair_Capability_List_Excel

DTF555-220	Hose	Intertechnique
DTF55A0395	Hose	Intertechnique
DTF55A290	Hose	Intertechnique
DTF55AV505	Hose	Intertechnique
DV3454A00	Speed Control	Technofan
DV8456701-3	Travel Limitation Unit	Artus
DV8456701-4	Travel Limitation Unit	Artus
DV8456701-5	Travel Limitation Unit	Artus
DV8902AA1	Cooling Effect Detector	Technofan
DVE90-05	Solenoid Valve	Intertechnique
DVE90-06	Solenoid Valve	Intertechnique
DVS100A	Control Box	Technofan
E01000	Fire Shut-off Valve	Westland-Sitec
E01A00	Fire Shut-off Valve	Westland-Sitec
E03000	Fire Shut-off Valve	Westland-Sitec
E03A00	Fire Shut-off Valve	Westland-Sitec
E07391-04-056	Sensitive Airspeed Indicator	Kollsman
E07391-10-057	Sensitive Airspeed Indicator	Kollsman
E10-02-2	SOLENOID	SAMM
E12A10A294	Airspeed Switch	Munro
E12A10A332	Airspeed Switch	Munro
E1AM0	Rod Pitch	Thales Avionics
E21350000	Drive Shaft Tachometer	Technofan
E31BAM	Dynamic Rod	Thales
E31BAM1	Dynamometric Rod	Thales Avionics
E42452-10-009	Altimeter Encoder	Kollsman
E438-6A	Relay Box	Leach International
E6020M32-1	Motor	Plessey
E69001	Pressure Reducer	Draegerwerk
E69002	Electrical Shut-off Valve	Draegerwerk
E69005	Temperature Transducer	Draegerwerk
E69007	Indicator	Draegerwerk
E69012	Low Pressure Switch	Draegerwerk
E69025	Pressure Reducer	Draegerwerk
E72021	Cable Tension Regulator	Teleflex
E72022	Cable Tension Regulator	Teleflex
E72023	Cable Tension Regulator	Teleflex
EA100434C	Anti-Ice Air Valve	Dunlop Aerospace
EA100435C	Anti-Ice Air Valve	Dunlop Aerospace
EA1066A-2183	Transmitter	Liquidometer Corp
EA148ANH	Water Methanol Indicator	Simmonds Precision
EA148ANHD111H	Water Methanol Indicator	Simmonds Precision
EA148ANHD119H	Water Methanol Indicator	Simmonds Precision
EA148ANHD120H	Water Methanol Indicator	Simmonds Precision
EA148ANHD126H	Water Methanol Indicator	Simmonds Precision
EA148ANHD129H	Water Methanol Indicator	Simmonds Precision
EA321-1	Horizontal Stab. Indicator	Liquidometer Corp
EA326-15A	Position Indicator	Liquidometer Corp
ED724419-2	Temperature Sensor	Hamilton Standard
ED741776-1	Valve Position Indicator	Hamilton Sundstrand
ED741776-2	Valve Position Indicator	Hamilton Sundstrand
ED747201	EPR Transmitter	Hamilton Sundstrand
ED747202	EPR Transmitter	Hamilton Sundstrand
EIA1533A	Junction & Amplifier	TEAM
EIA1533B	Junction & Amplifier	TEAM
EIA1533C	Junction & Amplifier	TEAM
EIA1533E	Junction Amplifier	TEAM
EJP100	Pump assy	Goodrich Control Systems

Repair_Capability_List_Excel

EJP101	Pump assy	Goodrich Control Systems
EM56-20-1	Shut-Off Valve	Circle Seal Controls
EM56-20-3	Shut-Off Valve	Circle Seal Controls
EM56-20-4	Shut-Off Valve	Circle Seal Controls
EM56-20-5	Shut-Off Valve	Circle Seal Controls
EM91-79	Shut-Off Valve	Circle Seal Controls
EM91-79-1	Shut-Off Valve	Circle Seal Controls
EM91-79-3	Shut-Off Valve	Circle Seal Controls
EM91-79-4	Shut-Off Valve	Circle Seal Controls
EM91-79-5	Shut-Off Valve	Circle Seal Controls
EM91-80	Shut-Off Valve	Circle Seal Controls
EM91-80-1	Shut-Off Valve	Circle Seal Controls
EM91-80-3	Shut-Off Valve	Circle Seal Controls
EM91-80-4	Shut-Off Valve	Circle Seal Controls
EM91-80-5	Shut-Off Valve	Circle Seal Controls
EV5193-2-00	Solenoid Valve	Industria
EV5193-2-01	Solenoid Valve	Industria
EV6016-0-00	Solenoid	Industria
EVAC2423EC	Ground Cooling Fan	Technofan
EVAC2423FC	Ground Cooling Fan	Technofan
EVAC2423FD	Ground Cooling Fan	Technofan
EVAC2423H	Ground Cooling Fan	Technofan
EVAC523C2	Fan	Technofan
EVAC523DXA	Fan	Technofan
EVAC523EXA	Fan	Technofan
EVAC523G2	Recirculation Fan	Technofan
EVCT1525	Fan	Technofan
EVCT1525A	Fan assy	Technofan
EVP504	Selector Valve	SAMM
EVS630B	Electric Motor Fan	Technofan
EVT174-02M1	Fan	Technofan
EVT174-04-01	Impeller	Technofan
EVT174-2B	Cooling Fan	Technofan
EVT174-2D	Cooling Fan	Technofan
EVT174-2D1	Cooling Fan	Technofan
EVT174-2E1	Cooling Fan	Technofan
EVT174-2E2	Cooling Fan	Technofan
EVT174-2E3	Cooling Fan	Technofan
EVT174-2E4	Cooling Fan	Technofan
EVT174-2E5	Fan	Technofan
EVT174-2E8	Fan	Technofan
EVT174-4	Cooling Fan	Technofan
EVT174-4A	Cooling Fan	Technofan
EVT174-4B	Cooling Fan	Technofan
EVT174-4C	Cooling Fan	Technofan
EVT174-4D	Cooling Fan	Technofan
EVT174-4E	Cooling Fan	Technofan
EVT174-4F	Cooling Fan	Technofan
EVT174-4G	Cooling Fan	Technofan
EVT174-500C	Fan Motor	Technofan
EVT174-500E	Fan Motor	Technofan
EVT174-6D	Fan	Technofan
EVT1925B	Air Extraction Fan	Technofan
EVT3454	Fan assy	Technofan
EVT3454A	Fan assy	Technofan
EVT3454B	Fan assy	Technofan
EVT3454G	Fan assy	Technofan
EVT3454H	Fan assy	Technofan

Repair_Capability_List_Excel

EVT3454J	Fan assy	Technofan
EVT3640A	Fan assy	Technofan
EVT3640A1	Fan assy	Technofan
EVT3640A3	Fan assy	Technofan
EVT3745A	Electro Fan	Technofan
EVT3745A1	Electro Fan	Technofan
EVT4160	Electric Fan	Technofan
EVT4160A	Electric Fan	Technofan
EVTA103B	Fan	Technofan
EVTA1826DC	Fan Air Extraction	Technofan
EVTA1925B	Fan Air Extraction	Technofan
EVTA1926	Fan Air Extraction	Technofan
EVTA1926BA	FAN ASSY	TECHNOFAN
EVTA1926CA	FAN ASSY	TECHNOFAN
EVTA1926DA	Fan Air Extraction	Technofan
EVTA1926DC	Fan Air Extraction	Technofan
F05000	Differential Pressure Switch	Westland-Sitec
F05-560-08	Pilot Seat Track	Sogerma
F05-560-09	Pilot Seat Track	Sogerma
F05-560-100	SEAT TRACK	.
F-10	Thermometer	Edison
F-11	Thermometer	Edison
F11QB3121	Transformer Rectifier	Auxilec
F11QH3121X1	Transformer Rectifier	Auxilec
F11QY3121	Transformer Rectifier	Auxilec
F-12	Thermometer	Edison
F1714-1	Overspeed Relay	Goodrich
F1714-1A	Overspeed Relay	Goodrich
F1727	Overspeed Relay	Goodrich
F1731	Overspeed Relay	Goodrich
F2557170000400	Entrance Guide	Airbus Industrie
F2557170000600	Entrance Guide	Airbus Industrie
F2557170100400	Entrance Guide	Airbus Industrie
F2557170100600	Entrance Guide	Airbus Industrie
F2727004900051	Rudder Control Centering Mechanism	Airbus Industrie
F2727004900251	Rudder Control Centering Mechanism	Airbus Industrie
F2727004900451	Rudder Control Centering Mechanism	Airbus Industrie
F2727004900651	Rudder Control Centering Mechanism	Airbus Industrie
F2727006500051	Rudder Control Centering Mechanism	Airbus Industrie
F2727100000251	Rudder Control Frame	Airbus Industrie
F2727100100051	Rudder Control Frame	Airbus Industrie
F2727100100251	Rudder Control Frame	Airbus Industrie
F2727100100451	Rudder Control Frame	Airbus Industrie
F2727100300051	Rudder Control Frame	Airbus Industrie
F2727100300251	Rudder Control Frame	Airbus Industrie
F2727104900000	Spring Rod	Airbus Industrie
F2727123000000	Artificial Feel Spring Rod	Airbus Industrie
F2727156000000	Spring Rod	Airbus Industrie
F2727161100051	Rudder Control Centering Mechanism	Airbus Industrie
F2727170000051	Rudder Control Frame	Airbus Industrie
F2727170000251	Rudder Control Frame	Airbus Industrie
F27310011000AE	Side Stick Controller	Airbus Industrie
F27310011000AF	Side Stick Controller	Airbus Industrie
F27310011000AG	Side Stick Controller	Airbus Industrie
F27310011000AJ	Side Stick Controller	Airbus Industrie
F27310011000AL	Side Stick Controller	Airbus Industrie
F27310011000AM	Side Stick Controller	Airbus Industrie
F27310012000AE	Side Stick Controller	Airbus Industrie

Repair_Capability_List_Excel

F27310012000AF	Side Stick Controller	Airbus Industrie
F27310012000AG	Side Stick Controller	Airbus Industrie
F27310012000AJ	Side Stick Controller	Airbus Industrie
F27310012000AL	Side Stick Controller	Airbus Industrie
F27310012000AM	Side Stick Controller	Airbus Industrie
F2747035000200	Cable Tension Regulator	Airbus Industrie
F2747035000400	Cable Tension Regulator	Airbus Industrie
F27510126000AA	Flap and Slat Control Unit	Airbus Industrie
F27510126000AB	Flap and Slat Control Unit	Airbus Industrie
F27510126000AC	Flap and Slat Control Unit	Airbus Industrie
F-3	Pressure Transmitter	Ametek
F34PB6224	Fan assy	Goodrich Control Systems
F-3A	Pressure Transmitter	Ametek
F6103	Temperature Sensor	Goodrich Control Systems
F6184	Temperature Sensor	Goodrich Control Systems
F61B0132	Valve assy	Parker Hannifin
F61B0132M1	Valve assy	Parker Hannifin
F61B0138M2	Valve assy	Parker Hannifin
F61B0139	Sensor	Parker Aerospace
F61B0139M1	Sensor	Parker Aerospace
F61C0058	Valve	Parker-Hannifin
F61C0058M1	Valve	Parker-Hannifin
F61D0236M4	Valve	Parker Aerospace
F61D0236M4-11	Valve	Parker Aerospace
F61D0236M6	Valve	Parker Aerospace
F-8	Thermometer	Edison
F9550001800100	Side Stick Controller	Airbus Industrie
F95500018001AA	Side Stick Controller	Airbus Industrie
F95500018001AB	Side Stick Controller	Airbus Industrie
F95500018001AC	Side Stick Controller	Airbus Industrie
F95500018001AD	Side Stick Controller	Airbus Industrie
F95500018001AE	Side Stick Controller	Airbus Industrie
F95500018001AF	Side Stick Controller	Airbus Industrie
F95500018001AG	Side Stick Controller	Airbus Industrie
F9550001800200	Side Stick Controller	Airbus Industrie
F95500018002AA	Side Stick Controller	Airbus Industrie
F95500018002AB	Side Stick Controller	Airbus Industrie
F95500018002AC	Side Stick Controller	Airbus Industrie
F95500018002AD	Side Stick Controller	Airbus Industrie
F95500018002AE	Side Stick Controller	Airbus Industrie
F95500018002AF	Side Stick Controller	Airbus Industrie
F9550001800300	Side Stick Controller	Airbus Industrie
F9550001800400	Side Stick Controller	Airbus Industrie
F9550001900100	Side Stick Controller	Airbus Industrie
F95500019001AA	Side Stick Controller	Airbus Industrie
F95500019001AB	Side Stick Controller	Airbus Industrie
F95500019001AC	Side Stick Controller	Airbus Industrie
F95500019001AD	Side Stick Controller	Airbus Industrie
F95500019001AE	Side Stick Controller	Airbus Industrie
F95500019001AF	Side Stick Controller	Airbus Industrie
F95500019001AG	Side Stick Controller	Airbus Industrie
F9550001900200	Side Stick Controller	Airbus Industrie
F95500019002AA	Side Stick Controller	Airbus Industrie
F95500019002AB	Side Stick Controller	Airbus Industrie
F95500019002AC	Side Stick Controller	Airbus Industrie
F95500019002AD	Side Stick Controller	Airbus Industrie
F95500019002AE	Side Stick Controller	Airbus Industrie
F95500019002AF	Side Stick Controller	Airbus Industrie

Repair_Capability_List_Excel

F9550001900300	Side Stick Controller	Airbus Industrie
F9550001900400	Side Stick Controller	Airbus Industrie
F97-13-602	Self-Clean Filter	Intertechnique
FA00512A	Filter	Sofrance
FCU9811	Flush Control Unit	LGG
FCU9811-01	Flush Control Unit	LGG
FDT1403	Rod-assy	Sarma
FDT16321	Rod-connecting	Sarma
FDT16421	Rod-connecting	Sarma
FE101-000	Elevator Control Cable Tension Regulator	Ratier-Figeac
FE101-001	Elevator Control Cable Tension Regulator	Ratier-Figeac
FE101-002	Elevator Control Cable Tension Regulator	Ratier-Figeac
FE101-003	Elevator Control Cable Tension Regulator	Ratier-Figeac
FE102-000	Aileron Control Cable Tension Regulator	Ratier-Figeac
FE102-001	Aileron Control Cable Tension Regulator	Ratier-Figeac
FE102-002	Aileron Control Cable Tension Regulator	Ratier-Figeac
FE102-003	Aileron Control Cable Tension Regulator	Ratier-Figeac
FE103	Rudder Control Cable Tension Regulator	Ratier-Figeac
FE103-001	Rudder Control Cable Tension Regulator	Ratier-Figeac
FE104-002	Low Speed Ail. Ctrl Cable Tension Regul.	Ratier-Figeac
FE127-02-000	Passenger Door Damper	Ratier-Figeac
FE127-02-000 Amdt A	Passenger Door Damper	Ratier-Figeac
FE127-02-000 Amdt B	Passenger Door Damper	Ratier-Figeac
FE127-02-000 Amdt C	Passenger Door Damper	Ratier-Figeac
FE127-02-0001	Passenger Door Damper	Ratier-Figeac
FE127-02-0001 Amdt A	Passenger Door Damper	Ratier-Figeac
FE127-02-0001 Amdt B	Passenger Door Damper	Ratier-Figeac
FE127-02-0002	Passenger Door Damper	Ratier-Figeac
FE127-02-0002 Amdt A	Passenger Door Damper	Ratier-Figeac
FE127-02-0003	Passenger Door Damper	Ratier-Figeac
FE127-02-0003 Amdt A	Passenger Door Damper	Ratier-Figeac
FE127-02-001	Passenger Door Damper	Ratier-Figeac
FE136-000	Aileron Control Cable Tension Regulator	Ratier-Figeac
FE136-001	Aileron Control Cable Tension Regulator	Ratier-Figeac
FE136-002	Aileron Control Cable Tension Regulator	Ratier-Figeac
FE136-003	Aileron Control Cable Tension Regulator	Ratier-Figeac
FE162-000	Emergency Door Damper	Ratier-Figeac
FE162-001	Emergency Door Damper	Ratier-Figeac
FE162-002	Emergency Door Damper	Ratier-Figeac
FE162-003	Emergency Door Damper	Ratier-Figeac
FE171-000	Cable Tension Regulator	Ratier-Figeac
FE174-001	Door Damper Cylinder	Ratier-Figeac
FE174-003	Door Damper Cylinder	Ratier-Figeac
FE188-003	Rudder Damper	.
FE188-004	Rudder Damper	.
FE188-005	Rudder Damper	.
FE192-000	Flap Block Valve Restrictor	Ratier-Figeac
FE197-000	Cable Tension Regulator	Ratier-Figeac
FE209-000	Emergency Door Damper Actuator Unit	Ratier-Figeac
FE209-000 Amdt A	Emergency Door Damper Actuator Unit	Ratier-Figeac
FE209-000 Amdt B	Emergency Door Damper Actuator Unit	Ratier-Figeac
FE209-0001	Emergency Door Damper Actuator Unit	Ratier-Figeac
FE209-0001 Amdt A	Emergency Door Damper Actuator Unit	Ratier-Figeac
FE209-001	Emergency Door Damper Actuator Unit	Ratier-Figeac
FE209-002	Emergency Door Damper Actuator Unit	Ratier-Figeac
FE209-002 Amdt A	Emergency Door Damper Actuator Unit	Ratier-Figeac
FE209-003	Emergency Door Damper Actuator Unit	Ratier-Figeac
FE209-003 Amdt A	Emergency Door Damper Actuator Unit	Ratier-Figeac

Repair_Capability_List_Excel

FE237-001	Flap Actuator	Ratier-Figeac
FE237-002	Flap Actuator	Ratier-Figeac
FE240-002	Door Damper Cylinder	Ratier-Figeac
FE240-002-1	Door Damper Cylinder	Ratier-Figeac
FE240-003	Door Damper Cylinder	Ratier-Figeac
FE240-003-1	Door Damper Cylinder	Ratier-Figeac
FE240-004	Door Damper Cylinder	Ratier-Figeac
FE240-005	Door Damper Cylinder	Ratier-Figeac
FE256	Passenger Door Damper	Ratier-Figeac
FE256-000	Passenger Door Damper	Ratier-Figeac
FE256-000 Amdt A	Passenger Door Damper	Ratier-Figeac
FE276-000	Emergency Door Damper Actuator Unit	Ratier-Figeac
FF0707	Selector Valve	Messier-Bugatti
FG1006AA01	Fuel Quantity Tank Unit ay	Honeywell
FG1006AA02	Fuel Quantity Tank Unit ay	Honeywell
FG1006AA03	Fuel Quantity Tank Unit ay	Honeywell
FG1006AA04	Fuel Quantity Tank Unit ay	Honeywell
FG1006AA05	Fuel Quantity Tank Unit ay	Honeywell
FG1006AA06	Fuel Quantity Tank Unit ay	Honeywell
FG1006AA07	Fuel Quantity Tank Unit ay	Honeywell
FG1006AA08	Fuel Quantity Tank Unit ay	Honeywell
FG1006AA09	Fuel Quantity Tank Unit ay	Honeywell
FG1006AA10	Fuel Quantity Tank Unit ay	Honeywell
FG1006AA11	Fuel Quantity Tank Unit ay	Honeywell
FG1006AA12	Fuel Quantity Tank Unit ay	Honeywell
FG1006AA13	Fuel Quantity Tank Unit ay	Honeywell
FG1006AA14	Fuel Quantity Tank Unit ay	Honeywell
FG1006AA15	Fuel Quantity Tank Unit ay	Honeywell
FG1006AA16	Fuel Quantity Tank Unit ay	Honeywell
FG1006AA17	Fuel Quantity Tank Unit ay	Honeywell
FG1007AA01	Fuel Quantity Compensator ay	Honeywell
FG1007AA02	Fuel Quantity Compensator ay	Honeywell
FG1007AA03	Fuel Quantity Compensator ay	Honeywell
FG1007AA04	Fuel Quantity Compensator ay	Honeywell
FG220A127	Fuel Quantity Tank Unit	Honeywell
FG220A157	Fuel Quantity Tank Unit	Honeywell
FG220A77	Fuel Quantity Tank Unit	Honeywell
FG220A88	Fuel Quantity Tank Unit	Honeywell
FLYB52230-1	Anti-Ice Pneumatic Shut-Off Valve	Rohr
FLYB52230-2	Anti-Ice Pneumatic Shut-Off Valve	Rohr
FN00B3B3YS00014	Cabin Attendant Seat	Sicma Aero Seat
FN00B3B3YS00041	Cabin Attendant Seat	Sicma Aero Seat
FN00B3F4YS00008	Cabin Attendant Seat	Sicma Aero Seat
FP-O410A	Water Quantity Transmitter	Ametek
FPTN304758R3	Sensor assy	Superflexit
FPTN404466R5	Proximity Sensor assy	Crane-Eldec
FPTN404466R7	Proximity Sensor assy	Crane-Eldec
FR3123	Smoke Detector	L'Hotellier
FR3212	Smoke Detector	L'Hotellier
FR3222	Smoke Detector	L'Hotellier
FRH010041	Twin Motor Actuator	FR Hitemp
FRH100002A	Pressure Switch	FR Hitemp
FRH100004A	Pressure Switch	FR Hitemp
FRH100013A	Pressure Switch	FR Hitemp
FRH100014A	Pressure Switch	FR Hitemp
FRH100021A	Pressure Switch	FR Hitemp
FRH100028A	Pressure Switch	FR Hitemp
FRH120106M	Crossfeed Fuel Valve	FR Hitemp

Repair_Capability_List_Excel

FRH210008M	Restrictor Valve	FR Hitemp
FRH230003C	Reducer Pressure Valve	FR Hitemp
FRH280002	Air Release Valve	FR Hitemp
FRH340004	Drain Water Valve	FR Hitemp
FRH340005	Drain Water Valve	FR Hitemp
FRH530004H	Non-Return Valve	FR Hitemp
FRH530014D	Landing Gear By-Pass Valve	FR Hitemp
FRH530017C	Gas-Charging Valve	FR Hitemp
FTC16063-1	Non-Return Valve	FPT Industries
FV295	Flap Actuator Ballscrew	Hamilton Sundstrand
G033CN469	AC Motor	Parker Hannifin
G09000	Fire Shut-Off Valve	Westland-Sitec
G1014A	DME Control Panel	Gables
G-1168	TXP Control Head	Gables Engineering
G1431	Controller	Gables
G1976	Audio Panel	Gables Engineering
G1977	Audio Panel	Gables Engineering
G1980	Audio Panel	Gables Engineering
G2048A	Audio Control Panel	Gables
G-2510	Radar Control	Gables Engineering
G2581-04	Selcal Control Panel	Gables
G2584	Audio Control Panel	Gables
G-2584	Control Box Com	Gables Engineering
G2745	Controller	Gables
G2747010000000	Cable Tension Regulator	Airbus Industrie
G3223A	Controller	Gables
G3359	Audio Control Panel	Gables
G3416	ATC Control Panel	Gables
G3426	Microphone Preamplifier	Gables
G3426A	Microphone Preamplifier	Gables
G-3752TN2	ATC Control	Gables Engineering
G3800A1	Landing Light	Grimes Aerospace
G3800A2	Landing Light	Grimes Aerospace
G3800A3	Landing Light	Grimes Aerospace
G3800A5	Landing Light	Grimes Aerospace
G3800A6	Landing Light	Grimes Aerospace
G3801A1A	Landing Light	Grimes Aerospace
G3801A2A	Landing Light	Grimes Aerospace
G3801A3A	Landing Light	Grimes Aerospace
G3801A5A	Landing Light	Grimes Aerospace
G3801A6A	Landing Light	Grimes Aerospace
G3803	Isolation Amplifier	Gables
G3805	Interphone Amplifier	Gables
G3951	VHF Comm Control Panel	Gables
G3952	Selcal/PA Level Control Panel	Gables
G3953	VHF Navigation Control Panel	Gables
G3953B	Dual NAV/DME Control Panel	Gables
G3954	ADF Control Panel	Gables
G3955	ATC Control Panel	Gables
G3956	Radar Control Panel	Gables
G3958	Jack Box Control Panel	Gables
G-4282	Warning Unit	Gables Engineering
G4407-1	Lube & Scavenge Pump	Parker Hannifin
G4407-2X	Lube & Scavenge Pump	Parker Hannifin
G4407-5	Lube & Scavenge Pump	Parker Hannifin
G4413-3	Lube & Scavenge Pump	Parker Hannifin
G4413-4	Lube & Scavenge Pump	Parker Hannifin
G4413-5	Lube & Scavenge Pump	Parker Hannifin

Repair_Capability_List_Excel

G4413-6	Lube & Scavenge Pump	Parker Hannifin
G4480	ATC Control Panel	Gables
G4562	Audio Control Panel	Gables
G-4562	Audio Panel	Gables Engineering
G-4959	Audio Controller	Gables Engineering
G-5	Thermometer	Weston Aerospace
G-515BA-2	Speaker	Gables Engineering
G540DA5	Waste Balancing Valve	LGG
G540DA51	Waste Drain Valve	LGG
G540DA72	Waste Separator	LGG
G540DA74	Liquid Level Transmitter	LGG
G540DA9	Air Shut-off Valve	LGG
G5515	Cockpit Speaker	Gables
G-5543-02	Radio Control	Gables Engineering
G-5586	Headset Microphone	Gables Engineering
G5790	Audio Control Panel	Gables
G5790B	Rotating Warning Light	Grimes Aerospace
G5790B1	Rotating Warning Light	Grimes Aerospace
G5790B10	Rotating Warning Light	Grimes Aerospace
G5790B1-12	Rotating Warning Light	Grimes Aerospace
G5790B12	Rotating Warning Light	Grimes Aerospace
G5790B2	Rotating Warning Light	Grimes Aerospace
G5790B3	Rotating Warning Light	Grimes Aerospace
G5790B4	Rotating Warning Light	Grimes Aerospace
G5790B8	Rotating Warning Light	Grimes Aerospace
G5790B9	Rotating Warning Light	Grimes Aerospace
G5790BA	Rotating Warning Light	Grimes Aerospace
G5790BA1	Rotating Warning Light	Grimes Aerospace
G5935	Cockpit Speaker	Gables
G5935-02	Cockpit Speaker	Gables
G5936	Interphone Amplifier	Gables
G5937	Audio Control Panel	Gables
G5937-03	Audio Control Panel	Gables
G5937-05	Audio Controller	Gables
G5937-06	Audio Control Panel	Gables
G5937-08	Audio Control Panel	Gables
G5937A	Audio Control Panel	Gables
G5938	ATC Control Panel	Gables
G5938-04	ATC Control Panel	Gables
G5939	NAV/DME Control Panel	Gables
G5939-02	NAV/DME Control Panel	Gables
G5941	VHF Comm Control Panel	Gables
G5941-03	Communication Control Panel	Gables
G5941-04	VHF Comm Control Panel	Gables
G5941-05	VHF Comm Control Panel	Gables
G5942	VHF Comm Control Panel	Gables
G5942A	VHF Comm Control Panel	Gables
G5942D	VHF Comm Control Panel	Gables
G5943	Intercom Selector Panel	Gables
G5944	Intercom Control Panel	Gables
G5944A	Intercom Control Panel	Gables
G5945	Intercom Control Panel	Gables
G5946-03	Audio Control Panel	Gables
G5946A	Audio Control Panel	Gables
G5947	Audio Control Panel	Gables
G5951	Audio Control Panel	Gables
G-5951	Control Panel	Gables Engineering
G5951-04	Audio Control Panel	Gables

Repair_Capability_List_Excel

G5951B	Audio Control Panel	Gables
G5974	Dual NAV/DME Control Panel	Gables
G5975	ATC Control Panel	Gables
G5976	Audio Control Panel	Gables
G5977	Jack Box Control Panel	Gables
G6018	Remote Datum Selector Panel	Gables
G6018A	Remote Datum Selector Panel	Gables
G6018B	Remote Datum Selector Panel	Gables
G6018C	Remote Datum Selector Panel	Gables
G6018F	Remote Datum Selector Panel	Gables
G6018H	Remote Datum Controller	Gables
G6018J	Remote Datum Selector Panel	Gables
G6074	VHF COMM Control Panel	Gables
G6074-02	VHF COMM Control Panel	Gables
G6074-03	VHF COMM Control Panel	Gables
G6074-04	VHF COMM Control Panel	Gables
G6074-05	VHF COMM Control Panel	Gables
G6074-06	VHF COMM Control Panel	Gables
G-610-11	Intercom Amplifier	Gables Engineering
G6137	Audio Control Panel	Gables
G6137-03	Audio Control Panel	Gables
G6137A	Audio Selector Panel	Gables
G6200-02	VHF Comm Control Panel	Gables
G6200-12	VHF Comm Control Panel	Gables
G6200-13	VHF Comm Control Panel	Gables
G6201-03	HF Communication Control Panel	Gables
G6204-02	ADF Control Panel	Gables
G6204-04	ADF Control Panel	Gables
G6204-12	ADF Control Panel	Gables
G6205	Audio Control	Gables Engineering
G6206-02	ATC Control Panel	Gables
G6206-03	ATC Control Panel	Gables
G6206-04	ATC Control Panel	Gables
G6206-05	ATC Control Panel	Gables
G6206-06	ATC Control Panel	Gables
G6206-07	ATC Control Panel	Gables
G6206-10	ATC Control Panel	Gables
G6206-13	ATC Control Panel	Gables
G6206-14	ATC Control Panel	Gables
G6207	Radar Control Panel	Gables
G6207-03	Radar Control Panel	Gables
G6207-04	Radar Control Panel	Gables
G6207-05	Radar Control Panel	Gables
G6227-02	ILS Control Panel	Gables
G6227-12	ILS Control Panel	Gables
G6227-14	ILS Control Panel	Gables
G6229-02	VOR/DME Control Panel	Gables
G6229-12	VOR/DME Control Panel	Gables
G6481-01	VHF NAV/DME Control Panel	Gables
G6762-02	Dual ADF Control Panel	Gables
G6931-01	Audio Control Panel	Gables
G6931-02	Audio Control Panel	Gables
G6931-04	Audio Control Panel	Gables
G6931-05	Audio Control Panel	Gables
G6931-06	Audio Control Panel	Gables
G6931-07	Audio Control Panel	Gables
G6931-08	Audio Control Panel	Gables
G6931-09	Audio Control Panel	Gables

Repair_Capability_List_Excel

G6935-01	Speaker	Gables
G6935-02	Speaker	Gables
G6935-03	Speaker	Gables
G6937-02	Audio Control Panel	Gables
G6937-03	Audio Control Panel	Gables
G6937-04	Audio Control Panel	Gables
G6937-05	Audio Control Panel	Gables
G6937-12	Audio Control Panel	Gables
G6937-13	Audio Control Panel	Gables
G6937-14	Audio Control Panel	Gables
G6937-18	Audio Control Panel	Gables
G6937-19	Audio Control Panel	Gables
G6937-20	Audio Control Panel	Gables
G6937-21	Audio Control Panel	Gables
G6937-22	Radio Control Panel	Gables
G6937-23	Audio Control Panel	Gables
G6937-25	Audio Control Panel	Gables
G6937-26	Audio Control Panel	Gables
G6937-27	Audio Control Panel	Gables
G6937-28	Audio Control Panel	Gables
G6939-02	Audio Control Panel	Gables
G6939-12	Audio Control Panel	Gables
G6940-02	Audio Jack Panel	Gables
G6940-03	Audio Jack Panel	Gables
G6940-04	Audio Jack Panel	Gables
G6940-05	Audio Jack Panel	Gables
G6940-12	Audio Jack Panel	Gables
G6940-13	Audio Jack Panel	Gables
G6940-18	Audio Jack Panel	Gables
G6940-19	Audio Jack Panel	Gables
G6940-20	Audio Jack Panel	Gables
G6940-21	Audio Jack Panel	Gables
G6946-01	Cockpit Speaker	Gables
G6946-11	Cockpit Speaker	Gables
G6968	Audio Control Panel	Gables
G6968-02	Audio Control Panel	Gables
G6968-04	Audio Control Panel	Gables
G6992-12	Dual ATC Control Panel	Gables
G7104-01	Radio Management Panel	Gables
G7104-04	Radio Management Panel	Gables
G7112-02	ATC Control Panel	Gables
G7112-03	ATC Control Panel	Gables
G7112-05	ATC Control Panel	Gables
G7112-06	ATC Control Panel	Gables
G7112-07	ATC Control Panel	Gables
G7400-13	VHF Comm Control Panel	Gables
G7400-27	VHF COMM Control Panel	Gables
G7400-34	VHF Comm Control Panel	Gables
G7400-35	VHF Comm Control Panel	Gables
G7406-10	VHF Comm Control Panel	Gables
G7406-12	VHF Comm Control Panel	Gables
G7406-210	VHF Comm Control Panel	Gables
G7406-22	VHF Comm Control Panel	Gables
G7490-04	Flight ID/ATC/TCAS Control Panel	Gables
G7490-14	Flight ID/ATC/TCAS Control Panel	Gables
G7490-30	Flight ID/ATC/TCAS Control Panel	Gables
G8400A10-24	Rotating Warning Light	Grimes Aerospace
G8400A11-24	Rotating Warning Light	Grimes Aerospace

Repair_Capability_List_Excel

G8400A12	Rotating Warning Light	Grimes Aerospace
G8400A12-12	Rotating Warning Light	Grimes Aerospace
G8400A13-24	Rotating Warning Light	Grimes Aerospace
G8400A14-24	Rotating Warning Light	Grimes Aerospace
G8400A15-24	Rotating Warning Light	Grimes Aerospace
G8400A21-24	Rotating Warning Light	Grimes Aerospace
G8400A22-24	Rotating Warning Light	Grimes Aerospace
G8400A23-24	Rotating Warning Light	Grimes Aerospace
G8400A24	Rotating Warning Light	Grimes Aerospace
G8400A24-24	Rotating Warning Light	Grimes Aerospace
G8400A3-12	Rotating Warning Light	Grimes Aerospace
G8400A31-24	Rotating Warning Light	Grimes Aerospace
G8400A3-24	Rotating Warning Light	Grimes Aerospace
G8400A36-24	Rotating Warning Light	Grimes Aerospace
G8400A37-24	Rotating Warning Light	Grimes Aerospace
G8400A39-24	Rotating Warning Light	Grimes Aerospace
G8400A41-24	Rotating Warning Light	Grimes Aerospace
G8400A43-24	Rotating Warning Light	Grimes Aerospace
G8400A45-12	Rotating Warning Light	Grimes Aerospace
G8400A47-24	Rotating Warning Light	Grimes Aerospace
G8400A49-24	Rotating Warning Light	Grimes Aerospace
G8400A8-12	Rotating Warning Light	Grimes Aerospace
G8400A8-24	Rotating Warning Light	Grimes Aerospace
G8400A9-24	Rotating Warning Light	Grimes Aerospace
G9950-1	Tandem Oscillating Nav Light	Grimes Aerospace
GA54	Tank Unit	Smiths Industries
GA55-49-12	Pressure Transducer	Auxitrol
GA57087-1	Cover assy	Messier-Bugatti
GA57087-2	Cover assy	Messier-Bugatti
GA57088-1	Cover assy	Messier-Bugatti
GA57088-2	Cover assy	Messier-Bugatti
GAI2800	Smoke Detector	Cerberus Guinard
GAI2800-01	Smoke Detector	Cerberus Guinard
GAI2800-02	Smoke Detector	Cerberus Guinard
GAI2820-00	Smoke Detector	Cerberus Guinard
GB2000AA0	Check Valve	Technofan
GC1097	Flange	FR Hitemp
GD20-2	Gearbox Drive Shaft	Dowty Aerospace
GM5341-1	Transducer	Kavlico
GM5341-4	Transducer	Kavlico
GM5341-5	Transducer	Kavlico
GM5341-6	Transducer	Kavlico
GM5341-7	Transducer	Kavlico
GM5341-8	Transducer	Kavlico
GM7184-1	Transducer	Kavlico
GM7184-2	Transducer	Kavlico
GM7184-3	Transducer	Kavlico
GM7184-4	Transducer	Kavlico
GM7184-5	Transducer	Kavlico
GM8708-2	Transducer	Kavlico
GM8708-3	Transducer	Kavlico
GM9713-1	Rod assy	Kavlico
GMT4190-020	Electronic Clock	Thales Avionics
GMT4200	Electronic Clock	Thales Avionics
GN127	Tank Unit	Smiths Industries
GN128	Tank Unit	Smiths Industries
GN129	Tank Unit	Smiths Industries
GN130	Tank Unit	Smiths Industries

Repair_Capability_List_Excel

GN131	Tank Unit	Smiths Industries
GN132	Tank Unit	Smiths Industries
H138JFM	Gyroscopic Horizon	Thales Avionics
H138JM	Gyroscopic Horizon Indicator	Thales
H138JM1	Gyroscopic Horizon	Thales Avionics
H138SM	Gyroscopic Horizon	Thales Avionics
H140KQM	Gyroscopic Horizon	Thales Avionics
H140KYM	Gyroscopic Horizon	Thales Avionics
H150AKM1	Stand-By Attitude Indicator	Thales
H19-601A	Valve assy	Intertechnique
H220ABM	Gyroscopic Horizon	Thales Avionics
H221BLM	Gyroscopic Horizon	Thales Avionics
H2295-17	Flush Lock assy	Hartwel Corporation
H2295-21	Flush Lock assy	Hartwel Corporation
H2295-25	Flush Lock assy	Hartwel Corporation
H2295-27	Flush Lock assy	Hartwel Corporation
H2295-5	Flush Lock assy	Hartwel Corporation
H2295-7	Flush Lock assy	Hartwel Corporation
H2295-9	Flush Lock assy	Hartwel Corporation
H2869-1	Toggle Hook Latch assy	Hasco Hartwell
H2869-5	Toggle Hook Latch assy	Hasco Hartwell
H301AZM1	Gyroscopic Horizon Indicator	Thales
H301BAM	Gyroscopic Horizon	Thales Avionics
H301BDM1	Gyroscopic Horizon	Thales Avionics
H321ALM1	Gyroscopic Horizon	Thales Avionics
H321BDM1	Gyroscopic Horizon	Thales Avionics
H321DAM	Gyroscopic Horizon	Thales Avionics
H321EAM	Gyroscopic Horizon	Thales Avionics
H341ABM	Gyroscopic Horizon	Thales Avionics
H341ADM2	Gyroscopic Horizon	Thales Avionics
H341AGM1	Gyroscopic Horizon	Thales Avionics
H341AMM1	Gyroscopic Horizon	Thales Avionics
H341AZM	Gyroscopic Horizon	Thales Avionics
H44	Potentiometer	Airbus Industrie
H504A	Transmitter	Novatronics
H504B	Transmitter	Novatronics
H505A	Transmitter	Novatronics
H505B	Transmitter	Novatronics
H509B	Transmitter	Novatronics
H60C0645	Check Valve	Parker Hannifin
H61C0551	Check Valve	Parker Aerospace
H61C0552	Check Valve	Parker Aerospace
H61C0552M1	Check Valve	Parker Aerospace
H911A	Transducer assy	Novatronix
H913A	Transducer assy	Novatronix
HA2542AR04	Handset Fwd Attendant	Thales Avionics
HC1750	Wing Anti-Icing Control Valve	Hymatic Engineering
HC1750A	Wing Anti-Icing Control Valve	Hymatic Engineering
HC1751	Wing Anti-Icing Control Valve	Hymatic Engineering
HC1752	Wing Anti-Icing Control Valve	Hymatic Engineering
HC1753	Wing Anti-Icing Control Valve	Hymatic Engineering
HC1754	Wing Anti-Icing Control Valve	Hymatic Engineering
HC1755	Wing Anti-Icing Control Valve	Hymatic Engineering
HC1756	Wing Anti-Icing Control Valve	Hymatic Engineering
HC1757	Wing Anti-Icing Control Valve	Hymatic Engineering
HC1758	Wing Anti-Icing Control Valve	Hymatic Engineering
HL11200-01	Hydrolock assy	Porter
HL11200-03	Hydrolock assy	Porter

Repair_Capability_List_Excel

HL11200-04	Hydrolock assy	Porter
HL11200-15	Hydrolock assy	Porter
HL11200-16	Hydrolock assy	Porter
HL11200-29	Hydrolock assy	Porter
HL11200-32	Hydrolock assy	Porter
HL11200-34	Hydrolock assy	Porter
HL11200-37	Hydrolock assy	Porter
HL11200-39	Hydrolock assy	Porter
HL11200-41	Hydrolock assy	Porter
HL11200-42	Hydrolock assy	Porter
HL11200-44	Hydrolock assy	Porter
HL11200-46	Hydrolock assy	Porter
HL11200-48	Hydrolock assy	Porter
HL11200-51	Hydrolock assy	Porter
HL11200-52	Hydrolock assy	Porter
HL11200-53	Hydrolock assy	Porter
HL11200-58	Hydrolock assy	Porter
HL11200-59	Hydrolock assy	Porter
HL11200-63	Hydrolock assy	Porter
HL11200-64	Hydrolock assy	Porter
HL11200-65	Hydrolock assy	Porter
HL11200-70	Hydrolock assy	Porter
HL11200-71	Hydrolock assy	Porter
HL11200-79	Hydrolock assy	Porter
HN1503G	Servo Valve	Messier-Bugatti
HP1368100-1	Module Valve	Tactair-Teledyne
HP1368100-3	Module Valve	Tactair-Teledyne
HP1368100-4	Module Valve	Tactair-Teledyne
HP1368100-5	Module Valve	Tactair-Teledyne
HP1368100-6	Module Valve	Tactair-Teledyne
HP1368100-7	Module Valve	Tactair-Teledyne
HP1373100-1	Selector Valve	Tactair-Teledyne
HP1373100-3	Selector Valve	Tactair-Teledyne
HP3520AC01	Cockpit Speaker	Thales Avionics
HR6B9-310-GB1A	Valve assy	Honeywell
HTE10005-1	Pressure Reducing Valve	FR Hitemp
HTE190000-1	Actuator	FR Hitemp
HTE190001	Actuator Valve	FR Hitemp
HTE190001-1	Actuator Valve	FR Hitemp
HTE190001-2	Actuator Valve	FR Hitemp
HTE190021	Twin Actuator	FR Hitemp
HTE190026	Twin Actuator	FR Hitemp
HTE200002	Single Motor Actuator	FR Hitemp
HTE200002-1	Single Motor Actuator	FR Hitemp
HTE200043	Single Motor Actuator	FR Hitemp
HTE250113-1	Isolation Valve	FR Hitemp
HTE2932	Fuel Shut-Off Valve	FR Hitemp
HTE310019	Air Inlet Valve	FR Hitemp
HTE310020	Valve assy	FR Hitemp
HTE310021	Air Inlet Valve	FR Hitemp
HTE310021-1	Air Inlet Valve	FR Hitemp
HTE310028	Fuel Drain Valve assy	FR Hitemp
HTE370001	Valve assy	FR Hitemp
HTE400115	Non-Return Valve	FR Hitemp
HTE400117	Non-Return Valve	FR Hitemp
HTE400127	Non-Return Valve	FR Hitemp
HTE400180	Non-Return Valve	FR Hitemp
HTE400207	Non-Return Valve	FR Hitemp

Repair_Capability_List_Excel

HTE4172	Valve assy	FR Hitemp
HTE4195	Valve assy	FR Hitemp
HTE420026	Relief Pressure Valve	FR Hitemp
HTE420028	Relief Pressure Valve	FR Hitemp
HTE420044	Holding Pressure Valve	FR Hitemp
HTE420080	Holding Pressure Valve	FR Hitemp
HTE420085	Valve assy	FR Hitemp
HTE420086	Pressure Holding Valve	FR Hitemp
HTE440007	Check Valve	FR Hitemp
HTE4418	Non-Return Valve	FR Hitemp
HTE460009	Non-Return Valve	FR Hitemp
HTE460009-1	Non-Return Valve	FR Hitemp
HTE460023	Door ByPass Valve	THE
HTE490004	Valve assy	FR Hitemp
HTE490005	Valve assy	FR Hitemp
HTE490012	Pump Outlet Non-return Valve	FR Hitemp
HTE4918	Valve assy	FR Hitemp
HTE510005	Pressure Reducing Valve	FR Hitemp
HTE510005-1	Pressure Reducing Valve	FR Hitemp
HTE510010	Pressure Reducing Valve	FR Hitemp
HTE510010-1	Pressure Reducing Valve	FR Hitemp
HTE510016	Gas-Charging Valve	FR Hitemp
HTE510027	Valve assy	FR Hitemp
HTE510027-1	Valve assy	FR Hitemp
HTE620071-1	Sliding Union	FR Hitemp
HTE620072-1	Sliding Union	FR Hitemp
HTE6394	Fuel Transfer & Fuel Crossed Valve	FR Hitemp
HTE6395	Fuel Transfer & Fuel Crossed Valve	FR Hitemp
HTE660020	Compensated Slide	FR Hitemp
HTE69000	Pressure Switch	FR Hitemp
HTE69000-1	Pressure Switch	FR Hitemp
HTE690035	Pressure Switch	FR Hitemp
HTE690035-1	Pressure Switch	FR Hitemp
HTE690045	Pressure Switch	FR Hitemp
HTE690047	Pressure Switch	FR Hitemp
HTE70001	HP Ground Connector	FR Hitemp
HTE8002	Vee-band Clamp	FR Hitemp
HTE900001	Low Pressure Valve	FR Hitemp
HTE900056	Interzell Transfer Valve	FR Hitemp
HTE900057	Interzell Transfer Valve	FR Hitemp
HTE900087	Interzell Transfer Valve	FR Hitemp
HTE900087-001	Interzell Transfer Valve	FR Hitemp
HTE900088	Interzell Transfer Valve	FR Hitemp
HTE900095	Transfer Valve Drive Shaft	FR Hitemp
HTE900096	Transfer Valve Drive Shaft	FR Hitemp
HTE900118	Low Pressure Valve	FR Hitemp
HTE900118-001	Low Pressure Valve	FR Hitemp
HTE900132	Fuel Transfer & Fuel Crossed Valve	FR Hitemp
HTE900133	Fuel/Defuel Valve	FR Hitemp
HTE900134	Fuel Transfer & Fuel Crossed Valve	FR Hitemp
HTE900135	Crossfeed Fuel Valve	FR Hitemp
HTE900158	Hydraulic Shut-Off Valve	FR Hitemp
HTE900158-001	Shut-Off Valve	FR Hitemp
HTE900162	Valve	FR Hitemp
HTE900189	Fuel Valve	FR Hitemp
HTE900195	Shut-Off Valve	FR Hitemp
HTE900196	Fuel Fire Shut-Off Valve	FR Hitemp
HTE900208-001	Isolation Valve	FR Hitemp

Repair_Capability_List_Excel

HTE900209-001	Isolation Valve	FR Hitemp
HTE900214-001	Isolation Valve	FR Hitemp
HTE960023	BYPASS VALVE	THE
HTE960034	Manual Ball Valve	FR Hitemp
HTE960035	Manual Ball Valve	FR Hitemp
HV22-8	Bleed Valve	Circle Seal Controls
J-082269-1	Ball Transfer Unit	Goodrich
J-082269-2	Ball Transfer Unit	Goodrich
J-082269-3	Ball Transfer Unit	Goodrich
J-082269-4	Ball Transfer Unit	Goodrich
J-082269-5	Ball Transfer Unit	Goodrich
J-082269-6	Ball Transfer Unit	Goodrich
J-082269-7	Ball Transfer Unit	Goodrich
J-082269-8	Ball Transfer Unit	Goodrich
J172ABM	Accelerometer Unit	Thales Avionics
J172AFM02	Accelerometer Unit	Thales Avionics
J172AHM01	Accelerometer Unit	Thales Avionics
J196AAM01	Rate Gyro	Thales Avionics
J1AM1	Sensor	Thales Avionics
J21AM0	Accelerometer Unit	Thales Avionics
J500ZZ40	Flush Control Unit	LGG
J540AI1-010	Toilet assy	LGG
J540AI1-020	Toilet assy	LGG
J540AI1-021	Toilet assy	LGG
J540AI1-100	Toilet assy	LGG
J540AI1-110	Toilet assy	LGG
J540AI1-111	Toilet assy	LGG
J540AI1-112	Toilet assy	LGG
J540AI1-120	Toilet assy	LGG
J540AI1-121	Toilet assy	LGG
J540AI1-200	Toilet assy	LGG
J540AI1-300	Toilet assy	LGG
J540AI1-500	Toilet assy	LGG
J540AI1-520	Toilet assy	LGG
J540AI16-100	Flush Control Unit	LGG
J540AI16-200	Flush Control Unit	LGG
J540AI2-010	Toilet assy	LGG
J540AI2-020	Toilet assy	LGG
J540AI2-021	Toilet assy	LGG
J540AI2-100	Toilet assy	LGG
J540AI2-110	Toilet assy	LGG
J540AI2-111	Toilet assy	LGG
J540AI2-112	Toilet assy	LGG
J540AI2-120	Toilet assy	LGG
J540AI2-121	Toilet assy	LGG
J540AI2-200	Toilet assy	LGG
J540AI2-300	Toilet assy	LGG
J540AI2-500	Toilet assy	LGG
J540AI2-520	Toilet assy	LGG
J540AI4	Vacuum Generator	LGG
J540AI4-100	Vacuum Generator	LGG
J540AI5	Waste Balancing Valve	LGG
J540AI51	Waste Drain Valve	LGG
J540AI6	Check Valve	LGG
J540AI71	Waste Tank assy	LGG
J540AI71-100	Waste Tank assy	LGG
J540AI73	Liquid Level Sensor	LGG
J540AI74-100	Liquid Level Transmitter	LGG

Repair_Capability_List_Excel

J540AI75-100	Differential Pressure Sensor	LGG
J540AI9	Air Shut-off Valve	LGG
J540AI9-100	Air Shut-off Valve	LGG
J5BM2	Rate Gyro	Thales Avionics
JG1052AA01	Altitude Alerter Indicator	Honeywell
JG1052AA02	Altitude Alerter Indicator	Honeywell
JG1052AA03	Altitude Alerter Indicator	Honeywell
JG1052AA04	Altitude Alerter Indicator	Honeywell
JG1052AA05	Altitude Alerter Indicator	Honeywell
JG1052AA06	Altitude Alerter Indicator	Honeywell
JG1052AA07	Altitude Alerter Indicator	Honeywell
JG1052AB01	Altitude Alerter Indicator	Honeywell
JG1052AB02	Altitude Alerter Indicator	Honeywell
JG1052AB03	Altitude Alerter Indicator	Honeywell
JG1052AB04	Altitude Alerter Indicator	Honeywell
JG1052AC01	Altitude Alerter Indicator	Honeywell
JG1052AC02	Altitude Alerter Indicator	Honeywell
JG1052AC03	Altitude Alerter Indicator	Honeywell
JG1052AC04	Altitude Alerter Indicator	Honeywell
JG1052AC09	Altitude Alerter Indicator	Honeywell
JG1052AK01	Altitude Alerter Indicator	Honeywell
JG1052AP01	Altitude Alerter Indicator	Honeywell
JG1052BC01	Altitude Alerter Indicator	Honeywell
JG1052BD01	Altitude Alerter Indicator	Honeywell
JG1072AC04	Radio Altimeter	Honeywell
JG1072AC09	Radio Altimeter	Honeywell
JG1072AC10	Radio Altimeter	Honeywell
JG1072AC11	Radio Altimeter	Honeywell
JG1072AC13	Radio Altimeter	Honeywell
JG1208AA01	Load Select Indicator	Honeywell
JG1208AK01	Load Select Indicator	Honeywell
JG1208CA01	Load Select Indicator	Honeywell
JG1208CK01	Load Select Indicator	Honeywell
JP3934AA02	Jack Box	Thales Avionics
JP3935AA02	Jack Box	Thales Avionics
K2727000100000	Load Limiting Spring Rod	Airbus Industrie
K38396	Operating Head	Kidde Technologies
K-9	Thermometer	Weston Aerospace
K97-63-601	Refuelling & Defuelling Connector	Intertechnique
K97-63-607	Defuel/Refuel Adapter	Intertechnique
K97B63-601	Pressure Fueling Adapter	Intertechnique
K98-63-204	Filler Cap	Intertechnique
K98E63-601	Cap Coupling	Intertechnique
KAB0803	Airspeed Indicator	Smiths Industries
KCA0105W	Stand-by Compass	Smiths Industries
KGA0402	RPM Generator	Smiths Industries
KGA0403	RPM Generator	Smiths Industries
KGA0407	RPM Generator	Smiths Industries
KM436	Indicator	VDO
KSA0202L	Synchroscope	Smiths Industries
KSD0208	Altitude Switch	Smiths Industries
KTS0202	Turn & Slip Indicator	Smiths Industries
KTS0203L	Turn & Slip Indicator	Smiths Industries
KTS0301L	Turn & Slip Indicator	Smiths Industries
KTS0401	Turn & Slip Indicator	Smiths Industries
KTS0404	Turn & Slip Indicator	Smiths Industries
L16-49-11	Linear Actuator	Plessey
L32-600-250-1	Cable Control assy	ECE

Repair_Capability_List_Excel

L32-600-251-1	Cable Control assy	ECE
L32-600-252-1	Cable Control assy	ECE
L32-600-253-1	Cable Control assy	ECE
L32-600-254-1	Cable Control assy	ECE
L32-600-255-1	Cable Control assy	ECE
L32-600-261	Cable Control assy	ECE
L32-600-262-1	Cable Control assy	ECE
L32-600-263-1	Cable Control assy	ECE
L32-600-264-1	Cable Control assy	ECE
L32A300-106	Cable Control assy	ECE
L32A300-132-1	Cable Control assy	ECE
L32A300-132-2	Cable Control assy	ECE
L32A300-138-1	Cable Control assy	ECE
L32A300-138-2	Cable Control assy	ECE
L32A300-141	Cable Control assy	ECE
L32A300-151	Cable Control assy	ECE
L32A300-152	Cable Control assy	ECE
L32A300-153	Cable Control assy	ECE
L32A300-154	Cable Control assy	ECE
L32A300-155	Cable Control assy	ECE
L32A300-157	Cable Control assy	ECE
L32A300-161	Cable Control assy	ECE
L32A300-166	Cable Control assy	ECE
L32A310-185	Cable Control assy	ECE
L32A310-188	Cable Control assy	ECE
L32A310-189	Cable Control assy	ECE
L32A310-190	Cable Control assy	ECE
L32A310-191	Cable Control assy	ECE
L32A310-195-1	Cable Control assy	ECE
L32A310-195-2	Cable Control assy	ECE
L32A310-196-1	Cable Control assy	ECE
L32A310-196-2	Cable Control assy	ECE
L32A310-198-1	Cable Control assy	ECE
L32A310-199-1	Cable Control assy	ECE
L32A310-200-1	Cable Control assy	ECE
L32A310-202-1	Cable Control assy	ECE
L32A310-203-1	Cable Control assy	ECE
L32A310-204-1	Cable Control assy	ECE
L32A310-205-1	Cable Control assy	ECE
L32A310-206-1	Cable Control assy	ECE
L32A310-210-1	Cable Control assy	ECE
L32A310-211-1	Cable Control assy	ECE
L32A310-212-1	Cable Control assy	ECE
L32A310-213-1	Cable Control assy	ECE
L32A310-214-1	Cable Control assy	ECE
L32A310-215-1	Cable Control assy	ECE
L32A310-216-1	Cable Control assy	ECE
L32A310-217-1	Cable Control assy	ECE
L32A310-218-1	Cable Control assy	ECE
L32A310-219-1	Cable Control assy	ECE
L32A310-222	Cable Control assy	ECE
L32A310-223	Cable Control assy	ECE
L32A310-230	Cable Control assy	ECE
L32A310-235-1	Cable Control assy	ECE
L32A310-240-1	Cable Control assy	ECE
L32A310-245-1	Cable Control assy	ECE
L32A310-250-1	Cable Control assy	ECE
L32A310-255-1	Cable Control assy	ECE

Repair_Capability_List_Excel

L32A310-260-1	Cable Control assy	ECE
L32A310-265-1	Cable Control assy	ECE
L32A310-270-1	Cable Control assy	ECE
L32A310-275-1	Cable Control assy	ECE
L32A310-276	Cable Control assy	ECE
L32A310-290-1	Cable Control assy	ECE
L32A320-110	Cable Control assy	ECE
L32A320-111	Cable Control assy	ECE
L32A320-112	Cable Control assy	ECE
L32A320-113	Cable Control assy	ECE
L32A320-114	Cable Control assy	ECE
L32A320-120	Cable Control assy	ECE
L32A320-122	Cable Control assy	ECE
L32A320-124	Cable Control assy	ECE
L32A320-126	Cable Control assy	ECE
L32A320-13	Cable Control assy	ECE
L32A320-150LH	Cable Control assy	ECE
L32A320-150RH	Cable Control assy	ECE
L32A320-160	Cable Control assy	ECE
L32A320-20	Cable Control assy	ECE
L32A320-212A	Swivel assy	ECE
L32A320-216	Swivel assy	ECE
L32A320-217	Bulkhead Connection	ECE
L32A320-221A	Cable Control assy	ECE
L32A320-230LH	Cable Control assy	ECE
L32A320-230RH	Cable Control assy	ECE
L32A320-240	Ball Bearing Control assy	ECE
L32A320-245LH	Cable Control assy	ECE
L32A320-245RH	Cable Control assy	ECE
L32A320-250	Cable Control assy	ECE
L32A320-310	Cable Control assy	ECE
L32A320-350	Cable Control assy	ECE
L32A321-310	Cable Control assy	ECE
L32A321-350	Cable Control assy	Teleflex Controls
L32A340-410	Cable Control assy	ECE
L32A340-415	Cable Control assy	ECE
L32A340-420	Cable Control assy	ECE
L32A340-421	Cable Control assy	ECE
L32A340-422	Cable Control assy	ECE
L32A340-423	Cable Control assy	ECE
L32A340-424	Cable Control assy	ECE
L32A340-425	Cable Control assy	ECE
L32A340-426	Cable Control assy	ECE
L32A340-428	Cable Control assy	ECE
L32A340-430	Cable Control assy	ECE
L32A340-435	Cable Control assy	ECE
L32A340-440	Cable Control assy	ECE
L83122-10-300	Barometric Altimeter	Kollsman
L83A13-601-1	Water Drain Valve	Intertechnique
L83A13-602	Water Drain Valve	Intertechnique
L83A13-602-1	Water Drain Valve	Intertechnique
L83A13-604	Water Drain Valve	Intertechnique
L83A13-605-1	Water Drain Valve	Intertechnique
L83A13-606-1	Water Drain Valve	Intertechnique
L83A13-608	Water Drain Valve	Intertechnique
L83A13-609	Water Drain Valve	Intertechnique
L83A13-610	Water Drain Valve	Intertechnique
L83A13-611	Water Drain Valve	Intertechnique

Repair_Capability_List_Excel

L83A13-612	Drain Valve	Intertechnique
L83A13-613	Drain Valve	Intertechnique
L83A13-614	Water Drain Valve	Intertechnique
L83A13-615	Water Drain Valve	Intertechnique
L83A13-616	Water Drain Valve	Intertechnique
L83A13-616 Amdt A	Water Drain Valve	Intertechnique
L83A13-617	Leak Monitor	Intertechnique
L83A13-619	Water Drain Valve	Intertechnique
L83A13-620	Water Drain Valve	Intertechnique
L83A601	Water Drain Valve	Intertechnique
L83A602	Water Drain Valve	Intertechnique
L83A602A	Water Drain Valve	Intertechnique
L83A603	Water Drain Valve	Intertechnique
L83A604	Drain Valve	Intertechnique
L83A605	Drain Valve	Intertechnique
L85-38-601	Check Valve	Intertechnique
L87-20-202	Air Vent Valve	Intertechnique
L87-26-601	Float Valve	Intertechnique
L92B13-602	Valve Cartridge	Intertechnique
L92C13-602	Shut-Off Valve	Intertechnique
L93C31-651	Refuelling Unit	Intertechnique
L93E38-601	Refuel/Defuel Valve	Intertechnique
L94L38-651	Valve Module	Intertechnique
L95B13-401	Pressure Relief Valve	Intertechnique
L95F100-601	Overpressure Protector	Intertechnique
L95F100-602	Overpressure Protector	Intertechnique
L95F100-603	Overpressure Protector	Intertechnique
L95F100-604	Overpressure Protector	Intertechnique
L95F100-605	Overpressure Protector	Intertechnique
L95F50-602	Overpressure Protector	Intertechnique
L95F50-603	Overpressure Valve	Intertechnique
L96-26-601	Check Valve	Intertechnique
L96A602	Fuel Indicator	Intertechnique
L96A603	Fuel Indicator	Intertechnique
L96A604	Fuel Indicator	Intertechnique
L96A605	Fuel Indicator	Intertechnique
L96F90-601	Pressure Valve	Intertechnique
L96L90-601	Pressure Valve	Intertechnique
L97-63-601	Pressure Relief Valve	Intertechnique
L97-63-602	Pressure Relief Valve	Intertechnique
L98A602	Fuel Indicator	Intertechnique
L98A603	Magnetic Level Indicator	Intertechnique
L98A604	Fuel Indicator	Intertechnique
L98A605	Fuel Indicator	Intertechnique
L98A606	Fuel Indicator	Intertechnique
L98A608	Fuel Indicator	Intertechnique
L98A609	Fuel Indicator	Intertechnique
L98A611	Magnetic Level Indicator	Intertechnique
L98A617	Magnetic Level Indicator	Intertechnique
L98A618	Magnetic Level Indicator	Intertechnique
L98A619	Magnetic Level Indicator	Intertechnique
L98A629	Magnetic Level Indicator	Intertechnique
L98A630	Magnetic Level Indicator	Intertechnique
L98A634	Magnetic Level Indicator	Intertechnique
L98A640	Magnetic Level Indicator	Intertechnique
L98A641	Magnetic Level Indicator	Intertechnique
L98A642	Magnetic Level Indicator	Intertechnique
L98A644	Magnetic Level Indicator	Intertechnique

Repair_Capability_List_Excel

L98A645	Magnetic Level Indicator	Intertechnique
L98A646	Magnetic Level Indicator	Intertechnique
L98A647	Magnetic Level Indicator	Intertechnique
L98A648	Magnetic Level Indicator	Intertechnique
L98A649	Magnetic Level Indicator	Intertechnique
L98A650	Magnetic Level Indicator	Intertechnique
L98A651	Magnetic Level Indicator	Intertechnique
L98A652	Magnetic Level Indicator	Intertechnique
L98A653	Magnetic Level Indicator	Intertechnique
L98A654	Magnetic Level Indicator	Intertechnique
L98A655	Magnetic Level Indicator	Intertechnique
L98A656	Magnetic Level Indicator	Intertechnique
L98A657	Magnetic Level Indicator	Intertechnique
L98A658	Magnetic Level Indicator	Intertechnique
L98A659	Magnetic Level Indicator	Intertechnique
L98A660	Magnetic Level Indicator	Intertechnique
L98A661	Magnetic Level Indicator	Intertechnique
L98A662	Magnetic Level Indicator	Intertechnique
L98B623	Magnetic Level Indicator	Intertechnique
L98B624	Magnetic Level Indicator	Intertechnique
L98B625	Magnetic Level Indicator	Intertechnique
L98B628	Magnetic Level Indicator	Intertechnique
L98B629	Magnetic Level Indicator	Intertechnique
L98B630	Magnetic Level Indicator	Intertechnique
LA11A2104	Linear Actuator	ITT Industries
LA2H60200HM0100	Brake Temp.Monitor Unit	Thales Avionics
LA2H60300HM0100	Brake Temp.Monitor Unit	Thales Avionics
LG1189AC01	EPR Transmitter	Honeywell
LIBB-E32	Position Indicator	Boeing
LL1400-06	Hydrolok	Porter
LS14393-15	Circuit Breaker	Eaton
M046Z14-02	Sensor	Thales Avionics
M109206-01	Pickoff Flaps & Slats Asymetry Monitor.	Thales Avionics
M18217	Pressure Gage	Ranco
M18314	Pressure Gage	Ranco
M2047-501	Temperature Switch	Hamilton Sundstrand
M2048-501	Temperature Switch	Hamilton Sundstrand
M21520-1	Fan	Hamilton Sundstrand
M2217	Thrust Indicator	Negretti
M2217BB	Indicator	Meggitt
M35AA0104	Electrical Warmer	Auxilec
M35AB0102	Electrical Warmer	Auxilec
M35AN0102	Electrical Warmer	Auxilec
M36787D01	D.C. Motor	Honeywell
M4100714B	Inlet Guide Actuator ay	APIC
M4100714C	Inlet Guide Actuator ay	APIC
M421-01	Pressure Switch	Industria
M4663	Nipple Check Valve assy	Kaiser Aerospace
M4941A1A	Vaneaxial Fan	Dynamic Air
M5911327	Drive Shaft assy	Hamilton Sundstrand
M5911359	Drive Shaft assy	Hamilton Sundstrand
M5911361	Drive Shaft assy	Hamilton Sundstrand
M6212	Air Control Valve	Goodrich Control Systems
M6213	Air Control Valve	Goodrich Control Systems
M6215	Air Control Valve	Goodrich Control Systems
M6240	Air Control Valve	Goodrich Control Systems
M6241	Air Control Valve	Goodrich Control Systems
M6242	Air Control Valve	Goodrich Control Systems

Repair_Capability_List_Excel

M72012-427	Hydraulic Reservoir	Fokker Aircraft
M72036-425	Hydraulic Reservoir	Fokker Aircraft
M732591AF	Air Cooling Fan	Hamilton Sundstrand
M732591BF	Air Cooling Fan	Hamilton Sundstrand
M732591CF	Air Cooling Fan	Hamilton Sundstrand
M732591DF	Air Cooling Fan	Hamilton Sundstrand
M732591EF	Air Cooling Fan	Hamilton Sundstrand
M9838C	Attitude Monitor	Avimo
MA20A1001-1	Actuator	ITT Fluid Technology
MC10-04-105	Regulator O2 Mask assy	Intertechnique
MC10-04-110	Regulator O2 Mask assy	Intertechnique
MC10-04-127	Regulator O2 Mask assy	Intertechnique
MD430-16TAK	Microphone	Sennheiser
MF10-05-11	Quick Donning Mask Regulator	Intertechnique
MF10-05-12	Quick Donning Mask Regulator	Intertechnique
MF1-060-18	Hydraulic Motor	Vickers
MF1-095-6	Hydraulic Motor	Vickers
MF3-044-2A	Hydraulic Motor	Vickers
MF3-044-2B	Hydraulic Motor	Vickers
MF3-044-3	Hydraulic Motor	Vickers
MI252010	Mounting	Honeywell
MI585009	Transceiver	Honeywell
MI585011	Indicator	Honeywell
MI585011-1	Indicator	Honeywell
MI585011-2	Indicator	Honeywell
MI585011-3	Indicator	Honeywell
MI585015	Transceiver	Honeywell
MI585016	DME Indicator	Honeywell
MI585017	DME Indicator	Honeywell
MI585019	Transceiver	Honeywell
MI585020	TXP Control	Honeywell
MI585035	Transceiver	Honeywell
MI585036	Indicator	Honeywell
MI585036-1	Indicator	Honeywell
MI585048	Synchro	Honeywell
MI585057	Indicator	Honeywell
MI59022-1	Indicator	Honeywell
MI592021	Transceiver	Honeywell
MI592022	Indicator	Honeywell
MI592032	Shockmount assy	Honeywell
MI592034	Indicator	Honeywell
MI592035	Hood Indicator	Honeywell
MI592037	Reflector	Honeywell
MI592038	Reflector	Honeywell
MK14LL	Pneumatic Pressure Indicator	Smiths Industries
MN97	Course Indicator	Bendix
MPEV3-022-3A	Hydraulic Motorpump	Vickers
MPEV3-032-10A	Hydraulic Motor Pump	Vickers
MPEV3-032-10B	Hydraulic Motor Pump	Vickers
MPEV3-032-1D	Hydraulic Motor Pump	Vickers
MPEV3-032-1E	Hydraulic Motor Pump	Vickers
MPEV3-032-1G	Driven Motor Pump	Vickers
MPEV3-032-1H	Driven Motor Pump	Vickers
MPEV3-032-GB1	Hydraulic Motor Pump	Vickers
MPEV3-056-10	Driven Motor Pump	Vickers
MPEV3-056-6D	Hydraulic Motor Pump	Vickers
MPEV3-056-6F	Hydraulic Motor Pump	Vickers
MPEV3-056-6H	Hydraulic Motor Pump	Vickers

Repair_Capability_List_Excel

MPEV3-056-7	Driven Motor Pump	Vickers
MPEV3-056-7A	Driven Motor Pump	Vickers
MPEV3-056-9	Hydraulic Motor Pump	Vickers
MPEV3-056-9A	Driven Motor Pump	Vickers
MPHF1-152-3	Package	Vickers
MPHF1-152-3A	Hydraulic Motor Pump	Vickers
MPHFI-152-3	Hydraulic Motor Pump	Vickers
MPVE3-032-10	Hydraulic Motor Pump	Vickers
MPVF3-032-10	Pump assy	Vickers
MS28005-1	Pressure Transmitter	Bendix/King
MS28005-2	Pressure Transmitter	Ametek
MS28005-3	Pressure Transmitter	Ametek
MS28005-4	Pressure Transmitter	Ametek
MS28006-1	Thermometer	Weston Aerospace
MS28006-2	Thermometer	Weston Aerospace
MS28007-1	Thermometer	Weston Aerospace
MS28010-2	Pressure Transmitter	Ametek
MS28010-3	Pressure Transmitter	Ametek
MS28034-3	Bulb Oil Temperature	Honeywell
MS28043-2	Engine Gauge Unit	Edison
MS9-3911-30ZE	Hydraulic Motor	Vickers
MS9-3911-30ZE4C	Hydraulic Motor	Vickers
MSE101-01	Oxygen Mask Regulator	Intertechnique
MSE101-02	Oxygen Mask Regulator	Intertechnique
MSE101-07	Oxygen Mask Regulator	Intertechnique
MSE101-101	Oxygen Mask Regulator	Intertechnique
MSE101-102	Oxygen Mask Regulator	Intertechnique
MSE101-107	Oxygen Mask Regulator	Intertechnique
MSE101-121	Oxygen Mask Regulator	Intertechnique
MSE101-122	Oxygen Mask Regulator	Intertechnique
MSE101-127	Oxygen Mask Regulator	Intertechnique
MSE101-21	Oxygen Mask Regulator	Intertechnique
MSE101-22	Oxygen Mask Regulator	Intertechnique
MSE101-27	Oxygen Mask Regulator	Intertechnique
MVT100-1	Servo Valve	SAMM
MXP111	Stowage Box	Intertechnique
MXP401	Stowage Box assy	Intertechnique
MZ4306000-01	Servo-control Spoiler Actuator	Liebherr Aerospace
MZ4306000-10	Servo-control Spoiler Actuator	Liebherr Aerotechnik
MZ4306000-2	Servo-control Spoiler Actuator	Liebherr Aerospace
MZ4339390	Servo-control Spoiler Actuator	Liebherr Aerospace
MZ4339390-01	Servo-control Spoiler Actuator	Liebherr Aerospace
MZ4339390-02	Servo-control Spoiler Actuator	Liebherr Aerospace
MZ4339390-10	Servo-control Spoiler Actuator	Liebherr Aerotechnik
O-2	Pressure Gage	Ranco
P141-395-5	Valve assy	Circle Seal Controls
P15-736	Check Valve	Circle Seal Controls
P16-736	Check Valve	Circle Seal Controls
P193-45-2	Rudder Power Flying Ctrl Unit	Dowty
P193-45-30	Rudder Power Flying Ctrl Unit	Dowty
P193-45-53	Rudder Power Flying Ctrl Unit	Dowty
P193-45-54	Rudder Power Flying Ctrl Unit	Dowty
P193-45-63	Rudder Power Flying Ctrl Unit	Dowty
P193-45-64	Rudder Power Flying Ctrl Unit	Dowty
P20-349	Thermal Relief Valve	Circle Seal Controls
P20-349A	Thermal Relief Valve	Circle Seal Controls
P2-07-0001-101	Emergency Handtight	DME
P2-07-0001-201	Emergency Handtight	DME

Repair_Capability_List_Excel

P2-07-0001-201S	Emergency Handight	DME
P2-07-0001-214	Emergency Handight	DME
P2-07-0003-001	Emergency Handight	DME
P2-07-0009-120	Rechargeable Flashlight	DME
P2-07-0011-100	Rechargeable Flashlight	DME
P376A0002-04	Spoiler Speed Brake Actuator	Dowty Aerospace
P376A0002-05	Spoiler Speed Brake Actuator	Dowty Aerospace
P376A0002-07	Spoiler Speed Brake Actuator	Dowty Aerospace
P3C0040800	Sensor	Labem
P414A0002-02	Hyd. Rudder Actuator	Ultra Electronics
P436A0001-00	NLG Change Over Valve	Dowty Aerospace
P436A0001-01	NLG Change Over Valve	Dowty Aerospace
P5394	Clogging Indicator	Sofrance
P53942100021GC0A	Clogging Indicator	Sofrance
P53942100021JC0A	Clogging Indicator	Sofrance
P53942100021MC0A	Clogging Indicator	Sofrance
P53942100021PC0A	Clogging Indicator	Sofrance
P53942100021RC0A	Clogging Indicator	Sofrance
P53942100021YC0A	Clogging Indicator	Sofrance
P5394M	Clogging Indicator	Sofrance
P5394R	Clogging Indicator	Sofrance
P5394T	Clogging Indicator	Sofrance
P5394W	Clogging Indicator	Sofrance
P5394Y	Clogging Indicator	Sofrance
P6952	HP Hydraulic Filter	Sofrance
P6955	HP Hydraulic Filter	Sofrance
P6955A	HP Hydraulic Filter	Sofrance
P6971A	HP Hydraulic Filter	Sofrance
P6989	L.P. Hydraulic Filter	Sofrance
P6989A	L.P. Hydraulic Filter	Sofrance
P6990	Filter assy	Sofrance
P699000AA000PC0A	Filter assy	Sofrance
P699000AB000PC0A	Filter assy	Sofrance
P707264	Switch	Hamilton
P7119HP	Sampling Valve	Sofrance
P7244A	Hydraulic Filter	Sofrance
P93A25-602	Crossflow Pump Cartridge	Intertechnique
P93C13-604	APU Fuel Pump Cartridge	Intertechnique
P95B06-201	Hand Pump	Intertechnique
P95B06-203	Hand Pump	Intertechnique
P99C38-601	Engine Feed Pump	Intertechnique
P99C38-607	Booster Pump	Intertechnique
PA4028AB01	Passenger Address Amplifier	Thales Avionics
PAI2800-01	Smoke Detector	Cerberus Guinard
PAI2810-00	Smoke Detector	Cerberus Guinard
PAI2820-00	Smoke Detector	Cerberus Guinard
PAI2830-00	Smoke Detector	Cerberus Guinard
PAS129-155	Pressure Reducing Valve	Hymatic Engineering
PAS129-155B	Pressure Reducing Valve	Hymatic Engineering
PAS136-022	Air Pressure Reducer Valve	Hymatic
PAS148-132	Pressure Reducing Valve	Hymatic Engineering
PAS148-144A	Pressure Reducing Valve	Hymatic Engineering
PC01502-01	Current Transformer assy	Goodrich Control Systems
PC01801	Current Transformer assy	Goodrich Control Systems
PC01801-01	Current Transformer assy	Goodrich Control Systems
PC02001-01	Current Transformer assy	Goodrich Control Systems
PC07801-01	Current Transformer assy	Goodrich Control Systems
PC-251-123F	Static Inverter	Hamilton Sundstrand

Repair_Capability_List_Excel

PC350-2A	Static Inverter	Marathon Flite-Tronics
PC50	Static Inverter	Marathon Flite-Tronics
PC50-1	Static Inverter	Marathon Flite-Tronics
PCO1502-01	Current Transformer	Hamilton Sundstrand
PES64D4Q600D	Extensible Landing Light	ECE
PI-101C	Pressure Indicator	Standard Oil
PMP05VC-028	Hydraulic Pump	Abex
PN-O10A	Fill-Drain Status Panel	Ametek
PN-O10B	Fill-Drain Status Panel	Ametek
PN-O10C	Fill-Drain Status Panel	Ametek
PR4237-1	Stick Shaker	Artus
PRT75	Non-Return Valve	Intertechnique
PS100-1	Pressure Switch	SAMM
PS101-1	Pressure Switch	SAMM
PTG9-15B	Gearbox	Dowty Aerospace
PTG9-16A	Gearbox	Dowty Aerospace
PTG9-16B	Gearbox	Dowty Aerospace
PTG9-20A	Gearbox	Dowty Aerospace
PTG9-20B	Gearbox	Dowty Aerospace
PT-O33E	Differential Pressure Sensor	Ametek
PU90-401R1	Smoke Detector	Jamco
PU90-401R2	Smoke Detector	Jamco
PU90-401R3	Smoke Detector	Jamco
PU90-401R4	Smoke Detector	Jamco
PU90-401S	Smoke Detector	Jamco
PU90-421R1	Smoke Detector	Jamco
PU90-421R2	Smoke Detector	Jamco
PU90-421R3	Smoke Detector	Jamco
PU90-421R4	Smoke Detector	Jamco
PU90-421S	Smoke Detector	Jamco
PU90-431R1	Smoke Detector	Jamco
PU90-431R2	Smoke Detector	Jamco
PU90-431R3	Smoke Detector	Jamco
PU90-431R4	Smoke Detector	Jamco
PU90-431S	Smoke Detector	Jamco
PU90-441R1	Smoke Detector	Jamco
PU90-441R2	Smoke Detector	Jamco
PU90-441R3	Smoke Detector	Jamco
PU90-441R4	Smoke Detector	Jamco
PU90-441S	Smoke Detector	Jamco
PU90-451R1	Smoke Detector	Jamco
PU90-451R2	Smoke Detector	Jamco
PU90-451R3	Smoke Detector	Jamco
PU90-451R4	Smoke Detector	Jamco
PU90-451S	Smoke Detector	Jamco
PU90-461R1	Smoke Detector	Jamco
PU90-461R2	Smoke Detector	Jamco
PU90-461R3	Smoke Detector	Jamco
PU90-461R4	Smoke Detector	Jamco
PU90-461S	Smoke Detector	Jamco
PU90-499R1	Smoke Detector	Jamco
PU90-499R2	Smoke Detector	Jamco
PU90-499R3	Smoke Detector	Jamco
PU90-499R4	Smoke Detector	Jamco
PU90-499S	Smoke Detector	Jamco
PV3-075-12	Hydraulic Pump	Vickers
PV3-160-4	Hydraulic Pump	Vickers
PV3-160-4A	Hydraulic Pump	Vickers

Repair_Capability_List_Excel

PV3-160-4B	Hydraulic Pump	Vickers
PV3-160-4C	Hydraulic Pump	Vickers
PV3-160-8	Hydraulic Pump	Vickers
PV3-240-10	Hydraulic Pump	Vickers
PV3-240-2G	Hydraulic Pump	Vickers
Q10-48	Control assy	Porter
Q10-49	Control assy	Porter
Q17-94122051AA	Clock	Revue Thommen
Q17-94122051AB	Clock	Revue Thommen
Q17-94122051FA	Clock	Revue Thommen
QA03527	Air Filter	Pall Aerospace
QA04168	Sampling Valve	Pall Aerospace
QA04586	Air Filter	Pall Aerospace
QA05561	LP Filter	Pall Aerospace
QA05593	HP Filter	Pall Aerospace
QA05604	LP Filter	Pall Aerospace
QA05770	Hydraulic Fluid Filter	Pall Aerospace
QA05775	Hydraulic Fluid Filter	Pall Aerospace
QA05777	Hydraulic Fluid Filter	Pall Aerospace
QA05780	Hydraulic Fluid Filter	Pall Aerospace
QA05797	Filter	Pall Aerospace
QA05813	Fluid Separator	Pall Aerospace
QA05813-01	Fluid Separator	Pall Aerospace
QA05877	Restrictor Valve	Pall Aerospace
QA06304	HP Filter	Pall Aerospace
QA06305	Filter	Pall Aerospace
QA06306	Air Filter Manifold	Pall Aerospace
QA06415	Air Filter Manifold	Pall Aerospace
QA06854	Air Filter	Pall Aerospace
QA07146	Hydraulic Fluid Filter	Pall Aerospace
QA07146-01	Hydraulic Filter	Pall Aerospace
QA07236	Hydraulic Fluid Filter	Pall Aerospace
QA07237	Hydraulic Fluid Filter	Pall Aerospace
QA07242	Differential Pressure Switch	Pall Aerospace
QA07275	Hydraulic Fluid Filter	Pall Aerospace
QA07340	Pressure Reducing Valve	Pall Aerospace
QA07341	Air Filter Manifold	Pall Aerospace
QA07634	Pressure Reducing Valve	Pall Aerospace
QA07638	Clogging Indicator Xmtr	Pall Aerospace
QA07739	Reservoir Pressurisation Unit	Pall Aerospace
QB0217	Dust Nicotine Extractor	Pall Aerospace
QB0280	Air Cleaner	Pall Aerospace
QB0341	Air Cleaner	Pall Aerospace
QB0406-00	Housing Filter	Pall Aerospace
QB0407	Air Filter	Pall Aerospace
QB0407-00	Housing Filter	Pall Aerospace
QB0408-00	Filter Element	Pall Aerospace
QB0408-01	Filter Element	Pall Aerospace
QB0452	Vent Filter	Pall Aerospace
QB0553	Vent Filter	Pall Aerospace
QB0555	Vent Filter	Pall Aerospace
QB0639	Vent Filter	Pall Aerospace
QB280	Air Filter	Equipment Bay
QBQ508	Filter assy	Pall Aerospace
R1053M1	Autopilot Torque Limiter	Smiths Industries
R1053M17-1	Autopilot Torque Limiter	Smiths Industries
R1053M17-2	Autopilot Torque Limiter	Smiths Industries
R1053M18	Autopilot Torque Limiter	Smiths Industries

Repair_Capability_List_Excel

R1053M18-1	Autopilot Torque Limiter	Smiths Industries
R1053M18-2	Autopilot Torque Limiter	Smiths Industries
R1053M2	Autopilot Torque Limiter	Smiths Industries
R1053M2-1	Autopilot Torque Limiter	Smiths Industries
R1065-4	Gearbox assy	Plessey
R1065M1	Gearbox assy	Plessey
R1143M1-3	Gearbox assy	Plessey
R1143M1-4	Gearbox assy	Plessey
R1143M1-5	Gearbox assy	Plessey
R1143M1-6	Gearbox assy	Plessey
R1167	Speed Brake Control	Smiths Industries
R1409M10-1	Rotary Actuator	Plessey
R1409M12-1	Rotary Actuator	Plessey
R1409M13-1	Rotary Actuator	Plessey
R1409M5-11	Rotary Actuator	Plessey
R1409M5-111	Rotary Actuator	Plessey
R1409M5-111B	Rotary Actuator	Plessey
R1409M7-1	Actuator	Plessey
R1409M7-111	Actuator	Plessey
R1409M7-111B	Actuator	Plessey
R1409M9-1	Rotary Actuator	Plessey
R1419M12	Rotary Actuator	Smiths Industries
R1419M13	Rotary Actuator	Smiths Industries
R1419M14	Rotary Actuator	Plessey
R1631	Actuator	Plessey
R1631M1	Rotary Actuator	Plessey
R1631M1-1	Rotary Actuator	Plessey
R18423-2	ENGINE ISOLATOR	BARRY CTLS
R18423-49	ENGINE ISOLATOR	BARRY CTLS
R18424-2	ENGINE ISOLATOR	BARRY CTLS
R18424-50	ENGINE ISOLATOR	BARRY CTLS
R25-1-3	Top Beacon Lighting Wiring System	Logic Spa
R25-1M2AW	Anti-Collision Light	Logic Spa
R25-1M2BW	Anti-Collision Light	Logic Spa
R2703000500001	Pitch Control Bellcrank assy	Airbus Industrie
R4101-1	Rotary Actuator	Plessey
R4101-2	Rotary Actuator	Plessey
R4101-3	Rotary Actuator	Plessey
R5291	LINEAR ACTUATOR	PLESSEY
R5291-1	LINEAR ACTUATOR	PLESSEY
R5303-3	Actuator	Plessey
R5303-5	Actuator	Plessey
R5303-51	Actuator	Plessey
R5303M1	Actuator	Plessey
R5320	Linear Actuator	Plessey Dynamics
R5320-1	Linear Actuator	Smiths Industries
R5320-12	Linear Actuator	Smiths Industries
R5365-1	APU Door Actuator	Smiths Industries
R5365-2	APU Door Actuator	Smiths Industries
R5365-3	APU Door Actuator	Smiths Industries
R5366-4	Rudder Trim Linear Actuator	Smiths Industries
R5366-5	Rudder Trim Linear Actuator	Smiths Industries
R5366-6	Rudder Trim Linear Actuator	Smiths Industries
R5367M2-3	Elevator Feel Linear Actuator	Smiths Industries
R5367M2-4	Elevator Feel Linear Actuator	Smiths Industries
R5367M2-5	Elevator Feel Linear Actuator	Smiths Industries
R584M54	Linear Actuator	Smiths Industries
R6166M1	Actuator	Plessey

Repair_Capability_List_Excel

R6180-3	Actuator	Plessey
R6180M1	Actuator	Plessey
R6180M3	Actuator	Plessey
R6180M31	Actuator	Plessey
R6200M3-11	APU Door Actuator	Smiths Industries
R6200M3-12	APU Door Actuator	Smiths Industries
R6200M3-13	APU Door Actuator	Smiths Industries
R6200M6	Rotary Actuator	Plessey
R6200M7	Rotary Actuator	Plessey
R6206-5	Flap and Slat Electric Motor Unit	Smiths Industries
R6206-6	Flap and Slat Electric Motor Unit	Smiths Industries
R6206-7	Flap and Slat Electric Motor Unit	Smiths Industries
R6206-8	Flap and Slat Electric Motor Unit	Smiths Industries
R6357-501A	Controller	Teledyne Controls
R6357-505A	Controller	Teledyne Controls
R8755	APU Engine Starter	Smiths Industries
RC0200A00	Heater	Technofan
RC60ILB	Rate of Climb Indicator	Aerosonic
RC-60-VIL-1	VSI	Aerosonic Corp
RCF6701	HP Regulator Transmitter	Intertechnique
RCF6702	HP Regulator Transmitter	Intertechnique
RCF6703	OXY REG	INTERTECHNIQUE
RCF6704	OXY REG	INTERTECHNIQUE
RCF6705	Pressure Regulator Transmitter	Intertechnique
RCF6709	Oxygen Press Transmitter/Regulator	Eros
RCF6711	OXY REG	INTERTECHNIQUE
RCG8-03-01	Electronic Smoke Detection Box	Cerberus Guinard
RCG8-08-01	Electronic Smoke Detection Box	Cerberus Guinard
RCG8-11-01	Electronic Smoke Detection Box	Cerberus Guinard
RCG8-11-03	Electronic Smoke Detection Box	Cerberus Guinard
RCG9.10.01	Electronic Smoke Detection Box	Cerberus Guinard
RCG9-03-00	Electronic Smoke Detection Box	Cerberus Guinard
RCG9-03-01	Electronic Smoke Detection Box	Cerberus Guinard
RCG9-04-00	Electronic Smoke Detection Box	Cerberus Guinard
RCG9-04-01	Electronic Smoke Detection Box	Cerberus Guinard
RCG9-04-03	Electronic Smoke Detection Box	Cerberus Guinard
RCG9-08-00	Electronic Smoke Detection Box	Cerberus Guinard
RCG9-09-00	Electronic Smoke Detection Box	Cerberus Guinard
RCG9-09-01	Electronic Smoke Detection Box	Cerberus Guinard
RCG9-10-00	Electronic Smoke Detection Box	Cerberus Guinard
RCG9-10-01	Electronic Smoke Detection Box	Cerberus Guinard
RCG9-10-02	Electronic Smoke Detection Box	Cerberus Guinard
RCG9-10-03	Electronic Smoke Detection Box	Cerberus Guinard
RCG9-11-00	Electronic Smoke Detection Box	Cerberus Guinard
RCG9-11-01	Electronic Smoke Detection Box	Cerberus Guinard
RCG9-11-03	Electronic Smoke Detection Box	Cerberus Guinard
RCG9-11-04	Electronic Smoke Detection Box	Cerberus Guinard
RCG9-12-01	Electronic Smoke Detection Box	Cerberus Guinard
RCGSK10-00	Electronic Smoke Detection Box	Cerberus Guinard
RCGSK10-01	Electronic Smoke Detection Box	Cerberus Guinard
RCGSK10-02	Electronic Smoke Detection Box	Cerberus Guinard
RCGSK10-03	Electronic Smoke Detection Box	Cerberus Guinard
RCGSK10-04	Electronic Smoke Detection Box	Cerberus Guinard
RCGSK10-05	Electronic Smoke Detection Box	Cerberus Guinard
RDAM8001A	Electric Chime	Panasonic
RDAM8303	Cockpit Speaker	Panasonic
RDAM8303-01	Cockpit Speaker	Panasonic
RDAM8304	Cockpit Speaker	Panasonic

Repair_Capability_List_Excel

RG1017AA01	Load Select Control ay	Honeywell
RG1017AA02	Load Select Control ay	Honeywell
RL102ACRBU2	Pressure Indicator	Smiths Industries
RL22FYB3YS10006	Cabin Attendant Seat	Sicma Aero Seat
RL22FYF4YS00008	Cabin Attendant Seat	Sicma Aero Seat
RL27FYB3YS00014	Cabin Attendant Seat	Sicma Aero Seat
RL27FYB3YS00041	Cabin Attendant Seat	Sicma Aero Seat
RL27FYB3YS10006	Cabin Attendant Seat	Sicma Aero Seat
RL501-CUFF-FA-4	Mode Selector	Smiths Industries
RP109-00	Wing Anti-Ice Resistor Sensor	Auxitrol
RP109-01	Wing Anti-Ice Resistor Sensor	Auxitrol
RP154-00	Temperature Sensor	Auxitrol
RPP137-1-A	Water Level Preselection Control Unit	Telefunken
RPS1B	Battery Power Supply	Bruce Industrie
RR12550A	Pump	Lear Romec
RR12551A	Pump	Lear Romec
RR34150F	PUMP	LEAR SINGLER INC
RR34150G	PUMP	LEAR SINGLER INC
RR34150H	PUMP	LEAR SINGLER INC
RR34150K	PUMP	LEAR SINGLER INC
RR34150L	PUMP	LEAR SINGLER INC
RR37100	Lube and Scavenge Pump	Lear Romec
RR37100A	Lube and Scavenge Pump	Lear Romec
RR37100B	Lube and Scavenge Pump	Lear Romec
RR37100D	Lube and Scavenge Pump	Lear Romec
RV99-162	Thermal Relief Valve	Circle Seal Controls
RV99-199	Thermal Relief Valve	Circle Seal Controls
RV99-29-1	Thermal Relief Valve	Circle Seal Controls
RV99-29-2	Thermal Relief Valve	Circle Seal Controls
RYLB52192-2	Pressure Regulated Anti-Ice Valve	Smiths Industries
RYLB52192-3	Pressure Regulated Anti-Ice Valve	Smiths Industries
RYLB52192-4	Pressure Regulated Anti-Ice Valve	Smiths Industries
S104-3	Volt/Amperemeter	Weston
S104-3-131	Aieron Trim Indicator	Weston
S104-3-150	Aieron Trim Indicator	Weston
S-110 FORM 50	Bulb Resistance	Weston Aerospace
S110-50-911	Resistance Thermometer	Weston
S122A12-00	Transmitter	Thales Avionics
S122Z12-02	Transmitter	Thales Avionics
S127-5-152	Oil Temperature Indicator	Weston
S127-5-153	Oil Temperature Indicator	Weston
S127-5-160	Oil Temperature Indicator	Weston
S127-5-180	Oil Temperature Indicator	Weston
S127-5-189	Oil Temperature Indicator	Weston
S127-5-189K	Oil Temperature Indicator	Weston
S127-5-193	Oil Temperature Indicator	Weston
S127-5-193K	Oil Temperature Indicator	Weston
S127-5-199	Oil Temperature Indicator	Weston
S127-5-72	Oil Temperature Indicator	Weston
S127-5-73	Oil Pressure Indicator	Weston
S127-5-83	Oil Temperature Indicator	Weston
S1821502-02	Emergency Locator Xmtr	Thales Avionics
S218-5-110	Jet Pipe Temperature Indicator	Weston
S218-5-14	Jet Pipe Temperature Indicator	Weston
S218-5-14T	Jet Pipe Temperature Indicator	Weston
S218-5-26	Jet Pipe Temperature Indicator	Weston
S218-5-26T	Jet Pipe Temperature Indicator	Weston
S252T105-10	CTL ACTUATOR ASSY	MOOG

Repair_Capability_List_Excel

S252T105-11	CTL ACTUATOR ASSY	MOOG
S252T105-2	CTL ACTUATOR ASSY	MOOG
S252T105-3	CTL ACTUATOR ASSY	MOOG
S252T105-4	CTL ACTUATOR ASSY	MOOG
S252T105-5	CTL ACTUATOR ASSY	MOOG
S252T105-6	CTL ACTUATOR ASSY	MOOG
S252T105-7	CTL ACTUATOR ASSY	MOOG
S252T105-8	CTL ACTUATOR ASSY	MOOG
S252T105-9	CTL ACTUATOR ASSY	MOOG
S270T002-3	Valve assy	Whittaker
S28C1	Pressure Relief Valve	SAMM
S315N370-1	Synchro Shaft Lock	Goodrich Control Systems
S315N370-2	Synchro Shaft Lock	Goodrich Control Systems
S315N370-3	Synchro Shaft Lock	Goodrich Control Systems
S315T360-28	Thrust Reverse Actuator	Parker Hannifin
S315T360-29	Thrust Reverse Actuator	Parker Hannifin
S315T360-30	Thrust Reverse Actuator	Parker Hannifin
S315T360-31	Thrust Reverse Actuator	Parker Hannifin
S315T360-34	Thrust Reverse Actuator	Parker Hannifin
S315T360-39	Thrust Reverse Actuator	Parker Hannifin
S315T360-40	Thrust Reverse Actuator	Parker Hannifin
S315T360-41	Thrust Reverse Actuator	Parker Hannifin
S315T360-43	Thrust Reverse Actuator	Parker Hannifin
S315T360-44	Thrust Reverse Actuator	Parker Hannifin
S315T360-47	Thrust Reverse Actuator	Parker Hannifin
S315T360-49	Thrust Reverse Actuator	Parker Hannifin
S315T360-50	Thrust Reverse Actuator	Parker Hannifin
S315T360-51	Thrust Reverse Actuator	Parker Hannifin
S315T360-52	Thrust Reverse Actuator	Parker Hannifin
S315T360-53	Thrust Reverse Actuator	Parker Hannifin
S315W363-1	Hydraulic Power Unit	Goodrich Control Systems
S315W363-10	Fan Cowl Actuator	Goodrich Control Systems
S315W363-11	Hydraulic Power Unit	Goodrich Control Systems
S315W363-12	Hydraulic Power Unit	Goodrich Control Systems
S315W363-13	Fan Cowl Actuator	Goodrich Control Systems
S315W363-14	Fan Cowl Actuator	Goodrich Control Systems
S315W363-15	Fan Cowl Actuator	Goodrich Control Systems
S315W363-16	Fan Cowl Actuator	Goodrich Control Systems
S315W363-17	Fan Cowl Actuator	Goodrich Control Systems
S315W363-4	Fan Cowl Actuator	Goodrich Control Systems
S315W363-6	Fan Cowl Actuator	Goodrich Control Systems
S315W363-9	Fan Cowl Actuator	Goodrich Control Systems
S332T004-2	Differential Pressure Switch	Boeing
S332T004-35	Differential Pressure Switch	Boeing
S332T004-36	Differential Pressure Switch	Boeing
S3550-3	Valve assy	Sangamoweston
S3919	Union Filter	Bronzavia-Air Equipement
S3922	Union Filter	Bronzavia-Air Equipement
S3983	Motor	Liebherr Aerospace
S412SB01	Non-Return Valve	Goodrich Control Systems
S417N440-1	OXY FILL VALVE	CARLETON
S417N440-2	OXY FILL VALVE	CARLETON
S417N440-3	OXY FILL VALVE	CARLETON
S417N440-4	OXY FILL VALVE	CARLETON
S417N440-7	OXY FILL VALVE	CARLETON
S417N440-8	OXY FILL VALVE	CARLETON
S4-3000460	Spoiler Servocontrol Actuator	Liebherr Aerotechnik
S4-3000460-01	Spoiler Servocontrol Actuator	Liebherr Aerotechnik

Repair_Capability_List_Excel

S4-3000460-02	Spoiler Servocontrol Actuator	Liebherr Aerotechnik
S4-3000460-03	Spoiler Servocontrol Actuator	Liebherr Aerotechnik
S4-3000470	Spoiler Servocontrol Actuator	Liebherr Aerotechnik
S4-3000470-01	Spoiler Servocontrol Actuator	Liebherr Aerotechnik
S4-3000470-02	Spoiler Servocontrol Actuator	Liebherr Aerotechnik
S4-3000470-03	Spoiler Servocontrol Actuator	Liebherr Aerotechnik
S4-3300346	Cargo Door Jack	Liebherr Aerotechnik
S4-3300346-01	Cargo Door Jack	Liebherr Aerotechnik
S4-3300346-02	Cargo Door Jack	Liebherr Aerotechnik
S4-3300520	Hydraulic Actuator	Liebherr Aerotechnik
S4-3300520-01	Hydraulic Actuator	Liebherr Aerotechnik
S4-3300520-01 Amdt A	Hydraulic Actuator	Liebherr Aerotechnik
S4-3300520-02	Hydraulic Actuator	Liebherr Aerotechnik
S4-3300520-1	Actuator	Feinmechanische
S4-3300930-01	MLG Door Actuator	Liebherr Aerotechnik
S4-3300930-02	MLG Door Actuator	Liebherr Aerotechnik
S4-3300935	MLG Door Actuator	Liebherr Aerotechnik
S4-3300940	CLG Door Actuator	Liebherr Aerotechnik
S4-3300945	CLG Door Actuator	Liebherr Aerotechnik
S4-3300950-01	NLG Door Actuator	Liebherr Aerotechnik
S4-3300950-02	NLG Door Actuator	Liebherr Aerotechnik
S4-3300955	NLG Door Actuator	Liebherr Aerotechnik
S4-3300960-02	Actuator	Feinmechanische
S4-3301120	RAT Actuator	Liebherr Aerotechnik
S4-3301120-02	RAT Actuator	Liebherr Aerotechnik
S4-3301120-03	RAT Actuator	Liebherr Aerotechnik
S4-3301350	Actuator	Liebherr Aerotechnik
S4-3301370	Actuator	Liebherr Aerotechnik
S4-3400900	Selector Valve	Liebherr Aerotechnik
S4-3400900-01	Selector Valve	Liebherr Aerotechnik
S4-3400920-02	2/2 Way Valve	Liebherr Aerotechnik
S4-3400920-03	2/2 Way Valve	Liebherr Aerotechnik
S4-3400920-03 Amdt A	2/2 Way Valve	Liebherr Aerotechnik
S4-3400920-03 Amdt B	2/2 Way Valve	Liebherr Aerotechnik
S4-3400920-03 Amdt C	2/2 Way Valve	Liebherr Aerotechnik
S4-3400950-03	3/2 Way Valve	Liebherr Aerotechnik
S4-3400950-04	3/2 Way Valve	Liebherr Aerotechnik
S4-3400950-05	3/2 Way Valve	Liebherr Aerotechnik
S4-3400950-06	3/2 Way Valve	Liebherr Aerotechnik
S4-3401072-01	Valve assy	Liebherr Aerotechnik
S4-3401310-03	Safety Valve	Liebherr Aerotechnik
S4-3401310-04	Safety Valve	Liebherr Aerotechnik
S4-3401510	Valve assy	Feinmechanische
S4-3401510-01	Valve assy	Feinmechanische
S4-3401610	3/2 Way Valve	Liebherr Aerotechnik
S4-3401610-01	3/2 Way Valve	Liebherr Aerotechnik
S4-3402180	Electro Selector Valve	Liebherr Aerotechnik
S4-3402230-01	Main Selector Valve	Liebherr Aerotechnik
S4-3500272	Ground Service Manifold	Liebherr Aerotechnik
S4-3500603	RAT Manifold assy	Liebherr Aerotechnik
S4-3500603-01	RAT Manifold assy	Liebherr Aerotechnik
S4-3500711	Ground Service Manifold	Liebherr Aerotechnik
S4-3500712	Ground Service Manifold	Liebherr Aerotechnik
S4-350071L	Ground Service Manifold	Liebherr Aerotechnik
S4-4500271	RAT Spring Strut	Liebherr Aerotechnik
S-458 FORM 2	Indicator	Weston Aerospace
S458-2-134	Indicator	Weston Aerospace
S-458-2-134	Indicator	Weston Aerospace

Repair_Capability_List_Excel

S458-2-134T	Hydraulic Quantity Indicator	Weston
S458-2-135	Hydraulic Quantity Indicator	Weston
S458-2-135T	Hydraulic Quantity Indicator	Weston
S458-2-80	Hydraulic Quantity Indicator	Weston
S458-2-81	Hydraulic Quantity Indicator	Weston
S-483 FORM 2	Indicator	Weston Aerospace
S-483 FORM1	Indicator	Weston Aerospace
S483-1-16	Outside Air Temperature Indicator	Weston
S-483-1-16	Temperature Indicator	Weston Aerospace
S483-1-16U	Outside Air Temperature Indicator	Weston
S483-1-16Y	Outside Air Temperature Indicator	Weston
S483-1-17	Oil Temperature Indicator	Weston
S483-1-17R	Oil Temperature Indicator	Weston
S483-1-17U	Oil Temperature Indicator	Weston
S483-1-17Y	Oil Temperature Indicator	Weston
S483-1-18	Fuel Temperature Indicator	Weston
S-483-1-18	Temperature Indicator	Weston Aerospace
S483-1-18U	Fuel Temperature Indicator	Weston
S483-1-18V	Temperature Indicator	Sangamoweston
S-483-1-18V	Temperature Indicator	Weston Aerospace
S483-1-18Y	Fuel Temperature Indicator	Weston
S483-1-19	Air Duct Temperature Indicator	Weston
S-483-1-19	Temperature Indicator	Weston Aerospace
S483-1-19R	Air Duct Temperature Indicator	Weston
S483-1-19Y	Air Duct Temperature Indicator	Weston
S483-1-20	Cabin Air Temperature Indicator	Weston
S-483-1-20	Temperature Indicator	Weston Aerospace
S483-1-20R	Cabin Air Temperature Indicator	Weston
S483-1-20Y	Cabin Air Temperature Indicator	Weston
S483-1-21	Oil Temperature Indicator	Weston
S483-1-22	Anti-Icing Temperature Indicator	Weston
S483-1-27	Oil Temperature Indicator	Weston
S483-1-33	Oil Temperature Indicator	Weston
S483-1-48	Anti-Icing Temperature Indicator	Weston
S-483-1-48	Temperature Indicator	Weston Aerospace
S483-1-48R	Anti-Icing Temperature Indicator	Weston
S483-1-48U	Anti-Icing Temperature Indicator	Weston
S483-1-48Y	Anti-Icing Temperature Indicator	Weston
S483-2-23	Hydraulic Quantity Indicator	Weston
S483-2-23R	Hydraulic Quantity Indicator	Weston
S483-2-24	RPM Indicator	Sangamoweston
S-483-2-24	RPM Indicator	Weston Aerospace
S483-2-24R	APU RPM Indicator	Weston
S483-2-25	AOA Indicator	Weston
S483-2-25R	AOA Indicator	Weston
S483-2-28	Hydraulic Quantity Indicator	Weston
S483-2-28R	Hydraulic Quantity Indicator	Weston
S483-2-44	Hydraulic Quantity Indicator	Weston
S483-2-44R	Hydraulic Quantity Indicator	Weston
S483-2-45	Indicator	Sangamoweston
S-483-2-45	Indicator	Weston Aerospace
S483-2-45R	Hydraulic Quantity Indicator	Weston
S483-2-46	AOA Indicator	Weston
S483-2-46R	AOA Indicator	Weston
S483-2-61	AOA Indicator	Weston
S483-2-62	AOA Indicator	Weston
S483-2-62R	AOA Indicator	Weston
S-483-44	Hydraulic Quantity Indicator	Weston Aerospace

Repair_Capability_List_Excel

S-483-45	Hydraulic Quantity Indicator	Weston Aerospace
S527-4-31	Thermocouple	Weston Aerospace
S546-3-532	Hydraulic Quantity Indicator	Weston
S546-3-565	Hydraulic Quantity Indicator	Weston
S546-3-566	Hydraulic Quantity Indicator	Weston
S546-3-597	Hydraulic Quantity Indicator	Weston
S546-3-676	Hydraulic Quantity Indicator	Weston
S546-3-677	Hydraulic Quantity Indicator	Weston
S548-2-135	Hydraulic Quantity Indicator	Weston Aerospace
S6025-2	Valve	Sargent
S6216	Socket	Leach International
S63-4-1717	Outside Air Temperature Indicator	Weston
S63-4-687	Electrical Thermometer	Weston
S63-4-929	Outside Air Temperature Indicator	Weston
S63-4-989	Electrical Thermometer	Weston
S64-5-140	Jet Pipe Temperature Indicator	Weston
S64-5-241	Jet Pipe Temperature Indicator	Weston
S64-5-256	Jet Pipe Temperature Indicator	Weston
S64-5-257	Jet Pipe Temperature Indicator	Weston
S673U001-1	Synchro Shaft Lock	Goodrich Control Systems
S673U001-2	Synchro Shaft Lock	Goodrich Control Systems
S700H0389-55	Hose assy	Aeroquip
S700H0389-57	Hose assy	Aeroquip
SA02202	Starter Motor Contactor	Goodrich
SA02210	Contactor	Goodrich
SA02217	Contactor	Goodrich
SA03203	Contactor	Goodrich
SA03215	Contactor	Goodrich
SA03506	Contactor	Goodrich
SAS911-001A	Anti-ice Valve	Hymatic Engineering
SAS911-002A	Anti-Ice Valve	Hymatic Engineering
SAS912-002A	Wing Anti-Ice Control Valve	Hymatic Engineering
SAT275 A	Sound Reducer	Technofan
SB09270274-11	Spoiler Actuator	Douglas
SB09270274-13	Spoiler Actuator	Douglas
SB09270274-15	Spoiler Actuator	Douglas
SB09270274-17	Spoiler Actuator	Douglas
SB09270274-3	Spoiler Actuator	Douglas
SB09270274-5	Spoiler Actuator	Douglas
SB09270274-7	Spoiler Actuator	Douglas
SB09270274-9	Spoiler Actuator	Douglas
SB09270301-53	Rudder Actuator	Douglas
SB09270301-57	Rudder Actuator	Douglas
SB09270301-59	Rudder Actuator	Douglas
SB09270301-63	Rudder Actuator	Douglas
SB09270301-65	Rudder Actuator	Douglas
SB09270301-67	Rudder Actuator	Douglas
SB10270208-11	Valve assy	Douglas
SB10270208-15	Valve assy	Douglas
SB10270208-23	Valve assy	Douglas
SB10270208-5	Valve assy	Douglas
SB10270208-7	Valve assy	Douglas
SB209L1A1-1480	Accumulator	Hydac
SB209L1A1-1481	Accumulator	Hydac
SB209L1A1-1482	Hydraulic Accumulator	Hydac
SB209L1A1-1483	Accumulator	Hydac
SB209L1A1-1484	Accumulator	Hydac
SC4110A	Servocontrol	Goodrich Control Systems

Repair_Capability_List_Excel

SC4110B	Servocontrol	Goodrich Control Systems
SC4110D	Inner Airbrake Servocontrol	Goodrich Control Systems
SEDL-OC7E	Brake Pressure Indicator	Ametek
SEDL-OC7P	Hydraulic Brake Press Indicator	Ametek
SEDL-OC9A	Dual Duct Pressure Indicator	Ametek
SEDL-OC9B	Dual Duct Pressure Indicator	Ametek
SEDL-OC9C	Dual Duct Pressure Indicator	Ametek
SEL-0C3F	Pressure Gage	Ametek
SEL-0C3G	Pressure Gage	Ametek
SEL-0C3H	Pressure Gage	Ametek
SEL-0C3J	Pressure Gage	Ametek
SEL-OC12D	Flap Position Indicator	Ametek
SEL-OC19ES	Inner Turbine Temperature Indicator	Ametek
SEL-OC29DY	NH % RPM Indicator	Ametek
SEL-OC29EC	NH % RPM Indicator	Ametek
SEL-OC29ED	NL % RPM Indicator	Ametek
SETL-OC420H	Cabin Pressure Indicator	Ametek
SETL-OC420J	Cabin Pressure Indicator	Ametek
SETL-OC420L	Cabin Pressure Indicator	Ametek
SETL-OC420M	Cabin Pressure Indicator	Ametek
SETL-OC420P	Cabin Pressure Indicator	Ametek
SETL-OC420R	Cabin Pressure Indicator	Ametek
SF0090	Tube assy	Le Bozec
SG02206	Contactora	Goodrich
SG02213	Contactora	Goodrich
SG02217	Contactora	Goodrich
SL3924AA01	Decoder	Thales Avionics
SLZ9464A1	Vertical Speed Indicator	Teledyne
SM400D11	Relay	Eaton
SM601BA10A11	Remote Cockpit Breaker	Cutler-Hammer
SNC16	Corrector Unit	Ultra Electronics
SP-101	Indicator	Keystone
SP-103	Indicator	Keystone
SP2930A	Transformer	BIP
SP2979F	Lighting Controller	BIP
SP2979G	Lighting Controller	BIP
SP2985	Light Unit	BIP
SP2985A	Light Unit	BIP
SP2985B	Light Unit	BIP
SP3000C	Lighting Controller	BIP
SP3000D	Lighting Controller	BIP
SP3062	Transformer Rectifier	BIP
SPS-1607A	Inverter	KGS Electronics
SR09270026-5	Manifold Valve	Douglas
SR09320057-7001	Hydraulic Damper	Douglas
SR09320057-7005	Hydraulic Damper	Douglas
SR09320057-7009	Hydraulic Damper	Douglas
SR104-00	Flexible Drive Shaft	Auxitrol
SRDL-OC12D	Dual Flap Position Indicator	Ametek
SRDL-OC12G	Flap Position Indicator	Ametek
SRDL-OC12H	Flap Position Indicator	Ametek
SRL-027A	Pressure Indicator	Ametek
ST0109C	Pressure Transducer	Ametek
ST-104A	Transmitter	Ametek
ST-104Z	Pressure Transmitter	Ametek
ST107Q	Transmitter	Ametek
ST-107Q	Hydraulic Pressure Transmitter	Ametek
ST-12AE	Position Transmitter	Ametek

Repair_Capability_List_Excel

ST-12AF	Flap Position Indicator	Ametek
ST-12AF-1	Flap Position Transmitter	Ametek
ST-12BH	Flap Position Transmitter	Ametek
ST3100-20-01	Handset	Becker Flug
ST3100-20-02	Handset	Becker Flug
ST3100-21-10	Handset	Becker Flug
ST3100-21-11	Handset	Becker Flug
ST3100-22-10	Handset	Becker Flug
ST3100-23-10	Handset	Becker Flug
ST3100-30-01	Handset	Becker Flug
ST3100-33-10	Handset	Becker Flug
ST-3E	Transmitter	Ametek
ST-506A	Pressure Transducer	Ametek
ST-509A	Pressure Transmitter	Ametek
ST-9A	Transmitter	Ametek
ST-9E	Transmitter	Ametek
ST-O109A-3	Differential Pressure Transmitter	Ametek
T2714-01A	DRAIN VALVE	GENERAL ELECTRIC
T89-2C600	Overheat Thermostat	Auxitrol
T89-2C601	Overheat Thermostat	Auxitrol
T89-2C602	Overheat Thermostat	Auxitrol
T89-2CG00	Overheat Thermal Switch	Auxitrol
T89-2CG01	Overheat Thermal Switch	Auxitrol
T89-2CG02	Overheat Thermal Switch	Auxitrol
T99A38-601	Primary Ejector	Intertechnique
T99B19-602	Aft Scavenge Ejector	Intertechnique
T99B38-601	Transfer Ejector	Intertechnique
T99B38-602	Fwd Scavenge Ejector	Intertechnique
TA01Z6005	Transformer	Artus
TAA11-03CE00-01	Powered Copilot Seat	EADS Sogerma
TAA11-03CE01-01	Powered Copilot Seat	EADS Sogerma
TAA11-03CM00-01	Mechanical Pilot Seat	EADS Sogerma
TAA11-03PE00-01	Powered Pilot Seat	EADS Sogerma
TAA11-03PM00-01	Mechanical Pilot Seat	EADS Sogerma
TAA12-33CE00-01	First Officer Seat	EADS Sogerma
TAA12-33CE01-01	First Officer Seat	EADS Sogerma
TAA12-33PE00-01	Captain Seat	EADS Sogerma
TAA12-33PE01-01	Captain Seat	EADS Sogerma
TC201-00	Oil Temperature Sensor	Auxitrol
TD1721-1001	Time Delay Relay	LRE
TD1721-1002	Time Delay Relay	LRE
TD1721-2000	Time Delay Relay	LRE
TD1721-2001	Time Delay Relay	LRE
TD1721-2002	Time Delay Relay	LRE
TD1721-3001	Time Delay Relay	LRE
TD1721-3500	Time Delay Relay	LRE
TD1721-5001	Time Delay Relay	LRE
TD1721-5002	Time Delay Relay	LRE
TD1721-6501	Time Delay Relay	LRE
TD1721-7001	Time Delay Relay	LRE
TD1721-9002	Time Delay Relay	LRE
TDF27333	Rod assy	Sarma
TDF27356	Rod assy	Sarma
TDF27360	Rod assy	Sarma
TDF27361	Rod assy	Sarma
TDF27363	Rod assy	Sarma
TF6F880	Flexible Drive Shaft	ECE
TGP36-1	Transformer Rectifier Unit	Extel Systems Wedel

Repair_Capability_List_Excel

TL1373B	Transformer	SFIM
TL140L4000	Cable assy	Morse Teleflex
TLH460L120	Sliding End	Morse Teleflex
TM113	Transducer & Switch Temperature	VDO
TM113-1	Transducer & Switch Temperature	VDO
TM512-202	HYD PRESS XMTR	FAURE HERMAN
TM512-204	Fuel Flow Transmitter	Faure Herman
TP0710007	Pressure Switch	Howden Wade
TP0710010	Pressure Switch	Howden Wade
TP0710012	Pressure Switch	Howden Wade
TP0710014	Pressure Switch	Howden Wade
TP0714033	Pressure Switch	Howden Wade
TR4430	Sensor	Thales Avionics
TRA72-20	Smoke Detector	Cerberus Guinard
TRA73-60	Smoke Detector Control Unit	Cerberus Guinard
TRH644ALM3-90	Wave Guide Fitting	.
TSG420-101	Static Inverter	Thales Avionics
TSG420-102	Static Inverter	Thales Avionics
TSG420-103	Static Inverter	Thales Avionics
TT1850C	Temperature Sensor	Technofan
TY1346-03A	Check Valve	Goodrich Control Systems
TY1346-04A	Check Valve	Goodrich Control Systems
TY1359-01A	Slat Friction Brakes	Goodrich Control Systems
TY1359-01B	Slat Friction Brakes	Goodrich Control Systems
TY1360-01A	Slat Friction Brakes	Goodrich Control Systems
TY1360-01B	Slat Friction Brakes	Goodrich Control Systems
TY1361-01A	Downdrive Gearbox	Goodrich Control Systems
TY1361-02A	Downdrive Gearbox	Goodrich Control Systems
TY1361-02B	Downdrive Gearbox	Goodrich Control Systems
TY1362-01A	Downdrive Gearbox	Goodrich Control Systems
TY1362-02A	Downdrive Gearbox	Goodrich Control Systems
TY1362-02B	Downdrive Gearbox	Goodrich Control Systems
TY1540-23A	Hydraulic Control Unit	Goodrich Control Systems
TY1540-24A	Hydraulic Control Unit	Goodrich Control Systems
TY1540-24B	Hydraulic Control Unit	Goodrich Control Systems
TY1540-24C	Hydraulic Control Unit	Goodrich Control Systems
TY1541-22	Non-Locking Actuator	Goodrich Control Systems
TY1541-50	Non-Locking Actuator	Goodrich Control Systems
TY1542-22	Locking Actuator	Goodrich
TY1542-50	Locking Actuator	Goodrich
TY1544-20	Hand Wind assy	Goodrich
TY1558	AIR VALVE	LUCAS AEROSPACE
TY1558-51	Air Modulating Valve	Goodrich Control Systems
TY1558-52A	Air Modulating Valve	Goodrich Control Systems
TY1558-52B	Air Modulating Valve	Goodrich Control Systems
TY1558-52C	Air Modulating Valve	Goodrich Control Systems
TY1628-01	Hydraulic Control Unit	Goodrich
TY1628-02	Hydraulic Control Unit	Goodrich
TY1628-03	Hydraulic Control Unit	Goodrich
TY1628-04	Hydraulic Control Unit	Goodrich
TY1629-06	Synchronised Non-Locking Actuator	Goodrich
TY1629-07	Synchronised Non-Locking Actuator	Goodrich
TY1629-10	Synchronised Non-Locking Actuator	Goodrich
TY1629-15	Synchronised Non-Locking Actuator	Goodrich
TY1629-20	Synchronised Non-Locking Actuator	Goodrich
TY1629-50	Synchronised Non-Locking Actuator	Goodrich
TY1631-02	Dual Tee Piece	Goodrich
TY1632-02	Thrust Reverser Transmission	Goodrich

Repair_Capability_List_Excel

TY1633-01	Thrust Reverser Transmission	Goodrich
TY1634-02	Manual Drive	Goodrich
TY1634-03	Manual Drive	Goodrich
TY1635-01	Thrust Reverser Transmission	Goodrich
TY1716-52	Air Oil Heat Exchanger	Goodrich
TY1716-53	Air Oil Heat Exchanger	Goodrich
TY1716-54	Air Oil Heat Exchanger	Goodrich
TY1724-20	Thrust Reverser Actuator	Goodrich
TY1724-50	Thrust Reverser Actuator	Goodrich
TY1727-20	C-Duct Actuator	Goodrich
TY1728-20A	C-Duct Manifold	Goodrich
TY1728-50A	C-Duct Manifold	Goodrich
TY1755-51	Air Cooled Air Cooler	Goodrich
TY1755-52	Air Cooled Air Cooler	Goodrich
TY1755-53	Air Cooled Air Cooler	Goodrich
TY1795-07	Air Modulating Valve	Goodrich Control Systems
TY1795-51	Air Modulating Valve	Goodrich Control Systems
TY1795-52	Air Modulating Valve	Goodrich Control Systems
TY1795-53	Air Modulating Valve	Goodrich Control Systems
TY1801-03	Inner Actuator	Goodrich
TY1801-50	Inner Actuator	Goodrich
TY1802-03	Outer Locking Actuator	Goodrich
TY1802-04	Outer Locking Actuator	Goodrich
TY1802-50	Outer Locking Actuator	Goodrich
TY1805-02	Hydraulic Control Unit	Goodrich
TY1878-20	Synchro Shaft Lock	Goodrich Control Systems
TY1878-21A	Synchro Shaft Lock	Goodrich Control Systems
TY1878-21B	Synchro Shaft Lock	Goodrich Control Systems
TY1878-21C	Synchro Shaft Lock	Goodrich Control Systems
TY1878-22A	Synchro Shaft Lock	Goodrich Control Systems
TY1882-03	Hold Open Rod	Goodrich
TY1882-04	Hold Open Rod	Goodrich
TY1898-50	Fan Cowl Actuator	Goodrich Control Systems
TY1898-51	Fan Cowl Actuator	Goodrich Control Systems
TY1899-01	Fan Cowl Actuator	Goodrich Control Systems
TY1899-51	Fan Cowl Actuator	Goodrich Control Systems
TY1900-01	Fan Cowl Actuator	Goodrich Control Systems
TY1900-51	Fan Cowl Actuator	Goodrich Control Systems
TY1901-02	Fan Cowl Actuator	Goodrich Control Systems
TY1901-51	Fan Cowl Actuator	Goodrich Control Systems
TY1904-50	Fan Cowl Actuator	Goodrich Control Systems
TY1905-01	Hydraulic Power Unit	Goodrich Control Systems
TY1906-50	Hydraulic Power Unit	Goodrich Control Systems
TY1907-50	Hydraulic Power Unit	Goodrich Control Systems
TY1914-02	Handwind	Goodrich
TY1916-02	Direction Control Unit	Goodrich
TY1917-20A	Primary Door Lock	Goodrich
TY1917-20B	Primary Door Lock	Goodrich
TY2013-02	Hydraulic Control Unit	Goodrich Control Systems
TY2013-03	Hydraulic Control Unit	Goodrich Control Systems
TY2013-05	Hydraulic Control Unit	Goodrich Control Systems
TY2013-10	Hydraulic Control Unit	Goodrich Control Systems
TY2037-2A	Tertiary Lock	Goodrich Control Systems
TY2038-1A	Primary Door Lock Actuator	Goodrich Control Systems
TY2038-2A	Primary Door Lock Actuator	Goodrich Control Systems
TY2039-03B	Pivot Door Actuator	Goodrich Control Systems
TY2039-03C	Pivot Door Actuator	Goodrich Control Systems
TY2039-05B	Pivot Door Actuator	Goodrich Control Systems

Repair_Capability_List_Excel

TY2039-10A	Pivot Door Actuator	Goodrich Control Systems
TY2039-11A	Pivot Door Actuator	Goodrich Control Systems
TY2040-01A	Direction Control Unit	Goodrich Control Systems
TY2041-02B	Isolation Control Unit	Goodrich Control Systems
TY2044-20A	Tertiary Lock	Goodrich
TY2044-21A	Tertiary Lock	Goodrich
TY2044-30A	Tertiary Lock	Goodrich
TY2044-50A	Tertiary Lock	Goodrich
TY2044-51A	Tertiary Lock	Goodrich
TY2047-02A	Lock Sequencer	Goodrich Control Systems
TY2047-03A	Lock Sequencer	Goodrich Control Systems
TY2080-20	Synchro Shaft Lock	Goodrich Control Systems
TY2082-01	Thrust Reverser Transmission	Goodrich
TY2083-01	Thrust Reverser Transmission	Goodrich
TY2084-01	Thrust Reverser Transmission	Goodrich
TY2085-01	Thrust Reverser Transmission	Goodrich
TY2086-01	Thrust Reverser Transmission	Goodrich
TY2087-01	Tee Piece	Goodrich
TY2091-01	Primary Door Latch	Goodrich Control Systems
TY2092-01	Hydraulic Control Unit	Goodrich Control Systems
TY2092-12	Hydraulic Control Unit	Goodrich Control Systems
TY2092-21	Hydraulic Control Unit	Goodrich Control Systems
TY2092-22	Hydraulic Control Unit	Goodrich Control Systems
TY2095-20	Synchro Shaft Lock	Goodrich Control Systems
TY2138-01A	Tertiary Lock	Goodrich Control Systems
TY2518-01A	Synchronizing Shaft Lock	Goodrich
TY2630-06	Synchronised Non-Locking Actuator	Goodrich
TY2630-07	Synchronised Non-Locking Actuator	Goodrich
TY2630-10	Synchronised Non-Locking Actuator	Goodrich
TY2630-14	Synchronised Non-Locking Actuator	Goodrich
TY2630-15	Synchronised Non-Locking Actuator	Goodrich
TY2630-16	Synchronised Non-Locking Actuator	Goodrich
TY2630-17	Synchronised Non-Locking Actuator	Goodrich
TY2630-18	Synchronised Non-Locking Actuator	Goodrich
TY2630-20	Synchronised Non-Locking Actuator	Goodrich
TY2630-50	Synchronised Non-Locking Actuator	Goodrich
TY2915-20	Isolation Control Unit	Goodrich
TY2915-21	Isolation Control Unit	Goodrich
TY2915-50	Isolation Control Unit	Goodrich
U144CC01A02	APU Starting Contactor	ECE
UA538342-2	IDG Fuel/Oil Heat Exchanger	Parker Hannifin
UA538728-1	IDG Fuel/Oil Heat Exchanger	Parker Hannifin
UA538950-3	Servo Fuel/Oil Heat Exchanger	Parker Hannifin
UA538950-4	Servo Fuel/Oil Heat Exchanger	Parker Hannifin
UA538950-7	Servo Fuel/Oil Heat Exchanger	Parker Hannifin
UI-6000T	Pressure Manifold	Hamilton Standard
UI-6020T	Pressure Manifold	Hamilton Standard
UI-6040T	Pressure Indicator	Hamilton Standard
UI-6060T	Pressure Indicator	Hamilton Standard
UI-6080	Pressure Indicator	Hamilton Standard
UL8	RAT Uplock assy	Dowty Rotol
V1-4360	MLG Fuse	Circle Seal Controls
V1-4360-1	MLG Fuse	Circle Seal Controls
V1-4360-2	MLG Fuse	Circle Seal Controls
V1AM0	Actuator	Thales Avionics
V2-4360	MLG Fuse	Circle Seal Controls
V2-4360-1	MLG Fuse	Circle Seal Controls
V2-4360-2	MLG Fuse	Circle Seal Controls

Repair_Capability_List_Excel

V2AM0	Actuator	Thales Avionics
V2T125-1	Isolation Vent. Valve	Technofan
V2T125-2	Isolation Vent. Valve	Technofan
V2T127B	Air Butterfly Valve	Technofan
V2T127D	Air Butterfly Valve	Technofan
V2T152B	Air Butterfly Valve	Technofan
V2T152D	Air Butterfly Valve	Technofan
V308	Clock	Smiths Industries
V308-326	Clock	Smiths Industries
V3AM0	Output Gear	Thales Avionics
V44700-205-1	Solenoid Valve	Valcor
V44700-306	De-Oiling Solenoid Valve	Honeywell
V4AM0	Coupling Unit	Thales Avionics
V5000-220	Solenoid Valve	Valcor
V5000-232-1	Solenoid Valve	Valcor
V5AM0	Coupler	Thales Avionics
V6-4360	Fuse Self Resetting Valve	Circle Seal Controls
V6-4360-1	Fuse Self Resetting Valve	Circle Seal Controls
V6-4360-2	Fuse Self Resetting Valve	Circle Seal Controls
V99A13-001	Venturi Scavenge	Intertechnique
VA4110	Fwd Cargo Compartment Fan	Apparatebau Gaut.
VB6192	Water Tank	Extel Systems Wedel
VB6860	Water Tank	Extel Systems Wedel
VD3800	Mixed Flow Fan	Apparatebau Gaut.
VD3800-1	Mixed Flow Fan	Apparatebau Gaut.
VD3810	Mixed Flow Fan	Apparatebau Gaut.
VD3810-1	Mixed Flow Fan	Apparatebau Gaut.
VD3820	Mixed Flow Fan	Apparatebau Gaut.
VD3820MOD1	Mixed Flow Fan	Apparatebau Gaut.
VD3900-02	Recirculation Fan	Apparatebau Gaut.
VD3900-03	Recirculation Fan	Apparatebau Gaut.
VD3901-00	Recirculation Fan	Apparatebau Gaut.
VD3909-00	Recirculation Fan	Apparatebau Gaut.
VD3920	Extraction Fan	Apparatebau Gaut.
VD4100-02	Recirculation Fan	Apparatebau Gaut.
VD4100-03	Recirculation Fan	Apparatebau Gaut.
VD4100-04	Recirculation Fan	Apparatebau Gaut.
VF1620AA1	Overboard Extract Valve	Technofan
VF1620B00	Overboard Extract Valve	Technofan
VFT210	Skin Air Valve	Technofan
VFT210-1	Skin Air Valve	Technofan
VFT210A	Skin Air Valve	Technofan
VFT210A1	Skin Air Valve	Technofan
VFT210B00	Skin Air Valve	Technofan
VFT300A1	Skin Air Valve	Technofan
VFT300A1 Amdt A	Skin Air Valve	Technofan
VFT300A1 Amdt A-B	Skin Air Valve	Technofan
VFT300B00	Skin Air Valve	Technofan
VG10-00	Synchro Transmitter	Precilec
VG2-01	Speed Brake Transducer Box	Precilec
VHA698-006A	GEARBOX	LUCAS AEROSPACE
VIL0C3B	Fuel Pressure Indicator	Ametek
VIL0C3J	Fuel Pressure Indicator	Ametek
VIL0C4A	Oil Pressure Indicator	Ametek
VIL0C4E	Oil Pressure Indicator	Ametek
VIL-0CLA	OIL INDICATOR	AMETEK
VIL-OC3B	Fuel Pressure Indicator	Ametek
VIL-OC3C	Fuel Pressure Indicator	Ametek

Repair_Capability_List_Excel

VIL-OC3F	Fuel Pressure Indicator	Ametek
VIL-OC4A	Oil Pressure Indicator	Ametek
VIL-OC4C	Oil Pressure Indicator	Ametek
VIL-OC4E	Oil Pressure Indicator	Ametek
VIL-OC4F	Oil Pressure Indicator	Ametek
VIL-OC7B	Hydraulic Pressure Indicator	Ametek
VL32C11	Cargo Door Actuator	Messier-Bugatti
VL35A	Linear Actuator	Labinal
VL35A1	Linear Actuator	Labinal
VL35B	Linear Actuator	Labinal
VL35B1	Linear Actuator	Labinal
VL35B3	Linear Actuator	Labinal
VL35C	Linear Actuator	Labinal
VL35C1	Linear Actuator	Labinal
VL35D	Linear Actuator	Labinal
VL35D1	Linear Actuator	Labinal
VL35G	Linear Actuator	Labinal
VL35L	Linear Actuator	Labinal
VLO05030A	Actuator	Artus
VLO05030B	Actuator	Artus
VN1000	Spoiler Actuator	SAMM
VN1001	Spoiler Actuator	SAMM
VN1001-1	Spoiler Actuator	Goodrich Actuation Syst
VP1860AA0	Extract Valve	Technofan
VP1860C00	Extract Valve	Technofan
VR3910	Extraction Fan	Apparatebau Gaut.
VR7BH	Actuator	Labinal
VSDL-OC302C	Torque Indicator	Ametek
VSDL-OC302E	Torque Indicator	Ametek
VSL-OC112A	Stabilizer Position Indicator	Ametek
VSL-OC112B	Stabilizer Position Indicator	Ametek
VST170-1	Ventilation Valve	Technofan
VT-0107K	Hydraulic Pressure Transmitter	Ametek
VT0250A04	Turbofan Supply Valve	Technofan
VT0250AA1	Turbofan Supply Valve	Technofan
VT0250AA3	Turbofan Supply Valve	Technofan
VT-0304C	OPT	AMETEK
VT0304S	OIL PRESS TRANS	AMETEK VS GAUGE
VT0304S-1	OIL PRESS TRANS	AMETEK VS GAUGE
VT0361-1	Transmitter	Ametek
VT0361-71	Transmitter	Ametek
VT061-1	Transmitter	Diehl
VT061-2	Transmitter	Diehl
VT061-2MODA	Transmitter	Diehl
VT061-5	Transmitter	Diehl
VT061-7	Transmitter	Diehl
VT061-71	Transmitter	Diehl
VT061-71A	Transmitter	Diehl
VT061-71B	Transmitter	Diehl
VT061-9	Transmitter	Diehl
VT061-9A	Transmitter	Diehl
VT061-9B	Transmitter	Diehl
VT442	Quantity Indicator	VDO
VT442-2	Quantity Indicator	VDO
VT477	Quantity Indicator	VDO
VT477-1	Quantity Indicator	VDO
VT477-2	Quantity Indicator	VDO
VT477-3	Quantity Indicator	VDO

Repair_Capability_List_Excel

VT-O107B	Hydraulic Pressure Transmitter	Ametek
VT-O107F	Hydraulic Pressure Transmitter	Ametek
VT-O107H	Hydraulic Pressure Transmitter	Ametek
VT-O107K	Hydraulic Pressure Transmitter	Ametek
VT-O303C	Fuel Pressure Transmitter	Ametek
VT-O304C	Oil Pressure Transmitter	Ametek
VT-O304S	Oil Pressure Transmitter	Ametek
VT-O304S-1	Oil Pressure Transmitter	Ametek
VT-O306D	Oil/Fuel Pressure Transmitter	Ametek
VT-O306D-1	Oil/Fuel Pressure Transmitter	Ametek
VT-O306D-2	Oil/Fuel Pressure Transmitter	Ametek
W00007-405	Radio Switch Panel	Grimes Aerospace
W00011-813	Audio Accessory Unit	Grimes Aerospace
W00011-815	Audio Accessory Unit	Grimes Aerospace
W00011-817	Audio Accessory Unit	Grimes Aerospace
W00011-819	Audio Accessory Unit	Grimes Aerospace
W00011-821	Audio Accessory Unit	Grimes Aerospace
W00043-403	AC Current Sensor	Grimes Aerospace
W00081-813	Instrument Switching Unit	Grimes Aerospace
W10099-401	Audio Control Panel	Grimes Aerospace
W10099-407	Audio Control Panel	Grimes Aerospace
W10099-413	Audio Control Panel	Grimes Aerospace
W10099-415	Audio Control Panel	Grimes Aerospace
W10099-419	Audio Control Panel	Grimes Aerospace
W10099-421	Audio Control Panel	Grimes Aerospace
W10202-401	Central Annunciator Panel	Grimes Aerospace
W10202-402	Central Annunciator Panel	Grimes Aerospace
W10202-403	Central Annunciator Panel	Grimes Aerospace
W10202-405	Central Annunciator Panel	Grimes Aerospace
W10202-407	Central Annunciator Panel	Grimes Aerospace
W10202-409	Central Annunciator Panel	Grimes Aerospace
W10202-411	Central Annunciator Panel	Grimes Aerospace
W10202-413	Central Annunciator Panel	Grimes Aerospace
W10202-415	Central Annunciator Panel	Grimes Aerospace
W10202-417	Central Annunciator Panel	Grimes Aerospace
W10202-419	Central Annunciator Panel	Grimes Aerospace
W315T3800-1	Cowl Opening Actuator	Boeing
W315T3800-2	Cowl Opening Actuator	Boeing
W315T3800-3	Cowl Opening Actuator	Boeing
W315T3800-4	Cowl Opening Actuator	Boeing
WA761	Electrical Motor assy	Whittaker
WA8003	Electrical Actuator	Whittaker
WE3800770-1	Gearbox	Honeywell
WE3800770-2	Gearbox	Honeywell
WE3888439-1	Ignition Exciter	Honeywell
WE450-1D	Shut-Off Valve	Whittaker
WJ461250-1	Guide Module ay	Goodrich
WJ461310-1	Guide Torque Tube ay	Goodrich
WJ461310-2	Guide Torque Tube ay	Goodrich
WJ461310-3	Guide Torque Tube ay	Goodrich
WJ461310-4	Guide Torque Tube ay	Goodrich
WJ461310-5	Guide Torque Tube ay	Goodrich
WJ461310-6	Guide Torque Tube ay	Goodrich
WJ461313-1	Motor Control Housing ay	Goodrich
WJ461313-2	Motor Control Housing ay	Goodrich
WJ461313-3	Motor Control Housing ay	Goodrich
WJ461381-1	Latch ay	Goodrich
WJ461391-1	Latch ay	Goodrich

Repair_Capability_List_Excel

WJ461391-2	Latch ay	Goodrich
WJ461430-1	Latch ay	Goodrich
WJ461430-2	Latch ay	Goodrich
WKA-30110	Valve assy	Walter Kidde
WKA-30206	Cylinder assy	Walter Kidde
WKA-30342	Valve assy	Walter Kidde
WKA-31629	Cylinder assy	Walter Kidde
WKA-32914	Cylinder assy	Walter Kidde
WKA-32915	Valve assy	Walter Kidde
WKA-33318	Valve assy	Walter Kidde
WKA-33813	Valve assy	Walter Kidde
WKA-35831	Valve assy	Walter Kidde
WKA-36062	Valve assy	Walter Kidde
WKA-36268	Cylinder assy	Walter Kidde
WL101AMS1	Stand-by Airspeed Altimeter Indicator	Smiths Industries
WL101AMS2	Stand-by Airspeed Altimeter Indicator	Smiths Industries
WL101AMS5	Stand-by Airspeed Altimeter Indicator	Smiths Industries
WL101AMS6	Stand-by Airspeed Altimeter Indicator	Smiths Industries
WL101EED2	N1 RPM Indicator	Smiths Industries
WL101EED3	N1 RPM Indicator	Smiths Industries
WL102ACRBU5	Radiometer Pressure Indicator	Smiths Industries
WL102ACRCP3	Radiometer Pressure Indicator	Smiths Industries
WL102ACRCP4	Radiometer Pressure Indicator	Smiths Industries
WL102ACRCP5	Radiometer Pressure Indicator	Smiths Industries
WL102ACRCP7	Radiometer Pressure Indicator	Smiths Industries
WL102ACRCP9	Radiometer Pressure Indicator	Smiths Industries
WL102AMS1	Altitude / Airspeed Indicator	Smiths Industries
WL102AMS2	Altitude / Airspeed Indicator	Smiths Industries
WL102AMS3	Altitude / Airspeed Indicator	Smiths Industries
WL102AMS4	Altitude / Airspeed Indicator	Smiths Industries
WL102AMS5	Altitude / Airspeed Indicator	Smiths Industries
WL102AMS6	Altitude / Airspeed Indicator	Smiths Industries
WL103ACRBU2	Pressure Indicator	Smiths Industries
WL103ACRCP1	Pressure Indicator	Smiths Industries
WL103ACRMS3	Pressure Indicator	Smiths Industries
WL103ACRMS4	Pressure Indicator	Smiths Industries
WL103ACRMS5	Pressure Indicator	Smiths Industries
WL103ACRMS6	Pressure Indicator	Smiths Industries
WL103ACRMS7	Pressure Indicator	Smiths Industries
WL103ACRMS8	Pressure Indicator	Smiths Industries
WL104AMAJA1	Mach Airspeed Indicator	Smiths Industries
WL104AMAJA10	Mach Airspeed Indicator	Smiths Industries
WL104AMAJA2	Mach Airspeed Indicator	Smiths Industries
WL104AMAJA5	Mach Airspeed Indicator	Smiths Industries
WL104AMAJA6	Mach Airspeed Indicator	Smiths Industries
WL104AMAJA8	Mach Airspeed Indicator	Smiths Industries
WL104AMAJA9	Mach Airspeed Indicator	Smiths Industries
WL1058AMAJA25	Mach Airspeed Indicator	Smiths Industries
WL1058AMAJA34	Mach Airspeed Indicator	Smiths Industries
WL105AMAJA1	Mach Airspeed Indicator	Smiths Industries
WL105AMAJA10	Mach Airspeed Indicator	Smiths Industries
WL105AMAJA15	Mach Airspeed Indicator	Smiths Industries
WL105AMAJA17	Mach Airspeed Indicator	Smiths Industries
WL105AMAJA18	Mach Airspeed Indicator	Smiths Industries
WL105AMAJA19	Mach Airspeed Indicator	Smiths Industries
WL105AMAJA21	Mach Airspeed Indicator	Smiths Industries
WL105AMAJA22	Mach Airspeed Indicator	Smiths Industries
WL105AMAJA23	Mach Airspeed Indicator	Smiths Industries

Repair_Capability_List_Excel

WL105AMAJA24	Mach Airspeed Indicator	Smiths Industries
WL105AMAJA25	Mach Airspeed Indicator	Smiths Industries
WL105AMAJA26	Mach Airspeed Indicator	Smiths Industries
WL105AMAJA28	Mach Airspeed Indicator	Smiths Industries
WL105AMAJA29	Mach Airspeed Indicator	Smiths Industries
WL105AMAJA3	Mach Airspeed Indicator	Smiths Industries
WL105AMAJA30	Mach Airspeed Indicator	Smiths Industries
WL105AMAJA32	Mach Airspeed Indicator	Smiths Industries
WL105AMAJA33	Mach Airspeed Indicator	Smiths Industries
WL105AMAJA34	Mach Airspeed Indicator	Smiths Industries
WL105AMAJA35	Mach Airspeed Indicator	Smiths Industries
WL105AMAJA36	Mach Airspeed Indicator	Smiths Industries
WL105AMAJA37	Mach Airspeed Indicator	Smiths Industries
WL105AMAJA38	Mach Airspeed Indicator	Smiths Industries
WL105AMAJA4	Mach Airspeed Indicator	Smiths Industries
WL105AMAJA8	Mach Airspeed Indicator	Smiths Industries
WL105AMAJA9	Mach Airspeed Indicator	Smiths Industries
WL105AMAMS1	Mach Airspeed Indicator	Smiths Industries
WL105AMAMS12	Mach Airspeed Indicator	Smiths Industries
WL105AMAMS17	Mach Airspeed Indicator	Smiths Industries
WL105AMAMS45	Mach Airspeed Indicator	Smiths Industries
WL106AMA1	Mach Airspeed Indicator	Smiths Industries
WL106AMA2	Mach Airspeed Indicator	Smiths Industries
WL106AMA3	Mach Airspeed Indicator	Smiths Industries
WL106AMA31	Mach Airspeed Indicator	Smiths Industries
WL106AMA32	Mach Airspeed Indicator	Smiths Industries
WL106AMA44	Mach Airspeed Indicator	Smiths Industries
WL106AMA6	Mach Airspeed Indicator	Smiths Industries
WL107AMA1	Mach Airspeed Indicator	Smiths Industries
WL107AMA2	Mach Airspeed Indicator	Smiths Industries
WL107AMA3	Mach Airspeed Indicator	Smiths Industries
WL107AMA31	Mach Airspeed Indicator	Smiths Industries
WL107AMA4	Mach Airspeed Indicator	Smiths Industries
WL1101AMMS1	Servo Altimeter	Smiths Industries
WL1101AMMS10	Servo Altimeter	Smiths Industries
WL1101AMMS2	Servo Altimeter	Smiths Industries
WL1101AMMS3	Servo Altimeter	Smiths Industries
WL1101AMMS4	Servo Altimeter	Smiths Industries
WL1101AMMS7	Servo Altimeter	Smiths Industries
WL1101AMMS8	Servo Altimeter	Smiths Industries
WL1103AMMS1	Servo Altimeter	Smiths Industries
WL1103AMMS10	Servo Altimeter	Smiths Industries
WL1103AMMS13	Servo Altimeter	Smiths Industries
WL1103AMMS2	Servo Altimeter	Smiths Industries
WL1103AMMS3	Servo Altimeter	Smiths Industries
WL1103AMMS4	Servo Altimeter	Smiths Industries
WL1103AMMS7	Servo Altimeter	Smiths Industries
WL1103AMMS9	Servo Altimeter	Smiths Industries
WL1105AMMS1	Servo Altimeter	Smiths Industries
WL1105AMMS13	Servo Altimeter	Smiths Industries
WL1105AMMS2	Servo Altimeter	Smiths Industries
WL1105AMMS3	Servo Altimeter	Smiths Industries
WL1106AMMS2	Servo Altimeter	Smiths Industries
WL1106AMMS4	Servo Altimeter	Smiths Industries
WL1106AMMS5	Servo Altimeter	Smiths Industries
WL1106AMMS1	Servo Altimeter	Smiths Industries
WL1106AMMS2	Servo Altimeter	Smiths Industries
WL1106AMMS5	Servo Altimeter	Smiths Industries

Repair_Capability_List_Excel

WL1107AMMS1	Servo Altimeter	Smiths Industries
WL1107AMMS13	Servo Altimeter	Smiths Industries
WL1107AMMS3	Servo Altimeter	Smiths Industries
WL1108AMMS1	Servo Altimeter	Smiths Industries
WL1109AMMA1	Servo Altimeter	Smiths Industries
WL1109AMMA2	Servo Altimeter	Smiths Industries
WL1109AMMA3	Servo Altimeter	Smiths Industries
WL1109AMMS1	Servo Altimeter	Smiths Industries
WL1109AMMS2	Servo Altimeter	Smiths Industries
WL1109AMMS3	Servo Altimeter	Smiths Industries
WL1110AMMS1	Servo Altimeter	Smiths Industries
WL1110AMMS2	Servo Altimeter	Smiths Industries
WL1110AMMS3	Servo Altimeter	Smiths Industries
WL1110AMMS4	Servo Altimeter	Smiths Industries
WL1112AMMA1	Servo Altimeter	Smiths Industries
WL1112AMMA2	Servo Altimeter	Smiths Industries
WL1112AMMA3	Servo Altimeter	Smiths Industries
WL1112AMMA4	Servo Altimeter	Smiths Industries
WL1112AMMS1	Servo Altimeter	Smiths Industries
WL1112AMMS2	Servo Altimeter	Smiths Industries
WL1112AMMS3	Servo Altimeter	Smiths Industries
WL1112AMMS4	Servo Altimeter	Smiths Industries
WL1112AMMS5	Servo Altimeter	Smiths Industries
WL1113AMMA1	Servo Altimeter	Smiths Industries
WL1113AMMS1	Servo Altimeter	Smiths Industries
WL1113AMAJA1	Mach Airspeed Indicator	Smiths Industries
WL1113AMAJA2	Mach Airspeed Indicator	Smiths Industries
WL1113AMAJA5	Mach Airspeed Indicator	Smiths Industries
WL1113AMAJA7	Mach Airspeed Indicator	Smiths Industries
WL113AMAJA1	Mach Airspeed Indicator	Smiths Industries
WL113AMAJA2	Mach Airspeed Indicator	Smiths Industries
WL113AMAJA4	Mach Airspeed Indicator	Smiths Industries
WL113AMAJA5	Mach Airspeed Indicator	Smiths Industries
WL1150AMMA1	Servo Altimeter	Smiths Industries
WL1150AMMA2	Servo Altimeter	Smiths Industries
WL1150AMMA4	Servo Altimeter	Smiths Industries
WL1150AMMA5	Servo Altimeter	Smiths Industries
WL1150AMMS1	Servo Altimeter	Smiths Industries
WL1150AMMS2	Servo Altimeter	Smiths Industries
WL1150AMMS4	Servo Altimeter	Smiths Industries
WL1150AMMS5	Servo Altimeter	Smiths Industries
WL115AMAJA1	Mach Airspeed Indicator	Smiths Industries
WL115AMAJA3	Mach Airspeed Indicator	Smiths Industries
WL115AMAJA4	Mach Airspeed Indicator	Smiths Industries
WL118AMAJA1	Mach Airspeed Indicator	Smiths Industries
WL118AMAJA4	Mach Airspeed Indicator	Smiths Industries
WL120AMAJA1	Mach Airspeed Indicator	Smiths Industries
WL120AMAJA2	Mach Airspeed Indicator	Smiths Industries
WL120AMAJA4	Mach Airspeed Indicator	Smiths Industries
WL120AMAJA5	Mach Airspeed Indicator	Smiths Industries
WL120AMAJA6	Mach Airspeed Indicator	Smiths Industries
WL122AMAJA2	Mach Airspeed Indicator	Smiths Industries
WL122AMAJA3	Mach Airspeed Indicator	Smiths Industries
WL122AMAJA4	Mach Airspeed Indicator	Smiths Industries
WL122AMAJA5	Mach Airspeed Indicator	Smiths Industries
WL122AMAJA8	Mach Airspeed Indicator	Smiths Industries
WL122AMSJA2	Mach Airspeed Indicator	Smiths Industries
WL1350AMMS1	Counter Pointer Altimeter	Smiths Industries

Repair_Capability_List_Excel

WL1350AMMS2	Encoding Altimeter	Smiths Industries
WL1350AMMS3	Counter Pointer Altimeter	Smiths Industries
WL1350AMMS4	Counter Pointer Altimeter	Smiths Industries
WL1350AMMS5	Counter Pointer Altimeter	Smiths Industries
WL1350AMMS6	Counter Pointer Altimeter	Smiths Industries
WL1381AMMS1	Counter Pointer Altimeter	Smiths Industries
WL1381AMMS2	Counter Pointer Altimeter	Smiths Industries
WL1381AMMS3	Counter Pointer Altimeter	Smiths Industries
WL1381AMMS4	Counter Pointer Altimeter	Smiths Industries
WL1604AM1	Altimeter	Smiths Industries
WL1604AM2	Altimeter	Smiths Industries
WL1609AM1	Altimeter	Smiths Industries
WL1704AM1	Altimeter Indicator	Smiths Industries
WL1704AM3	Altimeter Indicator	Smiths Industries
WL1704AM5	Altimeter Indicator	Smiths Industries
WL1704AM6	Standby Altimeter	Smiths Industries
WL1704AM9	Counter Pointer Altimeter	Smiths Industries
WL2106KTDCP1	HP RPM Indicator	Smiths Industries
WL2107KTDCP1	RPM Indicator	Smiths Industries
WL2107KTDCP2	RPM Indicator	Smiths Industries
WL2108KTDCP1	RPM Indicator	Smiths Industries
WL2108KTDCP2	Indicator	Smiths Industries
WL246ASMS1	Standby Airspeed Indicator	Smiths Industries
WL271AS2	Standby Airspeed Indicator	Smiths Industries
WL300AS1	Airspeed Indicator	Smiths Industries
WL300AS3	Airspeed Indicator	Smiths Industries
WL300AS4	Airspeed Indicator	Smiths Industries
WL301RCMS3	Rate of Climb Indicator	Smiths Industries
WL301RCMS4	Rate of Climb Indicator	Smiths Industries
WL304RC1	Cabin Vertical Speed Indicator	Smiths Industries
WL305RC1	Cabin Vertical Speed Indicator	Smiths Industries
WL501RC1	Rate of Climb Indicator	Smiths Industries
WL501RC-1	Rate of Climb Indicator	Smiths Industries
WL502RC1	Rate of Climb Indicator	Smiths Industries
WL502RC-1	Rate of Climb Indicator	Smiths Industries
WL503RC1	Rate of Climb Indicator	Smiths Industries
WL503RC-1	Rate of Climb Indicator	Smiths Industries
WL506AMAJA10	Mach Airspeed Indicator	Smiths Industries
WL506AMAJA11	Mach Airspeed Indicator	Smiths Industries
WL506AMAJA9	Mach Airspeed Indicator	Smiths Industries
WL508AMA1	Mach Airspeed Indicator	Smiths Industries
WL508AMA2	Mach Airspeed Indicator	Smiths Industries
WL509AMA1	Mach Airspeed Indicator	Smiths Industries
WL510CUEA2	Preselector	Smiths Industries
WL510CUFEA2	Altimeter Alerter	Smiths Industries
WL701AMFA1	Servo Altimeter	Smiths Industries
WL701AMFA2	Servo Altimeter	Smiths Industries
WL702TSAEA1	Synchro Indicators	Smiths Industries
WL702TSAEA2	Synchro Indicators	Smiths Industries
WL704AMFA1	Servo Altimeter	Smiths Industries
WL704AMFA2	Servo Altimeter	Smiths Industries
WL704AMMSA3	Servo Altimeter	Smiths Industries
WL707AMFA1	Servo Altimeter	Smiths Industries
WL707AMFA2	Servo Altimeter	Smiths Industries
WL707AMFA4	Servo Altimeter	Smiths Industries
WL708AMFA1	Servo Altimeter	Smiths Industries
WL708AMFA2	Servo Altimeter	Smiths Industries
WL710AM/MS/2	Servo Altimeter	Smiths Industries

Repair_Capability_List_Excel

WL710AMMS2	Servo Altimeter	Smiths Industries
WL731MVFA1	Engage & Trim Indicator	Smiths Industries
WL731MVFA2	Engage & Trim Indicator	Smiths Industries
WL751AMFA/1	Servo Altimeter	Smiths Industries
WL751AMFA1	Servo Altimeter	Smiths Industries
WL753FA1	Servo Altimeter	Smiths Industries
WL801AMCP1	Altimeter	Smiths Industries
WL801AMMS6	Altimeter	Smiths Industries
WL802AMCP1	Altimeter	Smiths Industries
WL804AMCP1	Altimeter	Smiths Industries
WL806AMCP1	Altimeter	Smiths Industries
WL807AMCP1	Altimeter	Smiths Industries
WL808AMEA1	Altimeter	Smiths Industries
WL808AMEA2	Altimeter	Smiths Industries
WL809AMMS2	Altimeter	Smiths Industries
WL810AMMS1	Altimeter	Smiths Industries
WL820AMMS1	Altimeter	Smiths Industries
WL820AMMS2	Altimeter	Smiths Industries
WL820AMMS4	Altimeter	Smiths Industries
WL820AMMS5	Altimeter	Smiths Industries
WL820AMMS6	Altimeter	Smiths Industries
WL820AMMS7	Altimeter	Smiths Industries
WL820AMMS8	Altimeter	Smiths Industries
WL841AMMS1	Altimeter	Smiths Industries
WL841AMMS2	Altimeter	Smiths Industries
WL841AMMS3	Altimeter	Smiths Industries
WL841AMMS4	Altimeter	Smiths Industries
WL842AMMS1	Altimeter	Smiths Industries
WL842AMMS2	Altimeter	Smiths Industries
WL852AMMS1	Altimeter	Smiths Industries
WL852AMMS2	Altimeter	Smiths Industries
WL855AMMS1	Altimeter	Smiths Industries
WL855AMMS2	Altimeter	Smiths Industries
WL856AMMS1	Altimeter	Smiths Industries
WL862AMMS1	Altimeter	Smiths Industries
WL862AMMS2	Altimeter	Smiths Industries
WL862AMMS3	Altimeter	Smiths Industries
WL862AMMS4	Altimeter	Smiths Industries
WL862AMMS5	Altimeter	Smiths Industries
WL862AMMS7	Altimeter	Smiths Industries
WLMVMS5	Pressure Indicator	Smiths Industries
WN23BYB3YS10006	Cabin Attendant Seat	Sicma Aero Seat
WN23BYF4YS00008	Cabin Attendant Seat	Sicma Aero Seat
WN25BYB3YS00006	Cabin Attendant Seat	Sicma Aero Seat
WN25BYB3YS00014	Cabin Attendant Seat	Sicma Aero Seat
WN25BYB3YS00041	Cabin Attendant Seat	Sicma Aero Seat
WN25BYF4YS00008	Cabin Attendant Seat	Sicma Aero Seat
WN93BYB3YS00006	Cabin Attendant Seat	Sicma Aero Seat
WN93BYB3YS00014	Cabin Attendant Seat	Sicma Aero Seat
WN93BYB3YS00041	Cabin Attendant Seat	Sicma Aero Seat
WN93BYB3YS10006	Cabin Attendant Seat	Sicma Aero Seat
WN93BYF4YS00008	Cabin Attendant Seat	Sicma Aero Seat
XD0260-01001	Pressure Transducer	.
XW20101-F28	Wiper assy	Alco Controls
XW20345-360-50	Converter assy	Rosemount
XW20891-150-75	Wiper assy	Rosemount Aerospace
XW21132-11	Electrical Motor assy	Rosemount
XW21132-21	Electrical Motor assy	Rosemount

Repair_Capability_List_Excel

XW21871-360-50	Wiper Converter	Alco Controls
XW21872-11	Electrical Motor assy	Rosemount
XW21872-21	Electrical Motor assy	Rosemount
XW23513-7	Windshield Wiper Motor Converter	Rosemount
XW23513-8	Windshield Wiper Motor Converter	Rosemount
Y005-2	Transformer Rectifier	Artus
Y005-3	Transformer Rectifier	Artus
Y025	Rudder Trim Indicator	Valentin
Y025-01	Rudder Trim Indicator	Valentin
Y495MK-8	Hydraulic Motor Pump	Goodrich Control Systems
Y695MK-5	Hydraulic Motor Pump	Goodrich Control Systems
Y770MK-3	Hydraulic Motor Pump	Goodrich Control Systems
Y770MK-4	Hydraulic Motor Pump	Goodrich Control Systems
Y780MK-1	Hydraulic Motor Pump	Goodrich Control Systems
Y787MK-1	Hydraulic Motor Pump	Goodrich Control Systems
Y85540	Hydraulic Motor	Goodrich
YG101-02	Y Guide	Valentin
YG101-03	Y Guide	Valentin
YG101-04	Y Guide	Valentin
YG102-02	Y Guide	Valentin
YG102-03	Y Guide	Valentin
YG102-04	Y Guide	Valentin
Z111H0020110	Attendant Indication Panel	Kid Systeme
Z111H0020112	Attendant Indication Panel	Kid Systeme
Z111H0023112	Attendant Indication Panel	Kid Systeme
Z111H0023151	Attendant Indication Panel	Kid Systeme
Z111H0030151	Attendant Indication Panel	Kid Systeme
Z111H0033151	Attendant Indication Panel	Kid Systeme
Z120H0022110	Aft Attendant Panel	Kid Systeme
Z120H0024110	Aft Attendant Panel	Kid Systeme
Z120H0026110	Aft Attendant Panel	Kid Systeme
Z120H0029110	Aft Attendant Panel	Kid Systeme
Z120H0035110	Aft Attendant Panel	Kid Systeme
Z120H0036110	Aft Attendant Panel	Kid Systeme
Z120H0045110	Aft Attendant Panel	Kid Systeme
Z120H0061111	Aft Attendant Panel	Kid Systeme
Z120H0063112	Aft Attendant Panel	Kid Systeme
Z120H0071112	Aft Attendant Panel	Kid Systeme
Z120H0073112	Aft Attendant Panel	Kid Systeme
Z121H0002110	Additional Attendant Panel	Kid Systeme
Z121H0006110	Additional Attendant Panel	Kid Systeme
Z121H0018110	Additional Attendant Panel	Kid Systeme
Z121H0034110	Additional Attendant Panel	Kid Systeme
Z121H0038110	Additional Attendant Panel	Kid Systeme
Z121H0050110	Additional Attendant Panel	Kid Systeme
Z121H0056110	Additional Attendant Panel	Kid Systeme
Z121H0080110	Additional Attendant Panel	Kid Systeme
Z121H0084110	Additional Attendant Panel	Kid Systeme
Z121H0086110	Additional Attendant Panel	Kid Systeme
Z121H0092110	Additional Attendant Panel	Kid Systeme
Z121H0094110	Additional Attendant Panel	Kid Systeme
Z130H0022110	Fwd Attendant Panel	Kid Systeme
Z130H0024110	Fwd Attendant Panel	Kid Systeme
Z130H0052110	Fwd Attendant Panel	Kid Systeme
Z130H0054110	Fwd Attendant Panel	Kid Systeme
Z130H0065110	Fwd Attendant Panel	Kid Systeme
Z130H0069110	Fwd Attendant Panel	Kid Systeme
Z130H0081110	Fwd Attendant Panel	Kid Systeme

Repair_Capability_List_Excel

Z130H0085110	Fwd Attendant Panel	Kid Systeme
Z130H0101110	Fwd Attendant Panel	Kid Systeme
Z130H0114110	Fwd Attendant Panel	Kid Systeme
Z130H0130110	Fwd Attendant Panel	Kid Systeme
Z130H0132110	Fwd Attendant Panel	Kid Systeme
Z130H0133110	Fwd Attendant Panel	Kid Systeme
Z130H0134110	Fwd Attendant Panel	Kid Systeme
Z130H0163110	Fwd Attendant Panel	Kid Systeme
Z130H0185110	Fwd Attendant Panel	Kid Systeme
Z130H0199110	Fwd Attendant Panel	Kid Systeme
Z130H0200110	Fwd Attendant Panel	Kid Systeme
Z130H0201110	Fwd Attendant Panel	Kid Systeme
Z130H0235110	Fwd Attendant Panel	Kid Systeme
Z131H0416114	Fwd Attendant Panel	Kid Systeme
Z211H0000110	Control Unit	Deutsche Airbus
Z211H0001110	Control Unit	Deutsche Airbus
Z212H0000110	Control Unit	DA-Kid Systeme
Z212H0001110	Control Unit	DA-Kid Systeme
Z212H0002110	Control Unit	DA-Kid Systeme
Z212H0004110	Control Unit	Kid Systeme
Z220H0000110	Control Unit	DA-Kid Systeme
Z220H0001110	Control Unit	DA-Kid Systeme
Z220H0002110	Control Unit	DA-Kid Systeme
Z272H0000110	Master Control Unit	Kid Systeme
ZCV212	Check Valve	Circle Seal Controls
ZCV212G	Check Valve	Circle Seal Controls
ZCV212H	Check Valve	Circle Seal Controls
ZCV63-4	Non-Return Valve	Circle Seal Controls
ZCV63-6	Non-Return Valve	Circle Seal Controls
ZCV63-8	Non-Return Valve	Circle Seal Controls
ZCV64-10	Non-Return Valve	Circle Seal Controls
ZCV64-12	Non-Return Valve	Circle Seal Controls
ZCV64-16	Non-Return Valve	Circle Seal Controls
ZCV64-20	Non-Return Valve	Circle Seal Controls
ZCV66	Non-Return Valve	Circle Seal Controls
ZCV67	Non-Return Valve	Circle Seal Controls
ZRA1410030	Pressure Transducer	Labem
ZRA1990030	Pressure Transducer	Labem